

# USER MANUAL

---

Version 1.02 - February 2014



XNet.Monitor





## Copyright

EVS Broadcast Equipment SA– Copyright © 2009-2013. All rights reserved.

## Disclaimer

The information in this manual is furnished for informational use only and subject to change without notice. While every effort has been made to ensure that the information contained in this user manual is accurate, up-to-date and reliable, EVS Broadcast Equipment cannot be held responsible for inaccuracies or errors that may appear in this publication.

## Improvement Requests

Your comments will help us improve the quality of the user documentation. Do not hesitate to send improvement requests, or report any error or inaccuracy on this user manual by e-mail to [doc@evs.com](mailto:doc@evs.com).

## Regional Contacts

The address and phone number of the EVS headquarters are usually mentioned in the Help > About menu in the user interface.

You will find the full list of addresses and phone numbers of local offices either at the end of this user manual (for manuals on hardware products) or at the following page on the EVS website: <http://www.evs.com/contacts>.

## User Manuals on EVS Website

The latest version of the user manual, if any, and other user manuals on EVS products can be found on the EVS download center, on the following webpage: <http://www.evs.com/downloadcenter>.

# Table of Contents

<b>TABLE OF CONTENTS</b>	<b>II</b>
<b>WHAT'S NEW?</b>	<b>V</b>
<b>1. INTRODUCTION</b>	<b>1</b>
1.1. Product Overview	1
1.2. Installation	1
1.3. User Interface Overview	2
1.4. Menu Bar	4
<b>2. CONFIGURATION</b>	<b>5</b>
2.1. Network Settings	5
2.2. Monitoring Configuration	5
2.2.1. Description of the Monitored Device Tree	5
2.2.2. Organizing Monitored Devices	6
2.2.3. Managing the Monitored Device Tree	8
2.2.4. Customizing the Monitoring List	8
2.3. Trap Configuration	10
2.3.1. Description of the Trap Configuration Window	10
2.4. SNMP and General Settings	12
<b>3. MONITORING</b>	<b>14</b>
3.1. Start Monitoring	14
3.2. Monitoring List	15
3.2.1. Description of the Monitoring List	15
3.2.2. Fields in the Monitoring List	16
3.3. Server Details	17
3.3.1. Overview on the Server Details Area	17
3.3.2. Status Tab	17
3.3.3. Storage Tab	22
3.3.4. Hardware Tab	26
3.3.5. Codes Tab	27
3.3.6. MIB Browser Tab	27
3.4. Device Details	28
3.5. Extracting SNMP Information	30
3.6. Alert Messages	31
3.6.1. Managing Alerts	31
3.6.2. List of Possible Alerts	32
3.7. Disk Usage	40



**4. SERVER MAINTENANCE TASKS .....41**

4.1. Multicam Upgrades .....41

    4.1.1. Installing a Multicam Version .....41

    4.1.2. Removing a Multicam Version .....42

4.2. Remote Access to an EVS Server .....43

    4.2.1. Accessing Remotely a Server Desktop .....43

    4.2.2. Accessing the Multicam Web Setup .....44

    4.2.3. Accessing Remotely an LSM Remote Panel .....44

    4.2.4. Rebooting an EVS Server .....45

4.3. Uploading a Keyword File on an EVS Server .....46

4.4. Server Logs Extraction .....46



# What's New?

In the XNetWebMonitorTechnical Reference manual, the icon **NEW !** has been added on the left margin to highlight information on new and updated features.

The changes linked to new features in version 1.02 are listed below:

## **New fields and modified fields in the Status tab in the Server Details area**

- See section "Status Tab" on page 17.

## **New field in the Hardware tab**

- See section "Hardware Tab" on page 26.

The user manual has been restructured and reviewed since the last published version (version 1.01).

The following change is not related to a new feature:

## **New section on network settings**

- See section "Network Settings" on page 5.





# 1. Introduction

## 1.1. Product Overview

XNetMonitor is a tool aimed at monitoring EVS products. It displays real time information and status about the EVS video servers and other EVS products, as well as past alert and warning messages.

XNetMonitor uses the SNMP (Simple Network Management Protocol) protocol to request and receive monitoring data from the EVS servers. This internal status data is defined in the MIB (Management Information Base) on each EVS server.

One XNetMonitor application can monitor several EVS servers while one EVS server may also be monitored by several XNetMonitor applications.

XNetMonitor is mainly a monitoring application that cannot act on the monitored servers. Some remote actions are however possible: Multicam version upgrade, keyword file maintenance, as well as remote access to an EVS server desktop, or to an LSM Remote Panel.

## 1.2. Installation

### Requirement

- PC compatible computer
- Supported OS: Windows XP, Windows Vista, Windows 2003 Server, Windows 7
- .Net framework 3.0 or higher installed

### Recommendation

The SNMP information is available through the PC LAN connector of the server. The XNetMonitor running computer should be connected to the same network, and not on any of the Gigabit Ethernet ports of the servers. These ports are dedicated to high flow video data and cannot be used for any other purpose.

### Installation

XNetMonitor is delivered as a single executable file.

To install the program, run this installation file. During the installation, a warning will be displayed if .Net framework is not installed on your computer. In this case, you should manually install this.

If you need to install the .Net framework, double-click the DotNet 3.5 SP1 Install3.bat file, which is delivered with the XNetMonitor executable file.

During XNetMonitor installation, the only required parameter is the installation path for the application. If you want to change the default one, enter the desired path.

Once the application is installed it can be executed immediately.

## Upgrade and Downgrade


If an older version of XNetMonitor is already installed on your computer, it will be automatically removed and replaced by the new one when you will install the new version of XNetMonitor.

The XNetMonitor application must only be removed if you need to downgrade the application. Removing the application can be done as usual, through Windows Control Panel and Add or Remove Programs menu.

## 1.3. User Interface Overview

### Introduction

When you access XNetMonitor, the main window is displayed. The schema below highlights the various areas on the main window.



## Area Description

The table below describes the various parts of the XNetMonitor main window:

#	Window area	Description
1.	Menu bar	Gives access to various functions. See section "Menu Bar" on page 4.
2.	Monitored Device tree	It displays the monitored devices in a user-defined tree architecture. See section "Description of the Monitored Device Tree" on page 5.
3.	Monitoring Data area	It can display different data depending on what is selected in the <b>Monitored Device Tree</b> : <ul style="list-style-type: none"> <li>Detailed information on the selected EVS server. The area is then called the <b>Server Details</b> area. See section "Overview on the Server Details Area" on page 17</li> <li>Detailed information when another EVS hardware is selected. The area is then called the <b>Device Details</b> area. See section "Device Details" on page 28.</li> <li>Summary information on several devices when a group of devices is selected. The area is then called the <b>Monitoring List</b> area. See section "Description of the Monitoring List" on page 15</li> </ul>
4.	Alert Information area	Area that allows users to display and acknowledge the alerts. See section "Managing Alerts" on page 31
5.	Disk Usage	Displays a pie chart with the totalized used and left disk space for the selected devices(s).
6.	Status bar	Status information about the monitoring status.

## 1.4. Menu Bar

### General Description

The menu bar gives access to various functions. You will find below a short description of the menu items.

### Area Description

The following table presents the items on the menu bar:

Menu	Description
<b>File</b> menu	Allows you to manage the EVS servers and other EVS devices stored in the Monitor Device tree. See section "Managing the Monitored Device Tree" on page 8
<b>Tools</b> menu	Gives you access to the following configuration tools and settings: <ul style="list-style-type: none"><li>• "Customizing the Monitoring List" on page 8</li><li>• "Organizing Monitored Devices" on page 6</li><li>• "SNMP and General Settings" on page 12</li><li>• "Trap Configuration" on page 10</li></ul> Gives you access as well as to the commands to manage Multicam versions and keyword files on the EVS servers: <ul style="list-style-type: none"><li>• "Multicam Upgrades" on page 41</li><li>• "Uploading a Keyword File on an EVS Server" on page 46</li></ul>
<b>Monitoring</b> menu	Allows you to start or stop the monitoring on the EVS servers and devices displayed in the <b>Monitored Device Tree</b> . See section "Start Monitoring" on page 14
<b>Help</b> menu	Gives you access to the user manual and information about the application.

## 2. Configuration

### 2.1. Network Settings

#### Introduction

Should you face issues to set up XNetMonitor in your network, and should a network configuration be required, you will find the necessary network information in this section.

#### Description

##### Monitoring

- Monitoring protocol :SNMP
- Communication for the polling : TCP on port 161 (bidirectional)
- Communication of the SNMP traps : UDP on port 162 (outbound out of the server only)

##### Remote desktop and LSM Remote functions

- TCP 50000 (bidirectional)

##### Config Web


- Communication in HTTP on port 80 (bidirectional)

### 2.2. Monitoring Configuration

#### 2.2.1. Description of the Monitored Device Tree

##### Introduction

The **Monitoring Devices Tree** displays the devices monitored on the network. They are listed in a tree architecture independent of the network architecture as shown on the screenshot below. The Monitoring list is defined by the user.



## XNet Node

The higher node is called **XNet** as it represents the EVS XNet proprietary network. Under this first level node, you must add one or more groups. These groups are only virtual groups used for easy organization and management of multiple servers.

## Groups

The groups are defined by the user. The group definition is not tied to the network architecture: this is only a virtual layout the user can organize freely. For easier management, it is recommended to organize the groups based on physical localization of the devices.

## Hosts

The hosts are the monitored devices themselves. You can create them manually or automatically as explained in See section "Organizing Monitored Devices" on page 6.

## Status Summary

In the Monitored Device Tree, a colored bullet displayed next to the group or device provides a summary of the device status, and has the following meaning:

- A red bullet means that there is a warning and/or an error on a host.
- A green bullet means that everything is ok for that item.

The number between brackets next to an item indicates the number of pending SNMP alert messages.

## 2.2.2. Organizing Monitored Devices

### Introduction

To organize the monitored devices in the Monitoring List, you first have to create groups under the XNet node. Then, you can add the monitored devices under the created groups, either manually or automatically.

## How to Add and Remove Groups

For an easy management, it is recommended to organize the groups based on physical localization of servers.

To add a new group, proceed as follows:


1. Right-click on the XNet node and select **Add group**.
2. Enter a representative group name.

To remove a group, right-click on it and select **Remove**.

## How to Add Devices Manually

To add individual devices manually, proceed as follows:

1. Right-click on a group and select **Add host**.
2. Enter the device IP address in the Host Definition window.




Once the devices are entered in the list manually, you can organize them in the different groups by drag-and-drop operation.

## How to Add Devices Automatically

1. Open the **Tools** menu and select **Discover**.

The Discover SNMP Agents window opens



2. In this window, set the IP address range in which the program will look for available devices.
3. Click the **Start** button to start the discovery process.

At the end of this process, the discovered devices will be listed in a new group called **Discovered Hosts**.

Once the devices are entered through the discovery process, you can organize them in the different groups by drag-and-drop operation.

**Note**

As this process is based on timeout for not used addresses, it may take some time to parse a long list.

## How to Remove a Device

You can only remove a device when the monitoring is not started.

To remove a host, right-click on it and select the **Remove** command.

## 2.2.3. Managing the Monitored Device Tree

From the **File** menu, commands make it possible to manage the device and server list available in the **Monitored Device Tree**. This list is saved as an .xml file for future use and/or for transfer to another monitoring computer. This allows easy sharing and management synchronization of servers and hosts tree organization.

The following commands are available in the **File** menu.

Parameter	Description
<b>New</b>	To create a new virtual architecture from scratch.
<b>Open</b>	To open an existing architecture saved as an xml file.
<b>Save</b>	To save the currently open architecture xml file.
<b>Save As</b>	To save the currently open architecture xml file as a new file.
<b>Exit</b>	To close and exit XNetMonitor

## 2.2.4. Customizing the Monitoring List

### Introduction

When you select XNet or a group in the Monitored Device Tree, the Monitoring Data pane displays the **Monitoring List**, which provides summary data about the servers available under XNet or under the selected group.


You can specify which information should be displayed in the Monitoring List and how it should be displayed via the Select Columns window.



## How to Customize the Data

To customize the summary monitoring data, proceed as follows:

1. In the Monitoring Data pane, select the **Organize Columns** command from the **Tools** menu.
2. The **Select Columns** window opens:



3. Do one of the following actions:
  - To add a column to the display, select it in the left **Available columns** list and click on the **Insert** button.
  - To remove a column from the display, select it in the right **Selected Columns** list and click on the **Remove** button.
  - To change the columns order, select a column name in the right **Selected Columns** list and move it up or down in the list using the **Up** and **Down** buttons respectively.
4. Click on **OK** once the columns are organized as desired.

## 2.3. Trap Configuration

### 2.3.1. Description of the Trap Configuration Window


#### Overview

You can access Trap Configuration window by selecting the **Tools** menu, and the **Trap Configuration** command.

The Trap Configuration window displays the host tree (EVS servers or other EVS hardware). For each host, the list of IP addresses of the computers registered to the host to receive its SNMP trap messages. Such a computer is called a trap target.



The trap targets can be computers that host the XNetMonitor application or a polling service of XNetWebMonitor.

The Trap Configuration window contains the areas or buttons highlighted on the screenshot below:



#### Area Description

The table below describes the various parts of the Trap Configuration window:

Part	Name	Description
1.	Host tree	List of the monitored devices to which XNetMonitor applications can be registered.
2.	<b>LocalIP</b> column	Trap status of the local IP address: <ul style="list-style-type: none"> <li>• If the IP address is registered to receive the trap messages, the cell will appear as .</li> <li>• If the IP address is not registered to receive the trap messages, the cell will appear as .</li> </ul>
3.	<b>IP Addresses</b> columns	List of all IP addresses of computers (max. 10 per host) registered as trap targets to the corresponding host.
4.	<b>Add Local IP</b> button	Button that allows administrators to add the current XNetMonitor IP Address on the monitored server.
5.	<b>Remove</b> button	Button that allows administrators to remove, in one go, a trap target from all hosts it is registered to. This button is used in combination with the drop-down list on the left hand side, which allows the selection of the trap target to be removed.
6.	<b>Trap Registration</b> status bar	The status field and progress bar at the bottom of the window display the currently executed command and its progress status.

## 2.4. SNMP and General Settings

### Introduction

In the **Settings** command in the **Tools** menu, you can set following parameters.

Click **OK** once the parameters are properly configured for your application.

### Field Description

Parameter	Description
<b># Local Clip Threshold</b>	When this number of clips is reached on a machine, a message will be displayed to warn the user that a cleaning and purge will soon be necessary on that server.
<b>Rem. Cap. Threshold</b>	Same warning as the previous one but based on the server remaining storage capacity.
<b>SNMP Polling Period</b>	Wait time between polling. A small period will guarantee fast refreshing of data but will request high data flow on the network while a long period will display less up-to-date data but will reduce the load on the network.
<b>SNMP Time Out</b>	Delay after which a host will be considered as not responding. An alert message will be displayed in the event log if such an event happens for a monitored host. The automatic discovery process total duration depends on this parameter.
<b>Enable Gigabit ICMP Polling</b>	Enables the pinging of the Servers GBE ports.

Parameter	Description
<b>ICMP Time Out</b>	Time Out for the pinging of the Servers GBE ports
<b>Enable Server Reboot</b>	If this option is enabled, XNetMonitor will be able to initiate a reboot of any monitored server through the <b>Reboot</b> command in the contextual menu opened by right-clicking on a host in the Monitored Device Tree.
<b>Enable SNMP Log</b>	If this option is enabled, XNetMonitor will keep a log file with all SNMP messages.
<b>Enable Server Explorer</b>	Enables the <b>Explore</b> option from the Server Name contextual menu in the Monitored Devices Tree. The Explore option opens a ftp session on the server.
<b>Enable LSM Remote</b>	Enables the <b>LSM Remote</b> option from the Server Name contextual menu in the Monitored Device Tree.
<b>Server Log Target Directory</b>	Path to the directory used to store the SNMP log files.
<b>Temp. Unit</b>	Unit in which the temperature is expressed.

## 3. Monitoring

### 3.1. Start Monitoring

Once servers and hosts have been added in the groups, the monitoring is started by clicking on the **Start** command in the Monitoring menu.

To stop the monitoring once it is running, simply click on the **Stop** command in the same Monitoring menu.

The monitoring status is available in the status bar at the bottom of the XNetMonitor window.



- 'Polling not started' means that the monitoring has not been started yet since the application launch.
- 'Polling' followed by IP address means status data are presently read from the selected host MIB.
- 'Waiting x/y sec' indicates that the monitor is waiting for next polling process. It has already been waiting for x seconds out of a total of y seconds (according to related parameter setting).
- 'Polling ended' means that the monitoring has been stopped by the user. At monitoring restart, hosts will be immediately polled and the waiting period will be reset.



#### Note

When you start up XNetMonitor, the monitoring is always stopped and must be started manually using the Start command.


## 3.2. Monitoring List

### 3.2.1. Description of the Monitoring List

#### Overview

The Monitoring List area shows the groups of EVS servers and other EVS hardware, their status, and a set of parameters on each hardware.

The Monitoring List pane contains the areas highlighted on the screenshot below:



Name	SN	Soft. Rev.	State	Genlock	Analog LTC	Disk	PSU	XNE
<b>Discovered Hosts</b>								
XTNewADL	24940	12.02.35	Running	Valid bl...	Valid	OK (0 sp)	OK	Not
XTNewPGE	25120	12.02.35	Running	Valid bl...	Valid	OK (0 sp)	OK	Not
EPSIOA015530								
IPDA184130	Unk...	2.0.2.0	Unknown					
IPDA184130	Unk...	2.3.121.0	Running					
IPDA184130	Unk...	2.0.37.0	Running					
IPDA184130	Unk...	2.0.28.0	Running					
IPDA184130	100...	6.40.12.0	Running					

#### Area Description

The table below describes the various parts of Monitoring List area:

Part	Name	Description
1.	Column heading	Type of information available in the given column. The columns available in the Monitoring List are selected and ordered as defined in the section "Customizing the Monitoring List" on page 8.
2.	Group node	Name of the device or server group as defined in the Monitored Device Tree.
3.	Server List	Information on EVS servers and other EVS hardware belonging to a group. For more details on the fields available in this section, "Fields in the Monitoring List" on page 16. Clicking on a row corresponding to an EVS server or other hardware will display the detailed information on this host in the Server Details area.

## 3.2.2. Fields in the Monitoring List

The list of fields described in the table below is not exhaustive. It includes the fields available in the default display:

Name	Description
Name	<p>It indicates the name of the EVS server.</p> <p>The name displayed is assigned in the following order of priority, based on whether a value is assigned or not: facility name, net name or IP address.</p> <p>A color circle in front of the EVS server indicates its status:</p> <ul style="list-style-type: none"> <li>• green: no active alert present for the server</li> <li>• red: at least an active alert present for the given server</li> <li>• gray: XNet Web cannot retrieve information with the SNMP protocol.</li> </ul>
SN	It specifies the server's unique serial number.
Soft Rev.	It specifies the server software revision.
State	<p>It indicates the functional status of the EVS server or other EVS hardware.</p> <p>The possible statuses are 'Running', 'Initializing', 'In Maintenance' or 'Halted'.</p>
Genlock	It indicates the presence or absence of Genlock synchronization signal, and its type.
Analog LTC	It indicates the status of LTC (Longitudinal Time Code) analogue signal.
Disk	It indicates the disk connection status, and the number of spare disks.
PSU	It specifies the status of the power supply units.
XNet Status	It indicates the status of the SDTI network connection.
Traffic	It indicates the network traffic status.
DB Status	It indicates the status of the server database.
Loc Clips	It specifies the number of clips stored on the server.
Rem. Capacity	It indicates the remaining recording capacity on the EVS server in hours, and percentage.



## 3.3. Server Details

### 3.3.1. Overview on the Server Details Area

The Server Details area is located on the right hand side of the Monitored Device List.

When you select an EVS server in the Monitored Device List, the **Server Details** area provides detailed information on the selected server.

This information is organized in four tabs, which are themselves organized in different group boxes:

Tab Name	Included field groups
<a href="#">Status</a>	General information, data about A/V, network, controllers, GigE connections, and channels
<a href="#">Storage</a>	Information on disk capacity, array definition, disk numbers, and disk models
<a href="#">Hardware</a>	List of the boards fitted on the EVS server
<a href="#">Codes</a>	List of Codes installed on the EVS server
<a href="#">MIB Browser</a>	View on the MIB (Management Information Base)

When you select another EVS hardware in the Monitored Device List, the **Device Details** area provides data on the selected hardware, its drives and communication interfaces. See section "Device Details" on page 28 for more information.

### 3.3.2. Status Tab

#### Overview

In the Status tab, the main parameters are organized in several group boxes as shown on the following figure.

Status

Storage

Hardware

Codes

Mib Browser

General

Type: [XT3] 6U

Facility Name:

Base Config: [MulticamLSM]

Serial Number: [113640]

Version: [12.05.09]

State: [Running]

PSU: [OK]

Genlock: [Valid blackburst]

LTC: [Valid]

Local Clips: [0]

Net Clips: [0]

Rem. Capacity: [21:02:45 [99%]]

Clip Capacity: [Global]

Loop Recording: [On]

Up Time: [2 days, 22:40:42.37]

Date Time: [2016-10-09 21:32:41]

Sync PC to TC: [Yes]

Period: [00:15:00]

PC free disk space: [1528 MB]

DB Status: [Ok]

Rec Train Expiration: [991 days 07:22:47]

Audio-Video

AV Channels: [4in 4out 8audio]

Video Std: [1080 PAL]

Codec Config: [Intra+Lo-Res]

On Air Codec: [DVCPRO HD]

Intra Codec: [DVCPRO HD]

Intra Bit Rate: [100 Mbps]

LongGOP Codec: [Not applicable]

LongGOP Bit Rate: [Not applicable]

Lo-Res Codec: [Mjpeg]

Lo-Res Bit Rate: [5 Mbps]

Network

SDTI: [Off]

Net # - Name: [4 - ST02\_M04]

Net Type (Cfg): [NotApplicable(Server)]

Clip Edit by network: [No]

XNet Status: [Stand-alone]

Traffic: [Normal]

Clip Dft Copy Move: [GigE]

GigE Open Conn: [0/26]

Controller \ Protocol

Port	Controller\Protocol	Connection State
RS422 #1	EVSRemote	Connected
RS422 #2	EVSRemote	Connected
RS422 #3	IPDP	Disconnected
RS422 #4	SonyBW75	Defined
Ethernet #50106	LinX	Defined
Ethernet #50107	LinX	Defined

Gigabit Connections Settings

Status	LAN PC	Gbe Port1	Gbe Port2
Up	Up	Up	Down
IP Address	172.16.52.4	172.19.52.4	172.21.52.4
Subnet Mask	255.255.0.0	255.255.0.0	255.255.0.0
Def. Gateway	172.16.0.1	172.19.0.1	172.21.0.1
Phys. Interface	Not Applicable	Unknown	Unknown

Channels

Channel	Status	Config	Rem.Capacity	LTC	User TC	1st Ctrl	2nd Ctrl	Parallel Ctrl	OSD
CAM A	Recording	Rec (25%)	05:15:41	2016-10-09 21:3...	2016-10-10 01:5...	EVSRemote		Primary	
CAM B	Recording	Rec (25%)	05:15:41	2016-10-09 21:3...	2016-10-10 01:5...	EVSRemote		Primary	
CAM C	Recording	Rec (25%)	05:15:41	2016-10-09 21:3...	2016-10-10 01:5...	EVSRemote		Primary	
CAM D	Recording	Rec (25%)	05:15:41	2016-10-09 21:3...	2016-10-10 01:5...	EVSRemote		Primary	
PGM 1	Live	Play		2016-10-09 21:3...	2016-10-10 01:5...	EVSRemote		Primary	
PGM 2	Live	Play		2016-10-09 21:3...	2016-10-10 01:5...	EVSRemote		Primary	
PGM 3	Live	Play		2016-10-09 21:3...	2016-10-10 01:5...	EVSRemote		Primary	
PGM 4	Live	Play		2016-10-09 21:3...	2016-10-10 01:5...	EVSRemote		Primary	

The different group boxes and their parameters are detailed hereafter.

#### Note

If Multicam is not active and running on the selected server, most of the parameter fields will be left blank.

## General Area

The table below describes the fields available in the General area:

Parameter	Description
Type	It indicates the server type: XT3, XT2, XS, ...
Facility Name	It specifies the name given to the product by the user.
Base Config.	It indicates the base configuration used to start the server.
Serial Number	It specifies the server's unique serial number.
Version	It specifies the server software revision.
State	It indicates the functional status of the EVS server or other EVS hardware. The possible statuses are 'Running', 'Initializing', 'In Maintenance' or 'Halted'.

18

3. Monitoring

Parameter	Description
PSU	It specifies the status of the power supply units.
Genlock	It indicates the presence or absence of Genlock synchronization signal, and its type.
LTC	It indicates the status of LTC (Longitudinal Time Code) analogue signal.
Local Clips	It specifies the number of clips stored on the server.
Net Clips	It specifies the total number of clips stored on the whole SDTI network.
Rem. Capacity	It indicates the remaining recording capacity on the EVS server in hours, and percentage.
Clip Capacity	It specifies the clip capacity as defined on the server: Global or Per Channel.
Loop Recording	It specifies the loop recording mode as defined on the server.
Up Time	It indicates the elapsed time since the last boot.
Date Time	It indicates the MTPC date and time.
Sync PC to TC	It synchronizes the internal TC to the timecode read on the LTC input of the server and clears the TC discontinuities detected on the LTC input of the system.
Sync Period	It indicates the period at which the Sync PC to TC is applied.
PC Free Disk Space	It indicates the available space on the MTPC disk in megabytes (MB) or gigabytes (GB).
DB Status	It indicates the status of the server database.
<b>NEW !</b> Rec. Train Expiration	Time lapse by which the field counter for the record trains has to be manually reinitialized on the EVS server. Failing a reinitialization, the record train will not longer be recorded. Warning messages are issued in Multicam.

## Audio-Video Area

The table below describes the fields available in the Audio-Video area:

Parameter	Description
AV Channels	It specifies the configuration defined for video and audio channels: <ul style="list-style-type: none"> <li>• number of IN and OUT video channels</li> <li>• number of audio embedded mono channels per video channel</li> </ul>
Video Std	It specifies the video standard used on the server ports.
Codec Config	It specifies the codec essence(s) active on the EVS server.

Parameter	Description
On Air Codec	It specifies the codec in which the video is played out on the EVS server.
Intra Codec	It specifies the Intra codec in which the video is stored on the EVS server.
Intra Bitrate	It specifies the bitrate of compressed video data for the Intra codec.
LongGOP Codec	It specifies the LongGOP codec in which the video is stored on the EVS server.
LongGOP Bitrate	It specifies the bitrate of compressed video data for the LongGOP codec.
Lo-Res Codec	It specifies the Lo-Res codec in which the video is stored on the EVS server.
Lo-Res Bitrate	It specifies the bitrate of compressed video data for the Lo-Res codec.

## Network Area

The table below describes the fields available in the Network area:

Parameter	Description
SDTI	It indicates the SDTI (Serial Data Transport Interface) network type.
Net # - Name	It indicates the server identification number and name on the SDTI network.
Net Type (Cfg)	It indicates the server type on the SDTI network. The possible values are: <ul style="list-style-type: none"> <li>• Master</li> <li>• Server</li> <li>• Client</li> <li>• Not Applicable (SDTI not present or set to off).</li> </ul>
Clip Edit by network	It specifies whether a clip can be edited through the network or not.
XNet Status	It indicates the status of the SDTI network connection.
Traffic	It indicates the network traffic status.
Clip Dft Copy Move	It specifies the preferred network (SDTI or GigE) for copy/move actions on clips.
GigE Open Conn	It indicates the number of open GigE connections on a given port.

## Controller / Protocol Area

The table below describes the fields available in the Controller / Protocol area:

Parameter	Description
Port	It specifies the port used by the server controller.
Controller\Protocol	It specifies the controller or protocol used on that port.
Connection State	It specifies the connection status of the control port.

## Gigabit Connection Settings Area

The table below describes the fields available in the Gigabit Connection Settings area:

Parameter	Description
Status	It indicates the status of the Gigabit connection.
IP Address	It specifies the IP address of the interface port.
IP Mask	It specifies the IP mask of the interface port.
Def. Gateway	It specifies the default gateway used by the interface port.
<b>NEW !</b> Phys. Interface	It specifies on which hardware the gigabit port is located.

## Channels Area

The table below describes the fields available in the Channels area:

Parameter	Description
Channel	It specifies the name of the record channel (CAM) or play (PGM) channel.
<b>NEW !</b> Status	<p>It indicates the status of the channel:</p> <ul style="list-style-type: none"> <li>CAM: Recording, Rec Idle</li> <li>PGM: Ready, Playing, Live, Idle</li> </ul> <p>If a channel has no audio or video, it will be displayed in red with one of the following indication:</p> <ul style="list-style-type: none"> <li>(!A) when the audio is missing</li> <li>(!V) when the video is missing</li> <li>(!AV) when the audio and video are missing</li> </ul>
Config	It specifies the configuration of the channel as record or play channel.
Rem. Capacity	It indicates the remaining capacity for each recorder channel.
LTC	It gives the LTC timecode of the channel.
User TC	It gives the User timecode of the channel.

Parameter	Description
1st Ctrl	It specifies the primary controller defined for the selected channel. Possible values are: EVS Remote, EVS XTNano Remote, AVSP, IPDP
2nd Ctrl	It specifies the secondary controller defined for the channel, if any.
Parallel Ctrl	It specifies the controller used in parallel mode.
OSD	It specifies which controller (main or secondary) will manage the OSD display characters in parallel mode.

### 3.3.3. Storage Tab

#### Overview

The Storage tab differs according to the type of disks used: SAS or SCSI.

#### SAS Disks

Status **Storage** Hardware Codes Mib Browser

**General**  
 Remaining Capacity: 279:43:04 [99%] Storage type: Sas  
 Nominal Capacity: 279:51:43 RAID type: (4+1)

**Arrays**

	PSU	Fans	Thermal
EXT4			
EXT3			
EXT2			
EXT1	OK	OK	OK
INT1	/	/	OK

**RAID**

	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
R1	R2	R3	R4													

**Disk status**


	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
EXT4																								
EXT3																								
EXT2																								
EXT1	R2	R2	R2	R2	R3	R3	R3	R3	R3	R4	R4	R4	R4	R4	sp	sp	sp	sp	sp	sp	sp	sp	sp	sp
INT1	R1	R1	R1	R1	R1	R1	R2																	

**Disk temperature**

	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
EXT4																								
EXT3																								
EXT2																								
EXT1	21	21	21	20	20	20	20	20	20	19	20	20	20	19	20	20	20	19	20	20	20	20	19	19
INT1	37	29	27	24	24	30																		

Disk Details...

## SCSI Disks



The screenshot shows the 'Storage' tab in the XNetMonitor interface. It displays configuration for SCSI disks. The 'General' section includes 'Remaining Capacity' (37:47:31 [99%]), 'Nominal Capacity' (37:51:07), 'Storage type' (ParallelScsi), and 'RAID type' ((4+1)). The 'Arrays' section shows a table with columns for PSU, Fans, and Thermal, with a row for 'INT1' showing values '/ / OK'. The 'RAID' section shows a table with columns for RAID levels (1, 2, 3) and a row for 'R1' showing values 'R1'. The 'Disk status' section shows a table with columns for disk controllers (0-A, 0-B, 0-C, 0-D, 0-E, 1-A, 1-B, 1-C, 1-D, 1-E, 2-A, 2-B, 2-C, 2-D, 2-E) and a row for 'INT1' showing values 'R1, R1, R1, R1, R1'. The 'Disk temperature' section shows a table with columns for disk controllers (0-A, 0-B, 0-C, 0-D, 0-E, 1-A, 1-B, 1-C, 1-D, 1-E, 2-A, 2-B, 2-C, 2-D, 2-E) and a row for 'INT1' showing values '38, 30, 29, 32, 25'. A 'Disk Details...' button is located at the bottom left.

## General Area

The table below describes the fields available in the General area:

Parameter	Description
Rem. Capacity	It specifies the remaining capacity of the storage expressed as a video duration (hours, minutes and seconds) as well as a percentage.
Nom. Capacity	It specifies the total capacity of the storage expressed as a video duration (hours, minutes and seconds).
Storage Type	It specifies the type of disks: SCSI (ParallelSCSI) or SAS.
Raid Type	It specifies the type of RAID: <ul style="list-style-type: none"> <li>4+1: four disks and a parity disk, with a spare disk for SAS disks / without spare for SCSI disks</li> <li>5+1: five disks and a parity disk, without a spare disk for SAS disks</li> </ul>

## Arrays Area

The table below describes the fields available in the Arrays area:

Parameter	Description
PSU	It specifies the status of the PSU on the given array. See section "PSU HDX" on page 37 for examples of values for this field in case of SAS-HDX array. The values are the same for other arrays types.
Fans	It gives the state of the fans on the given array. See section "Fan HDX" on page 37 for examples of values for this field in case of SAS-HDX array. The values are the same for other arrays types.
Thermal	It gives the temperature status on the given array. See section "Disk Thermal" on page 38 for field values.

## Raid Area

This area gives indication on the number of RAIDs defined in the server and their respective identification (R1,...)

Parameter	Description
Raid ID	It specifies the RAID storage system identification

## Disk Overview Tab


### Disk Status Area

This area gives indication on the localization of each RAID and on the spare disks in the arrays:

The **xx** sign (red) identifies faulty disks, that should directly be replaced, especially when you work without spare disks.

The **??** sign (red) identifies disks other than EVS disks.

The **sp** sign (green) identifies the spare disks.



The screenshot shows a 'Disk status' window with a grid of 16 columns and 2 rows. The columns are labeled 0-A, 0-B, 0-C, 0-D, 0-E, 1-A, 1-B, 1-C, 1-D, 1-E, 2-A, 2-B, 2-C, 2-D, 2-E. The first row contains the labels INT1, R1, R1, R1, xx, R1, and then 10 empty cells. The 'xx' is in a red box, indicating a faulty disk.

	0-A	0-B	0-C	0-D	0-E	1-A	1-B	1-C	1-D	1-E	2-A	2-B	2-C	2-D	2-E
INT1	R1	R1	R1	xx	R1										


### Disk Temperature Area

This area provides the internal temperature of each disk.



## Disk Details Button

The **Disk Details** button gives access to the Disk Information window:



ID	State	Cap (Gb)	Temp(C°)	Model	Rev. Level	SN
0-A	Ok	279	35	FUJITSU MAW3300NC	0104	DA00P7A01WN7
0-B	Ok	279	37	FUJITSU MAW3300NC	0104	DA00P7A01WSJ
0-C	Ok	279	39	FUJITSU MAW3300NC	0104	DA00P7A01WS6
0-D	Ok	279	37	FUJITSU MAW3300NC	0104	DA00P7A01WRA
0-E	Ok	279	32	FUJITSU MAW3300NC	0104	DA00P7A01WS7
1-A	Ok	279	37	FUJITSU MAW3300NC	0104	DA00P7A01WDH
1-B	Ok	279	40	FUJITSU MAW3300NC	0104	DA00P7A01WSA
1-C	Ok	279	41	FUJITSU MAW3300NC	0104	DA00P7A01WPA
1-D	Ok	279	39	FUJITSU MAW3300NC	0104	DA00P7A01WP5
1-E	Ok	279	33	FUJITSU MAW3300NC	0104	DA00P7A01WTA
2-A	Ok	279	37	FUJITSU MAW3300NC	0104	DA00P7A01WSC
2-B	Ok	279	40	FUJITSU MAW3300NC	0104	DA00P7A01WT2
2-C	Ok	279	42	FUJITSU MAW3300NC	0104	DA00P7A01WSP

Parameter	Description
ID	Disk identification
State	Disk status: OK, not present, spare,...
Cap	Disk capacity in Gigabytes
Temp	Disk internal temperature in the unit defined in the general display settings
Model	Disk manufacturer and model
Rev. Level	Disk revision Level
SN	Disk serial number

## 3.3.4. Hardware Tab

### Overview

The Hardware tab lists the available modules and boards installed in the server along with their respective version or revision number and their configuration when relevant.

Boards	
Name	Version
MTPC Board	Id=0xA4
HCTX CPU Board	Id=0x21, Revision=0x33, Jumpers...
COHX Base Board #0	ID=0xC2, IDE=0xF3
COHX Base Board #1	ID=0xC2, IDE=0xD0
COHX Base Board #2	ID=0xC2, IDE=0xD0
CH#0 (COHX)	HW:0x0a/0x03 Feat:0x00c3
CH#1 (COHX)	HW:0x0a/0x03 Feat:0x00c3
CH#2 (COHX)	HW:0x0a/0x02 Feat:0x00c3
CH#3 (COHX)	HW:0x0a/0x02 Feat:0x00c3
CH#4 (COHX)	HW:0x0a/0x02 Feat:0x00c3
CH#5 (COHX)	HW:0x0a/0x02 Feat:0x00c3
ACODEC	Id=0x65, Ide=0x0A, Ide2=0x0A
HCTX GBE	Rev=HCTX_GBE A4 1

General	
Name	Value
Physical Memory	128 MB

### Board Area

Parameter	Description
Name	Name of the board or module
Version	Revision of the board or module, and additional parameters

### **NEW !** General Area

Parameter	Description
Physical Memory	RAM of the EVS server


### 3.3.5. Codes Tab

The Codes tab lists the license codes activated on the server along with their description.

Status	Storage	Hardware	Codes	Mib Browser
Number	Description			
2	Authorize SD configurations			
3	Authorize HD configurations			
4	Authorize video configuration changes			
5	Avid DNxHD(R) Codec			
6	Apple ProRes 422 Codec			
7	Proxy Codec			
8	DVCPRO HD Codec			
9	DVCPRO 50 Codec			
10	Mjpeg Codec			
11	IMX Codec			
12	Mpeg2Intra Codec			
13	AVCIntra Codec			
14	XDCAM HD 50			
20	LSM Hypermotion			
21	1080p Dual-Link			
22	1080p 3G			

### 3.3.6. MIB Browser Tab

The **MIB Browser** tab allows to view the MIB (Management Information Base) and provides a description of the parameters that can be polled. This tab is dedicated to maintenance operations.



## 3.4. Device Details

### Introduction

If a hardware other than an EVS server is selected in the Monitored Device List, the **Device Details** area on the right displays detailed SNMP information.

This information is organized the following tabs, which are themselves organized in different group boxes:

Tab Name	Included field groups
<b>Status</b>	Applications installed on the hardware, data on the computer, the drives, and the communication interfaces
<b>MIB Browser</b>	View on the MIB (Management Information Base)

### Status Tab

In the Status tab, the main parameters are organized in several group boxes as shown on the following figure.

The screenshot displays the 'Status' tab of the EVS interface. At the top, there are two tabs: 'Status' (selected) and 'Mib Browser'. Below the tabs, the 'Evs Products' section contains a table with columns: Type, Version, State, and Custom Name. The 'Computer' section shows fields for Name, CPU Usage, Physical Memory, Up Time, and Date Time. The 'Drives' section contains a table with columns: Name, Total Size, and Free Space. The 'Interfaces' section contains a table with columns: Description, Status, MTU, Speed, Phys. Address, IP Address, Net Mask, NIC IN, and NIC OUT.

Type	Version	State	Custom Name
XFile	2.12.89.0	Halted	Unknown
XTAccess	1.13.9.0	Running	Unknown

Name:	XF73130
CPU Usage:	0% 0%
Physical Memory:	489 / 997 MB (49 %)
Up Time:	21:49:17.04
Date Time:	2010-06-02 19:49:25

Name	Total Size	Free Space
Restore (R)	19.5 GB	14.0 GB
XT7 (F)	465.8 GB	28.1 GB
XT7 (E)	465.8 GB	444.4 GB
System (C)	19.5 GB	6.7 GB

Description	Status	MTU	Speed	Phys. Address	IP Address	Net Mask	NIC IN	NIC OUT
Intel(R) 82566DC...	Down	1500	1000 Mbps	01cc04a8ef7	0.0.0.0	0.0.0.0	126	
Intel(R) PRO/100...	Up	1500	1000 Mbps	01517766bd2	128.1.2.2	255.255.255.0	2,801,699	63,825
Intel(R) PRO/100...	Up	1500	1000 Mbps	015176fe98f	1.1.53.12	255.255.0.0	20,783,986	20,697,299

The different group boxes and their parameters are detailed hereafter.

## EVS Products

Parameter	Description
Type	EVS application name.
Version	Server software revision.
State	Server state: running, in maintenance, faulty, halted, unknown.
Custom Name	Name given to the product from the MIB.

## Computer

Parameter	Description
Name	Name of the computer.
CPU Usage	Percentage of use of central processing unit (CPU).
Physical Memory	Computer data storage used from the total amount.
Up Time	Elapsed time since the last boot.
Date Time	MTPC date and time.

## Drives

This area lists the hard disks drives from the computer.

Parameter	Description
Name	Name of the computer.
Total Size	Total size (GB) of the drive.
Free Space	Free space (GB) still available on the drive.

## Interfaces

Parameter	Description
Description	Generic description of the communication interface.
Status	Up or Down
MTU	Maximum Transmission Unit: size (in bytes) of the largest protocol data unit that the layer can pass onwards.
Speed	Data transfer rate in Megabits per second.
Phys. Address	Memory address that is electronically (in the form of binary number) presented on the computer address bus circuitry in order to enable the data bus to access a particular storage cell of main memory.
IP Address	Internet Protocol address of the communication interface.
Net Mask	Prefix bit mask expressed in quad-dotted decimal representation. For example, 255.255.255.0 is the subnet mask for the 192.168.1.0/24 prefix.
NIC IN	Number of octets getting through the network (input)
NIC OUT	Number of octets getting through the network (output)

## MIB Browser Tab


See section "MIB Browser Tab" on page 27 for an overview of the MIB Browser tab.

## 3.5. Extracting SNMP Information

To extract SNMP information relative to an EVS server, proceed as follows:

1. Right-click on the server in the **Monitored Device Tree**.
2. Select **Extract SNMP Information** from the contextual menu.

The extraction starts and once it is done, the SNMP Information Extraction window displays the .html file name and its storing folder and path:



## 3.6. Alert Messages

### 3.6.1. Managing Alerts

#### Alert Messages Display

The SNMP Messages pane displays the SNMP alert messages sent by the host or groups of hosts selected in the Monitored Device Tree. These messages are displayed until they are acknowledged by the user.

Start Date:	Monday , April 27, 2009	Filter:	Not Acknowledged	Ack alert(s)
End Date:	Monday , May 04, 2009			

Host Name	Date	Alert message	IP Address
Server 2	5/4/2009 12:14:12 ...	Disk alert: state of disk Disk 0-D is Disconnected	1.1.20.22
Server 2	5/4/2009 12:14:12 ...	Analog LTC NotDetected	1.1.20.22
Server 2	4/29/2009 3:46:50 ...	Analog LTC NotDetected	1.1.20.22
Server 2	4/28/2009 11:32:28...	Status: not running	1.1.20.22
Server 2	4/27/2009 10:36:57...	Analog LTC NotDetected	1.1.20.22

Use the calendar of the **Start Date** and **End Date** drop-down fields to restrict the displayed alerts list to the selected.

Use the Filter drop-down menu to select the alerts to be displayed:

- **All:** All alerts that occurred during the selected period are displayed.
- **Acknowledged:** Only alerts that have already been acknowledged are displayed.
- **Not Acknowledged:** Only alerts that do not have been acknowledged yet are displayed.

#### Alert Messages Acknowledgement

The alert acknowledgment function helps you to easily remove alert messages from the displayed list once they have been visualized and/or taken care of.

Use the **Ack Alert(s)** button to acknowledge the selected alerts. These alerts are kept in the log file, but are not displayed anymore (depending on the display filter configuration).

## 3.6.2. List of Possible Alerts

### Introduction

The section describes the fields for which an alert can be generated and the associated default message(s) (normal status) and alert/error messages.

### Working Principle

When an error is generated for a field, it is displayed in the Monitoring window:

- **as an alert** in the Alert pane if the given field is not selected in the Alert Configuration window.

The alert must be acknowledged by an administrator user to be removed from the list of active alerts. It is then sent to the list of acknowledge alerts.

- **as an error message** in the Server Details pane, and possibly in the Monitoring List pane (if the related field is displayed).

When the SNMP information is sent back and when the situation is back to normal or when the alert is acknowledged, the field status is updated accordingly, and the error is replaced by the normal status.

### Polling Status

It specifies the status of the polling service.

It indicates:

- whether the polling service is running correctly
- when the polling service last sent a query to the server (time interval in hh:mm:ss from current time)

#### Possible Values

Message	Explanation	Status Type
<b>OK (00:03:00)</b>	The polling service is working correctly, and the SNMP data was last sent 3 minutes ago.	Info
<b>No response to IMCP polling</b>	An ICMP (Internet Control Message Protocol) timeout was generated: the information was not sent in the requested time interval.	Error
<b>No response to SNMP polling</b>	An SNMP timeout was generated: the information was not sent in the requested time interval.	Error



## State

It indicates the functional status of the EVS server or other EVS hardware.

The possible statuses are 'Running', 'Initializing', 'In Maintenance' or 'Halted'.

### Possible Values

Message	Explanation	Status Type
<b>Running</b>	The EVS server is running a given configuration.	Info
<b>Not Running</b>	The EVS server	
<b>Initializing</b>	The EVS server is initializing (in the boot sequence).	Error
<b>Maintenance</b>	The EVS server is in the Multicam Setup window, hence it is not running a given configuration yet.	Error
<b>Halted</b>	The EVS server is turned off.	Error

## PSU

It specifies the status of the power supply units.

### Possible Values

Message	Explanation	Status Type
<b>OK (1)</b>	Only one PSU is installed on the server and is working fine	Info
<b>OK (2)</b>	Two PSUs are installed and are working fine	Info
<b>! PSU 1</b>	The first PSU is down.	Error
<b>! PSU 2</b>	The second PSU is down.	Error

## GigE1/2 Status

It specifies the operational status of the first (GigE 1) or second (GigE 2) Gigabit Ethernet interface connector.

### Possible Values

Message	Explanation	Status Type
<b>Up</b>	The GigE interface is running well.	Info
<b>Down</b>	The GigE interface is not working.	Error
<b>Not present</b>	No GigE card is installed.	Error

## Controller

It specifies the connection status of a given controller enabled on an EVS server.

Depending on the pane where the message is displayed, it is displayed in slightly different ways.

### Possible Values

Message	Explanation	Status Type
<b>OK</b>	All defined controllers are connected, which means up and running.	Info (in Monitoring List)
<b>Connected</b>	The corresponding controller is up and running.	Info (in Server Details)
<b>Defined</b>	The corresponding controller is defined in the configuration but is not used	Info (in Server Details)
<b>Disconnected</b>	The corresponding defined controller is disconnected, or the external communication has been lost.	Error (in Server Details)
<b>DD35 disconnected VDCP, AVSP disconnected</b>	The given controller(s) is/are disconnected on the EVS server.	Error (in Monitoring List or Alerts)

## Genlock

It indicates the presence or absence of Genlock synchronization signal, and its type.

### Possible Values

Message	Explanation	Status Type
<b>OK Blackburst</b>	A valid Blackburst signal is present.	Info
<b>OK Tri-level</b>	A valid Tri-level signal is present.	Info
<b>Bad Blackburst</b>	Bad Blackburst signal, or no Blackburst signal	Error
<b>Bad Tri-level</b>	Bad Tri-level signal, or no Tri-level signal	Error

## Analog LTC

It indicates the status of LTC (Longitudinal Time Code) analogue signal.

### Possible Values

Message	Explanation	Status Type
<b>OK</b>	A valid LTC signal is present on the EVS server.	Info
<b>Missing</b>	No LTC signal is detected on the EVS server.	Error
<b>Corrupted</b>	A bad LTC or an LTC drift is detected on the EVS server.	Error

## Local Clips

It specifies the number of clips stored on the server.

The alert generation depends on the threshold defined for the Local Clips field in the Monitoring settings defined in the **Tools > Settings** menu. The default threshold is 4000.

### Possible Values

Message	Explanation	Status Type
3500	When the number of clips is displayed in black, it means the number of clips on the EVS server does not exceed the threshold defined for the maximum number of local clips.	Info
<b>4200</b>	When the number of clips is displayed in red and bold characters, it means the number of clips on the EVS server exceeds the threshold defined for the maximum number of local clips.	Error

## DB Status

It indicates the status of the server database.

### Possible Values

Message	Explanation	Status Type
<b>OK</b>	The DB is OK.	Info
<b>Corrupted</b>	The DB is corrupted.	Error

## XNet Status

It indicates the status of the SDTI network connection.

**Possible Values**

<b>Message</b>	<b>Explanation</b>	<b>Status Type</b>
<b>Connected</b>	The EVS server is connected to the network.	Info
<b>Connecting</b>	The EVS server's connection to the network is in progress.	Info
<b>Stand alone</b>	The system does not have the XNet license, or the required hardware, or the SDTI network is disabled.	Info
<b>Not Connected</b>	The EVS server is not connected to the network.	Error
<b>Disconnected</b>	The EVS server is in a disconnection phase.	Error
<b>Connection fault</b>	The EVS server cannot connect to the XNet network due to an incompatibility error.	Error

**Traffic**

It indicates the network traffic status.

**Possible Values**

<b>Message</b>	<b>Explanation</b>	<b>Status Type</b>
<b>Normal</b>	The traffic on the SDTI network is properly managed.	Info
<b>Heavy</b>	The SDTI network makes full use of the available capacity.	Warning (orange)
<b>Corrupted</b>	The SDTI network is overloaded, has lost at least one command from a controller, and is desynchronized.	Error

**Rem. Capacity**

It indicates the remaining recording capacity on the EVS server in hours, and percentage.

The alert generation depends on the threshold defined for the Remaining Capacity field in the Monitoring settings defined in the **Tools > Settings** menu. The default threshold is 5%.

### Possible Values

Message	Explanation	Status Type
<b>48:01:53 (97%)</b>	The parameter is in a valid state (black font) when the Remaining Capacity threshold is not exceeded.	Info
<b>01:03:32 (2%)</b>	The parameter is in a warning state (orange font) when the Remaining Capacity threshold is exceeded.	Warning
<b>00:00:00 (0%)</b>	The parameter is in an error state (red font) when the Remaining Capacity is null.	Error

## PSU HDX

It specifies the status of the power supply units of the external SAS disk array.

### Possible Values

Message	Explanation	Status Type
<b>OK (1)</b>	Only one PSU is installed on the SAS-HDX disk array and is working fine	Info
<b>OK (2)</b>	Two PSUs are installed on the SAS-HDX disk array and working fine.	Info
<b>/</b>	No external storage system is installed.	Info
<b>! PSU1</b>	The first PSU of the SAS-HDX disk array is down.	Error
<b>! PSU2</b>	The second PSU of the SAS-HDX disk array is down.	Error

## Fan HDX

It specifies the state of the fans on the external SAS disk array.

### Possible Values

Message	Explanation	Status Type
<b>OK</b>	The fans is/are operating.	Info
<b>/</b>	No external fans are installed	Info
<b>! Fan 1</b> <b>! Fan 1,2</b>	The fan 1 is faulty. The fans 1 and 2 are faulty.	Error

## Disk Thermal

It specifies the temperature on the internal and external disks.

### Possible Values

Message	Explanation	Status Type
<b>OK</b>	All temperatures measured on disks are OK.	Info
<b>INT 1: Rising (orange)</b>	The temperature of disk 1 on the internal disk array is rising (between 50 and 55°C).	Warning
<b>EXT 2-3 : Rising (orange)</b>	The temperature of disk 3 of the second external disk array is rising (between 50 and 55°C).	Warning
<b>INT 1-2 : Overheating (red)</b>	The temperature of disk 2 of the first internal disk storage board exceeds 55°C.	Error

## RAID

It specifies the status of the raids.

### Possible Values

Message	Explanation	Status Type
<b>OK</b>	The raid system is working fine.	Info
<b>R1: Rebuilt X% (orange)</b>	The system is rebuilding raid 1 of the raid matrix. The X represent the percentage processed of the rebuild operation. In the Server Details pane, Storage tab, the raid has an orange background in the RAID area.	Warning
<b>R1: Degraded (red)</b>	The raid 1 of the raid matrix has lost a disk and cannot afford any new disk failure without losing the full storage. In the Server Details pane, Storage tab, the raid has a red background in the RAID area.	Error

## Raid R/W Retry

It specifies the number of renewed attempts of read and/or write operations on disks of the raids.

As soon as at least a read or write operation had to be retried, this generates a warning.

**Possible Values**

Message	Explanation	Status Type
<b>0r / 0w</b>	0 renewed read attempt, 0 renewed write attempt	Info
<b>0r / 1w (orange)</b>	0 renewed read attempt, 1 renewed write attempt	Warning

**Raid R/W Error**

It specifies the number of errors in read and/or write operations on disks of the raids.

As soon as at least a read or write operation failed, this generates an error.

**Possible Values**

Message	Explanation	Status Type
<b>0r / 0w</b>	0 read error, 0 write error	Info
<b>0r / 1w (red)</b>	0 read error, 1 write error	Error

**Disk**

It indicates the disk connection status, and the number of spare disks.

**Possible Values**

Message	Explanation	Status Type
<b>OK (1 sp)</b>	All disks are connected and accepted by the RAID matrix, and 1 spare disk is available.	Info (in Alerts and Monitoring List)
<b>1 xx (6 sp)</b>	All disks are connected and accepted by the RAID matrix, but one disk is faulty, and 6 spare disks are available.	Error (in Alerts and Monitoring List)
<b>OK</b>	The given disk is working fine.	Info (in Server Details)
<b>Spare</b>	The given disk is a spare disk.	Info (in Server Details)
<b>Disconnected</b>	The given disk is out of the RAID matrix.	Error (in Server Details)
<b>Not Present</b>	No disks are connected in the bay.	Error (in Server Details)

**PC Free Disk Space**

It indicates the available space on the MTPC disk in megabytes (MB) or gigabytes (GB).


**Possible Values**

Message	Explanation	Status Type
<b>300 MB</b>	When the space available is more than the value defined in the SNMP agent (100 MB), the label is in a normal state.	Info
<b>75 MB (orange)</b>	When the space available is less than the value defined in the SNMP agent (100 MB), the label is in a warning state. For PCs (no MTPC card), this value is not displayed as a warning.	Warning
<b>10 MB (red)</b>	When the space available is less than 20MB, the label is in an error state. For PCs (no MTPC card), this value is not displayed as a warning.	Error

## 3.7. Disk Usage

The Disk Usage pane displays a summary of the total used and remaining disk space. This total is computed for all disks available on the server or group of servers selected in the Monitored Device Tree.

A color pie chart helps you to immediately visualize the disk usage of your system. More precise figures are given over that pie chart, expressed as a used and remaining video time in hours, minutes and seconds.





## 4. Server Maintenance Tasks

### 4.1. Multicam Upgrades

#### 4.1.1. Installing a Multicam Version


##### How to Install a Multicam Version on an EVS Video Server

**Note**

The Multicam installation zip file can be generated from the makezip.bat file or from the XNet Install Zip.bat file available with all Multicam installation packages.

To remotely update Multicam on one or several servers, proceed as follows:


1. In the **Tools** menu, select **Server > Install Versions**. The Installation window appears:



2. Select the server(s) to update in the left pane of the Installation window.  
As a reminder, the currently installed Multicam version is displayed next to each server.
3. In the **Version** field, browse your computer to select the new Multicam installation zip file.
4. Click on the **Install** button to start the installation process on all selected servers.

5. Before the server upgrade starts, the installer checks the number of Multicam versions installed on each server.

If more than 5 versions are installed on the EVS server, the following error message appears. Otherwise, the upgrade process is automatically launched.



If you get the above message, do the following:

- a. Click **OK**. The Remove Installed Versions window appears.
- b. Remove the requested versions as described in the section "Installing a Multicam Version" on page 41 "Installing a Multicam Version" on page 41', on page "Installing a Multicam Version" on page 41.

The upgrade process is then launched. When the servers are upgraded, they are restarted, but you still need to launch the requested application.


## 4.1.2. Removing a Multicam Version

### How to Remove a Multicam Version from an EVS Server

To remove previously installed Multicam versions from an EVS server, proceed as follows:

1. In the **Tools** menu, select **Server > Remove Installed Versions**.

The Remove Installed Versions window appears.



2. Select the version(s) you want to remove.  
The selected versions are highlighted in black.
3. Click the **Remove Selected Versions** button.
4. Click **Close**.


## 4.2. Remote Access to an EVS Server

### 4.2.1. Accessing Remotely a Server Desktop


To access remotely a server desktop, proceed as follows:

1. Right-click on a server name, and select **Remote Desktop** from the contextual menu.

A message appears to warn you that you are going to take control of the EVS server:



2. Click **OK** to open the server screen:




From this screen, you are able to navigate through Multicam and EVS screens exactly as you accessed them from a keyboard.

## 4.2.2. Accessing the Multicam Web Setup

To access remotely a server desktop, proceed as follows:

1. Right-click on a server name, and select **Web configuration** from the contextual menu.

A message appears to warn you that you are going to take control of the EVS server:



2. Click **OK** to open the server screen.

The Multicam Web Setup window opens.

Refer to the EVS Server Configuration manuals for more information.


## 4.2.3. Accessing Remotely an LSM Remote Panel




### Important

This function must only be used for training purposes. It is not intended to be used for operations.

1. To connect to and take control of an LSM Remote connected to a server, proceed as follows:
2. Right-click on a server name and select **LSM Remote** from the contextual menu.
3. In the following window, select the port number linked to the physical remote device:



4. Clicking **OK** opens an interactive window representing the LSM remote panel and from which you can use the different commands, such as on the physical remote itself.



You can close this window by pressing **Escape**.

## 4.2.4. Rebooting an EVS Server

To remotely reboot a server, right-click on it in the Monitored Device Tree and select **Reboot** in the contextual menu.

The Server Reboot message window is displayed. You must confirm the reboot process to start it on the remote host.




### Note

This command will be available only if the corresponding parameter is enabled in the Settings window.

## 4.3. Uploading a Keyword File on an EVS Server

To upload a keyword file on one or several servers, proceed as follows:

1. In the **Tools** menu, select **Server > Keyword Files**. The Keywords window appears.




2. Select the server(s) to receive the keyword file in the left pane of the Keywords window.
3. In the **Keyword File** field, browse your computer to select the keyword file to upload.
4. Click on the **Upload** button to start the keyword file copy on all selected servers.


## 4.4. Server Logs Extraction

To remotely recover the SNMP logs stored on a server, right-click on it in the Monitored Device Tree and select Extract logs in the contextual menu.


The following warning message window is displayed to warn you that the extraction process may interfere with the video diffusion from that server. Launch the extraction process again later if you cannot accept any diffusion trouble at this time.



The next window displays progress bars of the extraction and the current directory and file being downloaded.



Once the logs extraction is done, a window briefly appears about the log files compression then the Logs Extraction window displays the zip file name and its storing folder and path.



The different logged information (configuration, alerts...) is stored in different folders and files and packed together in a zip file. Next to the zip files is a text file (LogExtracion\_servername.log) for each server that logs the extractions dates, operations, results and resulting zip file.

**Note**

At log extraction, the log file on the remote server is closed and transferred. After this operation, a new log file is created on the remote server to log the events that happen from now on.







**EVS Headquarters**  
Liège Science Park  
16, rue Bois St Jean  
B-4102 Seraing  
Belgium

Corporate  
+32 4 361 7000

North & Latin America  
+1 973 575 7811

Asia & Pacific  
+852 2914 2501

Other regional offices  
[www.evs.com/contact](http://www.evs.com/contact)

EVS Broadcast Equipment is continuously adapting and improving its products in accordance with the ever changing requirements of the Broadcast Industry.  
The data contained herein is therefore subject to change without prior notice. Companies and product names are trademarks or registered trademarks of their respective companies.



To learn more about EVS go to [www.evs.com](http://www.evs.com)