


# Technical Reference Software

Version 10.03 - July 2010



## XT(2)



Production & Playout Server



## **COPYRIGHT**

EVS Broadcast Equipment – Copyright © 2002-2010. All rights reserved.

## **DISCLAIMER**

The information in this manual is furnished for informational use only and subject to change without notice. While every effort has been made to ensure that the information contained in this user manual is accurate, up-to-date and reliable, EVS Broadcast Equipment cannot be held responsible for inaccuracies or errors that may appear in this publication.

## **IMPROVEMENT REQUESTS**

Your comments will help us improve the quality of the user documentation. Do not hesitate to send improvement requests, or report any error or inaccuracy on this user manual by e-mail to [doc@evs.tv](mailto:doc@evs.tv).



# Table of Contents

TABLE OF CONTENTS .....	III
WHAT'S NEW? .....	VI
1. EVS SOFTWARE .....	7
1.1 INTRODUCTION.....	7
1.2 EVS MAIN MENU .....	8
1.2.1 EVS Screen Layout.....	8
1.2.2 Tips to Move Inside the EVS Software.....	9
1.2.3 Starting an Application .....	9
1.2.4 Commands Available from the Main Menu .....	9
1.2.5 Configurations Available on XT[2] Systems .....	10
1.3 AUDIO & VIDEO CHANNEL PARAMETERS (AVCFG) .....	12
1.3.1 Introduction .....	12
1.3.2 How to Modify A/V Channel Parameters.....	13
1.3.3 Audio & Video Parameters Overview .....	13
Lock Video Configuration .....	13
Base Configuration.....	14
Loop Rec.....	15
Clip Capacity .....	15
Video Players .....	15
Video Recorders .....	15
SLSM REC.....	15
Audio Format.....	16
Audio Type .....	16
Lipsync .....	17
Audio Full Scale .....	17
REC 1 on all REC .....	17
3D Dual-Stream .....	17
Ancillary Mode.....	18
Sample Rate Converter.....	18
1.3.4 Channels Overview .....	18
Type .....	18
CTRL.....	18
Port.....	19
REC.....	19
Audio Tracks .....	19
Audio Monitoring (A. Mon.) .....	21
1.3.5 Dolby Audio Management.....	22
Some Definitions .....	22
Dolby Configurations in XT[2] Servers.....	22
1.3.6 3 D & 1080p Dual-Stream Management .....	23
Principle .....	23
Possible Channels Configurations .....	23
3D Configuration .....	23
1080p Configuration.....	23
1.3.7 Hypermotion Management.....	24
Principles.....	24
Remote Panel Assignment.....	24
1.3.8 OSD, Video and Audio Signals on COHX in Rec/Play .....	26
1.4 MAINTENANCE MENU.....	29
1.4.1 Advanced Parameters.....	29
How to Modify Advanced Parameters.....	30
Codecs Availability and Options Depending on the Video Standard and the Hardware.....	30
Video Disk Block Size .....	33
Operational Disk Size.....	33
Rec HD-> SD Low Latency .....	33
Vertical Interpolator and Four Lines Interpolation .....	33


1.4.2	Configuration.....	34
	How to Enter the Configuration Window .....	34
	How to Modify an Item in the Configuration Window .....	34
	Hardware Revisions Area .....	35
	Software Releases Area .....	36
	Network Area .....	36
	Video & Audio Area.....	37
	Ref & Phase Area .....	39
1.4.3	Options.....	40
	Accessing the Options Menu .....	40
	Introduction .....	40
	Display .....	41
	Expiration and Warning.....	41
	How to Enter New License Codes .....	42
	How to Remove a License Code.....	42
	How to Check Hardware Key (dongle) Information.....	42
1.4.4	Clear Video Disks .....	43
1.4.5	Force Load Clips .....	43
1.4.6	Phase Definition.....	44
	Standard Definition.....	44
	High Definition.....	44
	Commands.....	45
1.4.7	Default Application .....	46
	How to Define a Default Application.....	46
	How To Remove the Default Application .....	46
1.4.8	Default Parameters .....	47
	Default Parameters for all Applications .....	47
1.4.9	Default to VGA .....	48
1.4.10	TS Calibration .....	49
1.4.11	Set Time.....	49
1.4.12	Hardware Check / Raid Rebuild .....	49
	Disk Errors and Disconnection.....	49
	Disks Monitoring.....	50
	Rebuild Process .....	51
	Retrieving SCSI Logs.....	52
1.4.13	Clip Compatibility Between Multicam Versions .....	52
<b>2.</b>	<b>BOOTWINS &amp; ERROR MESSAGES .....</b>	<b>54</b>
2.1	INTRODUCTION.....	54
2.2	INITIALIZING THE DISKS.....	54
2.3	READING THE CONFIGURATION FILE .....	56
2.4	INITIALIZING THE MICROCODE .....	58
2.5	DISK DATA RECOVERY .....	59
<b>3.</b>	<b>MONITORING .....</b>	<b>60</b>
3.1	SDTI NETWORK MONITORING .....	60
3.1.1	Information Available on the Screen .....	60
	Data Displayed.....	60
	Background Color .....	61
	Text Color.....	61
	Link Colour.....	61
	Possible Actions.....	61
3.1.2	How to Disconnect a Machine from the Server .....	62
3.2	SERVER MONITORING .....	63
3.2.1	Disk Status.....	63
3.2.2	Genlock Status.....	63
3.2.3	Analog LTC Status.....	64
3.2.4	Timecode Statuses .....	64
3.2.5	Timecode Monitoring on SD Recorders .....	66
3.2.6	Timecode Monitoring on HD Recorders .....	66

3.2.7	Log Management .....	67
	Log File Types.....	67
	Criticality Levels .....	67
	Extracting Log Files.....	67
<b>4.</b>	<b>ASRUNLOG.....</b>	<b>69</b>
4.1	PURPOSE.....	69
4.2	AS RUN LOG MECHANISM .....	69
4.3	SERVER AS RUN LOG FILE .....	70
4.4	AS RUN LOG FILE CONTENT .....	70
<b>5.</b>	<b>PROTOCOLS .....</b>	<b>71</b>
5.1	CONTROL PROTOCOLS .....	71
5.2	MONITORING PROTOCOL.....	74
<b>6.</b>	<b>POSSIBLE CLIP IDENTIFIERS .....</b>	<b>75</b>
6.1	LSM ID .....	75
6.2	UMID .....	75
6.3	VARID .....	75
	<b>REGIONAL CONTACTS .....</b>	<b>1</b>

# What's New?

---

The following table describes the sections updated to reflect the new and updated features on Multicam version 10.03.

In the user manual, the icon  has been added on left margin to highlight information on new and updated features.

Click the section number (or the description) in the table to jump directly to the corresponding section.

## Corrections for Multicam version 10.03

---

1.3.7	Updated: Remote Panel Assignment.
1.4.1	New codec: Apple ProRes 422 LT
4	AsRunLog function

---

# 1. EVS Software

---

## 1.1 INTRODUCTION

The EVS software is used for configuration and maintenance operations. It is also used to select which application to run, since EVS disk recorders have the ability to run various dedicated applications (Video Server, Slow Motion ...).


When turning on the EVS mainframe, the first step is the PC boot sequence, followed by the boot of the video I/O boards, and finally the EVS software is started.

If a default application has been previously selected, this application will start automatically after a few seconds if no key is hit.

If a default application has not been defined or if the space bar is hit, the system will remain in the EVS main menu (see snapshot on next page) and wait for the operator's next command.

## 1.2 EVS MAIN MENU

### 1.2.1 EVS SCREEN LAYOUT



**Title bar:** the first line of the VGA screen is the title bar. It contains the EVS software revision and current date and time.

**Task bar:** the last line of the VGA screen is the task bar. It contains a summary of the keyboard controls available.

**Application window:** this window contains the list of all applications installed on the system.

**Configuration windows:** the windows show the hardware configuration of the system.

**Message window:** messages are displayed in this space to provide more information on the current selection.

## 1.2.2 TIPS TO MOVE INSIDE THE EVS SOFTWARE

- The active window is always shown with a double frame.
- Press the **UP ARROW**, the **DOWN ARROW** or the **<TAB>** key to change the selection inside the active window.
- Press the **<SPACE BAR>** to toggle between pre- defined values.
- Press **ENTER** to select an item or to confirm an entry.
- Press **ESC** to go back to the previous menu or to cancel an entry.

## 1.2.3 STARTING AN APPLICATION

Select the appropriate application from the Applications list, and then press **ENTER** to confirm the selection.

## 1.2.4 COMMANDS AVAILABLE FROM THE MAIN MENU

The **UP ARROW** and **DOWN ARROW** keys of the keyboard can be used to select an application. The purple line shows the current selection. The black line shows the default application.

The **ENTER** key is used to start the selected application.

Press **F7** to make the currently selected application the new default one. The default application is automatically started every time the EVS program is entered. When the application currently selected is already the default application, pressing **F7** will disable the default application and the system will remain in the EVS Main menu every time the EVS software is launched.


Press **F8** to immediately open the Channel Config window related to the selected application. Press **ALT + Q** to come back to main menu.

Press **F9** to enter the Maintenance menu.














To exit the EVS software and go back to the DOS prompt, press simultaneously **ALT + Q** and confirm with **ENTER**. To restart the EVS software from the DOS, simply type **RUN**.

## 1.2.5 CONFIGURATIONS AVAILABLE ON XT[2] SYSTEMS

### EVS XT[2] - Configurations with HD and SD Super Motion 3 Phases



## EVS XT[2] - Configurations with HD Super Motion 2 Phases

	2-Channel BDR222	4-Channel BDR444	6-Channel BDR666
1 CAM			
2 CAM			
3 CAM			
4 CAM			
5 CAM			
1 Super LSM (100/120Hz)			
1 Super LSM + 1 CAM			
1 Super LSM + 2 CAM			
2 Super LSM (100/120Hz)			
2 Super LSM + 1 CAM			



### Note on clips compatibility:

Clips are compatible across all Multicam configurations including Super LSM. Record trains are also compatible as long as the number of record channels (cameras) is not increased in LSM mode.

Ex.: SuperLSM → 2CAM (Fx): Record trains are lost.

4CAM (Fx) → 3CAM (Cut): Record trains are compatible.

Record trains are always kept in Spotbox mode (all modes except LSM), even when the number of record trains is increased.

## 1.3 AUDIO & VIDEO CHANNEL PARAMETERS (AVCFG)

### 1.3.1 INTRODUCTION



#### Important

Most parameters are factory preset, and should not be modified without advice of qualified EVS staff. Improper values for some parameters will prevent the proper operation of the system.

Please refer to the parameters' charts for correct values (See section 1.4.8 'Default Parameters', on page 47).

Each application has its own set of parameters. When the user selects an application in the EVS main menu and press **F8** (Parameters), the A/V Channels Configuration window (also called AVCFG) appears:

Custom		Channels Config=		Lock Video Conf:No	
Base Config: Multicam LSM					
Video Players : 3		Video Recorders: 3		SLSM Rec: None	
Audio Format : AES/EBU <D>		Lipsync (ms): 0.00		Audio Full Scale: 22 dBu	
Audio Type : 4 Tracks		REC1 on all REC: No		3D Dual-Stream: OFF	
Ancillary Mode: 24 bits		Sample Rate converter: On			
	1	2	3	4	5
Type	OUT1 - PGM1	OUT2 - PGM2	OUT3 - PGM3	IN1 - CAM A	IN2 - CAM B
Ctrl	Play	Play	Play	Record	Record
Rec.	LSM	LSM	LSM	LSM	LSM
A1	D 01 0 dB	D 03 0 dB	D 05 0 dB	33% Loop D 01 0 dB	33% Loop D 03 0 dB
A2	D 02 0 dB	D 04 0 dB	D 06 0 dB	D 02 0 dB	D 04 0 dB
A3	D 09 0 dB	D 11 0 dB	D 13 0 dB	D 09 0 dB	D 11 0 dB
A4	D 10 0 dB	D 12 0 dB	D 14 0 dB	D 10 0 dB	D 12 0 dB
A5					
A6					
A7					
A8					
A.Mon	1 D-01 Out 0 dB	2 D-02 Out 0 dB	3 D-09 Out 0 dB	4 D-10 Out 0 dB	
Press [Space Bar] to select value: Yes - No					

This window is used to define video & audio channels, type and configuration of recorders, audio format and audio-video synchronization parameter. All the parameters are described in this section.

## 1.3.2 HOW TO MODIFY A/V CHANNEL PARAMETERS

1. From the EVS main menu, press **F9** to open the Maintenance menu.
2. Select the 'Channel Parameters' item and press **ENTER**.
3. Select the Application to configure and press **ENTER**.  
The A/V Channel Config window appears.
4. Use the <**TAB**> key to move from one box to the next one. Some information about the current parameter is displayed in the INFO area.
5. Press <**TAB**> or the arrow keys to move across the different parameters in the window.
6. When the desired field is selected, modify the parameter to its new value by pressing the <**SPACE BAR**> or by entering its numeric value and then pressing **ENTER** to validate.
7. Press **F3** to enter the Advanced Parameters.
8. Press **F4** to save the current configuration. A dialog Box appears to enter a name.
9. Press **F5** to load the list of configurations previously saved.
10. Press **ALT + Q** to exit the A/V Channel Config window.

OR:

1. From the 'Application List' in the EVS main menu, select the application to configure and press **F8**.
2. Continue from step 4.

## 1.3.3 AUDIO & VIDEO PARAMETERS OVERVIEW



### Note:

When Modifying the value of a parameter in the Audio & Video Channel Config, always press **ENTER** after changing the value of a parameter to validate the new choice. Check the channels table in the centre of the screen to make sure that the changes are reflected there.

## LOCK VIDEO CONFIGURATION

Possible values: Yes / No

This item enables/disables the access to the modifications of the next three items: Video Players, Video Recorders and Type for REC1.

The video configuration is locked if Option Code 4 (Authorize video configuration changes) is not active in the Options List.

## BASE CONFIGURATION

Possible values:

Replay-Only LSM

Multicam LSM

XT Server Sony

XT Server DD35

XT Server Odetics

XT Server Odetics F&K

XT Server VDCP

XT Server VDCP F&K

XT Server AVSP

XT Server IPDP

XT SpotBox Sony

XT SpotBox DD35

XT SpotBox Odetics

XT SpotBox Odetics F&K

XT SpotBox VDCP

XT SpotBox VDCP F&K

XT SpotBox AVSP

XT SpotBox IPDP

Video Delay

2-ch VTR

The different configurations appear according to the license codes that have been enabled.

### *Secondary Controller*

When you select a Spotbox configuration, you can define secondary controllers by pressing **CTRL-F1**.

#### Limitations

Some configurations (\*) lead to the following message to warn the users of the limitations of the selected configuration:

“Warning: your parallel selection is not fully operational”

Parallel Configuration	VDCP	Odetics	DD35
Remote	*	*	*
IPDirector	*	*	*

VDCP, Odetics and DD35 protocols are standard protocols which have not been developed to work in collaborative mode. Each protocol has its own workspace, so the actions of the first controller are not always correctly interpreted by the second controller.

## LOOP REC

This parameter enables/disables the endless loop recording in AVSP Server/Spotbox configurations. It is forced to 'Yes' in LSM configurations. This function is applied to all recorder channels.

## CLIP CAPACITY

Possible values: Global / Per Channel

This parameter allows selecting the recording mode.

**In Global mode**, the clip capacity is shared between the different record trains. Example: When 3 record trains are used, creating a clip of 30 min on REC1 will take 10 min of recording capacity equally from each record train.

**In Per Channel mode**, the clip capacity is only relevant to the individual record train. Example: 3 record trains are used, creating a clip of 30 min on REC1 will take 30 min of recording capacity from the 1<sup>st</sup> record train, but will not affect the recording capacity of the other two record trains.

The default value depends on the basic configuration:

LSM	2-ch VTR	Slave/Server configurations	Video Delay
Global (locked)	Per Channel	Per Channel	Global (locked)

## VIDEO PLAYERS

Range: [1...6]

This parameter allows selecting the number of player channels of the application and the associated audio channels.

## VIDEO RECORDERS

Possible values in range: [1...6]

This parameter allows selecting the number of RECORD channels of the application. The partition of the disk storage between these channels, and the associated audio channels are automatically updated.

## SLSM REC

This parameter defines the type of SLSM recorders. The parameter is only editable if at least 2 channels are available to be used as SLSM recorders. Otherwise, the parameter has the value "None" and is not editable.

Six types of record are available:

- None (Standard rate 50/60 Hz)
- Single SD SLSM 3x Alternate Parity – EVS mode (150/180 Hz)
- Single SD SLSM 3x Identical Parity (150/180 Hz)
- Single HD SLSM 2x Alternate Parity – EVS mode (100/120 Hz)
- Single HD SLSM 3x Alternate Parity – EVS mode
- Double HD SLSM 2x Alternate Parity – EVS mode



#### Note

The fault tolerance on the different phases of the super motion camera is +/- 90% of one field. So there should be no delay between the different phases when all equipments are genlocked.

## AUDIO FORMAT

Possible values: [Analog (A), AES/EBU (D), Embedded (E), Dolby E AES (DY), Dolby E Embedded (EY)]

This parameter allows selecting the Audio format.

When the Audio Format is set to AES/EBU (D or DY) or Embedded (E or EY), the analogue audio outputs (if installed on the server) are automatically activated and can be used for additional monitoring.

When the Audio Format is set to Embedded (E or EY), the digital audio (AES/EBU) outputs (if installed on the server) are also active.

For more information on Dolby Audio Management, refer to section 1.3.5 'Dolby Audio Management', on page 22.

## AUDIO TYPE

Possible values: [1 Track, 2 Tracks, 4 Tracks, 8 Tracks, 16 Tracks]

This parameter allows selecting the type of audio (number of mono audio tracks associated to each video channel).

The following table specifies the audio types available for the various audio formats:

Audio Type	Analog (A)	Digital (D - DY)	Embedded (E - EY)
1 track	X		
2 tracks	X	X	
4 tracks	X	X	X
8 tracks		X	X
16 tracks			X

## LIPSYNC

Range for PAL: From -41,458 ms to 14,708 ms ➔ 848 to 3544 (samples)

With 0 ms = 2838

Range for NTSC: from -34,625 to 12,125 ms ➔ 688 to 2932 (samples)

With 0 ms = 2350

The Lipsync parameter is the delay (in ms) between video and audio signals. A positive value means video is ahead of audio. A negative value means audio ahead of video.

This parameter is also available from the **Setup** menu of the Remote when the Multicam application is started. Changing the Lipsync value in the **Setup** menu will update it in the EVS menu and vice versa.

**CTRL+UP ARROW** or **CTRL+DOWN ARROW** changes the value per 1 ms step. **CTRL+LEFT ARROW** or **CTRL+RIGHT ARROW** changes the value per 5 ms step. The operator can also enter directly a value with the keyboard.



### Note:

This adjustment is done during the RECORD process. A new Lipsync value will apply for the next recorded pictures only.

---

## AUDIO FULL SCALE

Range of value: [10...30] dBu

The audio full scale parameter (in dB) specifies the maximum audio level for the analogue outputs on the server.

It allows to indirectly define the head room, as the audio full scale is 4 dB higher than the head room. As the default value for the audio full scale is 22 dB, the default value for the head room is 18.

Change the value per 1 dBu step by pressing **CTRL+UP ARROW** or **CTRL+DOWN ARROW** or per 3 dBu step by pressing **CTRL+LEFT ARROW** or **CTRL+RIGHT ARROW**.

## REC 1 ON ALL REC

Possible values: [Yes or No]

All audio channels associated to REC1 (CAM A) will be automatically used for all other RECORD channels if 'Yes' is selected.

## 3D DUAL-STREAM

Possible values: [OFF or ON]

This parameter activates the 3D Dual-Stream option, which makes it possible to use the server to record and playback 3D video. The parameter is only available for users who have subscribed to the 3D Dual-Stream option (license code 23).

When the 3D Dual-Stream is set to ON, a message informs the user that the video and player configuration will automatically be adapted into a compatible configuration. For more information on the 3D Dual-Stream feature, please refer to the section 1.3.6 '3 D & 1080p Dual-Stream Management', on page 23.

## ANCILLARY MODE

Possible values: [20 bits or 24 bits]

This parameter defines the encoding method used for Digital Audio.

This parameter is solely applicable in SD, allowing you to have the output of the embedded audio in 20 or 24 bits. In HD, it is always 24 bits.

## SAMPLE RATE CONVERTER

Possible values: [OFF or ON]

This parameter is available with AES/EBU audio format.

If this parameter is set to OFF, the user has to ensure that the signals are properly synchronized.

## 1.3.4 CHANNELS OVERVIEW

Channels input/output and name are automatically defined according to the parameters entered in the fields: Base configuration, Video Players, Video Recorders and SLSM Rec.

The player channels are allocated first (starting with OUT1), then the record channels are allocated (starting with IN1).



### Note:

To modify the parameters included in the "Channels' area", press **F3** to enter the Advanced Configuration mode

---

## TYPE

Possible values: [Rec, Play, SLSM Rec, SLSM Rec. 1, SLSM Rec. 2, SLSM Rec. 3]

This parameter is automatically set according to the settings of the previous ones. It defines the type of channel and depends on the values of Video Players, Video Recorders and SLSM Rec.

## CTRL

Possible values: [Sony, DD35, VDCP, VDCP F&K, Odetics, Odetics F&K, Edit Rec, AVSP, LinX, IPDP]

This parameter defines which system or protocol controls the current channel. This parameter is automatically set and not editable when the Base Configuration is set to LSM or Video Delay.

## PORT

Range: [1 ... 6]

This parameter defines the RS422 port number that controls each channel. These fields are not available with LSM and Video Delay configurations.



### Note:

A single Sony BVW serial connection can control multiple PGM channels which are ganged on an XT server. It is therefore possible to assign the same RS422 port number (#n), which corresponds to a Sony BVW protocol, to several PGM channels on the same XT server.

A single Odetics or VDCP serial connection can control two PGM paired channels, in a Fill and Key configuration, on an XT server. It is therefore possible to assign the same RS422 port number (#n), which corresponds to a VDCP or Odetics protocol, to the Fill and Key player channels of one XT server. The first channel will be assigned as the Fill channel and the second will automatically be the Key channel.

---

## REC

For a player channel, this parameter defines which record train is the default source.

For a recorder channel, two parameters are available:

- Recording Capacity: (% Disk) Percentage of disk space allocated to each channel. Total of all values must not exceed 100%.
- Loop/No Loop: depends on the value of Loop Rec, previously described. Always forced to "Loop" with the current version.

## AUDIO TRACKS

The audio tracks are listed from A1 up to A16:

- A1 to A16 IN: Mono audio inputs of the current channel.
- A1 to A16 OUT: Mono audio output of the current channel.

### *Audio Format*

Possible values: [Analog (A), Digital AES/EBU (D), Dolby E AES (DY), Embedded (E), Dolby E Embedded (EY)]

The available values depend on the type of audio connectors defined in EVS hardware configuration:

None	16 XLR Analog	16 XLR Digital	16 XLR Analog + 8 XLR Digital 16 XLR Analog + 16 BNC Digital 16 XLR Analog + 4 DB15 Digital 4 DB15 Analog + 16 BNC Digital 4 DB15 Analog + 4 DB15 Digital
E - EY	E - EY - A	E - EY - D - DY	E - EY - A - D - DY

## Audio Channel

Range: [1 ... 64]

This parameter allows selecting each audio channel in the selected audio format. In 16 audio configurations, the **PAGE DOWN** and **PAGE UP** keys make it possible to navigate through the list of 16 audio channels.

The values depend on the audio format and available connectors:

	Analog (A)	Digital (D - DY)	Embedded (E - EY)
Embedded only	n/a	n/a	1 – 64
16 XLR Analog	1 – 8	n/a	1 – 64
16 XLR Digital	n/a	1 – 16	1 – 64
16 XLR Analog + 8 XLR Digital	1 – 8	1 – 8	1 – 64
16 XLR Analog + 16 BNC Digital or 16 XLR Analog + 4 DB15 Digital	1 – 8	1 – 16	1 – 64

In an Embedded configuration, the audio output is also sent in AES and Analogue formats. In an AES configuration, the audio output is also sent in analogue format.

The following tables specify the outputs the audio is sent to in the various audio formats at the same time. The following tables apply to a 6U configuration:

None / 16 XLR D / 16 BNC D / 4 DB15 D + 16 XLR A								
4 tracks	PGM1				PGM2			
Embedded	E1	E2	E3	E4	E9	E10	E11	E12
AES	D1	D2	D9	D10	D3	D4	D11	D12
Analog	A1	A2	A5	A6	A3	A4	A7	A8

	PGM3				PGM4			
Embedded	E17	E18	E19	E20	E25	E26	E27	E28
AES	D5	D6	D13	D14	D7	D8	D15	D16
Analog								

	PGM5				PGM6			
Embedded	E33	E34	E35	E36	E41	E42	E43	E44
AES								
Analog								

None / 16 XLR D / 16 BNC D / 4 DB15 D + 16 XLR A																
8 tracks	PGM1								PGM2							
Embedded	E1	E2	E3	E4	E5	E6	E7	E8	E9	E10	E11	E12	E13	E14	E15	E16
AES	D1	D2	D3	D4	D5	D6	D7	D8	D9	D10	D11	D12	D13	D14	D15	D16
Analog	A1	A2	A3	A4	A5	A6	A7	A8								

	PGM3								PGM4							
Embedded	E17	E18	E19	E20	E21	E22	E23	E24	E25	E26	E27	E28	E29	E30	E31	E32
AES																
Analog																

	PGM5								PGM6							
Embedded	E33	E34	E35	E36	E37	E38	E39	E40	E41	E42	E43	E44	E45	E46	E47	E48
AES																
Analog																

None / 16 XLR D / 16 BNC D / 4 DB15 D + 16 XLR A																
16 tracks	PGM1															
Embedded	E1	E2	E3	E4	E5	E6	E7	E8	E9	E10	E11	E12	E13	E14	E15	E16
AES	D1	D2	D3	D4												
Analog	A1	A2														

	PGM2															
Embedded	E17	E18	E19	E20	E21	E22	E23	E24	E25	E26	E27	E28	E29	E30	E31	E32
AES	D5	D6	D7	D8												
Analog	A3	A4														

	PGM3															
Embedded	E33	E34	E35	E36	E37	E38	E39	E40	E41	E42	E43	E44	E45	E46	E47	E48
AES	D9	D10	D11	D12												
Analog	A5	A6														

	PGM4															
Embedded	E49	E50	E51	E52	E53	E54	E55	E56	E57	E58	E59	E60	E61	E62	E63	E64
AES	D13	D14	D15	D16												
Analog	A7	A8														

## Audio Gain

Range: [from -78dB to +23.5dB]

This parameter allows the operator to adjust the audio gain for each audio track. CTRL+UP ARROW or CTRL+DOWN ARROW changes the value per 0.75 dB step. CTRL+LEFT ARROW or CTRL+RIGHT ARROW changes the value per 6 dB step.

## AUDIO MONITORING (A. MON.)

This parameter defines the audio monitoring outputs, selects the type of audio and allows adjusting the audio gain for each channel.

## 1.3.5 DOLBY AUDIO MANAGEMENT

### SOME DEFINITIONS

**Dolby Digital** or Dolby 5.1 or AC-3, is an audio coding system containing up to 6 discrete channels of sound, with 5 channels for normal-range speakers (20 Hz - 20,000 Hz) (Right front, Center, Left Front, Right Rear and Left Rear) and one channel (20 Hz - 120 Hz) for the LFE, or subwoofer.

**Dolby E** is a professional coding system optimized for the distribution of surround and multichannel audio through two-channel postproduction and broadcasting infrastructures, or for recording surround audio on two audio tracks of conventional digital video tapes, video servers, communication links, switchers, and routers.

### DOLBY CONFIGURATIONS IN XT[2] SERVERS

**Case 1: The 5.1 audio signal is carried on 6 discrete PCM audio channels**

- Available on an XT2 in all configurations
- The audio can be analogue, digital or embedded depending on the configuration
- In AES audio, if the audio is correctly genlocked to the video, the sample rate converter can be switched off.

**Case 2: The 5.1 audio signal is coded in the two-channels Dolby E standard**

- Dolby E over AES/EBU links
  - Set the configuration of the pair of channels carrying the Dolby E signal to "DY" in the AVCFG. This has two effects :
- It disables the sample rate converter on the input channels
- It forces all transitions to a hard cut.

If the sample rate converter is activated and the audio configuration is a mix between PCM audio over AES and Dolby E over AES, the sample rate converter will only be applied to the PCM over AES signal.

- Dolby E Embedded in the SDI/HD SDI stream
  - Set the configuration of the pair of channels carrying the Dolby E signal to "EY" in the AVCFG. This will force the transition to a hard cut.
  - The sample rate converter parameter does not apply to embedded audio.

The Dolby E transitions will be correct as long as:

- the configuration is correct
- the AES stream containing Dolby E is correctly synchronized with the video

Dolby E transitions will not be correct (2 frames of mute at the transitions) if the AVCFG is set to E instead of EY or D instead of DY.

Audio effects (scrub, slow motion) are not possible in Dolby E. If they are used anyway, the audio will be muted.

## 1.3.6 3 D & 1080P DUAL-STREAM MANAGEMENT

### PRINCIPLE

The 3D and 1080p features is based on the use of two physical channels (recorders or players) seen by the server as a logical channel. Consequently, two physical recorders or players are required but only one is assigned in the Channels Configuration. These two configurations require the record and playout on synchronous channels.

LSM 2REC 4PLAY		Channels Config		Lock Video Conf:No		
Base Config:Multicam LSM		Loop Rec:Yes		Clip Capacity:Global		
Video Players : 2		Video Recorders:1		SLSM Rec:None		
Audio Format : Embedded (E)		Lipsync (ms): 2.00		Audio Full Scale: 22 dBu		
Audio Type : 8 Tracks		REC1 on all REC: No		3D Dual-Link: ON		
Ancillary Mode: 24 bits						
Type Ctrl Rec.	1	2	3	4	5	6
	OUT1 - PGM1	OUT2 - PGM1	OUT3 - PGM2	OUT4 - PGM2	IN1 - CAM A	IN2 - CAM A
	3D PL.A1	3D PL.A2	3D PL.B1	3D PL.B2	3D RECA1	3D RECA2
	LSM	LSM	LSM	LSM	LSM	LSM
	A1	E 01 0 dB	E 09 0 dB	E 01 0 dB	100% Loop	
	A2	E 02 0 dB	E 10 0 dB	E 02 0 dB		
	A3	E 03 0 dB	E 11 0 dB	E 03 0 dB		
	A4	E 04 0 dB	E 12 0 dB	E 04 0 dB		
	A5	E 05 0 dB	E 13 0 dB	E 05 0 dB		
	A6	E 06 0 dB	E 14 0 dB	E 06 0 dB		
	A7	E 07 0 dB	E 15 0 dB	E 07 0 dB		
	A8	E 08 0 dB	E 16 0 dB	E 08 0 dB		
A.Mon	1 E-01 Out 0 dB	2 E-02 Out 0 dB	3 E-03 Out 0 dB	4 E-04 Out 0 dB		
Select the ancillary data mode for embedded audio : 20 or 24 bits						

### POSSIBLE CHANNELS CONFIGURATIONS

The possible video configurations are:

- 1IN 2 OUT
- 2IN 1 OUT

### 3D CONFIGURATION

With the 3D feature, the two physical cameras will record the same scene with a slightly different angle to mimic the angle difference between the human eyes.

The configuration is set up in the Channels Configuration screen, via the 3D Dual-Stream option. See also the section '3D Dual-Stream', on page 17.

### 1080P CONFIGURATION

With the 1080p feature, the two physical cameras make it possible to get the progressive image scan with a vertical resolution of 1080 pixels.

The configuration is adapted in the AVCFG when you select the 1080p video standard in the AVCFG main screen. See also the section 'Video & Audio Area', on page 37.



### Important

When you activate or deactivate the 1080p video standard, it is highly recommended to check and set manually the desired channel configuration in the Channels Configuration screen before you launch the requested application.

## 1.3.7 HYPERMOTION MANAGEMENT

### PRINCIPLES

The hypermotion cameras can now be controlled by the LSM Remote Panel. The camera is linked via a RS422 or GbE connector to the same XT[2] server as the controlling Remote Panel.

In setups including a hypermotion camera, the following principles apply:

- An XT[2] server cannot control more than one hypermotion camera.
- The hypermotion camera is used with the classical channel configurations.
- Not all Multicam LSM configurations with several PGMs and several Remotes are supported within the current RS422 and channel configuration constraints.
- If the **Recorder Mode** setting on the Remote Panel setup (page 6.4, F3) is set to 'Hypermotion only', an additional Remote Panel is made available in the Main menu of the LSM Remote.



### REMOTE PANEL ASSIGNMENT

In setups where several LSM Remotes and a hypermotion camera are defined, the assignment of the various PGMs and hypermotion camera to the Remote Panels is automatically performed as shown in the table below depending on:

- the number of PGMs in the selected channel configuration
- the selected Remote Mode (Hypermotion only or Hypermotion + LSM)
- the number of Remote Panels available

The following table presents the possible configurations:

# of Remotes	1		2		3		4	
Hypermotion Mode	Hyperm. Only	Hyperm. + LSM	Hyperm. Only	Hyperm. + LSM	Hyperm. Only	Hyperm. + LSM	Hyperm. Only	Hyperm. + LSM
1 OUT	NA	R1: PGM1 +hyperm.	R1: PGM1 R2: hyperm.	NA	NA	NA	NA	NA
2 OUT	NA	R1: PGM1 +PGM2 +hyperm.	R1: PGM1 +PGM2 R2: hyperm.	R1: PGM1 R2: PGM2 +hyperm.	R1: PGM1 R2: PGM2 R3: hyperm.	NA	NA	NA
3 OUT	NA	R1: PGM1 +PGM2 +PGM3 +hyperm.	R1: PGM1 +PGM2 +PGM3 R2: hyperm.	R1: PGM1 +PGM2 +PGM3 R2: PGM3 +hyperm.	R1: PGM1 +PGM2 R2: PGM3 R3: hyperm.	R1: PGM1 R2: PGM2 R3: PGM3 +hyperm.	R1: PGM1 R2: PGM2 R3: PGM3 R4: hyperm.	NA
4 OUT	NA	R1: PGM1 +PGM2 +PGM3 +hyperm.	R1: PGM1 +PGM2 +PGM3 R2: hyperm.	R1: PGM1 +PGM2 +PGM3 R2: PGM4 +hyperm. <u>OR</u> R1: PGM1 +PGM2 R2: PGM3 +PGM4 +hyperm.	R1: PGM1 +PGM2 R2: PGM3 +PGM4 R3: hyperm.	R1: PGM1 +PGM2 R2: PGM3 R3: PGM4 +hyperm.	R1: PGM1 +PGM2 R2: PGM3 R3: PGM4 R4: hyperm.	R1: PGM1 R2: PGM2 R3: PGM3 R4: PGM4 +hyperm.

'PGM1+PGM2' can represent the 2PGMs mode as well as the PGM/PRV mode.



### Important

The cells with 'NA' correspond to impossible configurations taking into account the existing constraints. In this case, the Hypermotion option is not available in the operational menu even if the Hypermotion setting is set to 'Yes'.


## 1.3.8 OSD, VIDEO AND AUDIO SIGNALS ON COHX IN REC/PLAY

Embedded audio is present on the monitoring of the codecs in rec.


The following table summarizes what is present on each of the BNC of a COHX input/output.

COHX rear panel connector


### SD Mode - Input




### HD Mode - Input



## SD Mode - Output



## HD Mode - Output



### SD Codec in Rec

BNCs	Video	Embedded Audio (if present at input)	Delay	Phase
J8	SD Input	n/a	n/a	n/a
J6	SD signal of J8 (IN1)	Audio of J8	n/a	n/a
J7	SD signal of J8	Audio of J8	n/a	n/a
J3	Hardware loop of BNC 1	Audio of BNC 1	n/a	n/a
J1	SD SDI or CVBS signal of BNC 1 with OSD	Audio of BNC 1 only in SDI	n/a	n/a
J4	SD signal of BNC 1 with OSD	Audio of BNC 1	n/a	n/a

### HD Codec in Rec

BNCs	Video	Embedded Audio (if present at input)	Delay	Phase
J8	HD Input	n/a	n/a	n/a
J6	HD signal of J8 (IN1)	Audio of J8	n/a	n/a
J7	HD signal of J8	Audio of J8	n/a	n/a
J3	SD down converted signal of BNC 1	Audio of BNC 1	No*	Adjustable
J1	SD SDI or CVBS signal of BNC 1 with OSD (08.03)	Audio of BNC 1 only in SDI	No*	Adjustable
J4	HD signal of BNC 1 with OSD	Audio of BNC 1	n/a	n/a

\* No delay if the **Rec HD -> SD Low Latency** setting is set to 'ON' in the Advanced Parameters window of the selected application in the EVS software.

### SD Codec in Play

BNCs	Video	Embedded Audio (depending on the avcfg configuration)
J8	n/a	n/a
J6	SD output	Yes
J7	SD output	Yes
J3	Hardware loop of BNC 1	n/a
J1	SD SDI or CVBS output with OSD	Only in SDI
J4	SD signal output with OSD	Yes

### HD Codec in Play

BNCs	Video	Embedded Audio (depending on the avcfg configuration)
J8	n/a	n/a
J6	HD output	Yes
J7	HD output	Yes
J3	SD down converted output	Yes
J1	SD SDI or CVBS signal output with OSD	Only in SDI
J4	HD output with OSD	Yes

## 1.4 MAINTENANCE MENU

The Maintenance menu contains various options to configure and check the system. These options are described in details in the next sections.



To select an option, press the **UP ARROW** and **DOWN ARROW** keys of the keyboard to highlight the corresponding line and press **ENTER** or press the key corresponding to the character between brackets.

To go back to the Application window, press **ESC** on the keyboard.


### 1.4.1 ADVANCED PARAMETERS



#### Important

Most parameters are factory preset, and should not be modified without advice of qualified EVS staff.

Improper values for some parameters will prevent the proper operation of the system. Please refer to the parameters' charts for correct values. (See section 1.4.8 'Default Parameters', on page 47)



## HOW TO MODIFY ADVANCED PARAMETERS

1. Press **F9** to open the Maintenance menu.
  2. Select the 'Advanced Parameters' item and press **ENTER**.
  3. Press the **UP ARROW** and **DOWN ARROW** keys to select the parameter to modify and press **ENTER**.
  4. Enter the desired value, and then press **ENTER**.
  5. When all parameters are set, press **ESC**.
- A confirmation message is displayed, press **ENTER**.

## CODECS AVAILABILITY AND OPTIONS DEPENDING ON THE VIDEO STANDARD AND THE HARDWARE

### SD 625i

Codec Type	COHX		
	SD MJPEG Standard	SD IMX (D10)	DVCPro 50
Bitrate	20-100 Mbps	30 ; 40 ; 50 Mbps	50 Mbps
	Default : 30 Mbps	Default : 30 Mbps	Default : 50 Mbps
Recorded video lines	576 lines (L23-310 ; L336-623) default	608 lines (L7-310 ; L320-623)	576 lines (L23-310 ; L335-622)
	592 lines (L15-310 ; L328-623)		
	608 lines (L7-310 ; L320-623)		

### SD 525i

Codec Type	COHX		
	SD MJPEG Standard	SD IMX (D10)	DVCPro 50
Bitrate	20-100 Mbps	30 ; 40 ; 50 Mbps	50 Mbps
	Default : 30 Mbps	Default : 30 Mbps	Default : 50 Mbps
Recorded video lines	496 lines (L16-23 ; L278-525) default	512 lines (L7-262 ; L270-525)	480 lines (L23-262 ; L285-524)
	480 lines (L23-262 ; L286-525)		
	512 lines (L7-262 ; L270-525)		



**HD 1080i/1080p  
50Hz**

Codec Type	COHX										
	HD MJPEG EVS	HD MJPEG Standard	HD MPEG2 Intra	AVID DNxHD 120 Mbps	AVID DNxHD 185 Mbps	AVID DNxHD (10-bit) 185 Mbps	Apple ProRes 422 LT 85 Mbps	Apple ProRes 422 120 Mbps	Apple ProRes 422 HQ 185 Mbps	Apple ProRes 422 HQ (10-bit) 185 Mbps	DVCPro HD 100 Mbps
Bitrate (Mbps)	20-360	20-360	20-360	1-120	121-185	121-185	85	120	185	185	100
	Default : 100	Default : 100	Default : 100	Default: 120	Default : 185	Default : 185	Default: 85	Default: 120	Default: 185	Default: 185	Default : 100
Horizontal Resolution	960	960	960	1920	1920	1920	1920	1920	1920	1920	1440
	1152	1152	1152								
	1280 (default)	1280 (default)	1280 (default)								
	1372	1372	1372								
	1440	1440	1440								
	1536	1536	1536								
	1600	1600	1600								
	1920	1920	1920								

**HD 1080i/1080p  
59,94Hz**

Codec Type	COHX										
	HD MJPEG EVS	HD MJPEG Standard	HD MPEG2 Intra	AVID DNxHD 145 Mbps	AVID DNxHD 220 Mbps	AVID DNxHD (10-bit) 220 Mbps	Apple ProRes 422 LT 102 Mbps	Apple ProRes 422 145 Mbps	Apple ProRes 422 HQ 220 Mbps	Apple ProRes 422 HQ (10-bit) 220 Mbps	DVCPro HD 100 Mbps
Bitrate (Mbps)	20-360	20-360	20-360	1-145	146-220	146-220	102	145	220	220	100
	Default: 100	Default: 100	Default: 100	Default: 145	Default: 220	Default: 220	Default: 102	Default: 145	Default: 220	Default: 220	Default : 100
Horizontal Resolution	960	960	960	1920	1920	1920	1920	1920	1920	1920	1280
	1152	1152	1152								
	1280 (default)	1280 (default)	1280 (default)								
	1372	1372	1372								
	1440	1440	1440								
	1536	1536	1536								
	1600	1600	1600								
	1920	1920	1920								

**HD 720p  
50Hz**

Codec Type	COHX										
	HD MJPEG EVS	HD MJPEG Standard	HD MPEG2 Intra	AVID DNxHD 120 Mbps	AVID DNxHD 185 Mbps	AVID DNxHD (10-bit) 185 Mbps	Apple ProRes 422 LT 85 Mbps	Apple ProRes 422 120 Mbps	Apple ProRes 422 HQ 185 Mbps	Apple ProRes 422 HQ (10-bit) 185 Mbps	DVCPro HD 100 Mbps
Bitrate (Mbps)	20-360	20-360	20-360	1-120	121-185	121-185	85	120	185	185	100
	Default : 100	Default : 100	Default : 100	Default: 120	Default : 185	Default : 185	Default: 85	Default: 120	Default: 185	Default: 185	Default : 100
Horizontal Resolution	640	640	640	1280	1280	1280	1280	1280	1280	1280	960
	768 (default)	768 (default)	768								
	960	960	960								
	1024	1024	1024								
	1280	1280	1280 (default)								

**HD 720p  
59,94Hz**

Codec Type	COHX										
	HD MJPEG EVS	HD MJPEG Standard	HD MPEG2 Intra	AVID DNxHD 145 Mbps	AVID DNxHD 220 Mbps	AVID DNxHD (10-bit) 220 Mbps	Apple ProRes 422 LT 102 Mbps	Apple ProRes 422 145 Mbps	Apple ProRes 422 HQ 220 Mbps	Apple ProRes 422 HQ (10-bit) 220 Mbps	DVCPro HD 100 Mbps
Bitrate (Mbps)	20-360	20-360	20-360	1-145	146-220	146-220	102	145	220	220	100
	Default: 100	Default: 100	Default: 100	Default: 145	Default: 220	Default: 220	Default: 102	Default: 145	Default: 220	Default: 220	Default : 100
Horizontal Resolution	640	640	640	1280	1280	1280	1280	1280	1280	1280	960
	768 (default)	768 (default)	768								
	960	960	960								
	1024	1024	1024								
	1280	1280	1280 (default)								



**Note:**

The dynamic bitrate management system modifies compression tables for each recorded field to keep the bitrate of the encoded stream as close as possible to the target. A higher bitrate means better picture quality and less storage capacity but a higher bandwidth is required. Improper values can lead to exceed disks performance, causing frozen pictures during playback.



### Important

Some video formats allowed on XT[2] hardware create clips that are not compatible with previous hardware. When an incompatible format is selected, a warning will be issued at the starting up of the application. In addition, the video format information displayed on the **Shift-F2** page of the Multicam indicates any incompatible information.

---

## VIDEO DISK BLOCK SIZE

[8 MB]

This parameter indicates the size (in KB) of data blocks to be recorded to or read from the disks.

## OPERATIONAL DISK SIZE

Range: [0...100]

This parameter indicates the percentage of the disks actually used to store the data. Restricting access to the centre part of the drives increases the performance of the system but decreases capacity.

## REC HD-> SD LOW LATENCY

Possible Values: Off / On

This parameter prevents the down converted output of the record channels from being delayed. This is very useful in setups including high resolution and low resolution servers.

## VERTICAL INTERPOLATOR AND FOUR LINES INTERPOLATION

Possible values: Off / On

This parameter enables or disables the interpolation processes. Select **off** to disable the interpolation process, or **on** to enable the interpolation process selected by the **Four lines interpolation** parameter. An interpolation process is aimed at reducing the vertical jitter of the pictures that is present during slow-motion replays.

This vertical jitter is actually caused by a violation of the frame parity when playing back the pictures at less than 100 % speed.

The process consists in re-building new frames to produce a more transparent result. These frames have to be interpolated - that is calculated by making suitably weighted averages of adjacent lines. There are 2 interpolation modes: the 2-line interpolator and the 4-line interpolator. The disadvantage of this method is that it reduces the vertical resolution. This is particularly true with the 4-line interpolator.

The user can choose between 3 modes:

**no interpolation:** maximizes the vertical bandwidth of the picture but a vertical jitter appears in "SloMo". [set 'Vertical Interpolator' to off, whatever the value of 'Four Lines Interpolation']

**2-line interpolator:** reduces the vertical jitter but the vertical bandwidth is reduced. [set 'Four lines interpolation' to off and 'Interpolation validation' to on]

**4-line interpolator:** the picture is perfectly steady but the vertical bandwidth is even more reduced. [set 'Four lines interpolation' to on and 'Interpolation validation' to on]




**Note:**

All VTRs use interpolation in PLAY VAR mode.

## 1.4.2 CONFIGURATION

This function is used to set the hardware configuration of the system (boards release numbers, port settings,...).



### HOW TO ENTER THE CONFIGURATION WINDOW

To enter the configuration window, press **F9** to open the Maintenance menu, select 'Configuration' and press **ENTER**. A double frame appears around the Configuration window, and the cursor blinks next to one of the parameters in this window part.

### HOW TO MODIFY AN ITEM IN THE CONFIGURATION WINDOW

1. Press the **UP ARROW**, **DOWN ARROW**, or **<TAB>** keys to select the desired item.
2. Press the **<SPACE BAR>** several times until the correct value appears.
3. Select another item to modify or press **ESC** to go back to the Maintenance menu.

## HARDWARE REVISIONS AREA

This area indicates, board by board, the detected hardware inside the chassis. Please refer to the XT Technical Reference Hardware manual for more information about the hardware.

Some pieces of information cannot be detected:

- **Audio In/Out:** defines the audio input and output connectors available from the rear panel.

### On a 6RU XT[2]

- 16 XLR Analog,
- 16 XLR Digital,
- 16 XLR Analog + 8 XLR Digital,
- 16 XLR Analog + 16 BNC Digital
- 16 XLR Analog + 4 DB15 Digital
- 8 XLR Analog + 16 XLR Digital
- None

### On a 4RU XT[2]

- 4 DB15 Analog + 16 BNC Digital,
- 4 DB15 Analog + 4 DB15 Digital
- None


- **Video Ch.:** the number of available video channels can be adjusted.



#### Note:

The order of the boards in this list is the same as inside the mainframe, from top to bottom. The revision of a board located in the front part of the mainframe is always written on a white label on the left front end of the board.

---



## SOFTWARE RELEASES AREA

### *LSM*

This parameter displays the version number of Multicam software installed.

### *HCT*

This parameter displays the version number and release date of HCT microcode installed.

## NETWORK AREA

### *SDTI*

Possible values: [off / 540Mbps Relay / 540Mbps Non-Relay / 1485Mbps Non-Relay]

This parameter makes it possible to enable the SDTI option and select the bandwidth of the network.

On XT[2] servers, there is one pair of SDTI connectors: XNet[2] Non-Relay connectors that can be used at either 540 or 1485 Mbps.

The SDTI circuit is closed only when the Multicam software is started.



#### **Important**

The SDTI bandwidth must be identical on all XT[2] servers connected to the XNet.

If one system is configured with a different bandwidth, it will block the entire network.

The Disk Block Size parameter must be the same on all XT[2] servers.

---

### *Net Name*

The Net name defines the machine name on the network. This name is user-defined but cannot exceed 8 characters. Entering a Network Name is not mandatory because a network number is also assigned to the system, but it is recommended to easily identify all servers connected to the XNet.

## *Net Number*

Range: [1 ... 29]

The Net Number parameter defines the machine number on the network. This number is user-defined and must be unique for each system on the network. When entering a new number if this number is already assigned to another machine, an error message will warn the user.

## *Type*

Possible values: [Client, Master, Server]

The type defines the privileges of the XT[2] server on the SDTI network. One XT[2] server on the network should be set to **Server** type. If no server is defined, XNet will not be activated. If more than one server is defined, only the first one to connect will be the actual server.

Other XT[2] servers on the network can be set either to **Master** type if they need to access clips from other servers, or to **Client** type if their clips must be available on the network but they don't need to access clips from other servers.

	Allowed to access the content of all XT[2] servers on the network	Can be accessed by other XT[2] servers on the network
SERVER	Yes	Yes
MASTER	Yes	Yes
CLIENT	No	Yes

## *DB Size*

Possible value: [32000 clips]

This parameter defines the size of the network database, i.e. the maximum number of clips that can be created for the entire SDTI network.

## VIDEO & AUDIO AREA

### *Std*

This parameter allows selecting the video standard:

- 625i 50.00 PAL (default for SD)
- 525i 59.94 NTSC
- 525i 59.94 NTSC Japan
- 1080i 50.00 PAL (default for HD)
- 1080i 59.94 NTSC

- 1080i 59.94 NTSC Japan
- 1080p 50.00 PAL
- 1080p 59.94 NTSC
- 1080p 59.94 NTSC Japan
- 720p 50.00 PAL
- 720p 59.94 NTSC
- 720p 59.94 NTSC Japan

## ***Aspect Ratio***

In High Definition, this parameter allows the user to select the format of the image for the down converted outputs of the XT[2] (not used in SD configurations).

<b>4:3 L Box</b>	letterbox ( <i>default</i> ), the entire width of the 16:9 original picture is shown, but there are black panels horizontally above and below the picture.
<b>4:3 Crop</b>	the sides of the 16:9 picture are cut off but the 4:3 frame is filled.
<b>16:9</b>	anamorphic, widescreen mode. The 16:9 picture area is squeezed horizontally to fit inside the 4:3 space.

In Standard Definition, the parameter defines the aspect ratio of the incoming video feeds to adjust the aspect ratio of the graphics when drawing circles in Target Tracking and Painting modes, and for third party usage, Xedio for instance.

## ***SD Mon OUT***

Possible values: [CVBS or SDI]

This parameter specifies the type of output monitoring.

## ***SD Edge Enhancement***

Range: [0 – 200%] (Default 66%)

This parameter specifies the value of the edge enhancer for the SD down converted outputs of the XT[2] servers set in HD.

## ***Audio***

Possible values: [On or Off]

This parameter enables or disables the Audio.

## REF & PHASE AREA

### *Ref Type*

Possible values: [SD Black Burst, HD Tri-Level Sync]

This parameter allows selecting the genlock reference input between:

- SD Black Burst (*default*)
- HD Tri-Level Sync (HD only)

### *Sync Mode*

Possible values: [Studio mode, Resync mode]

This parameter allows selecting the frame synchronizer mode between:

- **Studio mode:** should be used when the video input signals are synchronized. (*default*)
- **Resync mode:** should be used when the video input signals are not synchronized. In this case, they will be re-synchronized on the digital I/O board. This can cause a shift of up to 3 fields between the various video input signals.

### *Genlock*

Possible values: [OK or BAD]

This information is automatically displayed.

This parameter checks if the Genlock input is valid.

### *TC In*

This parameter displays the status of the LTC input of the server, and the video format corresponding to the incoming timecode.

Ex: "TC in 12:24:45:09 PAL" or "TC in 12:24:45:09 NTSC". If no valid timecode is detected, the display will show "TC in --:--:--:-- Bad".

### *Phase*

This parameter shows the value currently set for the main video phase of the digital video outputs. Refer to the 'Phase Definition' section for details.

## 1.4.3 OPTIONS

### ACCESSING THE OPTIONS MENU

To enter the Options menu, open the Maintenance menu, then press the UP ARROW and DOWN ARROW keys to highlight the 'Options' line, and press ENTER. The Options window appears as shown below:



### INTRODUCTION

This window is used to manage software license codes for all applications. This window only displays the permanent codes you have subscribed to, as well as valid or expired temporary codes.

To run particular application software and/or specific software options, not only the software itself is required but also a license key, which is unique for every option on every system.

This license key can be temporary and be valid only until a defined deadline for demonstration purposes, or permanent with no time limit.

#### Example of line for a PERMANENT option

104	PERM	Multicam LSM Base 1 PLAY
-----	------	--------------------------

### Example of line for a TEMPORARY option

108	DEMO	Multicam LSM Base 5 PLAY
-----	------	--------------------------

### Example of line for a TEMPORARY option with From Date/To Date

109	01/12/05 to 31/12/05	Multicam LSM Base 6 PLAY
-----	----------------------	--------------------------

## DISPLAY

In the Options menu, the highlighted lines show the valid options. The red line is the current line. Press the **UP ARROW** and **DOWN ARROW** keys to move inside the options list.

When temporary options are present, the limit time for these is shown in the lower part of the Options window.

To go back to the Maintenance menu, press **ESC**.

## EXPIRATION AND WARNING

When a temporary license key is about to expire, the system will warn the operator. The warning is displayed every time the EVS software starts, from 2 weeks before the expiration date. The following message appears:

```
===== Warning =====
Demo Options will be out of date on
Dec 31, 2000 23:59:59
Please contact EVS :
Tel: 32 4 361 7000
Fax: 32 4 361 7099
E-mail: support@evs.tv

Press <ENTER> to continue
```

## HOW TO ENTER NEW LICENSE CODES

To enter new license codes, proceed in one of the following ways:

- If you have received a xxxxx.COD file (xxxxx = serial number of the server for which this file has been calculated) from EVS, copy this COD file on a USB key and press simultaneously **ALT+U** keys. The license codes will be automatically read from the USB key and updated into the system.

*or*

- You can also copy manually the xxxxx.COD file to the C:\ drive, then restart the EVS menu, enter the Options windows and press simultaneously **ALT+F** keys. The codes will be read from the local file on the C:\ drive and updated into the system.

*or*

1. Make sure the cursor blinks in the 'Option' box in the lower part of the Options windows.
2. In the **Validation Code** field, type the code corresponding to the selected option (license codes are sent by EVS Technical Support Dpt) and press **ENTER**.
3. Repeat this operation for the next license code.
4. You can check that the corresponding options are enabled by scrolling into the options list.

## HOW TO REMOVE A LICENSE CODE

To remove a license code, proceed as follows:

1. Press the **UP ARROW** and **DOWN ARROW** keys to move inside the options list and select the option that must be removed.
2. When the option is selected (white characters), press simultaneously **CTRL+DEL** on the keyboard.
3. Confirm the deletion of the option with **ENTER** or cancel with **ESC**.

## HOW TO CHECK HARDWARE KEY (DONGLE) INFORMATION

When the Options window is open, press simultaneously **ALT + I**. A new window 'Option Info' appears. The following information is available:

<b>System ID:</b>	ID code of the hardware key. This information is necessary for license code calculation. Factory setting only.
<b>User:</b>	User's name. This information is a label and is for information only. Factory setting only.
<b>Serial #:</b>	Serial number of the mainframe. The S/N is also written on the back plate of the mainframe. Factory setting only.

<b>Chassis</b>	Defines the type of mainframe (6U or 4U). If this value is wrong, audio and video routing inside the system will not work properly. Factory setting only.
<b>PSU Type:</b>	Defines the type of CPU installed on the chassis: standard or redundant.
<b>Limit time:</b>	Expiry date & time for temporary license codes. This line does not appear when the permanent codes are installed.
<b>Key time:</b>	Current date & time of the hardware key displayed in a GMT+1 Time zone (Belgium Time). This is the date used to determine whether limit time for temporary license codes has been reached or not. Factory setting only.

Press **ENTER** to go back to the Options window.

## 1.4.4 CLEAR VIDEO DISKS

This function is used to erase all media from the RAID disk array.



**Important:**

**Caution: This will definitely delete all video and audio data, including protected clip and record trains.**

To clear video disks, proceed as follows:

1. Press **F9** to open the Maintenance menu.
2. Press the **UP ARROW** and **DOWN ARROW** keys to select the **Clear Video Disks** option line and press **ENTER**.
3. Confirm the deletion with **ENTER** or cancel with **ESC**.

## 1.4.5 FORCE LOAD CLIPS

This function is used when swapping disks arrays between XT[2] servers. If clips are saved to disks, this command forces the system to re-load the clips.

To force loading of clips, proceed as follows:


1. Press **F9** to open the Maintenance menu.
2. Press the **UP ARROW** and **DOWN ARROW** keys to select the **Force Load Clips** option line and press **ENTER**.
3. Confirm the reloading with **ENTER** or cancel with **ESC**.

## 1.4.6 PHASE DEFINITION

This option is used to adjust the digital phase of the mainframe.

### STANDARD DEFINITION

If the REF TYPE (see Configuration windows) is set to 'SD BlackBurst', the phase definition window is as follows:




The image shows a 'Phase Definition' window with a teal background. At the top, it says 'Main Phase Value <SD>: 0 half pixel <37 ns>'. Below this is a horizontal slider bar with a black square in the center. The left end of the bar is labeled '[-12000]' and the right end is labeled '[15000]'. At the bottom of the window, there is a line of text: '<ENTER> Validate <ESC> Cancel ↔ Mod Main Ph ↑↓ Mod Sec Ph'.

The phase value for SD can be adjusted between - 12000 ns and +15000 ns by 37 ns steps.

### HIGH DEFINITION


If the REF TYPE is set to 'SD BlackBurst' and if the system is configured for HD, the phase definition window appears as follows:



The image shows a 'Phase Definition' window with a teal background. It has two sections. The top section is 'Main Phase Value <SD>: 0 half pixel <37 ns>' with a slider bar ranging from '[-12000]' to '[15000]'. The bottom section is 'Secondary Phase Value <HD to SD SDI>: 0 half pixel <13.5 ns>' with a slider bar ranging from '[-1000]' to '[1000]'. At the bottom of the window, there is a line of text: '<ENTER> Validate <ESC> Cancel ↔ Mod Main Ph ↑↓ Mod Sec Ph'.

The main phase value for SD can be adjusted between - 12000 ns and +15000 ns by 37 ns steps and the secondary phase value (relative phase of the HD SDI outputs compared to the phase of the SD SDI outputs) can be adjusted between - 1000 ns and +1000 ns by 13.5 ns steps

If the REF TYPE is set to 'HD Tri-Level Sync', the phase definition window is as follows:



Phase Definition

Main Phase Value <HD>: 0 half pixel <13.5 ns>

[-30000] [32000]

Secondary Phase Value <SD SDI to HD>: 0 half pixel <37 ns>

[-400] [400]

<ENTER> Validate <ESC> Cancel <=> Mod Main Ph <↑> Mod Sec Ph

The main phase value for HD can be adjusted between - 30000 ns and +32000 ns by 13.5 ns steps and the secondary phase value (relative phase of the SD SDI outputs compared to the phase of the HD SDI outputs) can be adjusted between - 400 ns and +400 ns by 37ns steps

## COMMANDS

- Press the **LEFT ARROW** and **RIGHT ARROW** keys to adjust the main phase value by half pixel (i.e. SD: 37 ns or HD:13.5 ns) steps or type in the value in the **Phase Value** field.
- Press the **CTRL+LEFT ARROW** and **CTRL+RIGHT ARROW** keys to adjust the phase value by 1-line (i.e. 1440 in SD; 2880 half pixel in HD 720p; and 3840 half pixel in HD 1080i) steps.
- Press the **<TAB>** key to toggle between **Main Phase** and **Secondary Phase** fields.
- Press the **UP ARROW** and **DOWN ARROW** keys to adjust the secondary phase value by half pixel (i.e. SD: 37 ns or HD:13.5 ns) steps or type in the value in the **Phase Value** field.
- Press **ENTER** to save the new values and return to the Maintenance menu or press **ESC** to go back to the Maintenance menu without saving the changes.



### Important note 1:

The SD phase is always adjusted according to the SDI outputs. Internal CVBS outputs have a delay of 48 x 37 nsec compared to the corresponding SDI outputs.



### Important note 2:

The internal CVBS outputs cannot be used to feed directly a vision mixer or any equipment performing video effects, since the phase of the chroma subcarrier is not adjustable internally.

## 1.4.7 DEFAULT APPLICATION

This option is used to define the default application that is automatically started by the system. Every time the EVS software is entered, the default application is started a few seconds later. You can avoid the automatic start by pressing the **<SPACE BAR>** or the **UP ARROW** and **DOWN ARROW** keys immediately when entering the EVS software. If no default application has been defined, the system will remain in the EVS software.

The default application is shown against a black background in the Application window.

### HOW TO DEFINE A DEFAULT APPLICATION

- In the Application window, select the new default application using the **UP ARROW** and **DOWN ARROW** keys and press **F7**

OR:

- Call the Maintenance menu with **F9** and select 'Default Application', select the defined application from the list, and press **ENTER**
  - If a default application was already defined, a message warns the operator that it will be disabled. The command can be confirmed with **ENTER** or cancelled with **ESC**.
  - If the command is confirmed, another message warns the operator that a new default application has just been defined.

### HOW TO REMOVE THE DEFAULT APPLICATION

- In the Application window, select the application that is the current default application (blue characters with black background) using **UP ARROW** and **DOWN ARROW** keys, and press **F7**.

OR:

- Call the Maintenance menu with **F9** and select 'Default Application'. Then select the current default application from the list and press **ENTER**.

A message warns the operator that the current default application will be disabled. The command can be confirmed with **ENTER** or cancelled with **ESC**.

## 1.4.8 DEFAULT PARAMETERS

This command erases all current parameter settings and restores the default factory settings for all applications. When selecting this option, you are asked to confirm the command or cancel it.

### DEFAULT PARAMETERS FOR ALL APPLICATIONS

Multicam LSM	Replay Only LSM	HD XT[2] 6U	HD XT[2] 4U
00 LSM Custom	00 LSM Custom	Y	Y
01 LSM 1REC 1PLAY	01 R.O. LSM 1REC 1PLAY	Y	Y
02 LSM 1REC 2PLAY	02 R.O. LSM 1REC 2PLAY	Y	Y
03 LSM 2REC 1PLAY	03 R.O. LSM 2REC 1PLAY	Y	Y
04 LSM 2REC 2PLAY	04 R.O. LSM 2REC 2PLAY	Y	Y
05 LSM 2REC 4PLAY	05 R.O. LSM 2REC 4PLAY	Y	
06 LSM 3REC 1PLAY	06 R.O. LSM 3REC 1PLAY	Y	Y
07 LSM 3REC 2PLAY	07 R.O. LSM 3REC 2PLAY	Y	
08 Triple LSM	08 R.O. Triple LSM	Y	
09 LSM 4REC 1PLAY	09 R.O. LSM 4REC 1PLAY	Y	
10 LSM 4REC 2PLAY	10 R.O. LSM 4REC 2PLAY	Y	
11 SLSM 1PLAY	11 R.O. SLSM 1PLAY	Y	Y
12 SLSM 2PLAY	12 R.O. SLSM 2PLAY	Y	Y
13 SLSM + 1REC 1PLAY	13 R.O. SLSM + 1REC 1PLAY	Y	Y
14 SLSM + 1REC 2PLAY	14 R.O. SLSM + 1REC 2PLAY	Y	
15 SLSM + 2REC 1PLAY	15 R.O. SLSM + 2REC 1PLAY	Y	
16 SLSM + 2REC 2PLAY	16 R.O. SLSM + 2REC 2PLAY	Y	

Line	0	1	2	3	4	5	6	7	8
Application	LSM Custom	LSM 1REC 1PLAY	LSM 1REC 2PLAY	LSM 2REC 1PLAY	LSM 2REC 2PLAY	LSM 2REC 4PLAY	LSM 3REC 1PLAY	LSM 3REC 2PLAY	Triple LSM
Video Players	1	1	2	1	2	2	1	2	3
Video Recorders	1	1	1	2	2	4	3	3	3
Type of REC 1	1	1	1	1	1	2	1	1	1
Audio Format	Analogue	Analogue	Analogue	Analogue	Analogue	Analogue	Analogue	Analogue	Analogue
Audio Type	Stereo	Stereo	Stereo	Stereo	Stereo	Stereo	Stereo	Stereo	Stereo
Recorders Configuration (% Disk) *	100	100	100	50/50	50/50	50/50	33/33/33	33/33/33	33/33/33
Operational Disk Size	90	90	90	90	90	90	90	90	90
Video Bitrate (SD)	30	30	30	30	30	30	30	30	30
Video Bitrate (HD)	100	100	100	100	100	100	100	n/a	n/a
4-line interpolation	1	1	1	1	1	1	1	1	1
Interpolation Validation	0	0	0	0	0	0	0	0	0
Line	9	10	11	12	13	14	15	16	
Application	LSM 4REC 1PLAY	LSM 4REC 2PLAY	SLSM 1PLAY	SLSM 2PLAY	SLSM+1REC 1PLAY	SLSM+1REC 2PLAY	SLSM+2REC 1PLAY	SLSM+2REC 2PLAY	
Video Players	1	2	1	2	2	1	1	1	
Video Recorders	4	4	1	1	2	3	3	3	
Type of REC 1	1	1	2	2	2	2	2	2	
Audio Format	Analogue	Analogue	Analogue	Analogue	Analogue	Analogue	Analogue	Analogue	
Audio Type	Stereo	Stereo	Stereo	Stereo	Stereo	Stereo	Stereo	Stereo	
Recorders Configuration (% Disk) *	25/25/25/25	25/25/25/25	100	100	75/25	75/25	60/20/20	60/20/20	
Operational Disk Size	90	90	90	90	90	90	90	90	
Video Bitrate (SD)	30	30	30	30	30	30	30	30	
Video Bitrate (HD)	n/a	n/a	n/a	n/a	n/a	n/a	n/a	n/a	
4-line interpolation	1	1	1	1	1	1	1	1	
Interpolation Validation	0	0	1	1	1	1	1	1	

XT Spotbox**	XT server**	HD XT[2]	HD XT[2]
00 Custom	00 Custom	Y	Y
01 XT SpotBox BVW75	01 XT Server BVW75	Y	Y
02 XT SpotBox DD35	02 XT Server DD35	Y	Y
03 XT SpotBox Odetics	03 XT Server Odetics	Y	Y
04 XT SpotBox VDCP	04 XT Server VDCP	Y	Y
05 XT SpotBox AVSP	05 XT Server AVSP	Y	Y

\* (% per channel). Ex: 50/50 means 2 record channels, 50% of available storage for each channel.

\*\* All Spotbox/Server lines are similar to the LSM Custom line

## 1.4.9 DEFAULT TO VGA

Between the PC boot and the I/O boot, the video driver is loaded and the display is switched to one of the following mode:

- VGA mode
- B&W video mode, allowing the VGA screen to be displayed on a standard composite video monitor using the VGA↔BNC adapter provided with the unit.



**Note:**

At start-up, the keys' combination **ALT + <Backspace>** on the keyboard is still available for switching from one mode to the other.

## 1.4.10 TS CALIBRATION

When the Touch Screen option is installed, it can be calibrated using this command. If the Touch Screen is not installed, a warning message is displayed.

## 1.4.11 SET TIME

The Set Time command allows adjusting the system time & date.

Example of time format:

22:58:00 for 22 h 58 min 00 sec (24 hour display)

Example of date format (dd-mm-yyyy):

24-10-2007 for October 24, 2007

15-03-2008 for March 15, 2008

## 1.4.12 HARDWARE CHECK / RAID REBUILD

The purpose of this tool is to check the hardware and to verify the validity of the data recorded on the video disk array. After the selection of this command from the Maintenance menu, the system automatically starts the test process.

One after the other, the different stages are displayed in the BOOT.HCTX window. The test process is complete when the HCTX board is initialized.



**Important:**

Hardware check is also used to rebuild the video and audio information after replacing a faulty disk.

## DISK ERRORS AND DISCONNECTION

### *Disconnection*

When one disk of the video raid array has sustained errors, the Multicam automatically disconnect that disk and use the parity disk to rebuild the missing data and provide the video and audio data blocks to the application. The operator can thus continue working normally and the message "!" appears on all monitoring outputs.

## Exit

When exiting the Multicam application, a warning will appear to remind the operator that one disk was disconnected, and invite him to perform a hardware check to repair the video raid:

To protect disk array integrity, a disk has been disconnected. At the next opportunity please perform a hardware check to evaluate the faulty disk, and perform a rebuild to correct the problem.  
Enter: OK

## Restarting

If the Multicam is restarted without the RAID being rebuilt, the following message is blinking during the Bootwins: "SCSI Controller #C disconnected in operation!". Then when entering the Multicam, another message appears:

To protect disk array integrity, a disk has been disconnected. At the next opportunity please perform a hardware check to evaluate the faulty disk, and perform a rebuild to correct the problem.  
ESC: Exit                      Enter: Continue

The operator can press **ENTER** and operate normally on 4 disks or exit the software and return to EVS menu to run a Hardware Check.

## DISKS MONITORING

The 1<sup>st</sup> page of the Server Monitoring screen allows disk monitoring. Press **Shift-F5** to access this screen:

SH+ESC:UGA EXPLORER

SERVER MONITORING

Sh+F4:Network Monitoring F9:CLIP F10:PLST

/Zi

Disk Status

Raid Map

Raid 0

Raid 1

Raid 2

0/A 3/D Dsk!

Ok

Ok

Ok

Ok

Ok

Ok

1/B 2/C 4/E

Ok

Ok

Ok

/

Ok

Ok

Ok

/

Ok

Rebuild 26.92%

Genlock status

Analog LTC status

OK since 19/11/07 - 16:01:39

10:47:59:11 <LOST> Drifts : 000

TimeCode Status

Rec1 Rec2 Rec3

LTC

LTC jumps

LTC threshold

Peak alerts

Peak Limit (sec)

Frequency alerts

Frequency: Number

Frequency: Time

USER

USER jumps

USER threshold

005

005

005

050

050

050

004

004

004

010

010

010

000

000

000

010

010

010

050

050

050

004

004

004

050

050

050

TAB:SELECT <-/->:CHANGE

PgDn:Pg2

ALT+Q:EXIT MULTICAM

In the Disk Status section, the screen indicates the position of the disks on the disk array and the status of each disk:

/	Not present
!Raid	Disconnected disk
OK	Disk present

When a disk is disconnected, the message "Rebuild xx.xx%" will appear next to the disk array to which the disconnected disk belongs. This value shows the advance of the rebuild process. When a disk is disconnected but new pictures are still being recorded on the disk array, this number will decrease until the disk is replaced and the rebuild process starts. The rebuild is complete when this number reaches 100%.

## REBUILD PROCESS

The XT[2] server is capable of performing a rebuild process of the SCSI RAID. This process can happen either while the Multicam application is not running (offline process – rebuild is faster) or while the Multicam application is running (online process – rebuild is slower).

### *Disconnection Process*

As explained in the previous section, the software will disconnect a disk that does not behave as expected.

Two options are available for the operator:

- Replace the disconnected disk and restart the server
  - Start the Multicam application. The rebuild process will start automatically.
  - Start a hardware check from the EVS menu and launch the rebuild. The process starts offline. The operator can wait for the rebuild to be completed or cancel it (that is to say postpone it) and start the Multicam application, in which case the rebuild carries on in online mode.
- The operator can also force the disk to be reconnected by starting the rebuild process in the hardware check. The process starts offline. The operator can wait for the rebuild to be completed or cancel it and start the Multicam application, in which case the rebuild carries on in online mode.

Maximum duration for on-line rebuild:

- 5x73GB : 16.5h
- 5x146GB : 33h
- 5x300GB : 66h
- 10x300GB : 133h
- 15x300GB : 200h

Off-line rebuild time takes about 1.5h for 5x73GB disks, 3h for 5x146GB disks, 6h for 5x300GB disks.



**Note:**

If errors are detected during the rebuild process, a message appears after the rebuild is complete to warn the operator, and the raid is not considered as properly rebuilt. In this state, the system will keep working on 4 disks. If you want to run on 5 disks again, you can try replacing the disk again and perform another rebuild, or clear all clips.

---

If you don't need to retrieve the clips or the record trains, you don't need to rebuild the RAID. In this case, select the "Clear All Clips" answer when the message with this option appears in the Hardware Check.

If you don't rebuild the RAID array or if you don't clear clips, the XT will keep running on 4 disks only, and you will see a warning message appearing every time you start or close the Multicam application. Normal operation can be achieved on 4 disks, but then, if another disk fails, the system will hang and all video and audio data will be definitely lost.



**Important:**

By default, the online rebuild process takes up 10% of the disk bandwidth. If you want to change this, contact EVS support.

---

## RETRIEVING SCSI LOGS

If you suspect that the drive disconnection in operation was not due to a severe disk failure, but perhaps to the server being too prompt to disconnect a drive, you must run a hardware check immediately after ending the session during which the disk was disconnected.

Don't rebuild the RAID, but press simultaneously the **ALT+L** keys to generate the log file C:\LSMCE\DATA\LOG\SCSI.LOG, and send this file to EVS for detailed analysis. Note that this procedure is only valid if the drive is disconnected during operation, not for a drive being disconnected when booting the system.

### 1.4.13 CLIP COMPATIBILITY BETWEEN MULTICAM VERSIONS

---



**Important:**

The clips created in version 8.4 or lower are not compatible with Multicam v.9 or higher. For this reason, you should proceed as follows before using the Multicam version 9 or higher.

---

1. Back up all the clips stored on the XT Server, for example with XFile.
2. Just after migrating from version 8.04 to the new version, perform a Clear Video Disks operation.

This is available from the Maintenance menu (F9), with the Clear Video Disks option. For more information on the Clear Clip operation, refer to section 1.4.4 'Clear Video Disks', on page 43.

Later on, you can then convert and restore any clip that has been backed up.

# 2. Bootwins & Error Messages

## 2.1 INTRODUCTION

This section of the manual describes:

- the sequences of the system initialization and the errors that might occur during this process.

These different error messages will allow the EVS engineers to identify quickly the reason of a hardware problem and to provide the operator with a relevant solution.

- the tool, called EVS Disk Doctor, which makes it possible to recover the disk data in case Multicam would not succeed in reading it when the application is started.

## 2.2 INITIALIZING THE DISKS

### *Step 1: Initialization Start*

The system is trying to initialize the SCSI hard disks.

The message "Waiting for disk information ... " appears. The procedure is started on the system to initialize hard disks.

### *Step 2: Disk Status*

A status table is displayed:

	DISK A	DISK B	DISK C	DISK D	DISK E
Board #0	READY	READY	READY	READY	READY
Board #x	READY	READY	READY	READY	READY
Primary defects	XXX	XXX	XXX	XXX	XXX
Grown defects	YYY	YYY	YYY	YYY	YYY

It gives the status of each disk of each board. The different statuses are:

<b>NOT PRESENT</b>	Disk is not found.
<b>PRESENT</b>	Disk is present but Test unit ready function failed.
<b>MAJOR ERROR</b>	A major error has been detected: Disk cannot be used.
<b>READY</b>	Disk initialization succeeded.
<b>NOT_READY</b>	Time out after attempting to start the disk.
<b>VERIFY_ERROR</b>	An error occurred while verifying sectors on the disks. The system can probably work for a while but should be disconnected in operation.
<b>LBA ERROR</b>	LBA size is not 512. System cannot work.
<b>SYS ERROR</b>	All other possible errors.



**Note:**

The information regarding primary and grown defects is only available in maintenance mode (start a hardware check in EVS maintenance menu).  
XXX is the number of primary defects found on each disks. YYY is the number of defects found on each disks.

### ***Step 3: Board Capacity Display***

After this table, the system displays the total capacity of all boards.

The message "Capacity of board #x: m.n GBytes or XXX blocs of YYY KBytes" is displayed.

where:

<b>x</b>	is the board number
<b>m.n</b>	is the size of the board in base 1024*1024*1024 (Giga bytes)
<b>XXX</b>	is the number of blocs available on the disks
<b>YYY</b>	is the size of each block

### ***Possible Error Messages***

- If a major error has been detected on a disk, it has been disconnected. In this case, the system displays the message:

"!!! SCSI CONTROLLER #X DISCONNECTED!!!"

where X is the number of the controller. It is advised to replace this disk and to rebuild its data if necessary.

In that case, start the CHECK program in EVS menu to rebuild the data.

- If more than 2 disks are faulty at start up, the system displays the message:

```
"MORE THAN 2 CONTROLLERS IN ERROR. SYSTEM CANNOT  
WORK PROPERLY".
```

In that case, the faulty disks must be replaced. Data rebuild is not possible.

- If a major error occurred on the board or the board is not correctly plugged or simply missing, the system displays the message:

```
"!!! ERROR: TIMED OUT -> SCSI BOARD #0 PROBABLY NOT  
PRESENT".
```

In that case, check the board installation. If the error persists, install a new board or contact EVS support.

## 2.3 READING THE CONFIGURATION FILE

After the disk initialization sequence, the system reads the configuration file stored on the disk. This file contains the parameters which guarantee the coherence of main parameters of the system from session to session. Those parameters are: diskBlockSize and operationalDiskSize.

The message "Reading configuration file ... please wait" is displayed during process.

### *If the Configuration File is Found on Disks*

The parameters are displayed:

Configuration	of user	on disks
block size	xxx kBytes	yyy kBytes
nbr of blocks	aaa	bbb

This table shows the parameters stored on the system ('on disks' column) and the ones from the EVS advanced parameters ('of user' column).

The values from both columns must be identical to use properly the system. If not, the system displays a warning message:

```
"A parameter incoherence has been detected" "Would you like  
to format the system".
```

Answer 'Yes' to format the A/V data saved on disks.

Answer 'No' to go back to EVS main menu.



#### **Important:**

If you answer 'Yes' and decide to format the system, all clips will be cleared. This operation is instantaneous.

## ***If the Configuration File is not Found***

A warning message appears:

"Your system is not formatted" "Would you like to format the system ?".

Answer 'Yes' to format the A/V data saved on disks.

Answer 'No' to go back to EVS main menu.

## ***If Errors Occur While Reading the Configuration File***

The following message appears:

"Error reading configuration file – status = [Err]".

The type of error [Err] can be:

---

1.	<b>Block error</b>	A disk error occurred while loading the configuration file to disks. In this case, the disks have to be replaced by new ones.
2.	<b>Cache overflow error</b>	No more memory blocks are available from the memory cache.
3.	<b>Checksum error</b>	This error might occur when a disk has been replaced but the data of this disk is not restored. For solving the problem, start the Rebuild data process.
4.	<b>Signature error</b>	The signature of the configuration file is modified or the file format is modified and then the file is not compatible with the microcode. In this case, select the Format command to correct the error.

---

If the loading duration of the configuration file is too long, a time-out error message appears:

"READ CONFIGURATION ERROR: TIMED OUT – state = [ST]".

In this case, reset the system and start again the application.

## 2.4 INITIALIZING THE MICROCODE

The final step is the initialization of the microcode.

If the first line of the application is flashing with the message "Disk #x has been disconnected in operation", the system will display the message: "Disk to be disconnected: x". The system will work on 4 disks. Raid function is turned off.

The message "Init board: nb blocks of size kBytes. Audio:aud DiskUse:use%" is displayed.

where

<b>nb</b>	is the number of blocks used on the system
<b>size</b>	is the size in kBytes of a block on a disk
<b>aud</b>	is ON/OFF
<b>use</b>	is the operationalDiskSize in %

If the system must load tables (no clear clips done in EVS main menu), the message "Loading tables ..." will appear.

When the initialization is complete, the system displays the message "HCTX board initialized" and the system is ready. If an error occurs, the message "ERROR (0xErr): HCTX board not correctly initialized" is displayed. The errors (Err) are detailed in the following section.

### *Possible Errors*

If an error is detected while loading tables, the following message is displayed: "LOAD <TAB>LE ERROR – state = [St]" where 'St' can be:

1.	<b>Block error</b>	A disk error occurred while loading the table on hard disks. Maybe a disk failure. Replace disks.
2.	<b>Cache overflow error</b>	No more blocks available in cache. Algorithm problem. Contact EVS.
3.	<b>Checksum error</b>	This can occur if a disk has been replaced and data not rebuilt on it. Rebuild data on the disk to clear the message. If no disk has been replaced, try to re-start the server to clear the error message. If it does not resolve it after a few re-start, a clear clip will be necessary.
4.	<b>Signature error</b>	The signature on the table file is not found in the header file. Try to re-start the server to clear the error message. If it does not resolve it after a few re-start, a clear clip will be necessary.

If the message "INIT ERROR: TIMED OUT – state = [St]" is displayed, it means the initialization is not complete. 'St' refers to a position in the code.



**Note:**

Never forget that to start Multicam, the bootwins must successfully initialize the microcode. In that case, the message "HCTX board initialized" is displayed. In all other error case, the boot sequence or initialization phase is cancelled and Multicam cannot be started.

---


## 2.5 DISK DATA RECOVERY

When Multicam is started, it sometimes happens that the application does not succeed in reading the data stored on the disks. However, the data is still available on the disks.

The EVS Disk Doctor has been developed to address this issue. This tool allows reconstructing the data (trains and clips) stored on the disks.

The tool scans each data block, identifies the recorder on which the data has been created and reconstructs the whole audio and video material.

The clips will also be recovered. However several overlapping clips will be recovered as one single long clip. This means that, in the schema below, the clips CD, EF and GH will be recovered as one single long clip for which the IN point will be C and the OUT point will be H.




If you want to use this tool, please contact the EVS support.

## 3. Monitoring

### 3.1 SDTI NETWORK MONITORING

The SDTI Network Monitoring screen, available via **SHIFT-F4**, enables more accurate monitoring of the SDTI network status (the screen background is black).



#### 3.1.1 INFORMATION AVAILABLE ON THE SCREEN

##### DATA DISPLAYED

All the machines are displayed in the logical connection order, i.e. the way they are effectively connected on the network.

For each machine, the following information is displayed:

- net number + name
- serial number
- main network configuration setting (server, master or client) as defined in the EVS application.

## BACKGROUND COLOR

The background color of the data related to a given machine means:

- blue: effective server
- grey: not currently server

## TEXT COLOR

The color of the text indicates the video network overload, based on how many SDTI network mailboxes are used:

- White: ok, less than 90% capacity
- Red (over 90%): risk of network overload.

## LINK COLOUR

The color of the link indicates the physical link status between two machines:

- green: OK
- red: errors

## POSSIBLE ACTIONS

- Pressing the Space bar pauses or restarts the monitoring.
- Pressing **Enter** resets the counters.
- Pressing **PgDn** displays a new screen with the information of the list of machines sorted by serial number with error counters information.

```
SH+ESC:UGA EXPLORER <SH>F3:RESET<ALL> F6:KW1 F7:KW2 F8:SRCH F9:CLIP F10:PLST
SDTI Sn PrvSn Name CpLk Frm Mb
S11L 29010 23650 mdu xt2 0000 0000 11
M01 23650 51980 MDU 1 0000 0000 11
M20 51980 29010 XFile 0000 0000 11

Refresh time: 023/030 s [+/-] Change time [F5] Refresh Station: 3/ 3
Database check: Ok [Size 00005320 Mb 000015]
<-/->: CHANGE PAGE PgDn: SN Sort RETURN: RST STAT SPACE: PAUSE
```

In operating conditions, when all machines are connected, the CpLk (electrical quality of the network) and Frm (checksum on the packets) counters should not increase at all.

At the contrary, the counters will increase during disconnection/connection of/to the network.

## 3.1.2 HOW TO DISCONNECT A MACHINE FROM THE SERVER

The operator has the possibility to disconnect a machine from the XNet network. This can be useful when setting up an SDTI network or troubleshooting an SDTI network issue. This is only possible when using a XHub from version 3.03.

To disconnect a machine from the server, proceed as follows:

1.	Press <b>SHIFT-F4</b> to access the SDTI Network Monitoring screen.
2.	<p>Press <b>CTRL-ALT-L</b> to disconnect the XHub branch from the network.</p> <p>The following warning is displayed:</p> <div><p>Warning</p><p>The network branch you are connected on will be disconnected from the network. All network actions will be disabled.</p><p>ESC: Cancel      ENTER: Confirm</p></div>
3.	Press <b>ENTER</b> to confirm that you want to disconnect the XHub branch from the network.

On the SDTI Network Monitoring screen, the following message in red font informs that the machine is disconnected and how it can be connected again:

"XHub branch disconnected from the network. Press **CTRL-ALT-L** to reconnect."

## 3.2 SERVER MONITORING

The first page of the Server Monitoring section makes it possible to monitor the recording activity and the timecodes on the XT[2] server. They are also used to set up how the timecodes are managed in the timecode jump tables. They are available by selecting **SHIFT+F5** in Multicam.

SH+ESC:UGA EXPLORER

SERVER MONITORING

Sh+F4:Network Monitoring F9:CLIP F10:PLST

/Zi

Disk Status

Raid Map	Raid 0			Raid 1			Raid 2		
0/A	3/D	Dsk!	Ok	Ok	Ok	Ok	Ok	Ok	
1/B	2/C	4/E	Ok	Ok	Ok	/	Ok	Ok	
Rebuild 26.92%									

Genlock status

OK since 19/11/07 - 16:01:39

Analog LTC status

10:47:59:11 <LOST> Drifts : 000

TimeCode Status

LTC	LTC jumps	005	005	005
	LTC threshold	050	050	050
	Peak alerts	004	004	004
	Peak Limit (sec)	010	010	010
	Frequency alerts	000	000	000
	Frequency: Number	010	010	010
	Frequency: Time	050	050	050
USER	USER jumps	004	004	004
	USER threshold	050	050	050

TAB:SELECT <-/->:CHANGE

PgDn:Pg2

ALT+Q:EXIT MULTICAM

### 3.2.1 DISK STATUS

In this section, the Raid Map indicates the position of the disks on the disk array and the status of each disk on each existing raid on the right.

/	Disk not present
!Raid	Disk disconnected
OK	Disk present

When a disk is disconnected, the message "Rebuild xx.xx%" will appear next to the disk array to which the disconnected disk belongs. This value shows the progress of the rebuild process. For more information on the rebuild, please go to section 'Disks Monitoring', on page 50.

### 3.2.2 GENLOCK STATUS

This section displays the current status of the genlock.

### 3.2.3 ANALOG LTC STATUS

This section specifies the current status of the analogue LTC timecode and specifies the number of drifts detected compared to the genlock.

The possible status values are the following depending on the MTPC board used:

MTPC A2/A4	
OK	The timecode is incremented in a normal way.
Drift	The timecode received and the genlock are not synchronous.
Bad	The timecode received is not correct. For example when an NTSC timecode is received instead of a PAL timecode (freq. error), when there are disturbances in the timecode reception (bad signal).
Lost	No timecode is available.

### 3.2.4 TIMECODE STATUSES

This section displays the settings for managing and monitoring the timecode jump tables. Records are created in these tables when a break, or jump, in the timecodes occurs in the recorded material. The records in the timecode jump tables are then used to search for and manipulate the video material on the XT[2] server.

There are two timecode jump tables:

- Timecode jump table for the LTC timecodes
- Timecode jump table for the timecodes specified by the user in the VITC setting on the first page of the Setup screen.

LTC		Default Values
LTC jumps	Number of timecode jumps calculated in the LTC timecode jump table for the given recorder since the last start of the server.	1
LTC threshold	Number of continuous timecodes to be received, after a break in LTC timecodes in the recorded material, in order to create a new record in the LTC timecode jump table.	50
Peak alerts	Number of peak alerts generated for the recorder since the last start of the server. A peak alert is generated each time the peak limit specified in the Peak Limit field is reached.	0

<b>LTC</b>		<b>Default Values</b>
	In this case, this field is automatically incremented by one.	
<b>Peak limits (sec)</b>	Period of time (in seconds) of continuous timecodes after which a break in timecodes in the recorded material will generate a peak alert. When a peak alert is generated, the value in Peak Alerts field is incremented by one.	10
<b>Frequency alert</b>	Number of frequency alerts generated for the recorder since the last start of the server.  A frequency alert is generated when X timecode jumps have been detected in Y seconds.  The X value is defined in the Frequency Number field. The Y value is defined in the Frequency Time field.  In this case, this field is automatically incremented by one.	0
<b>Frequency: Number</b>	Number of timecode jumps detected for the recorder after which a frequency alert can be generated.	10
<b>Frequency: Time</b>	Period of time (in seconds) after which a frequency alert can be generated.	50
<b>VITC</b>		<b>Default Values</b>
<b>VITC jumps</b>	Number of timecode jumps calculated in the VITC timecode jump table for the given recorder since the last start of the server.	1
<b>VITC threshold</b>	Number of continuous timecodes to be received, after a break in VITC timecodes in the recorded material, in order to create a new record in the VITC timecode jump table.	50

## 3.2.5 TIMECODE MONITORING ON SD RECORDERS

The second page of the Server Monitoring section displays the following information:

- LTC timecode on the XT[2] server
- VITC timecode on the various recorders

```

SERVER MONITORING -Zi
SH+ESC:UGA EXPLORER Sh+F4:Network Monitoring F9:CLIP F10:PLST

TimeCode Monitoring
Analog LTC : 05:43:52;28.
          VITC
Rec1      06:09:13;14.
Rec2      06:09:13;14.
Rec3      06:09:13;14.
Rec4      06:09:13;14.

TAB:SELECT <-/->:CHANGE PgUp:Pg1 PgDn:Pg3 ALT+Q:EXIT MULTICAM/
  
```

## 3.2.6 TIMECODE MONITORING ON HD RECORDERS

One page of the Server Monitoring section displays the following information:

- LTC timecode on the XT[2] server
- VITC timecode on the various recorders

```

SERVER MONITORING
Sh+ESC:VGA EXPLORER Sh+F4:Network Monitoring F9:CLIP F10:PLST

TimeCode Monitoring
Analog LTC : 00:00:00:00
          HANC VITC      HANC LTC
Rec1      00:00:00:00    00:00:00:00
Rec2      00:00:00:00    00:00:00:00
Rec3      00:00:00:00    00:00:00:00
Rec4      00:00:00:00    00:00:00:00
Rec5      00:00:00:00    00:00:00:00
Rec6      00:00:00:00    00:00:00:00

TAB:SELECT <-/->:CHANGE PgUp:Pg1 ALT+Q:EXIT MULTICAM/
  
```

## 3.2.7 LOG MANAGEMENT

The 3<sup>rd</sup> page of the Server Monitoring section displays a menu dedicated to log management. This new page allows a user-friendly and easy management of the logs where log files can be accessed from a remote computer while the Multicam is still in use.

SH+ESC:UGA EXPLORER

SERVER MONITORING PAGE 4

SH+F4:Network Monitoring F9:CLIP F10:PLST

Z:

MicroCode Logs

Log Management Menu

Multicam Logs

0 mC\_General - Critical 112 Mul\_Gbe - Critical

1 mC\_Train\_Gestion - Critical 113 Mul\_P\_AUSP\_Play41 - Critical

2 mC\_GBE\_Driver - Critical 114 Mul\_P\_AUSP\_Play42 - Critical

3 mC\_SCSI - Critical 115 Mul\_P\_AUSP\_Play43 - Critical

4 mC\_Cache - Critical 116 Mul\_General - Critical

5 mC\_CnlMgr - Critical 117 Mul\_Database - Critical

6 mC\_DataSave - Critical 118 Mul\_Sdti\_Cmd - Critical

7 mC\_Audio\_Recs - Critical 119 Mul\_Console - Critical

8 mC\_Sdti - Critical 120 Mul\_Remote\_0 - Critical

9 mC\_CnlLgRec - Critical 121 Mul\_Remote\_1 - Critical

10 mC\_CnlLgPly - Critical 122 Mul\_Remote\_2 - Critical

123 Mul\_Remote\_3 - Critical

124 Mul\_Remote\_4 - Critical

125 Mul\_Remote\_5 - Critical

126 Mul\_PlayList - Critical

127 Mul\_TimeLine - Critical

128 Mul\_Incrust - Critical

## LOG FILE TYPES

The left column displays items related to microcode. The right column displays those of the Multicam.

Each item has two associated log files:

- a regular log file
- a log file logging only errors

## CRITICALITY LEVELS

Each item has a criticality level that can be modified:

- The lowest and default level of criticality is 'Critical', where the log is limited to recording critical and important commands.
- An intermediate level is 'Normal'
- The highest level is 'Debug' which basically records every command.

This highest level should never be chosen without advice of qualified EVS staff.

The default value for all items is "Critical".

A help screen can be reached by pressing **SHIFT+F1**.

## EXTRACTING LOG FILES

This screen also offers the ability to extract log files when the Multicam is running. On this 3<sup>rd</sup> page of the Server Monitoring section, pressing **E** extracts the log files instantly so that a user can access them through a common FTP client application from a remote computer.

The extracted files are located in C:\LSMCE\DATA\LOG. Their name starts with an underscore: The regular log file "Multicam\_Database.log" is renamed "\_Multicam\_Database.log" once extracted when the application is running.



**Note:**

From Multicam version 10.01, you will be able to extract the logs from the XNet Monitor for any server running on the XNet network. For more information, refer to the XNet Monitor manual.

---



## 4. AsRunLog

---

### 4.1 PURPOSE

An As Run Log is a file which logs what has been effectively played on a channel and when. The As Run Log will then have a format such as an EDL.

The purposes of using As Run Log can be:

- to produce bills for advertising agency
- to monitor what has effectively been played out in case of errors during transmission
- to be used as a point of reference when subjects are placed on a website after they have been played on air.

The As Run Log is generally started before a production and stopped after the production. This allows to have an As Run Log file with only the events of the current production.

### 4.2 AS RUN LOG MECHANISM

The As Run Log mechanism is not an automatic process. It must be triggered by a start command on the EVS video server and is handled through the GbE port of the MTPC board of the EVS server.

The As Run Log function can be activated or deactivated from the VGA screen of an EVS server or from the Playlist Panel of IPDirector. Refer to part 6 of IPDirector manual for more information on the IPDirector As Run Log function.

The As Run Log is a characteristic of a channel.

When it is activated from the EVS server, the server generates an event channel log file, the server As Run Log, and stores it on the server local storage (C:\multicam\asrunlog\playerX, where X is the number of the corresponding player from 1 to 6). This file will contain all the operations which have been done on the channel since the As Run Log mechanism has started.

When it is activated from IPDirector, the final As Run Log file is created in two different steps:

- First, the EVS video server generates the server As Run Log.
- Secondly, a configurable merger application can analyze the server As Run Log file and format it in the final As Run Log format. It can retrieve the As Run log files from each player and merge them to provide a single file per EVS server per day.

## 4.3 SERVER AS RUN LOG FILE

The As Run Log is a characteristic of a channel. One file is created per day per player, even if the process is started and stopped several times a day. Up to 10 As Run Log files are kept per player, which corresponds to 10 days.

The last clip which started the day before is included at the beginning of the event section of the current day if this clip is played out over midnight and no stop command is received during the current day.

The server As Run Log file is named as follows:

YYYYMMDD\_XTNUM\_XTNAME\_XTSERIAL\_PLAYER\_X\_PLAYERNAME where

- YYYYMMDD is the file creation date
- XTNUM is the user number of the EVS server on the XNET (as defined in evs.exe)
- XTNAME is the name of that EVS server (as defined in evs.exe)
- XTSERIAL is the serial number of the EVS server
- X is the number corresponding to the player (in case of a PGM/PRV the number of the PGM is considered)
- PLAYERNAME is the name of the player as defined in the SHIFT-F2 screen of the Multicam.

## 4.4 AS RUN LOG FILE CONTENT

The As Run Log file contains

- a header with all the information related to the channel: EVS server name and serial number, channel name and PGM number
- an event section with a line for each event played out. Events include playout of trains and playout of black clips.

The following information will be recorded in the file for each element played out to air: on-air date, on-air time, on-air duration (total duration of the clip even if a transition effect is present), Name, VarID, UmID, LSM ID, TC IN, TC OUT, end date, end time.

# 5. Protocols

---

## 5.1 CONTROL PROTOCOLS

These protocols allow the EVS video server to be controlled by external devices.

### *Sony BVW75 Protocol*

This protocol allows the server to be seen as a VTR by the controlling device. On a playback channel, all usual transport commands (play, PlayVar, pause, goto timecode, stop, etc...) are supported. On a record channel, only Rec and Stop commands are supported.

This protocol is the simplest one but does not support clip management. It should be used when the controlling device does not support the XtenDD35, Odetics or Louth VDCP protocols (ex: edit controllers, NLE applications, some video switchers, VTR controllers, etc.).

EVS has also adapted the behavior of specific commands:

- REC: when a REC command is sent to a player channel, this channel will return in E2E mode on its default record train. If the default recorder channel associated to that player is currently stopped, it will jump to the last recorded picture and pause.
- EJECT: if the player channel is not yet in E2E mode when the command is sent, it will return to E2E mode on its default record train (similar to receiving a REC command). If the player channel is already in E2E mode, it will switch to the next recorder channel available (A→B→C→...→A→...). This is for example useful with a BVE edit controller to allow the editors to select the record train they want to work with.

Refer to the EVS Sony Protocol documentation for more details.

### *EditRec Protocol*

EditRec protocol allows the EVS server to be controlled by one editing console, like Sony BVE2000, BVE9100, Sony Plug In Editor switcher interface or Editware Fastrack. This protocol name has been used to differentiate it from the already existing "Sony BVW" protocol that is limited in EVS server to the "read-only" command subset. EditRec protocol implements all Sony BVW protocol commands required for linear editing.

Refer to EditRec documentation for more details.

## *XtenDD35 Protocol*

This protocol is based on the Sony BVW75 protocol for all standard transport commands. It has extended commands so that it supports clip management: using this protocol, the controlling device can create, name, recall and delete clips.

This protocol can be used with Thomson/GVG XtenDD range of switchers, and with DNF ST300-EVS and 4040CL-EVS controllers.

EVS developed custom commands to propose all the features offered by the server.

EVS has also adapted the behavior of specific commands, such as for the Sony BVW75 protocol.

Refer to the EVS XtenDD35 Protocol documentation for more details.

## *Odetics Protocol*

This protocol is based on the Sony BVW75 protocol for all standard transport commands. It has extended commands so that it supports clip and playlist management: using this protocol, the controlling device can create, name, recall and delete clips, but it can also manage playlists.

This protocol can be used with many different control devices and automation softwares, including DNF ST300 and 4040CL controllers.

EVS developed custom commands to propose all the features offered by the server.

EVS has also adapted the behavior of specific commands, such as for the Sony BVW75 protocol.

A specific Odetics Fill & Key mode is available. It allows the controller to control two channels (Fill&Key) instead of one with one serial. When the controller loads a "Fill" clip, the EVS server automatically loads the associated Key clip on the second channel and manages the perfect synchronization of both channels during the browsing and playout. The F&K clip association can be done by IPDirector or VDCP Custom command. If no clip association is done, the server follows the camera mapping (ex: if the Fill clip 111A/02 is loaded on Channel 1, the server will load the clip 111B/02 as Key).

Refer to the EVS Odetics Protocol documentation for more details.

## *VDCP Protocol*

This protocol is a more complex protocol mainly used by automation systems but also by video switchers. It is based on standard Louth VDCP protocol, and can handle clips as well as playlists.

A specific VDCP Fill & Key mode is available. It allows the controller to control two channels (Fill&Key) instead of one with one serial. When the controller loads a "Fill" clip, the EVS server automatically loads the associated Key clip on the second channel and manages the perfect synchronization of both channels during the browsing and playout. The F&K clip association can be done by IPDirector or VDCP Custom command. If no clip association is done, the server follows the camera mapping (ex: if the Fill clip 111A/02 is loaded on Channel 1, the server will load the clip 111B/02 as Key).

Refer to the EVS VDCP Protocol documentation for more details.

## ***AVSP Protocol***

AVSP is a proprietary serial protocol giving quite full access to EVS video server resources:

- simultaneous multi-port control from one serial link @115kbps.
- dynamic channel configuration including mixed channel for effect (audio and/or video)
- playlist management including train (record in progress) with or without fixed delay
- timeline management including train (record in progress) with or without fixed delay
- start/stop mode and GPI conditional events
- slow-motion clips
- extended channel and clip status reporting
- ganged channels control
- duplication or move of clips among network EVS video servers
- auto-backup to XFile
- metadata management (1 name + 3 keywords of 12 bytes each)
- This protocol is used for other EVS products interfaced to the server, like AIRBOX, AIREDDIT, EDIT2AIR and by third-party partners for specific applications.

## ***IPDP Protocol***

For more information on how the IP Director application controls the EVS video server, refer to the IP Director Technical Reference manual and User manual.

## ***LinX API***

The LinX Application Programming Interface is an integrated API used to control the EVS family video servers through IP connection. It is available since Multicam 10.02 version. It is proposed to EVS partners in order to develop applications interacting with EVS servers.

This API exposes a simplified view of the video server and its functionalities and hides future underlying changes in the server architecture.

To be as open as possible to potential users, the API implements multiple layers to isolate all OS dependent parts in lower layers and provide an interface to many programming language in the upper layers (C, C++, C#).

Refer to the EVS LinX documentation for more details.

## 5.2 MONITORING PROTOCOL

### *SNMP*

Since Multicam 10.02, A SNMP agent is available in all the EVS products to monitor the status of the device/software. The Source MIB is proposed to EVS partners in order to develop monitoring applications interacting with EVS systems.

Refer to the EVS SNMP Documentation for more details.


## 6. Possible Clip Identifiers

---

### 6.1 LSM ID

The LSM ID is a clip identifier based on the EVS video server structure.

The LSM ID is made up of 3 digits and 1 letter, for example 112B, where the digits and letter represent the following elements in the server structure:



The digits after the LMS ID correspond to the Net Number of the server on which the clip is stored, i.e. the EVS video server ID on the XNet network. They are not part of the LSM ID.

### 6.2 UMID

The UmID is an 8-bytes ID with fixed length. It is used for the unique clip identification on the SDTI network.

By default, all the protocols access and identify the clips via the UmID.

### 6.3 VARID

The VarID is a 32-bytes ID with variable length and format.

It can only be used in the VDCP protocol. When this protocol uses the VarID, the following VarID parameters need to be set up:

- Length (8 bytes, 32 bytes)
- Format (ASCII, binary)
- Uniqueness level (local = server level, global = network level)
- Protocol visibility (list of Net Numbers of the servers)

For more information on the parameters, refer to the 'RS422 Protocol Settings' page in the Multicam Configuration manual.



#### **Note**

From Multicam 9, the VarID has been introduced to allow a redundant architecture where the VarID can be identical on two different servers. All servers can stay on the same SDTI network. Consequently, this does not require a full replication of the XNet network. With the Um ID, the full replication was necessary as this clip ID has to be unique on the XNet network.

---

# Regional Contacts

---

## AMERICA (NORTH & LATIN)

---

EVS Americas East Coast	Tel: +1 818 846 9600 Fax: +1 818 846 9601	usa@evs.tv
EVS Americas West Coast	Tel: +1 973 575 7811 Fax: +1 973 575 7812 Tech. line: +1 973 575 7813	usa@evs.tv USAsupport@evs.tv
EVS Canada	Tel: +1 514 750 7544 Fax: +1 514 750 7518 Tech. line: +1 973 575 7813	usa@evs.tv USAsupport@evs.tv

---

---

## ASIA & PACIFIC

---

EVS Australia	Tel: +61 02 9452 8600 Fax: +61 02 9975 1368 Mobile: +61 420 307 387	sales@evs-asia.com.hk
EVS China	Tel: +86 10 6808 0248 Fax: +86 10 6808 0246 Tech. line: +86 139 1028 9860	evschina@evs.tv
EVS Hong-Kong	Tel: +852 2914 2501 Fax: +852 2914 2505 Tech. line: +852 9401 2395	sales@evs-asia.com.hk
EVS India	Tel: +91 22 6697 2999 Fax: +91 22 2673 2092 Mobile: +91 98 9017 5958	sales@evs-asia.com.hk

---

---

## EUROPE, MIDDLE EAST & AFRICA

---

EVS Belgium Headquarters	Tel: +32 (0) 4 361 7000 Fax: +32 (0) 4 361 7099 Tech. line: +32 (0) 495 284 000	support@evs.tv sales@evs.tv marketing@evs.tv
EVS Brussels	Tel: +32 (0) 2 421.78.70 Fax: +32 (0) 2 421.78.79	evsbrussels@evs.tv
EVS Deutschland	Tel: +49 (0) 89 4111 949 00 Fax: +49 (0) 89 4111 949 99 Tech. line: +49 (0) 89 4111 949 77	germany@evs.tv
EVS France	Tel: +33 1 46 99 9000 Fax: +33 1 46 99 9009 Tech. line: +33 1 46 99 9003	france@evs.tv

---

---

**EUROPE, MIDDLE EAST & AFRICA**

---

EVS Iberica	Tel: +34 91 490 3930 Fax: +34 91 490 3939 Tech. line: +34 91 490 3933	iberica@evs.tv
-------------	---	----------------

---

EVS Italy	Tel: +39 030 296 400 Fax: +39 030 294 3650 Tech. line: +39 334 631 1493	italy@evs.tv
-----------	---	--------------

---

EVS Middle East	Tel: +971 4 365 4222 Fax: +971 4 425 3501 Mobile: +971 50 887 8758	middle-east@evs.tv
-----------------	--	--------------------

---

EVS UK	Tel: +44 (0) 1372 387 250 Fax: +44 (0) 1372 387 269 Tech. line: +44 (0) 1372 387 266	uk@evs.tv
--------	--	-----------

---

**EVS Broadcast Equipment**

Liège Science Park  
16, rue Bois St Jean  
B-4102 Ougrée  
Belgium



Corporate  
Headquarters  
**+32 4 361 7000**

North & Latin America  
Headquarters  
**+1 973 575 7811**

Asia & Pacific  
Headquarters  
**+852 2914 2501**

Other regional offices  
available on  
**[www.evs.tv/contact](http://www.evs.tv/contact)**



To learn more about EVS go to **[www.evs.tv](http://www.evs.tv)**