

3922 496 31191 Service Manual Camera Head LDK 5861 Series

Tab	Part number	Drawing Number	Description
1	8926 586 15001	8926 586 19901	HD TRIAX DYNAC BACK TRILOCK
	8926 586 14001	8927 586 19901	HD TRIAX DYNAC BACK BBC LEMO
	8926 586 11501	8928 586 19901	HD TRIAX DYNAC BACK LEMO 3T
	8926 586 11001	8929 586 19901	HD TRIAX DYNAC BACK LEMO 4E
	8926 586 10501	8930 586 19901	HD TRIAX DYNAC BACK ARD
	8926 586 10001	8931 586 19901	HD TRIAX DYNAC BACK FISHER
	3922 407 56521	No	SET OF ADDITIONAL SUPPLIES
2	3922 407 54581	3922 407 54581	TRIAX ADAPTER BASIC 5861
	3922 407 49231	3922 407 49231	ROTARY TRIAX BACKPANEL
3	3922 406 55151	3922 406 55151	TRIAX MOTHERBOARD
4	3922 406 55181	3922 406 55181	INTERCONNECTION BOARD TRIAX
5	3922 406 88571	3922 406 88571	VIDEO MUX HD
6	3922 406 87871	3922 406 87871	AUDIO/INTERCOM TX/RX
7	3922 406 87881	3922 406 87881	AUDIO INTERCOM LF
8	3922 406 55061	3922 406 55061	POWER BOARD
9	3922 406 55031	3922 406 55031	VIDEO REC./CONVERTER TP HD
10	3922 406 54871	3922 406 54871	DAC OUTPUT BOARD
11	3922 406 53061	3922 406 53061	TRIAX BACKPANEL
12	3922 406 53131	3922 406 53131	POWER INTERCONNECTION BOARD
13	3922 407 54561	3922 407 49261	ADAPTOR BOTTOM ASSY
	3922 406 53151	3922 406 53151	FISHER CONNECTOR BOARD
14	3922 407 55371	3922 407 55371	TOPPLATE TRIAX ASSY
15	3922 407 49291	3922 407 49291	ADAPTOR COVER LEFT ASSY
16	3922 407 52551	3922 407 52551	ADAPTOR COVER RIGHT ASSY