

# ***Index***

## **Symbols**

.rsv files, 18–1

\*\*\*\* (as status display), 5–111

## **Numbers**

0080CEDEADxy, 2–39

01–036373–001 cable, 2–106

01–041340–001 cable, 2–8

01–041420–001 cable, 2–106

01–041600–TAB cable, 2–102

10/100BaseT, defined, Glossary–1

100/400 offset method, 5–36 , 5–38

10Base2, defined, Glossary–1

110/220 VAC selection, 2–1

200, serial protocol table entry, 5–27

220 VAC selection, 2–1

3–stage. *See* Three–stage

3040SLCT/LOCK, U–3

4000 series, defined, Glossary–1

## **A**

A (flashing), on VGA display, 6–142

A (in CP–3000 display), 6–19

A board, defined, Glossary–1

A264S. *See* Alpha Image

AA board, defined, Glossary–1

Abekas, serial protocol table entry, 5–26

AC line selection, 2–1

AC power adapter, Q–1

AccuSwitch

defined, Glossary–1

ordering information, 1–26

Activating configuration set, 5–13

Active I/O Set Editor, 10–1

Adapter cable, EC–2000, 2–106

ADC, 5–203

Add row, 5–4

Address

CP–3808, 6–71

CP–3824, 6–87

CP–3830, 6–97

CP–3832/3864, 6–112

LAN devices

hardware, 5–22 , 8–1

TCP/IP, 9–3

Machine control device, 5–141

MPK device, 5–108

Display of ID, 6–21 , 6–47 , 6–72

Administrator, 5–1

and JNS, 4–1

Advise, 5–41

AES, defined, Glossary–1

AES11, defined, Glossary–1

AES3–1992, defined, Glossary–1

AFV, defined, Glossary–1

Alamar

*See also* Thomson Automation

defined, Glossary–1

Protocol Dependent Devices table entry, 5–145

Alarm, 8–2

ALP, 5–28

Alpha Image

A264S

Physical level no., 5–38

protocol entry, 5–39

A264S router, Connecting to, 2–22

serial protocol table entry, 5–26

Ampex

Addressing, 2–84 , 5–141

AVR–3, 2–82

Bus, 2–83

Installation notes, 2–84

max VTRs per port, 1–19

Protocol to ESBUS protocol, F–3

serial protocol table entry, 5–26

VPR–2, 2–82

VPR–3, 2–82

VPR–300 series, 2–82

VPR–6, 2–82

VPR–80, 2–82

Ampex bus, defined, Glossary–1

Analog–digital conversion, 5–203

Andromeda, 2–107

Array (Vistek)  
     Connecting to, 2–28  
     Routing switcher dialect, Matrix–physical level no., 5–38

ASC, entry on Serial Protocol table, 5–28

ASCII, Routing switcher protocol  
     Command set, N–1  
     Hardware connections, 2–79  
     Level indication, 5–57  
     load factor, 1–19  
     max. switcher size, 1–8  
     MPK table entry, 5–130  
     Serial protocol table entry, 5–26

Asoc name, 5–153

Assemble edit, MC–3000, 6–133

Assignable inputs. *See* Input Source Assignment

Assigning machines to control panels, 5–151

Audio  
     CP–3000 stereo switching, 6–18  
     CP–3800 stereo switching, 6–43  
     CP–3808 stereo switching, 6–74  
     CP–3830 stereo switching, 6–96 , 6–98  
     CP–3832/64 stereo switching, 6–115  
     GUI panel stereo switching, 7–14

Auto–Edit mode, 6–133

Automation  
     *See also* BTA–2300; Thomson Automation  
     Output passwords ignored, 5–53

AV board, defined, Glossary–1

AVR–3, 2–82

AVS–1B. *See* Utah Scientific

AVS–1B (PL–320), serial protocol table entry, 5–27

## B

B&B Electronics, 2–14

Backup  
     automatic source switching. *See* 2x1 Matrix Combiner  
     redundant VM/SI. *See* VM/SI redundant installation

Base load factor, 1–18

Base multiplier, 1–21

Baud rate  
     1200/2400 for MPK control panel, 5–29  
     entry on Serial Protocol table, 5–26

BBC–2300, 2–90

BCB–70/75, 60/65, 35, 2–82

BCS–3000, defined, Glossary–1

Belden  
     1422, 2–102  
     8723, 2–77  
     9505, 2–9

Betacart, 2–82

Binary  
     Mars protocol, 5–39  
     SDR–400 protocol, 5–39  
     super crosspoint bus, Glossary–2  
     Venus protocol, 5–39

Binary–hexadecimal–decimal chart, D–1

Black Box, 2–25 , 2–28 , 2–80 , 2–101

BNC Tee cover, 2–44

Board Info/Control, JNS Control Center, 9–3

Board Override, 9–4

Board Status  
     JNS application, 8–1  
     JNS Control Center, 9–1

Boot, VM/SI–3000/Saturn, B–1

Breakaway  
     CP–3000, 6–14  
     CP–3800, 6–41  
     CP–3808, 6–67  
     CP–3830, 6–81 , 6–94  
     defined, Glossary–2  
     Disabling, 5–56  
     Switching, 5–46

Bridge, 2–42

Broadcast Automation. *See* Thomson Automation

BSD–2000, technical manual, xxix

BTS  
     BCB–70/75, 60/65, 35, 2–82  
     DCR–10/18/20/28, 2–82  
     DCR–100/300/500, 2–82  
     DCR–34/35, 2–82  
     DCR–500, 2–74  
     defined, Glossary–2  
     PCB–2600/2650/2800, 2–82

Bulbs  
     Replacing, 2–72  
     Testing, 2–73  
     testing. *See* Diagnostics

Bus, defined, Glossary–2

Button–per–input, defined, Glossary–2

BVH-1000, 2-82  
BVH-1100, 2-82  
BVH-2000, 2-82  
BVH-2500, 2-82  
BVU-800, 2-82  
BVW-10, 2-82  
BVW-40, 2-82

## C

Carts. *See* Audio carts

Categories, Changing factory names for, 5-103 , 10-5

Category set

Changing, 5-107

default, 5-65 , 5-66 , 5-82 , 5-83

Category/number

defined, Glossary-2

Linking to switcher input, 5-58 , 5-62

Linking to switcher output, 5-76 , 5-79

CB-2000, 2-11

CB-3000, 2-3 , 2-11

CC-2010 cable, 2-9

CD-ROM, technical library, xxix

CE, xxvi

CE-1003B, 1-12 , 2-3

CE-3000, P-1

Defined, Glossary-2

CEC, xxvii

CET, entry on Serial Protocol table, 5-28

Characters, in set, table, & device names, 5-7

CheaperNet. *See* Thin net

Chomerics, 2-11 , 2-103

Chop

CP-3000 panel, 6-13

CP-3020 panel, 6-26

CP-3800, 6-49

CP-3824 panel, 6-80

CP-3830 panel, 6-93

CP-3864, 6-103

defined, Glossary-2

limitations, 6-13

Clear Flash, Board Info/Control menu, 9-4

Clear PMEM, Board Info/Control menu, 9-4

Clipboard, Windows, 5-6

Clock

PC, 9-5

VM, 9-5

CM-4000, 1-4

defined, Glossary-2

entry on Net Description table, 5-22

entry on Serial Protocol table, 5-25

ESbus tributary protocol, 5-26

manual, xxix

Combiner. *See* 2x1 Matrix Combiner; VM-400 or DC-400

Compiling/activating configuration set, 5-13

Computer

external, controlling router, 2-77

file server. *See* File server

non-Jupiter, controlling VTRs, 2-97

Concerto, 1-12

connecting to VM-3000, 2-3

Physical level no., 5-36

Switcher Description table entries, protocol, 5-39

Configuration

CP-3800, 6-50

Editor, 5-1

JNS Control Center, 9-6

Sets

Activating, 5-13

Compiling, 5-13

Copying and selecting for editing, 5-10

defined, Glossary-2

General description, 5-8

Modifying and downloading, 5-8

naming rules, 5-7

Numeric, 5-11

Configuration guide, 1-22

Configurator, 5-1

Confirm all, 5-39

Conformity, Declaration of, xxvi

Connect, on JNS Control Console, 4-2

Contact information, xxviii

Control

Center. *See* "Control Center" below

Panels

*See also* model no. ("CP-xxxx")

baud rate, 5-29

Custom mounting, 1-16

I/O set editor, 10-1

Installing, 2-45

JNS Router Control Utility, 17-1

naming rules, 5-7

- Operating, 6-1
  - Power supply, 1-16
  - Software Control Panel Suite. *See* Software Control Panel Suite
- Control Center, 5-8 , 5-13 , 9-1
  - clearing battery-protected memory, B-1
  - clearing flash memory, B-2
  - VM/SI-3000 reset, B-1
- Control Console, 4-1
- Controller, VTR, DM 400B, 5-49
- Controller board, defined, Glossary-2
- Conversion
  - analog-digital, 5-203
  - party line
    - input/output, 5-170
    - levels, 5-171
  - RS-232/422 converter. *See* RS-232/422 converter
- Copying
  - Configuration sets, 5-10
  - CP Input set, 5-74
  - CP Output set, 5-78
- Cover for BNC tee, 2-44
- CP
  - Category sets, 5-103
  - Input sets, 5-58
    - control panel types, 5-63 , 5-80
  - Level sets, 5-55
  - Output sets, 5-76
  - Override sets, 5-98
  - Sequence sets, 5-101
- CP board, defined, Glossary-2
- CP I/O Set Editor, 10-1
  - password, 10-2
- CP- 300 Series
  - diagnostics, 6-6
  - DIP switches, 2-46
  - Installation, 2-46
  - Installing button labels, 2-72
  - load factor, 1-18
  - rear panel connectors, 1-13
- CP- 300
  - AC power adapter, Q-1
  - assigning keys to inputs, 5-98
  - diagnostics, 6-6
  - front panel drawing, 2-46
  - installation, 2-46
  - MPK table entry, 5-112
  - Operation, 6-1
  - sticky levels, 5-109 , 6-1
- CP- 310
  - AC power adapter, Q-1
  - assigning keys to inputs, 5-98
  - CP Category set type entry, 5-104
  - CP output set entry, 5-80 , 5-85
  - diagnostics, 6-6
  - front panel drawing, 2-47
  - installation, 2-47
  - MPK table entry, 5-112
  - Operation, 6-2
- CP- 320
  - AC power adapter, Q-1
  - categories, 5-66 , 5-83
  - CP Category set type entry, 5-104
  - CP Input set type entry, 5-63
  - CP Output set table entry, 5-80
  - custom category set, 5-103
  - diagnostics, 6-6
  - Front panel drawing, 2-48
  - general description, 2-48
  - installation, 2-48
  - key positions (diagram), 5-105
  - MPK table entry, 5-112
  - Operation, 6-3
- CP- 328
  - AC power adapter, Q-1
  - categories, 5-66 , 5-83
  - CP Category set type entry, 5-104
  - CP Input set type entry, 5-63
  - CP Output set table entry, 5-80
  - diagnostics, 6-6
  - general description, 2-48
  - installation, 2-48
  - Level Set entry, 5-56
  - MPK table entry, 5-112
  - Operation, 6-4
- CP- 330
  - AC power adapter, Q-1
  - assigning keys to inputs, 5-98
  - diagnostics, 6-6
  - dual bus mode, CP output set entry, 5-81 , 5-85
  - entry on MPK table, 5-110
  - front panel drawing, 2-49
  - installation, 2-49
  - MPK table entry, 5-112
  - Operation, 6-4
  - sticky levels, 6-3
- CP- 330/6
  - diagnostics, 6-6
  - installation, 2-49
  - Operation, 6-5
- CP-2002
  - general, 1-5
  - manual, xxx

- CP-2002B
  - CP Input set type entry, 5-63
  - CP Output set table entry, 5-80
- CP-3000
  - 2400 baud operation, 2-101
  - Audio switching modes, 6-18
  - CHOP button, 6-13
  - CP Category type entry, 5-104
  - CP Input set type entry, 5-63
  - CP Output set table entry, 5-80
  - custom category set, 5-103
  - custom mounting, 1-16
  - defining
    - override keys, 5-98
    - overrides (at panel), 6-21
    - sequences, 5-101
  - Diagnostics, 6-20
  - Display ID, 6-21
  - Entering mnemonic for switcher input, 5-58
  - Expansion panel
    - entry on Machine Control table, 5-149
    - Level statused, 5-56
  - Front panel drawing, 2-50
  - Full matrix control, 5-113
  - General description, 2-50
  - Input selection, 6-8
  - Installation, 2-50
  - key positions (diagram), 5-105
  - LEV button, 6-14
  - Level mnemonics, 5-56
  - Levels order in status row, 5-56
  - Linking category/no. to switcher inputs, 5-58
  - Load factor, 1-18
  - LOCK key, 6-11
  - MENU key, 6-15
  - modem connection, 2-101
  - MPK Devices table entry, 5-108
  - Multi bus control, 5-113
  - operation, 6-7
    - force unprotect/unlock, 6-12
    - tutorial, J-1
  - Output to control, changing, 6-20
  - Override input selection, 6-7
  - password, 6-22
  - Pin outs, 2-102
  - PROTECT key, 6-9
  - re-legendable button kit, 5-103
  - Rear panel connectors, 1-13
  - Sequences (selecting), 6-17
  - Single bus control, 5-113
  - Status checking, 6-16
  - stereo special switching, 6-18
    - Switcher description table entry, 5-40
  - tutorial, J-1
  - Unlock, 6-11
  - Unprotect, 6-10
  - Work sheet for output set, M-1
- CP-3008
  - CP Input set type entry, 5-63
  - CP Output set table entry, 5-80
  - manual, xxix
- CP-3010
  - See also* CP-3000 expansion panel or MC-3000 expansion panel
  - Front panel drawing, 6-131
  - Load factor, 1-19
  - MPK Devices table entry, 5-108
  - With CP-3000
    - Front panel drawing, 2-50
    - General description, 2-50
    - Operation, 6-24
    - Permanent output assignment, 5-77, 5-83
  - with MC-3000 machine control panel, operation, 6-131
  - Work sheet for output set, M-1
- CP-3020
  - assigning keys to inputs, 5-98
  - Chop button, 6-26
  - Front panel drawing, 2-51
  - General description, 2-51
  - Installing button labels, 2-72
  - Load factor, 1-18
  - Lock button, 6-26
  - MPK Devices table entry, 5-108
  - Operation, 6-26
  - Rear panel connectors, 1-13
  - Selecting output for control, 5-113
- CP-3021
  - Front panel drawing, 2-51
  - General description, 2-51
  - Installation with CP-3020, 2-51
  - Installation with MC-3020D, 2-71
  - Installing button labels, 2-72
  - Load factor, 1-19
  - Rear panel connectors, 1-13
- CP-3030
  - CP Input set type entry, 5-63
  - CP Output set type entry, 5-80
  - installation and operating manual, xxix
  - MPK devices table entry, 5-109
- CP-3200, on remote PCs, T-1
- CP-3300, defined, Glossary-2
- CP-3310
  - CP Category set type entry, 5-104
  - CP Input set type entry, 5-63
  - CP Output set table entry, 5-80

- defined, Glossary-2
- CP-3320, defined, Glossary-2
- CP-38 xx series, 64 level limitation, 1-18
- CP-3800
  - Audio control mode, 6-43
  - baud rate set, 6-47
  - breakaway switch, 6-41
  - button lamps, brightness, 6-48
  - chop, 6-49
  - configuration, 6-50
  - CP Category set type entry, 5-104
  - CP Input set type entry, 5-63
  - CP Output set table entry, 5-80
  - CP Override table entry, 5-98
  - custom category set, 5-103
  - diagnostics, 6-47
  - display ID, 6-47
  - entry on Machine Control Devices table, 5-149
  - entry on MPK devices table, 5-109
  - error codes, S-2
  - front panel drawing, 2-52
  - installation, 2-52
  - Level button, 6-41
  - level selection mode, 6-41
  - Load factor, 1-18
  - lock, 6-61
  - machine control, 6-45
  - Menu mode, 6-45
  - modem connection, 2-101
  - Multiple destination mode, 6-31
    - changing output soft key, 6-34
    - erasing an output, 6-35
    - making a switch, 6-32
    - permanent output assignment, 5-77 , 5-83
    - switching to single destination mode, 6-37
  - operation, 6-27
  - override mode, 6-53
  - overview, 6-27
  - passwords, 6-51
  - power requirements, 1-13
  - prompting, 6-51
  - protect, 6-61
  - rear panel connectors, 1-13
  - Sequence mode, 6-57
  - Single destination mode, 6-37
    - making a switch, 6-40
    - selecting an output for control, 6-38
  - split switch, 6-41
  - stereo special switching, 6-43
    - Switcher description table entry, 5-40
  - sticky displays, 6-50
  - tie line status, 6-63
  - VTR control, 6-45
- CP-3808
  - audio switching modes, 6-74
  - baud rate set, 6-72
  - breakaway (split switch), 6-67
  - button lamps, brightness, 6-72
  - categories, 5-66 , 5-83
  - CP Category set type entry, 5-104
  - CP Input set type entry, 5-63
  - CP Output set table entry, 5-80
  - custom category set, 5-103
  - diagnostics, 6-71
  - display ID, 6-72
  - displaying address (ID), 6-71
  - error codes, S-2
  - front panel drawing, 2-53
  - input selection, 6-66
  - installation, 2-53
  - key positions (diagram), 5-106
  - load factor, 1-18
  - lock, 6-69
  - MENU key, 6-68
  - modem connection, 2-101
  - operation, 6-64
    - force unprotect/unlock, 6-70 , 6-71
  - output to control, changing, 6-65
  - password, 6-75
  - power requirements, 1-14
  - PROM version, 6-47 , 6-71 , 6-113 , 6-121
  - protect, 6-70
  - rear panel connectors, 1-14
  - Status checking, 6-69
  - stereo special switching, 6-74
  - unlock, 6-69
  - unprotect, 6-70
  - with Expansion Panel, entry on MPK table, 5-110
- CP-3809
  - button assignment, 5-77
  - diagnostics, 6-125
  - entry on MPK Devices table, 5-110 , 5-112
  - front panel drawing, 2-56
  - installation, 2-56
  - load factor, 1-18
  - operation, 6-124
  - power requirements, 1-14
  - rear panel connectors, 1-14
  - With CP-3808/3830, Permanent output assignment, 5-85
- CP-3810
  - assigning buttons to outputs, 5-77 , 5-83
  - diagnostics, 6-130
  - entry on Machine Control table, 5-149
  - entry on MPK Devices table, 5-110 , 5-112 , 5-137
  - front panel drawing, 2-63
  - general description, 2-63
  - hardware installation, 2-63

- load factor, 1–18
- operation, 6–126
- power requirements, 1–14
- rear panel connectors, 1–14
- CP–3810L, entry on MPK table, 5–109 , 5–138
- CP–3810S
  - entry on MPK table, 5–109 , 5–137
  - operation, 6–126
- CP–3824
  - categories, 5–66 , 5–84
  - category keys (diagram), 5–106
  - CHOP button, 6–80
  - CP Category set type entry, 5–104
  - CP Input set type entry, 5–63
  - CP Output set table entry, 5–80
  - custom category set, 5–103
  - diagnostics, 6–87
  - displaying address (ID), 6–87
  - front panel drawing, 2–54
  - installation, 2–54
  - LEVEL button, blinking, 6–84
  - load factor, 1–18
  - LOCK key, 6–79
  - MENU key, 6–87
  - operation, 6–76
    - force unprotect/unlock, 6–79 , 6–80
  - overrides, 6–77
  - power requirements, 1–14
  - PROTECT key, 6–79
  - rear panel connectors, 1–14
  - sticky levels, 6–83
  - unlock, 6–79
  - unprotect, 6–79
- CP–3830
  - audio switching modes, 6–96 , 6–98
  - baud rate set, 6–72 , 6–113 , 6–122
  - button lamps, brightness, 6–72
  - categories, 5–66 , 5–84
  - CHOP button, 6–93
  - CP Category set type entry, 5–104
  - CP Input set type entry, 5–63
  - CP Output set table entry, 5–80
  - custom category set, 5–103
  - diagnostics, 6–71 , 6–97
  - display ID, 6–72
  - displaying address (ID), 6–97
  - dual / dedicated output, 5–112 , 5–132 , 6–89
  - error codes, S–2
  - front panel drawing, 2–55
  - installation, 2–55
  - key positions (diagram), 5–106
  - load factor, 1–18
  - LOCK key, 6–92
  - MENU key, 6–96
  - modem connection, 2–101
  - operation, 6–88
    - force unprotect/unlock, 6–92 , 6–93
  - password, 6–75
  - power requirements, 1–13
  - PROTECT key, 6–92
  - rear panel connectors, 1–13
  - single bus control, entry on MPK table, 5–112
  - Status checking, 6–96
  - stereo special switching, 6–96 , 6–98
  - unlock, 6–92
  - unprotect, 6–92
  - with Expansion Panel, entry on MPK table, 5–110
- CP–3830P
  - 32 level limitation, 1–18
  - categories, 5–66
  - CP Input set type entry, 5–63
  - CP Output set type entry, 5–80
  - default outputs, 5–84
  - entry on MPK table, 5–109
  - installation, 2–56
  - operation, 6–88
- CP–3832
  - assigning keys to inputs, 5–58
  - audio switching modes, 6–115
  - button lamps, brightness, 6–114 , 6–122
  - CP Input set type entry, 5–63 , 5–80
  - diagnostics, 6–112
  - displaying address (ID), 6–112
  - entry on CP Input set table, 5–64 , 5–81
  - entry on MPK table, 5–110
  - front panel drawing, 2–58
  - general description, 2–58
  - hardware installation, 2–58
  - LEVEL button, blinking, 6–102
  - load factor, 1–18
  - MENU key, 6–112
  - modem connection, 2–101
  - multi-panel applications, entry on MPK table, 5–133
  - operation, 6–100
    - force unprotect/unlock, 6–104 , 6–105
  - Panel name, 6–112
  - password, 6–100
  - power requirements, 1–14
  - PRESET button
    - blinking green, 6–101
    - blinking red, 6–101
  - PROT/LOCK button, 6–103 , 6–104
  - rear panel connectors, 1–14
  - stereo special switching, 6–115
  - sticky levels, 6–102
  - unlock, 6–104
  - unprotect, 6–103
  - X–Y operation, entry on MPK table, 5–111 , 5–112

- CP-3832L
  - diagnostics, 6-121
  - entry on CP Input set table, 5-64
  - entry on MPK table, 5-110
  - general description, 2-58
  - hardware installation, 2-58
  - operation, 6-117
  - password, 6-117
  - PROT/LOCK button, 6-119
- CP-3832P
  - entry on MPK table, 5-110
  - operation, 6-101
  - use with expansion panel not possible, 2-58
- CP-3864
  - assigning keys to inputs, 5-58
  - audio switching modes, 6-115
  - baud rate set, 6-113 , 6-122
  - button lamps, brightness, 6-114 , 6-122
  - chop, 6-103
  - diagnostics, 6-112
  - displaying address (ID), 6-112
  - entry on CP Input set table, 5-64 , 5-81
  - entry on MPK table, 5-110
  - front panel drawing, 2-60
  - general description, 2-60
  - hardware installation, 2-60
  - LEVEL button, blinking, 6-102
  - load factor, 1-18
  - MENU key, 6-112
  - modem connection, 2-101
  - multi-panel applications, entry on MPK table, 5-133
  - operation, 6-100
    - force unprotect/unlock, 6-104 , 6-105
  - Panel name, 6-112
  - password, 6-100
  - power requirements, 1-14
  - PRESET button
    - blinking green, 6-101
    - blinking red, 6-101
  - PROT/LOCK button, 6-103
  - rear panel connectors, 1-14
  - stereo special switching, 6-115
  - sticky levels, 6-102
  - unlock, 6-104
  - unprotect, 6-103 , 6-119
- CP-3864L
  - diagnostics, 6-121
  - entry on CP Input set table, 5-64
  - entry on MPK table, 5-110
  - general description, 2-60
  - hardware installation, 2-60
  - operation, 6-117
    - force unprotect/unlock, 6-119
  - password, 6-117
  - PROT/LOCK button, 6-119
- CP-3864P
  - entry on MPK table, 5-110
  - operation, 6-101
  - use with expansion panel not possible, 2-58
- CPL, Glossary-2
- cpsatrn
  - CP Category set, 5-104
  - CP Input set, 5-63
  - CP Output set, 5-80
- Crash (program), B-1
- CRC, 8-1
- Crosspoint
  - Board, PROMs, 2-3
  - Bus
    - Connecting to, 2-3
    - load factor, 1-19
    - Transmission speed, 1-12
  - defined, Glossary-2
- Crosspoint bus, defined, Glossary-3
- Crosspoint bus router, defined, Glossary-3
- CRS-MC-C2, 2-3
- CSA, xxvi
- Cue/mark, MC-3000, 6-132
- Cut and Paste, Windows to Jupiter, 5-6

## D

- D-2000/2166. *See* Datatek
- D8C, V-1
- DA board, defined, Glossary-3
- DAC, 5-203
- Damage claim, 2-1
- Data bits, MPK, Glossary-7
- Data switcher, 2-32
- Datatek, D-2000/2166
  - Connecting to, 2-23
  - Physical level no., 5-38
  - protocol entry, 5-39
  - serial protocol table entry, 5-26
- DC-400, O-1
- DCR-10/18/20/28, 2-82
- DCR-100/300/500, 2-82
- DCR-34/35, 2-82



DCR-500, 2-74

DD Series. *See* Diamond

DD-5/10/20/30, 2-75

DDE, defined, Glossary-3

DEC, 5-28

Decimal-hexadecimal-binary chart, D-1

Declaration of Conformity, xxvi

Default linkage, 5-156

Delegate panel. *See* MC-3020D

Delegation  
     defined, Glossary-3  
     Group, Establishing, 5-161  
     Permanent, 5-167

Delete row, 5-4

Dependency, Standard tally, 5-180

DEST (CP-3800 button), 6-29 , 6-34 , 6-35 , 6-36 ,  
     6-38 , 6-42

Destination. *See* Output

Device  
     codes, TCS-1, 5-168  
     name, 5-168  
     rules, 5-7

DHCP, defined, Glossary-3

Diagnostic, physical, 15-1

Diagnostics  
     CP-300 series, 6-6  
     CP-3000, 6-20  
     CP-3800, 6-47  
     CP-3808, 6-71  
     CP-3809, 6-125  
     CP-3810, 6-130  
     CP-3824, 6-87  
     CP-3830, 6-71 , 6-97  
     CP-3832/3864, 6-112  
     CP-3832L/3864L, 6-121  
     MC-3000, 6-133  
     MC-3010, 6-137

Diamond  
     CP Input set, 5-64  
     CP Level set, 5-56  
     CP Output set, 5-81  
     entry on MPK table, 5-129  
     Hardware connections, 2-75  
     serial protocol table entry, 5-26  
     tally and DD-35, 2-107

Digital-analog conversion, 5-203

DIM, 5-28

Dimensions, 1-15

DIP switches  
     CP-300 Series panels, 2-46  
     VM/SI-3000, 2-2

Disable  
     Breakaway, 5-56  
     Level, 5-56

Display mnemonic, defined, Glossary-7

Distributed routing, Glossary-3

Distribution switcher. *See* Switcher, distribution

DM 400 Off Time, Switcher Description table, 5-43

DM-400/400A/400B. *See* Data switcher

Documents, related, xxix

Download, cable (VM to PC), 2-80

Downloadable, defined, Glossary-3

DSP, defined, Glossary-3

DTK, 5-28

Dubs panel (GUI), 7-22

DUN, 5-28

Dune  
     defined, Glossary-3  
     entry on Serial Protocol table, 5-26  
     Switcher Description table entries, protocol, 5-39

DV board, defined, Glossary-4

DVP-ASI, defined, Glossary-3

DVS, defined, Glossary-4

## E

E-E monitor mode, MC-3000, 6-133

E-MEM. *See* Grass Valley

EBU, defined, Glossary-4

EC-2000, Adapter cable, 2-106

Eclipse, 2-24

Editing guidelines, 5-3

EEC, xxvi

Electromagnetic radiation, xxvi

EMC, xxvi

EMI, notice, xxvi

EMI modifications, 2-11 , 2-103

EN Series, xxvi

Encore  
     connecting to, 2-18

- serial protocol table entry, 5–29
- Enforce, 5–41
- Error codes, S–1
  - CP–3800 series panels, S–2
  - VM/SI–3000, S–1
- ES, 5–28
- ES–3000, defined, Glossary–4
- ES–400, defined, Glossary–4
- ES–401, 5–32
  - defined, Glossary–4
- ES–bus, load factor, 1–19
- ES–LAN, R–1
- ESbus
  - defined, Glossary–4
  - Installation, 2–74
  - Max length, 1–11
  - Max tributaries, 1–11 , 2–85
  - max VTRs per port, 1–19
  - Multipoint, 2–85
  - Pin assignment, F–1
  - Point-to-point, 2–85
  - Protocol Dependent Devices table entry, 5–145
  - Protocol to Ampex protocol, F–3
  - Protocol to Sony protocol, F–2
  - router, 5–27
  - Routing switcher dialect
    - Control panel connections, 2–79
    - Matrix–physical level no., 5–38
    - MPK table entry, 5–130
    - serial protocol table entry, 5–28
  - Transmission speed, 1–11
  - tributary, 5–28
  - VTR
    - connection, 2–83
    - interface, 5–26
- ESC, 5–28
- ESnet
  - defined, Glossary–4
  - Interface board. *See* ES–3000
- ESP, 5–28
- ESswitch, 5–27
  - See also* ESbus routing switcher dialect
  - load factor, 1–19
  - Routing switcher protocol, Hardware connections, 2–79
- ESW, entry on Serial Protocol table, 5–28
- Ethernet
  - Cable part numbers, 1–23

- defined, Glossary–4
- Installation, 2–41
- Excel, 5–6
- Exclusion, 5–210
  - defined, Glossary–4
- Expansion panel
  - See also* see model, e.g., CP–3010, CP–3809, etc.
  - With CP–3000
    - Front panel drawing, 2–50
    - Operation, 6–24
  - with MC–3000
    - illustration, 5–155
    - operation, 6–131
- Extended crosspoint bus, defined, Glossary–3
- Extended party line, 5–169
  - defined, Glossary–7
- Extended Remote PC, G–1

## F

- Fabric board, Glossary–5
- Fair–Rite, 2–11 , 2–103
- Fast forward, MC–3000, 6–133
- Fault button, clearing PMEM, B–2
- FCC rules, xxvi
- FCS–3306, 2–101
- FCS–3343, manual, xxix
- FCS–3357, manual, xxix
- FCS–3360, manual, xxix
- Ferrite, 2–11 , 2–103
- Field Engineering Bulletin, 3–1
- File names, rules, 5–7
- File server
  - Clock, 2–103
  - clock, 9–5
  - Configuration Editor, 5–1
  - customer–supplied, 1–15
  - defined, Glossary–5
  - Disconnecting LAN, 5–16
  - Installation, 2–38
  - Printer. *See* Printer
  - Restart, B–1
  - specifications, 1–15
- Fixed load factor, 1–19
- Flash memory, clearing, B–2
- Follow switch, 5–38
  - defined, Glossary–5

- Force unprotect/unlock, 6–12
  - all outputs (JNS), 11–1
  - CP–3808, operation, 6–70 , 6–71
  - CP–3824, operation, 6–79 , 6–80
  - CP–3830, operation, 6–92 , 6–93
  - CP–3832/3864, operation, 6–104 , 6–105
  - CP–3864L, operation, 6–119
  - defined, Glossary–5
  - Party line panels, 5–21
  - Router Save/Restore application, 18–2
  - VGA, operation, 6–143
  - VGA Status Display, Software configuration, 5–115
- Forward switcher. *See* Data switcher
- FPGA, defined, Glossary–5
- Frame advance, MC–3000, 6–133
- FS–3000. *See* File server
- Full function machine control (GUI), 7–20
- Full function switcher panel (GUI), 7–11
- Full–matrix control, defined, Glossary–5

## G

- Gateway, defined, Glossary–5
- Generate VGA Files, A–2
- Getting Started guide, xxix , 2–1 , 3–1 , 5–1
- GJ–IC455B, 2–25 , 2–28 , 2–80
- GNP, 5–29
- GPI–T/CI, 2–21
- Grass Valley
  - Concerto, Physical level no., 5–36
  - E–MEM, 2–81
    - CP Category set type entry, 5–104
    - CP Input set type entry, 5–63
    - CP Output set table entry, 5–80
- Horizon
  - Physical level no., 5–36
  - protocol entry, 5–39
- Model 102, serial protocol table entry, 5–27
- Model 200
  - hardware connections, 2–81
  - MPK table entry, 5–129
  - peripheral bus, operation, 5–131
  - peripheral bus protocol, 5–28
  - serial protocol table entry, 5–27
- Native Protocol, serial protocol table entry, 5–27
- Streamline, 2–81
- TEN–20, 20–TEN
  - Physical level no., 5–36

- protocol entry, 5–39

- Group delegation panel. *See* MC–302D
- GS–400, connecting to VM–3000, 2–3
- GUI, defined, Glossary–5
- GUI panels. *See* Software Control Panels

## H

- Hardware, address, defined, Glossary–5
- Hexadecimal–decimal–binary chart, D–1
- Horizon
  - General Purpose Interface, connecting to, 2–21
  - Physical level no., 5–36
  - protocol entry, 5–39
  - serial protocol table entry, 5–27
  - Switcher Description table entries, VI, 5–33
- Hot key. *See* Shortcut key
- HRZ, 5–28
- HTTP, defined, Glossary–5
- Hyphen, in set, table, & device names, 5–7

## I

- I (entry on switcher input menu), 5–60
- I/O Set Editor, 10–1
  - password, 10–2
- ICS, defined, Glossary–5
- ID
  - display on CP–3000, 6–21
  - display on CP–3800, 6–47
  - display on CP–3808, 6–72
  - display on CP–3830, 6–72
- IF–10, 2–90
- Imaginary switcher, 5–157
- Indirect status instruction, 5–60
  - defined, Glossary–5
- Input currently in use... (error message), 5–42
- Input Source Assignment, to production switcher, U–1
- Inputs
  - Switcher
    - Entering # of, 5–47
    - Entering mnemonics for, 5–58 , 5–62
    - Entering name of, 5–47
    - Switcher Input table, 5–44
- Inputs, Switcher, max no. of, 1–27

## Insert

- edit, 6–133
- row, 5–4

## Installation, 2–1

*See also* model number of product

## Integrity Instruments, 2–101

## Interface bus, defined, Glossary–5

## Internet, xxviii

- time source, 9–5

## IP address

- defined, Glossary–10
- network devices, 9–3

# J

## JNIA, defined, Glossary–5

## JNS

- Applications, 4–3
  - on Remote PC, 4–1
- Board Status, 8–1
- Control Center, 5–8 , 9–1
  - Board Info/Control, 9–3
  - Configuration, 9–6
- Control Console, 4–1
- CP I/O Set Editor, 10–1
- defined, Glossary–5
- Force Unlock/unprotect, 11–1
- Logger and Log Viewer, 12–1
- Party Line Download, 13–1
- Physical Control, 14–1
- Physical Remapping, 16–1
- Router Control Utility, 17–1
- Router Save/Restore, 18–1
- Saturn Monitor Follow & Preview, 19–1
- Servers, defined, Glossary–5
- TFTP Status, 9–2
- Tools, 4–3
- Utilities, 4–4

## JNS Console.ini, 4–2

## Jog, MC–3000, 6–133

## Jupiter

- defined, Glossary–6
- LE, 1–26
- Network Interface Application. *See* JNIA
- Network Suite. *See* JNS
- Plus, 1–26
- XPress. *See* XPress

## Jupiter XPress, defined, Glossary–6

# K

## KUED protocol. *See* RP–0000

# L

## L (flashing), on VGA display, 6–142

## L4 (Venus level jumper), 5–35

## Labels, preparing, 2–72

## Lamps

- Replacing, 2–72
- Testing, 2–73
- testing. *See* Diagnostics

## LAN

- Addresses
  - hardware, 5–22
  - TCP/IP, 9–3
- Cable lengths, 2–42
- Cable part numbers, 1–23
- Disconnecting file server, 5–16
- Installation, 2–41
- use of non–Jupiter equip, 2–38 , 2–41

## Lawo

- See also* Dune
- defined, Glossary–6

## Leave alone, 5–41

## LEV key (CP–3000), 6–14

## Level

- breakaway, CP–3830, 6–81 , 6–94
- button
  - CP–3824, 6–84
  - CP–3832/3864, 6–102
- Conversion, 5–171
- CP–3800 button, 6–41
- defined, Glossary–6
- Disabling breakaway to, 5–56
- Disabling switching on, 5–56
- Mapping, 2–31 , 5–37
- Max inputs/outputs, 5–34
- max. no. of, 1–16 , 1–27
- Physical. *See* Physical level
- Switcher Description table, 5–31

## Library CD–ROM, xxix

## Limits, system, 1–18

## Linkage

- Default, 5–156
- defined, Glossary–6
- Machines to control panels, 5–151
- Panel. *See* MC–3020L

## Little Cloud, defined, Glossary–6

LMS, 2–82

Load, Factors, 1–18

Lock, 6–12  
     *See also* Unlock  
     CP–3000 panel, 6–11  
     CP–3020 panel, 6–26  
     CP–3800, 6–61  
     CP–3808, 6–69  
     CP–3824, 6–79  
     CP–3830, 6–92  
     CP–3832, 6–104  
     defined, Glossary–6  
     GUI panel, 7–8  
     Machine control, 6–138

Locked pathfinding, 5–204

Log Viewer, JNS, 12–1

Logger, JNS, 12–1

Logging, defined, Glossary–6

Logical, Level  
     Mapping, 2–31 , 5–37  
     Name, 5–31  
     Number, 5–31  
     Three-stage, H–2

Logical level mapping, defined. *See* level

Logical level name, defined, Glossary–6

Logical level number, defined, Glossary–6

Login, CP–3000 panel, 6–22

Logout, CP–3000 panel, 6–23

LOS, defined, Glossary–6

Loss of power, 5–16

LZR Electronics, 2–46

## M

M, in GUI status display, 7–15

M board. *See* CE–3000

Machine control  
     CP–3800, 6–45  
     Devices table, 5–141 , 5–148  
     full function (GUI), 7–20  
     load factor, 1–19  
     MCS–2000 linkage, 5–151  
     slaved (GUI), 7–9  
     TCS–1 device codes, 5–168  
     using non-Jupiter control panel/computer, 2–97

Machine Control table, 5–148

Machines table, 5–141

MADI, defined, Glossary–6

Mains voltage selection, 2–1

Manuals, related, xxix

Mapping, Logical level, 2–31 , 5–37

Mark, E–1

Mark key, MC–3000, 6–132

Mars  
     connecting to VM–3000, 2–3  
     inputs/outputs table entry, 5–34  
     protocol selection, 5–39

Master control. *See* MCS–2000; Saturn

Matrix  
     Board. *See* Crosspoint board  
     Bus  
         Connecting to, 2–3  
         defined, Glossary–6  
         Cable, VDE modifications, 2–11

Matrix Combiner. *See* 2x1 Matrix Combiner

MC, 5–33

MC–12/3, 2–88

MC–200/900/2095/2098. *See* Alamar

MC–24A, 2–88

MC–3000  
     custom mounting, 1–16  
     Diagnostics, 6–133  
     Front panel drawing, 6–131  
     Load factor, 1–18  
     MPK Devices table entry, 5–108  
     operation, 6–131  
     Rear panel connectors, 1–13  
     Sony Auto-Edit, 6–133

MC–3010  
     Diagnostics, 6–137  
     Front panel drawing, 6–135 , 6–136  
     Load factor, 1–18  
     Operation, 6–135  
     Rear panel connectors, 1–13

MC–3020D  
     Button labels, 2–72  
     Central control installation, 2–71  
     CP output set entry, 5–80  
     Front panel, 2–69 , 5–164  
     Installation, 2–69  
     Load factor, 1–19  
     MPK devices table entry, 5–162  
     Operation, 6–140  
     Rear panel connectors, 1–13

MC–3020L  
     Button labels, 2–72

- CP input set type entry, 5–63
- CP output set entry, 5–80
- Front panel drawing, 2–67
- Installation, 2–67
- Load factor, 1–19
- MPK table entry, 5–118
- Operation, 6–138
- Rear panel connectors, 1–13
- MC–3040
  - back panel drawing, 2–120
  - hardware connections, 2–97
  - hardware overview, 2–117
  - Machine control dev. table entries, 5–159
  - MPK table entries, 5–117
  - pin outs, status in / relay contacts, 2–99
  - reset switch, 2–119
  - Software configuration
    - Machine control dev. table, 5–159
    - MPK devices table, 5–117
- MCC–3500, load factor, 1–18
- MCS–2000
  - Input/output conversion, 5–170
  - Machine control
    - Preroll key, 5–150
    - TCS–1 device codes, 5–168
  - Machine control linkage, 5–151
  - Party line levels conversion, 5–171
  - Protected outputs, 5–53
  - Protocol Dependent Devices table entry, 5–145
- MCS–3500. *See* Saturn
- MCS\_TLY, 5–182 , 5–186
- MCX 400. *See* 2x1 Matrix Combiner
- MDI, 15–1
  - defined, Glossary–7
- Media, Networking, and Control, defined, Glossary–7
- Memory
  - Clearing battery–protected, B–1
  - clearing PMEM, B–1
- MENU
  - CP–3000 button, 6–15
  - CP–3800 button, 6–45
  - CP–3808 button, 6–68
  - CP–3824 button, 6–87
  - CP–3830 button, 6–96
  - CP–3832/3864 button, 6–112
- MI interface, 5–168
- MI–1002, 2–89
- MI–1003, 2–89
- MI–2003, 2–89
- MI–3040
  - Back panel drawing, 2–120
  - Connection to VTRs, 2–93
  - GPI/O application (“MI–3040IO”), 5–116
  - Hardware overview, 2–117
  - in Saturn Tally systems, 2–109
  - Load factor, 1–18
  - Machine control dev. table entries, 5–159
  - MPK table entries, 5–116
  - Pin outs, Status in / relay contacts, 2–95
  - Pin outs, MPK bus, 2–102
  - Rear panel connectors, 1–12
  - Reset switch, 2–119
  - Select/Lock, U–1
  - Software configuration
    - Machine control dev. table, 5–159
    - MPK devices table, 5–116
  - Tally, Hardware connections, 2–107
  - tally configuration (Standard tally), 5–174 , 5–180
  - with non–Jupiter machine control panels/computers, 2–97
- MI–3040IO, 5–116
- MI–8, 2–89
- Microsoft programs. *See* name of program
- Microvideo
  - Physical level no., 5–38
  - serial protocol table entry, 5–27
  - switcher protocol, 5–39
- MIDI, defined, Glossary–7
- Mix
  - CP–3800, 6–44
  - CP–3808, 6–69 , 6–74
  - CP–3830, 6–96 , 6–98
  - CP–3832/3864, 6–112
  - CP–3832/64, 6–115 , 7–14
- MNC, defined, Glossary–7
- Mnemonic, defined, Glossary–7
- Mnemonics
  - Length, max, 5–58
  - Linking to switcher inputs, 5–58 , 5–62
  - Linking to switcher outputs, 5–76 , 5–79
  - Split, 5–60
- Model 200, MPK devices table entry, 5–131
- Modem, connecting to control panel, 2–101
- Monitor bank, Saturn, 19–1
- Monitor combiner. *See* VM–400 or DC–400
- Monitoring, Venus, O–1

## MPK

### Bus

Baud rate, 5–29

Cable, 2–102

Installation, 2–45

Max devices, 1–18

Max length, 2–102

defined, Glossary–7

Devices, menu entry, 5–108

MSL–4000, 2–77

Multimedia, Jupiter courses, xxix

Multiple switcher installations

Hardware installation, 2–33

Path finding, 2–35

Statusing requirements, 5–77

Switcher levels table entry, 5–37

Multipoint, 2–85

MVD, 5–28

*See also* Microvideo

## N

Name, rules for set, table, & device names, 5–7

Native Protocol, 5–29

NEC, xxvii

NetBEUI, defined, Glossary–7

NetBIOS, defined, Glossary–7

NetLink, 2–101

Network, board. *See* LAN card

Network description menu, 5–22

Network Suite. *See* JNS

Nexus

Physical level no., 5–38

serial protocol table entry, 5–27

switcher protocol, 5–39

Nexus Star, Connecting to, 2–30

No Active Set, 4–2 , 7–6 , 10–2

Node, 2–42

defined, Glossary–7

Non-sequential path finding

Hardware installation, 2–35

Table entry, 5–207

NORM–L/R (CP–3800 display), 6–44

NORMAL

CP–3808 display, 6–74

CP–3830 display, 6–98

CP–3832/64 display, 6–115 , 7–14

Novotronic

Physical level no., 5–38

serial protocol table entry, 5–27

switcher protocol, 5–39

NT. *See* Windows NT

NUM–64/128, 5–11

Numeric

Mode, defined, Glossary–7

Set, 5–11

defined, Glossary–7

Nv, 5–29

NVISION

connecting to, 2–24

data router

serial protocol table entry, 5–27

switcher protocol, 5–39

Routing switcher dialect, Matrix–physical level no., 5–38

NVT, 5–28

*See also* Novotronic

NXS, 5–28

*See also* Nexus

## O

Octal, Mars architecture, 5–34

Odd/even ports, 2–89

Off Time, Switcher Description table, 5–43

Offset, 100/400 (switch. desc. table), 5–36 , 5–38

Option, Switcher Description table. *See* Data switcher

Options, overview, 1–27

Opto Change messages, MI 3040 limits, 1–21

Opto-isolator, Standard tally, 5–180

Optoelectronic relays & optical couplers (MI/MC–3040), 2–117

Ordering information, 1–22

Oshino Electric, 2–72

Output

changing on CP–3000, 6–20

changing on CP–3808, 6–65

monitoring (Venus), O–1

Sets, 5–76

Output monitoring, defined, Glossary–7

Outputs

Deleting from expansion panel, 6–24 , 6–125

- Switcher, Entering mnemonics for, 5–79
- switcher
  - entering # of, 5–52
  - entering name of, 5–52
  - max no. of, 1–27
  - password levels, 5–53
  - status checking, 6–16 , 6–69 , 6–96
- Switcher Output table, 5–51
- Override
  - Board, 9–4
  - CP–3800, 6–53
  - defined, Glossary–7
  - Defining at CP–3000, 6–21
  - Input selection, 6–7
  - Sets, 5–98

## P

- P (entry on switcher input menu), 5–60
- P (flashing), on VGA display, 6–142
- P board. *See* PL–3000
- Page file name, 5–173
- Pan Name, CP–3832/3864, 6–112
- Paper, technical, 2–107
- Parallel, VTRs, 2–89
- Parenthesis, in set, table, & device names, 5–7
- Parity, MPK, Glossary–7
- Part numbers, 1–22
- Parts, spare, xxviii
- Party Line, serial protocol table entry, 5–27
- Party line
  - defined, Glossary–7
  - Description menu, 5–169
  - Extended/super, 5–169
  - Input/output tables, 5–170
  - Levels conversion, 5–171
  - Polling number, 5–169
  - redundant VM–3000s, 2–4 , K–1
  - Utah Scientific, connecting to, 2–25
- Party Line (UDI–1B), serial protocol table entry, 5–27
- Party Line Download, 13–1
- PASS =
  - CP–3808/3830, 6–75
  - CP–3832/3864, 6–100
  - CP–3832L/3864L, 6–117
- Password
  - and automation, 5–53

- CP I/O Set Editor, 10–2
- CP–3000, 6–22
- CP–3808/3830, 6–75
- CP–3832/3864, 6–100
- CP–3832L/3864L, 6–117
- Jupiter
  - Changing, 5–20
  - CP–3800, 6–51
  - General description, 5–17
  - levels
    - control panels, 5–114
    - switcher outputs, 5–53
  - MCS–2000 outputs, 5–53
- Path finding
  - auto analog–digital conversion, 5–203
  - defined, Glossary–8
  - Hardware installation, 2–35
  - locked groups, 5–204
  - multimedia course, xxix
  - Non–sequential table entry, 5–207
  - Sequential table entry, 5–196
  - Three or more switchers, 5–200
  - VGA display, A–10
- Paths Full, message on GUI panel, 7–8
- PC
  - as file server. *See* File server
  - connecting to VM/SI–3000, 2–38
  - remote unit, G–1
    - connecting to LAN, 2–38
    - defined, Glossary–8
    - JNS applications, 4–1
- PC–3000. *See* File server
- PCB–2600/2650/2800, 2–82
- PCI, defined, Glossary–8
- Physical
  - diagnostic, 15–1
  - Input number, 5–44
  - level
    - Alpha switcher, 5–38
    - Concerto, 5–36
    - Datatek switcher, 5–38
    - defined, Glossary–6
    - ESbus switcher, 5–38
    - Horizon, 5–36
    - Microvideo switcher, 5–38
    - Nexus switcher, 5–38
    - Novotronic switcher, 5–38
    - NVISION router, 5–38
    - RKX switcher, 5–37
    - TEN–20, 20–TEN, 5–36
    - three–stage, H–2
    - Triton, 5–36
    - TVS/TAS, 5–37



- Utah Scientific, 5–38
- Venus, 5–35
- Vistek Array, 5–38
- Physical Control, JNS, 14–1
- Physical Remapping Utility, 16–1
- PL, 5–29
- PL–320, 2–27
- PL–3000, P–1
- PL–320, serial protocol table entry, 5–27
- Play key, MC–3000, 6–132
- PMEM
  - clearing, B–1
  - after modifying tables, 5–22
  - defined, Glossary–8
- Point-to-point, 2–85
  - Switching, 5–41
- Polling and polling names, defined, Glossary–8
- Polling number, 5–169
- Pop-up menu, 5–3
- Post Mortem, 9–4
- Power
  - Line (voltage) selection, 2–1
  - Loss, 5–16
  - Supply, control panels, 1–16
- Power adapter (AC), Q–1
- PowerPoint, Jupiter courses, xxix
- PPM, defined, Glossary–8
- Pre-wired, H–7
- Preroll, 5–150 , 6–132 , E–1
- Preset, Saturn Monitor Follow & Preview, 19–1
- Primary status instruction, 5–60
  - defined, Glossary–8
- Printer
  - command on Compile window, 5–13
  - commands on Options menu, 5–16
  - hardware connection, 2–39
- Pro-bel, 1–8
  - connecting to, 2–24
  - serial protocol table entry, 5–27
  - switcher protocol, 5–39
- Probe connector and cable, C–1
- Production switcher. *See* Switcher, production
- Program restart, B–1
- Prompting, CP–3800, 6–51

- PROMs, 2–3
  - 1200/2400 baud for MPK control panel, 5–29
  - TCS–1, 2–88
- Protect, 6–12
  - See also* Unprotect
  - CP–3000, 6–9
  - CP–3800, 6–61
  - CP–3808, 6–70
  - CP–3824, 6–79
  - CP–3830, 6–92
  - CP–3832/3864, 6–103
  - CP–3832L, 6–119
  - CP–3864L, 6–119
  - defined, Glossary–8
  - GUI panel, 7–8
  - MCS–2000 outputs, 5–53
- Protocol Dependent Devices, 5–144
- Protocol Dependent Devices table, 5–144
- PS–20, 2–46
  - SD–3x application, 2–122
- PS–300, Q–1
- Publications, related, xxix
- Punctuation, in set, table, & device names, 5–7
- PURS, 5–29

## Q

- QD8, V–1
- QNX, R–1
- Quick start manual, xxix , 2–1 , 3–1 , 5–1

## R

- R, in GUI status display, 7–15
- Rack mounting, 2–2
- Radiation, xxvi
- RCI, defined, Glossary–8
- RCMC, defined, Glossary–8
- Re-legendable button kit, 5–103
- Ready key, MC–3000 panel, 6–132
- Reboot
  - Board Info/Control menu, 9–4
  - VM/SI–3000/Saturn, B–1
- Record
  - In key, MC–3000, 6–133
  - Mode key, MC–3000, 6–133

- Out key, MC-3000, 6-132
- Redundant
  - 2x1 Matrix Combiner. *See* 2x1 Matrix Combiner
  - VM/SI-3000. *See* VM/SI redundant installation
- Refresh, defined, Glossary-8
- Regulatory Compliance Notices, xxvi
- Relay descriptions (Standard tally), 5-174
- Relays (MI/MC-3040), 2-118
- Remapping, 16-1
- Remote
  - PC. *See* PC remote unit
  - switcher, defined, Glossary-8
  - switcher (non-Crosspoint Bus), load factor, 1-19
  - switcher (third party), connecting to, 2-12
- Repeater, 2-42
  - defined, Glossary-8
- Reset, VM/SI-3000, B-1
- Restart
  - File server, B-1
  - Program, B-1
- Retained level, Glossary-9
- Retained levels. *See* Sticky levels
- Returning merchandise, 2-1
- Reverse, CP-3832/3864, 6-112
- Reverse switcher
  - See also* Data switcher
  - defined, Glossary-9
- Rewind, MC-3000, 6-133
- RFI modifications, 2-11 , 2-103
- RGB switcher, Level menu entry, 5-38
- RKX
  - Physical level no., 5-37
  - switcher protocol, 5-39
- RL11A, 2-46
- Root directory, 4-1
- Router. *See* Switcher, distribution
- Router Control Utility, 17-1
- Router Save/Restore utility, 18-1
- Row editing, 5-4
- RP 1/2/3 UMD
  - Bus loading, 1-19
  - CP Category set type entry, 5-104
  - CP input set type entry, 5-63
  - CP output set entry, 5-81

- dimensions, 1-16
  - general description, 1-6
  - hardware installation, 2-121
  - MPK table entry, 5-120
  - Rear panel connectors, 1-14
  - Software configuration, CP Level set, 5-56
  - software configuration, 5-118
- RPX, 5-29
- RS-232/422 converter
  - control panel connection, 2-101
  - Utah Scientific connection, 2-25
  - Vistek connection, 2-28
- RS-232/422/423, switching. *See* Data switcher
- RS-422
  - Cable, Connection to VM/SI-3000, 2-102
  - defined, Glossary-9
- rsv files, 18-1
- RV, 5-33

## S

- S (flashing), on VGA display, 6-142
- S board. *See* SC-3000
- S-T (on Swit. out menu), 5-52
- Safe input, 5-42 , 5-43
- Safe off time, Switcher Description table, 5-43
- Safe time, Switcher Description table, 5-43
- Safety notices, xxvii
- Salvo panel (GUI), 7-26
- Salvo, defined, Glossary-9
- Saturn
  - clearing battery-protected memory, B-1 , B-2
  - connecting to Jupiter, 2-104
  - CP I/O Set Editor, with, 10-1
  - force download, B-2
  - MCC-3500 Control Console, load factor, 1-18
  - Monitor Follow & Preview, 19-1
  - Reset, B-1
  - software version, 8-2
  - Source (category) keys, 5-105
  - status check, 8-1 , 9-1
  - tally, 2-104
- Save/Restore utility, 18-1
- SB, entry on Net Description table, 5-24
- SC-3000, P-1
- Scan rate, 9-5
- SCP, defined, Glossary-9

- SCT, 5–29
- SD–3x
  - Bus loading, 1–19
  - dimensions, 1–16
  - DIP switches, 2–121
  - general description, 1–6
  - Hardware installation, 2–121
  - Rear panel connectors, 1–14
  - Software configuration
    - CP Input set, 5–63
    - CP Level set, 5–56
    - CP Output set, 5–81
    - Permanent display, 5–128
    - With MCS–2000, 5–122
    - with non–Saturn MCS or production switcher, 5–125
  - software configuration, 5–118
  - technical manual, xxix
- SDR–400
  - connecting to VM–3000, 2–3
  - Protocol selection, 5–39
- Search
  - Cue, MC–3000, 6–132
  - Mark, E–1
  - mark key
    - MC–3000, 6–132
    - MCS–2000, 5–150
- Security board, 5–51
- Segment, 2–42
  - defined, Glossary–9
- Select, key, CP–3010, 6–134
- Selected, set, 5–8
- Semi–permanent linkage, 5–156
- Sequence sets, 5–101
- Sequences
  - CP–3000, 6–17
  - CP–3800, 6–57
- Sequencing, defined, Glossary–9
- Sequential path finding
  - Hardware installation, 2–35
  - Table entry, 5–196
- Serial
  - Bus, defined, Glossary–9
  - CP Category set type entry, 5–104
  - CP input set type entry, 5–63
  - CP output set type entry, 5–80
  - Data cable, 2–102
    - VDE modifications, 2–103
  - machine control, load factor, 1–19
  - MPK bus installation, 2–45
  - protocol table, 5–25
  - VTRs, 2–83
- SERIM, 2–20
- Server, defined, Glossary–9
- Service information, xxviii
- Set mark, E–1
- Set mark key, 5–150
  - MC–3000, 6–132
- Sets. *See* Configuration sets
- Setup, Router Save/Restore, 18–1
- Shuttle, MC–3000, 6–133
- SI–3000
  - clearing battery–protected memory, B–1
  - clearing flash memory, B–2
  - Connecting to VTRs, 2–83
  - Controls, indicators, connectors, 1–11
  - devices per bus, max, 1–18
  - DIP switches, 2–2
  - force download, B–2
  - front panel (drawing), 1–10 , C–1 , S–1
  - LED error codes, S–1
  - network address switches, 2–39
  - Odd/even ports, 2–89
  - Pin outs, serial ports, 2–102
  - Protocol table, 5–25
  - rear panel (drawing), 1–10
  - redundant
    - cable, 2–8
    - hardware installation, 2–86
    - installation, software configuration, 5–24
    - kit, 2–87
    - manual changeover, K–1
    - system preloading, K–2
  - Reset, B–1
  - software version, 8–2
  - status check, 8–1 , 9–1
- Siemens, 2–72
- Single–bus, defined, Glossary–9
- Slant, in set, table, & device names, 5–7
- Slashes, in set, table, & device names, 5–7
- Slaved machine control (GUI), 7–9
- Slow motion play, MC–3000, 6–132
- SMPTE
  - 259M–1997, defined, Glossary–9
  - 269M–1999, defined, Glossary–9
  - 274M–1998, defined, Glossary–9
  - 292M–1998, defined, Glossary–10

- SMS 7000
  - connecting to, 2–16
  - serial protocol table entry, 5–29
- SNMP, defined, Glossary–10
- Snowbird, defined, Glossary–10
- SNY, 5–29
- Software
  - Configuration Editor, 5–1
  - Installation, 3–1
  - upgrade, 3–1
  - version. *See* Version information
- Software Control Panel Suite, 7–1
  - dubs panel, 7–22
  - full function machine control, 7–20
  - full function switcher panel, 7–11
    - audio switching modes, 7–14
  - license floppy, 7–1
  - salvo panel, 7–26
  - slaved machine control, 7–9
  - source/destination panel, 7–24
  - X–Y panel, 7–29
- Sony
  - Auto–Edit mode, 6–133
  - Betacart, 2–82
  - BVH–1000, 2–82
  - BVH–1100, 2–82
  - BVH–2000, 2–82
  - BVH–2500, 2–82
  - BVU–800, 2–82
  - BVW–10, 2–82
  - BVW–40, 2–82
  - IF–10, 2–90 , 2–93
  - machine control bus, 2–83
    - cable, 2–102
    - serial protocol table entry, 5–27
  - max VTRs per port, 1–19
  - Protocol to ESBUS protocol, F–2
  - router, serial protocol table entry, 5–29
  - switcher protocol, 5–39
- Source Assignment, input to production switcher, U–1
- Source/destination panel (GUI), 7–24
- Space, in set, table, & device names, 5–7
- Spaces, 5–3
- Spare parts, xxviii
- SPD, defined, Glossary–10
- SPDIF, defined, Glossary–10
- Specifications, 1–9
- Split
  - defined, Glossary–10
- Mnemonics, 5–60
- switching, 5–46
  - and Level menu entry, 5–38
  - CP–3000, 6–14
  - CP–3800, 6–41
  - CP–3808, 6–67
  - CP–3830, 6–81 , 6–94
  - CP–3832/3864, 6–101
- Spreadsheet, 5–6
- Star. *See* Nexus
- Start bit, MPK, Glossary–7
- Start Board Override, 9–4
- State PROMs, 2–3
- Status
  - defined, Glossary–10
  - display
    - under monitor. *See* SD–3x
    - VG–3000. *See* VG–3000
    - VGA, A–1
    - See also* VGA Status Display
    - header table, 5–172
  - Multiple switcher installations, 5–77
- Stereo
  - CP–3000 switching modes, 6–18
  - CP–3800 switching modes, 6–43
  - CP–3808 switching modes, 6–74
  - CP–3830 switching modes, 6–96 , 6–98
  - CP–3832/3865 status, 6–112
  - CP–3832/64 switching modes, 6–115
  - GUI panel switching modes, 7–14
  - Venus, Level jumper, 5–35
- Sticky display (CP–3800), 6–50
- Sticky levels
  - 300 Series panels, 6–1
  - CP–3824, 6–83
  - CP–3832/3864, 6–102
  - defined, Glossary–10
  - entry on MPK devices table, 5–109
- Stop bit, MPK, Glossary–7
- Stop key, MC–3000, 6–132
- Streamline. *See* Grass Valley
- Sundance, defined, Glossary–10
- Super
  - Crosspoint bus, 2–3
  - defined, Glossary–3
  - Party line, 5–169
  - defined, Glossary–7
- Support package, 5–16
- SW 2500, 1–26

- SW 3100, 1–26
- Switch rate, 1–19
- Switcher Description table, 5–31
- Switcher Input table, 5–44
- Switcher Output table, 5–51
- Switcher, data matrix, 2–32
- Switcher, distribution
  - 100/400 offset, 5–36 , 5–38
  - Alpha Image. *See* Alpha Image
  - Controlling with external computer, 2–77
  - crosspoint bus control, connecting to, 2–3
  - Datatek. *See* Datatek
  - Disabling a level, 5–56
  - ESbus
    - Physical level no., 5–38
    - Serial Protocol table entry, 5–27
  - Grass Valley. *See* Grass Valley
  - Inputs
    - Entering mnemonics for, 5–58
    - Names, length of, 5–44
  - Microvideo. *See* Microvideo
  - Multiple switcher installations
    - Status, 5–77
    - Switcher levels table entry, 5–37
  - Nexus. *See* Nexus
  - Novotronic. *See* Novotronic
  - NVISION. *See* NVISION
  - Output
    - Selecting on CP–3000, 6–20
    - Selecting on CP–3808, 6–65
  - outputs, password levels, 5–53
  - physical, input number, 5–44
  - Pro–bel. *See* Pro–bel
  - RKX. *See* RKX
  - serial connection, 2–12
  - Status
    - Checking, 6–16 , 6–69 , 6–96
    - Multiple switcher installations, 5–77
  - Switcher Description table, 5–31
  - Switcher Input table, 5–44
  - Switcher Output table, 5–51
  - switching by physical connector number, 14–1
  - Triton, Connecting to, 2–14
  - Utah Scientific. *See* Utah Scientific
- Switcher, production
  - See also* specific model
  - Input Source Assignment, U–1
- Symbols, in set, table, & device names, 5–7
- Sync
  - Reference cable, 2–103

- Vertical interval, 5–32

- Syntax, naming rules for sets, tables, CPs, etc., 5–7

- System limits, VM/SI loading, 1–18

## T

- T/CI, 2–21

- Tab–delimited, 5–6

- Table names, rules for, 5–7

- TAKE key, Expansion panel, Deleting output from, 6–24

- Take/select key (CP–3010), Machine control, 6–134

- Tally, 2–107

- advanced (white paper), 2–107

- and DD–35, 2–107

- Example of operation, 5–194

- Hardware connections, 2–107

- multi–level (air+preview+iso)(red+yellow+green), 2–107

- multimedia course, xxix

- output, 2–107

- Saturn Tally, 2–107

- software configuration, 2–110

- MPK Devices table, 5–116

- Relay Description table, 5–174

- Tally Dependency table, 5–180

- Tape

- Drives. *See* HP 9144A (1/4 in) or HP 6400/2000 (DAT)

- Machines. *See* Audio carts or VTRs

- monitor mode, MC–3000, 6–132

- TCP/IP

- See also* IP address

- defined, Glossary–10

- TCS–1

- Cable to controllers, 2–91

- Command and status bits, I–1

- CP bus, 2–89

- defined, Glossary–10

- Device codes menu, 5–168

- interface to Jupiter, 2–89

- MI bus, Connection, 2–89

- PROMs, 2–88

- Protocol Dependent Devices table entry, 5–145

- Thumbwheel settings, 5–168

- Translator, I–1

- TCS–1/2, Serial protocol table entry, 5–27

- TCS–2

- defined, Glossary–10

- Protocol Dependent Devices table entry, 5–145

- Technical paper, 2–107

- Tee cover, 2–44
- Television Systems Limited, V–1
- Telnet, 9–4
- TEN, 5–28
- TEN–20 / 20–TEN, Switcher Description table entries, VI, 5–33
- Ten–20 / 20–Ten, Physical level no., 5–36
- TEN–20, 20–TEN
  - protocol entry, 5–39
  - serial interface, connecting to, 2–20
- Termination, LAN terminators
  - Installation, 2–42
  - Part number, 2–41
- Test. *See* Diagnostics
- TFTP, 9–2
- Thin net
  - See also* LAN
  - Cable part numbers, 1–23
  - cable type, 1–14
  - Installation, 2–41
- ThinLAN. *See* Thin net
- Third party, routers
  - See also* name of router manufacturer
  - entry on Switcher Description table, 5–33 , 5–38
- Thomson Automation
  - CP Input set entry, 5–70
  - CP Output set entry, 5–91
  - hardware connections, 2–77
  - MPK Devices table entry, 5–130
  - MSL 4000, 2–77
  - Protocol Dependent Devices table entry, 5–145
  - Serial Protocol table entry, 5–28
  - special compile/download procedures, R–1
  - Switcher Initialization menu, 5–70 , 5–91
- Three–stage switching
  - defined, Glossary–10
  - Installation, H–1
- Ticks, 8–1
- Tie line, 5–196
  - defined, Glossary–11
  - status on CP–3800, 6–63
  - VGA display, A–10
- Time, Internet, 9–5
- Time code, 2–103 , 9–5
- Time Standard table, 5–212
- Time sync, 9–5

- Timeout, MPK, Glossary–7
- Tools
  - Generate VGA Files, A–2
  - Zip/Unzip, 5–15
- TRI, 5–29
- Tributary
  - defined, Glossary–11
  - ESbus. *See* ESbus tributary
  - VTR, DM 400B, 5–49
- Trinix
  - connecting to VM–3000, 2–3
  - Switcher Description table entries, protocol, 5–39
- Triton
  - connecting to VM–3000, 2–14
  - front–panel controls, not statused by Jupiter, 2–15
  - Serial Control Kit, 2–14
  - Serial Protocol table entry, 5–27
  - Switcher Description table entries
    - audio/video/data, 5–40
    - level, 5–36
    - protocol, 5–39
    - VI, 5–33
- Troubleshooting, 5–15
  - Probe connections, C–1
  - program restart, B–1
  - zipping a configuration set, 5–15
- TSL, V–1
- TVS/TAS–1000, 1–12 , 2–3
- TVS/TAS–2000/3000, connecting to VM–3000, 2–3
- TVS/TAS–2001, 1–12 , 2–3
- Twisted pair, 2–10 , 2–102
- Type 43 material, 2–11 , 2–103

## U

- U12, 5–28
- U96, 5–28
- UDI–1B, 2–25
  - serial protocol table entry, 5–27
- UL, xxvi
- UMD–3A. *See* RP 1/2/3 UMD
- Under Monitor Displays, 2–121
  - See also* SD–3x, RP 1/2/3, or TSL
  - hardware installation, 2–121
  - software configuration, 2–125
- Underscore, in set, table, & device names, 5–7
- Universal Data Interface, 2–25

Unlink, 6-138

## Unlock

- CP-3000, 6-11
- CP-3808, 6-69
- CP-3824, 6-79
- CP-3830, 6-92
- CP-3832/3864, 6-104
- force, 6-12
  - all outputs (JNS), 11-1
  - CP-3808, 6-70 , 6-71
  - CP-3824, 6-79 , 6-80
  - CP-3830, 6-92 , 6-93
  - CP-3832/3864, 6-104 , 6-105
  - CP-3864L, 6-119
  - VGA, 6-143
- Machine control, 6-138

## Unprotect

- CP-3000, 6-10
- CP-3808, 6-70
- CP-3824, 6-79
- CP-3830, 6-92
- CP-3832/3864, 6-103
- CP-3864L, 6-119
- force, 6-12
  - all outputs (JNS), 11-1
  - CP-3808, 6-70 , 6-71
  - CP-3824, 6-79 , 6-80
  - CP-3830, 6-92 , 6-93
  - CP-3832/3864, 6-104 , 6-105
  - CP-3864L, 6-119
  - VGA, 6-143

Unqualified output (tally), 5-184 , 5-190

Update Board Info, Board Info/Control menu, 9-4

Upgrade, 3-1

## Utah Scientific

- AVS-1B, connecting to, 2-27
- AVS-1B (PL-320)
  - serial protocol table entry, 5-27
  - switcher protocol, 5-39
- Party Line (UDI-1B)
  - serial protocol table entry, 5-27
  - switcher protocol, 5-39
- physical level no., 5-38
- PL-320 Control/Memory Card, connecting to, 2-27
- UDI-1B Universal Data Interface, connecting to, 2-25

Utah\_12/96, Routing switcher dialect, Matrix-physical level no., 5-38

## Utilities

- Physical diagnostic, 15-1
- Physical Remapping, 16-1

# V

V board. *See* VG-3000

Vacuum fluorescent, 6-20

Downloading , configuration set, 5-13

Validating configuration set, 5-13

Variable play key, MC-3000, 6-132

## VC-3020

- bus loading, 1-19
- Button labels, 2-72
- Front panel, A-1
- Installation, A-1
- Rear panel connectors, 1-13

VCP-3000, A-2

## VDE

- Cable modifications, 2-11 , 2-103
- Defined, Glossary-11

Ventilation space, 2-2

## Venus

- 2x1 Matrix Combiner. *See* 2x1 Matrix Combiner
- connecting to VM-3000, 2-3
- output monitoring, O-1
- stereo
  - CP-3000 switching, 6-18
  - CP-3800 switching, 6-43
  - CP-3808 switching, 6-74
  - CP-3830 switching, 6-98
  - CP-3864 switching, 6-115 , 7-14
- Level jumper, 5-35
- Switcher Description table entry, 5-32 , 5-34 , 5-35 , 5-39 , 5-40

Version information, VM/SI/Saturn software, 8-2

## VG-3000, P-1

- Software configuration, Status Display Headers table, 5-172

## VGA Status Display

- cable length, A-1
- General description, 1-3
- Generate Files command, A-2
- hardware installation, A-1
- operation, 6-141
  - force unprotect/unlock, 6-143
- redundant VM-3000s, 2-4 , K-1
- Software configuration, A-2
  - Force unprotect/unlock, 5-115
  - Machine control table, 5-158
  - MPK devices table, 5-115
  - Status Display Headers table, 5-172
  - VGA Status Display table, 5-173
- tie line (path finding), A-10

Video  
 display/generator. *See* VG-3000  
 Mode (VGA), 5-173  
 monitor combiner. *See* VM-400 or DC-400

Video Reference table, 5-212

Vistek, Array  
 Connecting to, 2-28  
 Physical level no., 5-38  
 protocol entry, 5-39  
 serial protocol table entry, 5-27

VITC, defined, Glossary-11

VM- 400, O-1

VM-3000  
 clearing battery-protected memory, B-1  
 clearing flash memory, B-2  
 clock, 2-103 , 9-5  
 connecting to  
   multiple Crosspoint Bus routers, 2-33  
   PC, 2-38  
   remote (third party) switcher, 2-12  
 connecting to router, 2-3  
 Controls, indicators, connectors, 1-9  
 devices per bus, max, 1-18  
 DIP switches, 2-2  
 force download, B-2  
 front panel (drawing), 1-10 , C-1 , S-1  
 LED error codes, S-1  
 levels, max. no. of, 1-16  
 Multiple  
   Switchers, 2-33  
   Units/levels, 5-33  
 network address switches, 2-39  
 Next key, 6-141 , A-1  
 Odd/even ports, 2-89  
 party line configuration, 5-169  
 Pin outs, serial ports, 2-102  
 Protocol table, 5-25  
 rear panel (drawing), 1-10  
 redundant installation  
   cable, 2-8  
   hardware  
     party line, 2-4 , K-1  
     Crosspoint Bus router, 2-5  
     VGA port, 2-4 , K-1  
   kit, 2-7  
   manual changeover, K-1  
   software configuration, 5-24  
   system preloading, K-2  
 Reset, B-1  
 software version, 8-2  
 status check, 8-1 , 9-1  
 three-stage, H-2

VGA display controls, 6-141 , A-1

VM-3000B, defined, Glossary-11

VMC-3000, A-2

Voltage (AC line) selection, 2-1

VPR-2, 2-82

VPR-3, 2-82

VPR-300 series, 2-82

VPR-6, 2-82

VPR-80, 2-82

VT\_, serial protocol table entry, 5-29

VTk, 5-28

VTRs  
 Connecting to, 2-83  
 controlling with  
   CP-3800, 6-45  
   non-Jupiter panels or computer, 2-97  
 ESBUS. *See* ESBUS VTRs  
 Linking to control panels, 5-151  
 Max per bus, 1-19  
 Names, entering, 5-141  
 Parallel, 2-89

## W

Warranty, xxviii

White paper, 2-107

Windows, cut and paste to Jupiter, 5-6

Word, 5-6

Work sheet, CP-3000/3010 output set, M-1

WPE, defined, Glossary-11

## X

X-Y panel (GUI), 7-29

X-Y selection, defined, Glossary-11

XPress, key features, 1-27 , 1-28 , 1-29 , 1-30

XPT, defined, Glossary-11

## Y

Y line, L-8  
 defined, Glossary-11

Y line table, 5-211



## **Z**

ZIF, defined, Glossary–11

Zion, Glossary–11

Zip/Unzip, 5–15