




3605 BUFFALO RD
ROCHESTER, NY 14624

Phone: +1-585-594-5050
Fax: +1-585-594-8888
Toll Free: +1-888-723-9230 / 24 hrs.
On the web: www.northernairsystems.com

D120FMCGA2DDA01



REV A DATE 03/17/15

TABLE OF CONTENTS

Page 3	System Specifications
Page 4	Sequence of Operation

ELECTRICAL SECTION

Page 5	Input/Output List
Page 6	Dimensional Drawing
Page 7	High Voltage Diagram
Page 8-9	Control Wiring Diagram

REFRIGERATION SECTION

Page 10	Charging Information
Page 11	Refrigeration Piping Diagram
Page 12-13	Digital Compressor Controller Information (DCC)

CONTROLLER MENUS AND NAVIGATION

Page 14	Quick Reference Guide
Page 15-18	PLC Menus and Displays

SYSTEM ALARMS AND TROUBLESHOOTING

Page 19-20	System Alarms and Troubleshooting
Page 21-22	Replacement Parts Lists
Page 23	Installation Instructions
Page 24-26	Startup Procedures
Page 27	Maintenance Guidelines
Page 28-29	PM Service Checklist
Page 30	Sensor Calibration
Page 31	Rigging Instructions

System Specifications

Capacity: 120,000 BTU/hr @ 80F db/67F wb return air, 95F ambient air temperature

Supply Airflow: 3500 CFM @ 0.5"

Heat Capacity: 9 kW Per Side

Condenser Airflow: 6000 CFM

Refrigerant: 17 lbs. R407C Per Side

POWER:

230 VAC

1 PHASE

60 Hz

Per Side:

1 - .75 kW	Cond. Fan Motor	3.4 FLA
1 - 5.7 kW	Compressor	28.8 FLA
1 - .50 kW	Evap. Fan Motor	2.8 FLA
2 - 4.5 kW	Electric Heater	20.0 FLA ea.

MAX OVERCURRENT PROTECTION (MOP): 110

MINIMUM CIRCUIT AMPACITY (MCA): 90

COOLING FLA: 36

HEATING FLA: 45

COMBINED FLA: 81

Sequence of Operations

- System is turned on by the PGD display interface or selector switch
- System reads temperatures, humidity (optional) and system refrigerant pressures, as well as checks all alarm circuits for faults
- If unit is turned on and no faults are present, the evaporator fan contactor will be activated. The evaporator fan and condenser fans will run for 30 seconds as a purge cycle. The condenser fans will be deactivated; the evaporator fan will stay activated.
- Digital Compressor starts and runs modulating to maintain suction pressure set point.
- Based on cooling demand the system provides 0 – 10v output to digital compressor
- The condenser fans speed up and down based on pressure using a 0 – 10 volt analog signal to the drive.
- Heating is activated when the temperature drops below set point by 2° and turns off when temperature is satisfied.(Can be configured through factory)
- If there is a need for heating, the system stops cooling by bringing compressor demand to 0% and shut off when in cycling mode (optional)
- In the case of high humidity, the system will run cooling and heat at the same time to dehumidify and maintain temperature set points.(optional)
- When humidification is required, the system enables the humidifier contactor and sends a 0-10 volt signal to the CP4 board. (optional)
- In the event of an alarm, the system will display each one with a time and date stamp. This will be displayed until the problem is solved and alarm is reset by the control pad display.

**WALL MOUNT, 2.8V PCO3
SMALL**

		Analog Input									Digital Input		Analog Output		Digital Output		Relay (max.8, 250Vac 8A res.) Switching (max.1, 24Vac/dc 10W)	
		NTC Probe (max.5)	PT 1000 (max.2)	ON/OFF (max.2)	0-1V (max.3)	0-10V (max.3)	0-20 mA (max.3)	0-5V Ratiometric (max.3)	4-20 mA (max.3)	24 Vac/Vdc (max.8)	110/230 Vac (max.N/A)	0-10 V (max.4)						
WALL MOUNT, 2.8V PCO3 SMALL																		
Analog Inputs																		
AI-1	Low pressure sensor								X									
AI-2	High pressure sensor								X									
AI-3	Humidity Sensor (optional)				X													
AI-4	Room temperature		X															
AI-5	Suction temperature (optional)		X															
		Total	2			1			2									
Digital Inputs																		
DI-1	Phase monitor									X								
DI-2	Evaporator fan fault									X								
DI-3	Condenser fan fault									X								
DI-4	Low air flow switch or Generator status									X								
DI-5	Heater fault									X								
DI-6	Compressor 1 fault									X								
DI-7	Humidifier fault or Compressor #2 Fault (optional)									X								
DI-8	On/Off switch									X								
		Total								8								
Analog Output																		
AO-1	Condenser fan VFD 0-10vdc											X						
AO-2	Evaporator fan VFD 0-10 vdc											X						
AO-3	Digital compressor demand											X						
AO-4	Humidifier demand (optional)											X						
		Total										4						
Digital Outputs																		
DO-1	Heater #1 contactor												X					
DO-2	Heater #2 contactor												X					
DO-3	Heater #3 contactor (optional)												X					
DO-4	Evaporator fan contactor												X					
DO-5	Standard compressor or #2 compressor contactor (optional)												X					
DO-6	Remote Alarm Contact												X					
DO-7	Condenser fan VFD enable												X					
DO-8	Humidifier enable (optional)												X					
		Total											8					

Pco Address 1


***When using lead lag option the second unit Pco address will be 2

First Unit Hot Gas EVD Address 3

Second Unit Hot Gas EVD Address 4

05/11/10

1
2
3
4
5
6
7
8
9
10
11
12



- DCC TERMINALS
- 24COM Module Common
 - 24VAC Module Power
 - C1 Demand Common
 - C2 Demand Input +5VDC
 - P1 Pressure Common
 - P2 Pressure Signal
 - P3 Pressure Power +5VDC
 - P4 Pressure Shield
 - P5 Pressure Output Common
 - P6 Pressure Output +5VDC
 - T1 Discharge Temp Sensor
 - T2 Discharge Temp Sensor
 - A1 Alarm Relay Out
 - A2 Alarm Relay Out
 - M1 Contactor Coil
 - M2 Contactor Coil
 - L1 Control Voltage N
 - L2 Control Voltage L
 - U1 Digital Unloader Solenoid
 - U2 Digital Unloader Solenoid
 - V1 Vapor Injection Solenoid
 - V2 Vapor Injection Solenoid



	NAME	DATE	REV.	DATE	NAME	CHANGES	REVISION
DRAWN BY:	TJF	2/5/2015	A	2/5/2015	t.friday		A
APPROVED BY:							SCHEME
							5.1
D120FMCGA2DDA01						DIGITAL COMP CONTROL	9

CHARGING INFORMATION


Proper Refrigerant charge is critical for proper operation of unit across varying ambient conditions. System may operate with clear sight glass in warmer temperatures then charge may be insufficient once ambient temperatures drop.

Service Personnel should be familiar with head pressure control valves and their operation.


Consequently the only accurate method is to remove all refrigerant and weigh in charge to system name plate specifications.

If removing refrigerant to weigh use only clean non contaminating recovery tanks.

Systems using blended refrigerants and had refrigerant leaks we recommend replacing with all new refrigerant. 407C is a blended refrigerant.



REVISION HISTORY			
REV	DESCRIPTION	DATE	ECN#
A	INITIAL RELEASE	10/18/2010	

	NAME	DATE	 TITLE: REFRIGERATION DIAGRAM		
DRAWN	TMR	4/14			
CHECKED	TMR	4/14			
ENG. APPR.	TMR	4/14			
PROPRIETARY AND CONFIDENTIAL THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF NORTHERN AIR SYSTEMS. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF NORTHERN AIR SYSTEMS IS PROHIBITED.			SIZE B	DWG. NO. D120FM-12-00001	REV A
			SCALE: NONE	WEIGHT:	SHEET 1 OF 1 11

DIGITAL SCROLL INFORMATION

Flash Code Troubleshooting

While each ALERT code is active, the alarm relay contacts (A1 and A2) are closed. The ALERT code will remain active and the alarm relay contacts closed until the reset conditions have been met or 24 VAC power has been cycled off and on. All Flash Codes except Code 6 and 8 result in the compressor contactor, unloader solenoid and vapor injection being deenergized.

All LEDs flashing at the same rate indicates 24VAC supply is too low for operation. All LEDs on solid at the same time indicates Digital Compressor Controller failure.

Whenever power is cycled off and on, the current Flash Code and all internal counters are reset.

Flash Code 1 – Reserved for future use

Flash Code 2 – High Discharge Temperature

The discharge temperature thermistor has measured a temperature above 268°F (130°C) or the thermistor is short circuited (jumpered out)

The Digital Compressor Controller will deenergize the compressor contactor, unloader solenoid and vapor injection solenoid. The alarm relay contacts will close.

The compressor will be allowed to restart after a 30 minute delay and after the thermistor temperature is below 250°F (120°C). The Flash Code and alarm relay contacts will be reset after the compressor has run for 60 uninterrupted minutes without any other alerts.

If five high discharge temperature ALERTs have occurred within four hours, the Digital Compressor Controller will lock out the compressor. The lockout can only be reset by cycling the 24VAC power off and on.

Flash Code 3 – Compressor Protector Trip

The demand signal from the system controller is greater than 1.44VDC and there is no compressor current detected. This could be due to the compressor's internal overload protector being open, fuse or breaker open, power disconnected to compressor contactor, compressor power wiring not run through Digital Compressor Controller current transformer port or a compressor contactor failure.

The Digital Compressor Controller will deenergize the compressor contactor, unloader solenoid and vapor injection solenoid. The alarm relay contacts will close.

The Digital Compressor Controller will wait for the two minute anti-short cycle timer to time out and if the system controller demand signal is still greater than 1.44VDC, energize the compressor contactor again. If compressor current is detected on the restart, the ALERT code and alarm relay output will reset. The Digital Compressor Controller will attempt to restart compressor as long as the system controller demand is above 1.44VDC there is no lockout feature for this ALERT.

Flash Code 4 – Locked Rotor

A locked rotor condition in the compressor is sensed by the Digital Compressor Controller on four consecutive start ups.

The Digital Compressor Controller will deenergize the compressor contactor, unloader solenoid and vapor injection solenoid. The alarm relay contacts will close.

This code results in a lockout and can only be reset by cycling the 24VAC power off and on.

Flash Code 5 – Demand Signal Loss

The demand signal input has dropped below 0.5VDC. The demand input signal wire may be disconnected or the system controller providing the signal may not be powered.

The Digital Compressor Controller will deenergize the compressor contactor, unloader solenoid and vapor injection solenoid. The alarm relay contacts will close.

Once the system controller demand signal input has risen above 0.5VDC, the ALERT code, and alarm relay output will reset. If the demand signal is above 1.44VDC and the anti-short cycle timer has timed out, the compressor will restart.

The alarm relay contacts will close and the Digital Compressor Controller will not increase the capacity of the compressor beyond 50% loading.

This ALERT code and alarm relay output are reset by reconnecting the thermistor.

Flash Code 7 - Unloader Solenoid Fault

Reserved for future use

Flash Code 8 - Compressor Contactor Fault

Compressor current is detected when the system controller demand signal is below 1.44VDC. The compressor contactor may have welded contacts or the contacts may be mechanically jammed. The compressor will continue to run in this condition since the Digital Compressor Controller cannot open the compressor contactor.

The Digital Compressor Controller will energize the compressor contactor and vapor injection solenoid. The alarm relay contacts will close. The unloader solenoid will remain energized causing the compressor to run unloaded as long as the system controller demand signal is less than 1.44VDC. If the system controller demand is greater than 1.44VDC, the unloader solenoid will deenergize causing the compressor to run loaded.

The ALERT code and alarm relay output are reset when current is no longer detected while system controller demand signal is below 1.44VDC.

Flash Code 9 - Low 24VAC Supply

Supply voltage to the Digital Compressor Controller has dropped below 18.5VAC.

The Digital Compressor Controller will deenergize the compressor contactor, unloader solenoid and vapor injection solenoid. The alarm relay contacts may close if the voltage is high enough for the alarm relay to pull in.

The ALERT code and alarm relay output are reset when the supply voltage to the Digital Compressor Controller rises above 19.5VAC.

Testing the Installed Digital Compressor Controller

Once installed, the Digital Compressor Controller can be tested to verify it is working properly. In each test, 24VAC must be supplied to 24VAC and 24COM. For the output test, 24VAC must be supplied to L1 and L2.

Input Tests

Thermistor Input – disconnect the discharge temperature sensor wires from terminals T1 and T2. If functioning normally, the Digital Compressor Controller should display a Code 6 unless a previous ALERT code was present.

Demand Input – disconnect the System Controller Demand signal wires from C1 and C2. If functioning normally, the Digital Compressor Controller should display a Code 5 unless a previous ALERT code was present.

Output Tests

Contactor Output – while the Digital Compressor Controller is powered off (no supply voltage to 24VAC and 24COM), disconnect the System Controller Demand signal wire from C1 and C2. Add a jumper wire from P3 to C2 and a second jumper wire from P1 to C1. Reapply power to 24VAC and 24COM. If functioning normally, a voltmeter should read the same voltage across M1 and M2 as is measured across L1 and L2, unless an ALERT code is present.

Unloader Output – while Digital Compressor Controller is modulating the unloader solenoid, a voltmeter should read the same voltage across U1 and U2 as is measured across L1 and L2 whenever the yellow "Unloader" LED is lit.

QUICK REFERENCE GUIDE

CAREL CONTROLLER: PCO 3 Small - 2.8v / 3.0v

MAIN MENU

- Main Screen – Normal display screens, current running temperature, humidity and pressures.
- On/Off unit – Enables and disables system
- Set Points – Ability to change all temperature and humidity set points.
- Run Times – Displays run hours of all compressors.
- Min/Max reading – Displays min and max temperature and humidity in last 24 hours.
- Factory menu – Factory set and factory authorized changes only
- Network status – Display status of devices on the network.
- Alarm history – Shows all past alarms

VIEW AND CHANGE SET POINTS

- Press **"Prg"** to view menu list
- Press **↓** to highlight **"Set Points"**
- Press **↵**
- Press **↵** to move cursor to password
- Press **↓** to set password to **9999**
- Press **↵** (Set points will be displayed)
- Press **↓** until desired set point is displayed
- Press **↵** to move cursor to desired set point
- Press **↑** or **↓** to change the set point
- Press **↵** to initialize & save the set point
- Press **"Esc"** twice to exit set points and return to the **"systems status"** screens

TO VIEW CURRENT ALARMS

- Press **🔔**
- Press **↓** to view
- Press **↵** when prompted to clear current alarms


TO VIEW CURRENT STATUS

VIEW ALARM HISTORY

- Same as above but select **"Alarm History"** rather than **"Set Points"**
- Press **↑** to view past alarms

- Press **"Esc"** as needed
- Press **↑** or **↓** to view

*** AT ANY TIME THE ESC KEY TO GET BACK TO THE MAIN "SYSTEMS DISPLAY SCREENS"**



PLC MENUS AND DISPLAYS

MENU	DISPLAY	OPTIONS	DESCRIPTION
SYSTEM STATUS			
	TEMPERATURE	X DEG F	Displays current room temperature
	HIGH PRESSURE	X PSI	Displays current high pressure
	LOW PRESSURE	X PSI	Displays current low pressure
	HUMIDITY	X %	Displays current relative humidity (optional)
	HEAT DEMAND	X %	Displays current heating demand
	COOL DEMAND	X %	Displays current compressor demand
	COND FAN DEMAND	X %	Displays current condenser fan demand
	EVAP FAN SPEED	X %	Displays current evaporator fan speed
	HUMIDITY DEMAND	X %	Displays current humidification demand (optional)
	HEAT STAGE	X	Displays current heating stage
	TEMP SETPOINT	X DEG F	Displays current room temperature set point
	HUM SETPOINT	X %	Displays current room humidification set point (optional)
	DEHUM SETPOINT	X %	Displays current room dehumidification set point (optional)
	UNIT MODE	Multiple	Displays the current mode of operation
	STATUS	ON / OFF by switch	Displays the position of the unit ON/OFF switch
UNIT ON/OFF			
System ON/OFF	STATUS	ON/OFF BY SWITCH	Displays position of unit ON/OFF switch
	STARTUP DELAY:	X MIN	Allows fans to run for X amount of time before starting the compressor
	UNIT ADDRESS	X	Displays the units Plan communication address
	UNIT MODE	Multiple	Allows selection of unit mode of operation
SETPOINTS			
PSWD: 9999	TEMPERATURE	X DEG F	Controls temperature setpoint
	HUM SETPOINT:	X %	Controls humidification setpoint (optional)
	DEHUM SETPOINT:	X %	Controls dehumidification setpoint (optional)
	DEHUM STOP BAND	X DEG F	Number of degrees above or below setpoint dehumidification starts and stops
FACTORY MENU / CONFIGURATION			
	COND VFD SETP	X PSI	Controls the high pressure at which the condenser fan is set to maintain
	COND VFD EN	X PSI	High pressure set point used to enable the condenser fan VFD
	COND VFD START	X %	Percentage at which condenser fan will run during purge cycle on start up
	LEAD/LAG ENABLE	OFF	Not used
	ALT DUAL ENABLE	OFF	Not used
	ALT DUAL SETUP	X DEG F	Not used. DO NOT CHANGE
	DEMAND SD TIMER	X MIN	Compressor will shut down after having zero demand for this amount of time
	MIN COMP RUN V	X V	Output voltage to compressor controller at zero demand while running
	COMP OFF VOLT	X V	Output voltage to compressor controller while compressor is not running

COMP MIN OFF	X MIN	Minimum amount of time in minutes that the compressor cannot be off
COMP TYPE	CYCLING	Allows the compressors to be set for cycling or continuous run. DO NOT CHANGE
DEMAND SD TIME	X MIN	The amount of time in minutes the compressor demand is at 0% before the compressor will be deactivated.
LP SETPOINT	X PSI	Low pressure set point the compressor is modulating to maintain during cooling operation
COOL ON SETP	X DEG F	Degrees above set point when cooling is activated
DIG TANDEM COMP	NO	Not used. For use with Tandem compressors
EVAP VFD SPEED	X %	For use on systems with evaporator fan VFD DO NOT CHANGE
COND VFD TUNING	MULTIPLE	PI control loop settings for condenser fan, DO NOT CHANGE
COOLING TUNING	MULTIPLE	PI control loop settings for compressor, DO NOT CHANGE
HEATING TUNING	MULTIPLE	PI control loop settings for heating, DO NOT CHANGE
HUMIDIFIER TUNING	MULTIPLE	PI control loop settings for humidification, DO NOT CHANGE
CLOCK	TIME/DATE	Allows user to set the time and date
TEMPERATURE UNITS	°F / °C	Allows change of temperature unit of measure
PRESSURE UNITS	PSI	Displays the pressure unit of measure
CHANGE PASSWORD SERVICE	XXXX	Allows change of service level password
CHANGE FACTORY PASSWORD	XXXX	Allows change of factory level password
FACTORY MENU / I/O CONFIGURATION		
LOW PRESSURE	MULTIPLE	Low pressure sensor set up & calibration
HIGH PRESSURE	MULTIPLE	High pressure sensor set up & calibration
HUMIDITY	MULTIPLE	Humidity sensor set up & calibration (optional)
TEMPERATURE	MULTIPLE	Temperature sensor set up and calibration
SUCTION TEMP	MULTIPLE	Suction temp sensor set up & calibration (optional)
PHASE MONITOR	MULTIPLE	Phase monitor input set up
EVAP FAN FAILURE	MULTIPLE	Evap fan failure input set up
COND FAN FAILURE	MULTIPLE	Condenser fan fault input set up
AIR FLOW SWITCH	MULTIPLE	Optional airflow switch can be used to indicate dirty filters
HEATER FAILURE	MULTIPLE	Heater failure input set up
COMPRESSOR OVERLOAD	MULTIPLE	Compressor fault input set up
HUMIDIFIER FAILURE	MULTIPLE	Humidifier fault input set up (optional) If humidifier CP4 board faults, this alarm will be activated. See troubleshooting guide in humidifier section in this manual
ON/OFF SWITCH	MULTIPLE	ON/OFF switch input set up
REMOTE PANEL OPR	MULTIPLE	Remote panel operations input set up
GENERATOR STATUS	MULTIPLE	Generator input set up (optional)
FACTORY MENU / MANUAL CONTROL		
COND VFD	AUTO/HAND %	Allows manual operation of the condenser fan VFD
EVAP COND VFD	AUTO/HAND %	Only used on systems equipped with evaporator fan VFD. Allow manual control of evaporator fan VFD
MOD COMP	AUTO/HAND %	Allows manual operation of the modulating compressor

	HUMIDIFIER	AUTO/HAND %	Allows manual operation of the modulating humidifier
	HEATER 1	AUTO/HAND ON/OFF	Allows manual operation of the stage 1 heater contactor (optional)
	HEATER 2	AUTO/HAND ON/OFF	Allows manual operation of the stage 2 heater contactor (optional)
	HEATER 3	AUTO/HAND ON/OFF	Allows manual operation of the stage 3 heater contactor (optional)
	EVAP FAN	AUTO/HAND ON/OFF	Allows manual operation of the evaporator fan contactor
	COND EN	AUTO/HAND ON/OFF	Allows manual operation of the condenser fan VFD enable
	HUMID EN	AUTO/HAND ON/OFF	Allows manual operation of the humidifier enable
	COMP2	AUTO/HAND ON/OFF	Allows manual control of compressor#2 only used on systems equipped with 2 compressors
	ALARM	AUTO/HAND ON/OFF	Allows manual control of remote alarm output. Used to test light bulb and/or siren
FACTORY MENU / ALARM SET POINTS			
	TEMP AL DELAY	X MIN	Delay on start up only before hi or lo temp alarm is allowed
	HI TEMPERATURE	X DEG F	Degrees above set point when hi room temp alarm is activated
	LO TEMPERATURE	X DEG F	Degrees below set point when lo room temp alarm is activated
	LO PR SHUTDOWN	X PSI	Low pressure alarm set point that compressor will shutdown
	LO FREQUENT PR	X PSI	Frequent low pressure alarm set point no comp shutdown
	LO PR TIMEOUT	X MIN	Delay before alarming on frequent low pressure alarm
	HI PR SHUTDOWN	X PSI	High pressure alarm set point that compressor will shutdown
	HI FREQUENT PR	X PSI	Frequent high pressure alarm set point no comp shutdown
	HP TIMEOUT	X MIN	Delay before alarming on frequent high pressure alarm
	PLAN ALARM DLY	X SECONDS	The amount of time in seconds the PLAN network is off line before alarm is activated
	HIGH HUMIDITY	X %	Relative humidity at which high humidity alarm is activated
	LOW HUMIDITY	X %	Relative humidity at which low humidity alarm is activated
FACTORY MENU / HUMIDIFY/DEHUM			
	HUMIDIFIER ENABLE	ON/OFF	Activates humidification control option
	DEHUM ENABLE	ON/OFF	Activates dehumidification control option
	DEHUM BAND	X %	Controls RH% at which dehum is activated and deactivated
FACTORY MENU / HEAT SETUP			
	HEAT STAGE DELAY	X MIN	Delay time between stages of heat activation
	HEATING OFFSET	X DEG F	Degrees below set point when heating is activated
	STAGING	X %	Controls the demand for heat at which each stage is activated and deactivated.
FACTORY MENU / VALVE SETUP			
	ENABLE HOT GAS EVD	NO	Allows the enabling of electronic hot gas bypass valve controls. Not used DO NOT CHANGE

	ENABLE SPRHT EVD	NO	Allows the enabling of electronic pressure regulating valve controls. Not used DO NOT CHANGE
RUN TIMES			
	HEATER 1	X HRS	Displays current total hours of operation (optional)
	HEATER 2	X HRS	Displays current total hours of operation (optional)
	HEATER 3	X HRS	Displays current total hours of operation (optional)
	EVAPORATOR FAN	X HRS	Displays current total hours of operation
	COND FAN EN	X HRS	Displays current total hours of operation
	HUMIDIFIER EN	X HRS	Displays current total hours of operation (optional)
	COMPRESSOR	X DEG F	Displays current total hours of operation
MIN/MAX READINGS			
	HIGH PR	X PSI	Displays min and max readings over past 24 hours of operation
	LOW PR	X PSI	Displays min and max readings over past 24 hours of operation
	HUMIDITY	X %	Displays min and max readings over past 24 hours of operation (optional)
	TEMP	X DEG F	Displays min and max readings over past 24 hours of operation
NETWORK STATUS			
	NETWORK STATUS	NONE	Displays current network status an component address
ALARM HISTORY			
	ALARMS	ALARMS	Displays all past alarms with time and date stamp. Also the power supplied from generator or shore during the fault (optional)

SYSTEM ALARMS & TROUBLESHOOTING

DISPLAY	DESCRIPTION & TROUBLESHOOTING TIPS
FREQUENT LOW PRESSURE	Low pressure is nearing the low pressure shutdown setpoint: check for accurate pressure sensor reading, dirty evaporator coil or air filters. Make sure liquid line solenoid is open and liquid line filter drier is not plugged. Check for proper refrigerant charge & leak check.
LOW PRESSURE SHUTDOWN	Low pressure has reached the low pressure shutdown setpoint and has shut down the compressor: check for accurate pressure sensor reading, dirty evaporator coil or air filters. Make sure liquid line solenoid is open and liquid line filter drier is not plugged. Check for proper refrigerant charge & leak check.
FREQUENT HIGH PRESSURE	High pressure is nearing the high pressure shutdown setpoint: check for accurate pressure sensor reading, dirty condenser coil or lack of air flow through the condensing coil.
HIGH PRESSURE SHUTDOWN	High pressure has reached the high pressure shutdown setpoint and has shut down the compressor: check for accurate pressure sensor reading, dirty condenser coil or lack of air flow through the condensing coil.
LOW HUMIDITY	(Optional) The relative humidity level is below the alarm set point, check the humidifier, humidifier water supply tank and pump for proper operation. Also check for accurate humidity reading.
HIGH HUMIDITY	(Optional) The relative humidity level is above the alarm set point, check for accurate humidity reading, if dehumidification is needed ensure that the dehumidification option is activated in the factory menu.
LOW TEMPERATURE	The room temperature is below the low temperature alarm set point, check heater operation.
HIGH TEMPERATURE	The room temperature is above the high temperature alarm set point, check air conditioning operation.
EVAPORATOR FAN FAULT	The evaporator fan has possibly overheated: using the schematics in this manual check all wiring connections to the fan motor. Check all wiring from EBCR-1 to PCO3 controller. Check fan for high motor temperature and or seized bearings. Check the EBCR-1 for green light to be on. If green light is on, but alarm is present and all wiring is tight and correct, replace EBCR-1. If light on EBCR-1 is not on, check for 24vac at NO4 on PCO3 controller, if no 24vac, replace PCO3. If 24vac is good, check for continuity to ground on terminal A2 of EBCR-1. If it is open and no loose connections, replace fan as necessary.
CONDENSER FAN FAULT	The condenser fan has possibly overheated: Check all wiring connections to the fan motor. Check fan for high motor temperature and or seized bearings. Check motor overload wires for continuity, if open replace fan as necessary.
PHASE MONITOR FAULT	(Optional) Phase protection monitor has faulted: Check for 3 phase line voltage to be within the setting on the phase monitor & adjust phase monitor if required. If 3 phase line voltage is within the setting, check wiring connections to phase monitor from the PCO controller, replace monitor if necessary.

HEATER FAULT	The electric heaters have possibly overheated: If heat contactor is pulled in and running check the heat contactors for defective auxiliary contacts. If the heat contactors are not pulled in check all wiring connections to the heat contactors and heat elements. Check the auto reset high limit switch for closure, if open and plenum is below 145 degrees replace the automatic high limit switch. Also ensure the one shot high voltage cut out switches are closed.
COMPRESSOR FAULT	The digital compressor controller has faulted or the manual reset high pressure switch has tripped: Push the high pressure switch reset button located on the high side of the system, if compressor starts then look for dirty condenser coils or lack of air flow through condenser coil. If switch was not tripped check the compressor body for excessively high temperature, if compressor is truly overheated check refrigerant charge for 10 degree sub cooling and proper 12 degree superheat, adjust charge accordingly and leak check. If compressor is not hot check wiring to the compressor and the compressor controller. Count the red flashing light on the digital compressor controller and refer to this manual for the compressor controller fault codes and explanations.
LOW PRESSURE SENSOR FAIL HIGH PRESSURE SENSOR FAIL HUMIDITY SENSOR FAIL (optional) ROOM TEMPERATURE SENSOR FAIL SUCTION TEMPERATURE SENSOR FAIL (optional) OUTSIDE AIR TEMP SENSOR FAIL (optional)	The PLC has lost the input signal from the sensor. Check for broken wires, loose connections or terminations. Replace sensor as needed.

ELECTRICAL PARTS LIST

<u>DESCRIPTION:</u>	<u>PART NUMBER:</u>	<u>QTY- PER SIDE</u>
Controller, PC03 Small	20EPC03000ES0	1
Transformer	20E694M2A	1
Compressor Controller-DCC	20ETT72A10	1
Solenoid Coil, Unloader, Compressor, 24vac	20R923005800	1
Contact, 25 amp, 24vac	20G55801	2
Compressor Contactor, 32 amp, 24vac	20ED32B7	1
Compressor Run Capacitor	20E014006427	1
Compressor Secure Start Module	20E543012000	1
Crank Case Heater, Compressor	20E918-0043-00	1
Solenoid Coil, Liquid Line, 24vac	20S45201	1
Relay, Evap. Blower Fault, 24vac, EBCR-1	20E700HTLT2U24	1
ON/OFF Selector Switch	20G56901	1
ON/OFF Selector Switch Base	20G57001	1
Phase Monitor	20EICM408	1
High Pressure Switch, Manual Reset- 475psi	20E100DA2	1
Pressure Sensor	20C12101	2
Pressure Sensor Cables	20C13601	2
Temperature Sensor, Wall Mount- NTC	20C11901	1
Remote Display, Wall Mount- PGD1 (option)	20EPGD1	1
Evaporator Blower Assembly, EC	20MR3G280AF35	1
Condenser Fan Assembly, EC	20MS3G500	1
<u>HEATER PARTS LIST</u>		<u>QTY- PER SIDE</u>
Heater Element	20E45KW208	2
High Temperature Cutout, 300°, One Shot	20EL300F	2
High Temperature Cutout, 150°, Auto Reset	20ETT72A3	1

REFRIGERATION PARTS LIST

<u>DESCRIPTION:</u>	<u>PART NUMBER:</u>	<u>QTY- PER SIDE</u>
Compressor, Digital	20RZRD612301	1
Isolators, Compressor	20M527011600	1 PKG
Unloader Solenoid Valve & Tubing Kit	20R998007300	1
Liquid Receiver	20RL516C	1
Sight Glass, 1/2"	20S43102	1
Access Ports, Bulk Head Connections	20R3DXA2	2
Flexible Line, 36"	20RSEC99AB36	2
Solenoid Valve, Liquid Line, 1/2"	20RTT72A6	1
Drier, Liquid, Sweat, 1/2"	20SC164S	1
Suction Liquid Line Heat Exchanger	20RHXR150	1
Thermostatic Expansion Valve	20RBBIVE5	1
Head Pressure Control Valve	20S45601	1
Pressure Differential Valve	20S46901	1
Coil, Evaporator, Left	20REC16X38L	1
Coil, Evaporator, Right	20REC16X38R	1
Coil, Condenser, Right	20RCC48-1	1
Coil, Condenser, Left	20RCC48-1M	1
Refrigerant, 407C	20R407C	17 lbs
Filters, Return Air, Pleated- 18x20x2	20M1TBE4	2
Access Latch, Tool Slotted Cam	20M12265A53	1

Installation Instructions

To prevent warranty voiding installation and start up is to be performed by factory approved and trained personnel. These instructions are reference only.

- **CONDENSATE DRAIN CONNECTIONS:**

Connect all condensate drains with a minimum of ¾" line size and a 4" trap on each.

- **MAIN ELECTRICAL CONNECTIONS:**

Supply proper power using unit nameplate in electrical compartment conforming to local codes and ordinances. Install cover after connections are made.

- **INSTALL TEMP SENSORS:**

Mount and wire temperature sensors in proper location based on system design wiring diagram to show wire terminations.


- **MOUNTING TEMP/HUMIDITY SENSOR (When equipped)**

Connect temp/humidity sensor for room to designated 18/4 conductor cable off the front of A/C unit. Electrical diagram in this manual will show connections. Mount sensor in proper location based on system design.

- **CALIBRATE ALL SENSORS FOR HUMIDITY AND TEMPERATURE**

- **TEST AND RUN HEATING SYSTEM (When equipped)**

- **CHECK FLOW RATES AND CIRCUIT SETTER OPERATION (When equipped) Chillers Only**

	Date	
	Unit Model No.	
	Unit Serial No.	

A/C UNIT START UP PROCEDURE

NOTE:

“Side 1” is on the right when facing the condenser side of the unit.

“Side 2” is on the left when facing the condenser side of the unit.

Side 1

Side 2

- | | | |
|-------|-------|--|
| _____ | _____ | Mount and seal the system water-tight to the building or trailer. |
| _____ | _____ | Connect the approved supply and return duct systems to the unit. |
| _____ | _____ | Where desired, mount and connect the air temperature sensor and remote display. <i>Sensor placement is crucial to proper operation.</i> |
| _____ | _____ | Connect the condensate drain piping to the system if required. |
| _____ | _____ | Connect high voltage power leads to the unit's line voltage breaker. Connect ground wire to ground lug mounted on electrical panel. |
| _____ | _____ | Check for loose wiring on all high voltage connections including: phase monitor (optional), distribution block and contactors, by tightening each screw terminal as well as inspecting the wire terminations themselves. |
| _____ | _____ | Be sure all screw terminals and plug connections on the PCO controller are tight and secure |
| _____ | _____ | Inspect all mounting hardware for tightness on all fan motors, compressors, top skin, doors and all metal skins and covers. |



A/C UNIT START UP PROCEDURE

Continued

Side 1

Side 2

- | | | |
|-------|-------|--|
| _____ | _____ | Inspect all copper piping for proper mounting and strapping. Make sure there are no places where friction or rubbing can occur |
| _____ | _____ | Check access ports to be sure all caps are present. Look for any signs of oil which could indicate a refrigerant leak or damage in shipping |
| _____ | _____ | Inspect refrigerant piping insulation to ensure a good adhesion. |
| _____ | _____ | Make sure there is no continuity from L1, L2 or L3 to ground. |
| _____ | _____ | Make sure the system switch in the panel is turned off. |
| _____ | _____ | Turn on the main line voltage breaker in the electrical panel. |
| _____ | _____ | Power up high voltage to unit. |
| _____ | _____ | Check to make sure the controller powers up. |
| _____ | _____ | Check compressor crankcase heaters for operation. |
| _____ | _____ | Check the controller display for an accurate temperature reading against your temperature meter and adjust as needed in "Factory Menu" under "I/O Configuration". (Password is 9230) |
| _____ | _____ | Check for any alarms and troubleshoot as needed. |
| _____ | _____ | Check the remote display for operation. |



A/C UNIT START UP PROCEDURE

Concluded

Side 1 Side 2

- | | | |
|-------|-------|---|
| _____ | _____ | Make sure the condenser door panels are open, all other doors and panel covers are closed and air ducts are finished and diffusers open. |
| _____ | _____ | Turn system switch to on |
| _____ | _____ | Adjust the temperature set point under "Setpoints" menu on the controller (Password is 9999). Raise the temperature set point above currently displayed temp to call for heat. When heating starts, take an amp draw reading on the heater contactors to ensure heat is functioning. Let the heat run full out for five minutes. Refer to name plate label on the inside of electrical door for amp draw ratings. |
| _____ | _____ | Check for proper condenser fan operation. |
| _____ | _____ | Adjust the set point back to 72°F or as desired. |
| _____ | _____ | Let the unit continue to run and periodically check for any alarms on the display. |
| _____ | _____ | Northern Air Systems recommends replacing the air filters prior to system release to the end user. |

System commissioning is complete.

Thank you for choosing a Northern Air Systems custom air conditioning unit.

To contact us: 3605 Buffalo Road, Rochester, NY 14624, 888-723-9230
www.northernairtech.com

MAINTENANCE GUIDELINES

General

Restricted airflow through the evaporator & condenser coils will reduce the operating efficiency of the unit and can result in high temperatures and loss of cooling or heating. Clean all coils of debris that will inhibit air flow. This can be done with compressed air or an environmentally safe commercial coil cleaner. Thoroughly rinse the coil to remove any cleaner residue. Check for bent or damaged fins and repair as necessary. In winter, do not permit snow to accumulate around the sides or underneath the condenser coil. Snow or ice accumulations on the fan blades will cause them to be out of balance.

Condenser Fans

Inspect the motor & fan assembly to ensure bearings are free and motor is secure within its mount.

Evaporator Fan Section

Check air filters after initial run period and monthly thereafter, replacing as necessary.


Replace with the same size, and type filters as originally furnished. Periodic checks of the blower package include: motor mounts, fan bearings and wheels.

Refrigerant Piping

Visually inspect all refrigerant lines for signs of oil leaks, an indicator of a refrigerant leak. Check the refrigerant charge at the system sight glass. A bubbling sight glass does not always mean low charge. Use good troubleshooting methods to determine a leak location or possible restrictions leading to this condition. Check all piping for vibration isolation and support as necessary. Also check all roto-lock connections for tightness on compressors.

Electrical

Check and record all running amperage of all fan motors, heaters and compressors. Also look for signs of heat and loose connections. Make sure line voltage is switched off while tightening wires.

	Date	
	Unit Model No.	
	Trailer No.	
	Unit Serial No.	

A/C PM Service Checklist- Per Side

This form is to be filled out and signed by the person performing the preventive maintenance service procedure.

- _____ Check for loose wiring on all high voltage breakers, variable frequency drives, overload starters and contactors by tightening each screw terminal and inspecting the wire terminations.
- _____ Inspect and tighten all compressor wiring.
- _____ Inspect all low voltage wiring connections to the low voltage terminal block, control boards and controllers. Check by pulling on each individual wire ensuring that all connections are secure.
- _____ Inspect all mounting hardware for tightness on all fan motors, compressors, doors, all metal skins and covers.
- _____ Inspect refrigerant piping for any signs of leaks and repair as necessary.
- _____ Inspect the humidifier (if equipped) for any signs of water leakage.
- _____ Inspect the humidifier canister for excessive debris and sediment build up. Canister must be replaced at least once a year. If Canister fills more than $\frac{3}{4}$ full of water before producing steam and/or is impossible to see into, then replace the canister.
- _____ Make sure all seams are caulked and sealed tight on the exterior portion of the A/C unit.
- _____ Inspect condenser mounting hardware, Isolators, fan blades, motor brackets and fan guards.
- _____ Inspect refrigerant pipe insulation and repair as necessary.
- _____ Inspect all isolators: make sure they are not twisted, or deteriorated.
- _____ Clean both A/C coils with coil wash solution as necessary.

_____ Inspect both A/C coils for damaged or bent fins and repair as necessary.

_____ Replace the air filters in the A/C unit. Use only high grade pleated filters.

_____ Check all sensors for accurate readings, including the pressure sensors. Calibrate sensors as needed.

_____ Check for any alarms and troubleshoot as needed.

Company: _____

Print Name: _____

Signature: _____

Date: _____

PCO3 SENSOR CALIBRATION INSTRUCTIONS

- 1-Press PRG key until you see the menu list
- 2-Arrow down to “factory menu”
- 3-Press enter 2 times (left pointing arrow key)
- 4-Arrow down and set password 9230
- 5-Press enter
- 6-Arrow down to “I/O setup”
- 7- Press enter
- 8-Arrow down to the sensor screen that needs calibrating (ex. Temperature)
- 9-Press enter to move cursor to the cal offset setting(calibration offset)
- 10-Arrow up or down to set cal. offset +/- degrees as needed
- 11-Press enter
- 12-The actual temperature reading is on the bottom of the screen.
- 13- Press esc twice to get back to main temperature screens

RIGGING INSTRUCTIONS

**To prevent possible damage to the system
Please use the Factory supplied lifting jig or qualified
personnel to field install.
Contact factory for further instructions.
585-594-5050**

Attention Service Personnel **Please Read!**

Report all service calls to factory +1-585-594-5050
24 Hour Emergency Technical Support +888-723-9230

Before working on this system you should be familiar with the products in this system. It is imperative that you understand the charging procedure for head pressure control valves for proper winter and summer operation. Only use exact replacement O.E.M. parts. The electrical control system has special characteristics and factory support should be utilized. Failure to call will void warranty and might delay repairs.