


Service Manual

Sec. 1	Service Information
Sec. 2	Disassembly Procedures
Sec. 3	Electrical Adjustment
Sec. 4	Block Diagrams
Sec. 5	Schematic Diagrams
Sec. 6	Printed Circuit Board
Sec. 7	Exploded Views & Replacement Parts List

Memory Card Camera-Recorder

Model No. **AG-HPX370P**
AG-HPX371E
AG-HPX372EN
AG-HPX373MC
AG-HPX374ER

P2HD



Regarding the service for FUJINON LENS which is packed with AG-HPX370 series, please advise the customer to consult with local FUJINON sales agent or FUJINON service department.



AVC INTRA

DVC PRO HD

DVC PRO 50

DVC PRO

Panasonic®

© Panasonic Corporation 2010.
Unauthorized copying and distribution is a violation of law.


WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

Specifications

General

Power supply:	DC 12 V (11 V to 17 V)
Power consumption:	19 W (with the supplied lens, 3.2 LCD monitor)



Indicates safety information.

Ambient operating temperature/humidity:	0 °C to 40 °C (32 °F to 104 °F) / 10 % to 85 % (relative humidity)
Storage temperature:	-20 °C to 60 °C (-4 °F to 140 °F)
Weight:	Approx. 3.6 kg (7.93 lb) (camera unit only) Approx. 5.0 kg (11.02 lb) (Including lens and lens hood)
Dimensions:	
(Camera only)	246 mm (width) × 251 mm (height) × 441 mm (depth) (excluding protrusions) 9-11/16 inches (width) × 9-7/8 inches (height) × 17-3/8 inches (depth) (excluding protrusions)
(With supplied lens)	246 mm (width) × 251 mm (height) × 549 mm (depth) (excluding protrusions) 9-11/16 inches (width) × 9-7/8 inches (height) × 21-5/8 inches (depth) (excluding protrusions)

Camera Unit

Pickup devices:	1/3-inch progressive, 2.2-megapixel, 3MOS sensor
Lens mount:	1/3-inch bayonet type
Color separation optical system:	Prism system
ND filter:	4 positions (CLEAR, 1/4ND, 1/16ND, 1/64ND)
Gain settings:	-3/0/+3/+6/+9/+12/+24 dB
Shutter speed:	• 60i/60p mode: 1/60 (OFF), 1/100, 1/120, 1/250, 1/500, 1/1000, 1/2000 sec. • 30p mode: 1/30 (OFF), 1/60, 1/100, 1/120, 1/250, 1/500, 1/1000, 1/2000 sec. • 24p mode: 1/24 (OFF), 1/60, 1/100, 1/120, 1/250, 1/500, 1/1000, 1/2000 sec. • 50i/50p mode: 1/50 (OFF), 1/60, 1/120, 1/250, 1/500, 1/1000, 1/2000 sec. • 25p mode: 1/25 (OFF), 1/50, 1/60, 1/120, 1/250, 1/500, 1/1000, 1/2000 sec.
Shutter speed (Synchro scan):	• 60i/60p mode: 1/60.0 to 1/249.8 • 30p mode: 1/30.0 to 1/249.8 • 24p mode: 1/24.0 to 1/249.8 • 50i/50p mode: 1/50.0 to 1/250.0 • 25p mode: 1/25.0 to 1/250.0
Shutter speed (slow):	• 60i/60p mode: 1/15, 1/30 • 30p mode: 1/7.5, 1/15 • 24p mode: 1/6, 1/12 • 50i/50p mode: 1/12.5, 1/25 • 25p mode: 1/6.25, 1/12.5
Shutter opening angle:	3 degrees to 359.5 degrees in 0.5-degree increments
Frame rates:	• 59.94 Hz mode: variable 12/15/18/20/21/22/24/25/26/27/28/30/32/34/36/40/44/48/54/60 fps (frames per second) • 50 Hz mode: variable 12/15/18/20/21/22/23/24/25/26/27/28/30/32/34/37/42/45/48/50 fps (frames per second)
Sensitivity:	• F10 (2000 lx, 3200 K, 89.9 % reflectance, 1080/59.94i) • F11 (2000 lx, 3200 K, 89.9 % reflectance, 1080/50i)
Minimum illumination:	0.4 lx (F1.6, Gain +24 dB, shutter speed 1/30 sec.)
Horizontal resolution:	1000 TV lines or more (center)

Memory card recorder Unit

Recording media:	P2 card
Recording Formats:	AVC-Intra 100/AVC-Intra 50/DVCPRO HD/DVCPRO50/DVCPRO/DV formats switchable
Recording/Playback Time:	AVC-Intra 100/DVCPRO HD: 8 GB × 1 approx. 8 min 16 GB × 1 approx. 16 min 32 GB × 1 approx. 32 min 64 GB × 1 approx. 64 min AVC-Intra 50/DVCPRO50: 8 GB × 1 approx. 16 min 16 GB × 1 approx. 32 min 32 GB × 1 approx. 64 min 64 GB × 1 approx. 128 min DVCPRO/DV: 8 GB × 1 approx. 32 min 16 GB × 1 approx. 64 min 32 GB × 1 approx. 128 min 64 GB × 1 approx. 256 min The times listed above can be continuously recorded as one clip. The number of recording clips will reduce the above figures somewhat.
Recorded video signals:	59.94 Hz mode (1080-59.94i, 720-59.94P, 480-59.94i) 1080/59.94i, 1080/29.97p, 1080/29.97pN, 1080/23.98p, 1080/23.98pA, 1080/23.98pN, 720/59.94p, 720/29.97p, 720/29.97pN, 720/23.98p, 720/23.98pN, 480/59.94i, 480/29.97p, 480/23.98p, 480/23.98pA 50 Hz mode (1080-50i, 720-50P, 576-50i) 1080/50i, 1080/25p, 1080/25pN, 720/50p, 720/25p, 720/25pN, 576/50i, 576/25p

Digital video Unit

Sampling Frequency:	AVC-Intra 100/DVCPRO HD: Y: 74.1758 MHz, P _B /P _R : 37.0879 MHz (59.94 Hz) Y: 74.2500 MHz, P _B /P _R : 37.1250 MHz (50 Hz) DVCPRO50: Y: 13.5 MHz, P _B /P _R : 6.75 MHz DVCPRO: Y: 13.5 MHz, P _B /P _R : 3.375 MHz
Quantizing:	AVC-Intra 100/AVC-Intra 50: 10 bits DVCPRO HD/DVCPRO50/DVCPRO/DV: 8 bits
Video Compression Format:	AVC-Intra 100/AVC-Intra 50: MPEG-4 AVC/H.264 Intra Profile DVCPRO HD: DV-Based Compression (SMPTE 370M) DVCPRO50/DVCPRO: DV-Based Compression (SMPTE 314M) DV: DV Compression (IEC 61834-2)

Digital audio Unit

Audio Recording Signal:	AVC-Intra 100/AVC-Intra 50/DVCPRO HD: 48 kHz/16 bits, 4CH DVCPRO50: 48 kHz/16 bits, 4CH DVCPRO/DV: 48 kHz/16 bits, 2CH/4CH switchable
Head room:	20 dB/18 dB Menu selectable

Video Input/Output Unit

GEN LOCK IN:	BNC × 1, 1.0 V [P-P], 75 Ω
VIDEO OUT:	BNC × 1, 1.0 V [P-P], 75 Ω
SDI OUT:	• BNC × 2, 0.8 V [P-P], 75 Ω • HD/SD switching via menu

Audio Input/Output Unit

MIC IN:	• XLR, 3-pin • + 48 V (available) • available menu selections: -40 dBu/-50 dBu/-60 dBu
AUDIO IN:	• XLR × 2, 3-pin (CH1, CH2) • LINE/MIC / + 48 V (selectable) • LINE: 0 dBu • MIC: available menu selections: -50 dBu/-60 dBu
WIRELESS:	25-pin, D-SUB, -40 dBu
AUDIO OUT:	Pin jack × 2 (CH 1, CH 2), Output: 316 mV, 600 Ω
Earphone:	ø3.5 mm stereo mini jack × 1
Internal speaker:	28 mm diameter × 1

Other Input/Output Unit

TC IN:	BNC × 1, 0.5 V [P-P] to 8 V [P-P], 10 kΩ
TC OUT:	BNC × 1, low impedance, 2.0 V ± 0.5 V [P-P]
IEEE 1394:	6 pins, digital input/output (compliant with IEEE 1394)
DC IN:	XLR × 1, 4 pins, DC 12 V (11.0 V to 17.0 V)
DC OUT:	4 pins, DC 12 V (11.0 V to 17.0 V), Maximum rated current: 1.5 A
REMOTE:	10 pins
LENS:	12 pins
USB2.0 (DEVICE):	Type-B, 4 pin USB (compliant with USB ver. 2.0)
USB2.0 (HOST):	Type-A, 4 pin USB (compliant with USB ver. 2.0)

LCD Monitor Unit

LCD monitor:	3.2 inch color LCD monitor with approx. 921,000 dots (16:9)
--------------	---

Viewfinder Unit

LCD monitor:	0.45 inch color LCD monitor with approx. 1,226,000 dots (16:9)
--------------	--

SAFETY PRECAUTIONS

GENERAL GUIDELINES

1. When servicing, observe the original lead dress. If a short circuit is found, replace all parts, which have been over-heated or damaged by the short circuit.
2. After servicing, see to it that all the protective devices such as insulation barriers, insulation papers shields are properly installed.
3. After servicing, make the following leakage current checks to prevent the customer from being exposed to shock hazards.

LEAKAGE CURRENT COLD CHECK

1. Unplug the AC cord and connect a jumper between the two prongs on the plug.
2. Measure the resistance value, with an ohm meter, between the jumpered AC plug and each exposed metallic cabinet part on the equipment such as screwheads, connectors, control shafts, etc. The resistance value must be more than 5M Ω .




Figure1

LEAKAGE CURRENT HOT CHECK (See Figure 1)

1. Plug the AC cord directly into the AC outlet. Do not use an isolation transformer for this check.
2. Connect a 1.5K Ω , 10W resistor, in parallel with a 0.15 μ F capacitor, between each exposed metallic part on the set and a good earth ground such as a water pipe, as shown in Figure1.
3. Use an AC voltmeter, with 1000 ohms/volt or more sensitivity, to measure the potential across the resistor.
4. Check each exposed metallic part, and measure the voltage at each point.
5. Reverse the AC plug in the AC outlet repeat each of the above measurements.
6. The potential at any point should not exceed 0.15 volts RMS. A leakage current tester (Simpson Model 229 equivalent) may be used to make the hot checks, leakage current must not exceed 0.1 milliamp. In case a measurement is outside of the limits specified, there is a possibility of a shock hazard, and the equipment should be repaired and rechecked before it is returned to the customer.

ABOUT LEAD FREE SOLDER (PbF)

Distinction of PbF PCB:

PCBs (manufactured) using lead free solder will have a PbF stamp on the PCB.

Caution:

1. Pb free solder has a higher melting point than standard solder; Typically the melting point is 50–70°F (30–40°C) higher. Please use a high temperature soldering iron. In case of the soldering iron with temperature control, please set it to 700 $\pm$ 20°F (370 $\pm$ 10°C).
2. Pb free solder will tend to splash when heated too high (about 1100°F/600°C).

ELECTROSTATICALLY SENSITIVE (ES) DEVICES

Some semiconductor (solid state) devices can be damaged easily by static electricity. Such components commonly are called Electrostatically sensitive (ED) Devices. Examples of typical ES devices are integrated circuits and some field-effect transistors and semiconductor "chip" components. The following techniques should be used to help reduce the incidence of component damage caused by static electricity.

1. Immediately before handling any semiconductor component or semiconductor-equipped assembly, drain off any electrostatic charge on your body by touching a known earth ground.
Alternatively, obtain and wear a commercially available discharging wrist trap device, which should be removed for potential shock reasons prior to applying power to the unit under test.
2. After removing an electrical assembly equipped with ES devices, place the assembly on a conductive surface such as aluminum foil, to prevent electrostatic charge buildup or exposure of the assembly.
3. Use only a grounded tip soldering iron to solder or unsolder ES devices.
4. Use only an anti-static solder removal device classified as "anti-static" can generate electrical charges sufficient to damage ES devices.
5. Do not use freon-propelled chemicals. These can generate electrical charges sufficient to damage ES devices.
6. Do not remove a replacement ES device from its protective package until immediately before you are ready to install it.
(most replacement ES devices are package with leads electrically shorted together by conductive foam, aluminum foil or comparable conductive material).
7. Immediately before removing the protective material from the leads of a replacement ES device, touch the protective material to the chassis or circuit assembly into which the device will be installed.
CAUTION: Be sure no power is applied to the chassis or circuit, and observe all other safety precautions.
8. Minimize bodily motions when handling unpackaged replacement ES devices. (Otherwise harmless motion such as the brushing together of your clothes fabric or the lifting of your foot from a carpeted floor can generate static electricity sufficient to damage an ES device).

X-RADIATION


WARNING

1. The potential source of X-radiation in EVF sets is the High Voltage section and the picture tube.
2. When using a picture tube test jig for service, ensure that jig is capable of handling 10kV without causing X-Radiation.

Note: It is important to use an accurate periodically calibrated high voltage meter.

3. Measure the High Voltage. The meter (electric type) reading should indicate 2.5kV, $\pm$ 0.15kV. If the meter indication is out of tolerance, immediate service and correction is required to prevent the possibility of premature component failure. To prevent an X-Radiation possibility, it is essential to use the specified picture tube.

Read this first!



indicates safety information.



CAUTION RISK OF ELECTRIC SHOCK DO NOT OPEN



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK,
DO NOT REMOVE COVER (OR BACK).
NO USER-SERVICEABLE PARTS INSIDE.
REFER TO SERVICING TO QUALIFIED SERVICE PERSONNEL.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING:

- To reduce the risk of fire or electric shock, do not expose this equipment to rain or moisture.
- To reduce the risk of fire or electric shock, keep this equipment away from all liquids. Use and store only in locations which are not exposed to the risk of dripping or splashing liquids, and do not place any liquid containers on top of the equipment.

WARNING:

Always keep memory cards (optional accessory) or accessories (FRONT AUDIO LEVEL knob, knob screw, BNC cap, XLR connector cap, rear lens cap, zoom lever, connector cap) out of the reach of babies and small children.

CAUTION:

To reduce the risk of fire or electric shock and annoying interference, use the recommended accessories only.

CAUTION:

Do not jar, swing, or shake the unit by its handle while the conversion lens or another accessory is attached.

Due to the added weight of the conversion lens, any strong jolt to the handle may damage the unit or result in personal injury.

CAUTION:

In order to maintain adequate ventilation, do not install or place this unit in a bookcase, built-in cabinet or any other confined space. To prevent risk of electric shock or fire hazard due to overheating, ensure that curtains and any other materials do not obstruct the ventilation.

CAUTION:

Do not lift the unit by its handle while the tripod is attached. When the tripod is attached, its weight will also affect the unit's handle, possibly causing the handle to break and hurting the user. To carry the unit while the tripod is attached, take hold of the tripod.

CAUTION:

Excessive sound pressure from earphones and headphones can cause hearing loss.

CAUTION:

Do not leave the unit in direct contact with the skin for long periods of time when in use. Low temperature burn injuries may be suffered if the high temperature parts of this unit are in direct contact with the skin for long periods of time. When using the equipment for long periods of time, make use of the tripod.


CAUTION:

- Danger of explosion or fire if battery is mistreated.
- Replace only with same or specified type.
- Do not disassemble or dispose of in fire.
- Do not store in temperatures over 60°C (140°F).
- Do not leave the battery in an automobile exposed to direct sunlight for a long period of time with doors and windows closed.
- Use specified charger.

Caution regarding laser beams

The MOS sensor may be damaged if it is exposed to laser light.

When using the camera-recorder in locations where laser irradiation equipment is used, be careful not to allow the laser beam to shine directly on the lens.



indicates safety information.

FCC NOTICE (USA)

Declaration of Conformity

Model Number: AG-HPX370P
Trade Name: Panasonic
Responsible Party: Panasonic Corporation of North America
One Panasonic Way, Secaucus, NJ 07094
Support contact: 1-800-524-1448

This device complies with Part 15 of FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

To assure continued compliance, follow the attached installation instructions and do not make any unauthorized modifications.

CAUTION:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The user may find the booklet "Something About Interference" available from FCC local regional offices helpful.

FCC Warning:

To assure continued FCC emission limit compliance, follow the attached installation instructions and the user must use only shielded interface cables when connecting to host computer or peripheral devices. Also, any unauthorized changes or modifications to this equipment could void the user's authority to operate this device.

NOTIFICATION (Canada)

This class B digital apparatus complies with Canadian ICES-003.

IMPORTANT

"Unauthorized recording of copyrighted television programs, video tapes and other materials may infringe the right of copyright owners and be contrary to copyright laws."


For USA-California Only

This product contains a CR Coin Cell Lithium Battery which contains Perchlorate Material – special handling may apply.

See www.dtsc.ca.gov/hazardouswaste/perchlorate.

A rechargeable battery that is recyclable powers the product you have purchased.

Read this first!



indicates safety information.

WARNING:

- To reduce the risk of fire or electric shock, do not expose this equipment to rain or moisture.
- To reduce the risk of fire or electric shock, keep this equipment away from all liquids. Use and store only in locations which are not exposed to the risk of dripping or splashing liquids, and do not place any liquid containers on top of the equipment.

WARNING:

Always keep memory cards (optional accessory) or accessories (FRONT AUDIO LEVEL knob, knob screw, BNC cap, XLR connector cap, rear lens cap, zoom lever, connector cap) out of the reach of babies and small children.

CAUTION:

Do not remove panel covers by unscrewing them.
To reduce the risk of electric shock, do not remove cover. No user serviceable parts inside. Refer servicing to qualified service personnel.

CAUTION:

To reduce the risk of fire or electric shock and annoying interference, use the recommended accessories only.

CAUTION:

Do not jar, swing, or shake the unit by its handle while the conversion lens or another accessory is attached. Due to the added weight of the conversion lens, any strong jolt to the handle may damage the unit or result in personal injury.

CAUTION:

In order to maintain adequate ventilation, do not install or place this unit in a bookcase, built-in cabinet or any other confined space. To prevent risk of electric shock or fire hazard due to overheating, ensure that curtains and any other materials do not obstruct the ventilation.

CAUTION:

Do not lift the unit by its handle while the tripod is attached. When the tripod is attached, its weight will also affect the unit's handle, possibly causing the handle to break and hurting the user. To carry the unit while the tripod is attached, take hold of the tripod.

CAUTION:

Excessive sound pressure from earphones and headphones can cause hearing loss.

CAUTION:

Do not leave the unit in direct contact with the skin for long periods of time when in use. Low temperature burn injuries may be suffered if the high temperature parts of this unit are in direct contact with the skin for long periods of time.
When using the equipment for long periods of time, make use of the tripod.

CAUTION:

- Danger of explosion or fire if battery is mistreated.
- Replace only with same or specified type.
- Do not disassemble or dispose of in fire.
- Do not store in temperatures over 60°C (140°F).
- Do not leave the battery in an automobile exposed to direct sunlight for a long period of time with doors and windows closed.
- Use specified charger.

IMPORTANT

"Unauthorized recording of copyrighted television programs, video tapes and other materials may infringe the right of copyright owners and be contrary to copyright laws."

EEE Yönetmeliğine Uygundur.

EEE Complies with Directive of Turkey.

EMC NOTICE FOR THE PURCHASER/USER OF THE APPARATUS

1. Applicable standards and operating environment

The apparatus is compliant with:

- standards EN55103-1 and EN55103-2 1996.11, and
- electromagnetic environments E1, E2, E3 and E4.

2. Pre-requisite conditions to achieving compliance with the above standards

<1> Peripheral equipment to be connected to the apparatus and special connecting cables

- The purchaser/user is urged to use only equipment which has been recommended by us as peripheral equipment to be connected to the apparatus.
- The purchaser/user is urged to use only the connecting cables described below.

<2> For the connecting cables, use shielded cables which suit the intended purpose of the apparatus.

- Video signal connecting cables
Use double shielded coaxial cables, which are designed for 75-ohm type high-frequency applications, for SDI (Serial Digital Interface).
Coaxial cables, which are designed for 75-ohm type high-frequency applications, are recommended for analog video signals.
- Audio signal connecting cables
If your apparatus supports AES/EBU serial digital audio signals, use cables designed for AES/EBU.
Use shielded cables, which provide quality performance for high-frequency transmission applications, for analog audio signals.
- Other connecting cables (IEEE1394, USB)
Use shielded cables, which provide quality performance for high-frequency applications, as connecting cables.
- When connecting to the DVI signal terminal, use a cable with a ferrite core.
- If your apparatus is supplied with ferrite core(s), they must be attached on cable(s) following instructions in this manual.

3. Performance level

The performance level of the apparatus is equivalent to or better than the performance level required by these standards.

However, the apparatus may be adversely affected by interference if it is being used in an EMC environment, such as an area where strong electromagnetic fields are generated (by the presence of signal transmission towers, cellular phones, etc.). In order to minimize the adverse effects of the interference on the apparatus in cases like this, it is recommended that the following steps be taken with the apparatus being affected and with its operating environment:

1. Place the apparatus at a distance from the source of the interference.
2. Change the direction of the apparatus.
3. Change the connection method used for the apparatus.



TO REMOVE BATTERY

Main Power Battery (Ni-Cd / Ni-MH / Li-ion Battery)

- To detach the battery, please proceed in the reverse order of the installation method described in this manual.
- If a battery made by any other manufacturer is to be used, check the Operating Instructions accompanying the battery.

Back-up Battery (Lithium Battery)

- For the removal of the battery for disposal at the end of its service life, please consult your dealer.

Panasonic®

SECTION 1

SERVICE INFORMATION

Model No. : AG-HPX370P, AG-HPX371E, AG-HPX372EN
AG-HPX373MC, AG-HPX374ER








CONTENTS

1. Servicing Fixtures & Tools.....	INF-1
2. Lithium battery.....	INF-2
3. Service menu.....	INF-3
3-1. DIAG(SERVICE) menu.....	INF-4
3-1-1. 1394 DIAG display	INF-4
3-2. ADJUST menu.....	INF-5
3-2-1. VIDEO OUT LVL	INF-5
3-2-2. DEFECT COMP	INF-5
3-2-3. LCD Chromaticity Correction.....	INF-6
3-3. DEFECT(EDIT) menu.....	INF-7
3-4. DEFECT(NEW) menu.....	INF-7
4. Service menu (GUI).....	INF-8
4-1. Making of Service SD memory card	INF-8
4-2. How to open the menu.....	INF-8
4-3. VERSION.....	INF-9
4-4. SYSTEM INFO.....	INF-9
4-5. DATA INIT.....	INF-10
4-6. EXTERNAL.....	INF-10
4-7. LOG.....	INF-11
4-8. MACHINE CHECKSUM.....	INF-12
4-9. IMAGE CHECKSUM.....	INF-13
5. Firmware update procedure	INF-14
5-1. MICROCOMPUTER / FPGA CHART	INF-14
5-2. Software Version Display.....	INF-14
5-3. Update with the SD memory card	INF-16
5-3-1. Preparation.....	INF-16
5-3-2. Updated procedure.....	INF-16
6. PC EVR software	INF-20
6-1. Required tools and equipment for PC EVR software	INF-20
6-2. Connection.....	INF-20
6-3. Setup of PC EVR software	INF-23
6-3-1. Detection of not initialized Digital Main P.C.Board.....	INF-24
6-3-2. Setting of Digital Main P.C.Board for T (Japan) model	INF-24
6-4. Setting Tool screen (SYSCON(S) section).....	INF-26
6-4-1. Setting and confirmation of Date and Time of internal clock.....	INF-27
6-4-2. Display operation of a Service menu and the DIAGNOSTIC menu.....	INF-28
6-4-3. Software Version Display	INF-28
6-4-4. 1394 UID display	INF-28
6-4-5. LCD Chromaticity Correction.....	INF-29
6-5. Service Information screen (SYSCON(S) section)	INF-29
6-5-1. Display the Operation time (power-on time for the camera recorder).....	INF-30
6-5-2. Display the Operation time (power-on time for backlight of the LCD) and setting	INF-30
6-5-3. Setting of destination.....	INF-31
6-5-4. Power Supply Reboot.....	INF-31

6-6. Write UID/Read Serial screen (SYSCON(S) section).....	INF-32
6-6-1. UID display	INF-32
6-6-2. UID writing and automatic generation	INF-32
6-6-3. Serial No. display.....	INF-32
6-6-4. Power Supply Reboot.....	INF-32
6-7. Adjustment Tool screen (CAM(C) section)	INF-33
6-8. FPN Compensation screen (CAM(C) section)	INF-34
7. Save and write EEPROM data	INF-35
7-1. Save data of EEPROM data of Camera-Recorder to PC	INF-35
7-1-1. Save data of Camera EEPROM.....	INF-35
7-1-2. Save data of SYS EEPROM.....	INF-37
7-2. Write EEPROM data from PC to Camera-Recorder	INF-38
7-2-1. Write data of Camera EEPROM.....	INF-38
7-2-2. Write data of SYS EEPROM	INF-40
8. UID Writing Procedure.....	INF-41
9. Rewriting setting of data according to destination.....	INF-42
10. White Blemish Compensation	INF-44
10-1. Blemish Compensation flow.....	INF-44
10-2. Blemish compensation screen mode by camera setting	INF-45
10-3. Connection	INF-46
10-4. Blemish confirmation.....	INF-46
10-5. Manual compensation procedure.....	INF-47
10-6. Remarks.....	INF-48
10-6-1. OFF setting of blemish compensate operation.....	INF-48
10-6-2. Execution of auto detection and compensation for black blemish	INF-48
10-6-3. Delete all cursor position data (Blemish data) (For only a current mode).....	INF-48
10-6-4. Delete all cursor position data (Blemish data) (For all mode)	INF-48
10-6-5. Delete registered data one by one	INF-48
10-6-6. Change Parameter about blemish compensation	INF-49
10-6-7. Setting of CAC MAX RANGE mode	INF-49
10-6-8. About the position inhibited to register the compensation data.....	INF-49
11. Operation after major part exchanged.....	INF-50
11-1. Operation List.....	INF-50
11-2. Operation flow chart after replacement of major parts.....	INF-51
11-2-1. DIGITAL MAIN P.C.Board	INF-51
11-2-2. LCD Unit	INF-53
11-2-3. Camera Unit.....	INF-54
11-2-4. Optical Unit	INF-54
11-2-5. RSIDE2 P.C.Board	INF-54
11-3. Adjustment after replacement of major parts	INF-55
11-3-1. Electrical Adjustment	INF-55
12. Interconnection	INF-56
13. P.C.Board Location.....	INF-57


1. Servicing Fixtures & Tools

No	Part No.	Fixture & Tool Name	Remarks	Purpose
1	VFK1988	Measuring Board	For EVR Software	Electrical Adj. etc.
2	VFK1989	Extension Cable	For EVR Software	Electrical Adj. etc.
3	VFK1982	Extension Cable	For EVR Software	Electrical Adj. etc.
4	-----	RS232C cross cable (9P)	For EVR Software	Electrical Adj. etc.
5	K2GJ2DC00002	DC Cable	For Measuring Board. It is equal to VJA1128	Electrical Adj. etc.
6	-----	AC Adapter	For Measuring Board	Electrical Adj. etc.
7	VVS0083	PC EVR Software	Download from Global Service WEB Site	UID writing etc.
8	VVS0021	Service SD Card Software	Download from Global Service WEB Site	GUI display
9	VFK0645	Grayscale Chart	Reflection type	Electrical Adj.
10	-----	White Chart		Electrical Adj.


1 VFK1988 Measuring Board 	2 VFK1989 Extension Cable 	3 VFK1982 Extension Cable 	4 RS-232C Cross Cable (9P) 
5 K2GJ2DC00002 DC Cable 	6 ----- AC Adapter 	7 VVS0083 PC EVR Software 	8 VVS0021 Service SD Card Software 
9 VFK0645 Grayscale Chart 	10 ----- White Chart 		

2. Lithium battery

1. Remove the Side Case R S Unit. There is a Lithium battery on the RSIDE2 P.C.Board. (The removal procedure has been described to the item “3. Removal of Side Case R S Unit” of disassembly procedure (SECTION 2)).



2. Unsolder the each soldering point of electric lead terminal for Lithium battery (Ref No: B2101 at foil side of RSIDE2 P.C.B.) and remove the Lithium battery together with electric lead terminal.
3. Install the new battery.



4. Set the date and time of internal clock (Refer to item “Setting Date and Time of Internal Clock” of operation instructions for the setting method).

NOTE: A setup date and time of internal clock can be set also on PC EVR software (refer to item “6-4-1. Setting and confirmation of the Date and Time of Internal Clock”).

NOTE:

The lithium battery is a critical component.

It must never be subjected to excessive heat or discharge.

It must therefore only be fitted in equipment designed specifically for its use.

Replacement batteries must be of the same type and manufacture.

They must be fitted in the same manner and location as the original battery, with the correct polarity contacts observed.

Do not attempt to re-charge the old battery or re-use it for any other purpose.

It should be disposed of in waste products destined for burial rather than incineration.

CAUTION: DANGER OF EXPLOSION IF BATTERY IS INCORRECTLY REPLACED.
REPLACE ONLY WITH THE SAME OR EQUIVALENT TYPE.

3. Service menu

This model has DIAG(SERVICE), ADJUST, DEFECT(EDIT) and DEFECT(NEW) menu as service menu besides the setup menu.

NOTE: (Only the MC model)



The menu screen described in this item “3. Service menu” is an English display. When “CHINESE” is selected by item “LANGUAGE” of the OTHER FUNCTION screen (Setting menu), there is a portion used as a Chinese display (The factory shipments mode is “CHINESE”). Therefore, the procedure indicated in this item is also following the English display.

NOTE: Service menu can be displayed by PC EVR software except below indicated method. Please refer to item “6-4-2. Display operation of a Service menu and the DIAGNOSTIC menu” (page INF-28).

< How to open the SERVICE menu >

1. Push the button in order of “RESET” button → “STOP” button → “DISP/MODE CHK” button → “MENU” button, and then DIAG(SERVICE), ADJUST, DEFECT(EDIT) and DEFECT(NEW) menu can be displayed in addition to a setup menus.
2. After the DIAG(SERVICE), ADJUST, DEFECT(EDIT) and DEFECT(NEW) menu are displayed, use the JOG dial button to select the menu. And press the JOG dial button to open the selected menu.


NOTE: Thumbnail display screen mode can not be display the menu. When the thumbnail menu is displayed, press the THUMBNAIL button to display off.



3-1. DIAG(SERVICE) menu


3-1-1. 1394 DIAG display

Use the **JOG dial** button to select the “**1394 DIAG**”. And press the **JOG dial** button.



Items	Description	Remark
NODE CNT	Number of NODE connections.	
MY_ID	NODE ID of this unit.	
ROOT_ID	ROOT ID	
IRM_ID	PHY ID of IRM	IRM(Isochronous Resonance Manager)
RCV_ID	PHY ID of the equipment which is transmitting the data to be receiving of this unit.	
GAP CNT	Current gap count value	

The 1394 UID number is displayed in this 1394 DIAG screen. The displayed numbers of 16 figures is “UID”.
ex.) 00804582-38837003 (First 8 figures are fixed numbers and last 8 figures are unique numbers).



NOTE: The UID information can be confirmed also with the **Setting Tool** and **Write UID/Read Serial** screen (PC EVR software). Please refer to item “**6-4-4. 1394 UID Display**” (page INF-28) and item “**6-6-1. UID display**” (page INF-32).

3-2. ADJUST menu

NOTE: Please do not change the setting of the items of “FPN COMP.”, “1394 GAP COUNT”, “BATTERY TEST”, “TEST SDI IN”, “TEST VFR”, “TEST OPERATION”, “TEST CAM SIG”, “TEST AGING ERR”, “TEST SH ERR”, “TEST MODE7”, “CAM DEBUG MODE”, “CAMERA COM”, “LOG PORT SEL” and “LOG LEVEL”. These items are for factory use only.

3-2-1.VIDEO OUT LVL


Level of VIDEO OUT signal can be adjusted on this item.

ADJUST MENU	
VIDEO OUT LVL	+32
DEFECT COMP	0
LCD OFFSET	0
FPN COMP.	>>>
1394 GAP COUNT	40
BATTERY TEST	OFF
TEST SDI IN	OFF
TEST VFR	OFF
PUSH MENU TO RETURN	

Use the **JOG dial** button to select the item. And press the **JOG dial** button to make the setting (Then setting value blinks).
Use the **JOG dial** button to change the setting value. Press the **JOG dial** button to value is fixed.

3-2-2. DEFECT COMP

This item is used for blemish compensation. Please refer to item “10. White Blemish Compensation” (page INF-44) about execution procedure of each functions.

SET VALUE	Setting contents and outline function explanation
0	Blemish Compensate operation: ON (preset value of DEFECT COMP)
1	Blemish Compensate operation: OFF
2	Confirmation mode of ODD/EVEN compensation for 1080i. Only the ODD picture signal is output.
3	Confirmation mode of ODD/EVEN compensation for 1080i. Only the EVEN picture signal is output.
4	Not used
5	Execution of auto detection and compensation for Black Blemish
6	Not used
7	CAC MAX RANGE mode (The mode for the picture on outside effective area can be seen on the screen display.). For the blemish confirmation and correction of the video signal on outside effective area used in CAC. (The setting is reset to OFF at power supply ON. Even if the menu is closed, the setting is kept.)  (Screen display)
8	Not used
9	Not used
10	Delete all blemish compensation data (*Only a current mode) *Refer to item 10-6-3.
11	Not used
12	Not used
13	Not used
14	Not used
15	Delete all blemish compensation data (*For all mode) *Refer to item 10-6-4.

3-2-3. LCD Chromaticity Correction

LCD Chromaticity can be corrected by this item.

LCD OFFSET

Use the **JOG dial** button to select the “**LCD OFFSET**”. And press the **JOG dial** button.

Use the **JOG dial** button to select the setting value.

Press the **JOG dial** button to value is fixed.

ADJUST MENU	
VIDEO OUT LVL	+32
DEFECT COMP	0
LCD OFFSET	0
FPN COMP.	1
1394 GAP COUNT	2
BATTERY TEST	3
TEST SDI IN	OFF
TEST VFR	OFF
PUSH MENU TO RETURN	

LCD Chromaticity is corrected.

0: Correction level 0

1: Correction level 1

2: Correction level 2

3: Correction level 3

3-3. DEFECT(EDIT) menu

When the registered blemish compensation data is corrected and deleted, this menu is used.

ITEM	RANGE & SET VALUE	PRESET	Setting contents and outline function explanation
DEFECT NO.	000 – 255	----	Selection of compensation No. (000 to 255).
SET	RETURN / CHANGE / DELETE	----	CHANGE: Execution of auto detection and compensation for Black Blemish etc. DELETE: Delete all blemish compensation data etc.
H CURSOR COARSE	0-8	----	Coarse adjustment for horizontal cursor position.
H CURSOR FINE	0-FF	----	Fine adjustment for horizontal cursor position.
V CURSOR COARSE	0-4 or 0-2	----	Coarse adjustment for vertical cursor position.
V CURSOR FINE	0-FF	----	Fine adjustment for vertical cursor position.
SIZE	1-3, 5, 7	----	Select the compensation size (Horizontal direction). 1: 1 pixel 2: 2 pixel 3: 3 pixel 5: 5 pixel 7: 7 pixel
COLOR	Y/R/G/B	----	Select the Compensation color. Y: R.G.B channel are compensated simultaneously. R: R channel is compensated. G: G channel is compensated. B: B channel is compensated.

3-4. DEFECT(NEW) menu

When the new blemish compensation data is registered, this menu is used.

ITEM	RANGE & SET VALUE	PRESET	Setting contents and outline function explanation
SET	ADD	----	ADD: Registration of new blemish compensation data
H CURSOR COARSE	0-8	----	Coarse adjustment for horizontal cursor position.
H CURSOR FINE	0-FF	----	Fine adjustment for horizontal cursor position.
V CURSOR COARSE	0-4 or 0-2	----	Coarse adjustment for vertical cursor position.
V CURSOR FINE	0-FF	----	Fine adjustment for vertical cursor position.
SIZE	1-3, 5, 7	----	Select the compensation size (Horizontal direction). 1: 1 pixel 2: 2 pixel 3: 3 pixel 5: 5 pixel 7: 7 pixel
COLOR	Y/R/G/B	----	Select the Compensation color. Y: R.G.B channel are compensated simultaneously. R: R channel is compensated. G: G channel is compensated. B: B channel is compensated.

4. Service menu (GUI)

NOTE: (Only the MC model)

The thumbnail menu screen described in this item “4. Service menu (GUI)” is an English display. When “CHINESE” is selected by item “LANGUAGE” of the OTHER FUNCTION screen (Setting menu), it becomes a Chinese display (The factory shipments mode is “CHINESE”). Therefore, the explanation indicated in this item is also following the English display.

4-1. Making of Service SD memory card

The Service SD memory card is required to display the service menu on GUI screen.

1. Download the file “Service SD Card (VVS0021.zip)” from Global Service Web Site.
2. Copy the file “Service SD Card (VVS0021.zip)” to hard disk of your PC and extract the file “Service SD Card (VVS0021.zip)”.
3. Insert a formatted SD memory card into the card slot of PC and copy the folder “PRIVATE” to SD memory card.

The downloaded file “passwd” is included in folder “PRIVATE”.

NOTE: Do not change the construction of folder and file name. The folder construction shown in the following and top of directory should be “PRIVATE”.


Folder: PRIVATE \ MEIGROUP \ PAVCN \ SBG \ P2SD \ MNTNC \

File Name: passwd


SD memory card used in the P2 equipment requires to be conformed to SD™ standards. Be sure to format SD memory card with P2 equipment. To format SD memory card using a personal computer, download the proper software from the download site (Support Desk).

4-2. How to open the menu

1. Turn the power on. Press the **THUMBNAİL** button to thumbnail display screen mode.
2. Insert a Service SD memory card into the SD card slots of this unit.




3. Press the **THUMBNAİL MENU** button to display the menu. Use the **CURSOR** buttons to select the “OPERATION” and press **SET** button to open the OPERATION menu.
4. Select the item “SERVICE” on the menu and press the **SET** button. The service menu is displayed.



4-3. VERSION

Each software version can be confirmed.

1. Select the item **"VERSION"** on the service menu and press the **SET** button. The following screen is displayed.
2. Press the **CURSOR (Left and Right)** button so that the version screen is switched over.




3. Press the **SET** button to exit this screen.

NOTE: The version of software can be confirmed also with the **Setting Tool** screen (PC EVR software) and **DIAGNOSTIC** menu. Please refer to item **"6-4-3. Software Version Display"** (page INF-28) and item **"5-2. Software Version Display"** (page INF-14).

4-4. SYSTEM INFO

The information of model name and serial number can be confirmed.

1. Select the item **"SYSTEM INFO"** on the service menu and press the **SET** button. The following screen is displayed.



2. Press the **SET** button to exit this screen.

NOTE: The Serial No. can be confirmed also with the **Write UID/Read Serial** screen (PC EVR software) and **DIAGNOSTIC** menu. Please refer to item **"6-6-3. Serial No. display"** (page INF-32).

4-5. DATA INIT.


The GUI menu and the meta data is initialized by executing the DATA initialization (Initialization of FLASH on DIGITAL MAIN board.).

In the following cases, please execute the DATA initialization.

- When the FLASH ROM(IP2604) on DIGITAL MAIN board is exchanged.
- When the DIGITAL MAIN board is exchanged.

NOTE: Please turn OFF and ON the power after the DATA initialization is executed.


1. Select the item “**DATA INIT**” on the service menu and press the **SET** button. The confirmation menu of the execution is displayed.



2. Select the item “**YES**” and press **SET** button.

4-6. EXTERNAL

NOTE: This menu is only use at factory. Please do not execute it.



4-7. LOG


The LOG data can be written on the SD memory card.

Please execute **"MEMORY TO SD"** and **"FILE TO SD"**, when you write the LOG data on the SD memory card.


MEMORY TO SD: The LOG data is transfer to SD card from FLASH ROM on DIGITAL MAIN board (included error log).

FILE TO SD: The LOG data is transfer to SD memory card from SH4 MICON on DIGITAL MAIN board.

1. Select the item **"LOG"** on the service menu and press the **SET** button. The following screen is displayed.



2. Select the item **"MEMORY TO SD"** or **"FILE TO SD"** on the menu and press the **SET** button. The confirmation menu of the execution is displayed.



3. Select the item **"YES"** and press **SET** button, the LOG data is written on the SD memory card.

NOTE: There is no problem even if the LOG data is written on the Service SD memory card.


LOG data is saved by following file name to **"PRIVATE \ MEIGROUP \ PAVCN \ SBG \ P2SD \ MNTNC\"** folder

_ERR.LOG** (In case of **"MEMORY to SD"**)

_ERR.LOG** (In case of **"FILE TO SD"**)

4-8. MACHINE CHECKSUM

NOTE: This menu is only use at factory. Please do not select the menu. When it selects and the SET button is pushed, menu is executed. Please turn off the power of camera recorder once when executing it by mistake.



4-9. IMAGE CHECKSUM


The checksum of the image data written on the SD memory card can be confirmed.

NOTE: It is necessary to copy **Image Data(VSI****.img)** to the Service SD memory card to execute Image Checksum. Please copy the VSI****.img file to the following folder on the Service SD memory card.


Folder: PRIVATE \ MEIGROUP \ PAVCN \ SBG \ P2SD \ FW \
File Name: VSI****.img

1. Select the item **"IMAGE CHECKSUM"** on the service menu and press the **SET** button. The calculation of checksum starts.
2. When the calculation of checksum finishes, the checksum of each software are displayed as shown in the following screens.


When the SET button is pressed,
the calculation is starts.



When the calculation of checksum
finishes, the checksum is displayed.



It switches over when press the
CURSOR (Left and Right) button.



5. Firmware update procedure

NOTE: (Only the MC model)

The thumbnail screen described in this item “5. Firmware Update procedure” is an English display. When “CHINESE” is selected by item “LANGUAGE” of the OTHER FUNCTION screen (Setting menu), it becomes a Chinese display (The factory setting mode is “CHINESE”). Moreover, the screen shown on page INF-18 and 19 that screen are only an English display.


5-1. MICROCOMPUTER / FPGA CHART

Board	Name	Ref No.	IC type	Manufacture	Remark
DIGITAL MAIN	CAM SOFT	IP601	FLASH	SPANSION	
	SYSCON SOFT	IP1601, 1602	FLASH	SPANSION	
	P2CS BL2-1	IP2604	FLASH	SPANSION	
	P2CS BL2-2				
	P2CS KR				
	P2CS AP				
	VUP				
	VUP FS				
	DM FPGA				FPGA IC (IC800)

5-2. Software Version Display

The version number of software is displayed in DIAGNOSTIC menu screen of setting menu.

1. Turn the power on.
2. Press **MENU** button to display the setting menu.
3. Use **JOG dial** button to select the DIAGNOSTIC menu and press **JOG dial** button to open the DIAGNOSTIC menu.



4. The version number is displayed under item VERSION.

DIAGNOSTIC

VERSION	▶ >>>>
12.05-00-0.00	
MODEL NAME	AG-HPX370P
SERIAL NO.	B5TA00001
OPERATION	00056h

PUSH MENU TO RETURN

Version number →

5. Press **JOG dial** button.
6. Select **"DISPLAY"** and press **JOG dial** button to display the version of each software shown in item 5-1.

DIAGNOSTIC

VERSION	9.03-00-0.00	RETURN
		DISPLAY
MODEL NAME	AG-HPX370P	
SERIAL NO.	B5TA00001	
OPERATION	00056h	

PUSH MENU TO RETURN

Select **"DISPLAY"** and press **JOG dial** button to move the SOFT VERSION display screen.

↓

VERSION	
CAM SOFT	: 1.00-00-0.00
SYS CON SOFT	: 1.00-00-0.00
P2CS BL2-1	: 1.00-00-0.00
P2CS BLK-2	: 1.00-00-0.00
P2CS KR	: 1.00-00-0.00
P2CS AP	: 1.00-00-0.00
VUP	: 1.00-00-0.00
VUP FS	: 1.00-00-0.00

PUSH MENU TO RETURN

↔

VERSION	
CAM1 FPGA	: 1.00-00-0.00
CAM2 FPGA	: 1.01-00-0.00
CAM3 FPGA	: 1.01-00-0.00
DM FPGA	: 1.00-00-0.00

PUSH MENU TO RETURN

5-3. Update with the SD memory card

CAUTION: Before Updating Software

- Do not power down or pull card while upgrading. If the program quits during loading, the data will be erased or part writing condition and the restart is not made. However software can not be update, please contact Panasonic Service Engineering.

5-3-1. Preparation

< Preparation for SD memory card >

1. SD memory card (more than 64MB memory card) is required.
2. Insert an SD memory card into the P2 equipment and format it.

NOTE: SD memory card used in the P2 equipment requires to be conformed to SD™ standards. Be sure to format SD memory card with P2 equipment. To format SD memory card using a personal computer, download the proper software from the download site (Support Desk).

< Copy of Image data for update >

1. Download Image Data “VSI*****.zip” for the update from “Support Desk” web site.
2. Copy the file “VSI*****.zip” to hard disk of your PC and extract the file.
3. Insert a formatted SD memory card into the card slot of PC.
4. Copy the folder “PRIVATE” to SD memory card. The downloaded image data (upgrade file: VSI*****.img) is included in folder “PRIVATE”.

NOTE: Do not change the construction of folder and file name. The folder construction shown in the following and top of directory should be “PRIVATE”.


Folder: PRIVATE \ MEIGROUP \ PAVCN \ SBG \ P2SD \ FW \
File Name: VSI*****.img

< External Power >


It is best to power the unit from the external power supply. This will prevent the unit from shutting off during updating.

5-3-2. Updated procedure


1. Turn the power on. Press the **THUMBNAIL** button to thumbnail display screen mode.
2. Insert a formatted SD memory card into the SD card slots of this unit.
3. Press the **THUMBNAIL MENU** button to display the menu on thumbnail screen.



4. Use the **CURSOR** button to select the item **"OPERATION"** and press **SET** button to open the OPERATION menu.
5. Select the item **"UPDATE"** on the menu and press the **SET** button (If the update SD memory card does not insert into the unit, item **"UPDATE"** does not appeared.). The confirmation menu of the execution is displayed. If update is executed, select the item **"YES"** and press **SET** button. In this time, **BUSY lamp(SD Access LED)** is turned off.





6. Update program is started and the message **"PREPARING FOR UPDATE"** appears on screen. In this timing, it is doing preparation such as the confirmation of the data of the updating. In this time, **BUSY lamp(SD Access LED)** is turned off.



7. When shifting to the update process of the flash and microcomputer, following screen is displayed. During updating software, **BUSY lamp (SD Access LED)** is blink.



The name of firmware in the update is displayed.




- ◆ Software update takes approx. 10 to 30min.

NOTE: When the **BUSY lamp (SD Access LED)** remains being lit for more than 1 minute, updating is not completed normally even if the screen indicated as above. Turn the power of recorder to OFF and pull out the DC cable. Perform version update again with a newly made SD memory card for updating from the first step.

8. In updating succeed, following screen is displayed. In this time, **BUSY lamp (SD Access LED)** is turned off.



NOTE: If the update is not successful, an error message will appear as follows.



- ◆ When the power supply is shut off on the way of updating, or when updating does not start, or when the above error occurs, turn the power OFF and ON. Then perform writing again.
- 9. In updating succeed, remove the SD memory card and turn the power of camera recorder to OFF and pull out the DC cable. Then turn the power of camera recorder to ON to restart. This procedure is required to work the recorder normally.
NOTE: • Power OFF/ON by the power SW of camera recorder does not work just after updating the software. Please shut OFF the external power supply.
• The power OFF and ON of camera recorder is required for updating data renewal.
- 10. Confirm that the number of software version is renewed for your confirmation update was correctly done follow the item **"5-2. Software Version Display"**.

6. PC EVR software

6-1. Required tools and equipment for PC EVR software

When the PC EVR software is used, the following tools are required.

NAME	Part Number	Pcs.	Remark
PC EVR software	VVS0083	1	Download from the Global Service WEB site.
Measuring board	VFK1988	1	
Extension cable	VFK1989	1	
Extension cable	VFK1982	1	
DC cable	K2GJ2DC00002 or VJA1128	1	For Measuring board
AC Adaptor	---	1	For Measuring board
9pin RS232C cross cable	---	1	
Personal Computer	---	1	*NOTE:

***OS: WINDOWS XP SP2 / SP3**

6-2. Connection

1. Unless otherwise specified, set the switches on the Measuring Board as shown in the table below.

NAME	SETTING POSITION
SW5	CROSS
SW6	D-SUB
SW7	NORMAL
SW8	SYS
SW31	NORMAL
SW32	NORMAL
SW41	ON




Figure 6-2-1

2. Unscrew the 4 screws (A) and remove the GURDE PAD as shown in figure 6-2-2.




Figure 6-2-2

3. Connect the Extension Cable (VFK1982) to EVR connector in Unit. Then make sure that the direction of the VFK1982 is correct as shown in Figure 6-2-3.

When the VFK1982 is connected to EVR connector, be careful of the direction of connector on VFK1982. Please follow as shown in the figure.





Figure 6-2-3

4. Connect the Extension Cable (VFK1989) to connector P2 on Measuring Board (VFK1988).



Connect VFK1989 with connector P2 as shown in picture.
The unit will not work if the connector is attached backwards.

Figure 6-2-4

5. Connect the VFK1989 (Extension Cable) to VFK1982 (Extension Cable) as shown in figure 6-2-5.




Figure 6-2-5

6. Supply DC6V-9V to the Measuring Board (VFK1988). Please use the DC cable and AC Adaptor to supply DC voltage to Measuring Board.
7. Connect a 9 pin RS-232C cross cable between the Measuring Board and RS-232C connector on Personal Computer as shown in Figure.






Figure 6-2-6

6-3. Setup of PC EVR software

1. Copy all files of the PC EVR software (**VVS0083**) to the PC.
2. Supply power to the Camera-Recorder and turn power ON.
3. Start up the PC EVR software by double-clicking "**HPX370ServiceApp.exe**". The following screen will appear.
4. Select the model name.



5. Select the "**CAM(C)**" or "**SYSCON(S)**" according to the purpose and click "**OK**" button. The following screen will appear and when communication between the PC and the Camera-Recorder has been succeeded, blue is displayed to the status lamp.




6. The communication status between the PC and the camera recorder can be confirmed with the status lamp as following color.

Not Connected	:	black
Connected	:	blue
Reading	:	green
Writing	:	red

6-3-1. Detection of not initialized Digital Main P.C.Board

This EVR software is detecting whether the DIGITAL MAIN P.C.Board (CAM EEPROM, SYS EEPROM and P2CS(SH) microprocessor) was initialized after the “OK” button is clicked on **Selection** dialog screen.


When the not initialized P.C.Board was detected, the **Confirmation** dialog screen is displayed as follows. Clicking “OK” button, initialization is executed (*It is not possible to cancel).



It is displayed as “**FACTORY INIT ***” on the LCD panel.

After initialization is completed, it replaces the “**FACTORY INIT OK: *** ” display. The mark * is indicated as shipment destination information. Please confirm that mark is corresponding to the destination of the camera recorder.


Ex.) In case of AG-HPX370P, it displayed as “P”.




After initialization is executed, the EVR software is compulsorily closed. And please turn off the power of this camera recorder when it is displayed as “**TURN POWER OFF**” on the LCD panel.

6-3-2. Setting of Digital Main P.C.Board for T (Japan) model

If the Digital Main Board for T (Japan) model was not detected, when AG-HPX375 was selected by the model selection, the **Confirmation** dialog screen of the setting for T model is displayed.



Clicking “**Cancel**” button on the **Confirmation** dialog screen, **Error** message screen is displayed as follows. Clicking “**OK**” button on the **Error** message screen, the EVR software is compulsorily closed.




Clicking **"OK"** button on the Confirmation dialog screen, **"T"** destination setting is executed as shown in the following figure.

If once this **"T"** setting is executed, the destination setting can't be executed twice.

So don't select **"AG-HPX375"** on the model selection dialog.

If AG-HPX375 is selected by mistake, click **"Cancel"** button on the next Confirmation dialog.



6-4. Setting Tool screen (SYSCON(S) section)

This PC EVR software has **Setting Tool** screen in **SYSCON(S)** section.


< How to display the Setting Tool screen. >

1. Select "**SYSCON(S)**" section after start up the PC EVR software, and click "**OK**" button.
2. Start up the PC EVR software, and select "**Setting Tool**" in "**Tools(W)**" menu, **Setting Tool** screen will appear on screen.

< Function of the Setting Tool screen. >

The following confirmation and the setup can be performed on a **Setting Tool** screen.


- Setting and confirmation of Date and Time of internal clock.
- Display operation of a Service menu and the DIAGNOSTIC menu.
- Software version display.
- 1394 UID display.
- LCD Chromaticity Correction



6-4-1. Setting and confirmation of Date and Time of internal clock

< Confirmation method >


1. Clicking "**Get**" button, the date/time information in camera recorder is displayed.
2. Clicking "**Clear**" button, the displayed date/time is cleared. Clock information on the camera recorder is not cleared.



< Setting method >

1. The date/time information of PC is displayed in the window as shown in following figure on real time.
2. When the "**Input**" button is clicked, a date and time will be fixed on the **Setting Tool** screen (When the "**Input**" button is clicked again, it will return to a real-time display.). And the window to enter date/time becomes valid.
3. Confirm that the date/time is displayed on the LCD panel (DISPLAY SETUP menu → DATE/TIME → TIME&DATE).
4. Clicking "**Set**" button, clock is set in camera recorder follow the set up on the **Setting Tool** screen. In case of data/time is not input to window (gray window), clock information of PC is set. After click "**Set**" button, see the display on LCD panel to confirm the date/time display have changed.


NOTE: In case of put the check in box "-9H", the time of -9 hour from the time displayed on the **Setting Tool** is set.



NOTE: A setup of the date and time can be set also with the OTHER FUNCTION menu (Refer to the procedure of operation instructions for the setting method).

6-4-2. Display operation of a Service menu and the DIAGNOSTIC menu

1. Clicking “Service” button, DIAG(SERVICE), ADJUST, DEFECT(EDIT) and DEFECT(NEW) menu items are displayed in addition to a setup menus on the LCD panel as service menu.
2. Clicking “Diagnostic” button, DIAGNOSTIC menu screen is display on the LCD panel.
3. Please refer to item “3. Service menu” about contents of service menu (page INF-3).



6-4-3. Software Version Display

1. Clicking “Get Version” button, version information of each software are displayed.


NOTE: The number displayed in the item of “PRODUCT” is a number given by combining each software.

2. The version of each software can be confirmed also with the DIAGNOSTIC menu and GUI service menu. Please refer to item “5-2. Software version display” (page INF-14) and item “4-3. VERSION” (page INF-9).

Version Info			
PRODUCT	012.05-00-0.00	VUP Ver	1.00-00-0.00
CAM MICON	1.02-00-0.00	VUP FS	1.00-00-0.00
SYS MICON	1.01-00-0.00	DM FPGA	1.00-00-0.00
P2CS BL2-1	1.00-00-0.00	CAM1 FPGA	1.00-00-0.00
P2CS BL2-2	1.00-00-0.00	CAM2 FPGA	1.01-00-0.00
P2CS KR	1.00-00-0.00	CAM3 FPGA	1.01-00-0.00
P2CS AP	1.00-00-0.00		
			Get Version

6-4-4. 1394 UID display


1. Clicking “Get 1394 UID” button, UID information is displayed. The UID information can be confirmed also with the DIAG(SERVICE) menu and **Write UID/Read Serial** screen on PC EVR software. Please refer to item “3-1-1. 1394 DIAG display” (page INF-4) and item “6-6-1. UID display” (page INF-32).



6-4-5. LCD Chromaticity Correction

LCD Chromaticity can be corrected by this item.

1. Select LCD 0, LCD 1, LCD 2 or LCD 3 and click **"Set"** button. LCD Chromaticity can be corrected also with the ADJUST menu. Please refer to item **"3-2-3. LCD Chromaticity Correction"** (page INF-6).



6-5. Service Information screen (SYSCON(S) section)

This PC EVR software has **Service Information** screen in **SYSCON(S)** section..


< How to display the Service Information screen. >

1. Select **"SYSCON(S)"** section after start up the PC EVR software, and click **"OK"** button.
2. Select **"Service Information"** in **"Tools(W)"** menu, **Service Information** screen will appear on screen.

< Function of the Service Information screen. >

The following display and the setup can be performed on a **Service Information** screen.


- Display the operation time for the camera recorder
- Display the operation time for backlight of the LCD and setting.
- Setting of destination.
- Power supply reboot.



6-5-1. Display the Operation time (power-on time for the camera recorder)

Getting meter information (Operation time).

1. Clicking **"Get"** button, total operation time is displayed in the window.
2. Clicking **"Clear"** button, the display is cleared. The time information of camera recorder is not cleared.




3. Operation times can be confirmed also with the DIAGNOSTIC menu.

6-5-2. Display the Operation time (power-on time for backlight of the LCD) and setting

Getting meter information (LCD operation time) and setting LCD operation time are possible.

1. When you want to set LCD operation time, click **"Set"** button after setting time into hour window.
2. Clicking **"Clear"** button, the display of time is cleared. The time information of camera recorder is not cleared.
3. Click **"Get"** button to confirm that the setting time is displayed.

NOTE: After replacing LCD(backlight) unit, set 0 hour.




4. LCD Operation times can be confirmed also with the DIAGNOSTIC menu.

6-5-3. Setting of destination


NOTE: For AG-HPX371E model, “Setting of destination” is not required. Therefore the item of Destination does not displayed on Setting Tool screen.

1. A destination setup can be set up only on a **Setting Tool** screen. Please refer to item “9. Rewriting setting of data according to destination” (page INF-42) about setting procedure.



6-5-4. Power Supply Reboot

1. Clicking “Re-Boot” button, the power of camera recorder automatically OFF and ON.



6-6. Write UID/Read Serial screen (SYSCON(S) section)

This PC EVR software has **Write UID/Read Serial** screen in **SYSCON(S)** section.

< How to display the Write UID/Read Serial screen. >

1. Select "**SYSCON(S)**" section after start up the PC EVR software, and click "**OK**" button.
2. Select "**Write UID/Read Serial**" in "**Tools(W)**" menu, **Write UID** screen will appear on screen.

< Function of the Write UID/Read Serial screen. >

The following display and the setup can be performed on a **Write UID/Read Serial** screen.

- Display of UID information. • Writing and making of UID. • Display of Serial No.

6-6-1. UID display

Clicking "**Read**" button as shown in figure, UID information is displayed. The UID information can be confirmed also with the **DIAG(SERVICE)** menu and **Setting Tool** screen on PC EVR software. Please refer to item "**3-1-1. 1394 DIAG display**" (page INF-4) and item "**6-4-4. 1394 UID display**" (page INF-28).

6-6-2. UID writing and automatic generation


Clicking "**Make UID**" button as shown in figure, new UID is made automatically. Clicking "**Write**" button as shown in figure, UID information is write to camera recorder (The operation of power OFF/ ON is required to save the number into the camera recorder). Please refer to item "**8. UID Writing Procedure**" (page INF-41) about writing and making procedure.

6-6-3. Serial No. display

Clicking "**Read**" button as shown in figure, Serial No. is displayed. The Serial No. can be confirmed also with the GUI service menu and **DIAGNOSTIC** menu. Please refer to item "**4-4. SYSTEM INFO**" (page INF-9).

6-6-4. Power Supply Reboot

Clicking "**Re-Boot Power**" button, the power of camera recorder automatically OFF and ON.



6-7. Adjustment Tool screen (CAM(C) section)

This PC EVR software has **Adjustment Tool** screen in **CAM(C)** section..

< How to display the Adjustment Tool screen. >



1. Select "**CAM(C)**" section after start up the PC EVR software, and click "**OK**" button.
2. Select "**Adjustment Tool**" in "**Tools(W)**" menu, **Adjustment Tool** screen will appear on screen.

< Function of the Adjustment Tool screen. >

The following adjustment can be adjusted on an **Adjustment Tool** screen.

- Video Terminal Output Level Adjustment.
- Int. Frequency Adjustment.
- Blemish Compensation Adjustment.
- White Shading Adjustment.
- Standard Sensitivity Adjustment.
- White Balance Adjustment.
- ND FILTER Compensation Adjustment.

NOTE: The adjustment procedure uses the Adjustment Tool screen has been described in section 3 (Electrical Adjustment procedure). Please refer to section 3 for various settings etc..



6-8. FPN Compensation screen (CAM(C) section)



This PC EVR software has **FPN Compensation** screen in **CAM(C)** section.

FPN Compensation is abbreviation of “**Fixed Pattern Noise Compensation**”. All Fixed Pattern Noise peculiar to the MOS sensor is compensated in this adjustment.

< How to display the Adjustment Tool screen. >

1. Select “**CAM(C)**” section after start up the PC EVR software, and click “**OK**” button.
2. Select “**FPN Compensation**” in “**Tools(W)**” menu, **FPN Compensation** screen will appear on screen.

NOTE: The adjustment procedure uses the Adjustment Tool screen has been described in section 3 (Electrical Adjustment procedure). Please refer to section 3 for various settings etc..



7. Save and write EEPROM data


< PREPARATION >

When EEPROM data save and write, the PC EVR software is used. Please connect the tools and set up the PC EVR software follow the item "6. PC EVR software".

7-1. Save data of EEPROM data of Camera-Recorder to PC


7-1-1. Save data of Camera EEPROM

1. Select "**CAM(C)**" section after start up the PC EVR software, and click "**OK**" button.
2. Select "**Option**" in "**Setting(S)**" menu and select "**EEPROM : 4 byte read / write mode**" on Option screen.
3. Select "**Read EEPROM(R)**" in "**File(F)**" menu and select "**64K**" on Read EEPROM screen.




4. Click "**OK**" button and reading starts.
5. Green is displayed to the status lamp while reading it. When reading is completed, the status lamp changes into a blue display and a message of the "**EEPROM reading completed!**" will appear on **Confirmation** dialog screen. Click "**OK**" button on the **Confirmation** dialog screen.


NOTE: It takes about 7 minutes to read CAM EEPROM data (0000-0FFF).




NOTE: When the reading error of data occurs, the power of the camera recorder should be OFF and ON. The following message is displayed when the reading error occurred. Click **“OK”** button, the power of the camera recorder automatically OFF and ON.



6. Select **“Save Image File(S)”** in **“File(E)”** menu.




7. Click **“Save(S)”** button after the file name is input, and the place that saves a file is specified on **SAVE** screen. The following message is displayed when saving a file is completed.




7-1-2. Save data of SYS EEPROM


1. Select “**SYSCON(S)**” section after start up the PC EVR software, and click “**OK**” button.
2. Select “**Read EEPROM(R)**” in “**File(F)**” menu and “**16K**” is selected on **Read EEPROM** Read screen.
3. Click “**OK**” button and reading starts.




4. Green is displayed to the status lamp while reading it. When reading is completed, the status lamp changes into a blue display and a message of the “**EEPROM reading completed!**” will appear on **Confirmation** dialog screen. Click “**OK**” button on the **Confirmation** dialog screen.



5. Select “**Save Image File(S)**” in “**File(F)**” menu.



6. Click “**Save(S)**” button after the file name is input, and the place that saves a file is specified on **SAVE** screen. The following message is displayed when saving a file is completed.




7-2. Write EEPROM data from PC to Camera-Recorder


You can return the Camera-Recorder to the condition before board exchanged by writing EEPROM data to new board, which has been saved before board exchanged.

7-2-1. Write data of Camera EEPROM



1. Select “CAM(C)” section after start up the PC EVR software, and click “OK” button.
2. Select “Open Image File(O)” in “File(F)” menu, the screen for selecting the file to be written will appear.



3. Click “Open(O)” button in the Open screen and reading starts.



4. Select “Write EEPROM(W)” in “File(F)” menu, following message will appear.




When “Cancel(C)” button is clicked, writing EEPROM data is canceled.
When “OK” button is clicked, the writing starts.


5. Red is displayed to the status lamp while writing it. When writing is completed, the status lamp changes into a blue display and a message of the “EEPROM writing completed!” will appear on **Confirmation** dialog screen. Click “OK” button on the **Confirmation** dialog screen.

NOTE: It takes about 14 minutes to write CAM EEPROM data (0000-0FFF).

6. Turn off the external DC power supply as shown the message on **Confirmation** dialog screen.




NOTE: When the writing error of data occurs, the power of the camera recorder should be OFF and ON. The following message is displayed when the writing error occurred. Click “OK” button, the power of the camera recorder automatically OFF and ON.





7-2-2. Write data of SYS EEPROM

1. Select "SYSCON(S)" section after start up the PC EVR software, and click "OK" button.
2. Select "Open Image File(O)" in "File(F)" menu, the screen for selecting the file to be written will appear.




3. Select the file to be written in the Camera-Recorder.
4. Click "Open(O)" button in the Open screen and reading starts.
5. Select "Write EEPROM(W)" in "File(F)" menu, following message will appear.



When "Cancel(C)" button is clicked, writing EEPROM data is canceled.
When "OK" button is clicked, the writing starts.

6. Red is displayed to the status lamp while writing it. When writing is completed, the status lamp changes into a blue display and a message of the "EEPROM writing completed!" will appear on Confirmation dialog screen. Click "OK" button on the Confirmation dialog screen.



7. Turn off the external DC power supply as shown the message on Confirmation dialog screen.

NOTE:

Hour meter value (OPERATION & LCD OPERATION) of camera recorder is saved in SYS EEPROM.
After EEPROM backup data of SYSCON is written back to the replaced P.C.Board, please turn the power supply OFF and ON with the following procedure.

- > Write EEPROM data
- > Remove the DC cable or Turn off the SW of external DC power supply.
- > Return the power SW of camera recorder to the off position.
- > Connect the DC cable or Turn on the SW of external DC power supply..
- > Turn the power SW of camera recorder to ON.
- > Turn the power SW of camera recorder to OFF.
- > After turning the power SW of camera recorder to ON, confirm that Hour Meter value is returned to the original value.


8. UID Writing Procedure

< PREPARATION >


When UID is written, the PC EVR software is used. Please connect the tools and set up the PC EVR software follow the item "6. PC EVR software".

< Writing Procedures >

1. Select "**SYSCON(S)**" section after start up the PC EVR software, and click "**OK**" button.
2. Select "**Write UID/Read Serial**" in "**Tools(W)**" menu, **Write UID/Read Serial** screen will appear on screen.



3. Input the last 8 figure numbers in "**UID P2**" box. When the last 8 figure numbers are noted in advance, input the same numbers as noted ones. If the last 8 figures are missed or a new UID is required, click the "**Make UID**" button. New UID is made automatically, and displayed in the box.



4. Click "**WRITE**" button, the writing starts and following message is displayed.



5. Click "**OK**" button.
6. Click "**Re-Boot power**" button on **Write UID/Read Serial** screen, the power of camera recorder automatically OFF and ON. The operation of power OFF/ ON is required to save the number into the camera recorder.
7. Open the 1394 DIAG screen of DIAG(SERVICE) menu and confirm that the UID has been written in correctly.

9. Rewriting setting of data according to destination


NOTE: For AG-HPX371E model, "Setting of destination" is not required. Therefore the item of Destination does not displayed on Setting Tool screen.

< PREPARATION >

When rewriting setting of data according to destination, the PC EVR software is used. Please connect the tools and set up the PC EVR software follow the item "6. PC EVR software".

< PROCEDURE >


1. Select "**SYSCON(S)**" section after start up the PC EVR software, and click "OK" button.
2. Select "**Service Information**" in "**Tools(W)**" menu to open the **Service Information** dialog screen.




NOTE:

- Only the same destination as the model selected on the **Selection** dialog screen can be set.
- When the destination of the Digital Main P.C.Board and the selected model on the **Selection** dialog screen are the same, the "**Destination Set**" button is not displayed on the **Service Information** dialog screen. There if this setting is executed once, it becomes impossible to set twice.
- When the destination of the Digital Main P.C.Board is set to except "E", the "**Destination Set**" button is not displayed on the **Service Information** dialog screen.

3. Set the destination to "P", "EN", "ER" or "MC" following the selected model on the **Selection** dialog screen.




4. Clicking “Destination Set” button, **Confirmation** dialog screen is displayed as follows.



5. Clicking “OK” button on the **Confirmation** dialog screen, the message “**INPUT * SETTING NOW INITIALIZING WAIT JUST MOMENT PLEASE**” appears on LCD display.

NOTE: The position of mark *, the character displays “P”, “EN”, “ER” or “MC” follow the setting on item 3.

6. When a message “**TURN POWER OFF**” is displayed, it is completion of setting. Turn power off this camera recorder.



7. Click “**Re-Boot**” button on **Service Information** screen, the EVR software is compulsorily closed and the power of camera recorder automatically OFF and ON.
8. Open the **DIAGNOSTIC** menu and confirm that the item **MODEL NAME** is displayed as follows.

Set Destination	MODEL NAME
P	AG-HPX370P
EN	AG-HPX372EN
ER	AG-HPX374ER
MC	AG-HPX373MC


10. White Blemish Compensation

About 30 minutes aging or operation is required before starting an adjustment and confirmation.

< Features >

- a) It is possible to compensate blemish of each color signal individually (R, G, B and Y) on five mode screens (Five mode screens have been described to item 10-2).
(Total amount: 256 points / per each mode)
NOTE: It is possible to compensate blemish for ODD and EVEN screens at Mode 1 screen (refer to item 10-2).
Therefore, actually the total amount of compensation that can be compensated is 256 points X 6.
- b) It is possible to compensate blemish without extra equipment (PC, Service fixtures etc.).
- c) Automatic blemish compensation function. Also it is possible to compensate manually.

10-1. Blemish Compensation flow



10-2. Blemish compensation screen mode by camera setting

This camera recorder is saving the blemish compensation data for five mode screens as follows.

NOTE: Please set REC FORMAT to the format shown in the gray when you execute ABB (automatic compensation) and a manual compensation.

< For NTSC model >

Mode	*SYSTEM MODE	*REC FORMAT	*CAMERA MODE	SHUTTER
Mode 1 Two screens used for ODD/EVEN *NOTE: Refer to below.	1080-59.94i	AVC-I 100/60i	-----	Other than Slow Shutter
		AVC-I 50/60i	-----	
		DVCPROHD/60i	60i	
Mode 2	1080-59.94i	AVC-I 100/60i	-----	Slow Shutter (1/30, 1/15)
		AVC-I 50/60i	-----	
		DVCPROHD/60i	60i	
Mode 3	1080-59.94i	AVC-I 100/30PN	-----	-----
		AVC-I 100/24PN	-----	
		AVC-I 50/30PN	-----	
		AVC-I 50/24PN	-----	
		DVCPROHD/60i	30P	
			24P	
			24PA	
Mode 4	720-59.94P	-----	-----	-----
Mode 5	480-59.94i	-----	-----	-----

< For PAL model >

Mode	*SYSTEM MODE	*REC FORMAT	*CAMERA MODE	SHUTTER
Mode 1 Two screens used for ODD/EVEN *NOTE: Refer to below.	1080-50i	AVC-I 100/50i	-----	Other than Slow Shutter
		AVC-I 50/50i	-----	
		DVCPROHD/50i	50i	
Mode 2	1080-50i	AVC-I 100/50i	-----	Slow Shutter (1/25, 1/12.5)
		AVC-I 50/50i	-----	
		DVCPROHD/50i	50i	
Mode 3	1080-50i	AVC-I 100/25PN	-----	-----
		AVC-I 50/25PN	-----	
		DVCPROHD/50i	25P	
Mode 4	720-50P	-----	-----	-----
Mode 5	480-50i	-----	-----	-----

*MAIN MENU → SYSTEM SETUP screen → SYSTEM MODE

*MAIN MENU → SYSTEM SETUP screen → REC FORMAT

*MAIN MENU → SYSTEM SETUP screen → CAMERA MODE

< *Note for manual compensation >

The compensation data for two screens is used for ODD and EVEN with Mode 1. When manual compensation is executed with Mode 1, please execute the blemish compensation to both ODD/EVEN screen. Only the ODD or EVEN picture signal can be output by setting the item of DEFECT COMP as follows.

- Only the ODD picture / DEFECT COMP: 2
- Only the EVEN picture / DEFECT COMP: 3


(ADJUST MENU → DEFECT COMP)

Do not forget the item DEFECT COMP set to 0 after completing compensation at Mode 1 screen.

NOTE: When ABB (Automatic compensation) is executed, it is compensated to both ODD/EVEN. Therefore, the setting of DEFECT COMP does not require to be changed (DEFECT COMP : 0).

10-3. Connection

Connect the SDI OUT1 terminal of the camcorder and the TV-monitor.



10-4. Blemish confirmation

1. Close LENS iris.
2. Set the WHITE BAL SW and GAIN SW as follows.
WHITE BAL SW: PRST 3.2K
GAIN SW: L(0dB)
3. When the blemish level is confirmed, set the following menu items and shutter as follows.

< Camera settings of blemish level confirmation: for NTSC model >

*SYSTEM MODE	*REC FORMAT	*CAMERA MODE	SHUTTER
1080-59.94i	AVC-I 100/60i	-----	1/15

< Camera settings of blemish level confirmation: for PAL model >

*SYSTEM MODE	*REC FORMAT	*CAMERA MODE	SHUTTER
1080-50i	AVC-I 100/50i	-----	1/12.5

*MAIN MENU → SYSTEM SETUP screen → SYSTEM MODE

*MAIN MENU → SYSTEM SETUP screen → REC FORMAT

*MAIN MENU → SYSTEM SETUP screen → CAMERA MODE

4. Measure the level of blemish at waveform monitor (SDI OUT) and confirm that the level of blemish at each ch(R,G,B) is in the specification.

< For NTSC model >

Specification	
Rch / Gch	Bch
20% or less (140mV or less)	40% or less (280mV or less)

< For PAL model >

Specification	
Rch / Gch	Bch
24% or less (168mV or less)	48% or less (336mV or less)

NOTE: This camera recorder is using CMOS instead of CCD. A white noise (white blemish of at a minuteness level) appears on all zone screens when the output of this camera is set a black screen if the CMOS compared with CCD. A white blemish of brightness bright is becomes out of specification as shown in the above specification.



10-5. Manual compensation procedure

In case all blemishes are not compensated in automatic compensation (ABB), it is also possible to perform blemish compensation manually by using the cursor. Following shows then concrete manual compensation procedures for various cases.

1. Close LENS iris and open the **DEFECT (NEW)** menu.
2. Set following item.

SIZE : 1
COLOR : *NOTE

***NOTE:** Select to R, G or B where blemish has been generated.



3. Observe TV-monitor and then adjust item "H CURSOR COARSE" or "H CURSOR FINE" so that the H cursor position moves to the target blemish.
4. Observe TV-monitor and then adjust item "V CURSOR COARSE" or "V CURSOR FINE" so that the V cursor position moves to the target blemish. Then the blemish will disappear automatically.
5. When the blemish does not disappear by positional specification of cursor, the item of "SIZE" or "COLOR" is used. Set item "SIZE" and "COLOR" as follows.

<SIZE>

In case only left and right side disappears a blemish, change this setting value 2, 3, 5 and 7 from 1. And when a blemish disappears is set up.

<COLOR>

This item specifies the color of CCD with a blemish. When the setting value of this item is changed with R, G, and B from Y and a blemish disappears, a color when a blemish disappears is set up.

NOTE: When the blemish does not disappear well by R, G or B is selected, Y is selected. When Y is selected, R, G, and B colors are corrected.

6. Select the item "SET", and push **JOG Dial** button. Then Select "ADD" and push **JOG dial** button again.
7. When the message "ADD COMPLETED !" appears on the screen, data store will be completed.

NOTE: When this unit set to CAC MAX RANGE mode (Refer to item 3-2-2 and 10-6-7), the compensation position is different even if same H and V cursor position are specified in each channel (color). Moreover, the cursor is not displayed white. It is displayed by the color according to "COLOR" of each blemish data (In case of the item "COLOR" is selected to "Y", two lines of cursor appeared).

10-6. Remarks

10-6-1. OFF setting of blemish compensate operation

1. Open the **ADJUST** menu.
2. Set the item "**DEFECT COMP**" to item "**1**", blemish compensate operation is OFF.

10-6-2. Execution of auto detection and compensation for black blemish

1. Shoot the white chart so that the full screen is white and execute AWB.
2. Adjust IRIS of lens so that the white level is becomes 70 to 85%.
3. Open the **ADJUST** menu.
4. Set the item "**DEFECT COMP**" to item "**5**".
5. Open the **DEFECT (EDIT)** menu.
6. Select the item "**SET**" and push "**JOG dial**" button.
7. Select "**CHANGE**" and push "**JOG dial**" button.
8. When the message "**CHANGE COMPLETED !**" appears on the screen, black blemish compensation will be completed.
9. Close the menu and then turn off the power of the Unit.

10-6-3. Delete all cursor position data (Blemish data) (For only a current mode)

1. Open the **ADJUST** menu.
2. Set the item "**DEFECT COMP**" to item "**10**".
3. Open the **DEFECT (EDIT)** menu.
4. Select the item "**SET**" and push "**JOG dial**" button.
5. Select "**DELETE**" and push "**JOG dial**" button.
6. When the message "**DELETE COMPLETED !**" appears on the screen, blemish data will be deleted.
7. Close the menu and then turn off the power of the Unit.

10-6-4. Delete all cursor position data (Blemish data) (For all mode)

1. Open the **ADJUST** menu.
2. Set the item "**DEFECT COMP**" to item "**15**".
3. Open the **DEFECT (EDIT)** menu.
4. Select the item "**SET**" and push "**JOG dial**" button.
5. Select "**DELETE**" and push "**JOG dial**" button.
6. When the message "**DELETE COMPLETED !**" appears on the screen, all blemish data will be deleted.
7. Close the menu and then turn off the power of the Unit.

10-6-5. Delete registered data one by one

1. Open the **DEFECT (EDIT)** menu.
2. Select "**DEFECT NO.**" to desired position of cursor.
3. Select the item "**SET**" and push "**JOG dial**" button.
4. Select "**DELETE**" and push "**JOG dial**" button.
5. When the message "**DELETE COMPLETED !**" appears on the screen, one blemish data will be deleted.

10-6-6. Change Parameter about blemish compensation

1. Open the **DEFECT (EDIT)** menu.
2. Select **"DEFECT NO."** to desired position of cursor.
3. Change some parameters on **DEFECT (EDIT)** menu screen (COLOR, SIZE etc.).
4. Select the item **"SET"** and push **"JOG dial"** button.
5. Select **"CHANGE"** and push **"JOG dial"** button.
6. When the message **"CHANGE COMPLETED !"** appears on the screen, data change will be completed.

10-6-7. Setting of CAC MAX RANGE mode

1. Open the **ADJUST** menu.
2. Set the item **"DEFECT COMP"** to item **"7"**.
3. Open the **DEFECT (EDIT)** menu.
4. Select the item **"SET"** and push **"JOG dial"** button.
5. Select **"CHANGE"** and push **"JOG dial"** button.
6. When the message **"CHANGE COMPLETED !"** appears on the screen, setting of CAC MAX RANGE mode will be completed.

NOTE: When the CAC MAX RANGE mode is OFF, **"DELETE"** is selected instead of **"CHANGE"**, and push **"JOG dial"** button. It returns to the normal screen mode when the message **"DELETE COMPLETED !"** appears on the screen. (The unit can be set to normal screen mode also with the power off and on.)


10-6-8. About the position inhibited to register the compensation data

When there is already registered blemish compensation data, depending on the position relation of the newly registered blemish compensation position (cursor position), blemish compensation operation may not be performed normally. In that case, cursor is flashed on the screen, and a blemish compensation position cannot be registered.

When blemish compensation data is added with the registered blemish compensation data, the inhibit position for blemish compensation is as follow.

Registered blemish compensation size	Additional blemish compensation size	Range of inhibit position	
		Horizontal direction	Vertical direction
1	1	± 4	± 0 (Only the same line)
	2, 3	± 5	
	5	± 6	
	7	± 7	
2, 3	2, 3	± 6	
	5	± 7	
	7	± 8	
5	5	± 8	
	7	± 9	
7	7	± 10	

Ex.: When the 7 pixel compensation data is added to near the registered 5 pixel compensation data
The position shown in the gray of the following figure turns into a registration prohibition position.



-  : Registered blemish compensation position (There is compensation data of 5 pixels)
-  : Registration inhibited position (The compensation data of the 7 pixels cannot register additionally to the right and left 9 pixels.)

11. Operation after major part exchanged

11-1. Operation List

These are items that must be done when the major part has been replaced.


X: Operation required

	Replacement Parts	Adj.	Version conf.	EEPROM	Remark
	DIGITAL MAIN P.C.Board	X	X	X	
	AUDIO P.C.Board				Not required
	POWER P.C.Board				Not required
	POWER SUB P.C.Board				Not required
	RELAY P.C.Board				Not required
	BATT IF P.C.Board				Not required
CARD SLOT U	P2CARD P.C.Board				Not required
	SDCARD P.C.Board				Not required
CAMERA U	CAMERA U	X			
	OPTICAL U	X			
	POS SENSOR P.C.Board				Not required
	FRONT SW P.C.Board				Not required
	REC BUTTON P.C.Board				Not required
SIDE CASE L U	F MIC P.C.Board				Not required
	USB_CN P.C.Board				Not required
	LSIDE JACK P.C.Board				Not required
SIDE CASE R U	RSIDE1 P.C.Board				Not required
	MENU P.C.Board				Not required
	TOGGLE_SW P.C.Board				Not required
	RSIDE2 P.C.Board				Setting of Internal clock's
	POWER_SW P.C.Board				Not required
	PHONE P.C.Board				Not required
LCD U	LCD U				Reset of LCD operation time
	LCD IF P.C.Board				Not required
REAR JACK U	REAR JACK P.C.Board				Not required
	1394_CN P.C.Board				Not required
	DC_IN P.C.Board				Not required
HANDLE U	HANDLE_SW P.C.Board				Not required
	HANDLE_TALLY P.C.Board				Not required
EVF U	EVF TALLY P.C.Board				Not required
	EVF IF P.C.Board				Not required

11-2. Operation flow chart after replacement of major parts

11-2-1. DIGITAL MAIN P.C.Board

NOTE: Be careful the hour meter information can not be back up, restore and writing operation.



```

graph TD
    A([Write the Scene file data to SD memory card.]) --> B([Write the Setting menu data (USER FILE) to SD memory card.])
    B --> C([Confirm that the CAC files saved in the camera recorder.  
The saved files can be confirmed by open the CAC PROPERTY screen on the LENS SETUP menu.  
(MAIN MENU → LENS SETUP → CAC PROPERTY).  
NOTE: It is only the check of files. Please do not delete a file.])
    C --> D([Replace the DIGITAL MAIN P.C.board.])
    D --> E{Confirm that the software version.  
Refer to item "5-2. Software Version Display" on page INF-14 about version display procedure.  
  
Be the latest version.  
(Refer to Global Service WEB Site about number of latest version.)}
    E -- YES --> F([Set the setting data according to destination.  
Refer to item "5.2. Setting of destination" (page INF-42)  
NOTE: For AG-UX100 model, "Setting of destination" is not required.])
    E -- NO --> G([Refer to item "5. Firmware update procedure" on page INF-14 about update procedure.])
    G --> H([Update to latest version.])
    H --> F
    F --> I([Check the Serial Number  
Refer to item "5.3. Check the Serial Number" (page INF-43)  
NOTE: For AG-UX100 model, "Check the Serial Number" is not required.])
    I --> J([Take the PCB Number  
Refer to item "5.4. Take the PCB Number" (page INF-44)  
NOTE: For AG-UX100 model, "Take the PCB Number" is not required.])
    J --> K([Execute the "Check the PCB Number" (page INF-45)  
NOTE: For AG-UX100 model, "Check the PCB Number" is not required.])
    K --> L([Turn the power off.])
    L --> M([It continues to next page.])
  
```

Write the Scene file data to SD memory card.

Write the Setting menu data (USER FILE) to SD memory card.

Confirm that the CAC files saved in the camera recorder.
The saved files can be confirmed by open the CAC PROPERTY screen on the LENS SETUP menu.
(MAIN MENU → LENS SETUP → CAC PROPERTY).
NOTE: It is only the check of files. Please do not delete a file.

Replace the DIGITAL MAIN P.C.board.

Confirm that the software version.
Refer to item "5-2. Software Version Display" on page INF-14 about version display procedure.

Be the latest version.
(Refer to Global Service WEB Site about number of latest version.)

YES

NO

Refer to item "5. Firmware update procedure" on page INF-14 about update procedure.

Update to latest version.

Set the setting data according to destination.
Refer to item "5.2. Setting of destination" (page INF-42)
NOTE: For AG-UX100 model, "Setting of destination" is not required.


Check the Serial Number
Refer to item "5.3. Check the Serial Number" (page INF-43)
NOTE: For AG-UX100 model, "Check the Serial Number" is not required.

Take the PCB Number
Refer to item "5.4. Take the PCB Number" (page INF-44)
NOTE: For AG-UX100 model, "Take the PCB Number" is not required.


Execute the "Check the PCB Number" (page INF-45)
NOTE: For AG-UX100 model, "Check the PCB Number" is not required.

Turn the power off.


(It continues to next page.)




11-2-2. LCD Unit




11-2-3. Camera Unit



11-2-4. Optical Unit



11-2-5. RSIDE2 P.C.Board



11-3. Adjustment after replacement of major parts

When the following parts are exchanged showing in the table, the adjustment and confirmation are required follow the items shown by mark "X" in the table.
The adjustment procedure have been described to section 3 (Electrical adjustment procedure).

11-3-1. Electrical Adjustment


ADJUSTMENT ITEM	PARTS NAME						
	*DIGITAL MAIN P.C Board		Camera U	Optical U	POS SENSOR P.C Board	Front Panel U	
	When back up EEPROM data	When no back up EEPROM data				FRONT SW P.C Board	REC BUTTON P.C Board
FPN Compensation Adj.	X	X	X	X			
Video Terminal Output Level Adj.	X	X					
Int. Frequency Adj.	X	X					
Blemish Compensation. Adj.	X	X	X	X			
White Shading Adj.		X	X	X			
Standard Sensitivity Adj.		X	X	X			
White Balance Adj.		X	X	X			
ND FILTER Compensation Adj.		X	X	X			

X: Adjustment / Confirmation Required


* The method of data backup (EEPROM) has been described to the item "7. Save and write EEPROM data" of service information (SECTION 1).

NOTE: FPN and Blemish compensation data are saved in FLASH MEMORY.

12. Interconnection



13. P.C.Board Location



SECTION 2

DISASSEMBLY PROCEDURES


Model No. : AG-HPX370P, AG-HPX371E, AG-HPX372EN
AG-HPX373MC, AG-HPX374ER

CONTENTS

1. Disassembly Flowchart	DIS-1
2. Removal of SIDE CASE L Unit.....	DIS-2
3. Removal of SIDE CASE R S Unit	DIS-3
4. Removal of POWER MAIN P.C.B.	DIS-4
5. Removal of AUDIO P.C.B.	DIS-4
6. Removal of P2CARD and SDCARD P.C.B.....	DIS-5
7. Removal of POWER SUB P.C.B.....	DIS-6
8. Removal of REAR JACK Unit.....	DIS-9
9. Removal of DIGITAL MAIN P.C.B.....	DIS-11
10. Removal of EVF Unit.....	DIS-13
11. Removal of EVF TALLY P.C.B.....	DIS-15
12. Removal of EVF IF P.C.B.....	DIS-16
13. Removal of CAMERA Unit	DIS-19
14. Removal of HANDLE Unit	DIS-21
15. Removal of LCD Unit.....	DIS-23

1. Disassembly Flowchart

NOTE: Please put on your hand glove, when you operated disassemble and assemble.



2. Removal of SIDE CASE L Unit

1. Unscrew the 4 screws (A) as shown in figure 2-1 and remove the GURDE PAD.




Figure 2-1

2. Unscrew the 6 screws (B) as shown in figure 2-2 and open the SIDE CASE L Unit.

NOTE: The connector (A), (B) and (C) as shown in figure 2-3 combined with the connectors on DIGITAL MAIN P.C.B..




Figure 2-2

3. Disconnect the Jumper Plug as shown in figure 2-3 and remove the SIDE CASE L Unit.




Figure 2-3

3. Removal of SIDE CASE R S Unit

1. Unscrew the 5 screws (A) and the 4 screws (B) as shown in figure 3-1, and open the SIDE CASE R S Unit.




Figure 3-1

2. Removes the wires from the clamber as shown in figure 3-2.
3. Disconnect the connector (A) and (B) as shown in figure 3-2, and remove the SIDE CASE R S Unit.




Figure 3-2

4. Removal of POWER MAIN P.C.B.

1. Open the SIDE CASE R S Unit.
2. Remove the POWER MAIN P.C.B as shown in figure 4-1.




Figure 4-1

5. Removal of AUDIO P.C.B.

1. Open the SIDE CASE R S Unit.
2. Unscrew the 2 screws (A) as shown in figure 5-1 and open the AUDIO P.C.B..




Figure 5-1

6. Removal of P2CARD and SDCARD P.C.B.

1. Remove the SIDE CASE L Unit.
2. Unscrew the 2 screws (A) as shown in figure 6-1.
3. Remove the SIDE CASE R S Unit.
4. Unscrew a screw (B) as shown in figure 6-1 and remove the CARD SLOT Unit.




Figure 6-1

5. Disconnect the connector (A) and (B) combined with the DIGITAL MAIN P.C.B. as shown in figure 6-2, and remove the CARD SLOT Unit.




Figure 6-2

6. Unscrew the 3 screws (C) as shown in figure 6-3.
7. Disconnect the connector (C) combined with the P2CARD P.C.B. as shown in figure 6-3, and remove the SDCARD P.C.B. from P2CARD P.C.B..




Figure 6-3

7. Removal of POWER SUB P.C.B.

1. Remove the SIDE CASE R S Unit.
2. Remove the SIDE CASE L Unit.
3. Unscrew the 2 screws (A) as shown in figure 7-1 and remove the SHOULDER PAD.




Figure 7-1

4. Unscrew the 4 screws (B) as shown in figure 7-2 and remove the BOTTOM COVER.




Figure 7-2

5. Disconnect the connector (A), (B), (C), (D), (E) (F) and (G) on the POWER SUB P.C.B. as shown in figure 7-3.




Figure 7-3

6. Unscrew the 4 screws (D) on the POWER SUB P.C.B. as shown in figure 7-4.




Figure 7-4

7. Disconnect the connector (H) and (I) combined with the DIGITAL MAIN P.C.B. as shown in figure 7-5, and remove the POWER SUB P.C.B..




Figure 7-5

< Note for assembly >

1. Confirm that the POWER SUB COVER is installed to corrected position as shown in figure 7-6, before you assemble the POWER SUB P.C.B..




Figure 7-6

2. Insert the wires connected with connector (C) as shown in figure 7-3 in the cut and lacks part of POWER SUB P.C.B..




Figure 7-7

3. Wired the wires as shown in figure 7-8 and they are bundled by the clumper.




Figure 7-8

< NOTE: FRONT LEG BASE & FRONT V EDGE >

1. Tighten the screw (A) with $[80 \pm 5\text{cN}\cdot\text{m} (8.2 \pm 0.5\text{kg}\cdot\text{cm})]$ of torque as shown in figure 7-9, when you assemble the FRONT LEG BASE to MAIN FRAME.
2. Tighten the screw (B) with $[110 \pm 5\text{cN}\cdot\text{m} (11.2 \pm 0.5\text{kg}\cdot\text{cm})]$ of torque as shown in figure 7-9, when you assemble the FRONT V EDGE to MAIN FRAME.




Figure 7-9

8. Removal of REAR JACK Unit

1. Remove the SIDE CASE R S Unit.
2. Remove the SIDE CASE L Unit.
3. Remove the SHOULDER PAD and BOTTOM CASE (Refer to figure 7-1 and 7-2).
4. Disconnect a connector (A) as shown in figure 8-1.
5. Remove the jumper wire from the clammer as shown in figure 8-1.
6. Disconnect a jumper plug as shown in figure 8-1.




Figure 8-1

7. Disconnect the connector (B), (C), (D), (E), (F) and (G) on the POWER SUB P.C.B. as shown in figure 8-2.




Figure 8-2

8. Unscrew the 2 screws (A) as shown in figure 8-3 and remove the REAR JACK Unit.




Figure 8-3

< NOTE: Anton Bracket >

1. Connect the connector (A) and (B) as shown in figure 8-4, when you assemble the Anton Bracket to MAIN FRAME.
2. Tighten the screw (B) with $[50 \pm 5\text{cN}\cdot\text{m} (5.1 \pm 0.5\text{kg}\cdot\text{cm})]$ of torque as shown in figure 8-4, when you assemble the Anton Bracket to MAIN FRAME.




Figure 8-4

9. Removal of DIGITAL MAIN P.C.B.

1. Remove the SIDE CASE R S Unit.
2. Remove the SIDE CASE L Unit.
3. Remove the POWER MAIN P.C.B..
4. Remove the AUDIO P.C.B..
5. Remove the P2CARD and SDCARD P.C.B. (CARD SLOT Unit).
6. Remove the POWER SUB P.C.B..
7. Disconnect the connector (A) and (B) as shown in figure 9-1.




Figure 9-1

8. Disconnect the connector (C), (D), (E), (F), (G), (H), (I) and jumper plug as shown in figure 9-2.
9. Unscrew the 8 screws (A) as shown in figure 9-2 and remove the DIGITAL MAIN P.C.B..




Figure 9-2

< Note for assembly >

1. Match the hole of DIGITAL MAIN P.C.B. and positioning pin, claw as shown in figure 9-3.




Figure 9-3

< Note when connector is inserted >

Be careful when you connect the cable (A) shown in figure 9-4 with the P.C.Board. In connector (J) shown in figure 9-4, the contact side is the upper part. Confirm that the contact side and do not insert the connector of cable (A) reversely when connecting the cable (A).




Figure 9-4

10. Removal of EVF Unit

1. Remove the SIDE CASE L Unit.
2. Unscrew a screw (A) as shown in figure 10-1.
3. Disconnect a connector (A) as shown in figure 10-1.
4. Unscrew a screw (B) and remove the wires from CLAMPER (A) as shown in figure 10-1.




Figure 10-1

5. Unscrew the 2 screws (C) as shown in figure 10-2 and remove the EVF SLIDE STOPPER.
6. Slide the EVF Unit in the direction of arrow as shown in figure 10-2 and remove the EVF Unit from SLIDER.




Figure 10-2

7. Unscrew the 2 screws (D) as shown in figure 10-3 and remove the EVF CABLE COVER.
8. Unscrew a screw (E) and remove the wires from CLAMPER (B) as shown in figure 10-3.




Figure 10-3

9. Remove the cable passed through hole (A) and (B) shown in Figure 10-4 and remove the EVF Unit.




Figure 10-4

< Note for assembly >

1. Pass the EVF cable through hole (B).




Figure 10-5

2. Match the cut part of EVF cable and frame as shown in figure 10-6.




Figure 10-6

11. Removal of EVF TALLY P.C.B.

1. Remove the EVF Unit.
2. Unscrew the 2 screws (A) as shown in figure 11-1 and remove the MIC HOLDER.




Figure 11-1

3. Unscrew the 2 screws (B) as shown in figure 11-2 and remove the EVF CABLE HOLDER.
4. Unscrew a screw (C) as shown in figure 11-2 and remove the GND cable.
5. Unscrew the 4 screws (D) as shown in figure 11-2 and remove the EVF TOP CASE.




Figure 11-2

6. Disconnect the connector (A) and (B) as shown in figure 11-3.
7. Unscrew a screw (E) as shown in figure 11-3 and remove the GND cable.
8. Unscrew the 2 screws (F) as shown in figure 11-3 and remove the EVF TALLY P.C.B..




Figure 11-3

12. Removal of EVF IF P.C.B.

1. Remove the EVF Unit.
2. Unscrew the 2 screws (A) as shown in figure 11-1 and remove the MIC HOLDER.
3. Unscrew the 2 screws (B) as shown in figure 11-2 and remove the EVF CABLE HOLDER.
4. Unscrew the 4 screws (D) as shown in figure 11-2 and remove the EVF TOP CASE.
5. Unscrew a screw (E) as shown in figure 12-1 and remove the GND cable.
6. Disconnect the connector (A) as shown in figure 12-1 and remove the EVF HOLDER.




Figure 12-1

7. Slide the EYEPIECE LOCK BUTTON and turn the EYEPIECE clockwise to remove it.




Figure 12-2

8. Unscrew the 3 screws (F) as shown in figure 12-3 and remove the LCD Unit.




Figure 12-3

9. Unscrew a screw (G) and remove the GND cable and EVF SHIELD CASE as shown in figure 12-4.




Figure 12-4

10. Release the 2 lock claws and open the EVF IF P.C.B in the direction of the arrow as shown in figure 12-5.




Figure 12-5

11. Disconnect a connector (B) and remove the EVF IF P.C.B. as shown in figure 12-6.




Figure 12-6

< Note at disassemble and assembly of EYEPIECE >

1. Do not stick dust etc. to EVF LCD FILTER and LENS of EYEPIECE (inside) as shown in figure 12-7.




Figure 12-7

< Note for assemble of EVF SHIELD CASE >

1. Tighten a screw (G) while pressing surface of EVF SHIELD CASE as shown in figure 12-8.




Figure 12-8

2. Confirm that the black part of the resin (EVF LCD COVER) is seen from the edge side of EVF SHIELD CASE as shown in figure 12-9.




Figure 12-9

13. Removal of CAMERA Unit

1. Open the SIDE CASE R S Unit.
2. Remove the SIDE CASE L Unit.
3. Remove the EVF Unit.
4. Disconnect a connector (A) on the RELAY P.C.B. as shown in figure 13-1.




Figure 13-1

5. Disconnect the connector (B), (C) and (D) on the DIGITAL MAIN P.C.B. as shown in figure 13-2.




Figure 13-2

6. Unscrew the 4 screws (A) as shown in figure 13-3 and remove the CAMERA Unit.




Figure 13-3

< NOTE: OPTICAL Unit >

1. Tighten the screw (A) with [$120 \pm 5\text{cN}\cdot\text{m}$ ($12.2 \pm 0.5\text{kg}\cdot\text{cm}$)] of torque as shown in figure 13-4, when you assemble the OPTICAL Unit to Front Case 1 Unit.




Figure 13-4

14. Removal of HANDLE Unit

1. Open the SIDE CASE L Unit.
2. Disconnect a connector (A) as shown in figure 14-1.




Figure 14-1

3. Unscrew the 2 screws (A) as shown in figure 14-2 and remove the EVF SLIDE STOPPER.
4. Slide the EVF Unit in the direction of arrow as shown in figure 14-2 and remove the EVF Unit from SLIDER.




Figure 14-2

5. Unscrew the 4 screws (B) and 2 screws (C) as shown in figure 14-3, and remove the HANDLE Unit.




Figure 14-3

< Note for assembly >

1. Pass the wires from HANDLE Unit through hole of SIDE CASE L Unit side as shown in figure 14-4.




Figure 14-4

2. Paint SCREW LOCK at the screw hole (6 places) as shown in figure 14-5.

Paint SCREW LOCK at the
part shown with X mark.




Figure 14-5

3. Tighten the screw (B) with [$110 \pm 5\text{cN}\cdot\text{m}$ ($11.2 \pm 0.5\text{kg}\cdot\text{cm}$)] of torque and tighten the screw (C) with [$80 \pm 5\text{cN}\cdot\text{m}$ ($8.2 \pm 0.5\text{kg}\cdot\text{cm}$)] of torque as shown in figure 14-3, when you assemble the HANDLE Unit to MAIN FRAME.

15. Removal of LCD Unit

1. Remove the SIDE CASE R S Unit.
2. Unscrew the 5 screws (A) as shown in figure 15-1 and remove the FACE PAD.




Figure 15-1

3. Disconnect a connector (A) as shown in figure 15-2.




Figure 15-2

4. Unscrew the 2 screws (B) as shown in figure 15-3 and remove the LCD Unit.




Figure 15-3

< Assembly procedure >

1. Pass flexible cable from the LCD Unit is passed through the hole as shown in figure 15-4.
2. Match the hole of HINGE and positioning pin as shown in figure 15-3.
3. Tighten the 2 screws (B) as shown in figure 15-3.




Figure 15-4

4. Connect the flexible cable to connector (A) as shown in 15-2 and then put it cable on FPC HOLD CUSHION.
5. Install the FACE PAD to SIDE CASE PANEL and tighten the 5 screws (A) as shown in figure 15-1.

NOTE: When flexible cable connected with connector (A) is removed from FPC HOLD CUSHION, it CUSHION can not be re-used by bend and break. Please put use new FPC HOLD CUSHION at the assembly.




Figure 15-5

SECTION 3

ELECTRICAL ADJUSTMENT

Model No. : AG-HPX370P, AG-HPX371E, AG-HPX372EN
AG-HPX373MC, AG-HPX374ER

CONTENTS

1. Preparation of adjustment.....	ELE-1
1-1. Required tools and equipment for PC EVR software.....	ELE-1
1-2. Connection	ELE-1
1-3. Adjustment Item	ELE-4
1-4. Setup of PC EVR software.....	ELE-5
2. Adjustment Procedure.....	ELE-6
2-1. FPN Compensation screen	ELE-6
2-1-1. FPN Compensation Adjustment	ELE-6
2-2. Adjustment Tool screen	ELE-7
2-2-1. Video Terminal Output Level Adjustment.....	ELE-9
2-2-2. Int. Frequency Adjustment.....	ELE-10
2-2-3. Blemish Compensation Adjustment.....	ELE-11
2-2-4. White Shading Adjustment	ELE-12
2-2-5. Standard Sensitivity Adjustment.....	ELE-13
2-2-6. White Balance Adjustment	ELE-14
2-2-7. ND FILTER Compensation Adjustment.....	ELE-15

1. Preparation of adjustment

1-1. Required tools and equipment for PC EVR software

When the PC EVR software is used, the following tools are required.

NAME	Part Number	Pcs.	Remark
PC EVR software	VVS0083	1	Download from the Global Service WEB site.
Measuring board	VFK1988	1	
Extension cable	VFK1989	1	
Extension cable	VFK1982	1	
DC cable	K2GJ2DC00002 or VJA1128	1	For Measuring board
AC Adaptor	---	1	For Measuring board
9pin RS232C cross cable	---	1	
Personal Computer	---	1	*NOTE:

***OS: WINDOWS XP SP2 / SP3**

1-2. Connection

1. Unless otherwise specified, set the switches on the Measuring Board as shown in the table below.

NAME	SETTING POSITION
SW5	CROSS
SW6	D-SUB
SW7	NORMAL
SW8	SYS
SW31	NORMAL
SW32	NORMAL
SW41	ON




Figure 1-2-1

2. Unscrew the 4 screws (A) and remove the GURDE PAD as shown in figure 1-2-2.




Figure 1-2-2

3. Connect the Extension Cable (VFK1982) to EVR connector in Unit. Then make sure that the direction of the VFK1982 is correct as shown in Figure 1-2-3.

When the VFK1982 is connected to EVR connector, be careful of the direction of connector on VFK1982. Please follow as shown in the figure.




Figure 1-2-3

4. Connect the Extension Cable (VFK1989) to connector P2 on Measuring Board (VFK1988) as shown in Figure 1-2-4.




Figure 1-2-4

5. Connect the Extension Cable (VFK1989) to Extension Cable (VFK1982) as shown in figure 1-2-5.




Figure 1-2-5

6. Supply DC6V-9V to the Measuring Board (VFK188). Please use the DC cable and AC Adaptor to supply DC voltage to Measuring Board.
7. Connect a 9 pin RS-232C cross cable between the Measuring Board and RS-232C connector on Personal Computer as shown in Figure.




Figure 1-2-6


1-3. Adjustment Item

Below indicated tools are required to perform each adjustment in addition to tools in introduced in item 1-1.


ITEM	Required Tool and equipment	Remark
FPN Compensation Adjustment	Unnecessary	AUTO Adj.
Video Terminal Output Level Adjustment	SD WFM	Manual Adj.
Int. Frequency Adjustment	SD NTSC/PAL Composite Signal Generator SD WFM	Manual Adj.
Blemish Compensation Adjustment	White Chart Halogen lamp Color Pyrometer & Lux Meter SD WFM (with SDI INPUT)	Manual Adj.
White Shading Adjustment	White Chart Halogen lamp Color Pyrometer & Lux Meter SD WFM (with SDI INPUT)	AUTO Adj.
Standard Sensitivity Adjustment	Gray Scale Chart (4:3, Reflection Type) Halogen lamp Color Pyrometer & Lux Meter SD WFM (with SDI INPUT / R,G,B display switching)	AUTO Adj.
White Balance Adjustment	Gray Scale Chart (4:3, Reflection Type) Halogen lamp Color Pyrometer & Lux Meter SD WFM (with SDI INPUT)	AUTO Adj.
ND FILTER Compensation Adjustment	SD WFM (with vector scope) Monitor TV Lux Meter SD WFM (with SDI INPUT)	Manual Adj.

1-4. Setup of PC EVR software

1. Copy all files of the PC EVR software (**VVS0083**) to the PC.
2. Supply power to the Camera-Recorder and turn power ON.
3. Start up the PC EVR software by double-clicking "**HPX370ServiceApp.exe**". The following screen will appear.
4. Select the model name.



5. Select the "**CAM(C)**" and click "**OK**" button. The following screen will appear and when communication between the PC and the Camera-Recorder has been succeeded, blue is displayed to the status lamp.



6. The communication status between the PC and the camera recorder can be confirmed with the status lamp as following color.
 Not Connected : black
 Connected : blue
 Reading : green
 Writing : red

NOTE: When the "OK" button is clicked on the **Selection** screen, "**Detection of not initialized Digital Main P.C.Board**" and "**Setting of Digital Main P.C.Board for T (Japan) model**" might be executed in this EVR software. Please refer to the item "**6-3. Setup of PC EVR software**" (SECTION 1).


2. Adjustment Procedure

When performing the electrical adjustment, the **Adjustment Tool** and **FPN Compensation** screen are used.

2-1. FPN Compensation screen


< How to display the Setting Tool screen. >

1. Select "**CAM(C)**" section after start up the PC EVR software, and click "**OK**" button.
2. Select "**FPN Compensation**" in "**Tools(W)**" menu, **FPN Compensation** screen will appear on screen.




2-1-1. FPN Compensation Adjustment

1. Confirm that the all temperature values are within from +013 to +034 in the display column of Current Temperature on the **FPN Compensation** screen.
2. Clicking "**Execute**" button, the FPN compensation is executed automatically.
3. The message "**ABB ACTIVE**" displays on LCD panel and the message "**Processing...**" is displayed in the STATUS column on the **FPN Compensation** screen.
4. When the compensation is completed, the message "**ABB END**" displays on LCD panel and the message "**Completed!**" is displayed in the STATUS column on the **FPN Compensation** screen. It takes about two minutes until completion.



NOTE: When the FPN Compensation screen was started up, the temperature of RGB-MOS sensor is detected. When the temperature of all MOS sensor is within from 13 to 34 degrees, the **“Execute”** button is effective and the **“Execute”** button becomes invalid outside this temperature range. The temperature detection after the FPN Compensation screen starts is done every 30 seconds. Be careful that when the power of camera recorder is turned ON at the room temperature 25 degrees, the temperature that can be adjusted is exceeded after about 5 minutes.


Execute this adjustment when the temperature of all MOS sensor is within from 13 to 34 degrees. The execution button becomes invalid outside this temperature range. When the temperature is low, leave the camera turn power ON. When the temperature is high, leave the camera turn power OFF.



2-2. Adjustment Tool screen


< How to display the Setting Tool screen. >

1. Select **“Adjustment Tool”** in **“Tools(W)”** menu, **Adjustment Tool** screen will appear on screen.




< Setting of System Mode >

System Mode and System Frequency can be set on the Adjustment Tool screen.



System Mode is set to 720/60p as shown in the following screen. The setting procedure of System Mode is as follows (Ex.: When setting it to 1080/60i).

1. Click the “1080/60i” button. And click the “Re-Boot Power” button after the message “TURN POWER OFF” is displayed on the LCD panel. The power of camera recorder is automatically OFF and ON.



2-2-1. Video Terminal Output Level Adjustment


NOTE: Please execute the adjustment to either systems NTSC or PAL.

<For NTSC>

1. Connect the WFM to the VIDEO OUT with 75ohm termination.
2. Open the SYSTEM SETUP screen and set the item "SYSTEM MODE" to "1080/59.94i" (MAIN MENU > SYSTEM SETUP > SYSTEM MODE).
3. Select "CAM(C)" section after start up the PC EVR software, and click "OK" button.
4. Select "Adjustment Tool" in "Tools(W)" menu, Adjustment Tool screen will appear on screen.
5. Click the "Start" button for Video Level Adj..
6. Adjust Luminance level "A" by clicking the adjustment button for Video Level Adj. so that it is within specification.
7. Click the "Set" button for Video Level Adj. to end of video level adjustment mode.


<For PAL>

1. Connect the WFM to the VIDEO OUT with 75ohm termination.
2. Open the SYSTEM SETUP screen and set the item "SYSTEM MODE" to "1080/50i" (MAIN MENU > SYSTEM SETUP > SYSTEM MODE).
3. Select "CAM(C)" section after start up the PC EVR software, and click "OK" button.
4. Select "Adjustment Tool" in "Tools(W)" menu, Adjustment Tool screen will appear on screen.
5. Click the "Start" button for Video Level Adj..
6. Adjust Luminance level "A" by clicking the adjustment button for Video Level Adj. so that it is within specification.
7. Click the "Set" button for Video Level Adj. to end of video level adjustment mode.




For NTSC

$$A = 714\text{mV} \pm 14\text{mV}$$



For PAL

$$A = 700\text{mV} \pm 14\text{mV}$$



2-2-2. Int. Frequency Adjustment


NOTE: Please execute the adjustment to both systems NTSC and PAL.

<For NTSC>

1. Connect the WFM to the VIDEO OUT with 75ohm termination.
2. Open the SYSTEM SETUP screen and set the item “**SYSTEM MODE**” to “**1080/59.94i**” (MAIN MENU > SYSTEM SETUP > SYSTEM MODE).
3. Input a color bar signal to EXT IN BNC of WFM.
4. Set to EXT reference mode on WFM.
5. Select “**CAM(C)**” section after start up the PC EVR software, and click “**OK**” button.
6. Select “**Adjustment Tool**” in “**Tools(W)**” menu, **Adjustment Tool** screen will appear on screen.
7. Click the “**Start**” button for **X’tal Oscillator Freq**.
8. Observe the video output signal on the waveform display mode.
9. Clicking the adjustment button for **X’tal Oscillator Freq** so that the H-shift of the waveform is become stop.
NOTE: Actually, H-shift of the waveform does not stop completely. Set it to the value of slowing of the H-shift.
10. Observe the video output signal on the vector scope display mode.
11. Clicking the adjustment button for **X’tal Oscillator Freq** so that the rotation of the vector is become stop.
NOTE: Actually, the rotation of the vector does not stop completely. Set it to the value of slowing of the rotation, because the direction where the vector is rotated changes in change 1 unit of an adjustment value finally.
12. Click the “**Set**” button for **X’tal Oscillator Freq** to end of internal frequency adjustment mode.

<For PAL>


1. Connect the WFM to the VIDEO OUT with 75ohm termination.
2. Open the SYSTEM SETUP screen and set the item “**SYSTEM MODE**” to “**1050/50i**” (MAIN MENU > SYSTEM SETUP > SYSTEM MODE).
3. Input a color bar signal to EXT IN BNC of WFM.
4. Set to EXT reference mode on WFM.
5. Select “**CAM(C)**” section after start up the PC EVR software, and click “**OK**” button.
6. Select “**Adjustment Tool**” in “**Tools(W)**” menu, **Adjustment Tool** screen will appear on screen.
7. Click the “**Start**” button for **X’tal Oscillator Freq**.
8. Observe the video output signal on the waveform display mode.
9. Clicking the adjustment button for **X’tal Oscillator Freq** so that the H-shift of the waveform is become stop.
NOTE: Actually, H-shift of the waveform does not stop completely. Set it to the value of slowing of the H-shift.
10. Observe the video output signal on the vector scope display mode.
11. Clicking the adjustment button for **X’tal Oscillator Freq** so that the rotation of the vector is become stop.
NOTE: Actually, the rotation of the vector does not stop completely. Set it to the value of slowing of the rotation, because the direction where the vector is rotated changes in change 1 unit of an adjustment value finally.
12. Click the “**Set**” button for **X’tal Oscillator Freq** to end of internal frequency adjustment mode.



2-2-3. Blemish Compensation Adjustment


NOTE: Please execute the adjustment to NTSC system.

1. Connect the WFM to the SDI OUT1 with 75ohm termination.
2. Aim the Camera-Recorder at white chart under the Halogen lamp condition (3100K, 2000Lux).
3. Shoot the white chart so that the full screen is white.
4. Open the SYSTEM SETUP screen and set the item "SYSTEM MODE" to "1080/59.94i" (MAIN MENU > SYSTEM SETUP > SYSTEM MODE).
5. Select "CAM(C)" section after start up the PC EVR software, and click "OK" button.
6. Select "Adjustment Tool" in "Tools(W)" menu, Adjustment Tool screen will appear on screen.



7. Click the "Start" button for 1080/60i Mode1.

NOTE: When SYSTEM MODE is not set to "1080/59.94i", the following error messages is displayed.




8. Confirm that the white level of signal is about 70 to 85%.
9. Clicking the "Execute" button, the blemish compensation adjustment is executed automatically.
10. When the adjustment is completed, the message "Blemish Compensation Completed!" is displayed in the STATUS column on the Adjustment Tool screen.
11. Click the "Start" button for 1080/60i Mode2.
12. Confirm that the white level of signal is about 70 to 85%.
13. Clicking the "Execute" button, the blemish compensation adjustment is executed automatically.
14. When the adjustment is completed, the message "Blemish Compensation Completed!" is displayed in the STATUS column on the Adjustment Tool screen.
15. Click the "Start" button for 1080/30p.
16. Confirm that the white level of signal is about 70 to 85%.
17. Clicking the "Execute" button for Blemish Comp Mode 1, the blemish compensation adjustment is executed automatically.
18. When the adjustment is completed, the message "Blemish Compensation Completed!" is displayed in the STATUS column on the Adjustment Tool screen.

19. Open the SYSTEM SETUP screen and set the item **"SYSTEM MODE"** to **"720/59.94p"** (MAIN MENU > SYSTEM SETUP > SYSTEM MODE).

20. Click the **"Start"** button for **720/60p**.

NOTE: When SYSTEM MODE is not set to "720/60p", the following error messages is displayed.



21. Confirm that the white level of signal is about 70 to 85%.


22. Clicking the **"Execute"** button, the blemish compensation adjustment is executed automatically.

23. When the adjustment is completed, the message **"Blemish Compensation Completed!"** is displayed in the STATUS column on the **Adjustment Tool** screen.

24. Open the SYSTEM SETUP screen and set the item **"SYSTEM MODE"** to **"480/59.94i"** (MAIN MENU > SYSTEM SETUP > SYSTEM MODE).

25. Click the **"Start"** button for **480/60i**.

NOTE: When SYSTEM MODE is not set to "480/60i", the following error messages is displayed.



26. Confirm that the white level of signal is about 70 to 85%.


27. Clicking the **"Execute"** button, the blemish compensation adjustment is executed automatically.

28. When the adjustment is completed, the message **"Blemish Compensation Completed!"** is displayed in the STATUS column on the **Adjustment Tool** screen.

2-2-4. White Shading Adjustment

NOTE: Please execute the adjustment to NTSC system.


1. Open the SYSTEM SETUP screen and set the item **"SYSTEM MODE"** to **"1080/59.94i"** (MAIN MENU > SYSTEM SETUP > SYSTEM MODE).
2. Connect the WFM to the SDI OUT1 with 75ohm termination.
3. Aim the Camera-Recorder at white chart under the Halogen lamp condition (3100K, 2000Lux).
4. Shoot the white chart so that the full screen is white.
5. Select **"CAM(C)"** section after start up the PC EVR software, and click **"OK"** button.
6. Select **"Adjustment Tool"** in **"Tools(W)"** menu, **Adjustment Tool** screen will appear on screen.
7. Clicking the **"Start"** button for **White Shading**, the camera recorder is set to white shading adjustment mode.
8. Confirm that the white level of signal is about 70 to 85%.
9. Clicking the **"Execute"** button for **White Shading**, the white shading adjustment is executed automatically.
10. When the adjustment is completed, the message **"Shading Completed!"** is displayed in the STATUS column on the **Adjustment Tool** screen.



2-2-5. Standard Sensitivity Adjustment


NOTE: Please execute the adjustment to NTSC system.

1. Open the SYSTEM SETUP screen and set the item “**SYSTEM MODE**” to “**1080/59.94i**” (MAIN MENU > SYSTEM SETUP > SYSTEM MODE).
2. Connect the WFM to the SDI OUT1 with 75ohm termination.
3. Aim the Camera-Recorder at grayscale chart under the Halogen lamp condition (3100K, 2000Lux).
4. Shoot the white portion at center of grayscale chart greatly.
5. Select “**CAM(C)**” section after start up the PC EVR software, and click “**OK**” button.
6. Select “**Adjustment Tool**” in “**Tools(W)**” menu, **Adjustment Tool** screen will appear on screen.
7. Clicking the “**Start**” button for **Standard Sensitivity**, the confirmation message appears as “**White Shading Adjustment completed?**”.
8. Clicking the “**OK**” button, camera recorder is set to standard sensitivity adjustment mode.




9. Set the IRIS to “**F10 ± 1/3**”.

NOTE: The position of F10 is as follows.



■ ■ ■ Set it to this position.


10. Clicking the adjustment button for Standard Sensitivity so that the signal level of Gch signal is becomes 100%±1% (It adjusts use an adjustment button of Upper and Lower).
11. Click the “**Set**” button for **White Shading** to end of standard sensitivity adjustment mode.



2-2-6. White Balance Adjustment


NOTE: Please execute the adjustment to NTSC system.

1. Open the SYSTEM SETUP screen and set the item **"SYSTEM MODE"** to **"1080/59.94i"** (MAIN MENU > SYSTEM SETUP > SYSTEM MODE).
2. Connect the WFM to the SDI OUT1 with 75ohm termination.
3. Aim the Camera-Recorder at grayscale chart under the Halogen lamp condition (3100K, 2000Lux).
4. Shoot the grayscale chart so that fit the picture to the frame of grayscale chart.
5. Select **"CAM(C)"** section after start up the PC EVR software, and click **"OK"** button.
6. Select **"Adjustment Tool"** in **"Tools(W)"** menu, **Adjustment Tool** screen will appear on screen.
7. Clicking the **"Start"** button for **White Balance**, the confirmation message appears as **"Sense Adjustment completed?"**.
8. Clicking the **"OK"** button, camera recorder is set to white balance adjustment mode.



*Sense = Standard sensitivity


9. Confirm that the white level of signal is about 90 to 105%.
10. Clicking the **"Execute"** button for **White Balance**, the white balance adjustment is executed automatically.
11. When the adjustment is completed, the message **"White Balance Completed!"** is displayed in the STATUS column on the **Adjustment Tool** screen.



2-2-7. ND FILTER Compensation Adjustment

NOTE: Please execute the adjustment to NTSC system.


1. Open the SYSTEM SETUP screen and set the item "**SYSTEM MODE**" to "**1080/59.94i**" (MAIN MENU > SYSTEM SETUP > SYSTEM MODE).
2. Connect the WFM to the SDI OUT1 with 75ohm termination.
3. Connect the VIDEOI OUT to Monitor TV.
4. Shoot a halogen lamp. Bring a lamp close to a lens and set illumination as 10,000 to 15,000lux.
5. Set the **ND FILTER** switch to "**1**" position.
6. Select "**CAM(C)**" section after start up the PC EVR software, and click "**OK**" button.
7. Select "**Adjustment Tool**" in "**Tools(W)**" menu, **Adjustment Tool** screen will appear on screen.
8. Clicking the "**AWB->ABB->AWB**" button for **ND Filter Adjustment**, execute **AWB** → **ABB** → **AWB**.
9. The message "**Enable ND Filter Adjustment!**" is displayed in the STATUS column on the **Adjustment Tool** screen. The "**Start**" button becomes valid.
10. Set the **ND FILTER** switch to "**2**" position.
11. Confirm that the white level of Y signal is around 70%.
12. Clicking the "**Start**" button for **ND Filter1**, the camera recorder is set to ND Filter1 adjustment mode.
13. Adjust location of vector dot by clicking the adjustment button for **ND Filter1** so that the vector dot is located at the zero point in the vector (It adjusts use an adjustment button of R and Bch.).



14. Confirm that there is no colored on Monitor TV.
15. Click the "**Set**" button for **ND Filter1** to end of ND Filter1 adjustment mode. The adjusted value is saved in EEPROM.

NOTE: Please use to standard lens. If the white level of Y signal is not around 70%, adjust IRIS of lens manually so that the white level becomes around 70%. Do not open the IRIS over F5.6-1/2 during this adjustment.

16. Set the **ND FILTER** switch to "**3**" position.
17. Clicking the "**Start**" button for **ND Filter2**, the camera recorder is set to ND Filter2 adjustment mode.
18. Confirm that the white level of Y signal is around 70%.
19. Adjust location of vector dot by clicking the adjustment button for **ND Filter2** so that the vector dot is located at the zero point in the vector (It adjusts use an adjustment button of R and Bch.).



20. Confirm that there is no colored on Monitor TV.

21. Click the **"Set"** button for **ND Filter2** to end of ND Filter2 adjustment mode. The adjusted value is saved in EEPROM.


NOTE: Please use to standard lens. If the white level of Y signal is not around 70%, adjust IRIS of lens manually so that the white level becomes around 70%. Do not open the IRIS over F5.6-1/2 during this adjustment.

22. Set the **ND FILTER** switch to **"4"** position.

23. Clicking the **"Start"** button for **ND Filter3**, the camera recorder is set to ND Filter3 adjustment mode.

24. Confirm that the white level of Y signal is around 70%.


25. Adjust location of vector dot by clicking the adjustment button for **ND Filter3** so that the vector dot is located at the zero point in the vector (It adjusts use an adjustment button of R and Bch.).



26. Confirm that there is no colored on Monitor TV.

27. Click the **"Set"** button for **ND Filter3** to end of ND Filter3 adjustment mode. The adjusted value is saved in EEPROM.

NOTE: Please use to standard lens. If the white level of Y signal is not around 70%, adjust IRIS of lens manually so that the white level becomes around 70%. Do not open the IRIS over F4 during this adjustment.



SECTION 4


BLOCK DIAGRAMS ブロック図

品番/Model No.: AG-HPX375, AG-HPX370P, AG-HPX371E
AG-HPX372EN, AG-HPX373MC, AG-HPX374ER


CONTENTS

OVERALL BLOCK DIAGRAM.....	BLK-1
CAMERA BLOCK DIAGRAM.....	BLK-2
CODEC BLOCK DIAGRAM	BLK-3
AUDIO BLOCK DIAGRAM.....	BLK-4
POWER BLOCK DIAGRAM.....	BLK-5

OVERALL BLOCK DIAGRAM




CAMERA BLOCK DIAGRAM




[illegible]

AUDIO BLOCK DIAGRAM



BLK-5




SECTION 5

SCHEMATIC DIAGRAMS

回路図

品番/Model No.: AG-HPX375, AG-HPX370P, AG-HPX371E
AG-HPX372EN, AG-HPX373MC, AG-HPX374ER



NOTE:
BE SURE TO MAKE YOUR ORDERS OF REPLACEMENT PARTS ACCORDING TO PARTS LIST SECTION.

CAUTION

THE  MARK INDICATES THE PRIMARY CIRCUIT TO DISTINGUISH THE PRIMARY FROM THE SECONDARY CIRCUIT.
PAY ATTENTION NOT TO RECEIVE AN ELECTRIC SHOCK DURING REPAIR AND SERVICE OF THE PRODUCTS.

IMPORTANT SAFETY NOTICE:
COMPONENTS IDENTIFIED WITH THE MARK  HAVE THE SPECIAL CHARACTERISTICS FOR SAFETY.
WHEN REPLACING ANY OF THESE COMPONENTS, USE ONLY THE SAME TYPE.

警告

 の部品は、安全上重要な部品です。
交換するときは、安全及び性能維持のため、必ず指定の部品をご使用ください。
部品は難燃性や耐電圧など、安全上の特性を持ったものとなっていますので、部品交換は、使用されているものと同じ特性の部品をご使用ください。
部品ご注文の際には必ず部品リストに記載の品番でご注文ください。

警告



AC100Vの加わっている
活電部(充電部、活電部)
に直接触れないでくだ
さい。
感電注意
感電ややけどの可能性
があります。

①

警告

 の部品は安全上重要な部品です。
交換するときは、安全上および性能維持のため
必ず指定の部品をご使用ください。

②

 内は充電部です。AC 100Vが加わっておりますので点検、修理
のときは感電しないよう充分ご注意ください。

③

部品交換時には、電源プラグをぬいてから行ってください。

④

一次側(充電部)の電圧・波形は、一次側アースを基準に測定して
ください。

⑤

部品品番は、部品リストで確認の上交換ください。

The positions of parts on the schematic diagrams can be searched.
When the search function of Adobe Acrobat is used, the character of
specified part is displays as highlight.

回路図上の部品位置を検索することが出来ます。
PDFの検索機能を使用すると、指定したREF No.がハイライト表示されます。

注意: 以下の回路図につきましては、検索機能はありません。
NOTE: The search function dose note work with the following
schematic diagrams.
・ POS SENSOR

CONTENTS

INTERCONNECTION

INTERCONNECTION (1/1)	SCM001
-----------------------	--------

DIGITAL MAIN

SENSOR CON (1/38)	SCM002
ARIA 1 (2/38)	SCM003
ARIA 2 (3/38)	SCM004
ARIA 3 (4/38)	SCM005
ARIA MEM (5/38)	SCM006
CAM UCOM (6/38)	SCM007
LENS I/F (7/38)	SCM008
DM FPGA (8/38)	SCM009
GEN LOCK (9/38)	SCM010
CLK BUF (10/38)	SCM011
SDI OUT (11/38)	SCM012
VBS OUT (12/38)	SCM013
EVF I/F (13/38)	SCM014
LCD I/F (14/38)	SCM015
AERO 1 (15/38)	SCM016
AERO 2 (16/38)	SCM017
AERO 3 (17/38)	SCM018
AERO MEM (18/38)	SCM019
FRM LOCK (19/38)	SCM020
ZION 1 (20/38)	SCM021
ZION 2 (21/38)	SCM022
ZION MEM (22/38)	SCM023
IEEE1394 (23/38)	SCM024
LTC (24/38)	SCM025
CPU (25/38)	SCM026
CPU MEM (26/38)	SCM027
USB DEVICE (27/38)	SCM028
USB HOST (28/38)	SCM029
PCI I/F (29/38)	SCM030
AUDIO I/F (30/38)	SCM031
POWER CON (31/38)	SCM032
SIDE CON (32/38)	SCM033
JIGU CON (33/38)	SCM034
EXT I/F (34/38)	SCM035
CAM1 FPGA (35/38)	SCM036
CAM2 FPGA (36/38)	SCM037
CAM2 FPGA (MEM) (37/38)	SCM038
CAM3 FPGA (38/38)	SCM039

MOS_SENSOR

MOS_SENSOR (1/1)	SCM040
------------------	--------

AUDIO

INPUT (1/6)	SCM041
CHSEL/HPF (2/6)	SCM042
VR (3/6)	SCM043
AGC/LIM (4/6)	SCM044
AD/DA (5/6)	SCM045
CONNECTOR (6/6)	SCM046

POWER MAIN

POWER MAIN (1/4)	SCM047
POWER MAIN (2/4)	SCM048
POWER MAIN (3/4)	SCM049
POWER MAIN (4/4)	SCM050

POWER SUB

POWER SUB (1/2)	SCM051
POWER SUB (2/2)	SCM052

P2CARD

CONNECTOR (1/3)	SCM053
CARD I/F (2/3)	SCM054
LAN I/F (3/3)	SCM055

SDCARD

CARD I/F (1/1)	SCM056
----------------	--------

RSIDE1

CONNECTOR (1/4)	SCM057
P/S (2/4)	SCM058
SW (3/4)	SCM059
P-ON/OFF (4/4)	SCM060

RSIDE2

CONNECTOR (1/3)	SCM061
SW (2/3)	SCM062
P/S (3/3)	SCM063

LCD_IF

LCD_IF (1/1)	SCM064
--------------	--------

POWER_SW

POWER_SW (1/1)	SCM065
----------------	--------

TOGGLE_SW

TOGGLE_SW (1/1)	SCM066
-----------------	--------

MENU

MENU (1/1)	SCM067
------------	--------

FRONT_SW

FRONT_SW (1/1)	SCM068
----------------	--------

REC_BUTTON

REC_BUTTON (1/1)	SCM069
------------------	--------

FRONT_MIC

FRONT_MIC (1/1)	SCM070
-----------------	--------

POS_SENSOR

POS_SENSOR (1/1)	SCM071
------------------	--------

RELAY

RELAY (1/1)	SCM072
-------------	--------

EVF_IF

EVF_IF (1/1)	SCM073
--------------	--------

EVF_TALLY

EVF_TALLY (1/1)	SCM074
-----------------	--------

EVF_U_FPC

EVF_U_FPC (1/1)	SCM075
-----------------	--------

USB_CN

USB_CN (1/1)	SCM076
--------------	--------

1394_CN

1394_CN	SCM077
---------	--------

LSIDE_JACK

LSIDE_JACK (1/1)	SCM078
------------------	--------

REAR_JACK

REAR_JACK (1/1)	SCM079
-----------------	--------

PHONE_CN

PHONE_CN (1/1)	SCM080
----------------	--------

BATT_IF

BATT_IF (1/1)	SCM081
---------------	--------

DC_INPUT


DC_INPUT (1/1)	SCM082
----------------	--------





HANDLE_SW

HANDLE_SW (1/1)	SCM083
-----------------	--------


HANDLE_TALLY

HANDLE_TALLY (1/1)	SCM084
--------------------	--------






CIRCUIT NAME	SENSOR CON		1/38
CIRCUIT BOARD NAME	DIGITAL MAIN	DRAWING NO.	
CIRCUIT BOARD NO.	VEB0882A/VEP03H88A	KR3A 1373 (1/38)	
		SCM002	




1
2
3
4
5
6
7
8


A B C D E F G H I J K L



CIRCUIT NAME	ARIA ☐	4/38
CIRCUIT BOARD NAME	DIGITAL MAIN	DRAWING NO. KR3A 1373 (4/38)
CIRCUIT BOARD NO.	VEB0882A/VEP03H88A	SCM000






uCOM/FPGA → LENS




CIRCUIT NAME	LENS I 		7/38
CIRCUIT BOARD NAME	DIGITAL MAIN	DRAWING NO. KR3A1373 (7/38)	
CIRCUIT BOARD NO.	VEB0882A/VEP03H88A		SCM00 

12




	RATE_SEL11	RATE_SEL10
SD 270M	0	1
HD 1.5G	0	0
HD 3G	1	X


CIRCUIT NAME	SDI O T		11/38
CIRCUIT BOARD NAME	DIGITAL MAIN	DRAWING NO.	8
CIRCUIT BOARD NO.	VEB0882A/VEP03H88A	KR3A1373 (11/38)	
		SCM02	



CIRCUIT NAME	E□□□□□		13/38
CIRCUIT BOARD NAME	DIGITAL MAIN	DRAWING NO.	
		KR3A1373 (13/38)	
CIRCUIT BOARD NO.	VEB0882A/VEP03H88A		SCM0□□





CIRCUIT NAME	AERO		15/38
CIRCUIT BOARD NAME	DIGITAL MAIN		DRAWING NO.
CIRCUIT BOARD NO.	VEB0882A/VEP03H88A		KR3A1373 (15/38)
			SCM0




CIRCUIT NAME	AERO 2		16/38
CIRCUIT BOARD NAME	DIGITAL MAIN		DRAWING NO.
CIRCUIT BOARD NO.	VEB0882A/VEP03H88A		KR3A1373 (16/38)
			SCM0


A B C D E F G H I J K L M N O P



CIRCUIT NAME	AERO MEM		18/38
CIRCUIT BOARD NAME	DIGITAL MAIN	DRAWING NO.	8
		KR3A1373 (18/38)	
CIRCUIT BOARD NO.	VEB0882A/VEP03H88A		SCM0 ☐




CIRCUIT NAME		ION MEM	22/38
CIRCUIT BOARD NAME		DRAWING NO.	
CIRCUIT BOARD NO.		KR3A1373 (22/38)	
CIRCUIT BOARD NO.		VEB0882A/VEP03H88A	
CIRCUIT BOARD NO.		SCM02	




CIRCUIT NAME	LTC		24/38
CIRCUIT BOARD NAME	DIGITAL MAIN		DRAWING NO.
CIRCUIT BOARD NO.	VEB0882A/VEP03H88A		KR3A1373 (24/38)
			SCM02

A B C D E F G H I J K L M N O P

1 2 3 4 5 6 7 8 9 10 11 12





CIRCUIT NAME	C□ MEM		26/38
CIRCUIT BOARD NAME	DIGITAL MAIN		DRAWING NO.
CIRCUIT BOARD NO.	VEB0882A/VEP03H88A		KR3A1373 (26/38)
			SCM02□

A B C D E F G H I J K L M N O P □

1

2

3

4

5

6

7



8

9

10

11

12




CIRCUIT NAME	DIGITAL MAIN		2/38
CIRCUIT BOARD NAME	VEB0882A/VEP03H88A		DRAWING NO. KR3A1373 (2/38)
CIRCUIT BOARD NO.	VEB0882A/VEP03H88A		SCM00

A B C D E F G H I J K L


SDI IN


CN3401
K1K470A00051
WR-705-VEP03H88-R1000




CIRCUIT NAME	EIT I 34/38	
CIRCUIT BOARD NAME	DIGITAL MAIN	DRAWING NO.
CIRCUIT BOARD NO.	VEB0882A/VEP03H88A	KR3A1373 (34/38)
		SCM0

D E F G H I J K L








CIRCUIT NAME	CAM2 GA MEM		37/38
CIRCUIT BOARD NAME	DIGITAL MAIN		DRAWING NO.
CIRCUIT BOARD NO.	VEB0882A/VEP03H88A		KR3A1373 (37/38)
			SCM0





CIRCUIT NAME	MOS SENSOR		1/1
CIRCUIT BOARD NAME	MOS SENSOR		DRAWING NO.
CIRCUIT BOARD NO.	VEP22411A		KR3A13C51 (1/1)
			SCM00




CIRCUIT NAME	INOUT		1/6
CIRCUIT BOARD NAME	ADIO		DRAWING NO.
CIRCUIT BOARD NO.	VEP0444A		KR4A0361 (1/6)
			SCM00




CIRCUIT NAME	CSEL			2/6
CIRCUIT BOARD NAME	ADIO		DRAWING NO.	
CIRCUIT BOARD NO.	VEP044A		KR4A0361 (2/6)	
			SCM02	



CIRCUIT NAME	☐ R	3/6	J
CIRCUIT BOARD NAME	A ☐ DIO	DRAWING NO.	
CIRCUIT BOARD NO.	VEP04 ☐ 44A	KR4A0361 ☐ (3/6)	K
		SCM0 ☐	






CIRCUIT NAME	AGC LIM		4/6
CIRCUIT BOARD NAME	A DIO	DRAWING NO. KR4A0361 (4/6)	
CIRCUIT BOARD NO.	VEP044A		SCM0



CIRCUIT NAME	ADIDA		5/6
CIRCUIT BOARD NAME	AADIO	DRAWING NO.	
CIRCUIT BOARD NO.	VEP0444A	KR4A0361 (5/6)	12
		SCM0	



A B C D E F G H I J K L M N O P





CIRCUIT NAME	☐ ☐ ER MAIN		1/4
CIRCUIT BOARD NAME	☐ ☐ ER MAIN	DRAWING NO. KR1A0558 (1/4)	
CIRCUIT BOARD NO.	VEP01A18B	SCM0 ☐ ☐	

V.S1 UNREG1



警告

△印の部品は安全上重要な部品です。交換するときは、安全および性能維持のため必ず指定の部品をご使用ください。


Components identified with the mark △ have the special characteristics for safety. When replacing any of these components, use only the same type.

PAT=PATTERN ONLY
Ref No.1201~1299 Series.

CIRCUIT NAME	□○ ER MAIN	2/4
CIRCUIT BOARD NAME	□○ ER MAIN	DRAWING NO.
CIRCUIT BOARD NO.	VEP01A18B	KR1A0558 (2/4)
		SCM0□

B C D E F G H I J K L M N O


2
3
4
5
6
7
8
10
11



PAT=PATTERN ONLY
Ref No.1301~1399 Series.

CIRCUIT NAME	ER MAIN	3/4
CIRCUIT BOARD NAME	ER MAIN	DRAWING NO.
CIRCUIT BOARD NO.	VEP01A18B	KR1A0558 (3/4)
		SCM0


7-UI 1 GI



PAT=PATTERN ONLY
Ref No.1401~1499 Series.

CIRCUIT NAME	ER MAIN	4/4
CIRCUIT BOARD NAME	ER MAIN	DRAWING NO.
CIRCUIT BOARD NO.	VEP01A18B	KR1A0558 (4/4)
		SCM00




A B C D E F G H I J K L M N O P



警告


△印の部品は安全上重要な部品です。交換するときは、安全および性能維持のため必ず指定の部品をご使用ください。

Components identified with the mark △ have the special characteristics for safety. When replacing any of these components, use only the same type.



CIRCUIT NAME	□□ ER S□□	1/2
CIRCUIT BOARD NAME	□□ ER S□□	DRAWING NO. KR1A055□ (1/2)
CIRCUIT BOARD NO.	VEP01A1□B	SCM0□□

B C D E F G H I J K L M N O P




CIRCUIT NAME		00ERS
CIRCUIT BOARD NAME		00ER S
C COT		VEP01A1B
-O- RD NO.		

D-ADMIN NO		2/2
KRTA055		(2/2)
SCM00		2


A B C D E F G H K

1 2 3 4 5 6 7 8




CIRCUIT NAME	CONNECTOR		1/3
CIRCUIT BOARD NAME	2CARD	DRAWING NO.	
CIRCUIT BOARD NO.		KR3A1027 (1/3)	
	VEP03H6A	SCM0	

A B C D E F G H I J K L M N O P




CIRCUIT NAME	CARD I		2/3
CIRCUIT BOARD NAME	2CARD	DRAWING NO.	
		KR3A1027 (2/3)	
CIRCUIT BOARD NO.	VEP03H6A		SCM0



CIRCUIT NAME	LAN	o/p
CIRCUIT NO.	2CARD	D=AWIN NO.
CARD NAME	VEP0 H6A	KR3A1027 (3/3)
CARD NO.	SCM0	

D E F G H I J K L M N O P



CIRCUIT NAME	CARD I		1/1
CIRCUIT BOARD NAME	SDCARD	DRAWING NO.	
CIRCUIT BOARD NO.	VEP0013B	KR0A0874 (1/1)	
		SCM0	

A


B

C





D

E


F





CIRCUIT NAME	☐ S	2/4
CIRCUIT BOARD NAME	RSIDE ☐	DRAWING NO.
CIRCUIT BOARD NO.	VEP001 ☐ 7B	KR0A0878:2 (2/4)
		SCM0 ☐



CIRCUIT NAME	S		3/4
CIRCUIT BOARD NAME	RSIDE		DRAWING NO.
CIRCUIT BOARD NO.	VEP0017B		KR0A08782 (3/4)
			SCM0








CIRCUIT NAME	LCD□□		1/1
	LCD□□		DRAWING NO.
	VEP08357B		KR8A00□3 (1/1)
CIRCUIT BOARD NO.	VEP08357B		SCM0□□

CN601
K1KA02B00157
DF13A-2P-1.25H (51)

SW601
K0E112G00033





CIRCUIT NAME	□ O □ E R □ S □	1/1
CIRCUIT BOARD NAME	□ O □ E R □ S □	DRAWING NO.
CIRCUIT BOARD NO.	VEP001 □ 4B	KR0A0885 (1/1)
		SCM0 □ □


C

D

E




CIRCUIT NAME	TOGGLE ☐ ☐		1/1
CIRCUIT BOARD NAME	TOGGLE ☐ ☐	DRAWING NO. KR0A088212 (1/1)	
CIRCUIT BOARD NO.	VEP0011B	SCM0 ☐	



CIRCUIT NAME	RONT S		1/1
CIRCUIT BOARD NAME	RONT S	DRAWING NO.	
CIRCUIT BOARD NO.	VEP001 5B	KR0A087612 (1/1)	
		SCM0	

JK1
K1AA104H0038
HA16RX-4P (SW1) (76)



C
NO
NC



D1
B0EAKR000059
S3V60-7000



J3
JP-OTHER



J1
JP-OTHER



J2
JP-OTHER



J4
JP-OTHER

CIRCUIT NAME	DC IN OUT		1/1
CIRCUIT BOARD NAME	DC IN OUT	DRAWING NO.	
CIRCUIT BOARD NO.	VEP01A20B	KR1A04142 (1/1)	
		SCM02	


C

D

E


3

4



CIRCUIT NAME	ATT		1/1
CIRCUIT BOARD NAME	ATT	DRAWING NO.	
CIRCUIT BOARD NO.	VEP0015B	KR0A08862 (1/1)	
		SCM0	

JK421
K2HC103B0202
HSJ0927-0160209



CIRCUIT NAME	ONE CN	1/1
CIRCUIT BOARD NAME	ONE CN	DRAWING NO.
CIRCUIT BOARD NO.	VEP0447B	KR4A03642 (1/1)
		SCM00

B

C


D

E

F

to CODEC_MOTHER

CN611
K1KA02A00164
DF13C-2P-1.25V(51)



REC

SW611
KOH1BA000503

DGND

R612
DGND

0
1.6 x 0.8

ZJ611
FRAME-GND

R613
DGND

0
1.6 x 0.8

ZJ612
FRAME-GND

CIRCUIT NAME	REC□□□TTON		1/1
CIRCUIT BOARD NAME	REC□□□TTON	DRAWING NO.	
CIRCUIT BOARD NO.	VEP001□6B	KR0A0877□2 (1/1)	
		SCM0□□	

1

2

3

4




B

C


D

E

F



CIRCUIT NAME	☐ RONT ☐ MIC	1/1
CIRCUIT BOARD NAME	☐ RONT ☐ MIC	DRAWING NO.
CIRCUIT BOARD NO.	VEP0446B	KR4A03632 (1/1)
		SCM000




PAT=PATTERN ONLY

CIRCUIT NAME	OS SENSOR		1/1
CIRCUIT BOARD NAME	OS SENSOR	DRAWING NO.	
CIRCUIT BOARD NO.	VEP80D27A	KR 0A0243 (1/1)	
		SCM0	



CN13
K1MN30BA0059
FH12-30S-0.5SH(78)

TOP VIEW



IMSA-9850B-20Y914
K1KY20BA0135
CN11

CN12
K1K11B00052
DF13A-11P-1.25H(51)



CIRCUIT NAME	RELA	1/1
CIRCUIT BOARD NAME	RELA	DRAWING NO.
CIRCUIT BOARD NO.	VEP00108B	KR0A08702 (1/1)
		SCM02

A

B

C

D

E

F

G

H

1


2



3

4

5

6







△印の部品は安全上重要な部品です。交換するときは、安全および性能維持のため必ず指定の部品をご使用ください。


Components identified with the mark △ have the special characteristics for safety. When replacing any of these components, use only the same type.

CIRCUIT NAME	□□□□CN	1/1
CIRCUIT BOARD NAME	□□□□CN	DRAWING NO.
CIRCUIT BOARD NO.	VEP001□4B	KR0A0875□2 (1/1)
		SCM0□□




CIRCUIT NAME	ANDLES	1/1
CIRCUIT BOARD NAME	ANDLES	DRAWING NO.
CIRCUIT BOARD NO.	VEP0016B	KR0A08872 (1/1)
		SCM0

CN9100
K1KA02B00157
DF13A-2P-1.25H(51)



SW9100
K0E122A00036
FT2D-22M-Z



R9100
1/8W
2.0 x 1.2
0
R9101
1/8W
2.0 x 1.2
0

D9100
B3AAA0000984
TLRMH30MP (QR, F)

CIRCUIT NAME	☐ ANDLE ☐ TALL	1/1
CIRCUIT BOARD NAME	☐ ANDLE ☐ TALL	DRAWING NO.
CIRCUIT BOARD NO.	VEP001 ☐ 7B	KR0A0888 ☐ 2 (1/1)
		SCM0 ☐

D

E

F

G

2

3

4

SECTION 6

PRINTED CIRCUIT BOARD

プリント基板図

品番/Model No.: AG-HPX375, AG-HPX370P, AG-HPX371E
AG-HPX372EN, AG-HPX373MC, AG-HPX374ER

注意: 本セクションには、主要基板のみ記載しています。
NOTE: Only the main circuit board is shown in this section.

基板図上の部品位置を検索することが出来ます。
PDF の検索機能を使用すると、指定した REF No. がハイライト表示されます。

The positions of parts on the circuit board diagrams can be searched.
When the search function of Adobe Acrobat is used, the character of specified part is displays as highlight.

NOTE:
BE SURE TO MAKE YOUR ORDERS OF REPLACEMENT PARTS ACCORDING TO PARTS LIST SECTION.

CAUTION

THE  MARK INDICATES THE PRIMARY CIRCUIT TO DISTINGUISH THE PRIMARY FROM THE SECONDARY CIRCUIT.
PAY ATTENTION NOT TO RECEIVE AN ELECTRIC SHOCK DURING REPAIR AND SERVICE OF THE PRODUCTS.

IMPORTANT SAFETY NOTICE:
COMPONENTS IDENTIFIED WITH THE MARK  HAVE THE SPECIAL CHARACTERISTICS FOR SAFETY.
WHEN REPLACING ANY OF THESE COMPONENTS, USE ONLY THE SAME TYPE.

警告

 の部品は、安全上重要な部品です。
交換するときは、安全及び性能維持のため、必ず指定の部品をご使用ください。
部品は難燃性や耐電圧など、安全上の特性を持ったものとなっていますので、部品交換は、使用されているものと同じ特性の部品をご使用ください。
部品ご注文の際には必ず部品リストに記載の品番でご注文ください。

警告



感電注意

AC100Vの加わっている
充電部(充電部、充電部)
に直接触れないでください。
感電ややけどの可能性
があります。

① 警告


 印の部品は安全上重要な部品です。
交換するときは、安全上および性能維持のため
必ず指定の部品をご使用ください。

- ②  内は充電部です。AC 100Vが加わっておりますので点検、修理のときは感電しないよう充分ご注意ください。
- ③ 部品交換時には、電源プラグをぬいてから行ってください。
- ④ 一次側(充電部)の電圧・波形は、一次側アースを基準に測定してください。
- ⑤ 部品品番は、部品リストで確認の上交換ください。

CONTENTS

DIGITAL MAIN P.C.BOARD (FOIL SIDE).....	PCB-1
DIGITAL MAIN P.C.BOARD (COMPONENT SIDE)	PCB-2
MOS_SENSOR P.C.BOARD (FOIL SIDE)	PCB-3
MOS_SENSOR P.C.BOARD (COMPONENT SIDE).....	PCB-4
AUDIO P.C.BOARD (FOIL SIDE)	PCB-5
AUDIO P.C.BOARD (COMPONENT SIDE).....	PCB-6
POWER MAIN P.C.BOARD (FOIL SIDE)	PCB-7
POWER MAIN P.C.BOARD (COMPONENT SIDE).....	PCB-8
POWER SUB P.C.BOARD (FOIL SIDE).....	PCB-9
POWER SUB P.C.BOARD (COMPONENT SIDE)	PCB-10
P2CARD P.C.BOARD (FOIL SIDE)	PCB-11
P2CARD P.C.BOARD (COMPONENT SIDE).....	PCB-12
RSIDE1 P.C.BOARD (FOIL SIDE).....	PCB-13
RSIDE1 P.C.BOARD (COMPONENT SIDE)	PCB-14
RSIDE2 P.C.BOARD (FOIL SIDE).....	PCB-15
RSIDE2 P.C.BOARD (COMPONENT SIDE)	PCB-16
LCD_IF P.C.BOARD (FOIL SIDE)	PCB-17
LCD_IF P.C.BOARD (COMPONENT SIDE).....	PCB-17
FRONT_MIC P.C.BOARD (FOIL SIDE).....	PCB-18
FRONT_MIC P.C.BOARD (COMPONENT SIDE)	PCB-18
EVF_IF P.C.BOARD (COMPONENT SIDE)	PCB-19
REAR_JACK P.C.BOARD (FOIL SIDE).....	PCB-20
REAR_JACK P.C.BOARD (COMPONENT SIDE).....	PCB-21

DIGITAL MAIN P.C.BOARD (FOIL SIDE)





警告

△印の部品は安全上重要な部品です。交換するときは、安全および性能維持のため必ず指定の部品をご使用ください。

Components identified with the mark △ have the special characteristics for safety. When replacing any of these components, use only the same type.

DIGITAL MAIN P.C.BOARD (COMPONENT SIDE)




警告

△印の部品は安全上重要な部品です。交換するときは、安全および性能維持のため必ず指定の部品をご使用ください。


Components identified with the mark △ have the special characteristics for safety. When replacing any of these components, use only the same type.

PCB-2


MOS SENSOR MAIN P.C.BOARD (FOIL SIDE)




MOS SENSOR MAIN P.C.BOARD (COMPONENT SIDE)




AUDIO P.C.BOARD (FOIL SIDE)





AUDIO P.C.BOARD (COMPONENT SIDE)



POWER MAIN P.C.BOARD (FOIL SIDE)



POWER MAIN P.C.BOARD (COMPONENT SIDE)




△印の部品は安全上重要な部品です。交換するときは、安全および性能維持のため必ず指定の部品をご使用ください。

Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.


PCB-8

The floor plan depicts a complex building layout. On the left side, there is a large circular area, possibly a courtyard or a large room. Adjacent to it is a long, narrow rectangular area containing several smaller rectangular units. The central part of the plan features a large rectangular area with a central circular feature and a north arrow pointing towards the top right. To the right of this central area, there are several rectangular rooms, some of which are labeled 'TOP' and 'FPC/PFC'. The bottom right corner shows a large circular area and a rectangular area with a north arrow pointing towards the top right. The plan includes numerous small circles and lines representing structural details and corridors.




Components identified with the mark have the special characteristics for safety. When replacing any of these components, use only the same type.


P2CARD P.C.BOARD (FOIL SIDE)




P2CARD P.C.BOARD (COMPONENT SIDE)



RSIDE1 P.C.BOARD (COMPONENT SIDE)




RSIDE2 P.C.BOARD (FOIL SIDE)




[illegible]

LCD_IF P.C.BOARD

(FOIL SIDE)




(COMPONENT SIDE)




FRONT_MIC P.C.BOARD


(FOIL SIDE)




(COMPONENT SIDE)




EVF_IF P.C.BOARD (COMPONENT SIDE)



REAR_JACK P.C.BOARD (FOIL SIDE)



REAR_JACK P.C.BOARD (COMPONENT SIDE)



SECTION 7

EXPLODED VIEWS & REPLACEMENT PARTS LIST

Model No. : AG-HPX370P, AG-HPX371E, AG-HPX372EN
AG-HPX373MC, AG-HPX374ER

Note:


1. *Be sure to make your orders of replacement parts according to this list.
2. Unless otherwise specified, all resistors are in OHMS, K=1,000 OHMS, all capacitors are in MICROFARADS (μF) $P=\mu\mu F$.
3. The P.C.Board unit marked with "■" shown below the main assembled parts.
4. The parts marked with Ⓔ on the exploded view show the electric parts.
5. IMPORTANT SAFETY NOTICE
Components identified with the mark ⚠ have the special characteristics for safety When replacing any of these components, use only the same type.
6. The marking (RTL) indicates the retention time is limited for this item.
After the discontinuation of this assembly in production, it will no longer be available.
7. "M" in Remark column indicates needed in the periodical maintenance.

CONTENTS

FRONT CASE PARTS ASSEMBLY	MPL-1
MAIN FRAME PARTS ASSEMBLY	MPL-3
SIDE CASE L PARTS ASSEMBLY	MPL-5
LCD PARTS ASSEMBLY	MPL-7
SIDE CASE R PARTS ASSEMBLY	MPL-9
REAR JACK & HANDLE PARTS ASSEMBLY	MPL-11
EVF PARTS ASSEMBLY	MPL-13
PACKING PARTS ASSEMBLY	MPL-15
ELECTRICAL REPLACEMENT PARTS LIST	EPL-1

FRONT CASE PARTS ASSEMBLY

Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.



Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
1	VGM2293	FRONT CASE	1	
2	VXU1620	RUBBER BUTTON ASS'Y	1	
3	VGU8346	RUBBER BUTTON	1	
4	VMX3299	RUBBER BUTTON SPACER	1	
5	VJF1256	CABLE CLAMPER	2	
6	VMC1210	FRONT DOOR SPRING	1	
7	VMP4850	FRONT DOOR ANGLE	1	
8	VMS4088	FRONT DOOR ANGLE PIN	1	
9	VKF2485	FRONT DOOR	1	
10	VMG0832	SHIELD TUBE	1	
11	VMG1877	SHIELD GASKET	1	
12	VMX1312	POLY WASHER	2	
13	VMG1140	RAIN COVER SPONGE	2	
14	VMF1432	WATERPROOF CUSHION	2	
15	VGU0098	ND FILTER DIAL	1	
16	VHD1950	MOUNT ANGLE	4	
17	VSC6153	SHADING COVER A	1	
18	VEE1F65	LVDS MOS CABLE	3	
19	VEE1F30	FRONT CABLE	1	
20	VSC6125	SHIELD CASE	1	
21	VYQ5616	HEAD OPTICAL U	1	
22	VDW1737	LENS MOUNT RING	1	
23	VMD6009	LENS GUIDE	1	
24	VDS0168	COVER DISK	1	
25	VKF2726	MOUNT CAP	1	
26	VEQ4570	CAMERA U	1	
27	VYK3F17	FRONT CASE U	1	
101	XYN2+J4FJ	SCREW	1	
102	XSB2+6FJK	SCREW	2	
103	XYN2+J6FJ	SCREW	4	
104	XYN2+J5FJ	SCREW	8	
105	XQN2+B6FJK	SCREW	3	
106	XQN2+A4FJK	SCREW	3	
107	XYN2+J5FJ	SCREW	6	
108	XSB3+8FJK	SCREW	4	
E14	VEP001Y5B	FRONT SW P.C. BOARD	1	
E19	VEP80D27A	POSITION SENSOR P.C. BOARD	1	
E20	VEP001Y6B	REC BUTTON P.C. BOARD	1	


[illegible]

Components identified with the mark have the special characteristics for safety. When replacing any of these components, use only the same type.



SIDE CASE L PARTS ASSEMBLY

Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.




SIDE CASE L PARTS ASSEMBLY

Components identified with the mark have the special characteristics for safety. When replacing any of these components, use only the same type.

[illegible]


LCD PARTS ASSEMBLY



[illegible]

SIDE CASE R PARTS ASSEMBLY

Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.




SIDE CASE R PARTS ASSEMBLY

Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
1	VYP9276	SIDE CASE R IU	1	
2	VEK0N93	SPEAKER U	1	
3	VYF3258	P2 DOOR U	1	
4	VGU0B30	MODE SW KNOB	1	
5	VGJ9301	VR KNOB FRONT	1	
6	VGH4948	VF LABEL	1	
7	VGJ9303	VR KNOB	1	
8	VMP9344	SP HOLD FRAME	1	
9	VMG0646	WATERPROOF SW INSULATION SH	4	
10	VMT1494	WATERPROOF CUSHION	4	
11	VMX1312	POLY WASHER	4	
12	VMX0531	CLATCH SPACER	1	
13	VHN0382	NYLON NUT	1	
14	VKW3407	CARD DOOR WINDOW	1	
15	VMF0585	TAPE	1	
16	VMT1961	P2 DOOR CUSHION	1	
17	VMP9346	P2 DOOR FRAME	1	
18	VMS7987	P2 DOOR SHAFT	1	
19	VGH4633	MODE SELECT NAME PLATE	1	
20	VGH4680	VR NAME PLATE	1	
21	VGU8130	SLIDE SW COVER	4	
22	VMG1195	SLIDE SW RUBBER	4	
23	VMP5578	SLIDE SW ANGLE	1	
24	VGUD067	OPERATION BUTTON R	1	
25	VGL1228	LED PANEL LIGHT	2	
26	VYQ3999	HINGE UNIT	1	
27	VGUE43	OPERATION BUTTON F	1	
28	VMD6077	P2 DOOR MAGNET	2	
△ 29	VEE1F29	HEAO PHONE CABLE	1	
△ 30	VEE1F40	R SIDE ICABLE	1	
31	VGH5143	SLIDE KNOB SHEET	6	
32	VMT1884	SLIDE KNOB SPONGE	6	
33	VGUOB27	RUBBER BUTTON B	1	
34	VGP6264	FACE PAD	1	
35	VMT1896	FPC HOLD CUSHION	1	
36	VGH5095	FILTER PLATE	1	
37	VJF1583	CABLE CLAMP	1	
101	XYN2+JGFJK	SCREW	21	
102	XQN2+A2FJK	SCREW	1	
103	XSB2+GFJK	SCREW	4	
104	XTB3+8GFJK	SCREW	5	
105	XSB3+8FJK	SCREW	5	
E10	VEP001Y7B	R SIDE 1 P.C.BOARO	1	
E11	VEP001Z2B	R-SIDE 2 P.C.B.OAR	1	
E15	VEP001Z4B	POWER SW P.C. BOA	1	
E17	VEP001Z1B	TOGGLE SW P.C. BOA	1	
E22	VEP001Y9B	MENU P.C. BOARD	1	
E23	VEP04947B	PHONE P.C. BOARD	1	

REAR JACK & HANDLE PARTS ASSEMBLY


Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.



Components identified with the mark have the special characteristics for safety. When replacing any of these components, use only the same type.

[illegible]


EVF PARTS ASSEMBLY



[illegible]

PACKING PARTS ASSEMBLY

Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.



PACKING PARTS ASSEMBLY

Components identified with the mark have the special characteristics for safety. When replacing any of these components, use only the same type.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
1	VFC4148	SHOULDER BELT	1	
2	VPF1016	POLYETHYLENE BAG	1	
3	VGU8322	KNOB	1	
4	XYN2+J6FJK	SCREW	1	
Δ 5	VQT2T24	OPERATING INSTRUCTIONS	1	FOR AG-HPX370P
Δ 5	VQT2T25	OPERATING INSTRUCTIONS	1	FOR AG-HPX371E
Δ 5	VQT2T26	OPERATING INSTRUCTIONS	1	FOR A GHPX372EN
Δ 5	VQT2T27	OPERATING INSTRUCTIONS	1	FOR AG-HPX373MC
Δ 5	VQT2T28	OPERATING INSTRUCTIONS	1	FOR AG-HPX374ER
6	VMG1458	EYE CAP	1	
7	VPG2L18	PACKING CASE	1	FOR A GHPX370P
7	VPG2L20	PACKING CASE	1	FOR AG-HPX371E
7	VPG2L22	PACKING CASE	1	FOR AG-HPX372EN
7	VPG2L23	PACKING CASE	1	FOR AG-HPX373MC
7	VPG2L24	PACKING CASE	1	FOR AG-HPX374ER
8	VPN6818	CUSHION (TOP)	1	
9	VPN6819	CUSHION (BOTTOM)	1	
10	VPN6820	PARTITION	1	
11	VPF1347	POLYETHYLENT BAG	1	
Δ 12	VYQ5622	OPERATING INSTRUCTIONS	1	(CD-R) FOR AG-HPX370P/371E/372EN
Δ 12	VYQ5623	OPERATING INSTRUCTIONS	1	(CD-R) FOR AG-HPX373MC
Δ 12	VYQ5624	OPERATING INSTRUCTIONS	1	(CD-R) FOR AG-HPX374ER
13	VPG1Z14	PACKING CASE	1	FOR AG-HPX373MC

ELECTRICAL REPLACEMENT PARTS LIST

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
■ E1	VEP03H88A	DIGITAL MAIN P.C. BOARD	1	(RTL)	■ E1	VEP03H88A	DIGITAL MAIN P.C. BOARD	1	(RTL)
■ E2	VEP04944A	AUDIO P.C. BOARD	1	(RTL)					
■ E3	VEP01A18B	POWER MAIN P.C. BOARD	1	(RTL)	C105	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
■ E4	VEP01A19B	POWER SUB P.C. BOARD	1	(RTL)	C106, 07	F1J0J106A013	C. CAPACITOR CH6.3V 10U	2	
■ E5	VEP03H69A	P2 CARD P.C. BOARD	1	(RTL)	C108	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
■ E6	VEP001Y3B	SD CARD P.C. BOARD	1	(RTL)	C109	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
■ E7	VEP04945B	REAR JACK P.C. BOARD	1	(RTL)	C140	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
■ E8	VEP001Z5B	BATT IF P.C. BOARD	1	(RTL)	C141, 42	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
■ E9	VEP01A20B	DC IN P.C. BOARD	1	(RTL)	C143	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
■ E10	VEP001Y7B	R SIDE 1 P.C. BOARD	1	(RTL)	C145	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
■ E11	VEP001Z2B	R SIDE 2 P.C. BOARD	1	(RTL)	C147	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
■ E12	VEP001Z3B	L SIDE JACK P.C. BOARD	1	(RTL)	C148	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
■ E13	VEP08357B	LCD IF P.C. BOARD	1	(RTL)	C149, 50	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
■ E14	VEP001Y5B	FRONT SW P.C. BOARD	1	(RTL)	C162-67	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	6	
■ E15	VEP001Z4B	POWER SW P.C. BOARD	1	(RTL)	C168-73	F1H1C105A118	C. CAPACITOR CH 16V 1U	6	
■ E16	VEP001Z6B	HANDLE SW P.C. BOARD	1	(RTL)	C174-82	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	9	
■ E17	VEP001Z1B	TOGGLE SW P.C. BOARD	1	(RTL)	C183-85	F1H1C105A118	C. CAPACITOR CH 16V 1U	3	
■ E18	VEP04946B	F MIC P.C. BOARD	1	(RTL)	C186-91	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	6	
■ E19	VEP80027A	POS SENSOR P.C. BOARD	1	(RTL)	C192-94	F1H1C105A118	C. CAPACITOR CH 16V 1U	3	
■ E20	VEP001Y6B	REC BUTTON P.C. BOARD	1	(RTL)	C195-99	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	5	
■ E21	VEP001Y8B	RELAY P.C. BOARD	1	(RTL)	C200	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
■ E22	VEP001Y9B	MENU P.C. BOARD	1	(RTL)	C201, 02	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
■ E23	VEP04947B	PHONE P.C. BOARD	1	(RTL)	C203-05	F1H1C105A118	C. CAPACITOR CH 16V 1U	3	
■ E24	VEP08361A	EVF IF P.C. BOARD	1	(RTL)	C206-09	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4	
■ E25	VEP001Z7B	HANDLE TALLY P.C. BOARD	1	(RTL)	C210, 11	F1J0J106A013	C. CAPACITOR CH6.3V 10U	2	
■ E26	VEP08359B	EVF TALLY P.C. BOARD	1	(RTL)	C212-14	F1H1C105A118	C. CAPACITOR CH 16V 1U	3	
■ E27	VEP001Z0A	USB CN P.C. BOARD	1	(RTL)	C215	F1H1A225A051	C. CAPACITOR CH 10V 2.2U	1	
■ E28	VEP001Y4B	1394 CN P.C. BOARD	1	(RTL)	C216, 17	F1H1C105A118	C. CAPACITOR CH 16V 1U	2	
					C232	F1J0J106A013	C. CAPACITOR CH6.3V 10U	1	
					C233	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
					C400-04	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	5	
					C405	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
					C406	F1J0J106A013	C. CAPACITOR CH6.3V 10U	1	
					C407-10	F1H1C105A118	C. CAPACITOR CH 16V 1U	4	
					C411-14	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4	
					C415	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
					C416	F1J0J106A013	C. CAPACITOR CH6.3V 10U	1	
					C417-24	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	8	
					C431	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
					C432	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
					C433	F1L1A2260013	C. CAPACITOR CH 10V 22U	1	
					C434-39	F1H1C105A118	C. CAPACITOR CH 16V 1U	6	
					C446	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
					C447-54	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	8	
					C461	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
					C462-69	F1G1H101A565	C. CAPACITOR CH 50V 100P	8	
					C471-77	F1G1H101A565	C. CAPACITOR CH 50V 100P	7	
					C479	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
					C480-82	F1G1H101A565	C. CAPACITOR CH 50V 100P	3	
					C483-87	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	5	
					C488, 89	F1G1H101A565	C. CAPACITOR CH 50V 100P	2	
					C490-95	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	6	
					C496, 97	F1G1H101A565	C. CAPACITOR CH 50V 100P	2	
					C498-00	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3	
					C501	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
					C502	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
					C505	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
					C506	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
					C507-14	F1G1H101A565	C. CAPACITOR CH 50V 100P	8	
					C515-26	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	12	
					C527, 28	F1G1H101A565	C. CAPACITOR CH 50V 100P	2	
					C530-33	F1G1H101A565	C. CAPACITOR CH 50V 100P	4	
					C534, 35	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
					C536, 37	F1G1H101A565	C. CAPACITOR CH 50V 100P	2	
					C539	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
					C541-44	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4	
					C545, 46	F1G1H101A565	C. CAPACITOR CH 50V 100P	2	
					C548-51	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4	
					C553-55	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3	
					C557-65	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	9	
					C600-03	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4	
					C605, 06	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
					C607	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
					C608-14	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	7	
					C615	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks	Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
C616, 17	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	2		C905, 06	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C618-23	FIG1H101A565	C. CAPACITOR CH 50V 100P	6		C907	FIL1A2260013	C. CAPACITOR CH 10V 22U	1	
C624	FIG1C105A118	C. CAPACITOR CH 16V 1U	1		C908	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C627	FIG1H8R0A564	C. CAPACITOR CH 50V 8P	1		C909, 10	FIG1A224A012	C. CAPACITOR CH 10V 0.22U	2	
C628	FIG1H100A565	C. CAPACITOR CH 50V 10P	1		C911-13	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	3	
C629	FIG1H101A565	C. CAPACITOR CH 50V 100P	1		C914	FIG1C105A118	C. CAPACITOR CH 16V 1U	1	
C630	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1		C915-19	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	5	
C632	FIG1H101A565	C. CAPACITOR CH 50V 100P	1		C920	FIG1H181A541	C. CAPACITOR CH 50V 180P	1	
C633	FIG1H0J2250008	C. CAPACITOR CH6.3V 2.2U	1		C921	FIG1C105A118	C. CAPACITOR CH 16V 1U	1	
C634	FIG1H101A565	C. CAPACITOR CH 50V 100P	1		C922, 23	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C635, 36	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	2		C925, 26	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C638-40	FIG1H101A565	C. CAPACITOR CH 50V 100P	3		C927, 28	FIG1H0J2250008	C. CAPACITOR CH6.3V 2.2U	2	
C641, 42	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	2		C929	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C644, 45	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	2		C930	FIG1C105A118	C. CAPACITOR CH 16V 1U	1	
C646	FIG1H105A118	C. CAPACITOR CH 16V 1U	1		C931-37	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	7	
C650-52	FIG1H101A565	C. CAPACITOR CH 50V 100P	3		C938	FIG1H101A565	C. CAPACITOR CH 50V 100P	1	
C653-55	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	3		C939, 40	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C656	FIG1H101A565	C. CAPACITOR CH 50V 100P	1		C941, 42	FIG1C105A118	C. CAPACITOR CH 16V 1U	2	
C657-61	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	5		C943, 44	FIG1H101A565	C. CAPACITOR CH 50V 100P	2	
C662	FIG1C105A118	C. CAPACITOR CH 16V 1U	1		C945, 46	FIG1C105A118	C. CAPACITOR CH 16V 1U	2	
C663	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1		C947	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C664	FIG1C105A118	C. CAPACITOR CH 16V 1U	1		C948	FIG1H101A565	C. CAPACITOR CH 50V 100P	1	
C665, 66	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	2		C949, 50	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C667	FIG1C105A118	C. CAPACITOR CH 16V 1U	1		C951, 52	FIG1C105A118	C. CAPACITOR CH 16V 1U	2	
C668	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1		C953-55	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	3	
C671-73	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	3		C956-63	FIG1H101A565	C. CAPACITOR CH 50V 100P	8	
C674	FIG1H103A706	C. CAPACITOR CH 50V 0.01U	1		C964	FIG1C105A118	C. CAPACITOR CH 16V 1U	1	
C677	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1		C965-70	FIG1H101A565	C. CAPACITOR CH 50V 100P	6	
C678	FIG1H103A706	C. CAPACITOR CH 50V 0.01U	1		C971	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C679	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1		C972-77	FIG1H101A565	C. CAPACITOR CH 50V 100P	6	
C680	FIG1H103A706	C. CAPACITOR CH 50V 0.01U	1		C978-82	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	5	
C681	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1		C990	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C700	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1		C997, 98	FIG1C105A118	C. CAPACITOR CH 16V 1U	2	
C702	FIG1C105A118	C. CAPACITOR CH 16V 1U	1		C1000-05	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	6	
C703	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1		C1006-08	FIG1H101A565	C. CAPACITOR CH 50V 100P	3	
C705-07	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	3		C1009	FIG1H1020008	C. CAPACITOR CH 50V 1000P	1	
C708	FIG1C105A118	C. CAPACITOR CH 16V 1U	1		C1010, 11	FIG1H101A565	C. CAPACITOR CH 50V 100P	2	
C709	FIG1H22A571	C. CAPACITOR CH 50V 2200P	1		C1012-19	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	8	
C710, 11	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	2		C1020	FIG1H8R0A564	C. CAPACITOR CH 50V 8P	1	
C713	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1		C1021	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C714	FIG1C105A118	C. CAPACITOR CH 16V 1U	1		C1022	FIG1H1020008	C. CAPACITOR CH 50V 1000P	1	
C716-18	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	3		C1023	FIG1H101A565	C. CAPACITOR CH 50V 100P	1	
C720	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1		C1024	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C721	FIG1C105A118	C. CAPACITOR CH 16V 1U	1		C1025	FIG1H100A565	C. CAPACITOR CH 50V 10P	1	
C722	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1		C1026	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C723	FIG1C105A118	C. CAPACITOR CH 16V 1U	1		C1027	FIG1H101A565	C. CAPACITOR CH 50V 100P	1	
C724	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1		C1028	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C726-29	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	4		C1030	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C730	FIG1C105A118	C. CAPACITOR CH 16V 1U	1		C1031, 32	FIG1C105A118	C. CAPACITOR CH 16V 1U	2	
C731-33	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	3		C1033	FIG1H1020008	C. CAPACITOR CH 50V 1000P	1	
C800	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1		C1034	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C803, 04	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	2		C1035	FIL1C106A009	C. CAPACITOR CH 16V 10U	1	
C805-12	FIG1H101A565	C. CAPACITOR CH 50V 100P	8		C1036	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C813-20	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	8		C1037	FIL1C106A009	C. CAPACITOR CH 16V 10U	1	
C821-28	FIG1C105A118	C. CAPACITOR CH 16V 1U	8		C1039	FIG1H1020008	C. CAPACITOR CH 50V 1000P	1	
C829-36	FIL1A4760003	C. CAPACITOR CH 16V 47U	8		C1040	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C837-40	FIG1C105A118	C. CAPACITOR CH 16V 1U	4		C1046	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C841, 42	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	2		C1047	FIG1H101A565	C. CAPACITOR CH 50V 100P	1	
C843, 44	FIG1C105A118	C. CAPACITOR CH 16V 1U	2		C1048, 49	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C845, 46	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	2		C1050	FIG1H101A565	C. CAPACITOR CH 50V 100P	1	
C847, 48	FIG1C105A118	C. CAPACITOR CH 16V 1U	2		C1051-53	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	3	
C849, 50	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	2		C1054	FIG1H1020008	C. CAPACITOR CH 50V 1000P	1	
C851, 52	FIG1C105A118	C. CAPACITOR CH 16V 1U	2		C1055, 56	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C853-63	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	11		C1100	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C864-66	FIG1H101A565	C. CAPACITOR CH 50V 100P	3		C1101, 02	F1J0J106A013	C. CAPACITOR CH6.3V 10U	2	
C867	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1		C1103	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C868-70	FIG1H101A565	C. CAPACITOR CH 50V 100P	3		C1104	FIG1C105A118	C. CAPACITOR CH 16V 1U	1	
C871-73	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	3		C1105, 06	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C874-76	FIG1H101A565	C. CAPACITOR CH 50V 100P	3		C1107	FIG1C105A118	C. CAPACITOR CH 16V 1U	1	
C877-85	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	9		C1108	F1J0J106A013	C. CAPACITOR CH6.3V 10U	1	
C886	FIG1H101A565	C. CAPACITOR CH 50V 100P	1		C1109	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C887-93	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	7		C1110	F1J0J106A013	C. CAPACITOR CH6.3V 10U	1	
C894	FIG1H101A565	C. CAPACITOR CH 50V 100P	1		C1112	FIG1J1050007	C. CAPACITOR CH6.3V 1U	1	
C895-98	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	4		C1113	FIG1H101A565	C. CAPACITOR CH 50V 100P	1	
C899	FIG1H101A565	C. CAPACITOR CH 50V 100P	1		C1115-17	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	3	
C900-03	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	4		C1118, 19	FIG1C105A118	C. CAPACITOR CH 16V 1U	2	
C904	FIG1C105A118	C. CAPACITOR CH 16V 1U	1		C1120-24	FIG1C104A077	C. CAPACITOR CH 16V 0.1U	5	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
C1125-27	F1H1C105A118	C. CAPACITOR CH 16V 1U	3		C1703	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C1128-30	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3		C1704	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C1131-33	F1H1C105A118	C. CAPACITOR CH 16V 1U	3		C1706-10	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	5	
C1135, 36	F1H0J475A009	C. CAPACITOR CH6.3V 4.7U	2		C1711-14	F1H1C105A118	C. CAPACITOR CH 16V 1U	4	
C1137	F1G1H103A706	C. CAPACITOR CH 50V 0.01U	1		C1715	F1J0J106A013	C. CAPACITOR CH6.3V 10U	1	
C1147-50	F1G1H1020008	C. CAPACITOR CH 50V 1000P	4		C1716-19	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4	
C1201	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C1720	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C1206	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C1721	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C1209	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C1723	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C1210, 11	F1H1C105A118	C. CAPACITOR CH 16V 1U	2		C1724	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C1213	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C1725-27	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3	
C1214, 15	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		C1729-31	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3	
C1216, 17	F1L1C106A009	C. CAPACITOR CH 16V 10U	2		C1733	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C1218-21	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4		C1736	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C1228	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C1737,38	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C1229	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C1739-48	F1G1H101A565	C. CAPACITOR CH 50V 100P	10	
C1230, 31	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		C1751-55	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	5	
C1232	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C1757	F1J0J106A013	C. CAPACITOR CH6.3V 10U	1	
C1233	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C1758-60	F1H1C105A118	C. CAPACITOR CH 16V 1U	3	
C1234, 35	F1G1H105A565	C. CAPACITOR CH 50V 15P	2		C1761-63	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3	
C1238-41	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4		C1765	F1J0J106A013	C. CAPACITOR CH6.3V 10U	1	
C1244	F1G1H103A706	C. CAPACITOR CH 50V 0.01U	1		C1766-71	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	6	
C1245	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C1772-75	F1H1C105A118	C. CAPACITOR CH 16V 1U	4	
C1246	F1G1H103A706	C. CAPACITOR CH 50V 0.01U	1		C1776-79	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4	
C1247	F1J0J106A013	C. CAPACITOR CH6.3V 10U	1		C1780, 81	F1H1C105A118	C. CAPACITOR CH 16V 1U	2	
C1248	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C1782-88	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	7	
C1249, 50	F1L1C106A009	C. CAPACITOR CH 16V 10U	2		C1790, 91	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C1251	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C1793, 94	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C1300-02	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3		C1797	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C1303, 04	F1G1H103A706	C. CAPACITOR CH 50V 0.01U	2		C1800	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C1305	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C1801	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C1306-10	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	5		C1802, 03	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C1311-13	F1G1H103A706	C. CAPACITOR CH 50V 0.01U	3		C1805	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C1314-16	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3		C1806	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C1321	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C1807-14	F1G1H101A565	C. CAPACITOR CH 50V 100P	8	
C1322	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C1815-23	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	9	
C1323, 24	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		C1824	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C1325	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C1825	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C1326	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C1828	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C1328, 29	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		C1829	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C1400, 01	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		C1830-37	F1G1H101A565	C. CAPACITOR CH 50V 100P	8	
C1402	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C1838-45	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	8	
C1403	F1G1H103A706	C. CAPACITOR CH 50V 0.01U	1		C1846-49	F1G1H101A565	C. CAPACITOR CH 50V 100P	4	
C1404	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C1850	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C1405	F1G1H103A706	C. CAPACITOR CH 50V 0.01U	1		C1851	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C1406	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C1853, 54	F1G1H101A565	C. CAPACITOR CH 50V 100P	2	
C1407	F1G1H103A706	C. CAPACITOR CH 50V 0.01U	1		C1855	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C1408-10	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3		C1856	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C1411, 12	F1G1H103A706	C. CAPACITOR CH 50V 0.01U	2		C1858, 59	F1G1H101A565	C. CAPACITOR CH 50V 100P	2	
C1413, 14	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		C1861	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C1417	F1G1H103A706	C. CAPACITOR CH 50V 0.01U	1		C1863	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C1418	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C1866	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C1500, 01	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		C1867, 68	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C1600	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C1873	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C1601-04	F1G1H103A706	C. CAPACITOR CH 50V 0.01U	4		C1900, 01	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C1605, 06	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		C1902	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C1608, 09	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		C1903	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C1610	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C1904	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C1611	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C1905	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C1612	F1G1H103A706	C. CAPACITOR CH 50V 0.01U	1		C1906	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C1613	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C1907-09	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3	
C1614, 15	F1H1C105A118	C. CAPACITOR CH 16V 1U	2		C1910, 11	F1G1H101A565	C. CAPACITOR CH 50V 100P	2	
C1616	F1G1H8ROA564	C. CAPACITOR CH 50V 8P	1		C1912	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C1617-19	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3		C1913	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C1620-22	F1H1C105A118	C. CAPACITOR CH 16V 1U	3		C1914	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C1623-25	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3		C1915	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C1626	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C1916	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C1627	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C1917	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C1633, 34	F1G1H101A565	C. CAPACITOR CH 50V 100P	2		C1918	F1G1H103A706	C. CAPACITOR CH 50V 0.01U	1	
C1635	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C1919	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C1636	F1K1H105A138	C. CAPACITOR CH 50V 1U	1		C1920-23	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4	
C1637	F1L1H106A086	C. CAPACITOR CH 50V 10U	1		C1924	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C1638	F1K1H105A138	C. CAPACITOR CH 50V 1U	1		C1925	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C1639	F1L1H106A086	C. CAPACITOR CH 50V 10U	1		C1926	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C1640	F1H1H104A783	C. CAPACITOR CH 50V 0.1U	1		C1927	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C1641	F1K1H105A138	C. CAPACITOR CH 50V 1U	1		C1928	F1G1H103A706	C. CAPACITOR CH 50V 0.01U	1	
C1702	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C1929	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
C1930	F1G1H330A565	C. CAPACITOR CH 50V 33P	1		C2411, 12	F1J0J106A013	C. CAPACITOR CH6.3V 10U	2	
C1931	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C2413	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C1932	F1G1H120A565	C. CAPACITOR CH 50V 12P	1		C2414	F1G1H5610004	C. CAPACITOR CH 50V 560P	1	
C1933	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C2415	F1G1H821A571	C. CAPACITOR CH 50V 820P	1	
C1934	F1G1H103A706	C. CAPACITOR CH 50V 0.01U	1		C2416	F1G1H120A565	C. CAPACITOR CH 50V 12P	1	
C1935	F1G1H101A565	C. CAPACITOR CH 50V 100P	1		C2417, 18	F1J0J106A013	C. CAPACITOR CH6.3V 10U	2	
C1936-39	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4		C2419-21	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3	
C1940	F1G1H101A565	C. CAPACITOR CH 50V 100P	1		C2501	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C1941, 42	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		C2502	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C1943	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C2503, 04	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C1944, 45	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		C2505	F1G1H330A565	C. CAPACITOR CH 50V 33P	1	
C1946	F1G1H101A565	C. CAPACITOR CH 50V 100P	1		C2506, 07	F1G1H8R0A564	C. CAPACITOR CH 50V 8P	2	
C1947-49	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3		C2508-32	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	25	
C1950-53	F1G1H101A565	C. CAPACITOR CH 50V 100P	4		C2533, 34	F1H1C105A118	C. CAPACITOR CH 16V 1U	2	
C1954-56	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3		C2535-40	F1G1H101A565	C. CAPACITOR CH 50V 100P	6	
C2000, 01	F1G1H7R00008	C. CAPACITOR CH 50V 7P	2		C2541, 42	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C2003	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C2543-55	F1G1H101A565	C. CAPACITOR CH 50V 100P	13	
C2004	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C2556, 57	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C2006	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C2558-61	F1J0J106A013	C. CAPACITOR CH6.3V 10U	4	
C2008	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C2562, 63	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C2009	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C2564, 65	F1H1C105A118	C. CAPACITOR CH 16V 1U	2	
C2010	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C2566-69	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4	
C2011	F1G1H101A565	C. CAPACITOR CH 50V 100P	1		C2600, 01	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C2012, 13	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		C2602, 03	F1H1C105A118	C. CAPACITOR CH 16V 1U	2	
C2014	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C2604-11	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	8	
C2015-26	F1G1H101A565	C. CAPACITOR CH 50V 100P	12		C2612-19	F1G1H101A565	C. CAPACITOR CH 50V 100P	8	
C2027, 28	F1H1C105A118	C. CAPACITOR CH 16V 1U	2		C2620, 21	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C2029	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C2622, 23	F1H1C105A118	C. CAPACITOR CH 16V 1U	2	
C2030-35	F1G1H101A565	C. CAPACITOR CH 50V 100P	6		C2624-31	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	8	
C2036, 37	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		C2632-39	F1G1H101A565	C. CAPACITOR CH 50V 100P	8	
C2038-43	F1G1H101A565	C. CAPACITOR CH 50V 100P	6		C2640, 41	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C2044	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C2642	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C2045-48	F1G1H101A565	C. CAPACITOR CH 50V 100P	4		C2643-45	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3	
C2049-61	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	13		C2647-50	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4	
C2062	F1G1H101A565	C. CAPACITOR CH 50V 100P	1		C2651	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C2063-69	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	7		C2652	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C2070	F1G1H101A565	C. CAPACITOR CH 50V 100P	1		C2654	F1G1H330A565	C. CAPACITOR CH 50V 33P	1	
C2071-80	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	10		C2700-12	F1G1H101A565	C. CAPACITOR CH 50V 100P	13	
C2081, 82	F1H1C105A118	C. CAPACITOR CH 16V 1U	2		C2713	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C2083-86	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4		C2714	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C2200, 01	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		C2715-27	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	13	
C2202, 03	F1H1C105A118	C. CAPACITOR CH 16V 1U	2		C2728	F1G1H8R0A564	C. CAPACITOR CH 50V 8P	1	
C2204-11	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	8		C2730	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C2212-19	F1G1H101A565	C. CAPACITOR CH 50V 100P	8		C2731	F1G1H8R0A564	C. CAPACITOR CH 50V 8P	1	
C2220, 21	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		C2732	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C2222, 23	F1H1C105A118	C. CAPACITOR CH 16V 1U	2		C2733	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C2224-31	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	8		C2735	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C2232-39	F1G1H101A565	C. CAPACITOR CH 50V 100P	8		C2736	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C2240	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C2737	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C2241	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C2738	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C2242-45	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4		C2739	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C2246-54	F1G1H101A565	C. CAPACITOR CH 50V 100P	9		C2740-42	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3	
C2300	F1G1H101A565	C. CAPACITOR CH 50V 100P	1		C2743	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C2301	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C2744	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C2302	F1G1H101A565	C. CAPACITOR CH 50V 100P	1		C2801	F1G1H100A565	C. CAPACITOR CH 50V 10P	1	
C2303-06	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4		C2802	F1G1H8R0A564	C. CAPACITOR CH 50V 8P	1	
C2307-11	F1G1H101A565	C. CAPACITOR CH 50V 100P	5		C2803-09	F1G1H101A565	C. CAPACITOR CH 50V 100P	7	
C2312	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C2810	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C2313	F1G1H7R00008	C. CAPACITOR CH 50V 7P	1		C2811	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C2314	F1G1H8R0A564	C. CAPACITOR CH 50V 6P	1		C2812	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C2315-19	F1G1H101A565	C. CAPACITOR CH 50V 100P	5		C2813	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C2320, 21	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		C2814	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C2323	F1G1H271A571	C. CAPACITOR CH 50V 270P	1		C2815, 16	F1G1H101A565	C. CAPACITOR CH 50V 100P	2	
C2324	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C2817, 18	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C2326	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C2819	F1J1A335A003	C. CAPACITOR CH 10V 3.3U	1	
C2327-29	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3		C2820-25	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	6	
C2330, 31	F1H1C105A118	C. CAPACITOR CH 16V 1U	2		C2826	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C2332	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C2827, 28	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C2333	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C2829, 30	F1H1C105A118	C. CAPACITOR CH 16V 1U	2	
C2334-36	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3		C2831-33	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3	
C2337	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C2834	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C2338	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C2835-38	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4	
C2340	F1L1A2260013	C. CAPACITOR CH 10V 22U	1		C2839	EEFUE0J151	E. CAPACITOR 6.3V 150P	1	
C2400-02	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3		C2840	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C2403-05	F1H1C105A118	C. CAPACITOR CH 16V 1U	3		C2841, 42	F1H1C105A118	C. CAPACITOR CH 16V 1U	2	
C2406-09	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4		C2843	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C2410	F1L1C106A009	C. CAPACITOR CH 16V 10U	1		C2844	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
C3000-07	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	8		C3628	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C3100	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C3630	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C3101	F1G1C223A081	C. CAPACITOR CH 16V 0.022U	1		C3631	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C3102	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C3634	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C3103	F1G1C223A081	C. CAPACITOR CH 16V 0.022U	1		C3636	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C3104	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C3638	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C3105	F1G1C223A081	C. CAPACITOR CH 16V 0.022U	1		C3639	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C3106	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C3642-49	F1G1H101A565	C. CAPACITOR CH 50V 100P	8	
C3107	F1G1C223A081	C. CAPACITOR CH 16V 0.022U	1		C3650-57	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	8	
C3108	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C3658-60	F1H1C105A118	C. CAPACITOR CH 16V 1U	3	
C3109	F1G1C223A081	C. CAPACITOR CH 16V 0.022U	1		C3666-68	F1L1A4760003	C. CAPACITOR CH 16V 47U	3	
C3111	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C3670	F1L1A4760003	C. CAPACITOR CH 16V 47U	1	
C3113	F1G1H101A565	C. CAPACITOR CH 50V 100P	1		C3674-76	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3	
C3115-17	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3		C3678	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C3202	F1G1H120A565	C. CAPACITOR CH 50V 12P	1		C3680, 81	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C3204	F1G1H120A565	C. CAPACITOR CH 50V 12P	1		C3682, 83	F1G1H101A565	C. CAPACITOR CH 50V 100P	2	
C3206	F1G1H103A706	C. CAPACITOR CH 50V 0.01U	1		C3688	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C3208	F1G1H103A706	C. CAPACITOR CH 50V 0.01U	1		C3690	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C3210	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C3692, 93	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C3211	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C3694, 95	F1G1H101A565	C. CAPACITOR CH 50V 100P	2	
C3212	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C3696	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C3213-15	F1G1H103A706	C. CAPACITOR CH 50V 0.01U	3		C3697, 98	F1J0J106A013	C. CAPACITOR CH6.3V 10U	2	
C3500-02	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3		C3699, 00	F1G1H101A565	C. CAPACITOR CH 50V 100P	2	
C3503	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C3701	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C3504-07	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4		C3702-05	F1G1H101A565	C. CAPACITOR CH 50V 100P	4	
C3509-11	F1G1H101A565	C. CAPACITOR CH 50V 100P	3		C3706-09	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4	
C3515-18	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4		C3710-13	F1G1H101A565	C. CAPACITOR CH 50V 100P	4	
C3519-22	F1G1H101A565	C. CAPACITOR CH 50V 100P	4		C3714-18	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	5	
C3523	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C3719	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C3524	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C3720	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C3525, 26	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		C3721	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C3527	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C3722	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C3528, 29	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		C3725	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C3530	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C3726	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C3531, 32	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		C3727	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C3533	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C3728-33	F1H1C105A118	C. CAPACITOR CH 16V 1U	6	
C3534-36	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3		C3734	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C3537	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C3735	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C3538	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C3736	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C3540	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C3737	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C3541	F1G1H101A565	C. CAPACITOR CH 50V 100P	1		C3738, 39	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C3542	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C3740	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C3543	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C3741-43	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3	
C3544	F1L1A4760003	C. CAPACITOR CH 16V 47U	1		C3744	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C3545	F1G1H101A565	C. CAPACITOR CH 50V 100P	1		C3745, 46	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C3546	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C3747, 48	F1J0J106A013	C. CAPACITOR CH6.3V 10U	2	
C3548	F1L1A4760003	C. CAPACITOR CH 16V 47U	1		C3800	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C3549	F1G1H101A565	C. CAPACITOR CH 50V 100P	1		C3802	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C3550	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C3804	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C3551	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C3805	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C3552	F1L1A4760003	C. CAPACITOR CH 16V 47U	1		C3808	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C3553	F1G1H101A565	C. CAPACITOR CH 50V 100P	1		C3810	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C3554	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C3812	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
C3555	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C3813	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C3556	F1L1A4760003	C. CAPACITOR CH 16V 47U	1		C3816	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C3557	F1G1H101A565	C. CAPACITOR CH 50V 100P	1		C3818	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C3558	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C3820, 21	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C3561	F1G1H101A565	C. CAPACITOR CH 50V 100P	1		C3822, 23	F1G1H101A565	C. CAPACITOR CH 50V 100P	2	
C3562	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C3828	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C3565	F1G1H101A565	C. CAPACITOR CH 50V 100P	1		C3830	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C3566	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C3832, 33	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C3569	F1G1H101A565	C. CAPACITOR CH 50V 100P	1		C3834, 35	F1G1H101A565	C. CAPACITOR CH 50V 100P	2	
C3570	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C3840	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C3603	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		C3841-45	F1G1H101A565	C. CAPACITOR CH 50V 100P	5	
C3604	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C3846-49	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4	
C3605, 06	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		C3850-53	F1G1H101A565	C. CAPACITOR CH 50V 100P	4	
C3607	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C3854-57	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4	
C3608, 09	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		C3861	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1	
C3610	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C3862	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C3611, 12	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		C3863, 64	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C3613	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C3865	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C3614, 15	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		C3866, 67	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C3616	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		C3868	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C3617, 18	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		C3869, 70	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C3619	F1G1H101A565	C. CAPACITOR CH 50V 100P	1		C3871	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
C3620-22	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	3		C3872, 73	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2	
C3623-26	F1G1H101A565	C. CAPACITOR CH 50V 100P	4		C3874	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
C3875, 76	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	2		IC704	COJBA0000621	IC	1	
C3877	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		IC705-07	COJBA0000686	IC	3	
C3878	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		IC708	COFBY000055	IC	1	
C3879	F1G1H101A565	C. CAPACITOR CH 50V 100P	1		IC709	SN75C1168NS	IC	1	
C3880-83	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4		IC710	COJBA0000362	IC	1	
C3884-94	F1G1H101A565	C. CAPACITOR CH 50V 100P	11		IC711	COABBA000025	IC	1	
C3895-02	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	8		IC800	C1ZBZ0003923	IC	1	
C3903, 04	F1H1C105A118	C. CAPACITOR CH 16V 1U	2		IC801	COJBA0000381	IC	1	
C3905	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		IC802	COJBA0000671	IC	1	
C3906	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		IC803	COJBAZ002192	IC	1	
C3907	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		IC804	COCBAC000061	IC	1	
C3908	F1G1H101A565	C. CAPACITOR CH 50V 100P	1		IC805	COCBAC000072	IC	1	
C3909	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		IC806	COCBBC000048	IC	1	
C3910	F1G1H101A565	C. CAPACITOR CH 50V 100P	1		IC900, 01	COABHA000020	IC	2	
C3911, 12	F1L1A4760003	C. CAPACITOR CH 16V 47U	2		IC902, 03	COJBAZ002262	IC	2	
C3913	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		IC904	COJBA0000362	IC	1	
C3914	F1G1H101A565	C. CAPACITOR CH 50V 100P	1		IC905	COJBA0000174	IC	1	
C3915	F1L1A4760003	C. CAPACITOR CH 16V 47U	1		IC906	C1A00002726	IC	1	
C3916	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	1		IC907, 08	COJBAR0000432	IC	2	
C3917	F1G1H101A565	C. CAPACITOR CH 50V 100P	1		IC909, 10	COCBBC000053	IC	2	
C3918-21	F1G1C104A077	C. CAPACITOR CH 16V 0.1U	4		IC911	COJBAE000307	IC	1	
					IC913	COCBBC000053	IC	1	
CN100-02	K1KY40B00015	CONNECTOR	3		IC914	COCBAD000042	IC	1	
CN1300	K1KA10AA0001	CONNECTOR (MALE)	1		IC915	COCBDB000004	IC	1	
CN2300	K1KA05AA0083	CONNECTOR (MALE)	1		IC1000-06	COJBAZ001825	IC	7	
CN2900, 01	K1KA70AA0044	CONNECTOR (MALE)	2		IC1007, 08	COJBA0000662	IC	2	
CN3000	K1KA70AA0044	CONNECTOR (MALE)	1		IC1009	COJBAZ001825	IC	1	
CN3001	K1KA12A00260	CONNECTOR (MALE)	1		IC1011	COJBAZ001825	IC	1	
CN3002	K1MN30AA0018	CONNECTOR	1		IC1013	COJBAZ001825	IC	1	
CN3100	K1KA10B00093	CONNECTOR (MALE)	1		IC1015, 16	COJBAZ001825	IC	2	
CN3101	K1KB60A00031	CONNECTOR (FEMALE)	1		IC1017	COJBA0000662	IC	1	
CN3102	K1KB50BA0015	CONNECTOR (FEMALE)	1		IC1018	COJBA0000358	IC	1	
CN3200	K1KY40A00031	CONNECTOR	1		IC1100	C1AB00003287	IC	1	
CN3201	K1MN30AA0018	CONNECTOR	1		IC1102	COOBZG000060	IC	1	
CN3202	K1KY16AA0550	CONNECTOR	1		IC1103	COBFFY00230	IC	1	
CN3203	K1KY10AA0550	CONNECTOR	1		IC1200	COFBFB000056	IC	1	
CN3204	K1KA05A00218	CONNECTOR (MALE)	1		IC1201	COCBBC000053	IC	1	
CN3205	K1KA06B00140	CONNECTOR (MALE)	1		IC1202	COCBAD000042	IC	1	
CN3300, 01	K1KB70A00051	CONNECTOR (FEMALE)	2		IC1203	COCBDB000004	IC	1	
CN3302	K1KA30A00227	CONNECTOR (MALE)	1		IC1204, 05	COABGB000027	IC	2	
					IC1300	COBZ0001764	IC	1	
D610	DA3J101F0L	DIODE	1		IC1400	C1CB00003188	IC	1	
D700-02	D2ZJ051M0L	DIODE	3		IC1500	MN1A92120R1	IC	1	
D704	DA3S101F0L	DIODE	1		IC1601	COJBA0000362	IC	1	
D706-09	DA3S101F0L	DIODE	4		IC1602	G1ZBZ0002602	IC	1	
D713	DA3S101F0L	DIODE	1		IC1603	COCBAGE00012	IC	1	
D900	DA2S10100L	DIODE	1		IC1705	COOBZG000060	IC	1	
D901	MA3J74200L	DIODE	1		IC1706	COJBA0000621	IC	1	
D1200	MA3J74200L	DIODE	1		IC1707	COJBA0000381	IC	1	
D1600-03	DA3J101F0L	DIODE	4		IC1708	COJBA0000621	IC	1	
D1605, 06	DA3J101F0L	DIODE	2		IC1800, 01	C3ABTG000007	IC	2	
D1607	MAZ81500HL	DIODE	1		IC1900	COCBBC000053	IC	1	
D2400, 01	DA3J101F0L	DIODE	2		IC1901	COJBAZ002331	IC	1	
D3300-06	D4ED1270A008	VARI STOR	7		IC1902	C1AB00003023	IC	1	
					IC1903	BH7086KV	IC	1	
FL100-11	JOJAD0000028	FILTER	12		IC1904	COJBAF000545	IC	1	
FL1300	JOJAD0000028	FILTER	1		IC1905, 06	COJBAZ000851	IC	2	
					IC1907, 08	COJBA0000662	IC	2	
IC100-02	C1CB00003196	IC	3		IC1909	COJBAZ000851	IC	1	
IC103	COOBZG000060	IC	1		IC1910	C1AB00002574	IC	1	
IC104	COEBE0000348	IC	1		IC2000	C1AB00002377	IC	1	
IC105	COOBZG000060	IC	1		IC2001	COCBAC000072	IC	1	
IC106	COOBGY01337	IC	1		IC2200-04	C3ABRY000032	IC	5	
IC107	COCBAC000060	IC	1		IC2300	C1DB00001589	IC	1	
IC108	COCBCC000034	IC	1		IC2301	COJBA0000362	IC	1	
IC200	C1AB00003111	IC	1		IC2302	COCBBC000053	IC	1	
IC201	COJBA0000511	IC	1		IC2400	COBBBA000024	IC	1	
IC400	COCBAC000072	IC	1		IC2401	COJBAZ002328	IC	1	
IC401	COOBZG000060	IC	1		IC2402, 03	COABBB000196	IC	2	
IC500	C3ABTG000007	IC	1		IC2500	C2GB00000332	IC	1	
IC600	MNZSFD0RSA1	IC	1		IC2501, 02	COJBAZ001537	IC	2	
IC601	COABHZ000004	IC	1		IC2504	TVHC164FT	IC	1	
IC602, 03	COJBA0000362	IC	2		IC2505	C1ZBZ0002771	IC	1	
IC607	COJBAZ002328	IC	1		IC2506, 07	COOBZG000060	IC	2	
IC608, 09	COJBA0000362	IC	2		IC2508	COJBAE000307	IC	1	
IC701	COFBAG000068	IC	1		IC2509	COEBE0000348	IC	1	
IC702, 03	COABGA000007	IC	2		IC2600-03	C3ABRY000032	IC	4	

Components identified with the mark Δ have the special characteristics for safety.
When replacing any of these components, use only the same type.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
IC2604	TLCX245FT	IC	1		L1068	JOJCC0000405	FERRITE CORE	1	
IC2606, 07	COJBAAE000321	IC	2		L1070	JOJCC0000405	FERRITE CORE	1	
IC2609	COJBAAZ000855	IC	1		L1100, 01	JOJHC0000032	FILTER	2	
IC2610	COJBAA000545	IC	1		L1102-05	JOJDC0000102	FILTER	4	
IC2611	COJBAA000381	IC	1		L1106, 07	G1C6N8J00006	COIL 6.8UH	2	
IC2700	C1DB00001355	IC	1		L1108	JOJDC0000099	FILTER	1	
IC2701	COBCAC000061	IC	1		L1201	JOJCC0000405	FERRITE CORE	1	
IC2800	C1CB00002607	IC	1		L1203	JOJCC0000405	FERRITE CORE	1	
IC2801	COBZY600002	IC	1		L1205	JOE1355B0002	FILTER	1	
IC2802	COBCBC000053	IC	1		L1206	JOJCC0000405	FERRITE CORE	1	
IC3100	COEBF0000264	IC	1		L1207	JOJHC0000032	FILTER	1	
IC3101	COEBA0000027	IC	1		L1300-02	JOJHC0000032	FILTER	3	
IC3102	COEBE0000348	IC	1		L1303	JOJDC0000099	FILTER	1	
IC3103	COEBD0000224	IC	1		L1400	JOJHC0000032	FILTER	1	
IC3104	COEBE0000156	IC	1		L1401	JOMAB0000225	FILTER	1	
IC3105	COJBAB0000832	IC	1		L1602	JOJHC0000032	FILTER	1	
IC3108	COJBAA000174	IC	1		L1603	JOJCC0000405	FERRITE CORE	1	
IC3109	COJBAAZ002392	IC	1		L1604-06	JOJHC0000032	FILTER	3	
IC3110	COJBAB0000671	IC	1		L1700	JOJHC0000009	FILTER	1	
IC3500	C1ZBZ0004199	IC	1		L1701	JOJCC0000405	FERRITE CORE	1	
IC3503	COJBAAZ002192	IC	1		L1702-05	JOJHC0000032	FILTER	4	
IC3504	COJBAD0000207	IC	1		L1706-08	JOJHC0000009	FILTER	3	
IC3600	C1ZBZ0004200	IC	1		L1709-12	JOJHC0000032	FILTER	4	
IC3601	COJBAAZ002192	IC	1		L1713, 14	JOJCC0000405	FERRITE CORE	2	
IC3602	COJBAD0000207	IC	1		L1800, 01	JOJHC0000032	FILTER	2	
IC3603	COBCAC000072	IC	1		L1900-02	JOJHC0000032	FILTER	3	
IC3604	COBCBC000048	IC	1		L1903	JOJCC0000405	FERRITE CORE	1	
IC3605	COBCAC000061	IC	1		L1904	G1C120JA0036	COIL 12UH	1	
IC3606, 07	COBZG0000060	IC	2		L1905	JOJCC0000405	FERRITE CORE	1	
IC3700	C3ABT0000007	IC	1		L1911	JOJCC0000405	FERRITE CORE	1	
IC3701	C3FBD0000026	IC	1		L1912	JOJHC0000032	FILTER	1	
IC3800	C1ZBZ0004200	IC	1		L1913	JOJCC0000405	FERRITE CORE	1	
IC3801	C3ABSJ000009	IC	1		L2001	JOJHC0000009	FILTER	1	
IC3803	COJBAAZ000855	IC	1		L2002, 03	JOJHC0000032	FILTER	2	
IP602, 03	C3EBJG0000001	IC	2		L2004	JOJCC0000405	FERRITE CORE	1	
IP801	C1ZBZ0003922	IC	1		L2005, 06	JOJHC0000032	FILTER	2	
IP1601	VEF0118	IC	1		L2200-04	JOJHC0000032	FILTER	5	
IP1602	VEF0119	IC	1		L2300, 01	JOMAB0000212	FILTER	2	
IP1603	C3EBGG000016	IC	1		L2302, 03	JOJHC0000032	FILTER	2	
IP2604	VEF0117	IC	1		L2400-02	JOJCC0000405	FERRITE CORE	3	
IP3802	C1ZBZ0003922	IC	1		L2500	JOJCC0000405	FERRITE CORE	1	
JK1100, 01	VJP4131	CONNECTOR (MALE)	2		L2501, 02	JOJHC0000032	FILTER	2	
L100-02	JOJCC0000405	FERRITE CORE	3		L2503	JOJHC0000009	FILTER	1	
L103-05	JOMAB0000225	FILTER	3		L2504	JOJHC0000032	FILTER	1	
L106-20	JOJHC0000032	FILTER	15		L2600-05	JOJHC0000032	FILTER	6	
L121	JOJDC0000099	FILTER	1		L2700, 01	JOJHC0000032	FILTER	2	
L400-03	JOJHC0000009	FILTER	4		L2702	JOMAB0000212	FILTER	1	
L404, 05	JOJCC0000405	FERRITE CORE	2		L2703	JOJHC0000032	FILTER	1	
L406-11	JOJHC0000032	FILTER	6		L2800, 01	JOJHC0000032	FILTER	2	
L418	JOJHC0000032	FILTER	1		L2803	JOMAB0000212	FILTER	1	
L500	JOJHC0000032	FILTER	1		L2804	JOJHC0000032	FILTER	1	
L600	JOJHC0000032	FILTER	1		L2805	JOJCC0000405	FERRITE CORE	1	
L602, 03	JOJHC0000032	FILTER	2		L3100, 01	JOJHC0000032	FILTER	2	
L604	JOJCC0000405	FERRITE CORE	1		L3200-03	JOJDC0000099	FILTER	4	
L700, 01	JOJHC0000032	FILTER	2		L3204	JOJHC0000032	FILTER	1	
L703	JOJHC0000032	FILTER	1		L3205-15	JOJDC0000099	FILTER	11	
L704	JOJCC0000405	FERRITE CORE	1		L3500-02	JOJHC0000032	FILTER	3	
L801, 02	JOJCC0000405	FERRITE CORE	2		L3503-05	JOJCC0000405	FERRITE CORE	3	
L804-06	JOJHC0000032	FILTER	3		L3601, 02	JOJHC0000032	FILTER	2	
L900	JOJHC0000032	FILTER	1		L3603, 04	JOJCC0000405	FERRITE CORE	2	
L901-09	JOJCC0000405	FERRITE CORE	9		L3605	JOJHC0000032	FILTER	1	
L912, 13	JOJHC0000032	FILTER	2		L3606, 07	JOJHC0000009	FILTER	2	
L1000-07	JOJCC0000405	FERRITE CORE	8		L3608	JOJHC0000032	FILTER	1	
L1011	JOJCC0000405	FERRITE CORE	1		L3700, 01	JOJHC0000032	FILTER	2	
L1013	JOJDC0000099	FILTER	1		L3801, 02	JOJHC0000032	FILTER	2	
L1018	JOJCC0000405	FERRITE CORE	1		L3803, 04	JOJCC0000405	FERRITE CORE	2	
L1027	JOJCC0000405	FERRITE CORE	1		L3805, 06	JOJHC0000032	FILTER	2	
L1029-31	JOJDC0000099	FILTER	3		L3808	JOJHC0000032	FILTER	1	
L1039	JOJDC0000099	FILTER	1		Δ PA3100-02	K5H5011A0004	FUSE	3	
L1041-43	JOJDC0000099	FILTER	3		Δ PA3104	K5H5011A0004	FUSE	1	
L1051	JOJDC0000099	FILTER	1		Q900	B1ABDB000034	TRANSISTOR	1	
L1058	JOJDC0000099	FILTER	1		Q1600	DRA9114TOL	DIODE	1	
L1063	JOJCC0000405	FERRITE CORE	1		Q1601	DRC9114TOL	DIODE	1	
L1064	JOJDC0000099	FILTER	1		Q1602	DRA9114TOL	DIODE	1	
					Q1603, 04	DRC9144EOL	DIODE	2	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
Q1605	B1ABBL000006	TRANSISTOR	1		R655	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	1	
Q1700	DRC9114YOL	DIODE	1		R657-66	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	10	
Q1701	B1DFCC000012	TRANSISTOR	1		R668-70	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	3	
Q3000	DRA9144EOL	DIODE	1		R676	EXB24V103J	COMBI. R-R	10K	1
Q3001	B1ABBL000006	TRANSISTOR	1		R678	ERJ2GEJ330	M.RESISTOR CH 1/16W 33	1	
Q3002	B1ADBL000010	TRANSISTOR	1		R679	ERJ2RHD473	M.RESISTOR CH 1/16W 47K	1	
Q3100, 01	DRC9144EOL	DIODE	2		R681	ERJ2RHD101	M.RESISTOR CH 1/16W 100	1	
					R682	ERJ2RHD473	M.RESISTOR CH 1/16W 47K	1	
R100	ERJ2RHD392	M.RESISTOR CH 1/16W 3.9K	1		R684	ERJ2RHD473	M.RESISTOR CH 1/16W 47K	1	
R101	ERJ2RHD561	M.RESISTOR CH 1/16W 560	1		R695	ERJ2RHD473	M.RESISTOR CH 1/16W 47K	1	
R102	ERJ2RHD103	M.RESISTOR CH 1/16W 10K	1		R698-00	ERJ2RHD101	M.RESISTOR CH 1/16W 100	3	
R103	ERJ2RHD472	M.RESISTOR CH 1/16W 4.7K	1		R701, 02	ERJ2GEOR00	M.RESISTOR CH 1/16W	0 2	
R104	ERJ2RHD102	M.RESISTOR CH 1/16W 1K	1		R703	ERJ2RHD473	M.RESISTOR CH 1/16W 47K	1	
R105	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1		R704	ERJ2RHD433	M.RESISTOR CH 1/16W 43K	1	
R106	ERJ2RHD102	M.RESISTOR CH 1/16W 1K	1		R705	ERJ2RHD303	M.RESISTOR CH 1/16W 30K	1	
R107	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1		R706	ERJ2RHD273	M.RESISTOR CH 1/16W 27K	1	
R108	ERJ2RHD102	M.RESISTOR CH 1/16W 1K	1		R707	ERJ2GEOR00	M.RESISTOR CH 1/16W	0 1	
R109	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1		R708	ERJ2RHD223	M.RESISTOR CH 1/16W 22K	1	
R110	ERJ2RHD123	M.RESISTOR CH 1/16W 12K	1		R709-11	ERJ2GEOR00	M.RESISTOR CH 1/16W	0 3	
R111	ERJ2RHD103	M.RESISTOR CH 1/16W 10K	1		R712	ERJ2RHD472	M.RESISTOR CH 1/16W 4.7K	1	
R112	ERJ2RHD472	M.RESISTOR CH 1/16W 4.7K	1		R713	ERJ2RHD101	M.RESISTOR CH 1/16W 100	1	
R113-17	ERJ2GEOR00	M.RESISTOR CH 1/16W	0 5		R716	ERJ2RDK154	M.RESISTOR CH 1/16W 150K	1	
R118	ERJ2RHD103	M.RESISTOR CH 1/16W 10K	1		R717	ERJ2RHD563	M.RESISTOR CH 1/16W 56K	1	
R200	ERJ2RDK680	M.RESISTOR CH 1/16W 68	1		R718	ERJ2RDK154	M.RESISTOR CH 1/16W 150K	1	
R202, 03	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	2		R719	ERJ2RHD563	M.RESISTOR CH 1/16W 56K	1	
R204	ERJ2RHD201	M.RESISTOR CH 1/16W 200	1		R720	ERJ2RHD103	M.RESISTOR CH 1/16W 10K	1	
R205-08	ERJ2GEJ560	M.RESISTOR CH 1/16W 56	4		R721	ERJ2RHD101	M.RESISTOR CH 1/16W 100	1	
R209	ERJ2GEJ820	M.RESISTOR CH 1/16W 82	1		R722	ERJ2RHD123	M.RESISTOR CH 1/16W 12K	1	
R210-13	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	4		R723	ERJ2GEOR00	M.RESISTOR CH 1/16W	0 1	
R214-16	ERJ2GEJ560	M.RESISTOR CH 1/16W 56	3		R725	ERJ2RHD123	M.RESISTOR CH 1/16W 12K	1	
R217-20	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	4		R727	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1	
R221-23	EXBN8V750J	COMBI. R-R	75	3	R728, 29	ERJ2RHD101	M.RESISTOR CH 1/16W 100	2	
R224-27	EXBN8V470J	COMBI. R-R	47	4	R731	ERJ2RHD473	M.RESISTOR CH 1/16W 47K	1	
R228, 29	ERJ2RHD102	M.RESISTOR CH 1/16W 1K	2		R733	ERJ2RHD101	M.RESISTOR CH 1/16W 100	1	
R230	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1		R735	ERJ2GEOR00	M.RESISTOR CH 1/16W	0 1	
R301	ERJ2RHD101	M.RESISTOR CH 1/16W 100	1		R736, 37	ERJ2RHD103	M.RESISTOR CH 1/16W 10K	2	
R303, 04	ERJ2GEJ330	M.RESISTOR CH 1/16W 33	2		R738-41	ERJ2GEJ100	M.RESISTOR CH 1/16W 10	4	
R305	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1		R743	ERJ2GEOR00	M.RESISTOR CH 1/16W	0 1	
R307, 08	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	2		R744-46	ERJ2RHD104	M.RESISTOR CH 1/16W 100K	3	
R309-13	EXBN8V470J	COMBI. R-R	47	5	R748	ERJ2RHD101	M.RESISTOR CH 1/16W 100	1	
R314-20	EXBN8V330J	COMBI. R-R	33	7	R749	ERJ2RHD473	M.RESISTOR CH 1/16W 47K	1	
R321, 22	ERJ2GEJ330	M.RESISTOR CH 1/16W 33	2		R751, 52	ERJ2RHD102	M.RESISTOR CH 1/16W 1K	2	
R324-27	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	4		R753	ERJ2RHD101	M.RESISTOR CH 1/16W 100	1	
R328-31	EXBN8V470J	COMBI. R-R	47	4	R754, 55	ERJ2RHD104	M.RESISTOR CH 1/16W 100K	2	
R334-37	EXBN8V470J	COMBI. R-R	47	4	R756	ERJ2RHD103	M.RESISTOR CH 1/16W 10K	1	
R340-45	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	6		R757	ERJ2RHD473	M.RESISTOR CH 1/16W 47K	1	
R346	ERJ2GEOR00	M.RESISTOR CH 1/16W	0 1		R758	ERJ2RHD103	M.RESISTOR CH 1/16W 10K	1	
R351	ERJ2RHD102	M.RESISTOR CH 1/16W 1K	1		R759	ERJ2RHD333	M.RESISTOR CH 1/16W 33K	1	
R352	ERJ2RHD473	M.RESISTOR CH 1/16W 47K	1		R760	ERJ2RHD303	M.RESISTOR CH 1/16W 30K	1	
R353, 54	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	2		R761	ERJ2RHD101	M.RESISTOR CH 1/16W 100	1	
R355-58	EXBN8V330J	COMBI. R-R	33	4	R762	ERJ2RHD473	M.RESISTOR CH 1/16W 47K	1	
R400	ERJ2RHD332	M.RESISTOR CH 1/16W 3.3K	1		R763	ERJ2GEJ100	M.RESISTOR CH 1/16W 10	1	
R401	ERJ2RHD122	M.RESISTOR CH 1/16W 1.2K	1		R765	ERJ2RHD102	M.RESISTOR CH 1/16W 1K	1	
R403	ERJ2RHD103	M.RESISTOR CH 1/16W 10K	1		R766, 67	ERJ2GEOR00	M.RESISTOR CH 1/16W	0 2	
R508	ERJ3GEYJ101	M.RESISTOR CH 1/16W 100	1		R768	ERJ2RHD472	M.RESISTOR CH 1/16W 4.7K	1	
R511, 12	ERJ2RHD102	M.RESISTOR CH 1/16W 1K	2		R769	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1	
R515	ERJ2GEOR00	M.RESISTOR CH 1/16W	0 1		R770	EXBN8V103J	COMBI. R-R	10K	1
R601	ERJ2GEJ684	M.RESISTOR CH 1/16W 680K	1		R771, 72	EXBN8V101J	COMBI. R-R	100	2
R603	ERJ2RHD103	M.RESISTOR CH 1/16W 10K	1		R773	EXBN8V102J	COMBI. R-R	1K	1
R604	ERJ2GEJ105	M.RESISTOR CH 1/16W 1M	1		R774	ERJ2RHD473	M.RESISTOR CH 1/16W 47K	1	
R606	EXBN8V473J	COMBI. R-R	47K	1	R775-77	ERJ2RHD102	M.RESISTOR CH 1/16W 1K	3	
R609	ERJ2RHD103	M.RESISTOR CH 1/16W 10K	1		R779	ERJ2RHD472	M.RESISTOR CH 1/16W 4.7K	1	
R611	ERJ2RHD103	M.RESISTOR CH 1/16W 10K	1		R780	ERJ2GEOR00	M.RESISTOR CH 1/16W	0 1	
R615	ERJ2RHD103	M.RESISTOR CH 1/16W 10K	1		R781	ERJ2RHD472	M.RESISTOR CH 1/16W 4.7K	1	
R616	ERJ2GEOR00	M.RESISTOR CH 1/16W	0 1		R783	ERJ2RHD102	M.RESISTOR CH 1/16W 1K	1	
R617, 18	ERJ2RHD101	M.RESISTOR CH 1/16W 100	2		R784	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1	
R624	ERJ2GEOR00	M.RESISTOR CH 1/16W	0 1		R785, 86	ERJ2GEJ100	M.RESISTOR CH 1/16W 10	2	
R627	EXB24V103J	COMBI. R-R	10K	1	R787	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1	
R631, 32	ERJ2RHD101	M.RESISTOR CH 1/16W 100	2		R800	ERJ2GEOR00	M.RESISTOR CH 1/16W	0 1	
R633	EXBN8V102J	COMBI. R-R	1K	1	R804	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	1	
R639	ERJ2RHD101	M.RESISTOR CH 1/16W 100	1		R805	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1	
R643	EXBN8V473J	COMBI. R-R	47K	1	R806	ERJ2GEJ330	M.RESISTOR CH 1/16W 33	1	
R646	ERJ2RHD102	M.RESISTOR CH 1/16W 1K	1		R807	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	1	
R647	ERJ2GEOR00	M.RESISTOR CH 1/16W	0 1		R810-16	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	7	
R648	ERJ2RHD101	M.RESISTOR CH 1/16W 100	1		R817	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	1	
R652, 53	ERJ2RHD103	M.RESISTOR CH 1/16W 10K	2		R818	ERJ2RHD101	M.RESISTOR CH 1/16W 100	1	
R654	ERJ2GEJ330	M.RESISTOR CH 1/16W 33	1		R819	ERJ2GEJ330	M.RESISTOR CH 1/16W 33	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R824	ERJ2GEJ330	M.RESISTOR CH 1/16W 33	1		R1009	ERJ2RKD680	M.RESISTOR CH 1/16W 68	1	
R825	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1		R1012	ERJ2RHD102	M.RESISTOR CH 1/16W 1K	1	
R827, 28	ERJ2GEOR00	M.RESISTOR CH 1/16W 0	2		R1013	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1	
R830	ERJ2GEOR00	M.RESISTOR CH 1/16W 0	1		R1014	ERJ2RHD102	M.RESISTOR CH 1/16W 1K	1	
R831	EXBN8V103J	COMBI. R-R 10K	1		R1015	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	1	
R840-43	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	4		R1016	ERJ2GEJ100	M.RESISTOR CH 1/16W 10	1	
R846-49	ERJ2GEOR00	M.RESISTOR CH 1/16W 0	4		R1017, 18	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	2	
R852-54	ERJ2GEJ330	M.RESISTOR CH 1/16W 33	3		R1019	ERJ2GEJ100	M.RESISTOR CH 1/16W 10	1	
R855	ERJ2GEOR00	M.RESISTOR CH 1/16W 0	1		R1020	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	1	
R856	ERJ2RHD101	M.RESISTOR CH 1/16W 100	1		R1021	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1	
R857	ERJ2GEOR00	M.RESISTOR CH 1/16W 0	1		R1022, 23	ERJ2GEJ330	M.RESISTOR CH 1/16W 33	2	
R860	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	1		R1026	ERJ2RHD103	M.RESISTOR CH 1/16W 10K	1	
R862	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	1		R1030	ERJ2RKD680	M.RESISTOR CH 1/16W 68	1	
R863-78	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	16		R1031	ERJ2GEJ820	M.RESISTOR CH 1/16W 82	1	
R879-81	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	3		R1032	ERJ2RHD101	M.RESISTOR CH 1/16W 100	1	
R882	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1		R1033, 34	ERJ2GEJ820	M.RESISTOR CH 1/16W 82	2	
R883-86	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	4		R1035-40	ERJ2RKD680	M.RESISTOR CH 1/16W 68	6	
R887	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1		R1046	ERJ2RHD101	M.RESISTOR CH 1/16W 100	1	
R890	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1		R1047	ERJ2GEJ820	M.RESISTOR CH 1/16W 82	1	
R899	EXBN8V470J	COMBI. R-R 47	1		R1048	ERJ2RKD680	M.RESISTOR CH 1/16W 68	1	
R901	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1		R1049	ERJ2RHD102	M.RESISTOR CH 1/16W 1K	1	
R902	ERJ2RKD750	M.RESISTOR CH 1/10W 75	1		R1050, 51	ERJ2RKD680	M.RESISTOR CH 1/16W 68	2	
R903, 04	ERJ2RHD472	M.RESISTOR CH 1/16W 4.7K	2		R1052	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1	
R905	ERJ2RHD683	M.RESISTOR CH 1/16W 68K	1		R1053, 54	ERJ2GEJ330	M.RESISTOR CH 1/16W 33	2	
R906	ERJ2RHD102	M.RESISTOR CH 1/16W 1K	1		R1055	ERJ2RKD680	M.RESISTOR CH 1/16W 68	1	
R907, 08	ERJ2RHD223	M.RESISTOR CH 1/16W 22K	2		R1056	ERJ2GEJ560	M.RESISTOR CH 1/16W 56	1	
R909	ERJ2RHD101	M.RESISTOR CH 1/16W 100	1		R1057, 58	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	2	
R910	ERJ2RHD222	M.RESISTOR CH 1/16W 2.2M	1		R1062	ERJ2RHD103	M.RESISTOR CH 1/16W 10K	1	
R911, 12	ERJ2RHD104	M.RESISTOR CH 1/16W 100K	2		R1063	ERJ2GEJ820	M.RESISTOR CH 1/16W 82	1	
R913	ERJ2RHD221	M.RESISTOR CH 1/16W 220	1		R1064	ERJ2GEOR00	M.RESISTOR CH 1/16W 0	1	
R914-17	ERJ2RHD223	M.RESISTOR CH 1/16W 22K	4		R1066	ERJ2RHD102	M.RESISTOR CH 1/16W 1K	1	
R918	ERJ2RHD103	M.RESISTOR CH 1/16W 10K	1		R1069, 70	ERJ2RHD102	M.RESISTOR CH 1/16W 1K	2	
R919	ERJ2RHD102	M.RESISTOR CH 1/16W 1K	1		R1072	ERJ2GEOR00	M.RESISTOR CH 1/16W 0	1	
R920, 21	ERJ2RHD333	M.RESISTOR CH 1/16W 33K	2		R1074-76	ERJ2GEOR00	M.RESISTOR CH 1/16W 0	3	
R922	ERJ2RHD103	M.RESISTOR CH 1/16W 10K	1		R1077	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1	
R923, 24	ERJ2GEJ474	M.RESISTOR CH 1/16W 470K	2		R1078	ERJ2GEOR00	M.RESISTOR CH 1/16W 0	1	
R925, 26	ERJ2RHD102	M.RESISTOR CH 1/16W 1K	2		R1080	ERJ2GEJ560	M.RESISTOR CH 1/16W 56	1	
R927-30	ERJ2RHD223	M.RESISTOR CH 1/16W 22K	4		R1081	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	1	
R931, 32	ERJ2RHD104	M.RESISTOR CH 1/16W 100K	2		R1085	ERJ2GEJ820	M.RESISTOR CH 1/16W 82	1	
R933, 34	ERJ2GEOR00	M.RESISTOR CH 1/16W 0	2		R1086	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1	
R935-39	ERJ2RHD101	M.RESISTOR CH 1/16W 100	5		R1088	ERJ2GEJ820	M.RESISTOR CH 1/16W 82	1	
R940	ERJ2RHD104	M.RESISTOR CH 1/16W 100K	1		R1092	ERJ2GEJ330	M.RESISTOR CH 1/16W 33	1	
R941	ERJ2RHD102	M.RESISTOR CH 1/16W 1K	1		R1093	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1	
R942	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	1		R1094	ERJ2GEJ330	M.RESISTOR CH 1/16W 33	1	
R943	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1		R1095	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	1	
R944, 45	ERJ2RHD103	M.RESISTOR CH 1/16W 10K	2		R1096	ERJ2GEJ330	M.RESISTOR CH 1/16W 33	1	
R946	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	1		R1097	ERJ2RKD680	M.RESISTOR CH 1/16W 68	1	
R947-49	EXBN8V470J	COMBI. R-R 47	3		R1101	ERJ2RHD472	M.RESISTOR CH 1/16W 4.7K	1	
R950	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1		R1103	ERJ2RHD123	M.RESISTOR CH 1/16W 12K	1	
R951	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	1		R1104	ERJ2RHD103	M.RESISTOR CH 1/16W 10K	1	
R952	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1		R1105	ERJ2RHD101	M.RESISTOR CH 1/16W 100	1	
R953	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	1		R1106	EXBN8V103J	COMBI. R-R 10K	1	
R954	ERJ2RHD101	M.RESISTOR CH 1/16W 100	1		R1107	ERJ2RHD102	M.RESISTOR CH 1/16W 1K	1	
R955-61	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	7		R1108	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1	
R962	ERJ2RHD102	M.RESISTOR CH 1/16W 1K	1		R1109	ERJ2GEOR00	M.RESISTOR CH 1/16W 0	1	
R964-70	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	7		R1110	ERJ2RHD751	M.RESISTOR CH 1/16W 750	1	
R971	ERJ2GEOR00	M.RESISTOR CH 1/16W 0	1		R1111, 12	ERJ2RKD750	M.RESISTOR CH 1/10W 75	2	
R972	ERJ2GEJ330	M.RESISTOR CH 1/16W 33	1		R1113, 14	ERJ2RHD101	M.RESISTOR CH 1/16W 100	2	
R973	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1		R1115	ERJ2RKD680	M.RESISTOR CH 1/16W 68	1	
R974, 75	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	2		R1116, 17	ERJ2GEJ330	M.RESISTOR CH 1/16W 33	2	
R976, 77	ERJ2RHD101	M.RESISTOR CH 1/16W 100	2		R1121	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1	
R978, 79	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	2		R1123-27	EXBN8V470J	COMBI. R-R 47	5	
R981-83	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	3		R1130	ERJ2RHD101	M.RESISTOR CH 1/16W 100	1	
R984	ERJ2GEJ100	M.RESISTOR CH 1/16W 10	1		R1132	ERJ2GEOR00	M.RESISTOR CH 1/16W 0	1	
R985-87	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	3		R1134-38	ERJ2GEOR00	M.RESISTOR CH 1/16W 0	5	
R988	ERJ2GEJ100	M.RESISTOR CH 1/16W 10	1		R1141-44	ERJ2GEOR00	M.RESISTOR CH 1/16W 0	4	
R989	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1		R1207	ERJ2RHD103	M.RESISTOR CH 1/16W 10K	1	
R991	ERJ2RHD101	M.RESISTOR CH 1/16W 100	1		R1208	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	1	
R992	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	1		R1209, 10	ERJ2RKD680	M.RESISTOR CH 1/16W 68	2	
R999	ERJ2GEOR00	M.RESISTOR CH 1/16W 0	1		R1214	ERJ2RHD561	M.RESISTOR CH 1/16W 560	1	
R1000, 01	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	2		R1216	ERJ2RKD680	M.RESISTOR CH 1/16W 68	1	
R1002	ERJ2RKD680	M.RESISTOR CH 1/16W 68	1		R1218	ERJ2RHD511	M.RESISTOR CH 1/16W 510	1	
R1003	ERJ2GEJ105	M.RESISTOR CH 1/16W 1M	1		R1236	ERJ2RHD561	M.RESISTOR CH 1/16W 560	1	
R1004	ERJ2GEOR00	M.RESISTOR CH 1/16W 0	1		R1237, 38	ERJ2RHD473	M.RESISTOR CH 1/16W 47K	2	
R1005	ERJ2GEJ681	M.RESISTOR CH 1/16W 680	1		R1239	ERJ2RHD103	M.RESISTOR CH 1/16W 10K	1	
R1006	ERJ2GEOR00	M.RESISTOR CH 1/16W 0	1		R1240	ERJ2RHD471	M.RESISTOR CH 1/16W 470	1	
R1007, 08	ERJ2GEJ470	M.RESISTOR CH 1/16W 47	2		R1241	ERJ2RHD103	M.RESISTOR CH 1/16W 10K	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R1242	ERJ2RHD471	M. RESISTOR CH 1/16W 470	1		R1668-71	EXBN8V220J	COMBI. R-R	22	4
R1243, 44	ERJ2RHD102	M. RESISTOR CH 1/16W 1K	2		R1683-86	EXBN8V220J	COMBI. R-R	22	4
R1245, 46	ERJ2RHD182	M. RESISTOR CH 1/16W 1.8K	2		R1687-90	EXBN8V470J	COMBI. R-R	47	4
R1247-50	ERJ3GEYJ151	M. RESISTOR CH 1/16W 150	4		R1695	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	1	
R1251	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1		R1696	ERJ2RHD102	M. RESISTOR CH 1/16W 1K	1	
R1253-55	EXBN8V330J	COMBI. R-R	33	3	R1697-99	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	3	
R1300	ERJ2GEJ820	M. RESISTOR CH 1/16W 82	1		R1700-02	ERJ2RHD101	M. RESISTOR CH 1/16W 100	3	
R1302	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1		R1703	ERJ2RHD102	M. RESISTOR CH 1/16W 1K	1	
R1303	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	1		R1706	ERJ2RHD102	M. RESISTOR CH 1/16W 1K	1	
R1305	ERJ2RHD123	M. RESISTOR CH 1/16W 12K	1		R1707	ERJ2RKD680	M. RESISTOR CH 1/16W 68	1	
R1307	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1		R1708	ERJ2RHD102	M. RESISTOR CH 1/16W 1K	1	
R1309-14	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	6		R1709-12	EXBN8V101J	COMBI. R-R	100	4
R1315	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	1		R1713	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1	
R1318-23	EXBN8V680J	COMBI. R-R	68	6	R1714, 15	ERJ2RHD102	M. RESISTOR CH 1/16W 1K	2	
R1400	ERJ2GEJ820	M. RESISTOR CH 1/16W 82	1		R1716	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	1	
R1403, 04	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	2		R1717	EXBN8V330J	COMBI. R-R	33	1
R1405	ERJ2RHD101	M. RESISTOR CH 1/16W 100	1		R1718	ERJ2RHD332	M. RESISTOR CH 1/16W 3.3K	1	
R1407-12	EXBN8V680J	COMBI. R-R	68	6	R1719	ERJ2RHD122	M. RESISTOR CH 1/16W 1.2K	1	
R1500	ERJ2GEJ820	M. RESISTOR CH 1/16W 82	1		R1721	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	1	
R1502	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1		R1722	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1	
R1503	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	1		R1723	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	1	
R1504-07	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	4		R1725, 26	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	2	
R1509-12	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	4		R1727	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	1	
R1513-17	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	5		R1730-34	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	5	
R1518	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1		R1735, 36	ERJ2RHD102	M. RESISTOR CH 1/16W 1K	2	
R1519-23	EXBN8V470J	COMBI. R-R	47	5	R1737	ERJ2RHD104	M. RESISTOR CH 1/16W 100K	1	
R1524-31	EXBN8V220J	COMBI. R-R	22	8	R1738	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	1	
R1533	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1		R1739	ERJ2RHD473	M. RESISTOR CH 1/16W 47K	1	
R1534	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	1		R1740	ERJ2GEJ560	M. RESISTOR CH 1/16W 56	1	
R1535	ERJ2GEJ560	M. RESISTOR CH 1/16W 56	1		R1741	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1	
R1536, 37	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	2		R1742, 43	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	2	
R1539-43	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	5		R1744	ERJ8GEYJ102	M. RESISTOR CH 1/8W 1K	1	
R1544	ERJ2GEJ560	M. RESISTOR CH 1/16W 56	1		R1745, 46	ERJ2RHD101	M. RESISTOR CH 1/16W 100	2	
R1545, 46	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	2		R1747	EXBN8V102J	COMBI. R-R	1K	1
R1548	ERJ2RHD301	M. RESISTOR CH 1/16W 300	1		R1748, 49	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	2	
R1549	ERJ6RED510	M. RESISTOR CH 1/10W 51	1		R1750	EXBN8V103J	COMBI. R-R	10K	1
R1550-52	EXBN8V470J	COMBI. R-R	47	3	R1751	ERJ2RHD102	M. RESISTOR CH 1/16W 1K	1	
R1553-58	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	6		R1753	ERJ8GEYJ102	M. RESISTOR CH 1/8W 1K	1	
R1564	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	1		R1754	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1	
R1566	ERJ6RED220	M. RESISTOR CH 1/10W 22	1		R1755	ERJ2RHD102	M. RESISTOR CH 1/16W 1K	1	
R1567-69	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	3		R1802-05	EXBN8V470J	COMBI. R-R	47	4
R1577-80	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	4		R1806	ERJ3GEYJ101	M. RESISTOR CH 1/16W 100	1	
R1581	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1		R1811, 12	EXBN8V560J	COMBI. R-R	56	2
R1582	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	1		R1813, 14	EXBN8V470J	COMBI. R-R	47	2
R1583, 84	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	2		R1815	ERJ3GEYJ101	M. RESISTOR CH 1/16W 100	1	
R1585	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	1		R1816, 17	ERJ2RHD102	M. RESISTOR CH 1/16W 1K	2	
R1586	ERJ2RHD101	M. RESISTOR CH 1/16W 100	1		R1820, 21	ERJ2RHD102	M. RESISTOR CH 1/16W 1K	2	
R1588, 89	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	2		R1824	EXBN8V103J	COMBI. R-R	10K	1
R1590	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1		R1902	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1	
R1591, 92	EXBN8V330J	COMBI. R-R	33	2	R1903-05	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	3	
R1593	EXBN8V220J	COMBI. R-R	22	1	R1906	ERJ2RHD222	M. RESISTOR CH 1/16W 2.2M	1	
R1595, 96	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	2		R1907	ERJ2RHD102	M. RESISTOR CH 1/16W 1K	1	
R1600	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1		R1908, 09	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	2	
R1602	ERJ2RHD102	M. RESISTOR CH 1/16W 1K	1		R1910	ERJ2RHD102	M. RESISTOR CH 1/16W 1K	1	
R1603, 04	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	2		R1911	ERJ2GEJ183	M. RESISTOR CH 1/16W 18K	1	
R1611-16	EXBN8V103J	COMBI. R-R	10K	6	R1912	ERJ2RHD223	M. RESISTOR CH 1/16W 22K	1	
R1617	EXB24V103J	COMBI. R-R	10K	1	R1913	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1	
R1618-20	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	3		R1914	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	1	
R1621	ERJ2RHD101	M. RESISTOR CH 1/16W 100	1		R1915	ERJ2RHD101	M. RESISTOR CH 1/16W 100	1	
R1622	ERJ2RHD471	M. RESISTOR CH 1/16W 470	1		R1916, 17	ERJ2RHD102	M. RESISTOR CH 1/16W 1K	2	
R1623	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	1		R1918-21	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	4	
R1624	EXB24V103J	COMBI. R-R	10K	1	R1923, 24	ERJ2GEJ105	M. RESISTOR CH 1/16W 1M	2	
R1625	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	1		R1925-30	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	6	
R1627, 28	ERJ2RHD473	M. RESISTOR CH 1/16W 47K	2		R1931, 32	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	2	
R1629	ERJ2RHD333	M. RESISTOR CH 1/16W 33K	1		R1933	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	1	
R1630	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1		R1934	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1	
R1633	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	1		R1935	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	1	
R1634	ERJ2RHD563	M. RESISTOR CH 1/16W 56K	1		R1936	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1	
R1639, 40	ERJ2RHD101	M. RESISTOR CH 1/16W 100	2		R2000	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	1	
R1644-47	ERJ2RHD101	M. RESISTOR CH 1/16W 100	4		R2001-06	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	6	
R1649, 50	ERJ2RHD101	M. RESISTOR CH 1/16W 100	2		R2011	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	1	
R1652-54	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	3		R2012, 13	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	2	
R1655-58	EXBN8V330J	COMBI. R-R	33	4	R2015	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1	
R1659	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1		R2016	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	1	
R1660	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1		R2017-19	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	3	
R1661-65	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	5		R2020	ERJ2RKD680	M. RESISTOR CH 1/16W 68	1	
R1667	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1		R2021	EXBN8V220J	COMBI. R-R	22	1

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R2026	ERJ2RHD101	M. RESISTOR CH 1/16W	100	1	R2431	ERJ2RHD102	M. RESISTOR CH 1/16W	1K	1
R2027-35	ERJ2GEJ220	M. RESISTOR CH 1/16W	22	9	R2432	ERJ3GEYJ510	M. RESISTOR CH 1/16W	51	1
R2036	ERJ2GEJ330	M. RESISTOR CH 1/16W	33	1	R2433	ERJ2RHD101	M. RESISTOR CH 1/16W	100	1
R2037	ERJ2GEJ220	M. RESISTOR CH 1/16W	22	1	R2500, 01	EXB24V103J	COMBI. R-R	10K	2
R2038	ERJ2GEOR00	M. RESISTOR CH 1/16W	0	1	R2505	ERJ2RHD103	M. RESISTOR CH 1/16W	10K	1
R2039-41	EXBN8V220J	COMBI. R-R	22	3	R2507, 08	ERJ2GEJ470	M. RESISTOR CH 1/16W	47	2
R2042-45	EXBN8V680J	COMBI. R-R	68	4	R2509-11	ERJ2GEJ220	M. RESISTOR CH 1/16W	22	3
R2046-50	EXBN8V220J	COMBI. R-R	22	5	R2512-15	ERJ2GEJ330	M. RESISTOR CH 1/16W	33	4
R2051	ERJ2GEJ105	M. RESISTOR CH 1/16W	1M	1	R2516, 17	ERJ2GEJ470	M. RESISTOR CH 1/16W	47	2
R2053	EXBN8V101J	COMBI. R-R	100	1	R2518, 19	ERJ2GEJ330	M. RESISTOR CH 1/16W	33	2
R2054	ERJ2RHD103	M. RESISTOR CH 1/16W	10K	1	R2520	ERJ2GEOR00	M. RESISTOR CH 1/16W	0	1
R2057	ERJ2RHD103	M. RESISTOR CH 1/16W	10K	1	R2521-25	ERJ2GEJ220	M. RESISTOR CH 1/16W	22	5
R2100, 01	ERJ2GEJ220	M. RESISTOR CH 1/16W	22	2	R2526	ERJ2GEJ272	M. RESISTOR CH 1/16W	2.7K	1
R2107, 08	ERJ2RHD103	M. RESISTOR CH 1/16W	10K	2	R2527	ERJ2GEOR00	M. RESISTOR CH 1/16W	0	1
R2109	ERJ2GEJ220	M. RESISTOR CH 1/16W	22	1	R2528-30	ERJ2GEJ272	M. RESISTOR CH 1/16W	2.7K	3
R2110	ERJ2GEJ330	M. RESISTOR CH 1/16W	33	1	R2531	EXBN8V103J	COMBI. R-R	10K	1
R2113	ERJ2GEJ220	M. RESISTOR CH 1/16W	22	1	R2532	ERJ2GEJ272	M. RESISTOR CH 1/16W	2.7K	1
R2115, 16	EXBN8V330J	COMBI. R-R	33	2	R2533	EXB24V103J	COMBI. R-R	10K	1
R2117	ERJ2RKD680	M. RESISTOR CH 1/16W	68	1	R2534	ERJ2RHD103	M. RESISTOR CH 1/16W	10K	1
R2118-20	EXBN8V220J	COMBI. R-R	22	3	R2535	ERJ2GEJ272	M. RESISTOR CH 1/16W	2.7K	1
R2121	ERJ2GEJ470	M. RESISTOR CH 1/16W	47	1	R2536	ERJ2RHD103	M. RESISTOR CH 1/16W	10K	1
R2125-35	ERJ2GEJ220	M. RESISTOR CH 1/16W	22	11	R2537	EXBN8V103J	COMBI. R-R	10K	1
R2136-39	EXBN8V220J	COMBI. R-R	22	4	R2538	ERJ2RHD103	M. RESISTOR CH 1/16W	10K	1
R2140	ERJ2RKD680	M. RESISTOR CH 1/16W	68	1	R2539	ERJ2GEJ470	M. RESISTOR CH 1/16W	47	1
R2141	ERJ2GEJ220	M. RESISTOR CH 1/16W	22	1	R2540, 41	ERJ2GEJ272	M. RESISTOR CH 1/16W	2.7K	2
R2142	ERJ2RHD101	M. RESISTOR CH 1/16W	100	1	R2542, 43	ERJ2RHD102	M. RESISTOR CH 1/16W	1K	2
R2143	ERJ2GEJ220	M. RESISTOR CH 1/16W	22	1	R2544	ERJ2GEJ330	M. RESISTOR CH 1/16W	33	1
R2144, 45	ERJ2RHD103	M. RESISTOR CH 1/16W	10K	2	R2545, 46	ERJ2GEOR00	M. RESISTOR CH 1/16W	0	2
R2146	ERJ2GEJ220	M. RESISTOR CH 1/16W	22	1	R2547	ERJ2GEJ330	M. RESISTOR CH 1/16W	33	1
R2147	ERJ2RHD103	M. RESISTOR CH 1/16W	10K	1	R2548	ERJ2RHD103	M. RESISTOR CH 1/16W	10K	1
R2148-57	EXBN8V220J	COMBI. R-R	22	10	R2549, 50	ERJ2RHD102	M. RESISTOR CH 1/16W	1K	2
R2158, 59	ERJ2RHD103	M. RESISTOR CH 1/16W	10K	2	R2551, 52	ERJ2GEJ470	M. RESISTOR CH 1/16W	47	2
R2200-15	EXBN8V330J	COMBI. R-R	33	16	R2553	ERJ2RHD103	M. RESISTOR CH 1/16W	10K	1
R2300	ERJ2RHD472	M. RESISTOR CH 1/16W	4.7K	1	R2554	ERJ2GEJ330	M. RESISTOR CH 1/16W	33	1
R2301	ERJ2RHD102	M. RESISTOR CH 1/16W	1K	1	R2555	ERJ2RHD103	M. RESISTOR CH 1/16W	10K	1
R2302	ERJ2RHD103	M. RESISTOR CH 1/16W	10K	1	R2556	ERJ2RHD102	M. RESISTOR CH 1/16W	1K	1
R2303	ERJ2RHD102	M. RESISTOR CH 1/16W	1K	1	R2557-62	ERJ2RHD103	M. RESISTOR CH 1/16W	10K	6
R2304	ERJ2GEJ470	M. RESISTOR CH 1/16W	47	1	R2563, 64	ERJ2GEJ470	M. RESISTOR CH 1/16W	47	2
R2305	ERJ2RHD472	M. RESISTOR CH 1/16W	4.7K	1	R2565	ERJ2RKD680	M. RESISTOR CH 1/16W	68	1
R2306, 07	ERJ2GEOR00	M. RESISTOR CH 1/16W	0	2	R2566	ERJ2GEJ470	M. RESISTOR CH 1/16W	47	1
R2309	EXBN8V103J	COMBI. R-R	10K	1	R2567-75	EXBN8V220J	COMBI. R-R	22	9
R2310	ERJ2RHD104	M. RESISTOR CH 1/16W	100K	1	R2576	ERJ2GEJ470	M. RESISTOR CH 1/16W	47	1
R2311	ERJ2RHD912	M. RESISTOR CH 1/16W	9.1K	1	R2577	ERJ2GEJ560	M. RESISTOR CH 1/16W	56	1
R2313	ERJ2GEJ560	M. RESISTOR CH 1/16W	56	1	R2578, 79	ERJ2GEJ330	M. RESISTOR CH 1/16W	33	2
R2314	ERJ2GEOR00	M. RESISTOR CH 1/16W	0	1	R2580	ERJ2RHD332	M. RESISTOR CH 1/16W	3.3K	1
R2315	ERJ2GEJ560	M. RESISTOR CH 1/16W	56	1	R2581	ERJ2RHD122	M. RESISTOR CH 1/16W	1.2K	1
R2317	ERJ2GEJ560	M. RESISTOR CH 1/16W	56	1	R2582, 83	ERJ2RHD103	M. RESISTOR CH 1/16W	10K	2
R2318, 19	ERJ2GEOR00	M. RESISTOR CH 1/16W	0	2	R2584	ERJ2RHD472	M. RESISTOR CH 1/16W	4.7K	1
R2320	ERJ2GEJ560	M. RESISTOR CH 1/16W	56	1	R2586, 87	ERJ2RHD103	M. RESISTOR CH 1/16W	10K	2
R2321	ERJ2RHD512	M. RESISTOR CH 1/16W	5.1K	1	R2588	ERJ2GEJ330	M. RESISTOR CH 1/16W	33	1
R2324	ERJ3GEYOR00	M. RESISTOR CH 1/16W	0	1	R2590	ERJ2GEJ330	M. RESISTOR CH 1/16W	33	1
R2325, 26	EXBN8V330J	COMBI. R-R	33	2	R2591	ERJ2RHD102	M. RESISTOR CH 1/16W	1K	1
R2327, 28	ERJ2GEJ470	M. RESISTOR CH 1/16W	47	2	R2592	ERJ2RHD103	M. RESISTOR CH 1/16W	10K	1
R2400	ERJ2RHD123	M. RESISTOR CH 1/16W	12K	1	R2593-95	ERJ2GEJ330	M. RESISTOR CH 1/16W	33	3
R2401, 02	ERJ2RHD102	M. RESISTOR CH 1/16W	1K	2	R2596, 97	ERJ2GEJ470	M. RESISTOR CH 1/16W	47	2
R2404	ERJ2RHD473	M. RESISTOR CH 1/16W	47K	1	R2598	ERJ2RKD680	M. RESISTOR CH 1/16W	68	1
R2405, 06	ERJ2RHD102	M. RESISTOR CH 1/16W	1K	2	R2599	ERJ2GEJ470	M. RESISTOR CH 1/16W	47	1
R2408	ERJ2RHD104	M. RESISTOR CH 1/16W	100K	1	R2600, 01	EXBN8V100J	COMBI. R-R	10	2
R2409	ERJ2RHD223	M. RESISTOR CH 1/16W	22K	1	R2602	EXBN8V330J	COMBI. R-R	33	1
R2410, 11	ERJ2GEOR00	M. RESISTOR CH 1/16W	0	2	R2603	EXBN8V100J	COMBI. R-R	10	1
R2412	ERJ2RHD223	M. RESISTOR CH 1/16W	22K	1	R2604-07	EXBN8V220J	COMBI. R-R	22	4
R2413	ERJ2RKD334	M. RESISTOR CH 1/10W	330K	1	R2608	EXBN8V560J	COMBI. R-R	56	1
R2415	ERJ2RHD222	M. RESISTOR CH 1/16W	2.2M	1	R2609	EXBN8V470J	COMBI. R-R	47	1
R2416	ERJ2RHD332	M. RESISTOR CH 1/16W	3.3K	1	R2610	EXBN8V560J	COMBI. R-R	56	1
R2417	ERJ2RHD683	M. RESISTOR CH 1/16W	68K	1	R2611-15	EXBN8V470J	COMBI. R-R	47	5
R2418	ERJ2RHD333	M. RESISTOR CH 1/16W	33K	1	R2616	EXBN8V100J	COMBI. R-R	10	1
R2419	ERJ2RHD222	M. RESISTOR CH 1/16W	2.2M	1	R2617	EXBN8V220J	COMBI. R-R	22	1
R2420	ERJ2RHD123	M. RESISTOR CH 1/16W	12K	1	R2618	EXBN8V330J	COMBI. R-R	33	1
R2421	ERJ2GEOR00	M. RESISTOR CH 1/16W	0	1	R2619	EXBN8V220J	COMBI. R-R	22	1
R2422	ERJ2RHD473	M. RESISTOR CH 1/16W	47K	1	R2620, 21	EXBN8V560J	COMBI. R-R	56	2
R2423, 24	ERJ2RHD103	M. RESISTOR CH 1/16W	10K	2	R2622-25	EXBN8V470J	COMBI. R-R	47	4
R2425	ERJ2RHD104	M. RESISTOR CH 1/16W	100K	1	R2626	ERJ2GEJ470	M. RESISTOR CH 1/16W	47	1
R2426	ERJ2RHD103	M. RESISTOR CH 1/16W	10K	1	R2627-30	EXBN8V220J	COMBI. R-R	22	4
R2427	ERJ2RHD332	M. RESISTOR CH 1/16W	3.3K	1	R2631, 32	EXBN8V470J	COMBI. R-R	47	2
R2428	ERJ2RHD242	M. RESISTOR CH 1/16W	2.4K	1	R2633	ERJ2GEJ470	M. RESISTOR CH 1/16W	47	1
R2429	ERJ2RKD824	M. RESISTOR CH 1/10W	820K	1	R2634	ERJ2GEJ330	M. RESISTOR CH 1/16W	33	1
R2430	ERJ2RHD512	M. RESISTOR CH 1/16W	5.1K	1	R2635	ERJ2GEOR00	M. RESISTOR CH 1/16W	0	1

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R2636	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	1		R3318, 19	EXBN8V101J	COMBI. R-R	100	2
R2637, 38	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	2		R3322, 23	ERJ2RHD101	M. RESISTOR CH 1/16W 100	2	
R2639, 40	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	2		R3500	ERJ2GEJ100	M. RESISTOR CH 1/16W 10	1	
R2641	EXBN8V470J	COMBI. R-R	47	1	R3501	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1	
R2642-44	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	3		R3502, 03	ERJ2RHD101	M. RESISTOR CH 1/16W 100	2	
R2645-49	EXBN8V330J	COMBI. R-R	33	5	R3504	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1	
R2650, 51	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	2		R3505-07	ERJ2RHD101	M. RESISTOR CH 1/16W 100	3	
R2652	ERJ2GEJ100	M. RESISTOR CH 1/16W 10	1		R3511	ERJ2RHD101	M. RESISTOR CH 1/16W 100	1	
R2653	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	1		R3514-16	ERJ2RHD101	M. RESISTOR CH 1/16W 100	3	
R2654	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1		R3518-20	ERJ2RHD101	M. RESISTOR CH 1/16W 100	3	
R2655-58	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	4		R3523	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1	
R2659	ERJ2GEJ100	M. RESISTOR CH 1/16W 10	1		R3525	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1	
R2660	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1		R3528, 29	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	2	
R2661, 62	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	2		R3530	EXBN8V103J	COMBI. R-R	10K	1
R2664	ERJ2RKD680	M. RESISTOR CH 1/16W 68	1		R3534	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1	
R2665	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1		R3536	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1	
R2666	EXBN8V330J	COMBI. R-R	33	1	R3538	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1	
R2700	ERJ2RHD101	M. RESISTOR CH 1/16W 100	1		R3540-47	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	8	
R2702	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	1		R3551, 52	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	2	
R2703	ERJ2RHD101	M. RESISTOR CH 1/16W 100	1		R3553	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1	
R2704-14	EXBN8V220J	COMBI. R-R	22	11	R3554	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1	
R2715	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	1		R3555	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1	
R2716	ERJ2RKD680	M. RESISTOR CH 1/16W 68	1		R3561-68	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	8	
R2717	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	1		R3570	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1	
R2718	ERJ2RHD473	M. RESISTOR CH 1/16W 47K	1		R3571	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1	
R2719	ERJ2GEJ105	M. RESISTOR CH 1/16W 1M	1		R3572-75	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	4	
R2720	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1		R3576-79	ERJ2RHD102	M. RESISTOR CH 1/16W 1K	4	
R2721	ERJ2RHD101	M. RESISTOR CH 1/16W 100	1		R3580	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1	
R2722	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	1		R3600-15	EXBN8V100J	COMBI. R-R	10	16
R2723	ERJ6ENF2431	M. RESISTOR CH 1/10W 430	1		R3616-18	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	3	
R2724, 25	ERJ6ENF39R2	M. RESISTOR CH 1/10W 39	2		R3619-22	EXBN8V100J	COMBI. R-R	10	4
R2726	ERJ2RHD152	M. RESISTOR CH 1/16W 1.5K	1		R3626-29	EXBN8V100J	COMBI. R-R	10	4
R2727	ERJ2RHD473	M. RESISTOR CH 1/16W 47K	1		R3634-37	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	4	
R2729	ERJ2RHD473	M. RESISTOR CH 1/16W 47K	1		R3638	ERJ2GEJ100	M. RESISTOR CH 1/16W 10	1	
R2730	ERJ6ENF2432	M. RESISTOR CH 1/10W 4.3K	1		R3639-44	ERJ2RHD101	M. RESISTOR CH 1/16W 100	6	
R2732	EXBN8V102J	COMBI. R-R	1K	1	R3645	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1	
R2733	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	1		R3646-48	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	3	
R2800, 01	EXBN8V220J	COMBI. R-R	22	2	R3649	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1	
R2802	ERJ2RHD101	M. RESISTOR CH 1/16W 100	1		R3650-54	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	5	
R2803	EXBN8V330J	COMBI. R-R	33	1	R3655	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1	
R2804-12	EXBN8V220J	COMBI. R-R	22	9	R3656-58	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	3	
R2813	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	1		R3659	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1	
R2815	ERJ2RHD101	M. RESISTOR CH 1/16W 100	1		R3660-64	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	5	
R2817	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1		R3665	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1	
R2818	ERJ2RKD680	M. RESISTOR CH 1/16W 68	1		R3666-72	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	7	
R2819	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	1		R3673	EXBN8V470J	COMBI. R-R	47	1
R2821	ERJ2RHD152	M. RESISTOR CH 1/16W 1.5K	1		R3674	EXBN8V330J	COMBI. R-R	33	1
R2823, 24	ERJ2RHD152	M. RESISTOR CH 1/16W 1.5K	2		R3675	EXBN8V470J	COMBI. R-R	47	1
R2826	ERJ3RBD162	M. RESISTOR CH 1/16W 1.6K	1		R3676	EXBN8V330J	COMBI. R-R	33	1
R2827	EXBN8V103J	COMBI. R-R	10K	1	R3677	EXBN8V470J	COMBI. R-R	47	1
R2828	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	1		R3678	EXBN8V330J	COMBI. R-R	33	1
R2830	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	1		R3679	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	1	
R3000	ERJ2RHD104	M. RESISTOR CH 1/16W 100K	1		R3680	EXBN8V330J	COMBI. R-R	33	1
R3001, 02	ERJ2RHD473	M. RESISTOR CH 1/16W 47K	2		R3681-86	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	6	
R3003, 04	ERJ2GEJ224	M. RESISTOR CH 1/16W 220K	2		R3687	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1	
R3008	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	1		R3688	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1	
R3101	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1		R3693-96	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	4	
R3103	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1		R3697	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	1	
R3105	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1		R3698-00	ERJ2RHD101	M. RESISTOR CH 1/16W 100	3	
R3107	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1		R3701	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1	
R3109	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1		R3702	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1	
R3110-13	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	4		R3703	ERJ2RHD102	M. RESISTOR CH 1/16W 1K	1	
R3116-19	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	4		R3704-06	ERJ2RHD101	M. RESISTOR CH 1/16W 100	3	
R3120-22	ERJ2RHD472	M. RESISTOR CH 1/16W 4.7K	3		R3730	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1	
R3125	EXBN8V473J	COMBI. R-R	47K	1	R3731	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	1	
R3126	EXB24V103J	COMBI. R-R	10K	1	R3732	ERJ3GEYJ101	M. RESISTOR CH 1/16W 100	1	
R3127	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1		R3733-37	ERJ2RHD102	M. RESISTOR CH 1/16W 1K	5	
R3128-39	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	12		R3739	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1	
R3209, 10	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	2		R3741-44	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	4	
R3211-17	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	7		R3746	ERJ2RHD472	M. RESISTOR CH 1/16W 4.7K	1	
R3300-02	ERJ2RHD101	M. RESISTOR CH 1/16W 100	3		R3747	ERJ2RHD112	M. RESISTOR CH 1/16W 1.1K	1	
R3303-07	EXBN8V101J	COMBI. R-R	100	5	R3748	ERJ2RHD472	M. RESISTOR CH 1/16W 4.7K	1	
R3308, 09	ERJ2RHD101	M. RESISTOR CH 1/16W 100	2		R3749, 50	ERJ2RHD102	M. RESISTOR CH 1/16W 1K	2	
R3310-12	EXBN8V101J	COMBI. R-R	100	3	R3751	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1	
R3313, 14	ERJ2RHD101	M. RESISTOR CH 1/16W 100	2		R3753	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1	
R3315, 16	EXBN8V101J	COMBI. R-R	100	2	R3755	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1	
R3317	ERJ2RHD101	M. RESISTOR CH 1/16W 100	1		R3757	ERJ2RHD123	M. RESISTOR CH 1/16W 12K	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R3758	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	1		C4118, 19	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2	
R3759	ERJ2RHD472	M. RESISTOR CH 1/16W 4.7K	1		C4120	ECJ1VC1H330J	C. CAPACITOR CH 50V 33P	1	
R3761, 62	ERJ2RHD102	M. RESISTOR CH 1/16W 1K	2		C4121-23	EEHPIA100	E. CAPACITOR 10V 10U	3	
R3800	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	1		C4124, 25	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2	
R3801	ERJ2GEJ100	M. RESISTOR CH 1/16W 10	1		C4126, 27	ECJ1VC1H330J	C. CAPACITOR CH 50V 33P	2	
R3802-04	EXBN8V470J	COMBI. R-R	47	3	C4128, 29	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2	
R3805	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	1		C4130	ECJ1VC1H330J	C. CAPACITOR CH 50V 33P	1	
R3806, 07	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	2		C4131-33	EEHPIA100	E. CAPACITOR 10V 10U	3	
R3808-24	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	17		C4134, 35	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2	
R3825-32	EXBN8V330J	COMBI. R-R	33	8	C4136, 37	ECJ1VC1H330J	C. CAPACITOR CH 50V 33P	2	
R3833	ERJ3GEYJ101	M. RESISTOR CH 1/16W 100	1		C4140	ECJ1VC1H330J	C. CAPACITOR CH 50V 33P	1	
R3834-37	ERJ2RHD102	M. RESISTOR CH 1/16W 1K	4		C4141	EEHPIA100	E. CAPACITOR 10V 10U	1	
R3838-49	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	12		C4201, 02	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2	
R3850	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1		C4203, 04	ECJ1VB1C223K	C. CAPACITOR CH 16V 0.022U	2	
R3851-53	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	3		C4205, 06	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2	
R3858, 59	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	2		C4207	ECJ1VB1C223K	C. CAPACITOR CH 16V 0.022U	1	
R3880	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1		C4208, 09	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2	
R3881	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1		C4210, 11	ECJ1VB1C223K	C. CAPACITOR CH 16V 0.022U	2	
R3882	EXBN8V103J	COMBI. R-R	10K	1	C4212, 13	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2	
R3883, 84	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	2		C4214	ECJ1VB1C223K	C. CAPACITOR CH 16V 0.022U	1	
R3885	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1		C4215, 16	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2	
R3891, 92	ERJ2RHD102	M. RESISTOR CH 1/16W 1K	2		C4217, 18	ECJ1VB1C223K	C. CAPACITOR CH 16V 0.022U	2	
R3893-02	EXBN8V100J	COMBI. R-R	10	10	C4219, 20	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2	
R3903-06	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	4		C4221	ECJ1VB1C223K	C. CAPACITOR CH 16V 0.022U	1	
R3907, 08	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	2		C4222, 23	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2	
R3909, 10	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	2		C4224, 25	ECJ1VB1C223K	C. CAPACITOR CH 16V 0.022U	2	
R3911-16	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	6		C4226, 27	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2	
R3917, 18	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	2		C4228	ECJ1VB1C223K	C. CAPACITOR CH 16V 0.022U	1	
R3919	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1		C4229-36	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	8	
TP976	EYF6CU	TEST POINT	1		C4301-04	EEHPIA100	E. CAPACITOR 16V 10U	4	
TP3100-07	EYF6CU	TEST POINT	8		C4305	ECJ3YB1C106K	C. CAPACITOR CH 16V 10U	1	
X600	HOJ180500014	CRYSTAL OSCILLATOR	1		C4306	ECJ1VB1C223K	C. CAPACITOR CH 16V 0.022U	1	
X900	H1C2705B0020	CRYSTAL OSCILLATOR	1		C4307	ECJ3YB1C106K	C. CAPACITOR CH 16V 10U	1	
X901	H1C7415B0008	CRYSTAL OSCILLATOR	1		C4308, 09	ECJ1VB1C223K	C. CAPACITOR CH 16V 0.022U	2	
X902	H1C7425B0008	CRYSTAL OSCILLATOR	1		C4310, 11	ECJ3YB1C106K	C. CAPACITOR CH 16V 10U	2	
X1000	HOJ330500008	CRYSTAL OSCILLATOR	1		C4312	ECJ1VB1C223K	C. CAPACITOR CH 16V 0.022U	1	
X1600	HOJ327200085	CRYSTAL OSCILLATOR	1		C4313, 14	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2	
X2000	HOJ180500014	CRYSTAL OSCILLATOR	1		C4315	ECJ1VC1H330J	C. CAPACITOR CH 50V 33P	1	
X2300	HOJ246500002	CRYSTAL OSCILLATOR	1		C4316, 17	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2	
X2500	HOJ327200085	CRYSTAL OSCILLATOR	1		C4318	EEHPIA100	E. CAPACITOR 10V 10U	1	
X2700	HOJ300500024	CRYSTAL OSCILLATOR	1		C4319, 20	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2	
X2800	HOJ300500024	CRYSTAL OSCILLATOR	1		C4321	ECJ1VC1H330J	C. CAPACITOR CH 50V 33P	1	
ZA3100, 01	K4CD01000015	TERMINAL	2		C4322	EEHPIA100	E. CAPACITOR 10V 10U	1	
ZA3105	K4CD01000015	TERMINAL	1		C4323-25	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	3	
		MISCELLANEOUS			C4326	ECJ1VC1H330J	C. CAPACITOR CH 50V 33P	1	
	VGQ0N34	BUSTERAID	1		C4327, 28	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2	
	VSC6117	MAIN SHIELD	1		C4329	EEHPIA100	E. CAPACITOR 10V 10U	1	
	VMZ3811	SDI BARRIER	1		C4330, 31	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2	
	VMZ3460	MOTHER PB BARRIER (1)	1		C4332	ECJ1VC1H330J	C. CAPACITOR CH 50V 33P	1	
	VJF1562	LOCKING CLAMP	1		C4333	EEHPIA100	E. CAPACITOR 10V 10U	1	
	VGQ0N32	COOLING SHEET	2		C4401-04	ECJ1VC1H181J	C. CAPACITOR CH 50V 180P	4	
	XYN26+-J8FJ	SCREW	1		C4405-12	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	8	
					C4413-16	ECJ3YB1C106K	C. CAPACITOR CH 16V 10U	4	
					C4417-20	F3G1A226A012	T. CAPACITOR CH 10V 22U	4	
					C4421-24	F1J0J106A013	C. CAPACITOR CH 6.3V 10U	4	
					C4425-28	EEHPIA100	E. CAPACITOR 10V 10U	4	
					C4429-32	ECJ1VC1H330J	C. CAPACITOR CH 50V 33P	4	
					C4433-44	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	12	
					C4501, 02	EEHPIA100	E. CAPACITOR 16V 10U	2	
					C4503	ECJ3YB1C106K	C. CAPACITOR CH 16V 10U	1	
					C4504, 05	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2	
					C4506	ECJ3YB1C106K	C. CAPACITOR CH 16V 10U	1	
					C4507	ECJ2FB1C225K	C. CAPACITOR CH 16V 2.2U	1	
					C4508	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	1	
					C4509, 10	EEHPIA100	E. CAPACITOR 16V 10U	2	
					C4511	ECJ3YB1C106K	C. CAPACITOR CH 16V 10U	1	
					C4512, 13	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2	
					C4514	ECJ3YB1C106K	C. CAPACITOR CH 16V 10U	1	
					C4515	ECJ2FB1C225K	C. CAPACITOR CH 16V 2.2U	1	
					C4516	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	1	
					C4517	ECJ1VC1H100D	C. CAPACITOR CH 50V 10P	1	
					C4518	ECJ3YB1C106K	C. CAPACITOR CH 16V 10U	1	
					C4519	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	1	
					C4520	ECJ3YB1C106K	C. CAPACITOR CH 16V 10U	1	
					C4521	EEHPIA100	E. CAPACITOR 16V 10U	1	
					C4522	ECJ1VC1H102J	C. CAPACITOR CH 50V 1000P	1	
					C4523, 24	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2	
■ E2	VEP04944A	AUDIO P. C. BOARD	1	(RTL)					
C4101, 02	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2						
C4103	ECJ1VC1H330J	C. CAPACITOR CH 50V 33P	1						
C4104, 05	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2						
C4106	ECJ1VC1H330J	C. CAPACITOR CH 50V 33P	1						
C4107	EEHPIA100	E. CAPACITOR 10V 10U	1						
C4108, 09	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2						
C4110	ECJ1VC1H330J	C. CAPACITOR CH 50V 33P	1						
C4111, 12	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2						
C4113	ECJ1VC1H330J	C. CAPACITOR CH 50V 33P	1						
C4114	EEHPIA100	E. CAPACITOR 10V 10U	1						
C4115, 16	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2						
C4117	ECJ1VC1H330J	C. CAPACITOR CH 50V 33P	1						

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
C4525	ECJ1VC1H181J	C. CAPACITOR CH 50V 180P	1		IC4401-04	COJBAA000393	IC	4	
C4526	ECJ1VC1H330J	C. CAPACITOR CH 50V 33P	1		IC4405-08	COJBAR000432	IC	4	
C4527, 28	EEHPIA100	E. CAPACITOR 16V 10U	2		IC4409-12	COABBB000032	IC	4	
C4529	ECJ1VC1H102J	C. CAPACITOR CH 50V 1000P	1		IC4413, 14	COABBB000179	IC	2	
C4530, 31	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2		IC4501, 02	COFBAK000020	IC	2	
C4532	ECJ1VC1H181J	C. CAPACITOR CH 50V 180P	1		IC4503	COJBAZ001121	IC	1	
C4533	ECJ1VC1H330J	C. CAPACITOR CH 50V 33P	1		IC4504, 05	COFBBK000038	IC	2	
C4534	EEHPIA100	E. CAPACITOR 10V 10U	1		IC4506	COABBB0000432	IC	1	
C4535	ECJ1VC1H100D	C. CAPACITOR CH 50V 10P	1		IC4507	COJBAR0000432	IC	1	
C4536	ECJ3YB1C106K	C. CAPACITOR CH 16V 10U	1		IC4508	COABBB0000432	IC	1	
C4537	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	1		IC4509	COJBAR0000432	IC	1	
C4538	ECJ3YB1C106K	C. CAPACITOR CH 16V 10U	1		IC4510	COABBB0000179	IC	1	
C4539, 40	ECJ1VB1C105K	C. CAPACITOR CH 16V 1U	2		IC4511	C1AB000002729	IC	1	
C4541	ECJ1VC1H821J	C. CAPACITOR CH 50V 820P	1		IC4512	COABEB0000023	IC	1	
C4542-44	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	3		IC4513	C1BB000000820	IC	1	
C4545	ECJ1VB1C105K	C. CAPACITOR CH 16V 1U	1		IC4601-04	COJBAG0000148	IC	4	
C4546	FIL1A4760003	C. CAPACITOR CH 16V 47U	1		IC4605	COCBAD0000042	IC	1	
C4547	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	1		IC4606	COCBBD0000004	IC	1	
C4549	ECJ1VC1H330J	C. CAPACITOR CH 50V 33P	1		IC4607	COCBAD0000042	IC	1	
C4550, 51	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	2		IC4608	COCBGD0000008	IC	1	
C4552, 53	ECJ1VB1C105K	C. CAPACITOR CH 16V 1U	2		IC4609	COCBGY0000021	IC	1	
C4554-57	FIL1A4760003	C. CAPACITOR CH 16V 47U	4		IC4610	COCBGB0000053	IC	1	
C4558	ECJ1VC1H330J	C. CAPACITOR CH 50V 33P	1		IC4612	TVHT541FT	IC	1	
C4559	ECJ1VB1C105K	C. CAPACITOR CH 16V 1U	1		L4601-03	JOJHC00000032	FILTER	3	
C4560	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	1						
C4561	ECJ1VB1C105K	C. CAPACITOR CH 16V 1U	1						
C4562	ECJ3YB1C106K	C. CAPACITOR CH 16V 10U	1		Q4401-08	2SD197900L	TRANSISTOR	8	
C4563	FIL1A4760003	C. CAPACITOR CH 16V 47U	1		Q4409-12	2SD1819AOL	TRANSISTOR	4	
C4564-67	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	4		Q4413-16	2SD197900L	TRANSISTOR	4	
C4568, 69	ECJ1VC1H821J	C. CAPACITOR CH 50V 820P	2		Q4417-24	2SD1819AOL	TRANSISTOR	8	
C4601-04	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	4		Q4425-32	1NR9113JOL	TRANSISTOR	8	
C4605	ECJ1VB1C105K	C. CAPACITOR CH 16V 1U	1		Q4433-40	1NR9213JOL	TRANSISTOR	8	
C4606	ECJ3YB1C106K	C. CAPACITOR CH 16V 10U	1		Q4501-04	2SD197900L	TRANSISTOR	4	
C4607	ECJ1VB1C105K	C. CAPACITOR CH 16V 1U	1		Q4505	1NR9113JOL	TRANSISTOR	1	
C4608	ECJ3YB1C106K	C. CAPACITOR CH 16V 10U	1		Q4506, 07	1NR9213JOL	TRANSISTOR	2	
C4609	ECJ1VB1C105K	C. CAPACITOR CH 16V 1U	1		Q4508	1NR9113JOL	TRANSISTOR	1	
C4610	ECJ3YB1C106K	C. CAPACITOR CH 16V 10U	1		Q4509, 10	2SB1219AOL	TRANSISTOR	2	
C4611	ECJ1VB1C105K	C. CAPACITOR CH 16V 1U	1		Q4601, 02	1NR9213JOL	TRANSISTOR	2	
C4612	ECJ3YB1C106K	C. CAPACITOR CH 16V 10U	1						
C4613	ECJ1VB1C105K	C. CAPACITOR CH 16V 1U	1		R4101-04	ERJ3RBD472	M. RESISTOR CH 1/16W 4.7K	4	
C4614	ECJ3YB1C106K	C. CAPACITOR CH 16V 10U	1		R4105, 06	ERJ3RBD103	M. RESISTOR CH 1/16W 10K	2	
C4615	ECJ1VB1C105K	C. CAPACITOR CH 16V 1U	1		R4107	ERJ3RBD273	M. RESISTOR CH 1/16W 27K	1	
C4616	ECJ3YB1C106K	C. CAPACITOR CH 16V 10U	1		R4108	ERJ3GEY000	M. RESISTOR CH 1/16W 0	1	
C4619	ECJ1VF1E104Z	C. CAPACITOR CH 25V 0.1U	1		R4109	ERJ3RBD472	M. RESISTOR CH 1/16W 4.7K	1	
C4620	ECJ1VC1H102J	C. CAPACITOR CH 50V 1000P	1		R4110	ERJ3GEYJ104	M. RESISTOR CH 1/16W 100K	1	
					R4111-14	ERJ3RBD472	M. RESISTOR CH 1/16W 4.7K	4	
CN4601	K1KA70BA0028	CONNECTOR (FEMALE)	1		R4115, 16	ERJ3RBD103	M. RESISTOR CH 1/16W 10K	2	
					R4117	ERJ3RBD273	M. RESISTOR CH 1/16W 27K	1	
D4301, 02	MA3J74200L	DIODE	2		R4118	ERJ3GEY000	M. RESISTOR CH 1/16W 0	1	
D4401-04	MA3J142K0L	DIODE	4		R4119	ERJ3RBD472	M. RESISTOR CH 1/16W 4.7K	1	
D4501-04	MA3J74200L	DIODE	4		R4120	ERJ3GEYJ104	M. RESISTOR CH 1/16W 100K	1	
D4505, 06	MA3J142D0L	DIODE	2		R4121-24	ERJ3RBD472	M. RESISTOR CH 1/16W 4.7K	4	
D4507	MA3J142E0L	DIODE	1		R4125, 26	ERJ3RBD103	M. RESISTOR CH 1/16W 10K	2	
D4508	MA3J142D0L	DIODE	1		R4127	ERJ3RBD273	M. RESISTOR CH 1/16W 27K	1	
D4509	MA3J14300L	DIODE	1		R4128	ERJ3GEY000	M. RESISTOR CH 1/16W 0	1	
D4510, 11	MA3J142E0L	DIODE	2		R4129	ERJ3RBD472	M. RESISTOR CH 1/16W 4.7K	1	
D4601	MA3J74200L	DIODE	1		R4130	ERJ3GEYJ104	M. RESISTOR CH 1/16W 100K	1	
					R4131	ERJ3RBD103	M. RESISTOR CH 1/16W 10K	1	
IC4101	COABBB0000179	IC	1		R4132, 33	ERJ3GEYJ473	M. RESISTOR CH 1/16W 47K	2	
IC4102	COJBAR0000432	IC	1		R4134	ERJ3RBD152	M. RESISTOR CH 1/16W 1.5K	1	
IC4103	COABBB0000179	IC	1		R4135	ERJ3RBD122	M. RESISTOR CH 1/16W 1.2K	1	
IC4104	COJBAR0000432	IC	1		R4136-41	ERJ3RBD472	M. RESISTOR CH 1/16W 4.7K	6	
IC4105	COABBB0000179	IC	1		R4142	ERJ3GEYJ104	M. RESISTOR CH 1/16W 100K	1	
IC4106	COJBAR0000432	IC	1		R4143	ERJ3RBD103	M. RESISTOR CH 1/16W 10K	1	
IC4107	COABBB0000032	IC	1		R4144, 45	ERJ3GEYJ473	M. RESISTOR CH 1/16W 47K	2	
IC4108	COABBB0000179	IC	1		R4146	ERJ3RBD152	M. RESISTOR CH 1/16W 1.5K	1	
IC4109	COABBB0000032	IC	1		R4147	ERJ3RBD122	M. RESISTOR CH 1/16W 1.2K	1	
IC4201-04	COJBAA0000602	IC	4		R4148-53	ERJ3RBD472	M. RESISTOR CH 1/16W 4.7K	6	
IC4205-08	COABEB0000023	IC	4		R4154	ERJ3GEYJ104	M. RESISTOR CH 1/16W 100K	1	
IC4209-12	COJBAR0000432	IC	4		R4201	ERJ3GEYJ104	M. RESISTOR CH 1/16W 100K	1	
IC4301	C1AB000002501	IC	1		R4202	ERJ3RBD273	M. RESISTOR CH 1/16W 27K	1	
IC4302	TVHT541FT	IC	1		R4203	ERJ3RBD513	M. RESISTOR CH 1/16W 51K	1	
IC4303	COJBAR0000432	IC	1		R4204	ERJ3RBD751	M. RESISTOR CH 1/16W 750	1	
IC4304	COABBB0000032	IC	1		R4205	ERJ3GEYJ104	M. RESISTOR CH 1/16W 100K	1	
IC4305, 06	COJBAR0000432	IC	2		R4206	ERJ3RBD273	M. RESISTOR CH 1/16W 27K	1	
IC4307	COABBB0000032	IC	1		R4207	ERJ3RBD513	M. RESISTOR CH 1/16W 51K	1	
IC4308	COJBAR0000432	IC	1		R4208	ERJ3RBD751	M. RESISTOR CH 1/16W 750	1	

Components identified with the mark Δ have the special characteristics for safety.
When replacing any of these components, use only the same type.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
C1108	ECJVB1H103K	C. CAPACITOR CH 50V 0.01U	1		D1207, 08	BOJCPD000031	DIODE	2	
C1109	FIH1C105A118	C. CAPACITOR CH 16V 1U	1		D1209	MA8068-M	DIODE	1	
C1201	ECJVB1H104K	C. CAPACITOR CH 50V 0.1U	1		D1210, 11	MA2J11100L	DIODE	2	
C1202	FIH1C105A118	C. CAPACITOR CH 16V 1U	1		D1212	MA281100ML	DIODE	1	
C1203	ECJVC1H331J	C. CAPACITOR CH 50V 330P	1		D1213	MA2J11100L	DIODE	1	
C1204	ECJVB1E683K	C. CAPACITOR CH 35V 0.068U	1		D1214, 15	MA282000HL	DIODE	2	
C1205	ECJVB1H472K	C. CAPACITOR CH 50V 4700P	1		D1216	MA8180-M	DIODE	1	
C1206	ECJVC1H100D	C. CAPACITOR CH 50V 10P	1		D1217	MA2J11100L	DIODE	1	
C1207	ECJVC1H101J	C. CAPACITOR CH 50V 100P	1		D1301, 02	MA112	DIODE	2	
C1208	ECJVB1H472K	C. CAPACITOR CH 50V 4700P	1		D1303	MA280510ML	DIODE	1	
C1209	ECJVB1H103K	C. CAPACITOR CH 50V 0.01U	1		D1304, 05	MA2J11100L	DIODE	2	
C1210	ECJVB1H102K	C. CAPACITOR CH 50V 1000P	1		D1401	BOJCPD000031	DIODE	1	
C1211	FIK1E1060004	C. CAPACITOR CH 25V 10U	1		D1402	MA729	DIODE	1	
C1212	ECJVC1H101J	C. CAPACITOR CH 50V 100P	1		D1403	MA280470ML	DIODE	1	
C1213	ECJVB1H104K	C. CAPACITOR CH 50V 0.1U	1		D1404	MA2J11100L	DIODE	1	
C1214	FIK1E1060004	C. CAPACITOR CH 25V 10U	1		D1405	BOJCPD000031	DIODE	1	
C1215	ECJ2FB1E225K	C. CAPACITOR CH 25V 2.2U	1		D1406	MA729	DIODE	1	
C1216	FIL2A105A010	C. CAPACITOR CH100V 1U	1		D1407	MA280360HL	DIODE	1	
C1217	FIK1E1060004	C. CAPACITOR CH 25V 10U	1		D1408	MA2J11100L	DIODE	1	
C1219	FIL2A105A010	C. CAPACITOR CH100V 1U	1		D1409	BOJCPD000031	DIODE	1	
C1220, 21	FIK1E1060004	C. CAPACITOR CH 25V 10U	2		D1410	MA729	DIODE	1	
C1222-24	FIL2A105A010	C. CAPACITOR CH100V 1U	3		D1411	MA280330HL	DIODE	1	
C1225	F2H1C8200001	E. CAPACITOR CH 16V 82U	1		D1412	MA2J11100L	DIODE	1	
C1226, 27	FIK1E1060004	C. CAPACITOR CH 25V 10U	2		D1413	BOJCPD000031	DIODE	1	
C1228	FIL2A105A010	C. CAPACITOR CH100V 1U	1		D1414	MA8068-M	DIODE	1	
C1229	FIK1E1060004	C. CAPACITOR CH 25V 10U	1		D1415	MA2J11100L	DIODE	1	
C1230	ECJVB1H333K	C. CAPACITOR CH 50V 0.033U	1						
C1231	FIL2A105A010	C. CAPACITOR CH100V 1U	1		Δ F1101	K5H402300003	FUSE	1	
C1232	ECJVC1H470J	C. CAPACITOR CH 50V 47P	1						
C1233	FIH1H104A783	C. CAPACITOR CH 50V 0.1U	1		IC1101	COBBBA000084	IC	1	
C1235-37	ECJ2FB1E225K	C. CAPACITOR CH 25V 2.2U	3		IC1102	COBBAD000011	IC	1	
C1239	ECJ2FB1E225K	C. CAPACITOR CH 25V 2.2U	1		IC1201	COOBAYY00437	IC	1	
C1301	FIH1E154A050	C. CAPACITOR CH 25V 0.15U	1		IC1202	COOBAG000011	IC	1	
C1304	ECJVB1H102K	C. CAPACITOR CH 50V 1000P	1		IC1203	COOBAYY00430	IC	1	
C1306	ECJVC1H221J	C. CAPACITOR CH 50V 220P	1		IC1301	COOBAZH00020	IC	1	
C1307	FIH1H391A571	C. CAPACITOR CH 50V 390P	1		IC1401	COOBAYY00439	IC	1	
C1308	ECJ0EB1E103K	C. CAPACITOR CH 25V 0.01U	1		IC1402	COOBAG000011	IC	1	
C1311	FIH1E154A050	C. CAPACITOR CH 25V 0.15U	1						
C1313, 14	F1J1E2240007	C. CAPACITOR CH 25V 0.22U	2		L1201, 02	G1C220MA0077	COIL	22UH	2
C1315-17	FIK1E1060004	C. CAPACITOR CH 25V 10U	3		L1203, 04	G1A4R7HA0019	COIL	4.7UH	2
C1318, 19	F2H0J2210003	E. CAPACITOR CH6.3V 220U	2		L1205	G1C4R5ZA0156	COIL	4.5UH	1
C1320, 21	FIK1E1060004	C. CAPACITOR CH 25V 10U	2		L1206	G1A220HA0032	COIL	22UH	1
C1322, 23	FIL1C2260020	C. CAPACITOR CH 16V 22U	2		L1207	G1C470MA0240	COIL	47UH	1
C1324	FIK1E1060004	C. CAPACITOR CH 25V 10U	1		L1208	G1C100KA0031	COIL	10UH	1
C1401	FIL1C2260020	C. CAPACITOR CH 16V 22U	1		L1209	G1C3R9MA0024	COIL	3.9UH	1
C1402	ECJVC1H331J	C. CAPACITOR CH 50V 330P	1		L1301-04	JOUBCO000107	FILTER		4
C1404	F1J1E2240007	C. CAPACITOR CH 25V 0.22U	1		L1305, 06	G1C150M00015	COIL	15UH	2
C1405	FIL1C2260020	C. CAPACITOR CH 16V 22U	1		L1307, 08	G1C1R4ZA0119	COIL	1.4UH	2
C1406	F1J1E2240007	C. CAPACITOR CH 25V 0.22U	1		L1309	G1C4R5ZA0156	COIL	4.5UH	1
C1407	ECJVC1H681J	C. CAPACITOR CH 50V 680P	1		L1401	G1C100M00030	COIL	10UH	1
C1408	ECJVC1H470J	C. CAPACITOR CH 50V 47P	1		L1402	G1C6R4MA0240	COIL	6.4UH	1
C1409	FIL1C2260020	C. CAPACITOR CH 16V 22U	1		L1403	G1C4R7MA0240	COIL	4.7UH	1
C1410	ECJVC1H681J	C. CAPACITOR CH 50V 680P	1		L1404	G1C4R5ZA0156	COIL	4.5UH	1
C1411	ECJVC1H470J	C. CAPACITOR CH 50V 47P	1		L1405	G1A4R7HA0019	COIL	4.7UH	1
C1412	F1J1E2240007	C. CAPACITOR CH 25V 0.22U	1		L1406	G1A220HA0032	COIL	22UH	1
C1413-15	ECJVB1H223K	C. CAPACITOR CH 50V 0.022U	3		L1407-10	G1C1R8ZA0156	COIL	1.8UH	4
C1416-18	FIL1C2260020	C. CAPACITOR CH 16V 22U	3						
C1419-22	FIK1E1060004	C. CAPACITOR CH 25V 10U	4		Δ PA1201	D4FBR200A003	THERMISTOR		1
C1423	ECJ2FB1E225K	C. CAPACITOR CH 25V 2.2U	1		Δ PA1202	D4FBR500A003	THERMISTOR		1
C1427-29	FIL1C2260020	C. CAPACITOR CH 16V 22U	3						
C1430	FIH1E6830006	C. CAPACITOR CH 25V 0.068U	1		Q1101	UNR9214JOL	TRANSISTOR		1
C1431	ECJVC1H100D	C. CAPACITOR CH 50V 10P	1		Q1102	2SD2216JOL	TRANSISTOR		1
C1432	ECJVB1H472K	C. CAPACITOR CH 50V 4700P	1		Q1103	UNR9211JOL	TRANSISTOR		1
C1433	ECJVB1H104K	C. CAPACITOR CH 50V 0.1U	1		Q1104	UNR9112JOL	TRANSISTOR		1
C1434	FIK1E1060004	C. CAPACITOR CH 25V 10U	1		Q1105	UNR9113JOL	TRANSISTOR		1
C1435	F2H1A1510001	E. CAPACITOR CH 10V 150U	1		Q1106, 07	UNR9211JOL	TRANSISTOR		2
C1436, 37	FIK1E1060004	C. CAPACITOR CH 25V 10U	2		Q1201	XN4501	TRANSISTOR-RESISTOR		1
C1438	FIH1H104A783	C. CAPACITOR CH 50V 0.1U	1		Q1202	2SD2216JOL	TRANSISTOR		1
					Q1203	UNR9213JOL	TRANSISTOR		1
CN1101	K1KA60B00059	CONNECTOR (MALE)	1		Q1204	2SD2216JOL	TRANSISTOR		1
					Q1205	UNR9213JOL	TRANSISTOR		1
D1101, 02	MA2J11100L	DIODE	2		Q1206, 07	2SD2216JOL	TRANSISTOR		2
D1201	MA280620ML	DIODE	1		Q1208	2SD18210HL	TRANSISTOR		1
D1202	MA281100ML	DIODE	1		Q1209, 10	XN4501	TRANSISTOR-RESISTOR		2
D1203	BOJCPD000031	DIODE	1		Q1211, 12	UNR9213JOL	TRANSISTOR		2
D1204	BOHCKP000004	DIODE	1		Q1301, 02	UNR9213JOL	TRANSISTOR		2
D1205	MA2J11100L	DIODE	1		Q1303, 04	B1MBFDA00005	TRANSISTOR		2

EPL-17

Components identified with the mark Δ have the special characteristics for safety.
When replacing any of these components, use only the same type.

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks	Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
C212	F1G1H330A565	C. CAPACITOR CH 50V 33P	1		R115	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	1	
C213	F1J2A104A023	C. CAPACITOR CH100V 0.1U	1		R121-30	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	10	
C214	EEEFK1J4R7	E. CAPACITOR 63V 4.7U	1		R131, 32	ERJ2GEJ104	M. RESISTOR CH 1/16W 100K	2	
C215	F1G1C104A083	C. CAPACITOR CH 16V 0.1U	1		R133	ERJ2GEJ473	M. RESISTOR CH 1/16W 47K	1	
C216	F1J2A104A023	C. CAPACITOR CH100V 0.1U	1		R201	ERJ3GEY472	M. RESISTOR CH 1/16W 4.7K	1	
C217	F1G1C104A083	C. CAPACITOR CH 16V 0.1U	1		R202	ERJ3GEY473	M. RESISTOR CH 1/16W 47K	1	
C218	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		R203	ERJ2RHD101	M. RESISTOR CH 1/16W 100	1	
C219	ECJ3YB1C106K	C. CAPACITOR CH 16V 10U	1		R204	ERJ2RHD472	M. RESISTOR CH 1/16W 4.7K	1	
C220	F1H1C105A118	C. CAPACITOR CH 16V 1U	1		R205	ERJ2RHD473	M. RESISTOR CH 1/16W 47K	1	
C221	ECJ3YB1C106K	C. CAPACITOR CH 16V 10U	1		R206	ERJ2RHD101	M. RESISTOR CH 1/16W 100	1	
					R207	ERJ2RHD472	M. RESISTOR CH 1/16W 4.7K	1	
Δ CB101	K5JDKB000012	BREAKER	1		R208	ERJ2RHD471	M. RESISTOR CH 1/16W 470	1	
					R209	ERJ2RHD241	M. RESISTOR CH 1/16W 240	1	
CN101	K1KA02A00735	CONNECTOR (MALE)	1		R210	ERJ2GEJ474	M. RESISTOR CH 1/16W 470K	1	
CN102	K1KA03AA0500	CONNECTOR (MALE)	1		R211	ERJ3GEY472	M. RESISTOR CH 1/16W 4.7K	1	
CN103, 04	K1KA02A00164	CONNECTOR (MALE)	2		R212	ERJ3GEY473	M. RESISTOR CH 1/16W 47K	1	
CN105	K1KA02A00023	CONNECTOR (MALE)	1		R213	ERJ2RHD101	M. RESISTOR CH 1/16W 100	1	
CN106	K1KA10A00192	CONNECTOR (MALE)	1		R214	ERJ2RHD472	M. RESISTOR CH 1/16W 4.7K	1	
CN107	K1KB10A00001	CONNECTOR (FEMALE)	1		R215	ERJ2RHD473	M. RESISTOR CH 1/16W 47K	1	
CN201	K1MN24AA0018	CONNECTOR	1		R216	ERJ2RHD101	M. RESISTOR CH 1/16W 100	1	
CN202	K1KA50AA0240	CONNECTOR (MALE)	1		R217	ERJ2RHD472	M. RESISTOR CH 1/16W 4.7K	1	
					R218	ERJ2RHD471	M. RESISTOR CH 1/16W 470	1	
D101	B0JBSE000056	DIODE	1		R219	ERJ2RHD241	M. RESISTOR CH 1/16W 240	1	
D102	MA8130-M	DIODE	1		R220-22	ERJ2GEJ474	M. RESISTOR CH 1/16W 470K	3	
D103	MAZ80560HL	DIODE	1		R223, 24	ERJ2GEJ224	M. RESISTOR CH 1/16W 220K	2	
D104, 05	MA8068-M	DIODE	2		R225	ERJ2GEJ473	M. RESISTOR CH 1/16W 47K	1	
D107, 08	B0HCHM000006	DIODE	2		R226	ERJ2GEJ333	M. RESISTOR CH 1/16W 33K	1	
D109-13	D4ED1270A007	VARI STOR	5		R227	ERJ3GEYJ273	M. RESISTOR CH 1/16W 27K	1	
D115	MA3S13300L	DIODE	1		R228, 29	ERJ2GEJ473	M. RESISTOR CH 1/16W 47K	2	
D201-04	MA3S13300L	DIODE	4		R230, 31	ERJ2GEJ474	M. RESISTOR CH 1/16W 470K	2	
D205	MA3J74200L	DIODE	1		R232, 33	ERJ2GEJ224	M. RESISTOR CH 1/16W 220K	2	
					R234	ERJ2GEJ473	M. RESISTOR CH 1/16W 47K	1	
Δ F101	K5H183AA0013	FUSE	1		R235	ERJ2GEJ333	M. RESISTOR CH 1/16W 33K	1	
Δ F102	K5H402300003	FUSE	1		R236	ERJ2GEJ473	M. RESISTOR CH 1/16W 47K	1	
Δ F103	K5H312300005	FUSE	1		R237	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	1	
Δ F104	K5H202300011	FUSE	1		R239	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	1	
Δ F105	K5H402300003	FUSE	1		R240	ERJ3GEYJ121	M. RESISTOR CH 1/16W 120	1	
					R241, 42	ERJ2GEJ474	M. RESISTOR CH 1/16W 470K	2	
IC201, 02	COABBB000396	IC	2		ZA101	K4CD01000015	TERMINAL	1	
IC203, 04	COJBAD000207	IC	2						
IC205	COCBCDC00008	IC	1						
IC206	XC62DN5002M	IC	1						
L101-06	VLP0183	COIL	6						
L107	JOJBC0000019	FILTER	1						
L108	JOJCC0000009	FILTER	1		■ E5	VEP03H69A	P2 CARD P.C. BOARD	1	(RTL)
L109-14	JOJBC0000019	FILTER	6						
L115	JOJCC0000009	FILTER	1						
L116	JOJBC0000019	FILTER	1						
					C102	F1J0J106A020	C. CAPACITOR CH6. 3V	10U	1
PC101	B3PBA0000215	PHOTO COUPLER	1		C103	F1G1A1040006	C. CAPACITOR CH 10V 0.1U	1	
					C104	F1J0J106A020	C. CAPACITOR CH6. 3V	10U	1
Q101	B1CHRG000015	TRANSISTOR	1		C106	F1J0J106A020	C. CAPACITOR CH6. 3V	10U	1
Q102	UNR9113J0L	TRANSISTOR	1		C107	F1G1A1040006	C. CAPACITOR CH 10V 0.1U	1	
Q103-05	UNR9213J0L	TRANSISTOR	3		C108	F1J0J106A020	C. CAPACITOR CH6. 3V	10U	1
Q106	UNR9113J0L	TRANSISTOR	1		C109	F1G1A1040006	C. CAPACITOR CH 10V 0.1U	1	
Q107	UNR9213J0L	TRANSISTOR	1		C110	F1J0J106A020	C. CAPACITOR CH6. 3V	10U	1
Q108	2SD1820A0L	TRANSISTOR	1		C111	F1G1A1040006	C. CAPACITOR CH 10V 0.1U	1	
Q109, 10	2SB1462J0L	TRANSISTOR	2		C112	F1J0J106A020	C. CAPACITOR CH6. 3V	10U	1
Q111	UNR9213J0L	TRANSISTOR	1		C113	F1G1A1040006	C. CAPACITOR CH 10V 0.1U	1	
Q201	2SB12200RL	TRANSISTOR	1		C117, 18	F1G1A1040006	C. CAPACITOR CH 10V 0.1U	2	
Q202, 03	2SD18210HL	TRANSISTOR	2		C200	F2H0J4710003	C. CAPACITOR CH6. 3V	470P	1
Q204	2SB12200RL	TRANSISTOR	1		C201	F1J0J106A020	C. CAPACITOR CH6. 3V	10U	1
Q205	2SD18210HL	TRANSISTOR	1		C202	F1G1A1040006	C. CAPACITOR CH 10V 0.1U	1	
					C203	F1G1E1030005	C. CAPACITOR CH 25V 0.01U	1	
R101	ERJ3GEYJ331	M. RESISTOR CH 1/16W 330	1		C204	F1G1H101A565	C. CAPACITOR CH 50V 100P	1	
R102	ERJ2GEJ224	M. RESISTOR CH 1/16W 220K	1		C205	F1J0J106A020	C. CAPACITOR CH6. 3V	10U	1
R103	ERJ2GEJ473	M. RESISTOR CH 1/16W 47K	1		C206, 07	F1G1E1030005	C. CAPACITOR CH 25V 0.01U	2	
R104, 05	ERJ2GEJ103	M. RESISTOR CH 1/16W 10K	2		C208	F1G1A474A018	C. CAPACITOR CH 10V 0.47U	1	
R106	DOGF272JA002	M. RESISTOR CH 1/16W 2.7K	1		C209	F1G1E1030005	C. CAPACITOR CH 25V 0.01U	1	
R107	ERJ6GEYG103	M. RESISTOR CH 1/10W 10K	1		C210	F1G1A474A018	C. CAPACITOR CH 10V 0.47U	1	
R109	ERJ2GEJ103	M. RESISTOR CH 1/16W 10K	1		C211	F1G1E1030005	C. CAPACITOR CH 25V 0.01U	1	
R110	ERJ2GEJ473	M. RESISTOR CH 1/16W 47K	1		C214	F1J0J106A020	C. CAPACITOR CH6. 3V	10U	1
R111	ERJ2GEJ332	M. RESISTOR CH 1/16W 3.3K	1		C215	F1G1E1030005	C. CAPACITOR CH 25V 0.01U	1	
R112	ERJ2GEJ103	M. RESISTOR CH 1/16W 10K	1		C216, 17	ECJ0EB1H271K	C. CAPACITOR CH 50V 270P	2	
R113	ERJ2GEJ473	M. RESISTOR CH 1/16W 47K	1		C218	ECJ0EC1H181J	C. CAPACITOR CH 50V 180P	1	
R114	ERJ3GEYJ100	M. RESISTOR CH 1/16W 10	1		C219	F1G1E1030005	C. CAPACITOR CH 25V 0.01U	1	
					C220	ECJ0EC1H181J	C. CAPACITOR CH 50V 180P	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
C221	FIG1E1030005	C. CAPACITOR CH 25V 0.01U	1		R162-68	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	7	
C224	F1J0J106A020	C. CAPACITOR CH6.3V 10U	1		R179	EXBN8V220J	COMBI. R-R	22	1
C225	FIG1E1030005	C. CAPACITOR CH 25V 0.01U	1		R189	ERJ2GEJ472	M. RESISTOR CH 1/16W 4.7K	1	
C226, 27	FIG1H101A565	C. CAPACITOR CH 50V 100P	2		R190-95	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	6	
C228	FIG1E1030005	C. CAPACITOR CH 25V 0.01U	1		R196	ERJ2GEJ103	M. RESISTOR CH 1/16W 10K	1	
C231-33	FIG1E1030005	C. CAPACITOR CH 25V 0.01U	3		R200-08	EXBN8V220J	COMBI. R-R	22	9
C234, 35	ECJ0EC1H181J	C. CAPACITOR CH 50V 180P	2		R209	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1	
C236	FIG1E1030005	C. CAPACITOR CH 25V 0.01U	1		R210	ERJ2GEJ101	M. RESISTOR CH 1/16W 100	1	
C237	FIG1A1040006	C. CAPACITOR CH 10V 0.1U	1		R211, 12	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	2	
C238	F2H0J4710003	C. CAPACITOR CH6.3V 470P	1		R215	ERJ2GEJ103	M. RESISTOR CH 1/16W 10K	1	
C239	FIG1A1040006	C. CAPACITOR CH 10V 0.1U	1		R216	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1	
C241	FIG1A1040006	C. CAPACITOR CH 10V 0.1U	1		R217, 18	ERJ2GEJ104	M. RESISTOR CH 1/16W 100K	2	
C243	FIG1A1040006	C. CAPACITOR CH 10V 0.1U	1		R220	ERJ2GEJ102	M. RESISTOR CH 1/16W 1K	1	
C244	F1J0J106A020	C. CAPACITOR CH6.3V 10U	1		R222	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1	
C245	FIG1A1040006	C. CAPACITOR CH 10V 0.1U	1		R224	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1	
C246	F1J0J106A020	C. CAPACITOR CH6.3V 10U	1		R226	ERJ2GEJ102	M. RESISTOR CH 1/16W 1K	1	
C247	FIG1A1040006	C. CAPACITOR CH 10V 0.1U	1		R228	ERJ2GEJ103	M. RESISTOR CH 1/16W 10K	1	
C250	FIG1A1040006	C. CAPACITOR CH 10V 0.1U	1		R231	ERJ2GEJ103	M. RESISTOR CH 1/16W 10K	1	
C252	F1J0J106A020	C. CAPACITOR CH6.3V 10U	1		R234-36	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	3	
C253	FIG1A1040006	C. CAPACITOR CH 10V 0.1U	1		R237	ERJ2GEJ104	M. RESISTOR CH 1/16W 100K	1	
C254	FIG1H101A565	C. CAPACITOR CH 50V 100P	1		R240, 41	ERJ2GEJ103	M. RESISTOR CH 1/16W 10K	2	
C255, 56	FIG1A1040006	C. CAPACITOR CH 10V 0.1U	2		R243	ERJ2GEJ103	M. RESISTOR CH 1/16W 10K	1	
C257	FIG1H101A565	C. CAPACITOR CH 50V 100P	1		R245	ERJ2GEJ103	M. RESISTOR CH 1/16W 10K	1	
C258, 59	FIG1A1040006	C. CAPACITOR CH 10V 0.1U	2		R248	ERJ2GEJ102	M. RESISTOR CH 1/16W 1K	1	
C260	FIG1H101A565	C. CAPACITOR CH 50V 100P	1		R249	ERJ2GEJ103	M. RESISTOR CH 1/16W 10K	1	
C261, 62	FIG1A1040006	C. CAPACITOR CH 10V 0.1U	2		R251	ERJ2GEJ104	M. RESISTOR CH 1/16W 100K	1	
					R252	ERJ2GEJ103	M. RESISTOR CH 1/16W 10K	1	
CN100	K1KA70BA0028	CONNECTOR (FEMALE)	1		R253-67	EXBN8V750J	COMBI. R-R	75	15
CN101	K1MR70B00004	CONNECTOR	1		R268-70	ERJ2GEJ750	M. RESISTOR CH 1/16W 75	3	
CN102	K1KB20AA0011	CONNECTOR (FEMALE)	1		R271, 72	ERJ2GEJ103	M. RESISTOR CH 1/16W 10K	2	
CN200	K1NA68E00091	CONNECTOR	1		R279, 80	ERJ2GEJ103	M. RESISTOR CH 1/16W 10K	2	
CN201	K1NA68E00090	CONNECTOR	1		R281-83	ERJ2GEJ750	M. RESISTOR CH 1/16W 75	3	
CN202	K1YYZZ000049	CARD HOLDER B	1		R284-98	EXBN8V750J	COMBI. R-R	75	15
CN203	K1YYZZ000048	CARD HOLDER A	1		R299	ERJ2GEJ103	M. RESISTOR CH 1/16W 10K	1	
					R300	ERJ2GEJ104	M. RESISTOR CH 1/16W 100K	1	
D100-03	LNJ115W88RA	DIODE	4		R301	ERJ2GEJ333	M. RESISTOR CH 1/16W 33K	1	
D104	MA2J72800L	DIODE	1		R302	ERJ2GEJ223	M. RESISTOR CH 1/16W 22K	1	
					R303	ERJ2GEJ333	M. RESISTOR CH 1/16W 33K	1	
IC103	COJBAB000832	IC	1		R304	ERJ2GEJ223	M. RESISTOR CH 1/16W 22K	1	
IC104	COJBAA000362	IC	1		R305	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1	
IC200	C1DB00001179	IC	1		R306	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1	
IC201, 02	COJBAA000362	IC	2		R307	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1	
IC204-06	COJBAA001728	IC	3		R312	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1	
IC207	COJBAAE000321	IC	1		R313-19	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	7	
					R320	ERJ2GEJ333	M. RESISTOR CH 1/16W 33K	1	
L100	JOJHC0000032	FILTER	1		R321	ERJ2GEJ223	M. RESISTOR CH 1/16W 22K	1	
L101, 02	JOJHC0000009	FILTER	2		R324	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1	
L200-03	JOJHC0000032	FILTER	4		R325	ERJ2GEJ103	M. RESISTOR CH 1/16W 10K	1	
L204-06	JOJHC0000102	FILTER	3		R326, 27	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	2	
L207, 08	JOJHC0000032	FILTER	2		R328	EXBN8V220J	COMBI. R-R	22	1
L209-11	JOJCC0000405	FERRITE CORE	3		R329	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1	
					R330-33	ERJ2GEJ560	M. RESISTOR CH 1/16W 56	4	
Q100	UNR9115J0L	TRANSISTOR	1		R334, 35	EXBN8V470J	COMBI. R-R	47	2
Q101, 02	XP0411500L	TRANSISTOR	2		R336, 37	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	2	
Q200-02	B1DH0C000036	TRANSISTOR	3		R338	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1	
Q203	UNR9213J0L	TRANSISTOR	1		R339	EXBN8V470J	COMBI. R-R	47	1
					R340, 41	ERJ2GEJ103	M. RESISTOR CH 1/16W 10K	2	
R100-08	EXBN8V220J	COMBI. R-R	22	9	R343	ERJ2GEJ104	M. RESISTOR CH 1/16W 100K	1	
R109	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	1		R344, 45	ERJ2GEJ560	M. RESISTOR CH 1/16W 56	2	
R110-12	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	3		R347	ERJ2GEJ102	M. RESISTOR CH 1/16W 1K	1	
R115, 16	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	2						
R117, 18	ERJ2GEJ181	M. RESISTOR CH 1/16W 180	2		ZA102-05	K4C0D1000015	TERMINAL	4	
R119	ERJ2GEJ821	M. RESISTOR CH 1/16W 820	1						
R120	ERJ2GEJ181	M. RESISTOR CH 1/16W 180	1				MISCELLANEOUS		
R121	ERJ2GEJ821	M. RESISTOR CH 1/16W 820	1						
R122	ERJ2GEJ103	M. RESISTOR CH 1/16W 10K	1						
R123	EXBN8V473J	COMBI. R-R	47K	1		VMZ3478	CARD SLOT BARRIER B	1	
R124, 25	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	2			VMP9229	P2 CARO FRAME	1	
R126, 27	ERJ2GEJ181	M. RESISTOR CH 1/16W 180	2			VMZ3726	CARD COVER SHEET B	1	
R128, 29	ERJ2GEJ821	M. RESISTOR CH 1/16W 820	2			VMT1862	GASKET	1	
R138	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1			VMZ3720	CARD COVER SHEET	2	
R143-49	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	7			XYN2+J6FJ	SCREW	6	
R150	ERJ2GEJ472	M. RESISTOR CH 1/16W 4.7K	1						
R151	EXBN8V220J	COMBI. R-R	22	1					
R153, 54	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	2						
R155-57	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	3						
R161	ERJ2GEJ101	M. RESISTOR CH 1/16W 100	1		■ E6	VEP001Y3B	SD CARD P.C. BOARD	1	(RTL)

Components identified with the mark Δ have the special characteristics for safety.
When replacing any of these components, use only the same type.

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks	Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
						VEE1F34	ANTON BOX U2 CABLE	1	
						VEE1F35	ANTON BOX U3 CABLE	1	
C1	F1G1C1030008	C. CAPACITOR CH 16V 0.01U	1						
C2	F1J0J106A020	C. CAPACITOR CH6.3V 10U	1						
CN1	K1KB20AA0181	CONNECTOR (FEMALE)	1						
CN2	K1NA09E00038	CONNECTOR	1						
D1	LNJ310M6URA	DIODE	1		■ E9	VEP01A20B	DC IN P.C. BOARD	1	(RTL)
R1-R4	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	4		D1	BOEAKR000059	DIODE	1	
R5-10	ERJ2GEJ220	M. RESISTOR CH 1/16W 22	6						
					JK1	K1AA104H0038	CONNECTOR (MALE)	1	
ZA1-A3	K4CD01000015	TERMINAL	3				MISCELLANEOUS		
		MISCELLANEOUS							
	VGFI089	SD CARD COVER	1			VEE1F36	EXT DC IN 1 CABLE	1	
					Δ	VEE1F37	EXT DC IN 2 CABLE	1	
■ E7	VEP04945B	REAR JACK P.C. BOARD	1	(RTL)	■ E10	VEP001Y7B	R SIDE 1 P.C. BOARD	1	(RTL)
C101-03	ECJ1VB2A471K	C. CAPACITOR CH100V 470P	3		C1101-03	F1G1A1040006	C. CAPACITOR CH 10V 0.1U	3	
C104	ECJ1VF1H103Z	C. CAPACITOR CH 50V 0.01U	1		C1104	F1J0J106A020	C. CAPACITOR CH6.3V 10U	1	
C105-07	ECJ1VB2A471K	C. CAPACITOR CH100V 470P	3		C1105	F1G1A1040006	C. CAPACITOR CH 10V 0.1U	1	
C108	ECJ1VF1H103Z	C. CAPACITOR CH 50V 0.01U	1		C1106-12	F1G1H330A565	C. CAPACITOR CH 50V 33P	7	
C109-12	ECJ1VB2A471K	C. CAPACITOR CH100V 470P	4		C1113	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
CN101	K1MN24AA0018	CONNECTOR	1		C1114	F1J0J106A020	C. CAPACITOR CH6.3V 10U	1	
D101	KR5009X-1CDE	LED	1		C1115	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
					C1116	F1J0J106A020	C. CAPACITOR CH6.3V 10U	1	
JK101, 02	K1AY103A0001	CONNECTOR	2		C1117	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
L101-06	JOJCC0000118	FILTER	6		C1118	F1J0J106A020	C. CAPACITOR CH6.3V 10U	1	
L107-10	G1C100JA0041	COIL 10UH	4		C1119	F1H1C105A118	C. CAPACITOR CH 16V 1U	1	
R103-06	ERJ12YJ682	M. RESISTOR CH 1/2W 6.8K	4		C1120	F1J0J106A020	C. CAPACITOR CH6.3V 10U	1	
R107	ERJ3RBD223	M. RESISTOR CH 1/16W 22K	1		C1123	F1G1A1040006	C. CAPACITOR CH 10V 0.1U	1	
R108	ERJ3RBD332	M. RESISTOR CH 1/16W 3.3K	1		C1124	F1J0J106A020	C. CAPACITOR CH6.3V 10U	1	
R109	ERJ3RBD471	M. RESISTOR CH 1/16W 470	1		C1125	F1G1A1040006	C. CAPACITOR CH 10V 0.1U	1	
R110, 11	ERJ3RBD223	M. RESISTOR CH 1/16W 22K	2		C1225-31	F1G1A1040006	C. CAPACITOR CH 10V 0.1U	7	
R112	ERJ3RBD332	M. RESISTOR CH 1/16W 3.3K	1		C1301	F1G1A1040006	C. CAPACITOR CH 10V 0.1U	1	
R113	ERJ3RBD471	M. RESISTOR CH 1/16W 470	1		C1302	ECJ3YB1C106K	C. CAPACITOR CH 16V 10U	1	
R114	ERJ3RBD223	M. RESISTOR CH 1/16W 22K	1		C1303	F1G1A1040006	C. CAPACITOR CH 10V 0.1U	1	
R115-17	ERJ3GEYOR00	M. RESISTOR CH 1/16W 0	3		C1304, 05	F1G1E1030005	C. CAPACITOR CH 25V 0.01U	2	
SW101, 02	K0D143A00008	SWITCH	2		C1401-05	ECJ1VB1H104K	C. CAPACITOR CH 50V 0.1U	5	
		MISCELLANEOUS			C1406	F1L1A4760003	C. CAPACITOR CH 16V 47U	1	
	VMX3636	XLR SPACER	2		CN1101	K1KY40B00012	CONNECTOR	1	
	K9ZZ00000652	LED SPACER	1		CN1102	K1MN30BA0059	CONNECTOR	1	
	VMT1503	PCB HOLD RUBBER	1		CN1301	K1KA15B00052	CONNECTOR (MALE)	1	
					CN1302	K1KA02B00157	CONNECTOR (MALE)	1	
■ E8	VEP001Z5B	BATT IF P.C. BOARD	1	(RTL)	D1301-03	DA3J101FOL	DIODE	3	
					D1401, 02	MA3J142DOL	DIODE	2	
C1, C2	ECJ1VB1H223K	C. CAPACITOR CH 50V 0.022U	2		IC1101	C0CBBCB00053	IC	1	
C3, C4	F1G1A1040006	C. CAPACITOR CH 10V 0.1U	2		IC1102	C0CBBCB00049	IC	1	
C5, C6	ECJ1VB1H222K	C. CAPACITOR CH 50V 2200P	2		IC1103	C0CBBCY00015	IC	1	
C7, C8	ECJ1VC1H101J	C. CAPACITOR CH 50V 100P	2		IC1104	C0CBBCY00021	IC	1	
					IC1201-03	COJBA0000080	IC	3	
CN1, N2	K1KA04B00153	CONNECTOR (MALE)	2		IC1204, 05	COJBAZ002934	IC	2	
					IC1206	COZBZ0000992	IC	1	
ZA1	K4CD01000015	TERMINAL	1		IC1207	COJBAZ002328	IC	1	
		MISCELLANEOUS			IC1301, 02	COJBA0000621	IC	2	
					L1101, 02	JOJHC0000032	FILTER	2	
					L1103, 04	JOJDC0000102	FILTER	2	
					L1105	JOJAB00000225	FILTER	1	
					Q1101	DRC9144EOL	DIODE	1	
					Q1401	XP0121300L	TRANSISTOR	1	
					Q1402, 03	DRA9144EOL	DIODE	2	
					Q1404, 05	DRC9144EOL	DIODE	2	
					Q1406	DMG204010R	DIODE	1	
					Q1407, 08	DRC9144EOL	DIODE	2	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
C1115	F3G1D106A008	T. CAPACITOR CH 20V 10U	1						
C1116	F1G1C1040010	C. CAPACITOR CH 16V 0.1U	1		SW601	KOE112G00033	SWITCH	1	
C1117	FIK1E1060004	C. CAPACITOR CH 25V 10U	1						
C1118	FIK1C475A062	C. CAPACITOR CH 16V 4.7U	1						
C1119, 20	FIH1C105A096	C. CAPACITOR CH 16V 1U	2						
C1121-24	ECJ2FB1C225K	C. CAPACITOR CH 16V 2.2U	4						
C1125, 26	FIK1C475A062	C. CAPACITOR CH 16V 4.7U	2						
C1127	FIH1C105A096	C. CAPACITOR CH 16V 1U	1		■ E16	VEP001Z6B	HANDLE SW P.C. BOARD	1	(RTL)
C1128	FIK1C475A062	C. CAPACITOR CH 16V 4.7U	1						
C1129-34	ECJ2FB1C225K	C. CAPACITOR CH 16V 2.2U	6						
C1137	FIH1H1020008	C. CAPACITOR CH 50V 1000P	1		CN9001	K1KA03B00139	CONNECTOR (MALE)	1	
CN1101	K1MN27B00036	CONNECTOR	1		SW9001	KOD122B00054	SWITCH	1	
CN1102	K1MN12BA0059	CONNECTOR	1		SW9002	VST0335	SWITCH	1	
CN1103	K1MN39BA0132	CONNECTOR	1						
CN1104	K1MY29BA0338	CONNECTOR	1		ZA9001	K4CD01000015	TERMINAL	1	
D1101	MA8120-M	DIODE	1						
D1102, 03	MA2SD240GL	DIODE	2						
IC1101	C1CB00003189	IC	1		■ E17	VEP001Z1B	TOGGLE SW P.C. BOARD	1	(RTL)
L1101	JOJKC0000009	FILTER	1						
L1102	JOMAB0000225	FILTER	1						
L1103	JOJKC0000009	FILTER	1		CN9401	K1KA08B00192	CONNECTOR (MALE)	1	
L1104	JOJDC0000099	FILTER	1						
					R9401, 02	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	2	
Q1101-08	2SD2216JOL	TRANSISTOR	8						
Q1109	B1ADCE000018	TRANSISTOR	1		SW9401	KOE112G00029	SWITCH	1	
					SW9402-04	KOE112G00030	SWITCH	3	
R1103, 04	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	2						
R1105	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1						
R1106, 07	ERJ2GEJ470	M. RESISTOR CH 1/16W 47	2						
R1108	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1						
R1109	EXBN8V330J	COMBI. R-R 33	1						
R1110	ERJ2RHD102	M. RESISTOR CH 1/16W 1K	1		■ E18	VEP04946B	F MIC P.C. BOARD	1	(RTL)
R1111-13	ERJ2RKD270	M. RESISTOR CH 1/16W 27	3						
R1114	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1						
R1116	ERJ2RKD270	M. RESISTOR CH 1/16W 27	1		C1-C3	ECJ1VB2A471K	C. CAPACITOR CH100V 470P	3	
R1117	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	1		C4	ECJ1VF1H103Z	C. CAPACITOR CH 50V 0.01U	1	
R1118-21	ERJ2RKD270	M. RESISTOR CH 1/16W 27	4		C5, C6	ECJ1VB2A471K	C. CAPACITOR CH100V 470P	2	
R1122	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1		C7, C8	EEEFK1J4R7	E. CAPACITOR 63V 4.7U	2	
R1125	ERJ2RHD472	M. RESISTOR CH 1/16W 4.7K	1		C9-12	F1G1C104A083	C. CAPACITOR CH 16V 0.1U	4	
R1126-31	EXBN8V330J	COMBI. R-R 33	6		C13, 14	F1G1H330A565	C. CAPACITOR CH 50V 33P	2	
R1132	ERJ2RHD223	M. RESISTOR CH 1/16W 22K	1		C15	EEEFK1J4R7	E. CAPACITOR 63V 4.7U	1	
R1133, 34	ERJ2RHD103	M. RESISTOR CH 1/16W 10K	2		C16	FIH1C105A118	C. CAPACITOR CH 16V 1U	1	
R1135	ERJ2GEOR00	M. RESISTOR CH 1/16W 0	1		C17	ECJ3YB1C106K	C. CAPACITOR CH 16V 10U	1	
R1139, 40	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	2		C18	FIH1C105A118	C. CAPACITOR CH 16V 1U	1	
					C19	ECJ3YB1C106K	C. CAPACITOR CH 16V 10U	1	
ZA1101	K4CD01000015	TERMINAL	1		C20-29	F1G1H101A565	C. CAPACITOR CH 50V 100P	10	
					CN1	K1KY20B00011	CONNECTOR	1	
					CN2	K1KA10A00192	CONNECTOR (MALE)	1	
■ E14	VEP001Y5B	FRONT SW P.C. BOARD	1	(RTL)	D1, D2	MA3I3300L	DIODE	2	
					D3	MA3J74200L	DIODE	1	
CN601	K1KA05A00218	CONNECTOR (MALE)	1		IC1	COABB0000032	IC	1	
					IC2	COJBAR0000432	IC	1	
R605-08	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	4		IC3	COCBDC000008	IC	1	
					IC4	XC62DN5002M	IC	1	
SW601	VST0195	SWITCH	1						
SW602	VST0194	SWITCH	1		JK1	K1AY103A0001	CONNECTOR	1	
		MISCELLANEOUS			L1-L3	JOJCC0000118	FILTER	3	
					L4, L5	G1C100JA0041	COIL 10UH	2	
					L6-15	JOJBC0000019	FILTER	10	
VMP9223		FRONT TOGGLE PLATE	1						
					Q1	2SD18210HL	TRANSISTOR	1	
					Q2	UNR9113JOL	TRANSISTOR	1	
					Q3	UNR9213JOL	TRANSISTOR	1	
■ E15	VEP001Z4B	POWER SW P.C. BOARD	1	(RTL)	R1, R2	ERJ12YJ682	M. RESISTOR CH 1/2W 6.8K	2	
					R3	ERJ3GEYJ392	M. RESISTOR CH 1/16W 3.9K	1	
					R4, R5	ERJ2RHD473	M. RESISTOR CH 1/16W 47K	2	
					R6, R7	ERJ2RHD101	M. RESISTOR CH 1/16W 100	2	
CN601	K1KA02B00157	CONNECTOR (MALE)	1		R8	ERJ2RHD561	M. RESISTOR CH 1/16W 560	1	

Components identified with the mark have the special characteristics for safety. When replacing any of these components, use only the same type.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
CN9100	K1KA02B00157	CONNECTOR (MALE)	1				MISCELLANEOUS		
D9100	B3AAA0000984	LED	1			VMP9232	USB ANGLE	1	
R9100	ERJ6GEY0R00	M. RESISTOR CH 1/10W 0	1			XYN2+J6FJ	SCREW	2	
SW9100	KOE122A00036	SWITCH	1						
		MISCELLANEOUS			■ E28	VEP001Y4B	1394 CN P.C. BOARD	1	(RTL)
	VMX2188020	SPACER	1						
					CN901	K1KA05AA0083	CONNECTOR (MALE)	1	
					D901	B0KB00000041	DIODE	1	
					D902-05	D4ED12700007	DIODE	4	
■ E26	VEP08359B	EVF TALLY P.C. BOARD	1	(RTL)	JK901	K1KB06BA002B	CONNECTOR (FEMALE)	1	
					L901	JOJCC0000059	FILTER	1	
C1184, 85	FIH1C105A096	C. CAPACITOR CH 16V 1U	2		Δ PA901-04	K5H1012A0021	FUSE	4	
C1186	FI6IC1040010	C. CAPACITOR CH 16V 0.1U	1						
C1187, 88	FI6IH1020008	C. CAPACITOR CH 50V 1000P	2		R908	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	1	
C1189, 90	FIH1C105A096	C. CAPACITOR CH 16V 1U	2				MISCELLANEOUS		
C1191, 92	FI6IH1020008	C. CAPACITOR CH 50V 1000P	2			VJF1491	CONNECTOR HOLDER B	1	
C1198, 99	FI6IH1020008	C. CAPACITOR CH 50V 1000P	2			VJF1555	CONNECTOR HOLDER A	1	
CN1180	K1KY20B00012	CONNECTOR	1			VJF1559	CLAMPER	1	
CN1181	K1KA10AA0001	CONNECTOR (MALE)	1		Δ	VEE1F95	1394 CABLE	1	
D1180, 81	B3AAB0000103	DIODE	2			XYN2+J6FJ	SCREW	2	
FL1180	JOMAB0000169	FILTER	1						(RTL)
IC1180	C0C8CBC00049	IC	1						
L1180	JOJDC0000102	FILTER	1						
L1181, 82	JOJKC0000009	FILTER	2						
R1184	ERJ2GEJ330	M. RESISTOR CH 1/16W 33	1						
R1185	ERJ2GEJ103	M. RESISTOR CH 1/16W 10K	1						
R1192, 93	ERJ2RKD680	M. RESISTOR CH 1/16W 68	2						
R1196, 97	ERJ2RKD680	M. RESISTOR CH 1/16W 68	2						
SW1180	VSS0186	SWITCH	1						
ZA1180, 81	K4CD01000015	TERMINAL	2						
		MISCELLANEOUS							
	VMP9226	EVF PCB ANGLE	1						
	XYN2+J5FJ	SCREW	2						
■ E27	VEP001Z0A	USB CN P.C. BOARD	1	(RTL)					
CN1	K1KY10BA0135	CONNECTOR	1						
D1	B0KB00000041	DIODE	1						
D2, D3	D4ED12700007	DIODE	2						
D4	B0KB00000041	DIODE	1						
D5, D6	D4ED12700007	DIODE	2						
JK1	K1FB104B0064	CONNECTOR	1						
JK2	K1FY104B0010	CONNECTOR	1						
L1	JOJCC0000059	FILTER	1						
L2	JOMAB0000212	FILTER	1						
L3	JOJCC0000059	FILTER	1						
L4	JOMAB0000212	FILTER	1						
R1, R2	ERJ3GEY0R00	M. RESISTOR CH 1/16W 0	2						

! Warning

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service manual by anyone else could result in serious injury or death.

Service Manual

Supplement

NTSC/PAL

**Subject: Improvement of video process stability in high temperature
(45°C / 113°F) : Firmware update**

Please use this document together with the service manual of the following model(s):

Model No.	Effective from	Model No.	Effective from
AG-HPX370P	Running change in C2	AG-HPX373MC	Running change in C2
AG-HPX371E	Running change in C2	AG-HPX374ER	Running change in C2
AG-HPX372EN	Running change in C2	AG-HPX393MC	Running change in C2

Ref. No.	Original Part No.	New Part No.	Part name & Descriptions	Pcs	Remark
--	VSI5221B Ver.12.18-00-0.00	VSI5221C Ver.12.19-00-0.00	Firmware image data	1	Please refer to the service manual for the update procedure.

Following performance is improved with a new firmware version 12.19-00-0.00.

Video process stability in extreme ambient temperature environment of above 45°C / 113°F.

***** This update will also be introduced to end users via the “Support Desk” website. *****

EA33112

Panasonic

© 2012 Panasonic Corporation. All rights reserved.
Unauthorized copying and distribution is a violation of law.

