


TBX-2

Triple Bus Expander for ADAM/ADAM-M



PROPRIETARY NOTICE

The product information and design disclosed herein were originated by and are the property of Bosch Security Systems, Inc. Bosch reserves all patent, proprietary design, manufacturing, reproduction, use and sales rights thereto, and to any article disclosed therein, except to the extent rights are expressly granted to others.

COPYRIGHT NOTICE

Copyright 2018 by Bosch Security Systems, Inc. All rights reserved. Reproduction, in whole or in part, without prior written permission from Bosch is prohibited.

*All other trademarks are property of their respective owners.

WARRANTY AND SERVICE INFORMATION

For warranty and service information, refer to the appropriate web site below:

- RTS Intercoms www.rtsintercoms.com/warranty
- RTS Digital
- RTSTW
- AudioCom
- RadioCom
- Intercom Headsets..... www.telex.com

CUSTOMER SUPPORT

Technical questions should be directed to:

Customer Service Department
 Bosch Security Systems, Inc.
www.telex.com

TECHNICAL QUESTIONS EMEA

Bosch Security Systems Technical Support EMEA
http://www.rtsintercoms.com/contact_main.php

DISCLAIMER

The manufacturer of the equipment described herein makes no expressed or implied warranty with respect to anything contained in this manual and shall not be held liable for any implied warranties of fitness for a particular application or for any indirect, special, or consequential damages. The information contained herein is subject to change without prior notice and shall not be construed as an expressed or implied commitment on the part of the manufacturer.

	<p>CAUTION</p> <p>RISK OF ELECTRIC SHOCK DO NOT OPEN</p>	
<p>THE LIGHTNING FLASH AND ARROWHEAD WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF "DANGEROUS VOLTAGE" INSIDE THE PRODUCT.</p>	<p>CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER. NO USER-SERVICABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.</p>	<p>THE EXCLAMATION POINT WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF IMPORTANT INSTRUCTIONS ACCOMPANYING THE PRODUCT.</p>
<p>SEE MARKING ON BOTTOM/BACK OF PRODUCT.</p>		

WARNING: APPARATUS SHALL NOT BE EXPOSED TO DRIPPING OR SPLASHING AND NO OBJECTS FILLED WITH LIQUIDS, SUCH AS VASES, SHALL BE PLACED ON THE APPARATUS.

WARNING: THE MAIN POWER PLUG MUST REMAIN READILY OPERABLE.

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, GROUNDING OF THE CENTER PIN OF THIS PLUG MUST BE MAINTAINED.

WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPRATUS TO RAIN OR MOISTURE.

WARNING: TO PREVENT INJURY, THIS APPARATUS MUST BE SECURELY ATTACHED TO THE FLOOR/WALL/RACK IN ACCORDANCE WITH THE INSTALLATION INSTRUCTIONS.

	<p>This product is AC only.</p>
---	---------------------------------

	
---	--

Important Safety Instructions

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Table of Contents

Important Safety Instructions	3
INTRODUCTION	9
General Description	9
Version Requirements	9
Features	10
LED Indicators	11
Specifications	13
Fail-Over Modes	14
Full Redundancy	15
Partial Redundancy	15
Non-Redundancy	16
Debug Information	21
INSTALLATION AND CONFIGURATION	25
Installation	25
Requirements	25
Supported ADAM Configurations	26
Supported ADAM-M Configurations	27
Configuration	28
Manual Configuration	28
Configure each MCII-e Master Controller IP Address for the Ethernet	28
Configure the size of your Intercom system for each frame	29
Configure The Frame Using The Frame Mapping Window In Azedit	33
Cable the Ethernet and TBX-2 Links	34
Dynamic Configuration	34
Configure each MCII-e Master Controller IP Address for the Ethernet	34
Configure the Size of your Intercom System for each Frame	36
Cable the Ethernet and TBX-2 Links	41
Configure the frame using the Frame Mapping window in AZedit	42
Base 8 vs. Base 16 Port Number Systems	43
Base 8 Port Number System (Legacy support only)	43
Base 16 Port Number System	46
Force Autonomous Mode Check Box	48
AZedit Connections	49
WINDOW DESCRIPTIONS	51
Frame Mapping Table Window	51
Frame Column	51
IP Address 1 Column	52
MAC Address 1 Column	52

IP Address 2 Column	52
MAC Address 2 Column	52
Base 16 Column Check Box	52
Move Up Button	52
Move Down Button	53
Accept Frame Mapping Table from Other Frames Check Box	53
Apply Button	53
Test Button	53
Done Button	53
Select Frame Window	54
IP Address 1 Column	54
MAC Address 1 Column	54
IP Address 2 Column	54
MAC Address 2 Column	54
OK Button	54
Cancel Button	54
TBX-2 Links Status Window	55
TBX-2 Column	55
Comm Column	55
(A) Link Up/Dn Column	56
(A) Partner Column	56
(B) Link Up/Dn Column	56
(B) Partner Column	56
(C) Link Up/Dn Column	56
(C) Partner Column	56
Audio A Column	57
Audio B Column	57
Audio C Column	57
Intercom Alarms	57
Frame Column	59
Alarm Time Column	59
Resolved Time Column	59
Description Column	59
Logging Window	60
Configure Logging Window	61
J1 Radio Button	61
J9 Radio Button	61
J10 Radio Button	61
Ethernet Radio Button	61
IP Address Field	61
All Frames Radio Button	61
This Frame Only Radio Button	61

FIRMWARE UPGRADES	63
Download Firmware to the TBX-2 Card	63
Download the Bootloader File to the TBX-2 Card (v1.2.2 or later)	65
Download the Bootloader File to the TBX-2 Card (v1.1.0 or later)	67

RING ARCHITECTURE	71
Requirements	71
Ring Architecture Overview	71
Ring Configurations	75

List of Figures

FIGURE 1.	4 Frame System with Full Redundancy, including failover Master Controller	15
FIGURE 2.	Partially Redundant system, including failover Master Controller	16
FIGURE 3.	4 Frame System with No Redundancy, including failover Master Controller	17
FIGURE 4.	Eight Frame TBX-2 System – Non-Redundant	19
FIGURE 5.	Upload Debug Information	21
FIGURE 6.	TBX-2 Slots in the ADAM frame	26
FIGURE 7.	Base 8 Port Numbering System Example	44
FIGURE 8.	Tribus Slot in the ADAM Frame	44
FIGURE 9.	Base 8 Port Numbering scheme with both AIO-16 and an AIO-8 card installed.	45
FIGURE 10.	Base 8 Port Numbering scheme with both AIO-16 and AIO 8 card installed	45
FIGURE 11.	Force Autonomous Mode when no audio links up	48
FIGURE 12.	Connect To Frame Menu	49
FIGURE 13.	Frame Mapping Table	51
FIGURE 14.	Apply Button message	53
FIGURE 15.	Frame Mapping Table Valid message	53
FIGURE 16.	Select Frame Window	54
FIGURE 17.	TBX-2 Links Status Window	55
FIGURE 18.	Intercom Alarm Indication	57
FIGURE 19.	Log Viewer Window	60
FIGURE 20.	Configure Logging Window	61
FIGURE 21.	ADAM-M Three (3) Frame Ring Configuration	75
FIGURE 22.	ADAM-M Four (4) Frame Ring Configuration	75
FIGURE 23.	ADAM-M Five (5) Frame Ring Configuration	76
FIGURE 24.	ADAM-M Six (6) Frame Ring Configuration	76
FIGURE 25.	ADAM-M Seven (7) Frame Ring Configuration	77
FIGURE 26.	ADAM-M Eight (8) Frame Ring Configuration	78
FIGURE 27.	ADAM-M Nine (9) Frame Ring Configuration	79

General Description

A single TBX-2 fiber card can link up to four (4) ADAM/ADAM-M frames, while multiple Tribus cards can link up to nine (9) frames. This makes it possible to increase the number of available users on a system by transparently integrating additional frames. The ADAM/ADAM-M frame must be equipped with an MCII-e Master Controller card (version 2.0.4 or later), allowing the TBX-2 to link together multiple ADAM/ADAM-M intercom systems. Ring-mode wiring supports systems with more than 256 timeslots in a given frame; it reduces the number of Tri-Bus cards required for systems with larger numbers of frames, and it simplifies the wiring scheme. This needs an MCII-e Master Controller card version 2.8.0 or later. This functionality can be useful in mobile production scenarios to tie systems together via fiber using the digital audio of the TBX-2. In this scenario, the MCII-e Master Controllers are tied together via Ethernet connections. In a failure of the Ethernet connection of one (1) frame, the affected ADAM/ADAM-M can be automatically isolated as an autonomous frame, and the remaining frames function as a normal interconnected system. The TBX-2 works in both AIO-8 and AIO-16 frame environments with simple software settings in AZedit intercom software. The TBX-2 card comes with a fiber connection only, allowing a range of up to 24.8 miles (40km) between ADAM/ADAM-M frames.

Version Requirements

- MCII-e version 2.0.4 or later
- AZedit version 3.6.1 or later
- MCII-e version 2.8.0 or later for ring wiring
- AZedit version 4.3.0 or later for ring wiring

IMPORTANT: When updating a system, the PC II-e must have the firmware changed to that of the MCII-e before the TBX-2 cards are inserted into the frame.

Features

Interface with ADAM/ADAM-M The TBX-2 card is backward compatible with all existing AES, AIO, and RVON cards in an ADAM/ADAM-M intercom system. The hardware and software is compatible to work seamlessly with the **TDM**^a (Time Division Multiplexing) and control bus circuitry for routing audio and controlling data. This card provides a downloadable firmware feature through AZedit Intercom Software.

Channels Per Link The TBX-2 has three (3) fiber links. Each link can support up to a maximum of 256 audio channels per link. This channel capability is provided in AIO-16 systems. Moreover, the link can also be scaled down to 128 channels, allowing it to support AIO-8 based intercom systems.

New System Architecture The System Framework has been redefined for the TBX-2 allowing the system to reconfigure itself in the event of a frame failure. In the scenario where the master frame fails, another ADAM/ADAM-M frame within the system seizes control until the fault is fixed. This fail-save mechanism monitors both audio and control, and sends messages to report any corrupt behavior in the system.

NOTE: DBX cards are not compatible with TBX-2 cards.

Support for Multiple Distances The backcard features three (3) **SFP** (Small Form-Factor Pluggable) connectors that allow for support of multiple distances. This allows the user to configure these cards based on their custom application. The user can insert **COTS** (Commercial Off-The-Shelf) modules (Multi Mode/Single Mode) to match their needs.

System Expansion The TBX-2 employs the next generation **ASIC** (Application Specific Integrated Circuit) Nucleus for higher performance and future system expansion. See Table 1 on page 14.

Autonomous Mode Normally, a TBX-2 frame communicates with other frames that are part of the same intercom. However, if an Ethernet link is not present, the TBX-2 automatically enters Autonomous mode.

AZedit also has a new option on the Intercom Configuration Options window (*Options|Intercom Configuration|Options Tab*) called “Force Autonomous Mode when no audio links up.” The **Force Autonomous Mode** check box is used to force the current frame into autonomous (independent) mode, if none of its TBX-2 links are up. Normally, a frame communicates with other frames that are part of the same intercom. If selected, the frame refuses to communicate with any other frames if none of its TBX-2 links are up, even if Ethernet communications are fine. And, once one (1) or more of its audio links are restored, the frame automatically tries to re-establish messaging links to the other frames in the cluster.

Automatic Transfer of Control Within each frame, both the active and the standby MCII-e master controllers maintain Ethernet messaging links with every other frame in the cluster. If the Active controller in the frame loses its messaging links, but the standby controller has one (1) or more Ethernet links available, an automatic transfer of control is performed. When this transfer occurs, the standby controller becomes the active controller and the previously active controller becomes the standby controller when its messaging links are restored.

Alarms and Warnings A new view in AZedit displays various alarms and warnings occur in the intercom. Once an alarm has been resolved, it is deleted after five (5) minutes.

AZedit Connections AZedit Connections (*Options|Connect to Frame*) allow the user to select the frame AZedit should connect to.

AZedit version 3.6.1 or higher is required.

In Use Tally Indicator When a user turns a talk or listen key on to connect with a resource in another frame within the cluster, the key displays a busy tally, flashing between the *Alpha* and ******, to indicate the resource is unavailable.


NOTE: For special lists and party lines, no unavailable tally is generated if there are any members of the special list or party line in accessible frames.

Logging Each frame in an intercom cluster generates its own log message and stores them locally. Normally, the log messages are identical from frame to frame, except when frames are synchronizing. Using the logging configuration window, you can select whether changes affect all frames in a cluster or just the locally connected frame.


a. TDM is a technology that transmits multiple signals simultaneously over a single transmission path.

LED Indicators

Port Status



Link Status




Sub-Page Codes

- Link A - 0x08
- Link B - 0x04
- Link C - 0x02


Note: Use the lower push-button to select which link is displayed.

Note: The sub-page code is displayed on bits 23-20 while lower push-button is held in.

Executive



Test Audio




DIP Switch Settings

Ignore Port A Test Audio	1
Ignore Port B Test Audio	2
Ignore Port C Test Audio	3
	4
	5
	6
	7
Debug Only Mode	8


Sub-Page Codes

Port A - ASIC 0	0x80	Port A - ASIC 0
Port A - ASIC 1	0x08	Port A - ASIC 1
Port B - ASIC 0	0x40	Port B - ASIC 0
Port B - ASIC 1	0x04	Port B - ASIC 1
Port C - ASIC 0	0x20	Port C - ASIC 0
Port C - ASIC 1	0x02	Port C - ASIC 1
Combined Audio Out	0xee	Combined Audio Out

Message Queue Display



Card Status



Sub-Page Codes

Max msgs allocated	Uxff	Msgs currently in use
Queue to Local MC	0x80	Queue to this card

Note: Sub-page number is displayed on bits 22-23 while bottom button is pressed and held in.

Specifications

Power

Input Power

2.6 Amps at 5 V (Combined)

Power Consumption

13.2 W

Audio

Audio Performance

THD+N at 1 kHz, 0.4%

Frequency Response

Within± 1 dB from 20 Hz to 20 kHz

Environmental

Weight

Front Card

0.72 lb (0.33 kg)

Back Card

0.42 lb (0.19 kg)

Temperature

Operating

0°C to 50°C (32°F to 122°F)

Storage

-40°C to 70°C (-40°F to 158°F)

Board Performance

Throughput Per Link:

360Mb/sec

SFP Fiber Transceivers:

Voltage:

3.3 V Rails

Standard Rate:

SONET OC12 or Gigabit Ethernet

Recommended Parts:

Multi-Mode:

Finisar - FTLF8519P2BNL (Oxide VCSEL, Maximum reach of 550m)

Single Mode:

Finisar - FTLF1422P1BTL (1310nm, Maximum reach 40km)

Fiber Cable Connector Type:

Multiple Mode Fiber LC-LC Duplex Connector – max length 500m (546.8yd.)

Single Mode Fiber LC-LC Duplex Connector – max length 40km (24.9mi)

Configuration Requirements

An MCII-e Master Controller card must be installed in the same frame as the TBX-2. For more information, see the MCII-e User Manual which can be found at www.rtsintercoms.com.

TABLE 1. Systems Supported by the TBX-2 Card

# of Frames	Links Used	# TBX-2 Cards per Frame	System	Channels	TBX-2 Only System
2	1	1	AIO-8	256	ADAM with 1 TBX-2 Card - Place TBX-2 Card in Slot 9
2	1	1	AIO-16	512	
3	3	1	AIO-8	384	
3	3	1	AIO-16	768	
4	6	1	AIO-8	512	
4	6	1	AIO-16	880	
5	10	2	AIO-8	640	ADAM with 2 TBX-2 Cards - Place TBX-2 Cards in Slots 8 and 9
6	15	2	AIO-8	768	
7	21	2	AIO-8	880	
8	28	3	AIO-8	880	ADAM with 3 TBX-2 Cards - Place TBX-2 Cards in Slots 8, 9, and 10

NOTE:

- The TBX-2–TBX-2 supports up to eight (8) frames in non-redundant mode. Slot 10 should be used if a third TBX-2–TBX-2 card is needed.
- If ring wiring is selected, the TBX-2 supports up to nine frames in redundant mode. Two cards per frame must be used.

Fail-Over Modes

Audio and communications (called *control*¹) between frames is separated between the TBX-2 card and the MCII-e Master Controller Card. Communication between frames using TBX-2 occurs using the MCII-e Master Controller over Ethernet. Audio is passed between frames using the TBX-2 card fiber connection (see Figure 1 to Figure 3).

Audio between frames exists as long as there is a single valid link between frames. There are three (3) types of system configurations:

- Full Redundancy
- Partial Redundancy
- Non-Redundancy

1. *Control is the ability to talk to keypanels and act on key presses.*

Full Redundancy

In **Full Redundancy** systems, there are two (2) links, shown in Figure 1, between each frame, so losing either one does not affect audio.




FIGURE 1. 4 Frame System with Full Redundancy, including failover Master Controller

Partial Redundancy

In a **Partially Redundant** system, multiple frames, but not all frames, have two (2) links configured between them. In the example shown in Figure 2, Frame 1 and Frame 2 have full redundancy between them; however, Frame 3 has only one (1) link to Frame 1. This means if the fiber connection between Frame 1 and Frame 3 is broken, Frame 3 cannot send or receive audio.




FIGURE 2. Partially Redundant system, including failover Master Controller

Non-Redundancy

In a **Non-Redundant** system, shown in Figure 3, there is only one (1) link between frames, so if the fiber link goes down, audio communications between the frames is lost.




FIGURE 3. 4 Frame System with No Redundancy, including failover Master Controller




FIGURE 4. Eight Frame TBX-2 System – Non-Redundant

Debug Information

The **Debug Information** menu item, shown in Figure 5, allows you to send a flash file to RTS to help troubleshoot the reason for an intercom issue in AZedit. In the event of a processor crash, the processor saves diagnostic information about the cause of the problem to its flash memory. The menu item stays grayed-out until a flash file is created when the processor crashes.

NOTE: Every card in every frame stores its own debug information. So, if frame 3 has a processor crash, you must connect AZedit to frame three (3) to create an.azd file to send to RTS for debugging.





FIGURE 5. Upload Debug Information

To create the debug file, do the following:

NOTE: Once the processor has crashed the Upload Debug Information menu item becomes active.


1. From the Options menu, select **Upload Debug Information**.
The Upload Debug Information window appears.



NOTE: By default, the Debug folder (*C:\Telex\AZedit\Debug*) is where the AZedit debug file you create is stored.

2. In the File name field, enter a **name** for the debug file you create. For example, you could use the date as the file name – 12152008.azd.
3. Click **Save**.
The Uploading Debug Information Status window appears.

Card Type	Comm	Status	Errors To	BER To	Errors
2	-	-	-	-	-
)	-	-	-	-	-
3	-	-	-	-	-
4	AIO-16	OK	Cur	-	-
2	AIO-16	OK	Cur	-	-
)	AIO-16	OK	Cur	-	-
3	AIO-16	OK	Cur	-	-
3	AIO-16	OK	Cur	-	2
4	AIO-16	OK	Cur	-	-
2	AIO-16	OK	Cur	-	-
)	-	-	-	-	1
	TBX	-	-	-	-
3	AIO-16	OK	Cur	-	-
3	AIO-16	OK	Cur	-	1
4	AIO-16	OK	Cur	-	-
	AIO-16	OK	Cur	-	-
	AIO-16	OK	Cur	2	1
	-	-	-	-	-
	AIO-16	OK	Cur	8	-




NOTE: Select the *Delete debug information from intercom* check box if you want to delete the debug information from system once the azd file is created. Otherwise, the information is kept on the intercom system. Remember, you can only save the most current debug information. This means if your processor fails twice you only capture the second failure's diagnostic information.

4. Click **OK**.
The AZedit debug file is made.

To find the file you just created, do the following:

1. Right-click on **My Computer**, and from the popup menu, select **Explore**.
The My Computer window appears with a navigation pane down the left hand side of the window.
2. Navigate to **C:\Telex\AZedit\Debug**.
OR
Navigate to the **folder** you store your AZedit debug file.
The file you create is stored in this folder.



Once you have created the AZedit Debug file, please contact your RTS system engineering for further instructions. If you do not know your local system engineer, please see <http://www.rtsintercoms.com/contact.php>.

Installation and Configuration

Installation

Requirements

- 10 Base-T or 100 Base TX Ethernet connection to the network
- AZedit 3.6.1 or higher
- MCII-e Master Controller 2.0.4 or higher
- AZedit version 4.3.0 or later for ring wiring
- MCII-e Master Controller 2.8.0 or later for ring wiring

NOTE: See the MCII-e Master Controller User Manual (p/n 93507734000) user manual for specific DIP switch settings for proper TBX-2 operation.

IMPORTANT: All frames in a TBX-2 system must have the same firmware version on the Controllers and TBX-2 cards.

Supported ADAM Configurations

TABLE 2. Supported TBX-2 Configurations for the ADAM

ADAM with 1 TBX-2 Card

Place TBX-2 Card in Slot 9

ADAM with 2 TBX-2 Cards

Place TBX-2 Cards in Slots 8 and 9

ADAM with 3 TBX-2 Cards

Place TBX-2 Cards in Slots 8, 9, and 10




FIGURE 6. TBX-2 Slots in the ADAM frame

Supported ADAM-M Configurations

IMPORTANT: Remember to save your configuration, if needed, because it is deleted.

NOTE: Whenever possible avoid installing MADI cards in slot 6 due to improved reliability through heat reduction.

The ADAM-M has a limit of only two (2) MADI cards. The following configurations are supported:

TABLE 3. Supported MADI/TBX-2 Configurations for the ADAM-M

ADAM-M with 2 MADI cards and 0 TBX-2 Cards

Place MADI Cards in slots 5 and 6

ADAM-M with 2 MADI cards and 1 TBX-2 Card

Place MADI Cards in slots 5 and 8

Place TBX-2 Card in slot 6

ADAM-M with 2 MADI cards and 2 TBX-2 Cards

Place MADI Cards in slots 3 and 8

Place TBX-2 Cards in slots 5 and 6

ADAM-M with 1 MADI Card^a and 3 TBX-2 Cards

Place MADI Card in slot 8

Place TBX-2 Cards in slots 4, 5, and 6

a. When three (3) TBX-2 cards are used in the ADAM-M, only one (1) MADI card can be used in the system. For complete system clock redundancy slots 5 and 6 must be populated.

To install the TBX-2 into an ADAM/ADAM-M frame, do the following:

1. Firmly push the **back card** into proper slot in the ADAM/ADAM-M frame.

NOTE: See Table 2 or Table 3 for proper card placement in the intercom.

2. Using a screwdriver, secure the **back card** into the frame with the provided screws.
3. Firmly push the **front card** into the front corresponding back card slot.
4. Securely lock the **front card** in place with the top and bottom extractor handles.



Configuration

IMPORTANT: There are two (2) ways to configure multi-frame systems:

- Manual
- Dynamic Ethernet and TBX-2 links must be running

Manual Configuration

To **manually configure the TBX-2 card**, the following steps must be completed for the Intercom System to be active:

Step 1 Configure each MCII-e Master Controller IP Address for the Ethernet (page 28)

Step 2 Configure the size of your Intercom system for each frame (page 29)

NOTE: Each frame must be configured exactly the same. The number of ports must not exceed the number of ports allowed for the number of frames in the intercom system.

Step 3 Configure the frame using the Frame Mapping window in AZedit (page 33)

Step 4 Cable the Ethernet and TBX-2 Links (page 34)

Configure each MCII-e Master Controller IP Address for the Ethernet

To **configure the IP Address for the MCII-e**, do the following:

1. Verify you are **serially connected** to AZedit.
You must be connected serially to make any changes to the Ethernet Setup window in AZedit.
2. Open **AZedit**.
3. From the Options menu, select **Ethernet Setup**.
The Ethernet Setup window appears.

The screenshot shows the 'Ethernet Setup' dialog box. It is divided into two main sections: 'Left Controller (Active)' and 'Right Controller (Standby)'. Each section contains four input fields: 'IP Address', 'Network Mask', 'Default Gateway', and 'MAC Address'. The 'Left Controller (Active)' section has the following values: IP Address: 192 . 168 . 210 . 87, Network Mask: 255 . 255 . 0 . 0, Default Gateway: 0 . 0 . 0 . 0, and MAC Address: 00:0B:7C:80:03:3A. The 'Right Controller (Standby)' section has the following values: IP Address: 0 . 0 . 0 . 0, Network Mask: 0 . 0 . 0 . 0, Default Gateway: 0 . 0 . 0 . 0, and MAC Address: 00:00:00:00:00:00. At the bottom right of the dialog, there are two buttons: 'Apply' and 'Close'.

4. In the IP Address field, enter the **IP Address** for the MCII-e.
5. In the Network Mask field, enter the **Network Mask** for the MCII-e, if applicable
6. In the Default Gateway field, enter the **Default Gateway** for the MCII-e, if applicable.

NOTE: If you are unsure of your IP Address, Network Mask, or Gateway Address, contact your System Administrator for this information.

7. Click **Apply**.
The IP Address is set for the MCII-e.
8. Repeat **steps 1-7** for each frame in your system.


Configure the size of your Intercom system for each frame

NOTE: Each frame must be configured identically, otherwise they cannot talk to each other even when an Ethernet link is available.

To **configure the size of your frame**, do the following:

IMPORTANT: You must know the number of frames and the number of ports your intercom system supports.

1. In AZedit, from the Options menu, select **Intercom Configuration**.
A warning message appears.



2. Click **OK**.

The Intercom Configuration window appears.

The Intercom Configuration dialog box is divided into two tabs: Resources and Options. The Resources tab is active, showing the following settings:

Resource	Value
Frames	1
Ports	272
Party Lines	96
IFBs	64
IFB Special Lists	32
Special Lists	64
GPI Outputs	96
ISOs	64
Assignment Groups	32
UPL Resources	120
UPL Statements	256
GPI Inputs	96
Inter-panel Dims	32

There is an "Intercom Sizing Wizard" button in the Resources section. The Options tab contains an "Intercom Setup" section with the following settings:

- ADAM
 - Redundant Audio
 - Test Audio

At the bottom of the dialog are buttons for "Apply", "Cancel", "Test", "Help", and "Reset to Defaults".

3. Click **Intercom Sizing Wizard**.


The Select Intercom Type window appears.

The Select Intercom Type dialog box prompts the user to "Select the type of intercom to configure:". The options are:


- Zeus / Zeus-II
- Zeus-III
- Zeus-III LE
- Cronus
- ADAM-CS
- ADAM
- ODIN

At the bottom of the dialog are buttons for "< Back", "Next >", "Cancel", and "Help".

4. Select the **ADAM/ADAM-M** radio button.
5. Click **Next**.
The Select Intercom Size window appears.




6. From the drop down menu, select the number of frames in the system (up to eight frames).
7. Click **Next**.
The Select Frame Links window appears.



8. Verify the **TBX-2 Expander Cards (TBX-2)** radio button is selected.
9. Select the **Enable Test Audio (recommended)** check box.

10. Click **Next**.

The Allocate Ports Configuration window appears.



Allocate Ports To Frames


Configure the number of ports in each frame.

Frame	Size	Ports
1	256	001 - 256
2	256	257 - 512
3	256	513 - 768

< Back Next > Cancel Help

11. In the Size field, adjust the **intercom size**.

A warning message appears.




AZedit

 **Warning:** Timeslots 255-256, 511-512, 767-768 and 1023-1024 will not be available in all frames (in this configuration).

Mesh wiring configurations can forward a maximum of 256 timeslots between frames. However, test audio requires two timeslots on each link, limiting the number of timeslots that can be forwarded by each frame to 254.

OK

- Click **OK**.
The *Verify Intercom Configuration* window appears.




- Click **Test** to verify the configuration validity.
- Click **Apply** to apply the configuration to the intercom system.
The *Intercom Configuration* window closes and the configuration is applied to the intercom system.

Configure The Frame Using The Frame Mapping Window In Azedit

To configure the frames with the **Frame Mapping** window, do the following:

- From the Options menu in AZedit, select **Frame Mapping Table**.
The *Frame Mapping Table* appears with the current frame's IP and MAC Address(es) already entered in the table.



- Click the **Frame 2 IP Address 1** field.

The field becomes active and a browse button appears.



- Enter the **IP Address** for Frame 2.

4. Repeat **step 2** and **step 3** for every frame to be included in the system.
5. Using the Move Up and Move Down buttons, move the **frame** to the hierarchical position you desire.
6. Repeat **step 5** for all the frames in the intercom system.
7. Click **Test**.
The results will tell you the mapping is either valid or invalid.
8. Click **Apply**.
The frames are mapped together.

Cable the Ethernet and TBX-2 Links

To **cable the Ethernet and TBX-2 Links**, do the following:

1. Power **off** all the frames in the system.
2. Using an Ethernet cable, connect **each frame** to the network.
3. Using figures 1 through 4, connect the **frames** with the fiber links.
4. Power **on** the system.

Dynamic Configuration

IMPORTANT: Remember to save your configuration, if needed, because it is deleted when making changes to the Intercom Configuration menu item.

To dynamically configure the TBX-2 card, the following steps must be completed for the Intercom System to be active:

Step 1 Configure each MCII-e Master Controller IP Address for the Ethernet (page 28)

Step 2 Configure the size of your Intercom system for each frame (page 29)

NOTE: Each frame must be configured exactly the same. The number of ports must not exceed the number of ports allowed for the number of frames in the intercom system.

Step 3 Cable the Ethernet and TBX-2 Links (page 41)

Step 4 Configure the frame using the Frame Mapping window in AZedit (page 33)

Configure each MCII-e Master Controller IP Address for the Ethernet

To **configure the IP Address for the MCII-e**, do the following:

1. Verify you are **serially connected** to AZedit.

IMPORTANT: You must be connected serially to make any changes to the Ethernet Setup window in AZedit.

2. Open **AZedit**.

- From the Options menu, select **Ethernet Setup**.
The Ethernet Setup window appears.

Ethernet Setup

Left Controller (Active)

IP Address: 192 . 168 . 210 . 87

Network Mask: 255 . 255 . 0 . 0

Default Gateway: 0 . 0 . 0 . 0

MAC Address: 00:0B:7C:80:03:3A

Right Controller (Standby)

IP Address: 0 . 0 . 0 . 0

Network Mask: 0 . 0 . 0 . 0

Default Gateway: 0 . 0 . 0 . 0

MAC Address: 00:00:00:00:00:00

Apply

Close

- In the IP Address field, enter the **IP Address** for the MCII-e.
- In the Network Mask field, enter the **Network Mask** for the MCII-e, if applicable
- In the Default Gateway field, enter the **Default Gateway** for the MCII-e, if applicable.

NOTE: If you are unsure of your IP Address, Network Mask, or Gateway Address, contact your System Administrator for this information.

- Click **Apply**.
The IP Address is set for the MCII-e.
- Repeat **steps 1-7** for each frame in your system.


Configure the Size of your Intercom System for each Frame

NOTE: Each frame must be configured identically, otherwise they cannot talk to each other even when an Ethernet link is available.


To **configure the size of your frame**, do the following:

IMPORTANT: You must know the number of frames and the number of ports your intercom system supports.

1. In AZedit, from the Options menu, select **Intercom Configuration**.
A warning message appears.



2. Click **OK**.
The Intercom Configuration window appears.




The Intercom Configuration window is a dialog box with a title bar containing a question mark and a close button. It has two tabs: "Resources" and "Options". The "Options" tab is active. On the left, there are two input fields: "Frames" with the value "1" and "Ports" with the value "272". Below these is a button labeled "Intercom Sizing Wizard". The main area contains a list of configuration items, each with a corresponding input field:

Party Lines	96
IFBs	64
IFB Special Lists	32
Special Lists	64
GPI Outputs	96
ISOs	64
Assignment Groups	32
UPL Resources	120
UPL Statements	256
GPI Inputs	96
Inter-panel Dims	32

On the right side, there is a section titled "Intercom Setup" containing the "ADAM" section with two checkboxes: "Redundant Audio" and "Test Audio", both of which are unchecked. At the bottom right of the main area is a button labeled "Reset to Defaults". At the bottom of the window are four buttons: "Apply", "Cancel", "Test", and "Help".

3. Click **Intercom Sizing Wizard**.
The Select Intercom Type window appears.




The Select Intercom Type window is a dialog box with a title bar containing a question mark and a close button. It contains the text "Select the type of intercom to configure:" followed by a list of radio button options:

- Zeus / Zeus-II
- Zeus-III
- Zeus-III LE
- Cronus
- ADAM-CS
- ADAM
- ODIN

At the bottom of the window are four buttons: "< Back", "Next >", "Cancel", and "Help".

4. Select the **ADAM/ADAM-M** radio button.
5. Click **Next**.

The Select Intercom Size window appears.



Select Intercom Size


Select the number of intercom frames:

3

< Back Next > Cancel Help

6. From the drop down menu, select the number of frames in the system (up to eight frames).
7. Click **Next**.

The Select Frame Links window appears.



Select Frame Links

Select the type of card used to connect frames together:

Single Bus Expander Cards (SBX)

Dual Bus Expander Cards (DBX)

Tri-Bus Expander Cards (TBX)

Use Redundant Audio

Enable Test Audio (recommended)


Use Ring Wiring

< Back Next > Cancel Help

8. Verify the **TBX-2 Expander Cards (TBX-2)** radio button is selected.
9. Select the **Enable Test Audio (recommended)** check box.

10. Click Next.

The Allocate Ports Configuration window appears.



Allocate Ports To Frames


Configure the number of ports in each frame.

Frame	Size	Ports
1	256	001 - 256
2	256	257 - 512
3	256	513 - 768

< Back Next > Cancel Help

11. In the Size field, adjust the intercom size.

A warning message appears.



AZedit


 **Warning: Timeslots 255-256, 511-512, 767-768 and 1023-1024 will not be available in all frames (in this configuration).**

Mesh wiring configurations can forward a maximum of 256 timeslots between frames. However, test audio requires two timeslots on each link, limiting the number of timeslots that can be forwarded by each frame to 254.

OK

12. Click **OK**.

The Verify Intercom Configuration window appears.



13. Verify the **intercom configuration**.

14. Click **Finish**.

The Intercom Configuration window reappears.

The screenshot shows the 'Intercom Configuration' window with three tabs: Resources, Options, and Capabilities. The 'Options' tab is active. The window is divided into several sections:

- Resources:** Includes input fields for 'Frames' (set to 3) and 'Ports' (set to 768). Below these is an 'Intercom Sizing Wizard' button.
- Table:** A table with three columns: 'Frame', 'Size', and 'Ports'.

Frame	Size	Ports
1	256	(001 - 256)
2	256	(257 - 512)
3	256	(513 - 768)
- Party Lines:** A list of settings with input fields: Party Lines (96), IFBs (64), IFB Special Lists (32), Special Lists (64), GPI Outputs (96), ISOs (64), Assignment Groups (32), UPL Resources (120), UPL Statements (256), Auto Dials (64), GPI Inputs (96), and Inter-panel Dims (32).
- Intercom Setup:** A section titled 'ADAM w/TBX' containing three checkboxes: 'Redundant Audio' (unchecked), 'Test Audio' (checked), and 'Ring Wiring' (unchecked).
- Buttons:** At the bottom are 'Apply', 'Cancel', 'Test', and 'Help' buttons. A 'Reset to Defaults' button is located in the bottom right corner of the main configuration area.

NOTE: If redundant is not selected, redundant TBX-2 cards cannot be used in the same frame because ports are allocated to slot 9 and the Matrix cannot register the second TBX-2 card.

Test audio uses ports at the end of the 256 slots to send an audio test signal to other frames in the system and waits for them to be acknowledge. If the port gets back something different/out of range, it tears down the audio links and remakes them. Once finished, the process starts over. Test Audio should always be selected.

15. Under Number of Ports in, make any **changes to the frames** for port allocation, as needed.

16. Click **Test** to verify the configuration validity.

17. Click **Apply** to apply the configuration to the intercom system.

The Intercom Configuration window closes and the configuration is applied to the intercom system.

Cable the Ethernet and TBX-2 Links

To **cable the Ethernet and TBX-2 Links**, do the following:


1. Power **off** all the frames in the system.
2. Using an Ethernet cable, connect **each frame** to the network.
3. Using figures 1 through 4, connect the **frames** with the fiber links.
4. Power **on** the system.

Configure the frame using the Frame Mapping window in AZedit

To configure the frames with the Frame Mapping window, do the following:

TIP: To save time from manually entering in the IP Addresses and MAC Addresses for all you frames, be sure to connect to Ethernet. By being connected via Ethernet, you can browse for the other ADAM/ADAM-M frame's addresses, select them, and automatically update the table.

1. From the Options menu in AZedit, select **Frame Mapping Table**.
The Frame Mapping Table appears with the current frame's IP and MAC Address(es) already entered in the table.




2. Click the **Frame 2 IP Address 1** field.

The field becomes active and a browse button appears.



3. Click the **browse** button.

The Select Frame window appears.



4. Select the **Frame(s)** to add to the Frame Mapping Table.
5. Click **OK**.
The Select Frame window closes and the frame information appears in the Frame Mapping Table.
6. Using the Move Up and Move Down buttons, move the **frame** to the hierarchical position you desire.
7. Repeat **step 6** for all the frame in the intercom system.

8. Click **Test**.
The results display the mapping is either valid or invalid.
9. Click **Apply**.
The frame resets.
10. Open the **Frame Mapping Table**.

NOTE: Steps 11 through 13 must be done on each frame in the system, except frame 1.

11. Select the **Accept frame mapping table from other frames** check box.
12. Click **Test**.
13. Click **Apply**.
The frame resets.

Base 8 vs. Base 16 Port Number Systems

With the advent of the TBX-2 card and the ever-evolving technology to a 16-channel port system, **Base 8** (or standard density) and **Base 16** (or high density) port number systems were created.

In order to support cards with more than 16 ports, AZedit supports a Port Allocation Table. The Port Allocation Table is used to select which card types occupy which intercom slots and which ports are allocated to each card. Ports are allocated to each card, up to four groups of 16 (64 ports per card). Alternately, eight ports per slot can be selected.

Requirements

- Minimum version MCII-e 2.3.0 or later
- Minimum version AZedit 3.9.0 or later

NOTE: Any 16-channel card, must use the high density (Base 16) port numbering system. Alternatively, any 8-channel card can use either the standard density (Base-8) or high density (Base 16) port numbering system

Base 8 Port Number System (Legacy support only)

The **Base 8 Port Number System** splits 16 ports between a top and bottom group. The bottom group starts with 1 through 136; the top group consists of ports 137 through 272 (see Figure 7).

EXAMPLE: This means that if you have an AIO-16 in slot 1, ports 1–8 and 137–144 is used by the AIO-16 card. Alternatively, if you have AIO-16’s in slots 1 and 3 and an AIO-8 in slot 2, the following port mapping applies:

Figure 4. Example for Base 8 Port Numbering

AIO-16 Ports 1– 8 and 137–144	Ports 145-161 are not used when an AIO-8 card is in the slot	AIO-16 Ports 17–33 and 162–178
	AIO-8 Ports 9–16	




FIGURE 7. Base 8 Port Numbering System Example




FIGURE 8. Tribus Slot in the ADAM Frame




FIGURE 9. Base 8 Port Numbering scheme with both AIO-16 and an AIO-8 card installed.






FIGURE 10. Base 8 Port Numbering scheme with both AIO-16 and AIO 8 card installed

Base 16 Port Number System

The **Base 16 Port Number System** is newly supported with the TBX-2 Card. Unlike the Base 8 Port Number System, where the ports were split into an upper and lower set of eight (8) ports, the Base 16 Port Number System puts all 16 ports in one slot. This means, when you configure your intercom system to support Base 16, slot 1 in the ADAM holds ports 1 through 16, slot 2 holds ports 17 through 33, slot 3 holds 34 through 49, and so on. When a TBX-2 card is inserted into the frame, the port numbering system jumps to the next available AIO card slot.

When using the port allocation table, the position of the card and the available port numbering allows for greater density cards, such as OMI-32, 48, or 64. And when MADI 32, 48, and 64 cards are used in conjunction with the high density system and the total card port density exceeds 256 ports, the use of ring wiring is required.





Force Autonomous Mode Check Box

The **Force Autonomous Mode** check box, shown in Figure 11, is used to force the current frame into autonomous (independent) mode, if none of its TBX-2 audio links are active. Normally, a frame communicates with other frames that are part of the same intercom. However, the Options page of the Intercom Configuration dialog has a new option, *Force Autonomous Mode when no audio links up*. If selected, the frame refuses to communicate with any other frames if none of its TBX-2 links are up, even if Ethernet communications are fine. And, once one (1) or more of its audio links are restored, the frame automatically tries to re-establish messaging links to the other frames in the cluster.




FIGURE 11. Force Autonomous Mode when no audio links up

To **Force Autonomous Mode when no audio links are up**, do the following:

1. From the Options menu in AZedit, select **Intercom Configuration**.
A warning window appears.



2. Click **OK**.
The Intercom Configuration window appears.
3. Click the **Options** tab.
The Options page appears.
4. Select the **Force Autonomous Mode when no audio links up** check box.
Force Autonomous Mode is enabled.
5. Click **Apply**.
The Intercom Configuration window closes.

AZedit Connections

The **AZedit Connections** menu item, shown in Figure 12, is used to select a frame that AZedit connects to. This menu also has the option to *Auto Connect*. If this is selected, AZedit automatically tries to connect to another frame if it loses its connection to the current frame.

NOTE: This menu is only available when AZedit is configured to communicate using Ethernet.

TIP: You can also change the frame, the serial port, or IP Address in the Communications window (*Options|Communications*).




FIGURE 12. Connect To Frame Menu

Window Descriptions

Frame Mapping Table Window

The **Frame Mapping Table** window, shown in Figure 13, is used to link TBX-2 frames together. Determine the frame position (1 through 8) and enter the primary and secondary MCII-e Master Controller IP Addresses.

Frame	IP Address 1	MAC Address 1	IP Address 2	MAC Address 2	Base 16
1	192.168.210.81	00:0b:7c:80:03:52	-	-	<input type="checkbox"/>
2	192.168.210.82	80:00:00:ff:ff:19	-	-	<input type="checkbox"/>

Accept frame mapping table from other frames

FIGURE 13. Frame Mapping Table

Frame Column

The **Frame** column displays the frame's positional rank within the intercom system.


IP Address 1 Column

The **IP Address 1** column indicates the IP Address of the Active MCII-e Master Controller.

To set the **IP Address**, do the following:

1. Click the **Address** to make the field active and the Browse button appear.
2. Click the **Browse** button to open the Select Frame Window.

NOTE: For more information, see “Select Frame Window” on page 54.



MAC Address 1 Column

The **MAC Address 1** column indicates the MAC Address of the active MCII-e Master Controller in the frame.

IP Address 2 Column

The **IP Address 2** column indicates the standby MCII-e Master Controller IP Address.

To set the **IP Address 2**, do the following:

1. Click the **Address** to make the field active and the Browse button appear.
2. Click the **Browse** button to open the Select Frame Window.

NOTE: For more information, see “Select Frame Window” on page 54.

MAC Address 2 Column

The **MAC Address 2** column indicates the MAC Address of the standard MCII-e Master Controller in the frame.

Base 16 Column Check Box

The **Base 16** check box is used to enable the Base 16 port number system. For more information, see “Base 8 vs. Base 16 Port Number Systems” on page 43.

Move Up Button

The **Move Up** button allows you to set the frame position of the system up in the frame hierarchy. Frame 1 is the master frame and holds the most complete frame mapping table. If frame 1 fails, then frame 2 becomes the master frame.

Move Down Button

The **Move Down** button allows you to set the frame position of the system down in the frame hierarchy. Frame 1 is the master frame and holds the most complete frame mapping table. If frame 1 fails, then frame 2 becomes the master frame.

Accept Frame Mapping Table from Other Frames Check Box

The **Accept Frame Mapping Table from Other Frames** check box is used to allow other frames to send their frame mapping information to the selected frame.

IMPORTANT: This check box does not remain selected once the frame has been tested and accepted.

NOTE: Each frame in a valid system must be defined in a table map to be able to communicate with the other frames in the system.

Apply Button

The **Apply** button is used to accept the modifications you make and send them to the Intercom System. Once the modifications have been applied, AZedit displays the message below and then reboots itself.



FIGURE 14. Apply Button message

NOTE: You must press the **Test** button before the Apply button becomes active.

Test Button

The **Test** button is used to test the frame mapping configuration you create. Once you have tested your frame map configuration, press the **Apply** button to implement the modifications you make. The message below appears if the frame map is deemed valid.



FIGURE 15. Frame Mapping Table Valid message

Done Button

The **Done** button is used to close the Frame Mapping window.

Select Frame Window

The **Select Frame** window, shown in Figure 16, is used to select a Frame (IP Address and MAC Address) to include in the Frame Mapping table for your TBX-2 Intercom System.




FIGURE 16. Select Frame Window

IP Address 1 Column

The **IP Address 1** column displays the IP Address of the active master controller in the ADAM/ADAM-M frame.

MAC Address 1 Column

The **MAC Address 1** column displays the MAC Address of the active master controller in the ADAM/ADAM-M frame.

IP Address 2 Column

The **IP Address 2** column displays the IP Address of the standby master controller, if available, in the ADAM/ADAM-M frame.

MAC Address 2 Column

The **MAC Address 2** column displays the MAC Address of the standby master controller, if available, in the ADAM/ADAM-M frame.

OK Button

The **OK** button is used to accept the selections made and close the window.

Cancel Button

The **Cancel** button is used to reject the selections made and close the window.

TBX-2 Links Status Window

The **TBX-2 Links Status** window, shown in Figure 17, is used to check the status of the TBX-2 card status. From this window, you can also download firmware. For more information, see “Firmware Upgrades” on page 63.




FIGURE 17. TBX-2 Links Status Window

TBX-2 Column

The **TBX-2** column displays TBX-2 cards listed by frame and slot number.

EXAMPLE: **2:009** indicates the TBX-2 card is in Frame 2 and occupying slot 9.

Comm Column

The **Comm** column displays the communications status of the TBX-2 card.

(A) Link Up/Dn Column

The **(A) Link Up/Dn** column displays the status of the links on the TBX-2 port A.

Any of the following indicators may appear:

“—”	The link is down.
OK	The link is up for # hops.

(A) Partner Column

The **(A) Partner** column displays frame number of the TBX-2 card to which the connection is made. For example, if Frame 1's A connector is connected to Frame 2, a 2 appears under the **(A) Partner** column.

NOTE: If there are multiple TBX-2 cards in a frame, use the slot number to determine the card connection being used.

(B) Link Up/Dn Column

The **(B) Link Up/Dn** column displays the status of the links on the TBX-2 port B.

Any of the following indicators may appear:

“—”	The link is disabled.
OK	The link is active for # hops.

(B) Partner Column

The **(B) Partner** column displays frame number of the TBX-2 card to which the connection is made. For example, if Frame 1's B connector is connected to Frame 2, a 2 appears under the **(B) Partner** column.

NOTE: If there are multiple TBX-2 cards in a frame, use the slot number to determine the card connection being used.

(C) Link Up/Dn Column

The **(C) Link Up/Dn** column displays the status of the links on the TBX-2 port C.

Any of the following indicators may appear:

“—”	The link is disabled. If this is seen, the intercom ports were not configured correctly. See “Configuration” on page 28 to read how to configure the ports.
OK	The link is active for # hops.

(C) Partner Column

The **(C) Partner** column displays frame number of the TBX-2 card to which the connection is made. For example, if Frame 1's C connector is connected to Frame 2, a 2 appears under the **(C) Partner** column.

NOTE: If there are multiple TBX-2 cards in a frame, use the slot number to determine the card connection being used.

Audio A Column

The **Audio A** column displays the ports assigned to the Audio A link.

Audio B Column

The **Audio B** column displays the ports assigned to the Audio B link.

Audio C Column

The **Audio C** column displays the ports assigned to the Audio C link.

Intercom Alarms

The **Intercom Alarms** window, shown in Figure 18, displays alarms that occur in the intercom and an indication of whether they have been resolved or not. If an alarm has not been resolved, it is highlighted in yellow on the status bar (see Figure 18). Once an alarm has been resolved, it is automatically deleted out of the list after five (5) minutes.



*Unresolved
Alarm
Indication*


FIGURE 18. Intercom Alarm Indication

To open the **Intercom Alarms** window, do the following:


1. Double-click the **yellow highlighted alarm** in the status bar.

OR

From the Status menu, select **Alarms**.



The *Intercom Alarms* window appears.



Frame Column

The **Frame** column displays the frame affected by the warning or alarm.

Alarm Time Column

The **Alarm Time** column displays the date and time (in 24-hour clock time) the alarm or warning occurred.

Resolved Time Column

The **Resolved Time** column displays the date and time (in 24-hour clock time) the alarm or warning was resolved.

Description Column

The **Description** column displays a description of the alarm or warning.

Hiding and Clearing Alarms

Some alarms can be cleared, as shown in the example below. Other alarms, such as loss of the backplane clock, can be hidden but cannot be cleared. The only way to clear these alarms from the window is to resolve them.

EXAMPLE:Lost communications with the Trunk Master. In this case, the alarm is not regenerated unless the alarm condition is resolved, and then recurs. This means the Master Controller starts communicating with the Trunk Master again, and then loses communications again.

NOTE: You can also hide certain alarm type by selecting Hide this alarm type, if desired.

To **hide or clear alarms/alarm types out of the Intercom Alarms window**, do the following:

1. Right-click the **alarm** you want to clear.
A popup menu appears. From the popup menu, select **Hide this alarm**, **Clear this alarm** or **Hide this alarm type**.



Logging Window

The AZedit **Logging** window, shown in Figure 19, displays the log messages about the events that have occurred in the cluster. The log messages are kept locally on each frame. These normally are identical, with the exception of when the frames are re-synchronizing, across the intercom cluster.




FIGURE 19. Log Viewer Window

Configure Logging Window

The **Configure Logging** window, shown in Figure 20, is used to configure the connection type of the AZedit session where log messages are sent when the Log to File option is selected. The Configure Logging window is only accessible when connected to AZedit using the J1 serial connection or using the start AZedit session.




FIGURE 20. Configure Logging Window

J1 Radio Button

The **J1** radio button indicates log messages are sent to another AZedit session connected serially over the J1 port.

NOTE: The only AZedit session allowed to configure the log destinations is the session currently configured as the start destination for log messages or the main serial connection connected to J1 of the ADAM/ADAM-M MC breakout panel. Restrictions can be set up for the AZedit destination session to restrict access to the Configure Logging window.

J9 Radio Button

The **J9** radio button indicates log messages are sent to another AZedit session connected serially over the J9 port.

J10 Radio Button

The **J10** radio button indicates log messages are sent to another AZedit session connected serially over the J10 port.

Ethernet Radio Button

The **Ethernet** radio button indicates log messages are sent to another AZedit session connected over Ethernet.

IP Address Field

The **IP Address** field is used to enter the IP Address of the computer running the AZedit session you want to send log messages to over Ethernet.

All Frames Radio Button

The **All Frames** radio button is used to apply all changes made to the Log Configuration to all frames connected to this frame.

This Frame Only Radio Button


The **This Frame Only** radio button is used to allow the log destination for each frame to be different.

NOTE: The overall log status (enabled or disabled) applies to all frames.

Download Firmware to the TBX-2 Card

To download firmware to the TBX-2 card, do the following:

1. From the Status menu in AZedit, select **Software Versions**.
A flyout menu appears.
2. From the flyout menu, select **IO Cards**.
The I/O Card Version Information Window appears.




3. Right-click on the **TBX-2 card** you want to download the firmware update to.
A popup menu appears.
4. From the popup menu, select **Download firmware....**
The Firmware Download window appears.
5. Using the Look in: drop down menu, navigate to the **folder where the firmware is located.**

6. Click **Open**.


The *Download Device Firmware* window appears.

7. Click **Begin Download**.

The download begins. This takes a minute or two to occur.

8. When the download is finished, click **OK**.

The *TBX-2 card firmware download is complete and a Success message appears.*

9. Click **OK**.

The success message and *Download Device Firmware* window closes.

10. From the Status menu, select **I/O Cards**.
The IO Card Status window appears.
11. Verify the **TBX-2 card firmware has been updated**.

CAUTION: Do not power down the frame or remove the TBX-2 card from the frame until you have verified the new version information from AZedit. If the card loses power during download, undesirable results may occur.

Download the Bootloader File to the TBX-2 Card (v1.2.2 or later)

To **download the bootloader file to the TBX-2 Card**, do the following:

1. On the TBX-2 front card, press and hold the **Reset button**, and then press and hold both the **1** and **2 front-panel buttons**.
2. While still holding the 1 and 2 front-panel buttons, release the **Reset button**.
3. Wait for 1second, and then **release the 1 and 2 front-panel buttons**.
CPU remains in boot loader mode. Boot loader allows either the boot loader or the client code to be downloaded.

- From the AZedit menu bar, select **Status|Software Version| I/O Card**.

The I/O Card Version window appears.

Slot ▲	Version
1 : 001	n/a
1 : 002	ADAM AIO-16 Card, Version 1.1.4, Dec 10 2008, CRC=f044
1 : 003	n/a
1 : 004	n/a
1 : 005	n/a
1 : 006	n/a
1 : 007	n/a
1 : 008	ADAM TBX-2 Card, Version 1.2.1, Nov 05 2015, CRC=D948
1 : 009	ADAM TBX-2 Card, Version 1.2.0, Oct 16 2015, CRC=DBB5
1 : 010	n/a
1 : 011	n/a
1 : 012	n/a
1 : 013	n/a
1 : 014	ADAM MADI-2 Card, Version 2.2.1, Oct 08 2015, CRC=a500
1 : 015	n/a
1 : 016	n/a
1 : 017	n/a
2 : 001	n/a
2 : 002	ADAM AIO-16 Card, Version 1.3.0, Aug 17 2010, CRC=8e7c
2 : 003	ADAM MADI Card, Version 2.2.0, Jul 06 2015, CRC=0a16, S
2 : 004	ADAM MADI-2 Card, Version 2.2.2, Nov 05 2015, CRC=05a4
2 : 005	ADAM TBX Card, Version 1.2.1, Nov 05 2015, CRC=D948
2 : 006	ADAM TBX-2 Boot Downloader, Version 1.2.1, Nov 05 2015
2 : 007	n/a

Download firmware...


- Right-click the **TBX-2** card you want to update.

A Download Firmware... fly-out menu appears.


- Click **Download Firmware...**

A Windows Explorer folder appears.

7. Click **Open**.
The *Download Device Firmware* window appears.



8. Click **Begin Download**.
The file begins to download to the TBX-2 card. A progression bar displays the progress of the download. Once the bootloader file is completely downloaded, the card automatically reboots. This can take up to 1.5 minutes.



IMPORTANT: Multiple cards can be update at once. Take care to set all TBX-2 cards in bootloader mode before downloading the file (steps 1–3)

Download the Bootloader File to the TBX-2 Card (v1.1.0 or later)

To **download the bootloader file to the TBX-2 Card**, do the following:

1. Remove the TBX-2 card from the frame.
2. On JA 1, short pins 2 and 3 together.
3. Replace the TBX-2 card in the frame.
4. Hold in **both of the front-panel buttons and push the Reset button**.
This causes the TBX-2 card to restart in boot download mode.

- From the AZedit menu bar, select **Status|Software Version| I/O Card**.

The I/O Card Version window appears.

Slot ▲	Version
1 : 001	n/a
1 : 002	ADAM AIO-16 Card, Version 1.1.4, Dec 10 2008, CRC=f044
1 : 003	n/a
1 : 004	n/a
1 : 005	n/a
1 : 006	n/a
1 : 007	n/a
1 : 008	ADAM TBX-2 Card, Version 1.2.1, Nov 05 2015, CRC=D948
1 : 009	ADAM TBX-2 Card, Version 1.2.0, Oct 16 2015, CRC=DBB5
1 : 010	n/a
1 : 011	n/a
1 : 012	n/a
1 : 013	n/a
1 : 014	ADAM MADI-2 Card, Version 2.2.1, Oct 08 2015, CRC=a500
1 : 015	n/a
1 : 016	n/a
1 : 017	n/a
2 : 001	n/a
2 : 002	ADAM AIO-16 Card, Version 1.3.0, Aug 17 2010, CRC=8e7c
2 : 003	ADAM MADI Card, Version 2.2.0, Jul 06 2015, CRC=0a16, S
2 : 004	ADAM MADI-2 Card, Version 2.2.2, Nov 05 2015, CRC=05a4
2 : 005	ADAM TBX Card, Version 1.2.1, Nov 05 2015, CRC=D948
2 : 006	ADAM TBX-2 Boot Downloader, Version 1.2.1, Nov 05 2015
2 : 007	n/a

Download firmware...


- Right-click the **TBX-2** card you want to update.

A Download Firmware... fly-out menu appears.


- Click **Download Firmware...**

A Windows Explorer folder appears.

- Click **Open**.
The Download Device Firmware window appears.



- Click **Begin Download**.
The file begins to download to the TBX-2 card. A progression bar displays the progress of the download. Once the bootloader file is completely downloaded, the card automatically reboots. This can take up to 1.5 minutes.



- Once the download is complete, remove the TBX-2 card from the frame.
- On JA 1, remove the short pins 2 and 3 together.
- Replace the TBX-2 card in the frame.

IMPORTANT: Multiple cards can be update at once. Take care to set all TBX-2 cards in bootloader mode before downloading the file (steps 1–3).

Ring Architecture

Requirements

- MCII-e version 2.8.0 or higher.
- AZedit version 4.4.0 or higher.
- TBX-2 version 1.1.0 or higher.

IMPORTANT: Each frame in the system must have two (2) TBX-2 cards installed.
In ADAM, TBX-2 cards are in slots 8 and 9.
In ADAM-M, TBX-2 cards are in slots 5 and 6.

Ring Architecture Overview

In a ring-wiring architecture, each frame has TBX-2 links to two (2) other frames. Multiple links are used to pass multiple frames' timeslots from one frame to the next. It is not uncommon for timeslots to be forwarded across multiple links. The links in the Ring Architecture are bi-directional, meaning audio is passed two (2) different ways; thus, the system can be viewed as having two (2) separate, unidirectional rings. In one ring, timeslots are sent clockwise from frame to frame, and in the other ring, the timeslots are sent counterclockwise.

EXAMPLE: In a five (5) frame system, timeslots generated in frame one (1) are forwarded clockwise through frames two (2) to five (5). Frame five (5) does not forward the timeslots to frame one (1) because this is where the timeslots originated. Alternately, the timeslots generated in frame one (1) are also forwarded counterclockwise through frames five (5) to two (2).

To **configure your intercom matrix for ring architecture**, do the following:

- Using figure 21 through figure 27, cable your system for the number of frames you are using.


NOTE:

- The maximum number of frames allowed in a ring architecture is nine (9), with the possibility of 880 ports available.
- The largest number of forwarded ports across three fiber links is 768. A frame can contain up to 768 local ports, which are subject to the following limitations:
 - The intercom is limited to 880ports
 - MIN denotes the number of ports in the smallest frame (the frame with the fewest number of ports). The maximum system size is 768+MIN ports.

- Open **AZedit**.
- From the Options menu, select **Intercom Configuration**.
A warning appears.




- Click **OK**.
The Intercom Configuration window appears.
- Click **Intercom Sizing Wizard**.
The Intercom Sizing Wizard appears.
- Select **ADAM (multi-frame)**.




- Click **Next**.
- Select the **number of frames in your system** (2 – 9).

NOTE: When you have 2–8 frames, ring configuration is an option. However, when you have nine (9) frames, ring configuration is mandatory.



9. Click **Next**.
10. Select the **Ring** check box.



11. Click **Next**.

12. Using the Allocation table, configure the **port allocations** for your system.

Allocate Ports To Frames [?] [X]

Select the frame types and configure the number of ports in each frame.

Frame	Type	Size	Ports
1	ADAM	16	001 - 016
2	ADAM	16	017 - 032
3	ADAM	16	033 - 048
4	ADAM	16	049 - 064
5	ADAM	16	065 - 080
6	ADAM-M	16	081 - 096
7	ADAM-M	16	097 - 112

< Back **Next >** Cancel Help

13. Click **Next**.
The Intercom Configuration Wizard closes.
14. Click **Test**.
The Intercom Resizing Test Results window appears.

Intercom Resizing Test Results

Operating Memory (RAM)		Configuration Memory (FLASH)	
Amount Required:	19297622	Amount Required:	925088
Amount Available:	28267740	Amount Available:	8125472
Percent Usage:	68%	Percent Usage:	11%

Remote Alpha Storage			
Current # of Alphas:	0	(approximate)	
Current Pool Size:	279000	New Pool Size:	279000
Percent Usage:	0%	Percent Usage:	0%

SUCCESS: The intercom may be resized.

OK

15. Click **OK**.
16. Click **Apply**.

Ring Configurations

NOTE:

- When you interconnect two cards, you can cross-connect the ports in whatever way you desire. You do not have to connect link A to link A; however, it is recommended to connect A-A, B-B, etc. as this is the easiest method to document.
- Slots eight and nine in an ADAM frame are interchangeable. For example, you can connect frame 1 (slot eight or nine) to frame 2 (slot eight or nine).




FIGURE 21. ADAM-M Three (3) Frame Ring Configuration




FIGURE 22. ADAM-M Four (4) Frame Ring Configuration




FIGURE 23. ADAM-M Five (5) Frame Ring Configuration




FIGURE 24. ADAM-M Six (6) Frame Ring Configuration




FIGURE 25. ADAM-M Seven (7) Frame Ring Configuration




FIGURE 26. ADAM-M Eight (8) Frame Ring Configuration




FIGURE 27. ADAM-M Nine (9) Frame Ring Configuration

Bosch Security Systems, Inc.

12000 Portland Avenue South
Burnsville, MN 55337 U.S.A.
www.boschcommunications.com