**Ross Video Limited** 



Vision Engineering Manual

Software Issue: v12.0 MD



**Live Production Technology** 

#### Vision • Engineering Manual

- Ross Part Number: 4800DR-401-12.0
- Release Date: October 18, 2010. Printed in Canada.
- Software Issue: v12.0 MD

The information contained in this manual is subject to change without notice or obligation.

#### Copyright

#### © 2010 Ross Video Limited. All rights reserved.

Contents of this publication may not be reproduced in any form without the written permission of Ross Video Limited. Reproduction or reverse engineering of copyrighted software is prohibited.

#### Patents

This product is protected by the following US Patents: 4,205,346; 5,115,314; 5,280,346; 5,561,404; 7,034,886; 7,508,455. This product is protected by the following Canadian Patents: 2039277; 1237518; 1127289. Other patents pending.

#### **Notice**

The material in this manual is furnished for informational use only. It is subject to change without notice and should not be construed as commitment by Ross Video Limited. Ross Video Limited assumes no responsibility or liability for errors or inaccuracies that may appear in this manual.

#### **Trademarks**



is a trademark of Ross Video Limited.

- Ross, ROSS, ROSS ®, MLE, Vision, Octane, Squeeze & Tease, and Squeeze & Tease WARP, OverDrive, openGear, and SoftMetal are registered and unregistered trademarks of Ross Video Limited.
- All other product names and any registered and unregistered trademarks mentioned in this guide are used for identification purposes only and remain the exclusive property of their respective owners.
- Windows is a registered trademark of Microsoft Corporation in the United States and other countries.
- Mac OS X is a trademark of Apple Inc., registered in the U.S. and other countries.
- Fedora and the Infinity design logo are trademarks of Red Hat, Inc.

### Important Regulatory and Safety Notices to Service Personnel

Before using this product and any associated equipment, refer to the "**Important Safety Instructions**" listed below to avoid personnel injury and to prevent product damage.

Product may require specific equipment, and/or installation procedures to be carried out to satisfy certain regulatory compliance requirements. Notices have been included in this publication to call attention to these specific requirements.

#### **Symbol Meanings**

**Protective Earth** — This symbol identifies a Protective Earth (PE) terminal, which is provided for connection of the supply system's protective earth (green or green/yellow) conductor.

This symbol on the equipment refers you to important operating and maintenance (servicing) instructions within the Product Manual Documentation. Failure to heed this information may present a major risk of damage or injury to persons or equipment.

 $\triangle$ 

**Warning** — The symbol with the word "**Warning**" within the equipment manual indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

**Caution** — The symbol with the word "**Caution**" within the equipment manual indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



**Warning Hazardous Voltages** — This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product enclosure that may be of sufficient magnitude to constitute a risk of shock to persons.



**ESD Susceptibility** — This symbol is used to alert the user that an electrical or electronic device or assembly is susceptible to damage from an ESD event.

### **Important Safety Instructions**



- **1.** Read these instructions.
- **2.** Keep these instructions.
- 3. Heed all warnings.
- 4. Follow all instructions.
- **5.** Do not use this apparatus near water.
- **6.** Clean only with a dry cloth.
- **7.** Do not block any ventilation openings. Install in accordance with manufacturer's instructions.

- **8.** Do not install near heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- **9.** Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- **10.** Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- **11.** Only use attachments/accessories specified by the manufacturer.
- **12.** Unplug this apparatus during lightning storms or when unused for long periods of time.
- **13.** Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as when the power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- **14.** Do not expose this apparatus to dripping or splashing, and ensure that no objects filled with liquids, such as vases, are placed on the apparatus.
- **15.** To completely disconnect this apparatus from the AC Mains, disconnect the power supply cord plug from the AC receptacle.
- **16.** The mains plug of the power supply cord shall remain readily operable.
- **17.** The Octane/QMD-X, MD-X, QMD, and MD (Live Production Engine) chassis is to be rack mounted only.
- **18. Indoor Use: WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.
- **19.** The safe operation of this product requires that a protective earth connection be provided. A grounding conductor in the equipment's supply cord provides this protective earth. To reduce the risk of electrical shock to the operator and service personnel, this ground conductor must be connected to an earthed ground.
- **20.** WARNING: This apparatus, when equipped with multiple power supplies, can generate high leakage currents. To reduce the risk of electric shock, ensure that each individual supply cord is connected to its own separate branch circuit with an earth connection.
- **21. CAUTION**: These service instructions are for use by qualified service personnel only. To reduce the risk of electric shock, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so (Engineering Manual only).
- **22.** These apparatus contain Lithium batteries, which if replaced incorrectly, or with an incorrect type, may cause an explosion. Replace only with the same type. Dispose of used batteries according to the manufacturer's instruction.
- **23.** Service barriers within this product are intended to protect the operator and service personnel from hazardous voltages. For continued safety, replace all barriers after servicing.
- **24.** Certain parts of this equipment still present a safety hazard with the power switch in the OFF position. To avoid electrical shock, disconnect all A/C power cords from the chassis' rear appliance connectors before servicing.
- **25.** This product contains safety critical parts, which, if incorrectly replaced, may present a risk of fire or electrical shock. Components contained within the product's power supplies and power supply area are not intended to be customer-serviced and should be returned to the factory for repair.





- **26.** To reduce the risk of fire, replacement fuses must be the same type and rating.
- **27.** Use only power cords specified for this product and certified for the country of use.
- **28.** The safe operation of this equipment requires that the user heed and adhere to all installation and servicing instruction contained within the equipment's Engineering Manuals.
- **29.** For applicable V-100/V-100A Touchscreen Panel power supplies, see user instructions contained within the Product's Engineering Manual.
- **30.** WARNING: Batteries shall not be exposed to excessive heat such as sunshine, fire or the like.
- **31.** WARNING: This product includes an "Ethernet Port" which allows this product to be connected to a local area network (LAN). Only connect to networks that remain inside the building. Do not connect to networks that go outside the building.

#### **EMC Notices**

#### United States of America FCC Part 15

This equipment has been tested and found to comply with the limits for a class A Digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.



**Notice** — Changes or modifications to this equipment not expressly approved by Ross Video Limited could void the user's authority to operate this equipment.

#### CANADA

This Class "A" digital apparatus complies with Canadian ICES-003.

Cet appariel numerique de la classe "A" est conforme a la norme NMB-003 du Canada.

#### **EUROPE**

This equipment is in compliance with the essential requirements and other relevant provisions of **CE Directive 93/68/EEC**.

#### INTERNATIONAL

This equipment has been tested to **CISPR 22:1997** along with amendments **A1:2000** and **A2:2002**, and found to comply with the limits for a Class A Digital device.



**Notice** — This is a Class A product. In domestic environments, this product may cause radio interference, in which case the user may have to take adequate measures.

#### **General Handling Guidelines**

• Careful handling, using proper ESD precautions, must be observed.

• Power down the system before PCB removal.

#### A Word About Static Discharge

Throughout the many procedures in this Engineering Manual, please observe all static discharge precautions.



**Caution** — Avoid handling the switcher circuit boards in high static environments such as carpeted areas, and when synthetic fiber clothing is worn. Touch the frame to dissipate static charge before removing boards from the frame, and exercise proper grounding precautions when working on circuit boards.

### Warranty and Repair Policy

Ross Video Limited (Ross) warrants its switchers and related options, to be free from defects under normal use and service for a period of ONE YEAR from the date of shipment. Fader handle assemblies are warranted for the life of the product. If an item becomes defective within the warranty period Ross will repair or replace the defective item, as determined solely by Ross.

Warranty repairs will be conducted at Ross, with all shipping FOB Ross dock. If repairs are conducted at the customer site, reasonable out-of-pocket charges will apply. At the discretion of Ross, and on a temporary loan basis, plug in circuit boards or other replacement parts may be supplied free of charge while defective items undergo repair. Return packing, shipping, and special handling costs are the responsibility of the customer.

Software upgrades for switchers may occur from time to time, and are determined by Ross Video. The upgrades are posted on the Ross Video website, and are free of charge for the life of the switcher.

This warranty is void if products are subjected to misuse, neglect, accident, improper installation or application, or unauthorized modification.

In no event shall Ross Video Limited be liable for direct, indirect, special, incidental, or consequential damages (including loss of profit). Implied warranties, including that of merchantability and fitness for a particular purpose, are expressly limited to the duration of this warranty.

This warranty is TRANSFERABLE to subsequent owners, subject to Ross' notification of change of ownership.

### **Environmental Information**

# The equipment that you purchased required the extraction and use of natural resources for its production. It may contain hazardous substances that could impact health and the environment.

To avoid the potential release of those substances into the environment and to diminish the need for the extraction of natural resources, Ross Video encourages you to use the appropriate take-back systems. These systems will reuse or recycle most of the materials from your end-of-life equipment in an environmentally friendly and health conscious manner.

The crossed-out wheeled bin symbol invites you to use these systems.



If you need more information on the collection, reuse, and recycling systems, please contact your local or regional waste administration.

You can also contact Ross Video for more information on the environmental performances of our products.

### **Company Address**



Ross Video Limited 8 John Street Iroquois, Ontario, K0E 1K0 Canada Ross Video Incorporated P.O. Box 880 Ogdensburg, New York USA 13669-0880

General Business Office:	(+1) 613 • 652 • 4886
Fax:	(+1) 613 • 652 • 4425
Technical Support:	$(+1) 613 \cdot 652 \cdot 4886$
E mail (Technical Support):	(+1) 015 • 549 • 0000
E-mail (General Information):	solutions@rossvideo.com
Website:	http://www.rossvideo.com

# Contents

#### Introduction

Eng 1-2
Eng 1-3
Eng 1-4
Eng 1-5
Eng 1-6
Eng 1-7

#### **Switcher Basics**

Equipment Overview	Eng 2-2
Vision Control Panel	Eng 2-2
Vision Touchscreen Dis	blayEng 2-7
Frame	
Control Panel Modules	Eng 2-10
Control Panel CPU Mod	uleEng 2-10
Panel Module Controller	BoardEng 2-10
Keyers Module	Eng 2-10
Global Memory Module	Eng 2-10
MLE Memory Module	Eng 2-10
Transition Module	Eng 2-11
Positioner Module	Eng 2-11
Preview Bus Module	Eng 2-11
Power Distribution Boar	dEng 2-11
Frame Boards	Eng 2-12
Frame CPU Board	Eng 2-12
Video Input Board, 16 Ir	iputEng 2-12
Video Input Board, with	CrosspointEng 2-12
Video Input Board, 10 Ir	iputEng 2-12
Video Output Board	Eng 2-12
Video Processor Board	Eng 2-13
Midplane	Eng 2-13
Crosspoint Board	Eng 2-13
Squeeze & Tease Carrier	BoardEng 2-13
Power Supplies	Eng 2-13
Communication Ports	Eng 2-15
Control Panel Communi	cation PortsEng 2-15
Frame Communication F	PortsEng 2-16
Tally Ports	Eng 2-18
GPI I/O Port	Eng 2-19

1

Video Routing	Eng 2-20
Crosspoint Matrix	Eng 2-20
Video Processor	Eng 2-24
Squeeze & Tease	Eng 2-27
XFX Extra Effects	Eng 2-29
Video Formats	Eng 2-31
Horizontal Scan Lines	Eng 2-31
Interlaced vs. Progressive	Eng 2-31
Progressive Segmented Frame	Eng 2-33
Frequency	Eng 2-33
CPU Structure	Eng 2-35
A Note About CPU Architecture	Eng 2-36
Board Labelling	Eng 2-37

### Physical Installation and Cabling

Unpacking Your Switcher	Eng 3-2
enpressing root by itelier	
Static Discharge	Eng 3-2
Serial Numbers	Eng 3-2
Opening and Closing the Frame Door	Eng 3-3
Octane/QMD/X Frame	Eng 3-3
MD/X Frame	Eng 3-3
Frame Installation	Eng 3-5
Installing the Frame	Eng 3-5
Control Panel Installation	Eng 3-7
Control Panel Installation	Eng 3-7
Touchscreen Display Installation	Eng 3-9
Frame to Control Panel Cabling	Eng 3-11
Frame to Control Panel Cable Installation	Eng 3-11
Keyboard and Mouse Installation	Eng 3-12
Video Input Cabling	Eng 3-13
Default Input Mapping	Eng 3-13
Video Output Cabling	Eng 3-15
Default Output Mapping	Eng 3-15
Monitor Connections	Eng 3-16
Button Inserts	Eng 3-17
Button Insert Films	Eng 3-17
Installing Control Panel Button Inserts	Eng 3-17
Power Supply Connections	Eng 3-19
Frame Power Connection	Eng 3-19
Control Panel Power Connection	Eng 3-20
Power Fail Indicators	Eng 3-21
Power Failure	Eng 3-21

### Initial Setup and Verification

Powering Up and Powering Down the Switcher	Eng 4-2
Powering Up the Switcher	Eng 4-2
Powering Down the Switcher	Eng 4-3
Network Setup	Eng 4-5
Frame Network Setup	Eng 4-5
Control Panel Network Setup	Eng 4-7
Network Security	Eng 4-9
MultiPanel Setup	Eng 4-10
MLE Assignment	Eng 4-10
Reference Connection and Setup	Eng 4-12
Reference Signal Connection	Eng 4-12

### 3

4

#### ii • Contents

	Non-Sync Detection	
Vision Engineering Manual (v12.	0 MD)	

Compatible Video Formats	Eng 4-12
Reference Setup	Eng 4-13
Internal Reference	Eng 4-15
Input Verification	Eng 4-16
Functional Check	Eng 4-17
Removing and Installing Frame Boards	Eng 4-18
Frame Board Locations	Eng 4-18
Removing and Installing Front Frame Boards	Eng 4-21
Removing and Installing Rear Frame Boards	Eng 4-22
Resetting the Switcher	Eng 4-25
Full Restart	Eng 4-25
Control Panel Restart	Eng 4-26
Software Reset	Eng 4-26
Default State	Eng 4-28
	-

#### Using the Menu System

Touchscreen Interface	Eng 5-2
Menu System Basics	Eng 5-4
Using the Punchpad	Eng 5-6
Using the Positioner with the Menu System	Eng 5-8
Quick Navigation Buttons	Eng 5-9
Menu Skins	Eng 5-11
Control Panel Mnemonics	Eng 5-12
Default Mnemonic Appearance	Eng 5-12
Control Panel Displays	Eng 5-15
Using the Naming Menus	Eng 5-16
Help Features	Eng 5-17
Online Manuals	Eng 5-17
Pop-up Help	Eng 5-17
Screen Captures	Eng 5-18

### Software Upgrades and Options

Vision Web Interface Account	Eng 6-2
Software Upgrade	Eng 6-3
Preparing the Switcher Before an Upgrade	Eng 6-3
Performing the Upgrade	Eng 6-4
Rebooting the Switcher After an Upgrade	Eng 6-11
System Information Overview	Eng 6-12
System Information Region	Eng 6-12
Storage Capacity Region	Eng 6-13
Installed Options	Eng 6-14
Accessing the Installed Options Menus	Eng 6-14
Installing Serial Numbers	Eng 6-16
Installing Software Options	Eng 6-16
Storing and Recalling Option Codes	Eng 6-19

### Video Input Configuration and Check

Naming Video Inputs	Eng 7-2
Configuring Video Inputs	Eng 7-4
BNC Menu Overview	Eng 7-4
Assigning Input Types	Eng 7-4
Assigning Alphas	Eng 7-6
Configuring Auto Keys	Eng 7-8
Non-Sync Detection	Eng 7-9

### 6

7

Contents • iii

Creating Bus Maps	Eng 7-13
Editing Bus Maps	Eng 7-13
Shifted Crosspoint Buttons	Eng 7-16
Copying Bus Maps	Eng 7-16
Defaulting Bus Maps	Eng 7-17
Assigning Panel Bus Maps	Eng 7-19
Assigning Panel Bus Maps to Individual Buses	Eng 7-19
Assigning Panel Bus Maps to Multiple Buses	Eng 7-20
Naming Bus Maps	Eng 7-22
Assigning Tallies to Video Inputs	Eng 7-23
Assigning GPI Outputs to Video Inputs	Eng 7-25
Checking Keys	Eng 7-26
Video Output Configuration and Check	8
Configuring Video Outputs	Eng 8-2
Checking Video Outputs	Eng 8-5

Assigning Audio Channels to Video Inputs......Eng 7-11

Assigning Audio Channels and Groups to Input BNCs ......Eng 7-11

Configuring Video Outputs	Eng 8-2
Checking Video Outputs	Eng 8-5
Additional Video Output Configuration	Eng 8-7
Clean Feed Setup	Eng 8-7
Fade to Black Setup	Eng 8-8
MLE Tally Setup	Eng 8-9
Ancillary Data Setup	Eng 8-10
Switch on Field Setup	Eng 8-12
Multi-Viewer	Eng 8-13
Multi-Viewer Assignment	Eng 8-13
Multi-Viewer Layouts	Eng 8-14
Mix/DSK	Eng 8-17
Mix/DSK Setup	Eng 8-17
Mix/DSK Operation	Eng 8-18
MultiDSK	Eng 8-19
MultiDSK Setup	Eng 8-19
Mix/DSK and MultiDSK	Eng 8-21
AuxKeys	Eng 8-22
AuxKeys Setup	Eng 8-22
AuxKey Pre Mixer/Keyer	Eng 8-24

#### **Basic Communications Setup**

Communications Overview	Eng 9-2
Device Drivers	Eng 9-2
Control Panel Serial Communications Ports	Eng 9-2
Frame Serial Communications Ports	Eng 9-2
Ethernet Communications	Eng 9-3
Installing and Managing FlexDevice Drivers	Eng 9-4
Setting Up Communications	Eng 9-7
Setting Up Serial Communications	Eng 9-7
Setting Up Ethernet Communications	Eng 9-10
Port Expanders	Eng 9-13
Port Expander Cable Pinouts	Eng 9-13
Switcher Communications Setup	Eng 9-15
Port Expander Programming	Eng 9-17
Communication Settings	Eng 9-18
Assigning Devices to Port Expander Ports	Eng 9-18
External Panel Modules	Eng 9-21

Custom Devices	Eng 9-22
Programming Custom Device Commands	Eng 9-22
Extra Options	Eng 9-26
1	U

#### **Custom Controls**

Custom Controls	Eng 10-2
Custom Control Interfaces	Eng 10-3
Custom Control Bus	Eng 10-3
Custom Control Soft Shot Box	Eng 10-3
Custom Control Shot Box Module	Eng 10-4
Custom Control Banks	Eng 10-5
Custom Control Bank Setup	Eng 10-5
Naming Custom Control Banks	Eng 10-6
Programming Control Panel Functions	Eng 10-8
Tips for Creating Custom Controls	Eng 10-9
Relative Custom Controls	Eng 10-11
Running Multiple Custom Controls	Eng 10-13
Programming Special Functions	Eng 10-15
Attaching Custom Controls to Panel Buttons	Eng 10-21
Attaching a Custom Control to a Panel Button	Eng 10-21
Deleting Custom Control Attachment to Panel Buttons	Eng 10-22
Naming Custom Controls	Eng 10-24
Editing Custom Controls	Eng 10-25
Managing Custom Controls	Eng 10-28
Deleting Custom Controls	Eng 10-29
Custom Control Shortcuts	Eng 10-30
	0

#### **Switcher Personality**

Personality List	Eng 11-2
Control Panel Button Color Schemes	Eng 11-14
General Color Usage Setup	Eng 11-14
Assigning a Crosspoint Color	Eng 11-16
Selecting a Color	Eng 11-16
Mnemonic Color Schemes	Eng 11-18
Control Panel Display Brightness	Eng 11-20
Loading Color Schemes	Eng 11-21
Lock/Unlock Personality	Eng 11-22

### **Completing Setup**

Aux Bus Setup	Eng 12-2
Setting up Aux Buses	Eng 12-2
Naming Aux Buses	Eng 12-2
Default MLE Map Assignment	Eng 12-4
Squeeze & Tease Mode	Eng 12-5
Key 4 Mode	Eng 12-7
Standard GPI Setup	Eng 12-9
GPI I/O Information	Eng 12-9
GPI I/O Connection	Eng 12-10
Setting Up GPI Inputs	Eng 12-10
GPI Input Tallies	Eng 12-13
Setting Up GPI Outputs	Eng 12-14
Naming GPI Outputs	Eng 12-16
Clip Setup	Eng 12-17
Programming Clips	Eng 12-17
Grabbing a Timecode	Eng 12-20
5	e

#### 12

#### 11

Visio	0

#### Setting Up Audio Sources ......Eng 12-22 Setting Up Audio Groups ......Eng 12-24 Factory Default Settings......Eng 12-27 Recalling Factory Default Settings......Eng 12-27 Preview Overlay Setup......Eng 12-30 Preview Overlay Component Setup......Eng 12-31 Set System Time ......Eng 12-38 Setting System Time Manually ......Eng 12-38 Setting System Time Automatically ......Eng 12-39 Auto Follow ......Eng 12-40 Turning On Auto Follow ......Eng 12-40 Lock/Unlock Installation......Eng 12-46

Audio Channel Setup ......Eng 12-22

#### File and Setup Storage

File Storage Overview	Eng 13-2
Storing and Recalling Files and Setups	Eng 13-4
Storing Registers	Eng 13-4
Recalling Registers	Eng 13-9
Managing Setups with an External Computer	Eng 13-15
Downloading Setups to an External Computer	Eng 13-15
Uploading Setups from an External Computer	Eng 13-16

#### **Auxiliary Panels**

vi • Contents

Auxiliary Panel Overview	Eng 14-2
Auxiliary Control Panel	Eng 14-2
Remote Aux Panels	Eng 14-3
Installing Auxiliary Panels	Eng 14-5
Communications Connections	Eng 14-6
Remote Aux Cable Pinouts	Eng 14-7
Communications Setup	Eng 14-8
Auxiliary Control Panel	Eng 14-8
Remote Aux Panel	Eng 14-8
Auxiliary Panel GPIs	Eng 14-11
Auxiliary Control Panel GPIs	Eng 14-11
Remote Aux Panel GPIs	Eng 14-12
Setting Up CCU Joystick Control	Eng 14-13
	6

#### **Custom Control Shot Box Module**

Creating Shot Box PagesEng 15-
Naming Shot Box PagesEng 15-
Copying or Moving Shot Box Pages

#### SmartConversion and Up/Down Converters

16

15

Setting Up a Conversion Loop	Eng 16-2
Switcher Setup	Eng 16-5
Assigning Buses to Use SmartConversion	Eng 16-5
Locking Conversion Loops to Buses	Eng 16-6
Fade to Black Display Mode for Up/Down Converters	Eng 16-7

#### 14

#### Switcher Calibration and Diagnostics

Switcher Software Version	Eng 17-2
Switcher Calibration	Eng 17-3
Mapping a Module to a Row	Eng 17-5
Mapping Multiple Modules	Eng 17-5
Mapping a Single Module	Eng 17-6
Naming an External Row	Eng 17-8
Fail Indicators Diagnosis	Eng 17-10
Complete Status	Eng 17-10
Warnings	Eng 17-11
Status Components and Conditions	Eng 17-11
Communication Status and Errors	Eng 17-14
Control Panel Communication Status	Eng 17-14
Serial Communication Errors	Eng 17-14
Non-Sync Status	Eng 17-16
Control Panel Diagnostic Tools	Eng 17-18
Module Tests	Eng 17-18
Panel Communications Hub Tests	Eng 17-22
Control Panel SBC Test	Eng 17-25
Touchscreen Tests	Eng 17-26
Burn Mode	Eng 17-27
Frame Diagnostic Tools	Eng 17-29
Frame Transmit/Receive Test	Eng 17-29
GPI Test	Eng 17-30
LEDs Test	Eng 17-30
DIP Switch Test	Eng 17-31
Graphics Buffer Test	Eng 17-31
Video Checksum Custom Controls	Eng 17-33
Setting Up a Checksum Custom Control	Eng 17-33
Using a Checksum Custom Control	Eng 17-35
Communication Port Monitor	Eng 17-37
Port Monitor Data Files	Eng 17-38
Switcher Logs	Eng 17-39
5	8

#### Switcher Maintenance

#### Troubleshooting a Failed Power Supply ...... Eng 18-2 Troubleshooting a Failed Cooling Fan..... Eng 18-3 Replacing a Power Supply Module ......Eng 18-4 Control Panel Power Supply Functional Components ...... Eng 18-9 Frame Power Supply.....Eng 18-11 Frame Power Supply Functional Components......Eng 18-11 Replacing a Frame Power Supply ......Eng 18-12 Cleaning the Frame Air Filter......Eng 18-14 Replacing the Hard Drive ......Eng 18-15 Installing a Control Panel Module.....Eng 18-19 Upgrading PMCs.....Eng 18-21 Dusting Mode ......Eng 18-22

#### Vision Engineering Manual (v12.0 MD)

### Appendix A. Menu Trees

Setup and Installation Menu Trees	Eng 19-2
Setup Menu Tree	Eng 19-2
Installation Menu Tree	Eng 19-2
Input BNC Menu Tree	Eng 19-3
Output BNC Menu Tree	Eng 19-4
Communications Menu Tree	Eng 19-5
Custom Control Bank Menu Tree	Eng 19-6
Custom Controls Menu Tree	Eng 19-7
File Storage Menu Tree	Eng 19-8
Disk Store Menu Tree	Eng 19-8
Disk Recall Menu Tree	Eng 19-8
Disk Store Individual Item Menu Tree	Eng 19-9
Disk Recall Individual Item Menu Tree	Eng 19-9
Recall Factory Menu Tree	Eng 19-10
Squeeze & Tease and Effects Menu Tree	Eng 19-11
Effects Menu Tree	Eng 19-11
Squeeze & Tease MD Position/Crop Menu Tree	Eng 19-11
Squeeze & Tease MD Border Menu Tree	Eng 19-12
Squeeze & Tease MD Sequence Menu Tree	Eng 19-12
Channel Management Menu Tree	Eng 19-12
Squeeze & Tease MD Preprocessor Menu Tree	Eng 19-13
Squeeze & Tease MD Lighting Menu Tree	Eng 19-13
Squeeze & Tease WARP Menu Tree	Eng 19-13

### Appendix B. Specifications

Standard Components	Eng 20-2
General Switcher Specifications	Eng 20-3
Control Panel Power Supplies	Eng 20-3
Frame Power Supplies	Eng 20-4
Operating Environment Requirements	Eng 20-5
Physical Specifications	Eng 20-6
Control Panel Dimensions	Eng 20-6
Control Panel Desk Cutout Dimensions	Eng 20-7
Frame Dimensions	Eng 20-10
Communication Specifications	Eng 20-11
Default Network Settings	Eng 20-11
Module Control Link Backbone	Eng 20-12
Frame Connector Types	Eng 20-15
Control Panel Connector Types	Eng 20-16
Video Characteristics	Eng 20-17
Video Processing	Eng 20-17
Video Formats	Eng 20-17
Timing	Eng 20-18
LTC Timecode Input	Eng 20-18
Video Input Signal Characteristics	Eng 20-18
Video Output Signal Characteristics	Eng 20-19
Frame Pinouts	Eng 20-20
Peripheral Ports	Eng 20-20
Panel Port	Eng 20-20
GPI I/O Ports	Eng 20-21
LAN Ports	Eng 20-22
AC Power Ports	Eng 20-22
Control Panel Pinouts	Eng 20-24
Remote Ports	Eng 20-24

#### 19

External Link Ports	Eng 20-24
Tally Ports	Eng 20-25
AC Power Ports	Eng 20-26
Control Panel CPU Module Ports	Eng 20-27
Control Panel CPU Module Functional Components	Eng 20-27
Control Panel CPU Module Rear Panel	Eng 20-28
Remote Aux Panel Pinouts	Eng 20-30
GPI Port	Eng 20-30
Main Port	Eng 20-30
Echo Port	Eng 20-31
Aux Panel Programming Mode Summary	Eng 20-32

#### **Appendix C. Worksheets**

#### Video Input Worksheet......Eng 21-2 Bus Map Worksheet.....Eng 21-6 Video Output Worksheet ......Eng 21-9 Communications Worksheet......Eng 21-11 Standard GPI I/O Input Worksheets ...... Eng 21-13 Standard GPI I/O Output Worksheets ..... Eng 21-14 Aux Panel GPI I/O Worksheet......Eng 21-15 Conversion Loop Worksheets......Eng 21-20

#### Appendix D. Software Licenses

GNU General Public License	Eng 22-2
Lesser GNU Public License (LGPL)	Eng 22-4
BSD License	Eng 22-7
General	Eng 22-7
Apache License	Eng 22-8
Expat License	Eng 22-10
Imlib2	Eng 22-11
	-

Appendix E. Custom Device Protocols	23
Custom Devices – Uses and Limitations	Eng 23-2
Advanced Topics and Tables	Eng 23-3

### **Glossary of Terms**

#### Index

#### 22

GT

IX

21

# Introduction

### A Word of Thanks

Congratulations on choosing the Ross Vision Multi-Definition Digital Production Switcher. You have purchased the power and versatility of a digital Multi-Level Effects (MLE®) switcher that is ready to take on all creative challenges in today's competitive broadcast environment. You'll be pleased at how easily your Vision switcher fits into your overall working environment.

### **About This Manual**

This manual takes you through the physical installation, configuration, and setup required to integrate your Octane/QMD-X, MD-X, QMD, or MD frame with a Vision control panel into your facility.

If, at any time, you have a question pertaining to the installation of your Ross Vision switcher, please contact us at the numbers listed in the front of this manual. Our technical staff are always available for consultation, training, or service.

For information on setting up external devices to work with your Vision switcher, refer to the Ross Video External Device Setup Sheet for your device.

### **Documentation Conventions**

The following conventions are used throughout this manual:

- Navigation procedures in this manual set state the button you are to press, followed by the menu that the button appears on. For example, the following navigation procedure shows you how to navigate from the **Main Menus** to the **Installation Menus**. In this case, you press **More**, and then **Setup** on the **Main Menu 2-2**, then you press **Installation** on the **Setup Menu 1-2**.
  - → Press HOME  $\Rightarrow$  More  $\Rightarrow$  Setup  $\Rightarrow$  Installation.
- References in this manual to navigation buttons, such as **HOME**, **UP ONE**, and **HOLD**, refer to the buttons on the Touchscreen Display located immediately to the left of the **Display Region** that you are interacting with.
- Rear panel connectors are indicated in bold-faced upper case letters. For example:
  - $\rightarrow$  The **AUX 1** connector is ...
- Control Panel buttons are indicated in bold-faced upper case letters, using a sans-serif font. For example:
  - > Press WIPE to ...
- Menu names on the integral display panel are indicated in bold-faced text. For example:
  - > The Aux Bus Setup Menu allows you to ...
- Softkey labels on the integral display are indicated in bold-faced text, using a sans-serif font. They are not indicated by the function key below the display that you press. For example:
  - > Press Accept New Name to register ...
- Each module, or group of buttons, on the control panel is shown in bold-faced text. For Example:
  - > Press the UNDO button in the Global Memory Module to ...
- The "**Operating Tip**" and "**Note**" boxes are used throughout this manual to provide customers with additional useful information. For example:



**Operating Tip** — When the **DHCP** is set to **On**, you can use the **Refresh** button to poll the server for the current network address information.

**Note** — If the **DHCP** option in **On**, the remaining settings are automatically configured. If the **DHCP** is **Off**, you will have to manually enter values into all the fields.

### **Documentation Terms**

The following terms are used throughout this guide:

- "Switcher" refers to the entire Vision Multi-Definition Production Switcher, consisting of its electronics frame and control panel.
- "Frame" and "Electronics Frame" both refer to the Octane/QMD-X, MD-X, QMD, and MD Multi-Definition Digital Production Switcher chassis.
- "**Operator**" and "**User**" refer to the person who uses the Vision Multi-Definition Production Switcher.
- "Control Panel" refers to the large multi-button control panel of the Vision Multi-Definition Production Switcher.
- "Master Panel" refers to the panel in a MultiPanel application that can control and can be connected to external devices.
- "Satellite Panel" refers to the panels in a MultiPanel application that cannot be connected to an external device.
- "SDI" refers to Serial Digital Video, a digital video signal that is distributed via a single coaxial cable with BNC connectors.
- "Video System" refers to the mix of interconnected digital equipment (including the edit controller, VTRs, DVEs, etc.) in which the Vision Multi-Definition Production Switcher is included.
- "Storage device" refers to the hardware used to save and recall Setups, configurations and registers of the Vision Multi-Definition Production Switcher. Examples of storage devices are the internal hard drive and a USB flash drive.
- "Bottom MLE" refers to the lowest, or Program/Preset, MLE on each switcher. This MLE is typically the MLE that provides the main program output of the switcher, and includes the Downstream Keyers. On a Vision 2, for example, this would be MLE 2.
- "Half MLE" refers to the Program/Preset, MLE on the Vision x.5 MLE switchers. The Mix/DSK option is applied to this MLE.
- "Full MLE" refers to the full featured MLEs of a switcher. On a Vision 2.5, for example, MLEs 1 and 2 are Full MLEs, because they are fully functional, but MLE 3 is a Half MLE.
- "Setup" refers to a group, or set, of registers that are stored together either on the switcher, or on an external computer. Setups can be stored and recalled to quickly configure the switcher for different productions.

### **Abbreviations**

The following table (Table 1.1) abbreviations are used throughout the text.

Abbreviation	Definition
A-D	Analog-to-Digital
AUX	Auxiliary
CG	Character Generator
D-A	Digital-to-Analog
DA	Distribution Amplifier
DDR	Digital Disk Recorder
DSK	Downstream Keyer
DVE	Digital Video Effects
DVR	Digital Video Recorder
ID	Identification
HD	High Definition
MD	Multi-definition
MLE	Multi-level Effects
PGM	Program Bus
PST	Preset Bus
PST PATT	Preset Pattern
PV	Preview
RU	Rack Unit
SD	Standard Definition
TD	Technical Director
VCR	Video Cassette Recorder
VDCP	Video Disk Communications Protocol
VTR	Video Tape Recorder

Table 1.1 Abbreviations used in this Manual

### **Related Publications**

All Vision switchers come with a complete set of system documentation that includes an **Operator's Manual** and an **Engineering Manual**.

For a complete operational overview of the Vision product line, refer to the following publications:

- Vision Operator's Manual, Ross Part Number: 4800DR-403
- *Ross Video External Device Setup Sheets Compendium*, Ross Part Number: 4800DR-404

### **A Word About Technical Support**

At Ross Video, we take pride in the quality of our products, but if a problem does occur, help is as close as the nearest telephone.

Our 24-Hour Hot Line service ensures you have access to technical expertise around the clock. After-sales service and technical support are provided directly by Ross Video personnel. During business hours (eastern standard time), technical support personnel are available by telephone. Outside of normal business hours and on weekends, a direct emergency technical support phone line is available. If the technical support personnel who is on call does not answer this line immediately, a voice message can be left and the call will be returned shortly. Our Technical support staff are available to react to any problem and to do whatever is necessary to ensure customer satisfaction.

- Technical Support: (+1) 613-652-4886
- After Hours Emergency: (+1) 613-349-0006

# **Switcher Basics**

## In This Chapter

This chapter provides a basic introduction to the Vision switcher, including an overview of the boards in the control panel and frame, as well as an introduction to the various ports, and video buses.

The following topics are discussed in this chapter:

- Equipment Overview
- Control Panel Modules
- Frame Boards
- Communication Ports
- Tally Ports
- GPI I/O Port
- Video Routing
- Video Formats
- CPU Structure
- Board Labelling

### **Equipment Overview**

This section provides an overview of the control panel and frame of the Vision Live Production Engine.

The 4-Keyer option that is available for the Octane/QMD-X and QMD frames adds two additional keyers to each MLE of the switcher. Included with this option is a 4-Keyer, **Keyers Module** for each MLE.

#### **Vision Control Panel**

The control panel of the Vision switcher provides all the basic user input of the switcher, as well as the majority of the external device control. Depending on the Vision switcher you have, your control panel will look like one of the following:

#### **Vision 4 Control Panel**

The Vision 4 control panels (Figure 2.1) have 4 Panel Rows, 40 Crosspoint Buttons per Bus, 40 Custom Control Buttons, a Transition Module, Memory System Module and Keyer Module per MLE and a Positioner Module as standard.



Figure 2.1 Vision 4 Control Panel (4-Keyer Shown)

On the rear of the Vision 4 control panels there are 8 Remote Ports, 8 Tally Ports, 2 PS/2 Ports, 4 External Link Ports, an Ethernet Port for connecting the control panel to the frame, and a Primary and Redundant Power Supply Port, as standard. Refer to the section "Communication Ports" on page Eng 2-15 for more information on these communication ports.

#### **Vision 3 Control Panel**

The Vision 3 control panels (Figure 2.2) have 3 Panel Rows, 32 Crosspoint Buttons per Bus, 32 Custom Control Buttons, a Transition Module, a Memory Module, and Keyer Module per MLE, and a Positioner Module as standard.



Figure 2.2 Vision 3 Control Panel (4-Keyer Shown)

On the rear of the **Vision 3** control panels there are **8 Remote Ports**, **6 Parallel Tally Ports**, **2 PS/2 Ports**, **4 External Link Ports**, an **Ethernet Port** for connecting the control panel to the frame, and a **Primary** and **Redundant Power Supply Port**, as standard. Refer to the section "**Communication Ports**" on page Eng 2-15 for more information on these communication ports.

#### **Vision 2X Control Panel**

The Vision 2X control panels (Figure 2.3) have 2 Panel Rows, 32 Crosspoint Buttons per Bus, 32 Custom Control Buttons, a Transition Module, a Memory Module, and Keyer Module per MLE, and a Positioner Module as standard.



Figure 2.3 Vision 2X Control Panel (4-Keyer Shown)

On the rear of the Vision 2X control panel there are 8 Remote Ports, 6 Tally Ports, 2 PS/2 Ports, 4 External Link Ports, an Ethernet Port for connecting the control panel to the frame, and a Primary and Redundant Power Supply Port, as standard. Refer to the section "Communication Ports" on page Eng 2-15 for more information on these communication ports.

#### **Vision 3M Control Panel**

The Vision 3M control panels (Figure 2.4) have 3 Panel Rows, 24 Crosspoint Buttons per Bus, 24 Custom Control Buttons, a Transition Module, an Effects Memory Module and Keyer Module per MLE, and a Positioner Module as standard.



Figure 2.4 Vision 3M Control Panel (4-Keyer Shown)

On the rear of the **Vision 3M** control panels there are **8 Remote Ports**, **6 Parallel Tally Ports**, **2 PS/2 Ports**, **4 External Link Ports**, an **Ethernet Port** for connecting the control panel to the frame, and a **Primary** and **Redundant Power Supply Port**, as standard. Refer to the section "**Communication Ports**" on page Eng 2-15 for more information on these communication ports.

#### Vision 2M Control Panel

The Vision 2M control panels (Figure 2.3) have 2 Panel Rows, 24 Crosspoint Buttons per Bus, 24 Custom Control Buttons, a Transition Module, a Memory Module, and Keyer Module per MLE, and a Positioner Module as standard.



Figure 2.5 Vision 2M Control Panel (4-Keyer Shown)

On the rear of the **Vision 2M** control panel there are **8 Remote Ports**, **4 Tally Ports**, **2 PS/2 Ports**, **4 External Link Ports**, **an Ethernet Port** for connecting the control panel to the frame, and a **Primary** and **Redundant Power Supply Port**, as standard. Refer to the section "**Communication Ports**" on page Eng 2-15 for more information on these communication ports.

#### **Vision 2 Control Panel**

The Vision 2 control panels (Figure 2.6) have 2 Panel Rows, 16 Crosspoint Buttons per Bus, 16 Custom Control Buttons, a Transition Module, a Memory Module and Keyer Module per MLE, and a Positioner Module as standard.



Figure 2.6 Vision 2 Control Panel (4-Keyer Shown)

On the rear of the **Vision 2** control panels there are **8 Remote Ports**, **4 Parallel Tally Ports**, **2 PS/2 Ports**, **4 External Link Ports**, an **Ethernet Port** for connecting the control panel to the frame, and a **Primary** and **Redundant Power Supply Port**, as standard. Refer to the section "**Communication Ports**" on page Eng 2-15 for more information on these communication ports.

#### **Vision 1M Control Panel**

The Vision 1M control panel (Figure 2.8) has 1 Panel Row, 24 Crosspoint Buttons per Bus, 24 Custom Control Buttons, a Transition Module, a Memory Module, and Keyer Module per MLE, and a Positioner Module as standard.



Figure 2.7 Vision 1M Control Panel (4-Keyer Shown)

On the rear of the **Vision 1M** control panel there are **8 Remote Ports**, **2 Parallel Tally Ports**, **2 PS/2 Ports**, **4 External Link Ports**, an **Ethernet Port** for connecting the control panel to the frame, and a **Primary** and **Redundant Power Supply Port**, as standard. Refer to the section "**Communication Ports**" on page Eng 2-15 for more information on these communication ports.

#### Vision 1 Control Panel

The Vision 1 control panel (Figure 2.8) has 1 Panel Row, 16 Crosspoint Buttons per Bus, 16 Custom Control Buttons, a Transition Module, a Memory Module, and Keyer Module per MLE, and a Positioner Module as standard.



Figure 2.8 Vision 1 Control Panel (4-Keyer Shown)

On the rear of the **Vision 1** control panel there are **8 Remote Ports**, **2 Parallel Tally Ports**, **2 PS/2 Ports**, **4 External Link Ports**, an **Ethernet Port** for connecting the control panel to the frame, and a **Primary** and **Redundant Power Supply Port**, as standard. Refer to the section "**Communication Ports**" on page Eng 2-15 for more information on these communication ports.

#### **Vision Touchscreen Display**

The interactive touchscreen display (**Figure 2.9**) of the Vision control panel provides all of the menu interaction for the switcher, including functions such as pattern control selection, external device interface control, and switcher setup. Refer to the section "**Touchscreen Interface**" on page Eng 5-2 for more information on using the touchscreen display.



**Note** — The **Touchscreen Display** is an option with the **Vision 1**, and **2** control panels. If you do not have the Touchscreen Display, an LCD computer monitor with a DVI-D connector is required.



Figure 2.9 Vision Touchscreen Display

#### Frame

The frame of the Vision switcher performs all the video routing and manipulation of the switcher. The frame consists of a chassis with a midplane into which all the frame boards are installed. Boards are installed into both the front and the rear of the frame.

#### **Frame Rear**

The rear of the frame is where all of the **Video Input** and **Video Output Boards** are located, as well as the communications ports on the **Frame CPU Board**. The rear of the MD (**Figure 2.10**), QMD (**Figure 2.11**), and MD-X, and Octane/QMD-X (**Figure 2.12**) frames are shown below.



Figure 2.10 Rear View of Frame (MD Shown)



Figure 2.11 Rear View of Frame (QMD Shown)



Figure 2.12 Rear View of Frame (Octane/QMD-X Shown)

#### For More Information...

• on the rear frame boards, refer to the section "Frame Boards" on page Eng 2-12.

#### **Frame Front**

The front of the frame is where the **Squeeze & Tease Carrier Boards**, **Video Processor Boards**, and, in the Octane/QMD-X, and MD-X frames, the **Crosspoint Board** are located. The number and position of the Squeeze & Tease Carrier Boards, and Video Processor Boards depends on the configuration and model of your frame.

The frame can be configured in a number of ways, depending on the number of MLEs, and Squeeze & Tease DVE channels you require per MLE-pair. These requirements determine where boards are installed in the frame. Refer to the section "**Squeeze & Tease**" on page Eng 2-27 for more information on where the **Video Processor** and **Squeeze & Tease Carrier Boards** are located in the frame. The front of the Octane/QMD-X, and MD-X frame (**Figure 2.13**), and the QMD, and MD frame (**Figure 2.14**) are shown below.


Figure 2.13 Front View of Frame (Octane/QMD-X and MD-X)



Figure 2.14 Front View of Frame (QMD/MD)

- on the front frame boards, refer to the section "Frame Boards" on page Eng 2-12.
- on installing and removing boards from the frame, refer to the section "**Removing and Installing Frame Boards**" on page Eng 4-18.

# **Control Panel Modules**

The Vision control panel consists of a number of removable modules. These modules include all the interface buttons on the control panel, as well as the controllers inside the control panel.

# **Control Panel CPU Module**

The **Control Panel CPU Module** houses the **Single Board Computer** (**SBC**) and the **Panel Communications Hub** (**PCH**). This module performs all the command and control functions between the different modules on the control panel and the frame.

# **Panel Module Controller Board**

The **Panel Module Controller** (**PMC**) is installed on each control panel module and is used to communicate with the **Control Panel CPU Module**. Each **PMC** is connected in series with the other **PMCs** in the same row on the Module Control Link backbone and is identified by a link and node address. Refer to the section "**Module Control Link Backbone**" on page Eng 20-12 for more information on how the modules are connected on the Module Control Link backbone.

# **Keyers Module**

The **Keyers Modules** consists of the **Effects Keyer Board** that supports the buttons and mnemonic displays on the module, and a **PMC** that provides the communications with the **Control Panel CPU Module**.

The **Keyers Module** comes in a **2-Keyer**, **4-Keyer** and **6-Keyer** configuration, and allow you to perform all the Key type, Key modifier, and Key transitions for the assigned MLE. The **6-Keyer** configuration is only available with the MultiDSK<sup>TM</sup> option.

# **Global Memory Module**

The **Global Memory Module** consists of the **Global Memory Board** that supports the buttons, mnemonic displays, and module display on the module, and a **PMC** that provides the communications with the **Control Panel CPU Module**.

The **Global Memory Module** allows you to store and recall memories to all MLEs at once, or to specific MLEs. Only the Program/Preset MLE can support a **Global Memory Module**.

# **MLE Memory Module**

The **MLE Memory Module** consists of the **MLE Memory Board** that supports the buttons, mnemonic displays, and module display on the module, and a **PMC** that provides the communications with the **Control Panel CPU Module**.

 $\bigcirc$ 

**Note** — The **Vision 1** control panel does not support the **MLE Memory Module**. Instead, it uses a single **Global Memory Module**.

The **MLE Memory Module** allows you to store and recall memories to individual MLEs. The Program/Preset MLE does not support an **MLE Memory Module**.

# **Transition Module**

The **Transition Module** consists of the **Transition Board** that supports the buttons, mnemonic displays, module display, and fader on the module, and a **PMC** that provides the communications with the **Control Panel CPU Module**.

The **Transition Module** allows you to set and perform all key and background transitions on the assigned MLE. This includes the type of transition, as well as whether the transition is a cut, auto-transition, or a manual transition using the fader.

# **Positioner Module**

The **Positioner Module** consists of the **Positioner Board** that supports the buttons and positioner on the module. The **Positioner Module** connects to the **Preview Bus Module** to communicate with the **Control Panel CPU Module**.

The **Positioner Module** allows you to use the positioner to directly control external devices, such as robotic cameras, or quickly alter menu values by moving the positioner in the appropriate axis. The positioner can follow the menu system, or be locked to a specific external device, such as a robotic camera.

# **Preview Bus Module**

The **Preview Bus**, **Preview Overlay**, and **Fade To Black Modules** are all supported by the **Preview Bus Board**. The **Preview Bus Module** supports the buttons, module display and USB port on the modules, as follows:

- **Preview Bus Module** The **Preview Bus Module** allows you to assign video feeds directly to your preview monitor. These video feeds include the background and preview of each MLE, as well as the main program output.
- **Preview Overlay Module** The **Preview Overlay Module** allows you to turn on and off specific elements of the preview overlay. The menu systems follows the activation of preview overlay elements, allowing you to quickly adjust each one.
- Fade to Black Module The Fade To Black Module allows you to cut or fade the output of the switcher to black. A USB port is also located on this module to allow you to connect a USB device, or a USB flash drive, for storing and recalling setups.

# **Power Distribution Board**

The **Power Distribution Board** routes power between the control panel power supplies and the individual modules on the control panel, as well as pass power supply and cooling fan status signals to the **Control Panel CPU Module**.

# **Frame Boards**

The frame uses a number of removable boards and cards to operate. This allows the quick replacement of a board in the frame without having to power down or disassemble the frame.

# Frame CPU Board

#### (4800AR-001)

The **Frame CPU Board** resides in **Slot A** at the rear of the frame, and is connected to the midplane. It contains the Hard Drive, the system memory, and the main system microprocessor, and is responsible for the high-level control functions and all Ethernet and remote serial communication for the frame and the Ethernet connection between the frame and control panel. The **Frame CPU Board** is also where the Global-Store is located.

# Video Input Board, 16 Input

#### (4800AR-060, 4800AR-061)

The Video Input Board comes in four configurations, two with an analog reference loop (4800AR-060A, 4800AR-061A), and two without (4800AR-060B, 4800AR-061B). All versions have 16 multi-definition serial digital inputs, but the two with reference have 2 additional BNC for the reference connections.

# Video Input Board, with Crosspoint

#### (4400AR-062, 4400AR-061)

Both the **Video Input Boards with Crosspoint** (**4400AR-062**, **4400AR-061**), in addition to the **16** multi-definition serial digital inputs and reference loop, have a **72×72** crosspoint.

The Octane/QMD-X, and MD-X frames do not support the Video Input Board with Crosspoint, using the Crosspoint Board instead.

# Video Input Board, 10 Input

#### (4800AR-060, 4800AR-061)

Both the Video Input Boards with 10 Inputs (4800AR-060C, 4800AR-061C) come with 10 multi-definition serial digital inputs instead of 16, and no reference loop.

# **Video Output Board**

#### (4800AR-064, 4800AR-065, 4800AR-066, 4800AR-067)

Each **4800AR-064**, **4800AR-066**, and **4800AR-067** board contains **16** fully configurable multi-definition video outputs that can be used as Aux Buses, MLE Program, MLE Preview, MLE Clean Feed, Preview Overlay, AuxKeys<sup>TM</sup>, or MultiDSK<sup>TM</sup>.

The **4800AR-065** boards contain **16** SDI only video outputs that can be used as MLE Program, MLE Preview, MLE Clean Feed, or Preview Overlay.

Only BNCs E9 to E16 are available on a Video Output Board installed in Slot E of the QMD frame.

# Video Processor Board

(4800AR-040, 4800AR-041)

The **Video Processor Boards** performs all of the basic video effects in the Vision switcher. Functions such as the interface to the Squeeze & Tease MD Boards, Chroma keying, patterns and wipes, and transitions are all generated on this board.

How the **Video Processor Boards** are installed in the frame depends on the type of frame, and how the frame is configured for the number of MLEs. Refer to the section "**Video Processor**" on page Eng 2-24 for more information on the **Video Processor Boards** in the frame.

Each Video Processor Board provides 2 slots for the optional XFX Extra Effect Cards.

### Midplane

The **Midplane** is a non-removable board that provides the interconnections between the switcher frame boards, the power supplies, and the fan assembly, as well as the routing through which all video signals, communication, and control commands pass. The board has no active components.

### **Crosspoint Board**

#### (4800AR-020)

The **Crosspoint Board** is a **144**×**144** switch that can route HD as well as SD video signals. Only one **Crosspoint Board** can be installed in the front of the frame.

The **QMD** and **MD** frames do not support the Crosspoint Board, using the Video Input Board with Crosspoint instead.

# **Squeeze & Tease Carrier Board**

#### (4800AR-047)

The **Squeeze & Tease Carrier Board** provides **4** slots for the **Squeeze & Tease MD Cards** and **2** slots for the **Squeeze & Tease WARP MD Cards**. The board also provides local control as well as video routing and power to these cards.

How the **Squeeze & Tease Carrier Boards** are installed in the frame depends on the type of frame, and how the frame is configured for the number of MLEs and Squeeze & Tease DVE channels that are required. Refer to the section "**Squeeze & Tease**" on page Eng 2-27 for more information on where the **Squeeze & Tease Carrier Boards** are located in the frame.

### **Power Supplies**

Each frame requires at least one or two power supplies, depending on the type and size of frame, to provide enough power to operate. Additional Redundant power supplies can be installed to allow all power supplies to operate in a load sharing mode. In this mode, if a power supply were to fail, the remaining power supplies can provide enough power to keep the frame operating. This allows for the hot swapping of a failed power supply without interruption to the operation of the switcher.

The minimum number of power supplies required by each frame is listed as follows:

- Octane/QMD-X  $2 \times 12$  Volt, 700 Watt, Power Supply
- **MD-X**  $\mathbf{3} \times 12$  Volt, 500 Watt, Power Supply

- **QMD**  $1 \times 12$  Volt, 700 Watt, Power Supply
- **MD**  $\mathbf{2} \times 12$  Volt, 500 Watt, Power Supply

**Note** — If a power supply fails, the **Power Fail** indicator on the **Touchscreen Display** lights, indicating that there is a problem with one of the power supplies.

- on fail indicators, refer to the section "Fail Indicators Diagnosis" on page Eng 17-10.
- on fame power supplies, refer to the section "Frame Power Supply" on page Eng 18-11.

# **Communication Ports**

The Vision control panel has a number communication ports on both the control panel and the frame that are used to communicate with external devices, such as Character Generators, Video Servers, and Robotic Cameras. There are also RJ-45 LAN ports on both the control panel and the frame that are use for frame/control panel communication, switcher upgrades, and external device control.

# **Control Panel Communication Ports**

The majority of the communication ports for the switcher are located on the rear of the control panel. These ports (**Figure 2.15**) include the serial ports for external device control, external link ports for communication with Auxiliary Control Panels, the Touchscreen Display and other external modules, an Ethernet Port for communication with the frame, PS/2 ports, USB ports, and a DVI Video port.



Figure 2.15 Communication Ports on the Rear of the Vision Control Panel

1)	DVI Video Port	4) Ethernet Port	7) Remote Ports
2)	Mouse Port	5) UBS Ports	
3)	Keyboard Port	6) External Panel Link Ports	

### 1. DVI Video Port

The single **DVI-D** port is used to connect to the Touchscreen Display to provide the video signal from the control panel to the display. If you do not have the Ross Touchscreen Display, a LCD monitor with a DVI-D connector is required.

### 2. Mouse Port

This **PS/2** port is used to connect a standard mouse to the switcher.

### 3. Keyboard Port

This PS/2 port is used to connect a standard keyboard to the switcher.

### 4. Ethernet Port

The single **8-pin RJ-45** port is used to connect to the facility network on the same subnet as the frame. This connection provides all the communication between the control panel and the frame.

### 5. USB Ports

These **2 USB** ports are used to connect to supported USB devices.

### 6. External Panel Link Ports

The **4 External Panel Link** ports are used to connect with the Auxiliary Control Panels, legacy Synergy Remote Aux Panels, and to the Touchscreen Display.

### 7. Remote Ports

These **8 DB9** serial ports are used to connect to most of the external devices supported by the Vision switcher, with the exception of Editors. Remote ports support both **RS-232** and **RS-422** communication, in both a Straight Through and Null Modem configuration.

# **Frame Communication Ports**

The majority of the communications ports on the frame (**Figure 2.16**) are used for controlling peripheral equipment such as Editors. In addition to the Peripheral ports, there are LAN ports for connecting to an external computer for upgrades and for external device control, a GP I/O port for GPI and GPO triggers, a Panel port for communication with a legacy control panel, USB ports, and a Time Code Input port.



Figure 2.16 Communication Ports on the Frame CPU Board

1) LAN Ports	3) Peripheral Ports	5) USB Ports
2) GP I/O Port	4) Panel Port	6) Time Code Input

### 1. LAN Ports

These **2 RJ-45** ports support standard **10/100 Base TX Ethernet** communication for connection to the Vision control panel network hub, or switch for external device control, upgrades, image transfer, and the external backup of switcher setups. Only the **LAN 1** port should be used to connect to the Vision control panels.

### 2. GP I/O Port

The single **DB25 GP I/O** port is used to connect to a GP I/O distribution system, providing 10 pins for **GPI Inputs** and **10** pins for **GPI Outputs** to the switcher. A single pin is provided for ground. These GPIs can be used to trigger transitions, custom controls, or recall a memory registers on the switcher.

There are **4** additional pins on the port that are used as a power-fail relay. These normally closed relays open in the event of a power failure, or other switcher failure that may prevent reliable program output.

### 3. Peripheral Ports

These **4 DB9** serial ports are used to connect to external equipment such as Editors. Peripheral ports support both **RS-232** and **RS-422** communication in a Straight Through or Null configuration.

### 4. Panel Port

The single **8-pin RJ-45 Panel** port is used to connect to the legacy Synergy control panel and provides all the communication between the control panel and frame.

### 5. USB Ports

These 2 USB ports are used to connect to supported USB devices.

### 6. Time Code Input

The single **Time Code Input** port is used to connect to an external time reference for synchronization.

- on connecting external equipment to a remote or peripheral port, refer to the section "Communications Overview" on page Eng 9-2.
- on connecting to the frame, refer to the section "Frame Installation" on page Eng 3-5.
- on connecting to the control panel, refer to the section "**Control Panel Installation**" on page Eng 3-7.
- on setting up communications between the control panel and frame, refer to the section "Frame to Control Panel Cabling" on page Eng 3-11.

# **Tally Ports**

The **DB25 Tally** ports (**Figure 2.17**) on the Vision control panels provide standard parallel contact closure tallies for the switcher. Tallies can be assigned to any video input signal using the menu system.



Figure 2.17 Tally Ports on Rear of Vision Control Panel

The Vision control panel provides **36** tallies as standard, with **18** tallies per port (**Figure 2.18**). Depending on the Vision control panel you have, extended tallies can be installed in groups of **36**.



Figure 2.18 Tallies on Each Tally Port

The maximum parallel tallies supported by each control panel is as follows:

- **Vision 1 36** maximum
- Vision 1M 36, or 72
- Vision 2 36 maximum
- Vision 2M 36, or 72
- Vision 3M 36, 72, or 108
- Vision 2X 36, 72, or 108
- Vision 3 36, 72, or 108
- Vision 4 36, 72, 108, or 144

- on assigning tallies to video inputs, refer to the section "Assigning Tallies to Video Inputs" on page Eng 7-23.
- on the pinouts and voltages for the Tally ports, refer to the section "Control Panel Pinouts" on page Eng 20-24.

# **GPI I/O Port**

The single **DB25 General Purpose Interface** (**GPI**) port on the **CPU Board** of the frame (**Figure 2.19**) is used for GPI Input and GPI Output signals.



Figure 2.19 The GP I/O Port on the CPU Board of the Frame

There are **10 GPI Inputs** that can be used to trigger transitions, custom controls, or memory recalls on the switcher in different areas, or MLEs. Setup is done through the menu system, allowing you to associate a GPI Input with a Function, and specify which Area, or MLE, you want that function to be performed in. If you select custom control as the function, you must specify the custom control you want to execute, rather than the area. GPI Inputs can also be used to activate a tally.

There are **10** GPI Outputs that can be used to used to trigger events on external equipment. Like the GPI Inputs, setup is done through the menu system, allowing you to configure the trigger type and level for each GPI. Output GPIs are typically triggered using custom controls.

- on setting up GPI Inputs, refer to the section "Standard GPI Setup" on page Eng 12-9.
- on setting up GPI Outputs, refer to the section "**Programming Special Functions**" on page Eng 10-15.
- on the pinouts and voltages of the GP I/O port, refer to the section "**Frame Pinouts**" on page Eng 20-20.

# **Video Routing**

Video routing is handled by various boards installed in the frame. The boards used to route video through the frame depends on the type of frame you have, as follows:

- Octane/QMD-X/MD-X The boards primarily responsible for video routing are the Crosspoint Board, the Video Processor Board, and the Squeeze & Tease MD Carrier Board.
- **QMD/MD** The boards primarily responsible for video routing are the Video Input Board, the Video Processor Board, and the Squeeze & Tease MD Carrier Board.

Each of these boards in the frame work together with the Midplane and the Video Output Board to take an input video signal, manipulate it, and route it to the desired output.

# **Crosspoint Matrix**

The crosspoint matrix allows you to route a video signal from any **Input BNC** to any, or all, **Output BNC**. Video signals are received by the **Input BNC** and sent to the **Crosspoint**. Depending on how the switcher is currently operating, the **Crosspoint** will send the video signals to the **Video Processor** and **Squeeze & Tease Carrier** for any video manipulation that is required. The manipulated video signals are then sent back to the **Crosspoint** to be routed to the desired **Video Output**, and finally to the **Output BNC**.

Video flow through the crosspoint to the other boards in the frame depends on the frame you are using and how it is configured.

**Note** — Video manipulation can only occur on video signals that are in the same video format as the switcher is currently operating in. Non-native video formats must be converted before they can be manipulated. Refer to the section "**Setting Up a Conversion Loop**" on page Eng 16-2 for more information on up/down converters.

### For More Information...

• on the different board configurations of the frame, refer to the section "Squeeze & Tease" on page Eng 2-27.

### **Octane/QMD-X Crosspoint Matrix**



Figure 2.20 Video Flow Through the Crosspoint Board

The Crosspoint Board has the following inputs:

- 96 video feeds from the Input BNCs on the Video Input Boards in Slots C through H.
- 8 video feeds from the Video Processor Board in Slot 2 (depending on configuration).
- 8 video feeds from the Video Processor Board in Slot 4 (depending on configuration).
- 8 video feeds from the Video Processor Board in Slot 7 (depending on configuration).
- 8 video feeds from the Video Processor Board in Slot 9 (depending on configuration).
- 4 video feeds from the Global-Store on the CPU Board in Slot A.

The Crosspoint Board has the following outputs:

- 48 video feeds to the Output BNCs on the Video Output Boards in Slots I through K.
- 16 video feeds to the Video Processor Board in Slot 2 (depending on configuration).
- 16 video feeds to the Video Processor Board in Slot 4 (depending on configuration).
- 16 video feeds to the Video Processor Board in Slot 7 (depending on configuration).
- 16 video feeds to the Video Processor Board in Slot 9 (depending on configuration).
- 4 video feeds to the Global-Store on the CPU Board in Slot A.

### **MD-X Crosspoint Matrix**



Figure 2.21 Video Flow through the Crosspoint Board

The Crosspoint Board has the following inputs:

- 96 video feeds from the Input BNCs on the Video Input Boards in Slots C through H.
- 8 video feeds from the Video Processor Board in Slot 4.
- 8 video feeds from the Video Processor Board in Slot 9.
- 4 video feeds from the Global-Store on the CPU Board in Slot A.

The Crosspoint Board has the following outputs:

- 48 video feeds to the Output BNCs on the Video Output Boards in Slots I through K.
- 16 video feeds to the Video Processor Board in Slot 4.
- 16 video feeds to the Video Processor Board in Slot 9.
- 4 video feeds to the Global-Store on the CPU Board in Slot A.

### **QMD Crosspoint Matrix**



Figure 2.22 Video flow through the Crosspoint Matrix

The Crosspoint Board has the following inputs:

- 48 video feeds from the Input BNCs on the Video Input Boards in Slots C through E.
- 16 video feeds from the Video Processor Boards in Slots 1 and 3.
- 4 video feeds from the Global-Store on the CPU Board in Slot A.

The Crosspoint Board has the following outputs:

- 24 video feeds to the Output BNCs on the Video Output Boards in Slots B and E.
- 16 video feeds to the Video Processor Boards in Slots 1 and 3.
- 4 video feeds to the Global-Store on the CPU Board in Slot A.



**Note** — If a **Video Output Board** is installed in **Slot E**, a total of **32 Input BNCs** and **24 Output BNCs** will be available.

### **MD Crosspoint Matrix**



Figure 2.23 Video Flow through the Crosspoint Matrix

The Crosspoint Board has the following inputs:

- 32 video feeds from the Input BNCs on the Video Input Boards in Slots C through D.
- 8 video feeds from the Video Processor Board in Slot 1.
- 4 video feeds from the Global-Store on the CPU Board in Slot A.

The Crosspoint Board has the following outputs:

- 16 video feeds to the Output BNCs on the Video Output Boards in Slot B.
- 16 video feeds to the Video Processor Board in Slot 1.
- 4 video feeds to the Global-Store on the CPU Board in Slot A.

### **Video Processor**

The **Video Processor Board** performs most of the non-Squeeze & Tease video manipulation for the switcher. Background, Key, Alpha, DVE and Utility signals are all sent to the **Video Processor** and returned as Program, Preview, Clean, and DVE video and alpha.

The number and placement of the Video Processor Boards in the frame depends on the frame you have and how it is configured.

### **Octane/QMD/X Video Processor**

The Octane/QMD-X, and QMD frames can support **2** MLEs with each **Video Processor Board**. The placement of the **Video Processor Boards** depending on the number of MLEs, and Squeeze & Tease DVE channels you require per MLE-pair. These requirements will determine where boards are installed in the frame. Refer to the section "**Squeeze & Tease**" on page Eng 2-27 for more information on where the **Video Processor** and **Squeeze & Tease Carrier Boards** are located in the frame.

The inputs and outputs for the **Video Processor Board** are the same, except for the MLEs they are supporting (**Figure 2.24**).



Figure 2.24 Video flow through the Video Processor for MLEs 1 and 2

The Video Processor Board for MLE 1 and MLE 2 has the following inputs:

- 2 MLE BKGD video feeds (one for MLE 1 and one for MLE 2).
- 2 MLE PST video feeds (one for MLE 1 and one for MLE 2).
- 2 Key 1 Video video feeds (one for MLE 1 and one for MLE 2).
- **2** Key 1 Alpha video feeds (one for MLE 1 and one for MLE 2).
- 2 Key 2 Video video feeds (one for MLE 1 and one for MLE 2).
- 2 Key 2 Alpha video feeds (one for MLE 1 and one for MLE 2).
- 2 Key 3 Video video feeds (one for MLE 1 and one for MLE 2).
- 2 Key 3 Alpha video feeds (one for MLE 1 and one for MLE 2).
- 2 Key 4 Video video feeds (one for MLE 1 and one for MLE 2).
- 2 Key 4 Alpha video feeds (one for MLE 1 and one for MLE 2).

The Video Processor Board for MLE 1 and MLE 2 has the following outputs:

- **2** PGM video feeds (one for MLE 1 and one for MLE 2).
- **2** PV video feeds (one for MLE 1 and one for MLE 2).
- 2 Clean Feed video feeds (one for MLE 1 and one for MLE 2).
- 2 Utility Bus Out video feeds (one for MLE 1 and one for MLE 2).

### **MD/X Video Processor**

The MD-X and MD frames can support **2** MLEs with each Video Processor Board. The Video Processor Board performs most of the non-Squeeze & Tease video manipulation for the switcher. Background, Key, Alpha, DVE and Utility signals are all sent to the Video Processor and returned as Program, Preview, Clean, and Aux Loopthrough.

The inputs and outputs for the **Video Processor Board** are the same, except for the MLEs they are supporting (**Figure 2.25**).



Figure 2.25 Video Flow through the Video Processor

The Video Processor Board for MLE 1 and MLE 2 has the following inputs:

- 2 MLE BKGD video feeds (one for MLE 1 and one for MLE 2).
- 2 MLE PST video feeds (one for MLE 1 and one for MLE 2).
- 2 Key 1 Video video feeds (one for MLE 1 and one for MLE 2).
- 2 Key 1 Alpha video feeds (one for MLE 1 and one for MLE 2).
- **2** Key 2 Video video feeds (one for MLE 1 and one for MLE 2).
- 2 Key 2 Alpha video feeds (one for MLE 1 and one for MLE 2).
- **2** Aux Loopthrough video feed.
- **2** Utility video feeds.

The Video Processor Board for MLE 1 and MLE 2 has the following outputs:

- 2 PGM video feeds (one for MLE 1 and one for MLE 2).
- **2** PV video feeds (one for MLE 1 and one for MLE 2).
- 2 Clean Feed video feeds (one for MLE 1 and one for MLE 2).
- **2** Aux Loopthrough video feed.

# Squeeze & Tease

The **Squeeze & Tease Carrier Boards** support the **Squeeze & Tease MD** and **WARP** cards that perform all of the Squeeze & Tease video manipulation for the switcher. When Squeeze & Tease resources are required by the switcher, the desired video signals are sent from the **Video Processor Board** to the **Squeeze & Tease Carrier Board**. The video signals are then sent back to the **Video Processor Board**.

The number and placement of the **Squeeze & Tease Carrier Boards** in the frame depends on the frame you have and how it is configured.

### **Octane/QMD-X Squeeze & Tease**

The **Video Processor Boards** and **Squeeze & Tease Carrier Boards** can be installed in the Octane/QMD-X frame in a number of ways, depending on the number of MLEs, and Squeeze & Tease resources you require. These configurations are as follows:

- Slots 6 9 The Squeeze & Tease Carrier Boards in Slot 6 and Slot 8 of the QMD-X frame support the Video Processor Boards in Slot 7 and Slot 9, respectively. In this configuration, the 8 Squeeze & Tease DVE channel resources and 2 Squeeze & Tease WARP generators provided by each Squeeze & Tease Carrier Board in Slot 6 are dedicated to the Video Processor Board in Slot 7. Similarly, the 8 Squeeze & Tease DVE channel resources and 2 Squeeze & Tease DVE channel resources and 2 Squeeze & Tease DVE channel resources and 2 Squeeze & Tease WARP generators provided by each Squeeze & Tease Carrier Board in Slot 8 are dedicated to the Video Processor Board in Slot 9 (Figure 2.27).
- Slots 2 4 The Squeeze & Tease Carrier Board in Slot 3 of the QMD frame supports the Video Processor Boards in Slot 2 and Slot 4. In this configuration, the 8 Squeeze & Tease DVE channel resources, and 2 Squeeze & Tease WARP generators, provided by the Squeeze & Tease Carrier Board are split across the two Video Processor Boards. This provides a total of 4 Squeeze & Tease DVE channel resources and 1 Squeeze & Tease WARP generator to MLE 5 and MLE 6, supported by the Video Processor Board in Slot 4, and 4 Squeeze & Tease DVE channel resources and 1 Squeeze & Tease WARP generator to MLE 7 and MLE 8, supported by the Video Processor Board in Slot 2 (Figure 2.26).

### **MD-X Squeeze & Tease**

The Squeeze & Tease Carrier Board in Slot 3 supports MLE 1 and MLE 2 (Figure 2.27), and the Squeeze & Tease Carrier Board in Slot 8 supports MLE 3 and MLE 4. Both have the same inputs and outputs, except for the MLEs they are supporting.

**Note** — The inputs and outputs for the **Squeeze & Tease Carrier** in **Slot 8** are the same as the inputs for the **Squeeze & Tease Carrier** in **Slot 3**, except that they are for **MLE 3** and **MLE 4**, not **MLE 1** and **MLE 2**.

### **QMD Squeeze & Tease**

The **Squeeze & Tease Carrier Board** in **Slot 2** of the QMD frame supports the **Video Processor Boards** in **Slot 1** and **Slot 3**. In this configuration, the **8** Squeeze & Tease DVE channel resources, and **2** Squeeze & Tease WARP generators, provided by the **Squeeze & Tease Carrier Board** are split across the two **Video Processor Boards**. This provides a total of **4** Squeeze & Tease DVE channel resources and **1** Squeeze & Tease WARP generator to **MLE 1** and **MLE 2**, supported by the **Video Processor Board** in **Slot 1**, and **4** Squeeze & Tease DVE channel resources and **1** Squeeze & Tease WARP generator to **MLE 4**, supported by the **Video Processor Board** in **Slot 3** (**Figure 2.26**).

### **MD Squeeze & Tease**

The MD frame has a single **Squeeze & Tease Carrier Board (Figure 2.27)** that supports the **Squeeze & Tease MD** and **WARP** cards that perform all of the Squeeze & Tease video manipulation for the switcher. When Squeeze & Tease resources are required by the switcher, the desired video signals are sent from the **Video Processor Board**, to the **Squeeze & Tease Carrier Board**. The video signals are then sent back to the **Video Processor Board**.



Figure 2.26 Video flow to and from a shared Squeeze & Tease Carrier



Figure 2.27 Video flow to and from a dedicated Squeeze & Tease Carrier

The **Squeeze & Tease Carrier Board** in both the shared and dedicated configuration, has the following inputs:

- 8 video feeds to the Squeeze & Tease MD Cards (2 per card).
- 4 video feeds to the Squeeze & Tease WARP Cards (2 per card).

The **Squeeze & Tease Carrier Board** in both the shared and dedicated configuration, has the following outputs:

- 16 video feeds from the Squeeze & Tease MD Cards (4 per card).
- 4 video feeds from the Squeeze & Tease WARP Cards (2 per card).

### **XFX Extra Effects**

The **XFX Extra Effects Card** performs different functions, depending on the options you purchase. Current options include a Dual Border Generator and MLE-Store.

The Dual Border Generator option provides visually dynamic border, shadow, and outline effects to both linear MLE keyers, with either hard or soft edges. The option can also enhance Self Keys, Chroma Keys, and Preset Pattern Keys.

The MLE-Store option provides **4** channels of still images per MLE, or **2** video channels with **2** alpha channels. Each MLE can have separate images loaded and images with embedded alpha channels are supported by dedicating one of the MLE-Store channels to the alpha channel.

Each Video Processor Board supports up to **2 XFX Cards** (Figure 2.28). When XFX resources are required by the switcher, the desired video signals are sent from the Video Processor Board, to the XFX Cards on the Video Processor Board. The video signals are then sent back to the Video Processor Board.



Figure 2.28 Video flow to and from an XFX Card

The **XFX Card** has the following inputs:

• **4** video feeds.

The XFX Card has the following outputs:

- 4 MLE-Store Channels, or 2 MLE-Store Channels with 2 Alpha Channels.
- 4 video feeds from the **Dual Border Generator**, including 2 Video Channels and 2 Alpha Channels.

# **Video Formats**

The Vision switcher can operate in a number of different video formats, at different frequencies in either interlaced or progressive scan mode. When you switch between these formats, various displays and settings automatically change to show the new information. To better understand what is being displayed, you must first understand what the information for the different video formats means.

The video formats that are displayed on the Vision switcher (**Figure 2.29**) provide three pieces of information about the video format. This information is the number of horizontal Scan Lines, whether the scan lines are **Interlaced** (i) or **Progressive** (p), and the Frequency that the scan lines are drawn at.



Figure 2.29 Video Formats Provide Three Pieces of Information

# **Horizontal Scan Lines**

The number of horizontal scan lines is related to the pixel resolution of the image on screen. For example, if you have a **720p 59.94 Hz** video signal, the **720** is the number of vertical scan lines. A video signal with **720** scan lines usually corresponds to a **1280×720** (H×V) pixel image. This means that the image is comprised of **1280** columns of pixels and **720** rows of pixels (**Figure 2.30**). The reason the vertical resolution, the **720**, is used to denote the video format is because of how it is drawn on a standard television. With Cathode-Ray Tube (CRT) television monitors, the image is created, or drawn, one pixel at a time, in rows, from the left side of the screen to the right, to create one scan line.



Figure 2.30 A 720 video signal has 720 scan lines by 1280 vertical pixels

Since each scan line starts from a vertical pixel, there are **720** rows of pixels, or scan lines, being drawn horizontally. The same is true of a video signal with **1080** vertical scan lines, which corresponds to a **1920×1080** pixel image.

# Interlaced vs. Progressive

In the previous section we learned that a video signal is made up of a number of horizontal scan lines that are drawn from left to right on the screen. Although these scan lines are always drawn from left to right, they can be drawn in either an Interlaced or Progressive pattern.

### Interlaced

An Interlaced video format starts at the top of the screen and draws all the odd number scan lines and then all the even number scan lines in sequence. This results in half the image being drawn in one pass and the other half of the image being drawn in the second. These two passes are called **Fields**, where the first pass is called **Field 1** and the second pass is called **Field 2**. When both **Field 1** and **Field 2** have been drawn, resulting in a complete image, you have a single **Frame**.





Frame 1 (Field 1 + Field 2)

Figure 2.31 An Interlaced Video Format Draws Field 1 and Field 2 Separately, to Create a Frame

Both **Field 1** and **Field 2** must be drawn to create **Frame 1**. If you are using field or frame numbers as a counter, you should remember that you must double the number if you are converting from frames to fields. For example, a 4 frame delay is equal to an 8 field delay.

### **Progressive**

A Progressive scan video format draws each scan line in sequence, starting from the top of the screen and working to the bottom. Unlike Interlaced, with Progressive scan the entire image is drawn at one time, in a single pass (**Figure 2.32**). This means that there are no fields in a Progressive scan image.



Figure 2.32 A Progressive scan video format draws each line in sequence

Because there are no fields in a Progressive scan video signal, you cannot use it as a reference signal for an Interlaced video signal. Because the Interlaced video format requires information about when each field is being drawn, you must use a Progressive scan video format as reference for a Progressive scan video signal.

# **Progressive Segmented Frame**

A Progressive Segmented Frame video format is similar to a Progressive Scan video format, in that both draw each scan line in sequence from the top of the screen to the bottom. Unlike the Progressive Scan video format, the Progressive Segmented Frame video format transmits the video signal as if it were interlaced. The odd scan lines are transmitted, followed by the even ones. The even field are delayed one field on the transmitting end, and the odd fields are delayed one field on the receiving end. This allows the transmission of Progressive video signals via equipment that was designed to handle Interlaced video signals only.

Because there are no true fields in a Progressive Segmented Frame video format, you cannot use it as a reference signal for an Interlaced video format.

# Frequency

In the previous sections we learned that a video image is comprised of a number of horizontal scan lines that are drawn in either a Progressive or Interlaced format. The length of time it takes to draw the scan lines from the top of the screen to the bottom in a single pass is called the **Frequency**, and is measured in Hertz (Hz). With a Progressive scan video format, the frequency is the time it takes to draw the entire image. With an Interlaced video format, the frequency is the time it takes to draw 1 field, or half, of the image (**Figure 2.33**).



Figure 2.33 Interlaced and Progressive video formats with the same frequency

For example, an interlaced format of **1080i 50 Hz** draws **50** fields per second. Compare this to a Progressive scan format of **720p 50 Hz** which draws **50** frames per second. Notice that the Interlaced format is actually only drawing **25** frames (**Field 1** plus **Field 2**) per second, where the Progressive scan format is drawing the full **50** frames per second.

### **Using Frame and Field Information**

**Frame** and **Field** rates become very important when you are setting up custom control pauses, transition rates or any other system that counts a period of time in frame or fields on the switcher. Remember from the previous section that in a Progressive scan format, running at **50** Hz, the switcher draws **50** frames per second. In an Interlaced format, also running at **50** Hz, the switcher draws **25** frames per second.

The Vision switcher uses frames to measure transition rates and custom control pauses. The amount of time that this represents depends on the frequency and format you are operating the switcher in. For example, if you are operating the switcher in **1080i 59.94 Hz**, the default MLE transition rate is set at **15** frames (**Figure 2.34**). Since the frequency for an Interlaced format is shown in fields, you must divide this number by **2** in order to get the number of frames per second, **30**. By comparing the transition rate (**15** frames) and the video format frame frequency (**30** frame per second) you can calculate that the transition rate is  $\frac{1}{2}$  a second.



Figure 2.34 Transition Rate Information in the Global Memory System Module

If you were operating the switcher in **720p 59.94 Hz**, the default MLE rate is set at **30** frames. Since the frequency for a Progressive scan format is shown in frames, no conversion is required. By comparing the transition rate (**30** frames) and the video format frame frequency (**60** frames per second) you can calculate that the transition rate is  $\frac{1}{2}$  a second.



**Important** — When you switch reference formats, you must perform a soft reset of the switcher in order to load the default rates for the format you have set.

- on setting up the switcher reference, refer to the section "**Reference Connection and Setup**" on page Eng 4-12.
- on resetting the switcher, refer to the section "**Resetting the Switcher**" on page Eng 4-25.

# **CPU Structure**

This section describes the CPU structure of the Vision switcher, in terms of which areas are controlled by which specific microprocessors. Effectively, the CPU structure functions as a master/slave multi-processor system, where the master processor controls high level functionality and delegates other tasks to slave processors.

Processor distribution and functionality is as follows:

- One **PowerPC CPU** on the **Frame CPU Board** is responsible for performing high level functions, and issuing commands to the remaining microprocessors. This processor manages all serial channels to and from the frame, manages communications with the control panel, and manages communications with all other peripheral devices connected to the frame.
- The **Frame Processor** also controls non-MLE functions, including all Aux Bus functions and all crosspoint switching on the **Crosspoint Module**. It does not control the **Preview Overlay Module**, but it does issue commands to that module, in terms of what text and graphics to display.
- One **PowerPC CPU** on the **Video Processor Board** processes high-level information from the **Frame CPU Board** that pertains to the current state and specific commands issued on each MLE. This high level information includes which functions are enabled or disabled, and what configurations have been set up by the user on the control panel. The **Video Processor Board** translates that information, and sets the required bits in the hardware to complete the command request. Some examples of this high level information is as follows:
  - If you press WIPE in an MLE and select the circle wipe, that information goes to the Frame CPU which in turn tells the selected Video Processor that a circle wipe has been requested. The Video Processor then draws the proper tables required to make the image.
  - > If you pull the Fader from Program to Preset, the Frame Processor receives that information and analyzes how it affects the high level structures within the switcher, such as which buses are moving, what type of effect has been requested (Dissolve, Wipe, etc.). The Frame Processor then passes the current state of a particular field to the MLE Processor, which then writes the specific values of the effect to the video processing circuitry.
  - If you press the AUTO TRANS button, that command goes from the Control Panel to the Frame Processor, which in turn keeps track of which state the transition is in. Commands are then issued to the MLE Processor to perform the transition at (for example) 4% in one field, 8% in the next field until complete. The MLE Processor in turn does not process the video itself, but rather issues commands to the hardware on the MLE Board to set the mixer to the requested ratio and manipulate the pixels accordingly.
- One **PowerPC CPU** on the **Video Output Board** is used for local control of this card. It also provides internal ethernet access, program store, and still store images.
- One **PowerPC CPU** on the **Squeeze & Tease MD Carrier Board** governs the on-board communication and control, as well as the communication with the midplane and the daughter cards mounted on the board.
- The **Squeeze & Tease MD Carrier** board also contains a single CPU, which performs all the mathematical calculations required for the DVE effects.

All boards in the frame also contain a micro-controller to manage upgrades, system booting, and other housekeeping functions.

# A Note About CPU Architecture

Virtually all of the lookup tables and all of the bits that are used to configure the hardware and map the crosspoints are set every field. The switcher is in effect performing a complete memory recall operation every single field, always guaranteeing that the control panel is set properly. In terms of the architecture, there is no difference between a requested memory recall operation and the way that the switcher updates the panel normally — every field.

In addition to increasing the reliability of the switcher tremendously, this functionality also allows you to return to the exact state of the panel, should a power failure occur.

# **Board Labelling**

Every circuit board in the Vision switcher that was manufactured by Ross Video is labelled to identify the name of the board, the board number and the revision, or issue, number. This identification is usually found on the outside edge of the board, next to the Ross Video logo (**Figure 2.35**).



Figure 2.35 Circuit Board Identification

The following information is present on the circuit board:

- **Ross Logo** The Ross logo identifies the board as having been designed and manufactured by Ross Video.
- **Board Name** The board name identifies the function of the board, allowing you to quickly and easily identify the different boards in the switcher.
- **Board Number** The board number is tied to the board name and the product line that the board is from. This number identifies the board, and the function it performs.
- **Revision** The revision number identifies the issue of the board.

**Note** — Where a white square is present in the label string, letters may be written within the square to indicate a minor variation on the board itself.



# **Physical Installation and Cabling**

# In This Chapter

This chapter provides information on unpacking, installing, and basic cabling for your Vision switcher.

The following topics are discussed in this chapter:

- Unpacking Your Switcher
- Opening and Closing the Frame Door
- Frame Installation
- Control Panel Installation
- Frame to Control Panel Cabling
- Video Input Cabling
- Video Output Cabling
- Button Inserts
- Power Supply Connections
- Power Fail Indicators



**Warning Hazardous Voltage** — This apparatus, when equipped with multiple power supplies, can generate high leakage currents. To reduce the risk of electric shock, ensure that each individual supply cord is connected to its own separate branch circuit with an earth connection.



**Caution** — The frame door must be installed on the frame for proper cooling. Leaving the frame door off may cause the frame to overheat, resulting in unexpected behavior or damage to equipment.



**Important** — All cables must be run in accordance with good engineering practices. Ensure that there is sufficient room for the cable and that enough slack is left in the cable run to permit long, gentle bends. Always install cables so that they will not be subjected to physical abuse.

# **Unpacking Your Switcher**

A Vision switcher is usually shipped in two, or more, boxes, depending on the options you purchased with your switcher. These boxes may vary, but usually contain the following:

- **Box 1** This box contains the frame, with all the required boards installed.
- Box 2 This box contains the control panel, touchscreen display, cables, and manuals.



**Note** — The **Touchscreen Display** is an option with the **Vision 1** and **2** control panels. If you do not have the Touchscreen Display, an LCD computer monitor with a DVI-D connector is required.

Once the boxes are unpacked, check the contents against the packing list to ensure that all items are included. If any items are missing or damaged, contact your sales representative or Ross Video Limited immediately.

# **Static Discharge**



**ESD Susceptibility** — Static discharge can cause serious damage to sensitive semiconductor devices. Avoid handling the switcher circuit boards in high static environments such as carpeted areas and when synthetic fiber clothing is worn. Touch the frame to dissipate static charge before removing boards from the frame and exercise proper grounding precautions when working on circuit boards.

# **Serial Numbers**

Serial numbers have been implemented to allow Ross Video to properly track which options have been purchased by each customer. Switchers have serial numbers installed (in flash memory) at the factory.

### For More Information...

• on serial numbers, refer to the section "Installing Serial Numbers" on page Eng 6-16.

# **Opening and Closing the Frame Door**

If you are installing hardware options, or replacing a circuit board or power supply, you must remove and re-install the frame door.



**Caution** — The frame door must be installed on the frame for proper cooling. Leaving the frame door off may cause the frame to overheat, resulting in unexpected behavior or damage to equipment.

# **Octane/QMD/X Frame**

The door on the Octane/QMD-X and QMD frames swings open, allowing for quick access to the boards and cards in the frame. The door can also be completely removed for greater access into the frame.

Use the following procedure to open the door of the Octane/QMD-X or QMD frame:

**1.** Gently pull the door latch out and rotate it to release the door. The Octane/QMD-X door has two latches.



Figure 3.1 Frame Door Overview (QMD Shown)

2. Swing the door open, as shown (Figure 3.1).



This completes the procedure for opening the door of the Octane/QMD-X or QMD frame.

# **MD/X Frame**

### **Opening and Removing the Frame Door**

Use the following procedure to remove the frame door:

1. Gently pull the door latch out and up, releasing the door from the top of the frame (**Figure 3.2**). The door retainer prevents the door from falling.



Figure 3.2 Frame Door Overview (MD Shown)

- **2.** With both hands, grasp the sides of the door, and gently lift it. Rotate the bottom towards you until the bottom edge clears the pivoting tongue on which it rests, and the door retainer is free of the frame top plate.
- **3.** Move the door away from the frame, and place it on a clean, flat surface.

This completes the procedure for removing the frame door.

# Installing and Closing the Frame Door

Use the following procedure to install the frame door:

1. With both hands, grasp the sides of the frame door, and, ensuring that the door retainer is under the top of the frame, hook the grooved bottom edge over the pivoting tongue on the bottom front ledge of the frame (Figure 3.3).



Figure 3.3 Frame Door Overview (MD Shown)

**2.** When you are satisfied that the door is resting properly, firmly press the top of the door until the latch pops into place and is secure.

This completes the procedure for installing the frame door.

# **Frame Installation**

This section gives an in-depth overview on how to install the frame into your facility. For information on the dimensions of your frame, refer to the section "**Frame Dimensions**" on page Eng 20-10.

The Vision switcher has an operating temperature range of **0** to **35** degrees Celsius.

Use the following guidelines when installing the frame into your equipment rack:

- Install the frame so as to ensure maximum stability, and adequate ventilation during operation.
- Ensure that both sides of the frame are clear, so that airflow through the frame is not restricted in any way.
- If possible, but not required, leave a **1RU** space above the frame to facilitate installation and removal of the frame door.
- The frame should be installed in a dry, dust free, and easily accessible location.

To ensure maximum stability, the frame must be mounted to the rack using the **2 Support Brackets** that are located at the rear of the frame. These brackets are included in your **Installation Kit**.

# **Installing the Frame**



**Notice** — Failure to install both the **Support Brackets**, or **Rack Mount Arms**, as described will void the warranty.

Use the following procedure to install the frame into the equipment rack:

- Remove the front door from the frame. Refer to the section "Opening and Closing the Frame Door" on page Eng 3-3 for more information on removing and installing the frame door.
- 2. Using standard rack mounting bolts (not supplied) install the frame into the rack.
- **3.** Install the Rack Mount Arms or Support Backets as follows:
  - If you have an Octane/QMD-X frame, refer to the instructions that came with your Rack Mount Kit.
  - If you have a QMD frame, use standard rack mounting bolts (not supplied) to attach the support brackets to the **Rear Panel Mounting Flange** (Figure 3.4). The support brackets are adjustable to accommodate different rack sizes.



Figure 3.4 Support Brackets on the Frame (QMD Shown)

- 4. Inspect all the boards in the frame to ensure that they are properly seated.
- **5.** Inspect all power supplies installed in the frame to ensure that they are properly seated and that the power switch is in the **OFF** position.
- **6.** If you need to install or remove any of the boards or cards in the frame, refer to the section "**Removing and Installing Frame Boards**" on page Eng 4-18.
- **7.** Re-install the frame door.

**Operating Tip** — Even though you will be accessing the frame later in the installation process, it is a good practice to put the frame door on when you are not working in the frame. This protects the boards and circuits in the frame from accidental damage, and dust or debris.

This completes the procedure for installing the frame into the equipment rack.

- on frame specifications, refer to the section "Standard Components" on page Eng 20-2.
- on working with the frame power supplies, refer to the section "**Frame Power Supply**" on page Eng 18-11.


# **Control Panel Installation**

This section gives an in-depth overview on how to install the Vision control panel into your facility. This includes installing the control panel into, or on, the desk, installing the Touchscreen display into a mount, and installing any Auxiliary Control Panels.

### **Control Panel Installation**

The Vision control panel can be installed in one of 3 ways; on top of the desk, partially inserted into the desk, or flush with the desk. Refer to the section "**Control Panel Dimensions**" on page Eng 20-6 for the specific dimensions of each Vision control panel.

### **Desk Top Control Panel Installation**

The Vision control panel can be installed sitting on a desk (**Figure 3.5**). In this installation, ensure that nothing is blocking the cooling vents at the front and rear of the control panel.



Figure 3.5 Profile of Control Panel Sitting on Desk

### **In-Desk Control Panel Installation**

To install the Vision control panel in the desk, you will have to install the mounting brackets onto the control panel, and ensure that the cutout in the desk is of the specified size. There must also be enough cable clearance at the back of the cutout to allow the cables to be connected to the control panel. Refer to the section "**Control Panel Desk Cutout Dimensions**" on page Eng 20-7 for the specific cutout dimensions of each Vision control panel.

The desk must be between 0.65 and 1.7 inches thick for the Under-Desk Brackets to install properly and secure the Vision control panel into the desk.

Use the following procedure to install the control panel into the desk:

- 1. Ensure that the cutout and clearances are adequate for your control panel.
- **2.** If the mounting brackets are not already installed, install the mounting brackets onto the control panel (**Figure 3.6**) using the provided screws.



Figure 3.6 Installing the Mounting Brackets

**3.** Gently slide the control panel into the cutout in the desk. The control panel will drop into the cutout from above and rest on the edge supports (**Figure 3.7**).



Figure 3.7 Profile of Control Panel Sitting in the Desk

- 4. Check the clearances around the control panel and at the back for the cables.
- **5.** Install the Under-Desk Brackets on both sides of the control panel to secure the control panel in the desk (**Figure 3.8**). There are six (6) Under-Desk Brackets for the Vision 4, and four (4) for all other Vision control panels.



Figure 3.8 Under-Desk Brackets Installation

**6.** Additional screws (not provided by Ross Video) can be installed through the Under-Desk Bracket into the desk to ensure the control panel does not move.

This completes the procedure for installing the control panel into the desk.

### Flush Mounted Control Panel Installation

To install the Vision control panel flush into the desk, you must ensure that the cutout in the desk is of the specified size, and that there is enough cable clearance at the back of the cutout to allow the cables to be connected to the control panel. Refer to the section "**Control Panel Desk Cutout Dimensions**" on page Eng 20-7 for the specific cutout dimensions of each Vision control panel.

Use the following procedure to install the control panel into the desk:

- 1. Ensure that the cutout and clearances are adequate for your control panel.
- **2.** Gently slide the control panel into the cutout in the desk. The control panel will drop into the cutout from above and rest on the edge supports (**Figure 3.9**).



Figure 3.9 Profile of Control Panel Sitting Flush in the Desk

- 3. Check the clearances around the control panel and at the back for the cables.
- **4.** If you need to secure the control panel in place, pre-drilled holes are provided in the sides of the control panel tub for securing the control panel to the desk with screws. Screws are not provided.

This completes the procedure for installing the control panel into the desk.

### **Touchscreen Display Installation**

To install the Touchscreen Display for the Vision control panel, you must install the mounting arm, install the touchscreen display on the mounting arm, and then connect the video and communication cables between the control panel tub and the display.

**Note** — The **Touchscreen Display** is an option with the **Vision 1** and **2** control panels. If you do not have the Touchscreen Display, an LCD computer monitor with a DVI-D connector is required. Connect the LCD monitor to the DVI port on the back of the Vision control panel in accordance with the instruction that came with the LCD monitor.

Ross Video does not provide a mounting arm with the Vision control panel. When selecting a mounting arm, you should consider the environment that the control panel will be operating in. For example, in a mobile or truck environment, a more rigid mounting arm is needed to secure the Touchscreen Display.

**Operating Tip** — Ross Video recommends the Humanscale M7 Desk Mount Flat Panel Monitor Arm by Media Control Co., Inc. (mcergo.com).

In order to properly complete this procedure need the following Touchscreen Display cables and equipment:

- **DVI Cable** This is a standard DVI-D cable that connects to the DVI-D port on the control panel and the DVI-D port on the Touchscreen Display.
- **Control Cable** This is a network cable with an RJ-45 connector on both ends. This cable connects to the Aux 1 port on the control panel and the PREV port on the Touchscreen Display.
- USB Cable This is a standard USB cable that connects to the USB port on back of the control panel and the USB port on the Touchscreen Display.
- Mounting Arm The user supplied mounting arm must have a VESA FDMI MIS-D 75 or 100, C compliant mounting bracket to support the Touchscreen Display.

### Installing the Touchscreen

Use the following procedure to connect the Touchscreen Display to the panel (Figure 3.10):

 Secure the Touchscreen Display (Figure 3.10) to the VESA FDMI MIS-D 75 or 100, C Mounting Arm using the 4 #6 screws (#850-013R), flat washers (#960-010R), and locking washers (#960-023R) provided with the Vision control panel Installation Kit and position the display as desired.



Figure 3.10 Control Panel to Touchscreen Display Cable Connections



- 2. Connect and secure one end of the **DVI Cable** to the **DVI** port on the back of the control panel (Figure 3.11).
- **3.** Connect and secure the other end of the **DVI Cable** to the **DVI** port on the touchscreen display.



Figure 3.11 Touchscreen Display Connections to the Vision Control Panel

- **4.** Connect and secure one end of the **Control Cable** to the **External Panel Link 1** port on the back of the control panel.
- **5.** Connect and secure the other end of the **Control Cable** to the **PREV** port on the Touchscreen Display.
- 6. Connect one end of the USB Cable to a USB port on the back of the control panel. It does not matter which port you use.
- 7. Connect the other end of the USB Cable to the USB port on the Touchscreen Display.

This completes the procedure for connecting the Touchscreen Display to the control panel.

#### For More Information ...

- on connecting the power supply connections, refer to the section "**Power Supply Connections**" on page Eng 3-19.
- on installing a Remote Aux Panel, refer to the section "Auxiliary Panels" on page Eng 14-1.
- on control panel specifications, refer to the section "**Standard Components**" on page Eng 20-2.
- on the Touchscreen Display, refer to the section "**Touchscreen Interface**" on page Eng 5-2.
- on the ports on the back of the control panel, refer to the section "**Control Panel Communication Ports**" on page Eng 2-15.
- on the ports on the back of the frame, refer to the section "**Frame Communication Ports**" on page Eng 2-16.

# Frame to Control Panel Cabling

This section gives an in-depth overview of how to connect the Vision control panel to the frame. These connections include the network connection between the control panel and the frame, and connecting the keyboard and mouse to the control panel.

# Frame to Control Panel Cable Installation

The frame and control panel connect to each other through a standard network switch. This connection allows the control panel and frame to pass command and control information between each other, as well as allowing the control panel to connect to external devices on the same subnet. You can connect up to 9 control panels to the frame.



**Important** — Do not connect the CAT5 (TIA/EIA-568-B) network cable to any of the **External** Link ports on the back of the control panel. Doing so may damage the control panel.

Use the following procedure to cable the frame and the control panel:

1. Connect and secure one end of the CAT5 (TIA/EIA-568-B) network cable to the LAN1 port on the CPU Board at the back of the frame. (Figure 3.12)







**Important** — It is recommended that you use only a 10/100mbps switch to connect the Vision control panel to the frame. Using a 10/100/1000mbps (gigabit) switch may cause switcher instability and/or loss of communication between the control panel and the frame. Programming a 10/100/1000mbps (gigabit) switch to 100mbps is not recommended.

- **2.** Connect and secure the other end of the CAT5 (TIA/EIA-568-B) network cable to your local network (a local network switch for example). Refer to the documentation that came with your network switch, or talk to your IT personnel, for more information on setting up and using the switch.
- **3.** Connect and secure a second CAT5 (TIA/EIA-568-B) network cable to the LAN 10/100 port on the control panel. If you are connecting more than one control panel in a MultiPanel application, start by connecting the Master Panel.



- **4.** Connect and secure the other end of the CAT5 (TIA/EIA-568-B) network cable to the same local network or switch.
- 5. Repeat from Step (3.) for each Satellite Panel you are connecting to the switcher.

This completes the procedure for cabling the frame and the control panel.

#### For More Information ...

- on setting up network communication between the control panel and frame, refer to the section "**Network Setup**" on page Eng 4-5.
- on MultiPanel setup, refer to the section "MultiPanel Setup" on page Eng 4-10.

# **Keyboard and Mouse Installation**

A keyboard and a mouse can be connected to the Vision control panel to allow you to interact with the switcher and the menus. The Vision control panel supports a mouse and keyboard plugged into the dedicated PS/2 ports, or the USB ports.

The keyboard and mouse must be plugged into the PS/2 at startup in order to be discovered by the control panel. Plugging the keyboard or mouse into the USB ports can be done while the control panel is operating.

**Note** — The Vision control panel supports any standard 101-Key, 102-Key, or 104-Key Enhanced Keyboards, and any standard PS/2 Mouse.

Use the following methods to install the keyboard and mouse:

- Connect a standard keyboard to the **PS/2 Keyboard** port at the back of the Vision control panel (**Figure 3.13**).
- Connect a standard mouse to the **PS/2 Mouse** port at the back of the Vision control panel (**Figure 3.13**).



Figure 3.13 Keyboard and Mouse Ports on the Vision Control Panel

This completes the method for installing the keyboard and mouse.

### For More Information...

• on the Keyboard or Mouse ports, refer to the section "Control Panel Communication **Ports**" on page Eng 2-15.

# **Video Input Cabling**

This section discusses how to connect video signals to the Input BNCs of the Vision switcher.

Connect your input video signals to the BNCs on the **Video Input Boards** as required. Each input is identified by the **Slot** the board is in, and the **Number (1** to **16** inclusive) at the top left of the BNC (**Figure 3.14**). For example, if you connect a video source to the BNC numbered **5** on the **Video Input Board** in **Slot** C, this input will be identified as **BNC C05**.

The Video Input Board Slots for each frame are as follows:

- Octane/QMD-X Slots C, D, E, F, G, and H
- MD-X Slots C, D, E, F, G, and H
- QMD Slots C, D, and E (Slot E supports either a Video Input Board with 16 inputs or Video Output Board with 8 outputs.)
- MD Slots **C**, and **D**

**Important** — All cables must be run in accordance with good engineering practices. Ensure that there is sufficient room for the cable and that enough slack is left in the cable run to permit long, gentle bends. Always install cables so that they will not be subjected to physical abuse.



**Operating Tip** — A Video Input Worksheet is provided to assist you in keeping track of which sources have been connected to which BNCs, and how those BNCs need to be set up. Refer to the section "Video Input Worksheet" on page Eng 21-2 for a copy of this worksheet.

#### For More Information...

• on setting up video input signals, refer to the section "**Configuring Video Inputs**" on page Eng 7-4.



Figure 3.14 Video Input Boards on the frame (QMD Shown)

**Note** — The Vision switcher passes all embedded audio and ancillary data signals, including "closed captioning" that are present on the background video. The individual MLE program outputs each have the ancillary data associated with the background video for that MLE.

# **Default Input Mapping**

The Vision switcher is shipped with a factory default mapping for the available inputs to the crosspoint buttons on the control panel. This allows you to verify video input signals immediately, without having to first configure the inputs. The default mapping depends on the control panel and number of Video Input Boards you have installed.

By default, the first button on the crosspoint bus is mapped to Black, the buttons following that are mapped to the video inputs, starting with the upper most Video Input Board installed in the frame. The last buttons on the bus are mapped to the four Global-Store channels, MLE Re-entries (if installed), and Shift (**Figure 3.15**).



Figure 3.15 Default Crosspoint Button Mapping (Vision 1 Shown)

On the Shifted crosspoint bus, the first two buttons are mapped to Color Background 1 and Color Background 2, the next are mapped to each of the MLE-Stores (if installed), and the buttons following that are mapped to the video inputs continuing from those on the unshifted bus. The last button is the Shift button.

 $\checkmark$ 

**Operating Tip** — If you want to verify inputs connected to not mapped to crosspoint buttons by default, you will have to map those sources to crosspoint buttons manually.

### For More Information...

- on restoring factory default settings, refer to the section "**Resetting the Switcher**" on page Eng 4-25.
- on assigning inputs to specific crosspoint buttons, refer to the section "Configuring Video Inputs" on page Eng 7-4.
- on Global-Stores, refer to the section "Still-Store Overview" on page Ops 9-2.
- on Bus Holds, refer to the section "Editing Bus Maps" on page Eng 7-13.

# **Video Output Cabling**

This section discusses how to connect to the Output BNCs of the frame, and which Output BNCs to connect monitors to for verifying inputs.

Connect your output cables to the BNCs on the **Video Output Boards** as required. Each output is identified by the **Slot** the board is in, and the **Number (1** to **16** inclusive) at the top left of BNC (**Figure 3.16**). For example, if you connect a cable to the BNC numbered **5** on the **Video Output Board** in **Slot K**, this input will be identified as **BNC K05**.



**Important** — All cables must be run in accordance with good engineering practices. Ensure that there is sufficient room for the cable and that enough slack is left in the cable run to permit long, gentle bends. Always install cables so that they will not be subjected to physical abuse.



**Operating Tip** — A Video Output Worksheet is provided to assist you in keeping track of which sources have been connected to which BNCs, and how those BNCs need to be set up. Refer to the section "Video Output Worksheet" on page Eng 21-9 for a copy of this worksheet.

The Video Output Board Slots for each frame are as follows:

- Octane/QMD-X Slots I, J, and K
- MD-X Slots I, J, and K
- QMD Slot B, and E (Slot E supports either a Video Input Board with 16 inputs or Video Output Board with 8 outputs.)
- MD Slot B

#### For More Information...

• on setting up video input signals, refer to the section "**Configuring Video Outputs**" on page Eng 8-2.



Figure 3.16 Video Output Boards on the Frame (QMD Shown)

**Note** — The Vision switcher passes all embedded audio and ancillary data signals, including "closed captioning" that are present on the background video. The individual MLE program outputs each have the ancillary data associated with the background video for that MLE.

# **Default Output Mapping**

The Vision switcher is shipped with a factory default mapping for outputs. Like the input mapping, the output mapping has the Output BNCs configured to certain outputs from the factory. How the outputs are mapped depends on the options installed on your switcher.

The following output sources are default mapped from the factory:

- Program:
  - > Octane/QMD-X The main switcher program output is mapped to K01 by default.
  - **MD-X** The main switcher program output is mapped to **K01** by default.
  - **QMD** The main switcher program output is mapped to **B01** by default.
  - > MD The main switcher program output is mapped to **B01** by default.
- Preview:
  - > Octane/QMD-X The main switcher preview output is mapped to K02 by default.
  - MD-X The main switcher preview output is mapped to **K02** by default.
  - > QMD The main switcher preview output is mapped to **B02** by default.
  - MD The main switcher preview output is mapped to **B02** by default.

**Note** — If you have a half MLE switcher (a **Vision 2.5 QMD-X** for example), or you have the MultiDSK<sup>TM</sup> option installed, the main switcher program and preview are locked to specific Output BNCs. Refer to the section "**Mix/DSK**" on page Eng 8-17 for more information on the default mapping for the half MLE switchers.

• Aux — The Aux outputs are mapped to the remaining Output BNCs in order.

### **Monitor Connections**

Virtually any Output BNC of the switcher can be assigned as your program or preview output; however, if you have the Mix/DSK or MultiDSK<sup>TM</sup> options installed, these outputs are locked to specific Output BNCs. In order to verify the functionality of the switcher and the input video sources, connect a monitor to the Output BNC that is default mapped to.



**Important** — All cables must be run in accordance with good engineering practices. Ensure that there is sufficient room for the cable and that enough slack is left in the cable run to permit long, gentle bends. Always install cables so that they will not be subjected to physical abuse.

If you are using a serial digital monitor, connection is direct. If you are using an analog monitor, one of three D-A converters is required:

- Serial Digital to NTSC
- Serial Digital to PAL
- Serial Digital to Analog Component

For more information on the full line of Ross Video conversion equipment, contact your sales representative or Ross Video Limited.

#### For More Information ...

- on assigning output sources to individual BNCs, refer to the section "Configuring Video Outputs" on page Eng 8-2.
- on Output BNCs that are locked on the half MLE switchers, refer to the section "**Mix/DSK**" on page Eng 8-17.
- on Output BNCs that are locked with the MultiDSK option, refer to the section "**MultiDSK**" on page Eng 8-19.
- on Output BNCs that are locked with the AuxKey<sup>™</sup> option, refer to the section "AuxKeys" on page Eng 8-22.

# **Button Inserts**

This section discusses how to install an insert film into a button on the Vision control panel. Installing an insert film into a button allows you to name specific crosspoint or custom control buttons, or to replace the default button names with those of a different language.

### **Button Insert Films**

A number of commonly used alternative insert films are provided with each Vision switcher. These insert films will have to be cut out from the sheet with a sharp knife or razor and inserted into the desired button.

If you would like custom inserts for your switcher, or need a replacement sheet of alternative or default inserts, contact your Ross Video sales representative for ordering information.



**Important** — Using insert films that do not meet the recommended criteria may damage the button cap and diffuser.

If you would like to create your own insert films, they must meet the following criteria:

- All inserts must be created on a 0.1575 inch (4 millimetre) polyester film.
- All inserts must be created using a screen printing process.
- All inserts must be created using an epoxy based ink.
- All inserts must be cut the dimensions indicated (Figure 3.17).



Figure 3.17 Control Panel Button Insert Film Sizes

- The text on the insert film should fit within the white area in the center of the film (**Figure 3.17**) to be visible through the cap.
- The insert films must cut with **0.020** inch (**0.50** millimetre) rounded corners. This is to allow the insert films to easily fit into the cap.

# **Installing Control Panel Button Inserts**

Use the following procedure to install an insert film into a control panel button:

1. Remove the **Cap Assembly** from the **Switch Assembly** by grasping it firmly and pulling directly away from the control panel surface (**Figure 3.18**).



Figure 3.18 Removing Cap Assembly

2. Remove the Lens from the Diffuser by using your fingernail, or common end micro screwdriver, to pry the two apart (Figure 3.19).



Figure 3.19 Removing Lens from Diffuser

**3.** Place the **Insert Film** into the **Lens** so that the readable side is facing up. The notches on the sides of the **Lens** must be at the sides of the text on the **Insert Film**, and not on the top or bottom (**Figure 3.20**).





- **4.** Aligning the notches on the sides of the **Lens** and **Diffuser**, press the **Lens** and **Diffuser** together until they click together (**Figure 3.20**).
- 5. Aligning the notches on the sides of the **Cap Assembly** to the tabs on the side of the **Switch Assembly**, press **Cap Assembly** down onto the **Switch Assembly** with a rolling motion until they click together (**Figure 3.21**).



Figure 3.21 Re-Installing the Cap Assembly

This completes the procedure for installing an insert film into a control panel button.

# **Power Supply Connections**

Both the Vision control panel and frame have removable power supplies that connect to mains power to provide the operational power for the switcher. This section describes how to connect the power supplies to the AC outlet.

 $\bigcirc$ 

**Note** — Refer to the section "**Important Regulatory and Safety Notices to Service Personnel**", at the beginning of this manual, for correct line cord information.

# **Frame Power Connection**

The frame supports a number of power supplies to provide an N+1 or N+2 redundant power option. This allows one, or two, power supplies to be removed from the frame without interrupting the operation of the switcher. The N+2 option also allows you to power the switcher from 2 separate circuits, so that if one circuit goes down, the two power supplies connected to the other circuit will not be affected.



**Warning Hazardous Voltage** — This apparatus, when equipped with multiple power supplies, can generate high leakage currents. To reduce the risk of electric shock, ensure that each individual supply cord is connected to its own separate branch circuit with an earth connection.

In order to properly complete this procedure you need the following cables:

• **Power Cable** — One power cable per power supply is required.

Use the following procedure to connect power to the frame:

- 1. Ensure that all power supplies are properly installed and turned **OFF**. Refer to the section "**Powering Down the Switcher**" on page Eng 4-3 for more information on the location of the power switches.
- 2. Connect and secure a power cable into the **PS1** port at the back of the frame.
- **3.** Connect and secure a power cable into the remaining **PS** ports at the back of the frame. Ensure that there is a power supply installed in each slot that you are connecting the power cord to.
- 4. Connect each power cable into the appropriate AC outlet.

**Note** — Refer to the section "**Important Regulatory and Safety Notices to Service Personnel**", at the beginning of this manual, for correct line cord information.

This completes the procedure for connecting power to the frame.

#### For More Information...

- on installing a frame power supply, refer to the section "**Frame Power Supply**" on page Eng 18-11.
- on the power consumption of the frame, refer to the section "**Power Consumption Frame**" on page Eng 20-4.

Vision Engineering Manual (v12.0 MD)

# **Control Panel Power Connection**

The Vision control panel can have redundant power, providing an N+1 power source, allowing the failure of a power supply to not interrupt the operation of the switcher.

**Note** — A **Power Cord Retaining Clip** is provided with your installation kit to prevent the power cord from accidentally being removed from the power supply. Refer to the documentation that came with your power cord clip for installation information.

In order to properly complete this procedure you need the following cables:

• **Power Cable** — One power cable per power supply is required.

Use the following procedure to connect power to the control panel:

- 1. Ensure that the control panel is turned **OFF**. Refer to the section "**Powering Down the Switcher**" on page Eng 4-3 for more information on the location of the power switches.
- 2. Connect a power cable into each of the AC ports at the back of the control panel. If you do not have the redundant power option, only one power supply and AC port is present.
- 3. Connect each power cable into the appropriate AC outlet.

This completes the procedure for connecting power to the control panel.

#### For More Information...

• on the power consumption of the control panel, refer to the section "**Power Consumption – Control Panel**" on page Eng 20-3.

### **Touchscreen Display Power Connection**

The Touchscreen Display for the Vision control panel has an independent primary power supply, and optional redundant power supply. These external brick power supplies plug into the **PS1** and **PS2** ports on the back of the Touchscreen Display.

In order to properly complete this procedure you need the following equipment:

• **Power Supply** — This GlobTek® Inc., external power supply, model TR9CE4000LLP-Y, provides power to the Touchscreen Display.

Use the following procedure to connect power to the Touchscreen Display:

1. Connect and secure the **Primary GlobTek External Power Supply** to the **PS1** port on the back of the Touchscreen Display.

**Caution** — Always connect the External Power Supply to the Touchscreen before connecting the AC mains power. Connecting the power supply to the AC mains power before connecting to the Touchscreen could damage the Touchscreen.

- **2.** If purchased, connect and secure the **Secondary GlobTek External Power Supply** to the **PS2** port on the back of the Touchscreen Display
- 3. Connect the power cables into the appropriate AC outlets.

This completes the procedure for connecting power to the Touchscreen Display.





# **Power Fail Indicators**

At the bottom of the Touchscreen Display there are two **Power Fail** indicators that show the current state of the power supplies on the control panel and the frame.

- **Panel Fail** This indicator lights to show that there is a problem with the power supplies or fans in the control panel.
- **Frame Fail** This indicator lights to show that there is a problem with the power supplies or fans in the frame. This could be a complete power failure, or the failure of a power supply.

### For More Information...

- on diagnosing the power fail indicators, refer to the section "Fail Indicators Diagnosis" on page Eng 17-10.
- on replacing a frame power supply, refer to the section "**Frame Power Supply**" on page Eng 18-11.
- on replacing a control panel power supply, refer to the section "Control Panel Power Supply" on page Eng 18-9.

### **Power Failure**

When the Vision switcher experiences a power failure, the control panel and frame react as follows:

- **Control Panel Power Loss** If the control panel loses power, the frame is unaffected and the switcher continues to pass video. When power is restored to the control panel, the settings of the control panel before power was lost are restored.
- Frame Power Loss If the frame loses power, the Frame Fail indicator lights and the splash screen is shown on the Touchscreen Display. When power is restored to the frame, the Frame Fail indicator clears and the control panel returns to the Default State.
- **Complete Power Loss** If both the control panel and the frame lose power, the switcher returns to the **Default State** when power is restored.

### For More Information...

• on the **Default State** of the switcher, refer to the section "**Resetting the Switcher**" on page Eng 4-25.

# **Initial Setup and Verification**

# In This Chapter

This chapter provides information on how to initially set up and verify the video signals for your Vision switcher.

The following topics are discussed in this chapter:

- Powering Up and Powering Down the Switcher
- Network Setup
- Network Security
- MultiPanel Setup
- Reference Connection and Setup
- Input Verification
- Functional Check
- Removing and Installing Frame Boards
- Resetting the Switcher



**ESD Susceptibility** — Static discharge can cause serious damage to sensitive semiconductor devices. Avoid handling the switcher circuit boards in high static environments such as carpeted areas and when synthetic fiber clothing is worn. Touch the frame to dissipate static charge before removing boards from the frame and exercise proper grounding precautions when working on circuit boards.

# **Powering Up and Powering Down the Switcher**

This section describes how to power up and power down the control panel and the frame.

# **Powering Up the Switcher**

This procedure shows you how to properly power up the control panel and frame of your Vision switcher.

**Note** — The control panel will not start up properly if there is a USB flash drive in the USB port on the control panel. You must remove the USB flash drive from the USB port on the control panel before powering the control panel up.

Use the following procedure to power up the switcher:

- 1. Lift up on the control panel lid to gain access to the control panel tub.
- 2. Toggle the **Primary** and, if installed, **Secondary AC Power** switches for the control panel to **ON**. The power switches are located inside the control panel tub (**Figure 4.1**).



Figure 4.1 Power Switches Inside the Control Panel Tub

- **3.** Press the **Control Panel CPU Module Power Switch**. The control panel starts to power up.
- **4.** Close the control panel lid.
- **5.** Remove the door from the frame. Refer to the section "**Opening and Closing the Frame Door**" on page Eng 3-3 for more information.
- Find the Frame Power Supplies located on the right hand side, inside the frame (Figure 4.2). The yellow Standby indicator should be lit, indicating that AC power is connected to the power supply, but the power supply is not turned on.



Figure 4.2 The Frame Power Supplies are Located on the Right Side of the Frame (QMD Shown)

- **7.** Power on the frame as follows:
  - Octane/QMD-X/MD-X Toggle the Power switch on each Power Supply to ON. Find the Main Power switch located on the Cooling Fan Card on the left side of the frame, and toggle it to ON.
  - QMD/MD Toggle the Power switch on each Power Supply to ON. The yellow Standby indicator should clear and the green Power indicator is lit.

 $\bigcirc$ 

**Note** — If the green Power indicators on all power supplies are not lit, refer to the section **"Frame Power Supply**" on page Eng 18-11 for information on diagnosing a power supply.

- **8.** Check that the green **Status** indicators on the **Cooling Fan Board**, on the left side of the frame, come on, indicating that all the cooling fans are operating. If the green **Status** indicators do not come on, Refer to the section "**Frame Fan Failure**" on page Eng 18-8 for information on replacing a cooling fan.
- **9.** Check that the blue **Heartbeat** indicator on the front of the boards installed in the frame come on and start flashing. It may take a few seconds for all the boards to start up. If the **Heartbeat** indicator on a board does not start up after **5** minutes, remove the board and re-install it.
- **10.** Install the door back on the frame.
- 11. On the control panel, the Main Menus is shown on the Touchscreen Display.

This completes the procedure for powering up the switcher.

# **Powering Down the Switcher**

This procedure shows you how to properly power down your Vision switcher by placing the Frame CPU Board into a hibernation mode. In this mode, it is safe to turn off all your power supplies.



**Note** — Only the **Master Panel** can perform a system shutdown. The **System Shutdown Menu** is not accessible from the Satellite Panels.

Use the following procedure to power down the switcher:

- 1. Navigate to the System Shutdown Menu as follows:
  - Press HOME ⇒ More ⇒ System Shutdown.

system shuta	own	44 Back	WTormard	Copy Up	\$3 Swap	

System Shutdown Menu

2. Press **Shut Down** on the **System Shutdown Menu**. The system prompts you to confirm the shutdown. Once confirmed, the switcher powers down.

**Warning Hazardous Voltage** — Even though the switcher has been shut down, the power supplies are still active until they have been physically switched off.

- **3.** Open the front door of the frame. Refer to the section "**Opening and Closing the Frame Door**" on page Eng 3-3 for more information.
- 4. Confirm that the **System Status** indicators on the left side of the frame are flashing **Green**, indicating that it is safe to turn the power off.
- **5.** Power off the frame as follows:
  - Octane/QMD-X/MD-X
    - > Locate the **Main Power** switch on the **Cooling Fan Carrier** on the left side of the frame and toggle it to **OFF**.
    - > Toggle the **Power** switch on each **Power Supply** to **OFF**.
  - QMD/MD
    - > Locate the **Power Supplies** on the right side of the frame and toggle the **Power** switch on each one to **OFF**.
- **6.** Wait about 6 seconds for the system to discharge any residual power. The Status indicators will go out.
- 7. Lift up on the control panel lid to gain access to the control panel tub.
- **8.** Toggle the **Primary** and, if installed, **Secondary AC Power** switches for the control panel to **OFF**. The power switches are located inside the control panel tub (**Figure 4.1**).
- **9.** Close the control panel lid.

This completes the procedure for powering down the switcher.

#### For More Information...

- on using the menu system of the switcher, refer to the section "Menu System Basics" on page Eng 5-4.
- on the control panel power supplies, refer to the section "Control Panel Power Supply" on page Eng 18-9.
- on the frame power supplies, refer to the section "**Frame Power Supply**" on page Eng 18-11.

# **Network Setup**

This section provides instructions for configuring the network setup for your Vision switcher, including the frame and control panel. This allows proper communication between the control panel(s) and the frame, as well as any Ethernet based external devices on the same sub-network. Software upgrades can also be performed over a network by connecting to the web interface of the frame.

If the frame is using the default network settings, the control panel will automatically detect the frame on power up. No network setup is required. Once connected, you can change the network settings of each Vision control panel. You must restart the switcher each time you want to apply different network settings.

You can connect up to nine (9) Vision control panels to a single MD/X or Octane/QMD/X frame. In either a single panel or MultiPanel configuration, you must configure a Master Panel. Once the Master Panel is configured, up to eight (8) Satellite Panels can be configured.

**Important** — Contact your IT department before connecting the control panel or frame to your facility network to ensure that there are no conflicts. They will provide you with the network information for the frame and control panels (**Table 4.1**). Refer to the section "**Default Network Settings**" on page Eng 20-11 for the factory default network address and settings of the switcher.

Frame	I	P Addre	SS	Su	bnet Ma	ask	0	Bateway	/
LAN 1		•	-	-	•	•		•	
LAN 2 (optional)			•		•	•		•	
Panel ID									
Master Panel		•	-		•	•		•	
Satellite Panel #1			•		•	•		•	
Satellite Panel #2			•		•	•		•	
Satellite Panel #3			•		•	•		•	
Satellite Panel #4		•	•		•	•		•	
Satellite Panel #5		•	•		•	•		•	
Satellite Panel #6		•	-	-	•		-	•	
Satellite Panel #7		•	-		•			•	
Satellite Panel #8	-				•	•	-	•	

### Table 4.1 Frame and Panel Network Information

# **Frame Network Setup**

From the frame Web Interface, you set up the IP Addresses of the frame, as well as selecting the IP Addresses of all the control panels that can access the frame (**Table 4.1**). The **LAN 1** port is used to connect the Vision control panels to the frame. The **LAN 2** port can be used to connect external devices to the frame, or to a graphics suite for the uploading of stills.

Use the following procedure to configure the network settings of the frame:

- 1. On your computer, open your Web Browser and, in the address bar, enter the IP address of your frame and press Enter. The QMD/X Web Interface Splash Screen is displayed.
- 2. Enter your username and password as follows when the Login Dialog Box appears. The default Name is user and Password is password.
- 3. Click **Other...** ⇒ **Network** to display the **Network Page**. This page allows you to change the network configuration of the frame network ports, as well as enter the current IP Address of the Master Panel, and Satellite Panels.

Systemate Field	45 CON	Here and the second sec
letwork		
vis cace allows the Frame's network cor	figuration to be modified. A reboot is required after making changes.	
	Frame	
	L'ANT mercaneth	
	PAddens	
	Network Marke 199 and	
	MAC Address in a minimum of	
	LAN2 (optional)	
	P Aggest	
	Network Mask	
	MAC Address and an an an an	
	Gateway (optional)	
	Default Gateway	
	Vision Panel	
	P Address Master Panel	
	P Address Satellar 1 (2010)	
	P Address Sability 2	
	F Addres Seven 3	
	P" Address Subshield 4	
	P Address Satelite 5 1 minute	
	F Address Satelite 6	
	F* Address Satebook 7. 118 4448	
	F Address Sabalite 8	
	Charge and Ration	
-		S. S. 193
they will be an an in the second seco	ry partners for the provide. You must also control to be behavily patholes on parts. Danaf core	partial to the Ecology Ecology the Mathematic Calum-

Network Setup Page

- 4. Enter the network setup information for the LAN 1 port on the frame as follows:
  - Enter the new Frame IP address in the IP Address field for LAN 1.
  - Enter the new **Frame** network mask in the **Network Mask** field for LAN 1.
  - Enter the new **Frame** gateway in the **Gateway** field.

**Operating Tip** — To activate the LAN 2 port, enter an IP Address and Network Mask for LAN 2. The Gateway is common for both the LAN 1 and LAN 2 ports.

- **5.** Enter the IP address for the Master Panel, and each Satellite Panel, you are connecting to the frame as follows:
  - Enter the **Master Panel** IP address in the **IP Address Master Panel** field. This does not change the IP address of the Master Panel. To set the IP address of a control panel, you must set it from the panel.
  - Enter the **Satellite Panel** IP addresses in the **IP Address Satellite** *X* field for each Satellite Panel you want to use with the frame. The satellite number is the Panel ID that is set on the Satellite Panel.
- 6. Press Change and Reboot to restart the switcher and apply the new settings.

This completes the procedure for configuring the network settings of the frame. Next, you must set up the control panels with the corresponding IP address, and Panel ID.

### **Control Panel Network Setup**

To configure the network settings of the Master Panel and Satellite Panels, you must have the IP Address for both the frame that you want to connect to, and each of the control panels (**Table 4.1**). If you are not connecting any Satellite Panels to your switcher, only configure the Master Panel.

You must perform the following procedure on each control panel.

Use the following procedure to configure the network settings for the control panel(s):

- **1.** Ensure that the control panel and frame are connected to the same subnet.
- 2. Place the control panel into diagnostic mode by pressing HOME three (3) times quickly.
- 3. Navigate to the Network Setup Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ More ⇒ Network Setup.

Network Setup	44 Back	Witnessen	a catal etc.	<b>93</b> (99.00)	Panel ID: Master Par	iel C
Frame	Par IP St G	Panel IP Address: Subnet Mask: Gateway:				
The frame is responding.						
Defaults On/ <b>Off</b>			Save	Rev To C	urrent a	el Hann

Network Setup Menu

- **4.** Enter the IP address of the LAN 1 port on the frame in the **IP Address** field using the keyboard or the keypad on the **Global Memory Module**.
- 5. Enter the network setup information for the control panel as follows:
  - Enter the new **Panel** IP address in **IP Address** field using the keyboard or the keypad on the **Global Memory Module**.
  - Enter the new **Panel** subnet mask in the **Subnet Mask** field using the keyboard, or the keypad on the **Global Memory Module**.
  - Enter the new **Panel** gateway in the **Gateway** field using the keyboard, or the keypad on the **Global Memory Module**.
- 6. Use the **Panel ID** knob on the **Network Setup Menu** to select the Panel ID that corresponds to the IP Address you set from the **Network Page** from the **QMD/X Web Interface**.



**Operating Tip** — If you want to cancel the changes you have made to the network information, press **Revert To Current** on the **Network Setup Menu** to revert to the last saved network settings.

- 7. Press Save on the Network Setup Menu to store the new network setup information.
- 8. Press Yes to reboot the panel and apply the new network settings.
- 9. Repeat this procedure for each control panel you are connecting to the frame.

This completes the procedure to configure the network settings for the control panel(s). The switcher is now using the new network settings.

### For More Information...

- on powering up or down the switcher, refer to the section "**Powering Up and Powering Down the Switcher**" on page Eng 4-2.
- on setting the DIP switch to default the IP address of the frame, refer to the section "Frame CPU Board DIP Switch" on page Eng 20-11.

# **Network Security**

The Vision switcher uses a standard ethernet connection for communication between the control panel and the frame, as well as between some external devices and the switcher. Any time your switcher is connected to a public network, it is important to follow certain precautions to ensure that your switcher is not vulnerable. These precautions are as follows:

- Limit Access Anyone who can access your network could also have access to your sensitive data and equipment. Limit network access by keeping your production equipment on a separate network segment or use a firewall. Contact your IT department for more information about how your network is set up.
- Change Default Passwords Change the Web Interface password for your switcher. Refer to the section "Vision Web Interface Account" on page Eng 6-2 for more information.
- **Disable Unused Services** The Vision switcher provides access to a number of default services as listed below. These services can be disabled by **Ross Video Technical Support** if required for added security.
  - > Web Server This service is used for the Web Interface.
  - > **FTP Server** This service is used to transfer images and animations to the switcher for use with the internal Still-Stores.
  - > **WebDAV** This service is used to transfer images and animations to the switcher for use with the internal Still-Stores.
  - > Telnet Server This service is used for diagnostic and maintenance purposes.

# **MultiPanel Setup**

To set up a MultiPanel system you must configure the network settings on each of the control panels and frame, assign MLEs to each of the control panels, and then set up the video outputs for each of your Program MLEs.

Refer to the section "**Network Setup**" on page Eng 4-5 for information on setting the network configuration for a MultiPanel system.

### **MLE Assignment**

The MLE assignment sets which MLEs a specific control panel has access to, and can control. The highest number MLE assigned to a control panel is the program MLE for that control panel. This MLE is tallied for the control panel. The highest number MLE assigned to a control panel in the entire switcher is the Program MLE for the switcher. This is the MLE that has the MultiDSK, Half MLE, and Preview Overlay options.

Use the following procedure to set the MLE assignments:

- 1. Navigate to the MultiPanel Configuration Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ More ⇒ MultiPanel.

Master Panel		Satellite PGM MLE	1	Satellite 2 PGM MLE 1	5	atellite 3 PGM MLE 1	Sat	ellite 4 M MLE 1
PGM ML	FI	Satellite PGM MLE	5	Satellite 6 PGM MLE 1	5	atellite 7 PGM MLE 1	Sat	ellite 8 AM MLE 1
MLE	MLE 1	MLE 2	MLE 3	MLE 4	MLE 5	MLE 6	MLE 7	MLE 8
irtual ogram 4LE	MLE 1	MLE 2	MLE 3	MLE 4	MLE 5	MLE 6	MLE 7	MLE 8 Pgm MLE

MultiPanel Configuration Menu

- **2.** Select the **Master Panel**, or **Satellite** *X* panel, that you want to set the MLE assignment for.
- **3.** Next to **MLE Permissions**, select the MLEs that you want to assign to the control panel.
- **4.** Next to **Virtual Program MLE**, select the MLE that you want to use as the Program MLE for the control panel.

**Note** — The MLE that has the MultiDSK, Half MLE, and Preview Overlay options is indicated with **Pgm MLE** (full MLE), **Pgm Mix** (MixDSK), **Pgm Multi** (MultiDSK), or **Mix Multi** (Mix/DSK and MultiDSK).

- 5. Press HOME to display the Installation Change Confirmation Screen.
- 6. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.



- Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
- Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for setting the MLE assignments. Next, you must set up the Video Output BNCs for the Program MLEs. The Program output, and Preview output, for the switcher is locked to the highest MLE assigned in the system. If you are using different Program MLEs for different control panels, you must assign an output BNC to the **MLE X Program** and **MLE X Preview** for that MLE, where **X** is the number of your MLE.

Refer to the section "**Configuring Video Outputs**" on page Eng 8-2 for information on assigning the MLE Program and MLE Preview to an output BNC.

# **Reference Connection and Setup**

The Flexible Reference system in the Vision switcher allows you to use an Interlaced video format as the reference to operate the switcher in a video format of the same frequency. Choosing a progressive video format as a reference limits you to operating the switcher only in that **same** video format and frequency. For example, if you have a 1080i 59.94 Hz input reference you can operate the switcher in 720p 59.94 Hz, but not 1080i 50 Hz. However, if you have a 720p 59.94 Hz input reference, you can only operate the switcher in 720p 59.94 Hz. If you need to change frequencies, you can have multiple input references and switch between them as needed.

# **Reference Signal Connection**

The Vision switcher accepts either an analog Tri-Level Sync or Composite reference signal connected to the reference loop BNCs on one of the Video Input Boards on the switcher.



**Note** — If the reference loop is not connected, the loop BNC should be terminated with a 75ohm termination.

Connect the reference signal to one of the **REF** connectors on the **Video Input Board**. If an additional reference is needed, a second Video Input Board with reference must be used.

**Reference Connectors** 



Figure 4.3 Reference Connections on the Video Input Board



**Operating Tip** — Always use a stable signal that is low in jitter, and that preferably originates from a reliable analog test signal generator.

#### For More Information...

• on reference signal characteristics, refer to the section "Video Characteristics" on page Eng 20-17.

### **Compatible Video Formats**

Depending on the input reference format you use, you will only be able to operate the switcher in certain formats (Table 4.2).

Table 4.2 Compatible video Formats				
Input Reference	Usable Format			
	• 480i			
480i	• 480i 16:9			
	• 1080i 59.94 Hz*			
	• 576i			
576i	• 576i 16:9			
	• 1080i 50 Hz*			
720p 59.94 Hz	• 720p 59.94 Hz			
720p 50 Hz	• 720p 50 Hz			

Input Reference	Usable Format			
	• 480i			
1080i 59.94 Hz	• 480i 16:9			
	• 720p 59.94 Hz			
	• 1080i 59.94 Hz			
	• 576i			
1000: 50 H	• 576i 16:9			
10801 50 HZ	• 720p 50			
	• 1080i 50 Hz			
1080p 24 Hz	• 1080p 24 Hz			
1080pSF 24 Hz	• 1080pSF 24 Hz			
1080pSF 23.98 Hz	• 1080pSF 23.98 Hz			



\*Important — It is not recommended that you operate the switcher in these video formats when you are using a composite sync (480i or 576i) reference signal.

The Vision switcher allows you to use any interlaced video format to operate the switcher in any format of the same frequency; however, the use of **480i** or **576i** (Composite Sync) reference signals for High Definition (**720p** or **1080i**) video modes is not recommended. Using a composite sync reference signal for High Definition video modes results in excessive jitter on the video output of the switcher, falling outside the range specified by **SMPTE-292M**. This may result in downstream equipment being unable to properly receive these signals.

The use of composite sync reference formats is recommended for Standard Definition video modes only, and provides stable outputs with jitter performance in compliance with **SMPTE-259M** specifications.

### **Reference Setup**

Depending on the input reference, and the MLE options purchased, you can select a number of HD or SD video formats for the switcher to operate in. This is the native video format that all video manipulation is performed in by the switcher.

The current input reference format (**Reference mode**) and video format (**Video mode**) that the switcher is operating in are shown on the **Main Menu**. If the current input reference format is not present or locked, the **Reference mode** text appears red.

If you have the MLE SD option installed on one or more MLEs, those MLEs will only be able to operate in SD video formats; 480i, 576i, 480i 16:9, and 576i 16:9. The MLE MD options supports all video formats.

Use the following procedure to set the reference format of the switcher:

- 1. Navigate to the Reference Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ More ⇒ Reference.

Reference	44 Back	M Conservation	Copy Up	<b>13</b> Swap	Ref Format:	-
Committee Commit 1000 50 51					720p 50 1080i 59.94	Ô
Frames/sec: 29.97Hz					10801 50	۲
Fields/sec: 59.94Hz Scan Type: Interlaced					Input Board:	
Full Frame Resolution: 2200 x 1125 Active Video Resolution: 1920 x 1080					Board C	6
Switching Line (F1/F2): 7/569					BGard E	
Pixel Aspect Batio: 1.00						-
Pixel Aspect Ratio: 1.00					Video Format	1
Pixel Aspect Ratio: 1.00					Video Format 720p 59.94	P
Pixel Aspect Ratio: 1.00					Video Format 720p 59.94 1080i 59.94	0.0

Reference Menu

**2.** Use the **Input Board** knob on the **Reference Menu** to select the Video Input Board you have connected the reference to.

**Note** — Video Input Boards that are not installed, or do not have a reference input, appear gray and cannot be used as a reference input.

- **3.** Use the **Ref Format** knob on the **Reference Menu** to select the reference format of the input reference.
- 4. Use the Video Format knob on the Reference Menu to select the video format you want the switcher to operate in. The list of available formats will vary, depending on the format of the input reference that you selected above and the MLE MD or MLE SD option that is installed.
- **5.** Reset the video format of all Input BNCs to the video format of the switcher as follows:
  - Press **Reset Input Formats** on the **Reference Menu** to have the switcher set all Input BNCs to the same video format that the switcher is currently operating in.
- **6.** Reset the video format of all Output BNCs to the currently selected video format as follows:
  - Use the **Video Format** knob on the **Reference Menu** to select the video format that you want to set all Output BNCs to.

**Note** — When you reset all Output BNCs to the selected video format, this will include any Aux Buses that are being used for SmartConversion. Refer to the section "**Setting Up a Conversion Loop**" on page Eng 16-2 for more information.

- Press **Reset Output Formats** on the **Reference Menu** to have the switcher set all Output BNCs to the currently selected video format. You are asked to confirm the change.
- 7. Press HOME to display the Installation Change Confirmation Screen.
- 8. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.



**Important** — When you switch reference formats, you must perform a soft reset (**ALL+ALL**) in order to load the default Keyer, MLE, and dissolve rates for the format you have set.

### **Internal Reference**

The Vision switcher can generate an internal reference signal that can be used for any internally generated video signal. For example, you can use matte color, Global-Store images, or MLE-Store images with the internally generated reference signal to test the functionality of the switcher during initial setup.



**Important** — The internally generated reference signal cannot be used with external video signals. The switcher will not be able to synchronize the external video signals without an external reference.

The switcher can generate the following internal reference signals:

- 1080i 59.94
- 1080i 50
- 1080pSF 24
- 1080pSF 23.98
- 1080p 24

Refer to the section "**Compatible Video Formats**" on page Eng 4-12 for a list of video formats that the switcher can operate in using these internal reference formats.

Use the following procedure to select an internal or external reference signal:

- **1.** Navigate to the **Reference Menu** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ More ⇒ Reference.
- 2. Toggle **Reference** on the **Reference Menu** to select an Internal and External reference.
  - Int Select this option to use the internally generated reference signal.
  - **Ext** Select this option to use an external reference signal.
- 3. Press HOME to display the Installation Change Confirmation Screen.
- 4. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for selecting an internal or external reference signal.

#### For More Information...

- on working with different video formats, refer to the section "**Video Formats**" on page Eng 2-31.
- on reference signal specifications, refer to the section "Video Characteristics" on page Eng 20-17.

# **Input Verification**

The Vision switcher displays the currently assigned source for each crosspoint button on the mnemonic display above the button. For internally generated sources, such as Black or Global-Stores, the name describes the source, **BLCK** for example. For external video sources, the default name is the BNC that the crosspoint button is assigned to. For example, button **2** on the control panel is assigned to **Input BNC C01**. The name **BNC C01** is displayed above button **2**.



**Operating Tip** — Verification of video sources is best done on the **Program** (**PGM**) **Bus** of the bottom MLE. This is the bus that is fed directly out of the Program BNC. This procedure assumes that all crosspoint selections are made on this bus.

Use the following procedure to verify the video sources on your switcher:

- 1. The initial state, or reset state, of the switcher is to have **Black** selected on all buses. Black should be displayed on the monitor.
- 2. Select crosspoint button 2 on the PGM Bus. The name BNC C01 should be shown in the mnemonic display above the button.
- **3.** Refer to your **Input Worksheet** and confirm that the source you have connected to **BNC C01** is what is being displayed on the monitor.
  - If the video signal displayed on the monitor is not what you have recorded on the **Input Worksheet** for **BNC C01**, double-check the connections to the BNC to ensure that sources have not been mislabelled.
- **4.** Repeat **Steps** (**2**.) and (**3**.) for each crosspoint button on the **PGM Bus** that is mapped to a BNC. The last **4** crosspoint buttons are mapped to internal sources.
- Select Global-Store 1 on the PGM Bus. The name GS 1 is shown in the mnemonic display above the button and the Global-Store Menu is shown on the Touchscreen Display. Repeat this for the remaining global-store channels.
- **6.** Press and hold the **SHIFT** button. The mnemonics change, indicating the sources that are mapped to the crosspoint buttons on the shifted bus.
- 7. Select **Color BKGD 1** on the **PGM Bus**. The name **BKGD 1** is shown in the mnemonic display above the button and the **Matte Selection Menu** is shown on the touchscreen display.
- **8.** Repeat **Steps** (**2**.) and (**3**.) for each crosspoint button on the shifted bus that is mapped to a BNC.

This completes the procedure for verifying the video sources on your switcher. To verify sources that are not mapped to crosspoint buttons, you must map those sources to buttons and verify them that way.

#### For More Information ...

- on connecting monitors to your Output BNC, refer to the section "Monitor Connections" on page Eng 3-16.
- on setting up Input BNCs, refer to the section "**Configuring Video Inputs**" on page Eng 7-4.
- on loading Global-Store stills, refer to the section "Loading Stills" on page Ops 9-3.

# **Functional Check**

All Ross Video products undergo thorough quality control and testing before shipment. The following functional check ensures that no damage has occurred during transit, and that all boards are correctly installed.

To perform the functional check, a monitor must be connected to at least one of the outputs. Refer to the section "**Monitor Connections**" on page Eng 3-16 for information on how to connect a temporarily monitor for the verification of sources.



**Operating Tip** — Verification of video sources is best done on the **Program** (**PGM**) **Bus** of the highest number MLE. This procedure assumes that all crosspoint selections are made on this bus.

Use the following procedure to perform a functional check of your switcher:

- **1.** Perform a full software reset. Refer to the section "**Resetting the Switcher**" on page Eng 4-25 for more information on performing a software reset.
- **2.** Select a crosspoint button on the **PGM Bus**. This video source appears on the **Program** monitor.
- **3.** Select a different crosspoint button on the **PST Bus**. This video source appears on the **Preview** monitor.
- 4. In the Transition Module for that MLE, select Dissolve (DISS) as the transition type.
- 5. While watching the Program monitor, move the Fader in the MLE Transition Module from one limit to the other. The video on the Program monitor dissolves to the video source you selected on the PST Bus and the selected crosspoint buttons on each bus will switch, indicating that the new source is currently selected on the PGM Bus.
- 6. In the Transition Module for that MLE, select Wipe (WIPE) as the transition type.
- 7. While watching the **Program** monitor, move the **Fader** in the **MLE Transition Module** from one limit to the other. The video on the **Program** monitor wipes to the video source you selected on the **PST Bus** and the selected crosspoint buttons on each bus switch, indicating that the new source is currently selected on the **PGM Bus**.
- **8.** While watching the **Program** monitor, select different crosspoint buttons on the **PGM Bus**, ensuring that the cuts are taking place.
- **9.** If your control panel has multiple MLEs, re-enter one MLE into the PGM/PST MLE by pressing the re-entry button on the crosspoint bus. Refer to the section "**Default Input Mapping**" on page Eng 3-13 for more information on the location of the re-entry buttons.

This completes the procedure for performing a functional check of your switcher. If you experienced problems with this test, ensure that the buttons and faders are working properly, or check that the reference connections for the switcher are properly set up.

#### For More Information...

- on diagnosing problems with faders, or buttons refer to the section "Control Panel Diagnostic Tools" on page Eng 17-18.
- on checking the reference settings, refer to the section "**Reference Connection and Setup**" on page Eng 4-12.

# **Removing and Installing Frame Boards**

The frame comes standard with all the circuit boards already installed. If daughter cards or boards need to be installed, or replaced, you will have to either remove and install, or install the new boards into the frame.

When a new board is installed, the switcher checks the current version of software on the board and tries to upgrade it to the current version of the switcher. If the software on the board is the same as the software on the switcher, there is no change. If the board has a software version that is different than the version on the switcher, the switcher will upgrade the board to the same version as the switcher. For this reason it is important that you upgrade your switcher to the latest version of Vision software prior to installing a new board into the frame.

If you are installing one of the following options, refer to the documentation that came with your hardware for detailed instructions on this option:

- Squeeze & Tease MD
- Squeeze & Tease WARP
- XFX Board (Dual Border Generator and MLE-Store)

### For More Information...

- on upgrading the switcher, refer to the section "Software Upgrade" on page Eng 6-3.
- on removing or installing a control panel module, refer to the section "**Replacing a Control Panel Module**" on page Eng 18-18.

# **Frame Board Locations**

The number and position of the boards in the frame depends on the number of MLEs, Squeeze & Tease resources, video inputs and outputs you require. These boards must be installed in the proper slots in order to ensure proper switcher operation.

### **Front Frame Boards**

The front of the frame is where most of the video processing boards are located. The location and number of boards that are installed in the frame depends on the number of MLEs, and Squeeze & Tease DVE channels you require per MLE-pair. Refer to the following table (**Table 4.3**), and the illustrations of the Octane/QMD-X/MD-X (**Figure 4.4**) and QMD/MD (**Figure 4.5**) frames for information on which slot each front frame board should be installed in.

Slot	Octane/QMD-X	MD-X	QMD	MD
Slot 0	Fan Board <sup>a</sup>	Fan Board	Fan Board	Fan Board
Slot 1			Video Processor Board (MLE 1&2 or Multi-Viewer 4&3)	Video Processor Board (All MLEs)
Slot 2	Video Processor Board (MLE 7&8 <sup>b</sup> or Multi-Viewer 2&1)		Squeeze & Tease Carrier (All MLEs)	Squeeze & Tease Carrier (All MLEs)
Slot 3	Squeeze & Tease Carrier (MLE 5,6,7,8) <sup>c</sup>	Squeeze & Tease Carrier (MLE 1&2)	Video Processor Board (MLE 3&4 or Multi-Viewer 2&1)	
Slot 4	Video Processor Board (MLE 5&6 <sup>b</sup> or Multi-Viewer 4&3)	Video Processor Board (MLE 1&2)		
Slot 5	Crosspoint Board	Crosspoint Board		
Slot 6	Squeeze & Tease Carrier (MLE 3&4) <sup>c</sup>			
Slot 7	Video Processor Board (MLE 3&4 <sup>b</sup> or Multi-Viewer 6&5)			
Slot 8	Squeeze & Tease Carrier (MLE 1&2) <sup>c</sup>	Squeeze & Tease Carrier (MLE 3&4)		
Slot 9	Video Processor Board (MLE 1&2 <sup>b</sup> or Multi-Viewer 8&7)	Video Processor Board (MLE 3&4)		

### Table 4.3 Front Frame Boards

a. Iss.3 or higher only

b. Iss.1, Rev.P or higher only

c. WARP Cards of Iss.1, Rev.D or higher only



Figure 4.4 Board Slots in the Front of the Frame (Octane/QMD-X/MD-X)



Figure 4.5 Board Slots in the Front of the Frame (QMD/MD)

### **Rear Frame Boards**

The rear of the frame is where input and output BNCs boards are located. The number of boards that are installed in the frame depends on the number of inputs and outputs you require. Refer to the following table (**Table 4.4**), and the illustrations of the QMD-X/MD-X (**Figure 4.6**) and QMD/MD (**Figure 4.7**) frames for information on which slot each rear frame board should be installed in.

Slot	Octane/QMD-X	MD-X	QMD	MD
Slot A	Frame CPU Board	Frame CPU Board	Frame CPU Board	Frame CPU Board
Slot B			Video Output Board*	Video Output Board*
Slot C	Video Input Board	Video Input Board	Video Input Board	Video Input Board
Slot D	Video Input Board	Video Input Board	Video Input Board	Video Input Board
Slot E	Video Input Board	Video Input Board	Video Input Board or Video Output Board <sup>a</sup>	
Slot F	Video Input Board	Video Input Board		
Slot G	Video Input Board	Video Input Board		
Slot H	Video Input Board	Video Input Board		
Slot I	Video Output Board	Video Output Board		
Slot J	Video Output Board	Video Output Board		
Slot K	Video Output Board*	Video Output Board*		
Slot L				
Slot M				

Table 4.4	Rear	Frame	Boards
10010 4.4	ncai	riunic	Dourus

a. Only output BNCs E9 through E16 are available on a Video Output Board installed in Slot E of the QMD frame.

\* Only a Multi-Definition Video Output Board (**4800AR-064**, **066**, or **067**) can be installed in this slot to support the MultiDSK, Mix/DSK, or AuxKeys features.
	0	0	0	Ø	0	_
l°	Ø		Slot A		Ø^	0
	Ø		Slot B		Ø.	
	0		Slot C		@-	
0	Ø		Slot D		Ø.	0
	Ø		Slot E		Ø	
<u> </u>	Ø		Slot F		Ør	
0	Ø		Slot G		ذ	0
	0		Slot H		Ø H	
	Ø		Slot I		Ø'	
0	0		Slot I		۰.	0
	<u> </u> 0		Slot K		Øĸ	
	Ø		Slot L		Ő۲	
	0		Slot M		Ø	~
	0	0	0	0	0	0

Figure 4.6 Board Slots in the Rear of the Frame (Octane/QMD-X/MD-X)

Γ		0	0	٥	0		0
Q		Ø		Slot A		Ø	A 0
		Ø		Slot B		Ø	в
	ě	Ø		Slot C		Ø	c
Ø		Ø		Slot D		Ø	• •
		Ø		Slot E		Ø	E
L		0	0	0	0		0

Figure 4.7 Board Slots in the Rear of the Frame (QMD/MD)

### **Removing and Installing Front Frame Boards**

The circuit boards at the front of the frame manipulate and route video from the **Video Input Boards** at the rear of the frame to the **Video Output Board**. These boards can be removed and replaced as needed by removing the front door of the frame and sliding the desired boards out.



**Warning Hazardous Voltage** — Hazardous voltages are present in the frame as long as any of the power supplies are connected to the AC power.

### **Removing a Front Frame Board**

Use the following procedure to remove a front frame board:

- Back up any switcher setup configurations you have. Refer to the section "Storing and Recalling Files and Setups" on page Eng 13-4 for more information on storing switcher setups.
- **2.** Open the front frame door from the frame. Refer to the section "**Opening and Closing the Frame Door**" on page Eng 3-3 for more information.
- **3.** Locate the board you want to remove from the frame. Refer to the section "**Frame Board Locations**" on page Eng 4-18 for information on where each board is located.
- **4.** If a tie wrap has been used to secure the extractor tabs on the sides of the board, remove the tie wrap.
- 5. Locate the two locking tabs at either side of the board you want to remove.



**Important** — If you remove a board that is providing a resource that is being used on-air, that resource will no longer be available when that board is removed.

- **6.** Grasp both locking tabs and rotate them towards you and out towards the outer sides of the frame. This unseats the board from the midplane.
- 7. Gently slide the board out of the frame and place it on a clean, flat, static-free surface.
- **8.** Install the frame door when you are done removing boards from the frame.

This completes the procedure for removing a front frame board.

### Installing a Front Frame Board

Use the following procedure to install a front frame board:

- 1. With the frame door removed, locate the slot into which you will be installing the circuit board. Refer to the section "**Removing a Front Frame Board**" on page Eng 4-21 to ensure proper configuration.
- **2.** Inspect the **Power Connector Blades** on the edge of the board (**Figure 4.8**) to ensure that they are not bent or damaged.





**Important** — If the blades in the power connectors are bent or damaged, contact Ross Video Technical Support. Do not attempt to install a damaged board.

**3.** Align the board with the guide rails and push the board into the slot. When the board stops sliding freely, push firmly to seat the board, and secure it with the ejector tabs.

\*

**Important** — If there is significant resistance when seating the board, remove the board from the frame and inspect the connectors for bent pins or other damage to the connectors.

- **4.** The switcher upgrades the board you have installed, if required.
- **5.** Locate the two small holes on the front edge of the board, near the extractor tabs. If you wish, you can further secure the board by threading tie wraps through these holes and fastening them around the extractor tabs.
- 6. Close the frame door when you are done installing boards into the frame.

This completes the procedure for installing a front frame board.

### **Removing and Installing Rear Frame Boards**

The circuit boards at the rear of the frame include the **Frame CPU Board**, **Video Input Boards**, and **Video Output Boards**. With the exception of the **Video Input Board** that is providing the reference signal for the switcher, and the **Frame CPU Board**, each of these boards can be removed and replaced during operation.

### **Removing a Rear Frame Board**

Use the following procedure to remove a rear frame board:

- 1. Locate the board you want to remove from the frame. Refer to the section "**Frame Board Locations**" on page Eng 4-18 for information on where each board is located.
- **2.** Label and remove any cables connected to the board so that they can be properly connected again.
- **3.** Unscrew the **Locking Screws** located at either end of the rear panel of the board you want to remove (**Figure 4.9**).



Figure 4.9 Locking Screws on Rear Frame Board

4. Gently slide the board out of the frame and place it on a clean, flat, static-free surface.

This completes the procedure for removing a rear frame board.

### Installing a Rear Frame Board

Use the following procedure to install a rear frame board:

- 1. Locate the slot for the board you want to install in the frame.
- **2.** Inspect the **Power Connector Blades** on your board (**Figure 4.10**) to ensure that they are not bent or damaged.



Figure 4.10 Power Connector Blade Inspection

**Important** — If the blades in the power connectors are bent or damaged, contact Ross Video Technical Support. Do not attempt to install a damaged board.

- **3.** Align the new board with the guide rails and slide the board into the frame until the board stops sliding freely.
- **4.** Unscrew the **Locking Screws** located at either end of the rear panel of the board, or blank spacer, above or below the new board you are installing.
- Pull the board you just unscrewed the Locking Screws from out of the frame about 1/4" (6mm).
- 6. Push firmly and evenly on each side of the new board to seat it.

 $\wedge$ 

**Important** — DO NOT use the **Locking Screws** to seat or force the board into the slot. If you have trouble seating the new board, contact Ross Video Technical Support.

- **7.** Seat the board above or below the new board, and screw in the **Locking Screws** on both boards.
- 8. The switcher upgrades the new board you have installed, if required.

**9.** Reconnect the cables to the board.

This completes the procedure for installing a rear frame board.

# **Resetting the Switcher**

If required, the Vision switcher can be reset from the control panel, returning the switcher to the default state. This can be either a full restart of the switcher, or just the control panel, or a reset of the software.

- **Full Restart** The Full Restart affects hardware and software simultaneously, physically powering down the switcher and powering it back up again. This is not the same as powering the switcher off and back on again.
- **Control Panel Restart** The Control Panel Restart restarts the only the control panel, and does not affect the frame.
- Software Reset A Software Reset affects software only, returning the switcher to the default state.

**Note** — The control panel will not start up properly if there is a USB flash drive in the USB port on the control panel. You must remove the USB flash drive from the USB port on the control panel before powering the control panel up.

### **Full Restart**

This function performs both a hardware and a software reset simultaneously. Switcher memory registers, personality registers, installation registers, and custom control registers are not affected by the reset, but all other switcher parameters (for example, the current state of the panel) are reset. **BLACK** is selected on all buses.

**Note** — Only the **Master Panel** can perform a full restart. The **System Shutdown Menu** is not accessible from the Satellite Panels.

Use the following procedure to perform a full restart of the switcher:

- 1. Navigate to the System Shutdown Menu as follows:
  - Press HOME ⇒ More ⇒ System Shutdown.

System Shuto	lown	44 Back	- W Tormani	Copy Up	13 Swap	
		1	( materia	1		1
Shut Down	Restart	Restart Global-Store	Update Panel Data	Restart Panel	Upgrade Panel	- 44 March

System Shutdown Menu

- 2. Press Restart.
- **3.** The system prompts you to confirm the restart. Once confirmed, the frame powers down and boots up again.

This completes the procedure for performing a full restart of the switcher.

### **Control Panel Restart**

This function performs a restart of the Vision control panel. The frame is not affected by the restart of the control panel.

**S** 

**Note** — Only the **Master Panel** can perform a panel restart. The **System Shutdown Menu** is not accessible from the Satellite Panels.

Use the following procedure to perform a restart of the control panel:

- 1. Navigate to the **System Shutdown Menu** as follows:
  - Press HOME ⇒ More ⇒ System Shutdown.

System Shute	lown	44 Back	)   Mitomaculi (	Copy Up	133 Swap	
Chut Dawn		Restart	Update	Restart	Upgrade	n e

System Shutdown Menu

#### 2. Press Restart Panel.

**3.** The system prompts you to confirm the restart. Once confirmed, the control panel powers down and boots up again.

This completes the procedure for performing a restart of the control panel.

### **Software Reset**

The software reset function can be performed from either the **Global Memory Module** or any individual **MLE Memory Module** on the control panel. Both methods are described below.

### **Resetting from the Global Memory Module**

From the **Global Memory Module** you can reset either all of the MLEs assigned by your control panel at once, or each one individually.

Use one of the following methods to reset MLEs from the Global Memory Module:

• All MLEs — To reset all MLEs, press and hold both the ALL button in the Recall area and the ALL button in the Store areas (Figure 4.11). Only the MLEs assigned to the control panel are reset.



Figure 4.11 Press to Reset All MLEs at Once

- Individual MLEs (1-4) To reset MLEs 1-4 individually, press and hold both the MLE # button in the Recall and the MLE # button in the Store areas (Figure 4.12). Where the # is the number of the MLE you want to reset. For example, to reset MLE 1, you would press and hold the MLE 1 buttons. You can only reset MLEs that are assigned to your control panel.
- Individual MLEs (5-8) To reset MLEs 5-8 individually, toggle +4 on and press and hold both the MLE # button in the Recall and the MLE # button in the Store areas (Figure 4.12). Where the # is the number of the MLE you want to reset. For example, to reset MLE 5, you would toggle +4 on, and press and hold the MLE 1 buttons. You can only reset MLEs that are assigned to your control panel.

**Note** — You cannot reset an individual MLE from the 1-4 MLE and the 5-8 MLE at the same time.



Figure 4.12 Press to Reset an Individual MLE

This completes the method for resetting an individual MLE, or all MLEs, from the **Global Memory System Module**.

### **Resetting from an Individual MLE**

From each individual Effects Memory Module you can reset the MLE individually.

Use the following method to reset an MLE from the Effects Memory Module:

• Press and hold both the **Recall** and **Store** buttons in the **Effects Memory Module** (**Figure 4.13**).



Figure 4.13 Press to Reset an individual MLE

This completes the method for resetting an individual MLE from the Effects Memory Module.

### **Resetting From the Positioner Module**

You can also reset the **Crosspoint Group** individually from the **Positioner Module**. This allows you to reset an MLE or an Aux bus, depending on what is assigned to the **Crosspoint Group**.

Use the following procedure to reset a Crosspoint Group from the Positioner Module:

- Press and hold the SEL button on the Crosspoint Group that you want to reset. Refer to the section "Panel Row" on page Ops 4-5 for more information on the Crosspoint Group.
- 2. Press the **CLEAR** button on the **Positioner Module**. The **Crosspoint Group** will return to the default state.

This completes the procedure for resetting an individual MLE from the Positioner Module.

### **Default State**

When you reset an MLE, Aux Bus, the entire switcher, or perform a complete restart, the switcher returns to the default state.



**Note** — If you reset only an individual MLE, only that MLE is returned to the default state. The rest of the MLEs will remain unaffected.

The default state consists of the following:

- The first crosspoint button (Black by default) is selected on the Key, Background, and Preset buses.
- All Keys are taken off-air.
- In the **Preview Bus Module**, the **PV** button is selected.
- In the **Transition Modules**, **Background** (**BKGD**) is selected as included in the next transition, and **Dissolve** (**DISS**) is selected as the transition type.

**Note** — All transition rates shown are for an Interlaced video format operating at **59.54** Hz. The switcher automatically calculates the transition rate, based on the video format it is operating in.

- In the Effects Memory Module, the following memories and rates are set:
  - > **REG:00** Memory register **00** is preset

- > **Memory0** Memory register **00** was last recalled
- > MLE:015 MLE transition rate is 15 frames
- **Key:008** Key transition rate is **8** frames
- In the Global Memory Module, the following memories and rates are set:
  - > **REG:00** Memory register **00** is preset
  - > Memory0 Memory register 00 was last recalled
  - $\rightarrow$  M:015 MLE transition rate is 15 frames
  - > **D:008** DSK transition rate is **8** frames
  - > F:20 DSK fade-to-black transition rate is 20 frames
- Auto Select is selected as the Key type in each Keyer.
- The Key 4 Mode is set to External.

# **Using the Menu System**

# In This Chapter

This chapter provides information on using the menu system, and adjusting and using the Touchscreen Display of the Vision switcher.

The following topics are discussed in this chapter:

- Touchscreen Interface
- Menu System Basics
- Quick Navigation Buttons
- Menu Skins
- Control Panel Mnemonics
- Control Panel Displays
- Using the Naming Menus
- Help Features
- Screen Captures

# **Touchscreen Interface**

Each large Vision switcher comes with an adjustable touchscreen display (**Figure 5.1**) that is used to interface with the menu system of the switcher. As you operate the switcher, the menu system follows what you are doing, displaying the appropriate menu. For example, if you select a crosspoint that has been assigned to a robotic camera that is controlled from the switcher, the **Camera Head Control Menu** for that camera is displayed. Similarly, if you fly a key, the **Squeeze & Tease Position/Crop Menu** is displayed.

**Note** — The **Touchscreen Display** is an option with the **Vision 1** and **2** control panels. If you do not have the Touchscreen Display, an LCD monitor with a DVI-D connector is required.



Figure 5.1 Touchscreen Display for the Vision Switcher

1) Control Buttons	5) Lower Display Region	9) Display Power Button
2) Control Knobs	6) Function Buttons	10) Frame Fail Indicator
3) Quick Navigation Buttons	7) Quick Navigation MORE Button	11) Panel Fail Indicator
4) Upper Display Region	8) System Power Button	12) Touchscreen Adjustment Buttons

### 1. Control Buttons

To the left of the upper and lower displays there are three buttons that allow you to navigate the menu system in the adjacent display. These buttons are as follows:

- **HOME** Press this button to display the **Main Menus**. Pressing the **HOME** button next to a display region shows the **Main Menu 1-2** in that display region. The other display region remains the same.
- UP ONE Press this button to take the display region next to the button up one level in the menu tree. For example, if you navigate to the **Disk Menu** and press UP ONE, you will return to the **Main Menus**. Pressing the UP ONE button next to a display region shows the menus from the next level up the menu tree in that display region.
- **HOLD** Press this button to lock the displays to the current menus. Pressing the **HOLD** button locks the upper display region to the current menu. The lower display region remains unlocked. It is still be possible to go down levels of the menu tree, but you are not able to go up past the level at which you pressed the **HOLD** button.

• **MORE** — This button lights to indicate when it can be used to navigate to additional pages of the current menu in the display region next to it. Pressing the **MORE** button next to a display region shows the next page of the menu in that display region. A soft **More** button is also present on the display.

### 2. Control Knobs

Next to upper and lower display regions there are three knobs that allow you to make menu selection on the adjacent display. Each knob adjusts the menu item that is next to it.

If the Punchpad functionality is available for a menu item, pressing the knob next to a menu item jumps the value to the nearest 10. If you double-press the knob, the value is defaulted.

### 3. Quick Navigation Buttons

The **Quick Navigation Buttons** allow you to navigate to commonly used menus with a single button press. Refer to the section "**Quick Navigation Buttons**" on page Eng 5-9 for more information. Additional Quick Navigation Buttons can be accessed by using the **Quick Navigation More Button**.

### 4. Upper Display Region

The Upper Display Region is one of the two areas on the touchscreen that contains a menu.

When you use the **Online Help**, the text is shown in the upper display region.

### 5. Lower Display Region

The Lower Display Region is one of the two areas on the touchscreen that contains a menu.

### 6. Function Buttons

The **6** Function Buttons allow you to select items on the Lower Display Region directly above the physical buttons. Selections on the lower display region are made using either the function buttons, or by using the touchscreen directly.

### 7. Quick Navigation More Button

The **Quick Navigation More Button** allow you to cycle through all the sets of Quick Navigation Buttons that are programmed on the switcher.

### 8. System Power Button

The **System Power** button allows you to quickly shut down the switcher without having to navigate through the menus. When pressed, you are taken to the **System Shutdown Menu**. When the switcher is powered on, the button is lit.

### 9. Touchscreen Display Power Button

This button turns the touchscreen display on or off. The touchscreen display must be on in order to view and interact with the menu system on the switcher.

### 10. Frame Fail Indicator

The **Frame Fail Indicator** lights if there is a problem with one of the power supplies or cooling fans in the frame. Refer to the section "**Fail Indicators Diagnosis**" on page Eng 17-10 for more information.

### 11. Panel Fail Indicator

The **Panel Fail Indicator** will light if there is a problem with one of the power supplies in the control panel. Refer to the section "**Fail Indicators Diagnosis**" on page Eng 17-10 for more information.

### 12. Touchscreen Adjustment Buttons

The **Touchcreen Adjustment Buttons** allow you to adjust the characteristics, such as brightness and contrast, of the touchscreen display.

# **Menu System Basics**

The menu system on the Vision switcher allows you to set up the switcher, interface with external equipment, set up and perform complex shots or sequences, and record and edit custom controls.

The menu system is set up with a branching architecture, with the **Main Menus** as the starting point of all menus. This is the menu that is displayed when you press the **HOME** button next to a display region. Pressing the **HOME** button next to a display region shows the **Main Menu 1-2** in that display region. The other display region remains the same. If you do not have the Touchscreen Display, you must use the **Home** Quick Navigation button to navigate to the **Main Menu 1-2**.

From the **Main Menus** you can move down the tree by selecting one of the other menus in the **Navigation Area**, or you can move laterally to additional pages of the menu by pressing the **More** button. Pressing the **More** button on a display region displays the **Main Menu 2-2** in that display region. The other display region remains the same.

You can tell when there are additional pages to a particular menu by the title of the menu, whether it is page **1-3** or **3-3**, and whether the **More** button is lit or not. If the **More** button is not grayed out, it indicates that there are additional pages to the current menu that are not displayed.

The touchscreen allows you to show two independent menus at once. By default, the lower region is the main auto-follow menu for the switcher, and the upper region is a user mountable menu. For example, you can mount the **Global-Store Menu** on the upper region and use the bottom region for normal operation (**Figure 5.2**). This allows you to manage the **Global-Store Menu** without having to navigate to the menu every time.



Figure 5.2 Menus

Every menu on the switcher has the same layout, with a **Menu Title**, **Main Area**, **Selection Area**, and **Navigation Area** (Figure 5.3).



Figure 5.3 Functional Areas of the Menu System

1)	Back and Forward Buttons	4)	Swap Buttons	7)	Navigation Areas
2)	Menu Titles	5)	Selection Areas		
3)	Copy Down and Copy Up Buttons	6)	Main Areas		

### 1. Back and Forward Buttons

These buttons allow you to move back and forth between menus you have already navigated to, much like the Forward and Back button on your internet browser. For example, pressing the **Back** button takes you to the last menu that was displayed in that display region. If you press the **Forward** button, you navigate back to the original menu.

### 2. Menu Titles

The menu title gives you both the title of the current menu, as well as the current page and total number of pages of the menu. For example, **Main Menu 1-2** is the first page of the **Main Menu**, and **Main Menu 2-2** is the second, and last, page of the **Main Menu**.

### 3. Copy Down and Copy Up Buttons

These buttons allow you to copy the currently displayed menu from one display region to the other.

#### 4. Swap Buttons

These buttons allow you to swap the menus currently displayed between the upper and lower display regions. The menu in the upper display region is displayed in the lower, and the menu in the lower display region is displayed in the upper.

#### 5. Selection Areas

The selection area of the menu can contain up to three items that are adjusted using the **Selection Knobs** adjacent to the display. These knobs are where the majority of the selection on the menu system are made. In some cases, these items can be adjusted using the positioner.

If the Punchpad functionality is available for a menu item, pressing the knob next to a menu item jumps the value to the nearest 10. If you double-press the knob, the value is defaulted.

If you hover the mouse pointer over a knob value, the scroll wheel on the mouse can be used to adjust the knob value. The scroll wheel acts as if you are turning the knob.

### 6. Main Areas

The main area of the menu is where the bulk of the information is displayed. This includes helpful tips about using the menu, or information on the current state of the switcher. For example, on the **Main Menu 1-2** the main area provides the software version, whether the control panel is a Master Panel or Satellite Panel, the video format that the switcher is currently operating in, the input reference format, and the status of the Remote Enables and Video Correctors.

### 7. Navigation Areas

The navigation area of the menu contains up to six items that can be either a navigation button to another menu, a toggle for a feature, or display a sub-menu that changes the items in the **Selection Area**.

- **Navigation Buttons** have a down pointing arrow next to the name, indicating that if you select this item you are taken to another menu.
- **Toggle Buttons** have a highlighted item beneath the title, indicating what is currently active. This can be an On versus Off, or one feature versus another. Turning a feature on may also activate different option for the same menu.
- Option Buttons will change the items currently available in the Selection Area, and the Main Area. For example, selecting items in the Navigation Area of the Communications Menu does not take you to another menu, but changes the items in the Selection Area.

### **Using the Punchpad**

When you select specific installation and operational menus, **Punchpad Icons** () appear next to the **Selection Knobs** (**Figure 5.4**), indicating that you can press the button next to the **Selection Knobs** to use the Punchpad to enter values.



Figure 5.4 The Punchpad can be used to make selections on the menu system

When the punchpad icon is present, you can press the button next to the **Selection Knob** to display the Punchpad (**Figure 5.5**). The Punchpad remains on screen until you close it or you navigate away from the menu. Selecting another option on the menu, or pressing **More** does not close the Punchpad.

7	8	9
4		-
	-	6
1	2	3
+/-	0	
CLR	EN	TER
1	CLR	n CLR EN

Figure 5.5 Functional Regions of the Punchpad

1) New Value Field	3) Knob Selection	5) Default and Close Buttons
2) Keypad	4) Copy/Paste Buttons	

### 1. New Value Field

This field shows the new value for the selected knob. Values can be entered into the Punchpad using the keypad on the Punchpad, a keyboard, or the keypad on the Global Memory Module. Global Memory Number Entry must be turned on to use the keypad to enter values. Refer to the section "**Personality List**" on page Eng 11-2 for information on the **Global Memory Number Entry** feature.

New values must be within the range for the selected knob. If the new value is outside the range for the knob the closest valid value is entered instead. For example, if the knob goes from **0.0%** to **100.0%**, and you enter **-0.1%** or **109.0%**, the value enter for the knob will be **0.0%** or **100.0%** respectively.

### 2. Keypad

The keypad allows you to enter new values for the selected knob. The value appears in the New Value Field. Press **ENTER** on the keypad to use the new value, or **CLR** to clear the new value without changing the current knob value.

You can close the Punchpad by pressing **ENTER** again without entering another value.

#### 3. Knob Selection

The items in the knob selection area represent the knobs on the menu and their current values. The highlighted item represents the knob that the Punchpad is currently assigned to.

Only items that can use the Punchpad to enter values appear in the knob selection area.

#### 4. Copy/Paste Buttons

The copy and paste buttons allow you to copy a single, or all, the values for the current knobs and paste them to other knobs. Knob values can be copied between knobs on the same menu, or on different menus, as long as the values are in the same format. A decimal value, such as **25.5%**, cannot be pasted into a field that requires a whole number, such as **2 Frames**.

To copy a specific knob value, select the knob you want to copy and press **Copy**. The value appears in the **Mem:** field.

To copy all knob values, press **Copy All**. The values for each knob appear in the **Mem 1:**, **Mem 2:**, and **Mem 3:** fields.

#### 5. Default and Close Buttons

The **Default** button resets the currently selected knob to the default value. All other knob values remain unchanged. This is the same functionality as double-pressing the knob.

The **Close Window** button closes the Punchpad.

### Using the Positioner with the Menu System

When you select specific installation and operational menus, **Positioner Icons** appear next to the knobs (**Figure 5.6**) on the lower display region, indicating that moving the positioner in that axis adjusts the selection for that knob. Typically, two or three icons are shown, depending upon the selected menu and function.

When these icons appear, you can adjust the selected function or parameter either with the **Selection Knobs** or with the **Positioner**.

S&T MD Position / Crop (1-2)	44 Back	)   Witchward   E buffon to acces	Copy Up	13 Swap	-	(0.000)
Channels Used: 1 / 8						K Rotation
Position	Rotation	7 6	Point of Rota	ition	3 .	(0.000) Rotation
		R Y	× -	x	69	(0.000) Z Rotation
Position Rotation	Pivot Presets	Pivot Position	Aspect On/ <b>Off</b>	Char	nel	More

Figure 5.6 The Positioner can be used to make selection on the menu system

- When the left-right positioner icon ( ) appears, you can move the **Positioner** left and right to make adjustments to this value.
- When the up-down positioner icon (1) appears, you can move the **Positioner** up and down to make adjustments to this value.
- When the circular positioner icon () appears, you can twist the **Positioner** knob clockwise and counter-clockwise to make adjustments to this value.

### For More Information...

• on using the positioner, refer to the section "Using the Positioner" on page Ops 4-37.

# **Quick Navigation Buttons**

The **Quick Navigation** buttons (**Figure 5.7**) allow you to control the display region next to the buttons, or navigate to commonly used menus with a single button press. The additional **Quick Navigation** buttons are displayed by pressing the **Next Tab** button. Refer to the section "**Touchscreen Interface**" on page Eng 5-2 for more information on the buttons on the Touchscreen Display.

The Quick Navigation buttons displays the menu in the lower display region.



Figure 5.7 Quick Navigation Buttons

The default settings for these buttons are as follows:

### **First Tab**

- Home The Home button displays the Main Menu 1-2 on the adjacent display region.
- UP One The Up One button displays the menu up one level in the menu tree.
- Hold The Hold button locks the adjacent display region to the current menu.
- **Next Tab** The **Next Tab** button toggles between the first and second tab of Quick Navigation Buttons.

### Second Tab

- Install The Install button displays the Installation Menus.
- **Pers** The **Pers** button displays the **Personality Menu**.
- **Scheme** The **Color Scheme** button displays the **Color Scheme Menus**. From these menus, you can set the color of the buttons on the control panel, as well as the skin used for the menus.
- **Diags** The **Diag** button displays the **Panel Diagnostics Menu**.
- **Help** The **Help** button displays the welcome screen for the **Online Help**. If you have already accessed the online help, this button will display the help at the same page that it was last viewed. If you hold the **Help** button, and press another button on the control panel, you can view specific help information on that button, or group of buttons. Refer to the section "**Help Features**" on page Eng 5-17 for more information on using the help.

- Aux Bus The Aux Bus button displays the Aux Bus Outputs Menus.
- **DVE** The **DVE** button displays the **S&T MD Main Menu**. From this menu you can access any of the Squeeze & Tease Menus.
- **Cust Ctrl** The **Custom Control** button displays the **Custom Control ShotBox Menus**. From these menus you can run any custom control on the switcher.

# **Menu Skins**

The appearance of the menus, including colors and icons, can be customized by using one of the skins provided with your Vision switcher.

Use the following procedure to load a skin:

- 1. Navigate to the Select Monitor Skin Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Personality ⇒ Color Scheme ⇒ More
     ⇒ More ⇒ Select Skin.



Select Monitor Skin Menu

- **2.** Use the **Monitor Skin** knob (the middle knob) on the **Select Monitor Skin Menu** to select the skin that you want to use.
- 3. Press Select This Skin on the Select Monitor Skin Menu to load the selected theme.

This completes the procedure for loading a skin.

### For More Information...

• on editing or loading color schemes for your switcher, refer to the section "Control Panel Button Color Schemes" on page Eng 11-14.

# **Control Panel Mnemonics**

The Vision control panel uses mnemonics (**Figure 5.8**) to indicate the sources or functions that are assigned to buttons. For MLE crosspoint buses, and the custom control bus, the mnemonics indicate the sources that are assigned to each button. For the Keyers, the mnemonics indicate whether a key is on-air, and the current source that is selected for that key.

Crosspoint and custom control button mnemonics can be adjusted for color, font size, and brightness, either globally, or on an individual basis.



Figure 5.8 Mnemonics on the Vision 2 (4-Keyer Shown)

**Note** — The names that are shown on the mnemonics are those that are assigned to the sources or the custom controls. Function names, such as Global-Store, cannot be changed.

Mnemonics can be adjusted in a number of ways to meet the needs of your environment. These can be global adjustments, such as the contrast, brightness or the default appearance, or they can be specific, allowing you to adjust each crosspoint and custom control mnemonic individually when you name it.

### **Default Mnemonic Appearance**

You can adjust the font size, background color and whether or not the displays will show the shifted crosspoint names for the mnemonics. These setting are the default settings that are used by the switcher for all the mnemonics. You can override individual mnemonics when you name BNCs or custom controls. These mnemonics are no longer effected by the default settings.

Use the following procedure to set the default appearance of the mnemonics:

- 1. Navigate to the Standard Mnemonics Assignment Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Personality ⇒ Standard Mnemonics.



Standard Mnemonics Assignment Menu

- 2. Set the size of the font used in the mnemonic displays as follows:
  - Use the **Font** knob on the **Standard Mnemonics Assignment Menu** to select the size of the font used. You can select between the following:

**Note** — If names have more than the maximum number of characters per line, the last characters are dropped.







Small — Select this option to use a small black font on a color background in the mnemonics. This size allows you to use 6 characters per line, with 2 lines.



Small Invert — Select this option to use a small color font on a black background in the mnemonics. This size allows you to use 6 characters per line, with 2 lines.

> **Medium** — Select this option to use a medium black font on a color background in the mnemonics. This size allows you to use **4** characters per line, with **2** lines.



> Medium Invert — Select this option to use a medium color font on a black background in the mnemonics. This size allows you to use 4 characters per line, with 2 lines.

> **None** — Select this option to have no text appear in the mnemonic displays.

- **3.** Set the color of the background or text as follows:
  - Use the **Color** knob on the **Standard Mnemonics Assignment Menu** to select the color you want to assign to the background or text. You can select between the following:



**Note** — If you are using an inverted font the color is applied to the text, otherwise it is applied to the background.

- > **Green** Select this option to use green as the display color.
- > Yellow Select this option to use yellow as the display color.
- **Orange** Select this option to use orange as the display color.
- > **None** Select this option to not use a color for the display.

4. Set the shifted crosspoint display mode for the mnemonics as follows:



**Operating Tip** — The lower label always shows the name of the input that is considered active. Therefore, the name of the unshifted crosspoint is on the lower label until you press down on the shift key; then the shifted crosspoint becomes the lower label.

• Use the **Xpt Mode** knob on the **Standard Mnemonics Assignment Menu** to select the display mode you want to use. You can select between the following:



> **1 Name** — Select this option to show only the names of the crosspoints for the selected bus.

> **2 Names** — Select this option to show the names of the crosspoints for the selected bus and the names of crosspoints when the bus is in Shift mode.



**Note** — The size of the font is overridden to **Small** or **Small Invert** to allow both names to be shown. Names over **6** characters long drop the last characters to allow the name to fit.



> The example to the left shows the 2 Names feature with the font set to invert.

This completes the procedure for setting the default appearance of the mnemonics.

### For More Information...

• on setting mnemonic color schemes, refer to the section "**Mnemonic Color Schemes**" on page Eng 11-18.

# **Control Panel Displays**

The Vision control panel uses small displays (**Figure 5.9**) to provide you with information on the current state of the switcher, or modules on the switcher. Control Panel Displays are located in each MLE bus, Memory Module, and Positioner Module.



Figure 5.9 Displays on the Vision 2 (4-Keyer Shown)

The Control Panel Displays can be adjusted in a number of ways to meet the needs of your environment. These adjustments include brightness, contrast, and overall appearance.

### For More Information...

• on setting the brightness of the displays, refer to the section "**Control Panel Display Brightness**" on page Eng 11-20.

# **Using the Naming Menus**

The Naming Menus allow you to enter, or change, the name of video sources, custom control, memories and various other elements on the switcher.

BNC Names		44 Back	M Tennant I	A 647/08	13 (1000)	Font:
! @ 1 2	# \$ % 3 4 5	6 5 7	* ( ) 8 9 0	- + B	ackspace	Small Small Invert
Q W	ERT	UY	1 0 P		1	Color: Standard
Caps Lock A	5 D	FGH	JK	L	DEL	Yellow
Shift	z x c	VB	N M <	) <u>}</u> /	BNC	(C01)
		Space	New Name (MAX 8 BNC CO1	Characters):	CB1	BNC Number
Clear	Prev Mnem Start Pos	Next Mnem Start Pos	Preset     Names	Default	Accep New N	t tame

Use the following procedure to name an item using the naming menu:

BNC Names Menu

1. Use the **BACKSPACE** button to clear the current name from the **New Name** field.

**Operating Tip** — If you want to use one of the preset names on the switcher, press **Preset Names** to display **Preset Names Menu**. You can then use the knob to highlight the name you want to use and press **Select**. The new name is shown in the **New Name** field.

- 2. Use the letters on the menu, or the keyboard, to enter the name into the New Name field.
- **3.** Use the **Font** knob to select the font size you want to use. Along with size, you can also select whether you want to name to be displayed as inverted, or reverse color.
- 4. Use the **Color** knob to select the color you want to use for the mnemonic.



**Operating Tip** — If you want the name on the mnemonic to start at a different position, use the **Next Mnem Start Pos** and **Prev Mnem Start Pos** buttons to select how much of the name is displayed.

5. Press Accept New Name to save the mnemonic settings for the name.

This completes the procedure for naming an item using the naming menu. If you do not like the new name, you can change it back to the factory default by pressing **Default**.

## **Help Features**

The Vision switcher provides a complete set of online manuals and a function-specific help system that can be viewed on the Touchscreen Display. In addition to this, an extensive pop-up system is provided to help you quickly and easily diagnose operational problems that may occur.

### **Online Manuals**

A complete set of the Vision Manuals are provided on the switcher and can be viewed on the Touchscreen Display.

Use the following procedure to access the online manuals:

1. Press **Help** on the **Quick Navigation Bar** on the Touchscreen Display. The online manuals (**Figure 5.10**) are displayed in the **Upper Display Region**.



Figure 5.10 Online Manuals

2. Press the **Help** button again to close the help.

**Operating Tip** — To save a copy of the manuals in PDF format to a USB drive, insert a USB drive into the USB port on the Vision control panel and press **HOME** ⇒ **Help** ⇒ **Copy Manuals To USB**.

This completes the procedure for accessing the online manuals.

### **Pop-up Help**

The Pop-up Help feature is designed to alert you when an illegal function is attempted. When the illegal button, or combination of buttons, is pressed, the Pop-up Help window is displayed. This window provides a brief explanation of why the operation cannot be performed, and a reference number that can be used when contacting Ross Technical support.



Example of Pop-up Help

# **Screen Captures**

The Vision switcher allows you to take screen captures of the current state of the active menu. Screen captures are stored to your removable USB flash drive.

Use the following procedure to capture the current state of the menu system:

- 1. Insert a USB flash drive into the USB port on the Vision control panel.
- **2.** Navigate to the menu you want to capture. The switcher will only capture the active, or last used, menu.
- **3.** Take a screen capture as follows:
  - Press and hold the Store ALL button on the Global Memory Module.
  - Press the FADE RATE button on the Global Memory Module.
- 4. The control panel beeps and the file is stored to the USB flash drive.

This completes the procedure for taking a screen capture.

# **Software Upgrades and Options**

# In This Chapter

This chapter provides instructions for upgrading system software, as well as verifying and installing various software options.

The following topics are discussed in this chapter:

- Vision Web Interface Account
- Software Upgrade
- System Information Overview
- Installed Options

# **Vision Web Interface Account**

A software upgrade is performed using the QMD/X Web Interface. The QMD/X Web Interface allows you to view the status of the boards, cards and modules installed on the switcher and perform upgrades of the software and hardware packages. Since most of the boards are hot-swappable, it is necessary to constantly monitor which boards, cards and modules are installed, and make sure that their software and hardware versions are current and compatible with the rest of the system. In order to use the QMD/X Web Interface, you will have to setup an account to access the frame from the local sub-net.

The current versions of Internet Explorer, Mozilla, and Netscape are supported. If you have any problems, contact Ross Video Technical Support.

Use the following procedure to change the password for your QMD/X Web Interface account:

- On your computer, open your Web Browser and, in the address bar, enter the IP address of your frame and press Enter. The QMD/X Web Interface Splash Screen is displayed.
- 2. Enter your username and password as follows when the Login Dialog Box appears. The default Name is user and Password is password.
- 3. Click Other... ⇒ Admin to display the Admin Page. This page allows you to change the username and password for the frame.

ONDX		1.10.00	
Bysten into 1	ipgrade File Seta	Other	Heb
Admin			
This page allows y	ou to change the usemany	and password for access to the Upgrade Mahager	web interface
	New username	Life	Second Second
	New password		
	Confirm password		
		Apply changes	
Copyright 1998-20	09 Ross Video Limited. All	gifts reserved.	

Admin Page

4. Change the username and password for the QMD/X Web Interface account as follows:

**Note** — Usernames and Passwords can only contain numbers, letters, dashes, underscores and periods; all other characters are invalid.

- Enter the new name for the account in the **New Username** field. This is the name that is used when logging on.
- Enter the password for the new account in the **New password** field. This is the password that is used when logging on.
- Re-enter the same password in the Confirm password field.
- Click **Apply Changes** to change the username and password. The next time you access the QMD/X Web Interface, you must use this username and password.

This completes the procedure for setting up and managing accounts.

# Software Upgrade

The software upgrade procedure allows you to upload a software upgrade package to the switcher from an external computer that is on the same sub-network as the switcher. Once uploaded, the switcher extracts the upgrade information and sends it to the boards, cards, and modules on the switcher that require upgrading. Since most of the boards are hot-swappable, it is necessary to constantly monitor which boards are plugged in, and make sure that their software and hardware versions are current and compatible with the rest of the system.



**Important** — Because the software upgrade process automatically returns the switcher to default values, it is important that you back up all switcher registers to the hard drive or USB flash drive at this point. Refer to the section "**Storing and Recalling Files and Setups**" on page Eng 13-4 for more information on storing your switcher Setups onto the hard drive or USB flash drive.

Before you can perform the upgrade, you must perform a hard reboot of the switcher to ensure that all components are in a known state. This reboot includes both the control panel and the frame, and must be performed both before and after the upgrade.



**Important** — If you are upgrading to **Vision** from **Synergy**, you must upgrade to version 6.0MD or 6.1MD with Synergy before you can upgrade to version 7.1MD or higher with Vision.

### Preparing the Switcher Before an Upgrade

Recalling the factory default settings for the switcher before the upgrade ensures that all the boards, cards, and modules on the switcher are in a known state, and are ready to accept an upgrade. However, the factory default procedure reset the reference format. You must set the reference back to the input reference that is connected to the switcher, and reboot the switcher before starting the upgrade.

Use the following procedure to prepare the switcher before performing an upgrade:

- 1. Perform a recall of all factory default settings. Refer to the section "**Recalling Factory Default Settings**" on page Eng 12-27 for information on performing a factory default.
- **2.** Power down all Satellite Panels before the upgrade.
- **3.** Set the reference format back to the input reference that is connected to the switcher. Refer to the section "**Reference Setup**" on page Eng 4-13 for information on reference setup.
- **4.** Shut down the switcher. Refer to the section "**Powering Down the Switcher**" on page Eng 4-3 for information on shutting down the switcher.
- 5. Wait at least 6 seconds for the System Status Indicators to go out.
- **6.** Power up the switcher. Refer to the section "**Powering Up the Switcher**" on page Eng 4-2 for information on powering up the switcher.

This completes the procedure for preparing the switcher before performing the upgrade. Ensure that the switcher is fully powered up before attempting to perform the upgrade.

### Performing the Upgrade

After you have performed the factory default, you must unseat the Video Processor Boards and Squeeze & Tease Carriers, upgrade the switcher core and ensure that it is working, and then propagate the upgrade to each of the boards you unseated individually.

Depending on the number of boards, cards and modules in the switcher, and the current version of software on them, it will take between **15** and **40 minutes** to complete the upgrade.

**Note** — After the Factory Default is performed, the Bus Maps and Output BNC settings have been changed to the default settings. Ensure that you can find a source button that is assigned to a valid input, and that you have a monitor connected to a default Aux Bus output of your switcher. You will need to verify that the switcher is passing video properly after the upgrade.

### **Unseating Front Frame Boards**

Refer to the following table (**Table 6.1**), and the illustrations of the Octane/QMD-X/MD-X (**Figure 6.2**) and QMD/MD (**Figure 6.1**) frames for information on which slot each front frame boards are installed in.

Slot	Octane/QMD-X	MD-X	QMD	MD
Slot 0	Fan Board	Fan Board	Fan Board	Fan Board
Slot 1			Video Processor Board (MLE 1&2)	Video Processor Board (All MLEs)
Slot 2	Video Processor Board (MLE 7&8)		Squeeze & Tease Carrier (All MLEs)	Squeeze & Tease Carrier (All MLEs)
Slot 3	Squeeze & Tease Carrier (MLE 5,6,7,8)	Squeeze & Tease Carrier (MLE 1&2)	Video Processor Board (MLE 3&4)	
Slot 4	Video Processor Board (MLE 5&6)	Video Processor Board (MLE 1&2)		
Slot 5	Crosspoint Board	Crosspoint Board		
Slot 6	Squeeze & Tease Carrier (MLE 3&4)			
Slot 7	Video Processor Board (MLE 3&4)			
Slot 8	Squeeze & Tease Carrier (MLE 1&2)	Squeeze & Tease Carrier (MLE 3&4)		
Slot 9	Video Processor Board (MLE 1&2)	Video Processor Board (MLE 3&4)		

### Table 6.1 Front Frame Boards



Figure 6.1 Board Slots in the Front of the Frame (QMD/MD)



Figure 6.2 Board Slots in the Front of the Frame (Octane/QMD-X/MD-X)



**Warning Hazardous Voltage** — Hazardous voltages are present in the frame as long as any of the power supplies are connected to the AC power.

Use the following procedure to unseat the front frame boards:

- 1. Open the frame door to gain access to the front frame boards.
- 2. Identify the Video Processor Boards and Squeeze & Tease Carriers in the frame. Only these boards need to be unseated. The Crosspoint Board in the Octane/QMD-X frame should not be unseated.
- **3.** If a tie wrap has been used to secure the extractor tabs on the sides of the board, remove the tie wraps from the required board.
- 4. Locate the two locking tabs at either side of the board you want to unseat.
- **5.** Grasp both locking tabs and rotate them towards you and out towards the outer sides of the frame. This unseats the board from the midplane.
- 6. Gently slide the board about 2 inches (5 cm) out from the front of the frame. This ensures that no pins can make contact.
- **7.** Repeat this procedure for all the **Video Processor Boards** and **Squeeze & Tease Carriers** in the frame.

This completes the procedure for unseating the front frame boards. With the boards unseated, you can upgrade the switcher core.

### **Upgrading the Switcher Core**

To upgrade the switcher core, you must log into the QMD/X Web Interface and upload the new software package.



**Important** — Ensure that the switcher is fully powered up before attempting the upgrade. When the switcher is fully powered up it is able to pass video normally. Use the following procedure to upgrade the switcher:

- 1. On your computer, open your Web Browser and, in the address bar, enter the IP address of your frame and press **Enter**. The **QMD/X Web Interface Splash Screen** is displayed.
- 2. Enter your username and password as follows when the Login Dialog Box appears. The default Name is user and Password is password.

**Operating Tip** — The **System Information Page** shows a list of all the upgradable components on the boards, cards, and modules installed in the control panel and frame. Refer to the section "**System Information Overview**" on page Eng 6-12 for more information on this page.

**3.** Click **Upgrade** to display the **Upgrade Page**. The **Upgrade Page** lists all the previous upgrade packages that were stored on the hard drive of the frame.

Systeminto Upgrade File Seta	Oter_			2	- Ho
lpgrade					
he following software builds are installed or	n the switcher.				
	Name	Version	Build Date	Additional Files	
100.00		the second of		and a second	
COMPANY OF THE OWNER			and second		
0		Select MOX Ne to uplo	od		
New_rune			Detwoo.		
	[Copyright intercent of second	Panel type: O	s1234 Cist00 @vision		
opyright 1998-2009 Rose Video Limited. A	bevreeer atrigr 5				



**Important** — Consult a Ross Video Technical Support representative before attempting to revert to a previous version of software. Reverting to a previous version of software may disable certain features or processes that were not present in that previous version of software and cause switcher Setups to not be recalled properly.

- 4. Revert to a previous software version as follows:
  - Select the software upgrade package that you want to install. The name **Vision** appears in the **Additional File** column for upgrade packages that include the Vision control panel software upgrade package.
  - Select Vision as the Panel type.
  - Click Upgrade selected version to install the software version on the switcher.
  - Wait while the switcher installs the software version. This may take a few minutes.
  - When the selected software version has been installed, the **System Information Page** is displayed.
  - Proceed to **Step** (6.) to complete the procedure.
- **5.** Upload and install a new upgrade package as follows:
  - Enter a name for the upgrade package in the **New\_Name** field. This must be unique and descriptive enough to allow you to easily identify it at a later point. Upgrade package names can only include numbers, letters, and underscores or dashes. Spaces and other symbols are not allowed.
  - Click **Browse**. A file selection dialog box is displayed.

- Locate the upgrade package file you want to upload to the switcher on your computer. The file is named **mdx**-*version*>-*build*>.tar.gz.
- Click **Open/Choose** to select the file. The file path and name appears in the **Select File to Upload** field.
- Select Vision as the Panel type.
- Click Upgrade Selected Version. The Upgrade Page is displayed.

CMOX	moss
Bysters Infu Upgrade File Beta Other	Hete
Upgrade	
thuild indexice ick received, now verifying integrity	
Built is being activated, please wat	
Please select the Vision upgrade file for upload	
Select Nix to uptract Browne	
Check if there are additional Ross supplied files to global after this one.	
Add This File Skip This File	
Copyright 1998-2009 Ross Video Limited. All rights reserved	

Upgrade Page

- Click **Browse**. A file selection dialog box is displayed.
- Locate the Vision upgrade package file you want to upload to the switcher on your computer. The file is named **vision**-<*version*>-<*build*>.tar.gz.
- Click **Open/Choose** to select the file. The file path and name will appear in the **Select File to Upload** field. If the switcher is unable to verify that the file is an upgrade package, an error message is displayed.

**Note** — The **Check if there are additional Ross supplied files to upload after this one** should only be selected if you are advised to upload an additional file by Ross Video Technical Support.

- Click Add This File to add the selected file to the software upgrade package.
- Wait while the switcher installs the software version. This may take a few minutes.
- When the software version has been installed, the **Additional Files Page** is displayed.





 $\bigcirc$ 

**Note** — If you receive a warning that the upgrade has failed because the flash is full (**Rsync** failed, is flash full?), check the remaining **Application Flash** in the Storage Capacity section of the **System Info** page. If the remaining capacity is less than 2M, you must delete a number of FlexDevice drivers to free up space for the upgrade. You can re-install the FlexDevice drivers after the upgrade. Once you have freed up the required space, try the upgrade again.

**6.** Click **Reboot Now** to perform a soft restart of the switcher. The soft restart will propagate the upgrade to all the boards, cards and modules on the switcher.



**Important** — If a message asking you to **Reboot** the control panel appears on the menus of the Touchscreen display, click Cancel. You will be rebooting the entire switcher in a later step.

- **7.** Allow the switcher to propagate the upgrade to all the boards and cards installed in the frame by waiting at least **20 minutes** before proceeding to the next step.
- 8. Wait for the System Information Page to be displayed.
  - Periodically reload/refresh the **System Information Page** until all the items listed have **Done** as their **Status**.
  - Verify that the switcher is passing video properly by selecting different crosspoints. This ensures that the upgrade has completed. If the switcher is not passing video properly, check the **System Information Page** again to ensure all items are done.
- **9.** If the message "**The software versions of the panel and frame do not match**" is shown, you need to upgrade your panel.
  - Press HOME ⇒ More ⇒ System Shutdown ⇒ Upgrade Panel.
- **10.** If the message "**PMCs need to be upgraded; please go to Panel Modules menu**" is shown, you need to upgrade your PMCs.
  - Press HOME ⇒ More ⇒ Setup ⇒ More ⇒ Panel Modules ⇒ Upgrade PMCs.

This completes the procedure for upgrading the switcher core. Next you must re-seat and upgrade the Video Processor Boards.

### **Re-seat and Upgrading the Video Processor Boards**

After the switcher core has been upgraded, you must propagate the upgrade to all of the Video Processor Boards, one at a time.

Use the following procedure to re-seat and upgrade the Video Processor Boards:

**1.** Gently push the **Video Processor Board** into the slot. When the board stops sliding freely, push firmly to seat the board, and secure it with the ejector tabs.



**Important** — If there is significant resistance when seating the board, remove the board from the frame and inspect the connectors for bent pins or other damage to the connectors (*Figure 6.3*).



Figure 6.3 Power Connector Blade Inspection



**Important** — If the blades in the power connectors are bent or damaged, contact Ross Video Technical Support. Do not attempt to install a damaged board.

2. The switcher upgrades the board you have installed. Refresh the System Information Page until all the Video Processor Board functions, and any XFX DSP Card functions, have Done as their Status.
| the state of the state   |  |        |  |        |  |
|--|--|--------|--|--------|--|
| stem Info  |  |        |  |        |  |
| alled components and their versions are as follows. Please   | a click have to update the following info  | mation |  |        |  |
| soutenate Cuaral I Instante Programs 100%  |  |        |  |        |  |
| Contraste Official opginion ricograms, room  |  |        |  |        |  |
| Component  | Function   | Siot   | Version  | Date   | Status   |
| Careford Control Based   |  |        |  |        | -  |
| Charles - Manhaer - Tanaar   |  | -      | -  | -      | -  |
| AND DESCRIPTION OF A DE |  |        |  | -      | -  |
| Careford Contract  |  | -      |  |        | -  |
| and the set  |  |        | -  |        | -  |
| and the second sec   |  |        |  |        | -  |
| Control Street   |  |        |  |        | -  |
| Contract Name  |  | -      |  |        | -  |
| Compared Stand   |  |        | 1014   |        | -  |
| Comparing Statut   |  |        |  | *      | -  |
| Department of Concept Concept  |  |        | 1010   | *      | -  |
| Garrent & Tente Cortes   |  |        | 10.04  |        | -  |
| Internet in Versel 1997 Lonis.   | COLUMN -   |        | dial and   | 100    | -  |
| Support of Suma 1987 Sorth   | CONT. Manhama  |        |  | -      | -  |
| Chartens & Search 1987 (mile   | Capit (Million   |        |  | -      | -  |
| Report of American Conf. Lands.  | - Chantenik Juget  |        | -  | -      | -  |
| And and Address of Add | And Address of Conceptual States   | - 66   | dian.  | -      | -  |
| Description of Control Manager Control.  | these faces  |        | - Martine  | -      | the second   |
| Concession in France Streep Links  | Water Surgery  |        | - and the second | -      | -  |
| Later Property Sector  | 1000   |        | -  | -      | -  |
| Salary Propagation Street.   | Contract of Contra |        | 1000   | -      | -  |
| and delivery and   | 415. Box   |        | -  | Sec.   | -  |
| and the stand in case in   | and descents   |        | -  | and in | in the second  |
| and other loans  | and second links   |        |  | -      | in the second  |
| the location of the sec  | -  | -      |  | -      | -  |
| Read South   | 100  |        |  | -      | in the second se |
| diana famina   |  |        |  | 2      | -  |

System Information Page

- **3.** Verify that the **Video Processor Board** is passing video properly by selecting different crosspoints on the MLE(s) that the **Video Processor Board** is providing. This ensures that the upgrade has completed. If the MLE is not passing video properly, check the **System Information Page** again to ensure all items are done.
- **4.** Locate the two small holes on the front edge of the **Video Processor Board**, near the extractor tabs. If you wish, you can further secure the board by threading tie wraps through these holes and fastening them around the extractor tabs.
- 5. Repeat this procedure for all remaining Video Processor Boards.

This completes the procedure for re-seating and upgrading the Video Processor Boards. Next you must re-seat any Squeeze & Tease Carriers. If you do not have any Squeeze & Tease Carriers, proceed to reboot the switcher. Refer to the section "**Rebooting the Switcher After an Upgrade**" on page Eng 6-11.

## **Re-seat and Upgrading the Squeeze & Tease Carriers**

After the Video Processor Boards have been re-seated and upgraded, you must propagate the upgrade to all of the Squeeze & Tease Carriers, one at a time. If you do not have any Squeeze & Tease Carriers, proceed to reboot the switcher. Refer to the section "**Rebooting the Switcher After an Upgrade**" on page Eng 6-11.

Use the following procedure to re-seat and upgrade the Squeeze & Tease Carriers:

1. Gently push the **Squeeze & Tease Carrier** into the slot. When the board stops sliding freely, push firmly to seat the board, and secure it with the ejector tabs.

**Important** — If there is significant resistance when seating the board, remove the board from the frame and inspect the connectors for bent pins or other damage to the connectors (**Figure 6.4**).



Figure 6.4 Power Connector Blade Inspection

**Important** — If the blades in the power connectors are bent or damaged, contact Ross Video Technical Support. Do not attempt to install a damaged board.

 The switcher upgrades the board you have installed. Refresh the System Information Page until all the Squeeze & Tease Carrier functions, and any Squeeze & Tease WARP Card functions, and Squeeze & Tease DSP Card functions, have Done as their Status.

GHURA							
Bysten into Upgrade	File Sate	Other					
System Info							
nstalled components and th	er venions are r	a tolows. Please cld	a have to update the following	o momaton.			
	- Passes - 2008						
Approximate Overal Opgrad	e Progress, 100%	• :					
	Com	ponent	Function	Siot	Version	Date	Status
1.000	Contraction of the local division of the loc		-				-
	States - Second		100	-	10.0 m		-
- march	CARL DOC TOPOL			-		-	-
10000	Contract of Contra						-
Control of	Name:		and a		-		-
1000	A STATE OF STATE OF STATE		1000		-		-
10000	Contract of the local division of the local				1004		-
1.000	and the second s				1004		244
10.000	and State						-
1000	perior liseands		-				-
(married and a second sec	and income the				10.04	*	-
Capeto -	and its Personne Care				10.04		-
ingent of the local division of the local di	and in Versel of P	Cardia:	CONT. CHILDREN		the state	100	-
Taxa	and in factors (1997)	Cardo -	CONT. Charlenge		10.04	-	- 100
Contract of Contra	and the local differ	100	Contraction of the local division of the loc			-	-
The second se	and the fermion of the local	144	- Charles - Card		-	-	-
Table 1	and in case when	a franksi	And in case		dillo.	-	-
(Insure	and its Tenants Manage	elana.	dans dans		-	date:	-
- Constanting	and in factors where	a links	Many Surgery		-	1000	-
interest of the second s	Personal Property lies and		-		1000		-
- interest	Property Street		1000		1004		-
410.0	and the state of t		475, 314			dans.	-
and the second se	and in case of		and designed		-	and in	ines.
101 A	and the second sec		diffe manage ( March )	- 40	-	-	in the second
Table 1			-		and the second s	-	-
No. of Concession, Name	Name of Concession, Name o		100	-	The loss		Same .
						-	

System Information Page

- **3.** Verify that the **Squeeze & Tease Carrier** is passing video properly by flying a key on the MLE that the Squeeze & Tease Carrier is supporting. This ensures that the upgrade has completed. If the key is not flying properly, check the **System Information Page** again to ensure all items are done.
- **4.** Locate the two small holes on the front edge of the Squeeze & Tease Carrier, near the extractor tabs. If you wish, you can further secure the board by threading tie wraps through these holes and fastening them around the extractor tabs.
- 5. Repeat this procedure for all remaining Squeeze & Tease Carriers.

This completes the procedure for re-seating and upgrading the Squeeze & Tease Carriers. Next you will power down the switcher and power it back up in order to initialize the new software on all the boards and cards in the frame.

## **Rebooting the Switcher After an Upgrade**

Rebooting the switcher after the upgrade ensures that all the boards, cards, and modules on the switcher are properly upgraded and initialized. If a board, card or module was not properly upgraded, the switcher attempts to upgrade and initialize it again with the reboot.

**Caution** — If the switcher has not finished propagating the upgrade before you proceed to shut-down the switcher, you may damage the switcher.

Use the following procedure to shutdown and restart the switcher after performing an upgrade:

- **1.** Shut down the switcher. Refer to the section "**Powering Down the Switcher**" on page Eng 4-3 for information on shutting down the switcher.
- 2. Wait at least 6 seconds for the System Status Indicators to go out.
- **3.** Power up the switcher. Refer to the section "**Powering Up the Switcher**" on page Eng 4-2 for information on powering up the switcher.
- **4.** Power on each Satellite Panel, in order, to upgrade it. Ensure that a Satellite Panel is upgraded properly before powering on the next one.

**Note** — If the message "**The software versions of the panel and frame do not match**" is shown, you need to upgrade of your panel. Press **HOME** ⇒ **More** ⇒ **System Shutdown** ⇒ **Upgrade Panel**.

This completes the procedure for restarting the switcher after an upgrade. You have now completed the upgrade procedure and should now recall any Switcher Setups you stored before the upgrade. Refer to the section "**Storing and Recalling Files and Setups**" on page Eng 13-4 for more information on recalling Setups.

With the Master Panel and frame upgraded, and operating normally, you can power on each of the Satellite Panels and allow them to upgrade as normal.



# **System Information Overview**

The **System Information Page** of the QMD/X Web Interface provides an overview of all the boards, cards, and modules in the frame and control panel of the switcher, as well as their current status. An overview of the current storage capacity of the switcher is also provided.

alled components and their versions are as tofows cosimate Overall Upgrade Progress: 100% Component	Please click <u>here</u> to update the following in	formation.			
coximate Overall Upgrade Progress. 100% Component					
Component					
Composition	Exection	filet	Maralan	Dete	Status
Company of the American State of the State o	Pancoon	0101	rereion	Case	-OLUMN
And and a second se		-		1	_
And Distant States			and the second second	-	the second second
stars-fitmer	950		and the local diversity of the local diversit	-	States -
man finanti -	19524		distant.	-	in the second
man from 1	100.00		10.00		-
Contract Contract	460	-	10.04		in the second second
Control Manual			1004		inese .
COMPANY NUMBER				*	-
Comparison States					- 100
Construction of Construction of Construction			-	*	-
Caperoni & Territo Carter				*	-
Supervised in Venue 1987 Londo.	000,0000		there are a second seco	1001	Sec.
Description in Summer 1997 (Sardie	COLUMN T			100	the second second
Chartena de Sanas Contra Carda	and the second			-	-
Department di Franze (1997) (1995)	Concession of the local division of the loca		-	-	-
Address of American American	1000		-	-	-
Supervised in County States (1978)	The local divertion			1992	-
Construction of Construction Constru-	Rept. Surma		-	-	the second second
CORRECT CONTRACTOR OF THE OWNER.			-	-	
COMPANY OF COMPANY OF COMPANY					-
and sold could	475, BOR			-	-
and the state	and the second			-	-
and the second second	and second rest.		1111		and the second s
the cardword officer.					-
Property Complete	-			100	

System Information Page

**Note** — The information listed on this page is specific to your switcher and the boards, cards, and modules you have installed, and may not appear as shown.

The **System Information Page** is divided into two regions, the **System Information Region** and the **Storage Capacity Region**.

## **System Information Region**

This region provides a list of all the functional components on the boards, cards, and modules in the control panel and frame of the switcher. Components are identified by the board, card or module they are located on, the component on that board, card or module, and the slot the board, card or module is located in. For each of these components, the current version of software that is running on the component, the date of the software build and the current status of the component, is displayed. A more detailed description of each of these columns is provided as follows:

- **Component** This column identifies every board, card, or module on the control panel or frame of the switcher, as well as all satellite control panels, that has a functional component on it that can be upgraded by the normal upgrade procedure.
- **Function** This column identifies the function component on the board, card or module installed in the switcher. These functional components can be chips, processors, or applications/processes running on the boards, cards or modules.
- **Slot** This column identifies the slot on the front or rear of the frame that a particular board is installed in. For cards, this column identifies the board that the card is installed on. Numeric slots (1, 2, 3) are located at the front of the frame, and alphabetic slots (A, B, C) are located at the rear of the frame.

- **Version** This column specifies the current software version and build number that is running on the component. If a component is running a different software version than the other components on the switcher, this may indicate a problem with that component.
- **Date** This column specifies the date of the software that is running on the component. This is not the date that the software was upgraded, but the date that the software upgrade was created by Ross Video. This date, along with the version number, helps a Ross Video Technical Support person correctly identify the software you are running.
- **Status** This column specifies the status of the component upgrade. The possible status for a component is as follows:
  - > **Pending** The component requires upgrading and is in the queue to be upgraded.
  - > **In Progress** The component is being upgraded.
  - No Status The component has not reported a status. The component could be rebooting, or there is a failure. If this message remains on for an extended period of time, contact Ross Video Technical Support.
  - Failed The component is reporting a failure to upgrade. Contact Ross Video Technical Support.
  - > **Done** The component has been upgraded successfully.

## **Storage Capacity Region**

This region provides a list of all the storage both used and available on the switcher. This includes the hard drive located on the **Frame CPU Board**, as well as the flash memory located on the other boards and cards on the switcher. A more detailed description of each of these columns is provided as follows:

- **Device** This column identifies the storage device that is being used.
- **Total Size** This column specifies the total amount of storage, used and unused, on the storage device, measured in Megabytes and Gigabytes.
- **Current Usage** This column specifies the amount of storage that is currently being used for each storage device.
- **Remaining Capacity** This column specifies the amount of storage that is remaining for each storage device.
- **Percent Used** This column specifies the percentage of total size that is currently being used for each storage device.

**Note** — If the message **Hard disk log contains errors!** is displayed, contact Ross Video Technical Support for information on diagnosing this warning.

# **Installed Options**

Several menus are available that allow you to verify all of the standard and optional boards and software present in your Vision switcher. The menus also display the serial number, allow you to install additional software options, and store and recall option codes.

#### For More Information...

• on installing control panel modules, refer to the section "**Replacing a Control Panel Module**" on page Eng 18-18.

## **Accessing the Installed Options Menus**

The following procedures enable you to navigate through the various installed options menus on the Vision switcher. The menus are provided for information only — no action can be taken. Use the information provided in the following menus to verify which options are currently installed on your frame and panel boards.



**Note** — You cannot view, install, or manage software options from a Satellite Panel. Only the Master Panel has the **Installed Options Menu 2-2**, and the **Software Options**, **Enter Serial Number**, and **Add Options** buttons.

#### **Installed Options Menu**

Use the following procedure to display the Software Options Menus:

- 1. Navigate to the Software Options Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installed Options ⇒ Software Options.



Software Options — Installed Options Menu 1-2

- 2. Use any knob to scroll the list of options.
  - The **Option** column lists all the options that are available to be installed on the switcher.
  - The **Enabled** column indicated whether that particular option has been installed (enabled) or not.

This completes the procedure for displaying the Software Options Menu.

#### Panel Boards Menu

The **Panel Boards Menu** lists specifications of the Control Panel CPU Module, the current Vision OS (Operating System) version, and the status of the power supplies in the control panel.

Use the following procedure to display information on the installed Panel Boards:

- 1. Navigate to the Panel Boards Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installed Options ⇒ Panel Boards.

Panel Board List				
Board		 	16	
SBC: 100400 (Jose/14) Jun Ohr Mennery 2021048 NE Clark, 2005.210 Men Compact Rate 3 ATC 28 PCr 19941 State 3 ATC 29 Pcr 19941 State 3 ATC 20 Pcr 1994 State 3 ATC 29 Pcr 1994 State 3 ATC	Total # 2.000m		5	Use knob 2 to scroil through the list.
Software Panel Boards	Frame Boards	Enter Seri     Number	al	Wi Mor

Panel Boards — Installed Options Menu 1-2

- **2.** Use any knob to scroll the list of options.
  - The **Board** column lists all the boards installed in the control panel, and their current status.

This completes the procedure for displaying information on control panel boards.

#### **Frame Boards Menu**

Use the following procedure to display information for all installed Frame Boards:

- 1. Navigate to the Frame Boards Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installed Options ⇒ Frame Boards.

Slot	Board	HWRev	SWRev	BuildInfo	- Dia	
8	Frame (Pic Board)	- 20	11.0.4	Erection .		Lise knob 2 to
6.1	Input Roard (Ro. Spin).	*	10.64	souther .	ĩ	scroll through
н.	ment linest	14	12.5.4	lenetad.		the list.
	tivity at lines to	144	11.04	investigation of the second se		
6	colles Processor Reard	1.0	11.04	Avenue and		
8	Sec1.007	100	12.64	Aller 1		
÷	sail per reta		11.0.4	1000		

Frame Boards — Installed Options Menu 1-2

- 2. Use any knob to scroll the list of options.
  - The **Slot** column lists each slot on the frame. The slots at the back of the frame are identified with letters, and the slots at the front of the frame are identified with numbers.
  - The **Board** column lists each circuit board by name, including any daughter cards that may be installed on that board.
  - The **HWRev** column lists the hardware revision number of each board and card in the frame.
  - The **SWRev** column lists the revision number of the software that is currently installed on each board or card in the frame.

• The **BuildInfo** column lists the build, or software compile, date of the software that is currently installed on each board or card in the frame.

This completes the procedure for displaying information on frame boards.

## **Installing Serial Numbers**

If the label "**000000**" appears at the top of the **Installed Options Menus**, a serial number is required.

Use the following procedure to install a serial number:

- 1. Navigate to the Installed Options Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installed Options.
- 2. Press Enter Serial Number on the Installed Options Menu 1-2.

Enter Serial M	Number	44 Back	) M Lourent	A COLUMN P.	93	
Frame Serial Nu Ross Encrypt Co	mber:0000000 ide:0301					
Please contact F 8 John Street Iroquois, Ontario 1-613-652-4886 techsupport@ro	loss Video at: o, Canada KOE 1K0 ssvideo.com					
Finished	Cancel					-

Enter Serial Number Menu



**Note** — The **Encrypt Code** is a random number that is generated each time the switcher is powered up. The purpose of the Encrypt Code is to prevent unauthorized installation of software options. The code remains valid until the switcher is powered down or reset. The next time the switcher is powered up, a new Encrypt Code is generated.

- 3. Call Ross Video Technical Support at the number listed on the menu.
- **4.** Call Ross Video Technical Support to obtain a serial number for your switcher. Have the following information ready when you contact Ross Video Technical Support:
  - Your Name.
  - The Name of the Facility that the switcher is installed in.
  - The Ross Encrypt Code that is listed on the menu.
- 5. You are given a numeric code by the Technical Support representative.
- 6. Enter the code using the keypad in the Global Memory Module.
- 7. Press ENTER on the keypad, or press Finished on the Enter Serial Number Menu.

This completes the procedure for entering the serial number.

## **Installing Software Options**

Use the following procedure to activate your software options (after entering a new serial number) or to install a new software option that you have just purchased:

- 1. Navigate to the Installed Options Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installed Options.
- 2. Press Software Options on the Installed Options Menu 1-2.

ption	Enabled		i	à
	1			Use knob 2 to
The Restaulter Controls	786			scroll through
the last and hereafter	786. 988			the list.
table because Control				
reter Server Cantrol	785			
ter alle a second a s	100			
and the second	100			e

Software Options — Installed Options Menu

- 3. Use the middle knob to scroll the list of options. The following options are listed:
  - **4 Keyer Option** This option allows you to use 4 keyers in each MLE of your Vision QMD/X switcher.
  - Audio Server Control This option allows you to control an audio server from the Vision switcher.
  - AuxKeys The AuxKeys<sup>™</sup> option allows you to control an Aux Mixer/Keyer from the Aux Bus. Refer to the section "AuxKeys" on page Eng 8-22 to learn how to set up your AuxKeys option.
  - Character Generator This option allows you to control an external Still Store from the Vision switcher.
  - **DVE Send and Remote CTRL** This option allows you to control an external DVE from the Vision switcher.
  - Editor Interface This option allows you to use an external editor to control your Vision switcher.
  - Extra Half MLE This option allows you to control the bottom Program/Preset MLE on a half MLE switcher. For example, a Vision 2.5 switcher. When you add an MLE to the switcher, the default settings are applied to it, including Bus Maps.
  - Large Audio Mixer This option allows you to control a large audio mixer from the Vision switcher.
  - **MD DVE Option** This option allows you to use Squeeze & Tease MD with all the video formats that the switcher supports.
  - MLE *X* MD Option This option allows you to control MLE *X* on your Vision switcher in both High Definition and Standard Definition video formats; where *X* is the number of the MLE. When you add an MLE to the switcher, the default settings are applied to it, including Bus Maps.
  - MLE X SD Option This option allows you to control MLE X on your Vision switcher in Standard Definition video formats only; where X is the number of the MLE. When you add an MLE to the switcher, the default settings are applied to it, including Bus Maps.
  - MLE *X* XFX Borders This option allows you to control the Dual Border Generator for the XFX card installed for MLE *X*, where *X* is the number of the MLE.
  - MLE *X* XFX MLE-Store This option allows you to control the MLE-Store for the XFX card installed for MLE *X*, where *X* is the number of the MLE.

- **Monitor Wall** This option allows you to control a Monitor Wall from the Vision switcher.
- MultiDSK This option allows you to add two additional Downstream Keyers for your Program/Preset MLE. Refer to the section "MultiDSK" on page Eng 8-19 for information on how to set up your MultiDSK option.
- **Multi-Viewer** *X* This option allows you to add a Multi-Viewer to the switcher, where *X* is the number of the Multi-Viewer option.
- **Peripheral Bus II** This option allows you to control a device using the Pbus interface protocol from the Vision switcher.
- **Proc Amps** This option allows you to control Processing Amplifiers for every input on the switcher.
- **RGB Color Corrector** This option allows you to control a floating input-based color corrector.
- **Robotic System** This option allows you to control a robotic camera from the Vision switcher.
- **Router** This option allows you to control a router from the Vision switcher.
- **SD DVE Option** This option allows you to use Squeeze & Tease MD with standard definition video formats.
- Serial Tally This option allows you to control a device using the serial tally protocol from the Vision switcher.
- **Small Audio Mixer** This option allows you to control a small audio mixer from the Vision switcher.
- SmartConversion This option allows you to create a conversion loop with an external Up/Down converter and have the Vision switcher automatically route the video to the converter and back. Refer to the section "SmartConversion and Up/Down Converters" on page Eng 16-1 for information on how to set up a conversion loop.
- Still Store (Aprisa) This option allows you to control an external Still Store from the Vision switcher.
- Video Server Control This option allows you to control a video server from the Vision switcher.
- VTR Remote Control This option allows you to control a VTR from the Vision switcher.
- 4. Press Add Option to display the Enter Option Number Menu.

Enter Option Number	44 Back	PP Torpanti	A GROUP NOL	93 - 9 - 9	
Frame Serial Number:0000000					
Please contact Ross Video at: 8 John Street Iroquois, Ontario, Canada KOE 1K0 1-613-652-4886 techsupport@rossvideo.com					
Enished					

Enter Option Number Menu

**5.** Call Ross Video Technical Support to obtain the software option code for the option you want to install. Have the following information ready when you contact Ross Video Technical Support:

- Your Name.
- The Name of the Facility that the switcher is installed in.
- The Serial Number of the switcher you want to install the option on.
- The Name of the Options you want to install on the switcher.
- 6. You are given a 5-digit numeric code by Ross Video Technical Support.



**Operating Tip** — Store your serial number and option codes in a safe place for future reference.

7. Enter the option code using the keypad in the Global Memory Module.



**Important** — You must enter all **5** characters, including any leading zeros. Failure to do so may prevent the option from being installed properly.

8. Press ENTER on the keypad, or press Finished on the Enter Serial Number Menu.

This completes the procedure for activating software options. The **Installed Options Menu** now indicates the options you have just installed.

## **Storing and Recalling Option Codes**

The following procedures allow you to store and recall your option codes to a storage device.



**Note** — Only the **Master Panel** can store and recall option codes to either the hard drive or USB flash drive.

## **Storing Option Codes**

Use the following procedure to store option codes:

- 1. Navigate to the **Disk Menu** as follows:
  - Press **HOME**  $\Rightarrow$  **Disk**.
- 2. Select the storage device that you want to store your files to as follows:
  - Use the **Disk Type** knob on the **Disk Menu** to select the storage device you want to store your files on. You can choose between the following:
    - Hard Drive Select this option to store the option codes to the hard drive.
    - > **USB** Select this option to store the files to a USB flash drive inserted in the USB port on the control panel.
- 3. Navigate to the Installed Options Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installed Options ⇒ More.

Option	Enabled		- Dia	
100-100-1018			U	Use knob 2 to
17% Barnally Controls	-			scroll through
Dell land and human	e CTRL Her			the list.
Auto Served Control	100			
1986 Annual Cantoni	100		- 11	
Automatic	1000		- 11	
Income Training	100			

Installed Options Menu 2-2

4. Press Backup Codes To USB/Backup Option Codes on the Installed Options Menu 2-2 to store all of your option codes.

**Important** — The **Delete Selected SW Option** and **Delete All SW Options** commands allow you to delete selected, or all, installed software options. Do not attempt to delete your options unless instructed to by Ross Video Technical Support. Ensure that you have stored your option codes before attempting to delete the options.

This completes the procedure for saving your option codes.

## **Recalling Option Codes**

In case the option codes are accidentally erased or deleted, use the following procedure to recall option codes:

- 1. Navigate to the Installed Options Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installed Options ⇒ More.
- 2. Press Recall Option Codes on the Installed Options Menu 2-2 to recall all of your option codes.

This completes the procedure for recalling your option codes.

# Video Input Configuration and Check

# In This Chapter

This chapter provides information on configuring and checking the video signals on the Input BNCs of the Vision switcher.

The following topics are discussed in this chapter:

- Naming Video Inputs
- Configuring Video Inputs
- Assigning Audio Channels to Video Inputs
- Creating Bus Maps
- Assigning Panel Bus Maps
- Assigning Tallies to Video Inputs
- Assigning GPI Outputs to Video Inputs
- Checking Keys



**Operating Tip** — A Video Input Worksheet is provided to assist you in keeping track of which inputs have been connected to the BNCs. Refer to the section "Video Input Worksheet" on page Eng 21-2 for a copy of this worksheet.

# **Naming Video Inputs**

Each video input to the Vision switcher can be given a specific name that is displayed on the mnemonic for that source. The mnemonics can be further customized for color and font size on an individual basis.

You can assign an Input BNC to a UMD Input address to provide the mnemonic names. If an Input BNC is assigned to a UMD Input address, any BNC name you enter is replaced with the UMD Input name for all the mnemonics and menus.

**Note** — If you do not have the mnemonics option installed, or want to use button insert, refer to the section "**Button Inserts**" on page Eng 3-17 for more information on installing button inserts.

Use the following procedure to name a video input:

- **1.** Navigate to the **BNC Menus** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ BNC.
- **BNC Names** 44 Back 24 a, 113 Font: Standard Small Backspace Small Invert 9 0 Color Standard Green DEL Caps Lock Yellow Mnemonic Shift N M H (CO1) - (MAX B **BNC Number** Space BNC CO1 Prev Mnem Next Mnem Preset Accept ą. Default Clear 44 Start Pos Start Pos New Name
- 2. Press BNC Names on the BNC Menu 1-3.



BNC Names Menu

**Operating Tip** — Refer to the section "Using the Naming Menus" on page Eng 5-16 for more information on using the **BNC Names Menu** to enter a name, or set up the mnemonics for the crosspoint button.

- **3.** Use the **BNC Number** knob on the **BNC Names Menu** to select the BNC you want to name. The BNC numbers correspond to physical BNCs on the rear of the frame.
- 4. Enter the new name you want to use in the New Name field.
- 5. Press Accept New Name on the BNC Names Menu to assign the name to the BNC.
- 6. Press HOME to display the Installation Change Confirmation Screen.
- 7. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for naming a video input.

#### For More Information...

- on connecting video signals to Input BNCs, refer to the section "Video Input Cabling" on page Eng 3-13.
- on setting up individual mnemonics for an Input BNC, refer to the section "Using the Naming Menus" on page Eng 5-16.

# **Configuring Video Inputs**

This section discusses how to configure the video signals that are received by the Input BNCs. This includes setting up individual Input BNCs, alphas, and auto keys using the **BNC Menus**.

## **BNC Menu Overview**

BNC (1-3)	44 Back	1 M Topsage	<ul> <li>Been well</li> </ul>	93	BNC: BNC D01 BNC D02	(D01) (D02)
Use this menu to associate a function or a device type with a BNC input.		BNC: Type: Tally: Auto Key: Video Mode:	8NC D02 (D02) Video 18 Black 1080i 59,94		BNC D03 Type: CG Video	(D03) 💌
					Video For 1080i 60 1080i 59 ( 1080i 50	rmat: 94 0
BNC Names     BNC Type     Ta	lly	Alpha	Auto Key Setup	) ( A	udio	🖏 More

BNC Menu 1-3

The **BNC Menus** provide information to assist you in configuring each of the Input BNCs. This information is contained in the status box in the center of the menu and provides the following:

- **BNC** This field indicates the currently selected Input BNC. The BNC is identified by the name that it was given, or the default name, and the identification number of the BNC. For example, the identification number **C01** indicates it is the first BNC on the **Video Input Board** installed in **Slot C**.
- **Type** This field indicates the type that the BNC is configured as. This field identifies BNCs as being connected to a device that is controlled by the switcher, such as a Robotic Camera, or that the source is an Alpha.
- **Tally** This field indicates the tally number that is assigned to the BNC.
- **Auto Key** This field indicates whether the current BNC is set up for an Auto Select Key or not. If the current BNC is set up for an Auto Select Key, this field identifies the Alpha or Video (fill) BNC, depending on whether the current BNC is the Alpha or Video (fill). If the selected BNC is not set up as an Auto Select Key, this line will not be displayed.
- Video Mode This field indicates the video format the current BNC is set to. If the video format of the current BNC is different that the format the switcher is operating in, a video format conversion may be required.

## **Assigning Input Types**

Use the following procedure to assign your input types:

- 1. Navigate to the **BNC Menus** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ BNC.
- 2. Press BNC Type on the BNC Menu 1-3.



BNC Type — BNC Menu 1-3

- **3.** Use the **BNC** knob on the **BNC Menu 1-3** to select the Input BNC that you want to configure. Input BNCs that appear gray are on Video Inputs Boards that are not installed.
- **4.** Use the **Type** knob on the **BNC Menu 1-3** to configure the current BNC. You can choose between the following:



**Important** — All Input BNC types must be assigned to **Video** or **Alpha** unless the device connected to that Input BNC is controlled by the switcher.

- Off Select this option when there is no input physically connected to the selected BNC. Selecting Off removes the input from subsequent menus.
- VTR Select this option when a VTR or Video Server, or Audio Server is connected to the selected BNC. You must have the VTR Remote Control Software Option in order to control the VTR you are connecting to the selected Input BNC. You may also need the additional Video Server Control Software Option or Audio Server Control Software, depending on the device you are connecting. Contact your Ross Video representative for information on purchasing these options.
- **Alpha** Select this option when an alpha, or key, signal is connected to the selected BNC. Devices such as Character Generators, Graphics (Paint) Systems, and Still Stores typically provide unique alpha signals.
- **Router** Select this option when a routing switcher output is connected to the selected BNC. You must have the **Routing Switcher Interface Software Option** in order to control the Router you are connecting to the selected Input BNC. Contact your Ross Video representative for information on purchasing this option.
- **Extern Still** Select this option when an external Still-Store is connected to the selected BNC. You must have the **External Still Store Software Option** in order to control the external Still-Store you are connecting to the selected Input BNC. Contact your Ross Video representative for information on purchasing this option.
- **Robotic Cam** Select this option when a robotic camera controller is connected to the selected BNC. You must have the **Robotic Camera System Interface Software Option** in order to control the Robotic Camera you are connecting to the selected Input BNC. Contact your Ross Video representative for information on purchasing this option.
- **Char Gen** Select this option when a Character Generator is connected to the selected BNC. You must have the **Character Generator Interface Software Option** installed in order to control the Character Generator you are connecting to the selected Input BNC. Contact your Ross Video representative for information on purchasing this option.

- Video This is the default option. Use this option unless the input is an alpha, or a device listed above.
- 5. Use the **Video Format** knob on the **BNC Menu 1-3** to select the format of the input video of the selected BNC.

**Note** — Assigning a **Video Format** to an **Input BNC** that is different than the native video format that the switcher is operating in, can only be used for passing non-native video formats out an Aux Bus unless you have SmartConversion installed. Refer to the section "**Setting Up a Conversion Loop**" on page Eng 16-2 for information on SmartConversion.

- 6. Press HOME to display the Installation Change Confirmation Screen.
- 7. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for assigning Input BNC types.

## **Assigning Alphas**

The Alpha, or Key, video signal is the component of an Auto Key, or Auto Select Key, that cuts the hole in the background video signal for the Video, or fill, component. This section discusses how to assign a video input as an alpha.

Use the following procedure to configure an input as an alpha:

- 1. Navigate to the BNC Menus as follows:
  - Press HOME  $\Rightarrow$  More  $\Rightarrow$  Setup  $\Rightarrow$  Installation  $\Rightarrow$  BNC.
- 2. Press BNC Type on the BNC Menu 1-3.

BNC (1-3)	44 Back	) ( PP Tops and (	- <b>3</b> (1997) (199	<b>93</b> (1997)	BNC: BNC D02 (D	02) 🕑
Use this menu to associate a function or a device type with a BNC input.		BNC: Type: Tally: Alpha: Video Mode	8NC D03 (D03) Alpha 19 Unshaped 1080i 59.94		Type: VTR Alpha Router	() () () () () () () () () () () () () (
					Video Form 1080i 60 1080i 59,94 1080i 50	at:
BNC Names  BNC Type  T	ally	Alpha	Auto Key Setup		udio	More

BNC Type — BNC Menu 1-3

- **3.** Assign an Input BNC as an alpha as follows:
  - Use the **BNC** knob on the **BNC Menu 1-3** to select the Input BNC you want to assign as a Key Alpha.
  - Use the **Type** knob on the **BNC Menu 1-3** to select **Alpha**.



**Operating Tip** — When you select **Alpha** as the **Type**, the **Auto Key** item in the **Status Box** changes to **Alpha**, indicating whether the new alpha is Shaped or Unshaped.

• Use the **Video Format** knob on the **BNC Menu 1-3** to select the format of the input video of the associated BNC.

**Note** — Assigning a **Video Format** to an **Input BNC** that is different than the native video format that the switcher is operating in, can only be used for passing non-native video formats out an Aux Bus unless the **SmartConversion**<sup>™</sup> option is used. Refer to the section "**SmartConversion and Up/Down Converters**" on page Eng 16-1 for more information.

4. Press Alpha on the BNC Menu 1-3.

BNC (1-3)	44 Back	• Formant	a carrier	<b>93</b> (1997)	Alpha: BNC D02 (D02)
Use this menu to set up the alpha modes.		BNC: Type: Tally: Alpha: Video Mode:	BNC D03 (D03) Alpha 19 Unshaped 1080i 59.94		Mode: Unshaped Shaped
BNC Names     BNC Type     T	ally	Alpha	Auto Key Setup	AL	udio 🖓 More

Alpha Setup — BNC Menu 1-3

- **5.** Define the alpha as shaped or unshaped as follows:
  - Use the **Alpha** knob on the **BNC Menu 1-3** to select the Input BNC you want to configure.
  - Use the **Mode** knob on the **BNC Menu 1-3** to select the desired Key Alpha mode. You can choose between the following:

**Note** — Select **Unshaped** if you are unsure about which mode to use. Unshaped allows the switcher to match the alpha and fill signals that the source device (such as a CG or still-store) is generating. Refer to the Operation Manual of your device for details on its specific fill and alpha output signals.

- Unshaped Select this option to have the switcher perform a multiplicative key. With an Unshaped Key, the Key Alpha cuts a hole based on the gradient values of the alpha. Shades of gray are translated into transparency levels, giving the key a soft edge. Unshaped Key alphas can also be considered true linear alphas. Key alphas are set to unshaped by default.
- Shaped Select this option to have the switcher perform an additive key. With Shaped Keys, the Key Alpha cuts a hole based on the monochrome value of the alpha. Shades of gray are translated into either white or black, giving the key a hard edge. Shaped Key alphas are sometimes used with Character Generators to cut very precise holes for the fill.
- 6. Press HOME to display the Installation Change Confirmation Screen.
- 7. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.



- Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
- Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for configuring an input as an alpha.

## **Configuring Auto Keys**

Auto Keys allow you to associate the Alpha (key) and Video (fill) signals of an Auto Select Key so that the key is automatically configured when you select the crosspoint. This association simplifies the keying process on the switcher for outputs from Character Generators or External Still Stores, that generate separate Key and Video signals. When you select a key source on the crosspoint buses, the alpha and fill are automatically selected.

Use the following procedure to configure your auto keys:

- 1. Navigate to the BNC Menus as follows:
  - Press HOME  $\Rightarrow$  More  $\Rightarrow$  Setup  $\Rightarrow$  Installation  $\Rightarrow$  BNC.
- 2. Press Auto Key Setup on the BNC Menu 1-3.



Auto Key Setup — BNC Menu 1-3



**Operating Tip** — You can associate one Global-Store, or MLE-Store, channel as the alpha for another Global-Store, or MLE-Store, channel. This means that if you load a still that has alpha information in the file, the switcher uses the associated channel to load the alpha still. Only Global-Store and Global-Store, or MLE-Store and MLE-Store, channels can be used in the auto-key.

- **3.** Assign the Input BNC with the alpha video signal to the BNC with the fill video signal as follows:
  - Use the **BNC** knob on the **BNC Menu 1-3** to select the Input BNC with the video signal that you want to use as the Fill for the Auto Key.
  - Use the **Alpha** knob on the **BNC Menu 1-3** to select the Input BNC with the video signal that you want to use as the Key Alpha for the Auto Key.



**Note** — Select **BLACK** for Input BNCs with no associated alpha. This is the default setting for all input BNCs.

- 4. Press HOME to display the Installation Change Confirmation Screen.
- 5. Accept or reject the changes you have made as follows:

- Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
- Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
- Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for configuring an Auto Key.

## **Non-Sync Detection**

The Non-Sync Detect feature allows you to disable the detection and reporting of non-synchronized video inputs. Non-synchronised video sources are either not properly timed, or use a different reference format than the one the switcher is operating in.

Use the following procedure to set the non-sync detection:

- 1. Navigate to the BNC Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ BNC ⇒ More ⇒ More.
- 2. Press N/S Detect on the BNC Menu 3-3.



N/S Detect — BNC Menu 3-3

**3.** Use the **N/S Detection** knob on the **BNC Menu 3-3** to select how you want to apply the non-sync detection. You can choose between the following:

 $\bigcirc$ 

**Note** — The **N/S Control** selection is applied across all Input BNCs. Selecting **All On** or **All Off** for any Input BNC is applied to all Input BNCs.

- **Individual** Select this option to turn the Non-Sync Detection feature On or Off for individual Input BNCs.
- All On Select this option to have all non-synchronized inputs detected.
- All Off Select this option to not have any non-synchronized inputs detected.
- 4. Turn the Non-Sync Detection feature On and Off for individual Input BNCs as follows:
  - Use the N/S Control knob on the BNC Menu 3-3 to select Individual.
  - Use the **BNC** knob on the **BNC Menu 3-3** to select the Input BNC that you want to set the Non-Sync Detection feature for.
  - Use the N/S Detect knob on the BNC Menu 3-3 to toggle this feature On or Off.
    - **OFF** Select this option to not have non-synchronized inputs detected for the selected Input BNC.

- > **ON** Select this option to have non-synchronized inputs detected for the selected Input BNC. If a non-synchronized source is selected on the crosspoint bus, the crosspoint button flashes, indicating that the source is mis-timed.
- 5. Press HOME to display the Installation Change Confirmation Screen.
- 6. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for setting the non-sync detection.

#### For More Information...

• on the non-sync indicators, refer to the section "Non-Sync Status" on page Eng 17-16.

# **Assigning Audio Channels to Video Inputs**

Audio channels are assigned to Input BNCs to follow the video signal on and off-air during transitions. This Audio-Follow-Video (AFV) process is the normal interaction of an Audio Mixer and the Vision switcher. You can alter this normal AFV operation at any time by applying an Audio Override.

You can assign up to **2** audio sources to each Input BNC. Each source can be a channel, or a group of channels.

#### For More Information ...

• on assigning audio channels to groups, refer to the section "Audio Channel Setup" on page Eng 12-22.

## Assigning Audio Channels and Groups to Input BNCs

Use the following procedure to assign audio channels, or groups, to Input BNCs:

- 1. Navigate to the BNC Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ BNC ⇒ Audio.

BNC (1-3)		44 Back	1 W Tormand (	<ul> <li>Generation</li> </ul>	93	BNC: BNC D07 (D0 BNC D08 (D0	7) 🖲 6) 🖸
Use this menu to associate audio channels with BNC inputs.		nnels	BNC: Type: Tally: Auto Key: Video Mode	BNC D08 (D08) Video 24 Black 1080i 59.94		Audio 1: Channel 7 Channel 8 Channel 9	9) 0
						Audio 2: Channel 8 Channel 9 Channel 10	• 00
- BNC Names	BNC Type	Tally	Alpha	Auto Key Setup		udio	More

Audio Setup — BNC Menu 1-3

**2.** Assign audio channels, or groups, to your Input BNCs as follows:

**Note** — The total number of audio channels that you have available to assign to the Input BNCs will depend on the **Audio Mixer Interface** option you have, and the number of audio channels your Audio Mixer supports.

• Use the **BNC** knob on the **BNC Menu 1-3** to select the Input BNC that you want to assign an audio channel to for audio follow video operation. When this video source it taken on-air, the Audio Mixer will bring up the selected audio channels.



**Note** — If you have programmed **Audio Assign Custom Controls**, the **Audio Channel** knobs on the **Audio Menu** will display the custom control that you assigned the channel to.

- Use the **Audio 1** knob on the **BNC Menu 1-3** to select an audio channel, or group, that you want to assign to the selected Input BNC.
- Use the **Audio 2** knob on the **BNC Menu 1-3** to select another audio channel, or group, that you want to assign to the selected Input BNC.
- 3. Press HOME to display the Installation Change Confirmation Screen.

- **4.** Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for assigning audio channels, or groups, to Input BNCs. Your configured Audio Mixer channels will now follow crosspoint transitions for normal AFV operation.

# **Creating Bus Maps**

The Vision switcher allows you to map any video signal to any crosspoint button on the control panel using a **Bus Map**. There are **16** editable Bus Maps available, and a single fixed, default, Bus Map, all of which can be applied to all, or select MLEs as either the primary Bus Map, or as a shifted set of sources for a bus.

In a MultiPanel configuration, all control panels share the same Bus Maps, but which Bus Maps are assigned to each MLE is specific to the panel. For example, on Satellite Panel 1 you can assign Bus Map 5 to MLE 3. On Satellite Panel 4 you can also assign Bus Map 1 to MLE 3, as long as both panels have MLE 3 assigned to them.

Each editable Bus Map must be assigned sources for each crosspoint button on the bus, and then assigned to the MLE, or bus, that you want to use it on.



**Operating Tip** — Use the **Bus Map Worksheet** to help identify the Input BNC that you want to assign to the crosspoint buttons for each Bus Map. Refer to the section "**Bus Map Worksheet**" on page Eng 21-6 for a copy of this worksheet.

## **Editing Bus Maps**

Bus Maps define the video source, or internal video signal, that is assigned to each crosspoint button on a bus.



**Operating Tip** — Unless the Bus Map you are editing is assigned to a panel row on the switcher, you will not see the changes you are making.

Use the following procedure to edit/create a bus map:

- 1. Navigate to the Edit Bus Maps Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ More ⇒ Bus Maps ⇒ Edit Map.

Edit Bus Map	s	44 Back	PP Tormant	A GROWING I	193 (CONT)	Map.	
Map: Map02						(1)Map01 (2)Map02	8
Button 1	Black					(3)Map03	e
Button 2	BKGD 1						
Button 3	BNC C02	(C02)				Button	
Button 4	BNC C03 (	(C03)				Button 1	(4)
Button 5	BNC C04	(C04)				Button 2	Ø
Button 6	BNC C05	(C05)				Button 3	
Button 7	BNC C06	(C06)					~
Button 8	BNC C07	(C07)					
Button 9	BNC C08	(C08)				Source	
Button 10	BNC C09	(09)				NONE	(3)
Button 11	BNC C10	(C10)				BKGD 1	Ø
Button 12	BNC C11	(C11)				BKGD 2	0
and a second	10.0000000						
Edit	Insert	Delete	Clear			44	Han

Edit Bus Maps Menu

- **2.** Use the **Map** knob on the **Edit Bus Maps Menu** to select the Bus Map you want to edit. The default Bus Map cannot be edited.
- **3.** Use the **Button** knob on the **Edit Bus Maps Menu** to select the crosspoint button on the bus that you want to assign a video signal to. The button lights on the program bus of all panel rows.



**Operating Tip** — Press **Insert** to insert a source at the selected button and shift the remaining sources down. Press **Delete** to delete a source at the selected button and shift the remaining sources up. Press **Clear** to remove the source from the selected button and not shift the remaining sources. **None** is selected for the cleared buttons and the last button when a source is deleted.

**4.** Use the **Source** knob on the **Edit Bus Maps Menu** to select the Input BNC, or internal video signal, that you want to assign to the selected crosspoint button. You can choose between the following:

**Note** — Input BNCs that are assigned to **OFF** on the **BNC Type Menu** do not appear in the list. If you want to assign these sources to a crosspoint button, you must assign them to a type on the **BNC Type Menu**.

- **NONE** Select this option to assign no input to the selected crosspoint button. When pressed, the button lights, but does not stay lit.
- **BKGD 1** Select this option to assign Color Background 1 to the selected crosspoint button. When selected on the crosspoint bus, the **Mattes Selection Menu** for Background Generator 1 is displayed.
- **BKGD 2** Select this option to assign Color Background 2 to the selected crosspoint button. When selected on the crosspoint bus, the **Mattes Selection Menu** for Background Generator 2 is displayed.
- **BLACK** Select this option to assign Black to the selected crosspoint button.

**Important** — You cannot select a crosspoint button assigned to **MLE #** on that MLE. For example, you cannot select a crosspoint button assigned to MLE 2 on MLE 2, as this causes a feedback loop.

• MLE X — Select this option to assign the Program output of an MLE to the selected crosspoint button, where "X" represents the number of the MLE. This allows you to re-enter an MLE into another MLE.



**Operating Tip** — By default, the MLE re-entry buttons are already mapped to crosspoint buttons. Refer to the section "**Default Input Mapping**" on page Eng 3-13 for more information on which button the MLE re-entries are default mapped to.

- SHIFT Select this option to assign the "Shift" function to the selected crosspoint button. Refer to the section "Shifted Crosspoint Buttons" on page Eng 7-16 for more information on using the SHIFT button.
- **Global-Store** X Select this option to assign a Global-Store channel to the selected crosspoint button, where "X" represents the number of the channel.
- **MLE-Store** X Select this option to assign an MLE-Store channel to the selected crosspoint button, where "X" represents the number of the channel.
- **MLE Cln Fd X** Select this option to assign the Clean Feed output from an MLE to the selected crosspoint button, where "**X**" represents the number of the MLE.

 $\widehat{}$ 

**Important** — On an **x.5 MLE** switcher, the **MLE Clean Feed** is not supported. Only the dedicated Output BNCs for the Mix/DSK option can provide a dedicated Clean Feed for the bottom, Program/Preset, MLE.

**MLE Preview** X — Select this option to assign the Preview output from an MLE to the selected crosspoint button, where "X" represents the number of the MLE.

• **PRV w/ OVL** — Select this option to assign the main Preview output with Overlay to the selected crosspoint button.



**Important** — Selecting the **Preview with Overlay** on the **Preset Bus** of the bottom MLE causes a feedback loop. This feedback loop does not apply if you have the **Mix/DSK** or **MultiDSK** option installed.

- **AuxKeyCut** Select this option to assign an AuxKey Cut to the selected crosspoint button. The AuxKeyCut allows you to perform a cut of the AuxKey keyer on the selected Aux Bus.
- **AuxKeyTrans** Select this option to assign an AuxKey Transition to the selected crosspoint button. The AuxKeyTrans allows you to perform a transition of the AuxKey keyer on the selected Aux Bus. Refer to the section "**AuxKey Setup**" on page Ops 7-40 for information on setting the AuxKey transition rate.
- **AuxBkgdCut** Select this option to assign an AuxKey Background Cut to the selected crosspoint button. The AuxBkgdCut allows you to perform a cut of the AuxKey background on the selected Aux Bus.
- **AuxBkgdTrans** Select this option to assign an AuxKey Background Transition to the selected crosspoint button. The AuxBkgdTrans allows you to perform a transition of the AuxKey background on the selected Aux Bus. Refer to the section "**AuxKey Setup**" on page Ops 7-40 for information on setting the AuxKey transition rate.
- AuxB+KCut Select this option to assign an AuxKey Background and Key Cut to the selected crosspoint button. The AuxB+KCut allows you to perform a cut of the AuxKey background and keyer on the selected Aux Bus.
- **AuxB+KTrans** Select this option to assign an AuxKey Background and Key Transition to the selected crosspoint button. The AuxB+KTrans allows you to perform a transition of the AuxKey background and keyer on the selected Aux Bus. Refer to the section "**AuxKey Setup**" on page Ops 7-40 for information on setting the AuxKey transition rate.
- **Bus Hold** Select this option to assign a Bus Hold to the selected crosspoint button. The Bus Hold allows you to have the currently selected source, on the bus that you select the Bus Hold for, not change when a memory recall is performed. This is the same as holding the crosspoint button when performing a memory recall. On an Aux Bus, the Bus Hold toggles the Aux Bus Lock on and off.
- **BNC** *XXX* Select the desired Input BNC to assign it to the selected crosspoint button, where "*XXX*" represents the input designation.
- 5. Select and assign each of your external inputs. Remember that inputs assigned as Off on the BNC Type Menu are filtered from this list.



**Operating Tip** — You can use the **Assign Maps** button on the **Edit Bus Maps Menu** to navigate to the **Assign Bus Maps Menu** directly. A confirmation screen is displayed, asking you to confirm your changes.

- 6. Press HOME to display the Bus Map Change Confirmation Screen.
- 7. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for editing and creating a bus map.

### **Bus Map Tips**

Use the following tips and tricks when editing or creating a bus map:

- You can map an input to more than one crosspoint.
- Associate your primary inputs first, followed by your shifted inputs.
- To save a button, you can assign Global-Store channel 2 to the shifted button of Global-Store channel 1.
- You do not need to assign alpha signals to crosspoint buttons. These signals are used automatically when you select the Video crosspoint of the Auto Key.
- A different Bus Map can be assigned to the same MLE from each control panel.

## **Shifted Crosspoint Buttons**

The Shift function can be assigned to a bus map and allows you to access additional bus maps on the bus. Up to **4** Shift functions can be assigned to a single bus map.

The **SHIFT** button only shifts the crosspoint bus that the button is pressed on. All other buses remain unchanged.

Use the following procedure to access a shifted crosspoint:

 Press and hold the SHIFT button on the crosspoint bus you want to access the shifted crosspoint on. If the Shift Lock feature is on, you can double-press the SHIFT button instead of holding it.

**Note** — If Shift Lock is active on an MLE, the mnemonics for that MLE switch to a two-line format.

- 2. Press the **Crosspoint** button you want to select.
- **3.** Release both buttons.
- **4.** Both the **Crosspoint** button and **SHIFT** buttons remain lit. If you press another Crosspoint button, an unshifted crosspoint and the **SHIFT** button will not be lit.

This completes the procedure for accessing a shifted crosspoint.

#### For More Information ...

• on Shift Locking, refer to the section "Personality List" on page Eng 11-2.

## **Copying Bus Maps**

You can copy a bus map from one bus map location to another. This allows you to organize or group your bus maps together.

Use the following procedure to copy a Bus Map:

- 1. Navigate to the Edit Bus Maps Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ More ⇒ Bus Maps ⇒ Copy Map.



Copy Bus Maps Menu

- **2.** Use the **Copy From** knob on the **Copy Bus Maps Menu** to select the bus map location you want to copy from.
- **3.** Use the **Copy To** knob on the **Copy Bus Maps Menu** to select the bus map location you want to copy to. Any bus map information in this location will be lost.
- 4. Press **Copy Map** on the **Copy Bus Maps Menu** to copy the bus map information from the one location to the other.

This completes the procedure for copying a bus map.

## **Defaulting Bus Maps**

You can reset a single, or all **16** user-defined, bus maps on the switcher. This returns the bus map to the default video source assignments.

Use the following procedure to default a Bus Map:

- 1. Navigate to the Edit Bus Maps Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ More ⇒ Bus Maps.

Bus Maps		44 Back	WTemant I	A SHOWNER	133 FORMER	Map:	
Map: Map07						(6)Map06	0
						(7)Map07	0
Button 1	Black					(в)маров	(e)
Button 2	BNC C01 (C	01)					
Button 3	BNC C02 (C	02)				Button	
Button 4	BNC C03 (C	0.3)				Button 1	G
Button 5	BNC C04 (C	04)				Button 2	Ø
Button 6	BNC C05 (C	05)				Button 3	
Button 7	BNC C06 (C	06)					
Button 8	BNC C07 (C	07)					
Button 9	BNC C08 (C	083					
Button 10	BNC C09 (C	09)					
Button 11	BNC C10 (C	10)					
Button 12	BNC C11 (C	11)					
a Assign	a Edit	3 Rename	4 Copy	Default	Def	ault =	Attor

Bus Maps Menu

- **2.** Default a single bus map as follows:
  - Use the **Map** knob on the **Bus Maps Menu** to select the Bus Map you want to default.
  - Press **Default Map** on the **Bus Maps Menu** to display the **Default Bus Maps Warning Screen**.
  - Accept or reject the changes you have made as follows:
    - > Press **Confirm** to accept the changes.

- > Press **Cancel** to not accept the changes. The switcher returns to the previously stored settings.
- **3.** Default all bus maps as follows:
  - Press **Default ALL Maps** on the **Bus Maps Menu** to display the **Default ALL Bus Maps Warning Screen**.
  - Accept or reject the changes you have made as follows:
    - > Press **Confirm** to accept the changes.
    - > Press **Cancel** to not accept the changes. The switcher returns to the previously stored settings.

This completes the procedure for defaulting a bus map.

#### For More Information...

- on connecting video signals to Input BNCs, refer to the section "Video Input Cabling" on page Eng 3-13.
- on default crosspoint mapping, refer to the section "**Default Input Mapping**" on page Eng 3-13.

# **Assigning Panel Bus Maps**

Bus Maps can be assigned to the program/preset, key, or utility buses of each MLE, or to each Aux Bus. Bus Maps can be assigned to individual buses, MLEs, Aux Buses, or to the entire panel. Bus Map assignment are control panel specific and do not affect the Bus Map assignments on other control panels.

Bus Map assignments are stored in the switcher personality register.



**Important** — The **OverDrive® Production Control System** requires that all buses on your switcher are assigned to the same bus map. OverDrive does not support different bus maps on different buses.

## **Assigning Panel Bus Maps to Individual Buses**

Each bus on the Vision control panel is set to the default Bus Map from the factory. To change what Bus Map is assigned to a bus on your control panel, you must first select the bus you want to assign the new map to and then select the new map. Buses assigned to the same MLE on another control panel are unaffected by bus map assignments.

Use the following procedure to assign a bus map to an individual bus:

- 1. Navigate to the Assign Panel Bus Maps Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Personality ⇒ Bus Maps ⇒ Assign Bus Map.
- 2. Press Individual Buses on the Assign Bus Maps Menu.

Assign Panel Bus Maps	44 Back	- Witerward	Copy Up	13 Swap	Bus: MLE1 Pgm/Pst MLE1 Key 1 MLE1 Key 2	( Q.)
This will assign the selected bus map t 'Perform Assign' is pressed.	o the selected b	us on this panel i	when		Мар. (6)Мар06 (7)Мар07 (8)Мар08	0 O O
	—— Assign M	Map to:		-		
Entire Panel	All MLE Buses	All Aux Buses	Individual Buses	Per	form 🛶 H	

Assign Individual Setup — Assign Panel Bus Maps Menu

- **3.** Use the **Bus** knob on the **Assign Panel Bus Maps Menu** to select the MLE and Bus that you want to assign a bus map to. Buses that are not available, or present, on your control panel appear gray, but are still selectable. You can choose between the following:
  - MLEX Pgm/Pst Select this option to assign a bus map to the Program and Preset buses of the selected MLE, where "X" represents the MLE you are selecting.
  - MLEX Key 1 Select this option to assign a bus map to the Key 1 bus of the selected MLE, where "X" represents the MLE you are selecting.
  - MLEX Key 2 Select this option to assign a bus map to the Key 2 bus of the selected MLE, where "X" represents the MLE you are selecting.
  - MLEX Key 3 Select this option to assign a bus map to the Key 3 bus of the selected MLE, where "X" represents the MLE you are selecting.

- MLEX Key 4 Select this option to assign a bus map to the Key 4 bus of the selected MLE, where "X" represents the MLE you are selecting.
- MLEX Utility Select this option to assign a bus map to the Utility bus of the selected MLE, where "X" represents the MLE you are selecting.
- MultiDSK 1 Select this option to assign a bus map to the MultiDSK Key 1.
- MultiDSK 2 Select this option to assign a bus map to the MultiDSK Key 2.
- Bank X Aux Y Select this option to assign a bus map to the selected Aux Bus, where "X" represents the Bank and "Y" the Aux you are selecting.
- **RmtAuxPnl LX** Select this option to assign a bus map to the Remote Aux Panel(s) connected to the **External Link Port** *X*, where "*X*" is the number of the External Link Port. **External Link Port 1** is used for the Touchscreen Display.
- **RmtAuxPnl PX** Select this option to assign a bus map to the Remote Aux Panel(s) connected to the **Peripheral Port** *X*, where "*X*" is the number of the Peripheral Port.
- **Extern Row X** Select this option to assign a bus map to the Auxiliary Control Panel assigned to the **External Row** *X*, where "*X*" is the number of the External row that the Auxiliary Control Panel is assigned to.
- 4. Use the **Map** knob on the **Assign Bus Maps Menu** to select the bus map that you want to assign to the selected bus.
- 5. Press **Perform Assign** on the **Assign Bus Maps Menu** to assign the selected bus map to the bus.

This completes the procedure for assigning a bus map to an individual bus.

## **Assigning Panel Bus Maps to Multiple Buses**

Each bus on the Vision control panel is set to the default bus map from the factory. To change what bus map is assigned to the entire control panel, or just the MLEs or Aux Buses on the control panel, you must select the component that you want to assign the new bus map to, and then select the new map. Buses assigned to the same MLEs, or Aux Buses, on another control panel are unaffected by bus map assignments.

Use the following procedure to assign a bus map to multiple buses on a control panel:

- 1. Navigate to the Assign Panel Bus Maps Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Personality ⇒ Bus Maps ⇒ Assign Bus Map.

**Operating Tip** — If all the buses on your control panel are not assigned to the same bus map, the **Map** knob on the **Assign Panel Bus Map Menu** will initially be set to **Different**.

- **2.** Assign a bus map to all buses on the control panel as follows:
  - Press Entire Panel on the Assign Bus Maps Menu.

Assign Panel Bus Maps	44 Back	)   III Tormerii	Copy Up	33 Swap	]	
This will assign the selected bus map "Perform Assign' is pressed.	to the entire pane	i when			Map. (6)Map0( (7)Map0 (8)Map0	5 7 8
	Assign M	ap to:		_		

Assign to Entire Control Panel — Assign Bus Maps Menu

- Use the **Map** knob on the **Assign Panel Bus Map Menu** to select the bus map you want to assign to the buses.
- **3.** Assign a bus map to all MLEs assigned to the control panel as follows:
  - Press All MLE Buses on the Assign Panel Bus Maps Menu.
  - Use the **Map** knob on the **Assign Panel Bus Map Menu** to select the bus map you want to assign to the buses.
- 4. Assign a bus map to all aux buses on the control panel as follows:
  - Press All Aux Buses on the Assign Panel Bus Maps Menu.
  - Use the **Map** knob on the **Assign Panel Bus Map Menu** to select the bus map you want to assign to the buses.
- 5. Press **Perform Assign** on the **Assign Panel Bus Maps Menu** to assign the selected bus map to the buses.

This completes the procedure for assigning a bus map to an multiple buses.

# Naming Bus Maps

Each Bus Map can be given a specific name that is displayed on the menus when working with bus maps.

Use the following procedure to name a Bus Map:

- 1. Navigate to the Edit Bus Maps Menus as follows:
  - Press HOME  $\Rightarrow$  More  $\Rightarrow$  Setup  $\Rightarrow$  More  $\Rightarrow$  Bus Maps.
- **2.** Use the **Map** knob on the **Bus Maps Menu** to select the Bus Map you want to change the name for.
- 3. Press Rename Map on the Edit Bus Maps Menus.

Rename Map	44 Back	M Tormary	- 4 (SOLV (SE)	13 FREE	
1 0 <b># \$</b> % ^ 1 2 3 4 5 6		* ( ) 8 9 0	- +	Backspace	
Q W E R T	v U	I O P			
Caps Lock A 5 D F	GH	)   K	L	; DEL	
Shift Z X C V	8	N M <	27		
	Space	New Name (MAX 8 Map01	Charactersk:		
Clear				Accept New Name	

Rename Map Menu

**Operating Tip** — Refer to the section "Using the Naming Menus" on page Eng 5-16 for more information on using the **Rename Map Menu** to enter a name, or set up the mnemonics for the crosspoint button.

4. Enter the new name you want to use in the New Name field.



**Operating Tip** — You should consult your **Bus Map Worksheet** and use that as a guide for configuring the Input BNCs. Refer to the section "**Bus Map Worksheet**" on page Eng 21-6 for a copy of this worksheet.

5. Press Accept New Name on the Rename Map Menu to assign the name to the Bus Map.

This completes the procedure for naming a Bus Map.

# **Assigning Tallies to Video Inputs**

Each Vision control panel includes at least **36** configurable tally relays, each of which can be assigned to any video input. The Extended Tallies options, if available, provide an additional **36** tallies (allowing for a total of **144** on a **Vision 4**).

Input BNCs are assigned to tallies so that only one source can be assigned to a tally, but the same source can be assigned to multiple tallies.

In a MultiPanel configuration, if you want the Program MLE of a panel to tally, and it is not the highest numbered MLE, then you must set that MLE to tally on that panel. Tallies are control panel specific.



**Operating Tip** — Use the **Tally Number** column in the **Video Input Worksheet** to help identify the tally connections that need to be made. Refer to the section "**Video Input Worksheet**" on page Eng 21-2 for a copy of this worksheet.

Use the following procedure to assign tallies:

- 1. Navigate to the BNC Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ BNC.
- 2. Press Tally on the BNC Menu 1-3.



Tally — BNC Menu 1-3

- **3.** Use the **Tally** knob on the **BNC Menu 1-3** to select the tally that you want to associate an Input BNC to. This tells the switcher logic to close the selected relay circuit when the associated input forms part of the switcher output (as dictated by the selection made with the **Type** knob).
- 4. Use the BNC/MLE knob on the BNC Menu 1-3 to select an Input BNC, MLE, or Global-Store to associate with the tally relay. If you do not want to associate a BNC or MLE with the tally, select NONE. By default, all inputs are assigned to tallies in ascending order. For example, Tally 1 is associated with BNC C01, Tally 2 is associated with BNC C02.



**Note** — You can only assign a tally relay to one input, but can assign multiple tallies to the same input.

**Operating Tip** — For wiring convenience, it is recommended that you make your tally associations on a 1:1 basis (i.e. Input **C11** assigned to **Tally 11**).

- Use the **Type** knob on the **BNC Menu 1-3** to select the type of tally to assign to the MLE, BNC, or Global-Store channel. You can choose between the following:
  - > **On Air** Select this option to have the selected BNC, MLE or Global-Store tally when it is on-air.
  - > Preview Select this option to have the selected BNC, MLE or Global-Store tally when it is on preview (part of the next transition). Whether the source is on preview depends on how the Preview Bus Module is set.
  - > **AuxNme(#:#)** Select the Aux Bus 1:1 through 4:8 that you want to tally when the selected BNC, MLE or Global-Store is selected on that Aux Bus.
- 5. Press HOME to display the Installation Change Confirmation Screen.
- 6. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for setting up tallies.

#### For More Information ...

- on the tally ports, refer to the section "Tally Ports" on page Eng 2-18.
- on the **Preview Bus Module**, refer to the section "Video Preview" on page Ops 4-14.
# **Assigning GPI Outputs to Video Inputs**

Each GPI Output on the switcher can be assigned to an Input BNC with a preroll time. When **Roll Clip** is active on the Transition Module, and a source with an assigned GPI Output is taken on-air, the GPI output is triggered immediately, but the transition is delayed for the Preroll time.

Use the following procedure to assign GPI Outputs to video sources:

- 1. Navigate to the BNC Menus as follows:
  - Press HOME  $\Rightarrow$  More  $\Rightarrow$  Setup  $\Rightarrow$  Installation  $\Rightarrow$  BNC  $\Rightarrow$  More  $\Rightarrow$  More.
- 2. Press GPIOs on the BNC Menu 3-3.



GPI Outputs - BNC Menu 3-3

**3.** Use the **BNC** knob on the **BNC Menu 3-3** to select the BNC that you want to assign a GPI Output to.

**Note** — You can only assign one GPI output to a BNC at a time, but you can assign multiple BNCs to the same GPI output.

- **4.** Use the **GPI Outputs** knob on the **BNC Menu 3-3** to select the GPI output that you want to assign to the selected BNC input.
- 5. Use the **Preroll** knob on the **BNC Menu 3-3** to select the amount of time between the GPI Output trigger, and the transition, when the **Roll Clip** button is active in the **Transition Module**.
- 6. Press HOME to display the Installation Change Confirmation Screen.
- 7. Accept or reject the changes you have made as follows:
  - Press Confirm to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for assigning GPI outputs to video sources.

#### For More Information...

• on the GPI I/O ports, refer to the section "GPI I/O Port" on page Eng 2-19.

# **Checking Keys**

After you have set up your Auto Keys you should test them to ensure that they display properly. This allows you to verify that each alpha-fill combination is working correctly, and generating a proper Linear Key.

Use the following procedure to check your keys on an upper MLE:

- **1.** Select a video source on the **Background** (**BKGD**) **Bus** of the highest number MLE. This is the background that you place the Auto Select key over.
- 2. Press the Key 1 select (SEL) button to assign the Keyers Module and Key Bus to Key 1 (Figure 7.1).

 $\checkmark$ 

**Operating Tip** — If you are unfamiliar with how to use the Keyers, refer to the section **"Keyers Module**" on page Ops 7-2.



Figure 7.1 Keyers Module with Keyer 1 Selected (4-Keyer Shown)

- **3.** Press the **Auto Select** button on the **Keyers Module** to display the key as an Auto Select Key.
- **4.** Select an **Auto Key** video source on the **Key Bus** of the MLE. This is the Key that you placed over the Background.

**Operating Tip** — If you select a crosspoint button that is set up to control an external device, the device control menu for that device is displayed. Press the crosspoint button again to display the **Auto Key Setup Menu**.

5. Select the **Key 1** button in the **MLE Transition Module** of the bottom MLE. This includes the keyer in the next transition. The key appears on the **Preview** monitor and the **Auto Key Setup Menu** is displayed.



Auto Key Setup Menu

- **6.** Visually check the appearance of the Auto Key on the preview monitor. Check for the following:
  - The assigned Alpha signal should be properly cutting the hole in the background.
  - The selected Video (fill) signal should be properly filling the hole.
  - The edges of the key should be clean.
- **7.** If the Auto Key does not display correctly, ensure that the proper MLE and Key is being shown, and that the proper Video (fill) and Alpha are selected. Check for the following:
  - The correct **MLE** and **Keyer** are shown. If the incorrect MLE or Key is shown, ensure that you have selected **Key 1** on the bottom **PGM/PST MLE**.
  - The correct **Key Video** (fill) source name and **Input BNC** are shown. If the Key Video is incorrect, ensure that the desired source has been selected, or that it has been properly assigned to the crosspoint button.
  - The correct **Key Alpha** source name and **Input BNC** are shown. If the Key Alpha is incorrect, ensure that the Auto Key has been properly set up.
  - The correct **Key Attributes** are shown. If the Key Attributes are incorrect, ensure that the Auto Key has been properly set up for Shaped or Unshaped, Clip, Gain, and Transparency.
- **8.** If the Auto Key has the correct video signals, but still does not display correctly, ensure that the key is properly set up for Shaped or Unshaped. Check for the following:
  - If the Auto Key has been set up for **Unshaped**, but the alpha signal is actually **Shaped**, you will see black edges around the key.
  - If the Auto Key has been set up for **Shaped**, but the alpha signal is actually **Unshaped**, you will see jagged edges and no gradation.
- **9.** If the Auto Key is set up properly, but the edges or shadows of the key, do not display properly, adjust the **Clip** and **Gain**. Adjust the **Clip** and **Gain** as follows:
  - Select the **SEL** button for **Key 1**. This ensures that the **Key Attribute** buttons are assigned to **Key 1**.
  - Toggle the **KEY MEM** button in the **Keyer Module** to **Off** (not lit) to allow you to override the **Clip** and **Gain** settings of the Auto Key.

Auto Key Setup	44 Back	1 M Termerri 1	Copy Up	13 Swap	A50595760
MLE 2 Key 1					( 90.8%) Clip
Key Fill: BNC C13 (C13) Key Alpha: BNC C14 (C14)					
					( 44.8%) Gain
Clip / Transparency Gain On/Off				Make I Linear	Cey with the

Clip and Gain Enabled — Auto Key Setup Menu

- Use the **Clip** and **Gain** knobs on the **Auto Key Setup Menu** to adjust the appearance of the Auto Key.
- Press and hold the **AUTO SELECT** button and press the **KEY MEM** button to save the new Clip and Gain setting for the Auto Key. The **Locked** labels re-appear and the Clip and Gain controls are locked at the new settings. The Auto Key uses these settings each time the selected Auto Key is used.

This completes the procedure for checking keys.

#### For More Information...

- on connecting video inputs, refer to the section "**Video Input Cabling**" on page Eng 3-13.
- on checking video inputs, refer to the section "Input Verification" on page Eng 4-16.
- on keying, refer to the section "Keying" on page Ops 7-1.
- on checking the Non-Sync status of an input selected on a bus, refer to the section "Non-Sync Status" on page Eng 17-16.

# Video Output Configuration and Check

# In This Chapter

This chapter provides instructions for configuring and checking the video signals on the Output BNCs of the Vision switcher. As you follow each procedure, you are, in effect, building a database that is used by the switcher to provide the desired names, sources, key and fill associations, and overall switcher functionality.

The following topics are discussed in this chapter:

- Configuring Video Outputs
- Checking Video Outputs
- Additional Video Output Configuration
- Multi-Viewer
- Mix/DSK
- MultiDSK
- Mix/DSK and MultiDSK
- AuxKeys



**Operating Tip** — A Video Output Worksheet is provided to assist you in keeping track of which outputs have been assigned to the BNCs. Refer to the section "Video Output Worksheet" on page Eng 21-9 for a copy of this worksheet.

# **Configuring Video Outputs**

The frame has a number of output BNCs that can be set up as either MLE Program, MLE Preview, MLE Clean Feed, Preview with Overlay, an Aux output or an AuxKey. The configuration of your facility will depend largely on how many Video Output Boards are installed, and which options have been purchased.

The number of Output BNC your switcher has depends on the number of Video Output Boards you have installed in the frame.

This section describes how to assign Output BNCs to the output signals of the switcher, such as MLE Program.



**Note** — If you have the **Mix/DSK**, **MultiDSK**<sup>™</sup> or **AuxKeys**<sup>™</sup> options installed, certain Output BNCs are locked to specific outputs. In some cases, only these Output BNCs can be used for the output of this option.

Use the following procedure to configure your output BNCs:

- 1. Navigate to the **Output Menus** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Output.
- 2. Press Output BNCs on the Output Menu 1-2.



Output BNC — Output Menu 1-2

3. Use the **Output** knob on the **Output Menu 1-2** to select a BNC to assign a type to.

**Note** — If you are setting up the Program output for a control panel that does not have the highest number MLE assigned to it, you must use the **MLE X PGM**.

- **4.** Use the **Type** knob on the **Output Menu 1-2** to select the output type you want to assign to the Output BNC. You can choose between the following:
  - **Program** Select this option to have the main **Program** output, the output of the highest number MLE, routed to the selected Output BNC. The Program MLE with the MultiDSK, Half MLE, and Preview Overlay options is the highest number MLE assigned to a control panel in the system.
  - **PRV w/ OVL** Select this option to have the main **Preview** output with **Preview Overlay** output routed to the selected Output BNC.
  - **PRV w/o OVL** Select this option to have the main **Preview** output without **Preview Overlay** output routed to the selected Output BNC.



- MLE X PGM Select this option to have the Program output of the selected MLE routed to the selected Output BNC, where "X" represents the MLE you are selecting.
- **MLE X PRV** Select this option to have the **Preview** output of the selected MLE routed to the selected Output BNC.
- **MLE X LkAhd** Select this option to have the **Look Ahead Preview** output of the selected MLE routed to the selected Output BNC.

**Note** — The number of **Clean Feed** outputs for an MLE (**MLE X CInFd**), or the main Clean Feed outputs (**Clean Feed**), depends on the **Key 4 Mode** that the MLE is set to. For the main Clean Feed output, it depends on the Key 4 Mode settings for the **PGM/PST MLE**.

- MLE X ClnFd1(2) Select this option to have the Clean Feed 1 or Clean Feed 2 output of the selected MLE routed to the selected Output BNC where "X" represents the MLE you are selecting.
- **MV** X Select this option to have the output of a Multi-Viewer routed to the selected Output BNC, where "X" is the number of the Multi-Viewer.
- Clean Feed 1(2) Select this option to have the main Clean Feed 1 or Clean Feed 2 output routed to the selected Output BNC.
- **GlobalStore** X Select this option to assign the output of the selected Global-Store to the selected Output BNC, where "X" represents the Global-Store channel you are selecting.
- Aux Monitor Select this option to have the **Program** output of the active Aux Bus routed to the selected Output BNC. When you assign an Aux Bus to a Crosspoint Group, or panel row, the output of that Aux Bus is routed to the Aux Monitor output. This does not apply to the Aux Bus selected by an Auxiliary Control Panel.
- Aux Bus Outputs 1:1 through 6:8 Select this option to have the output of an Aux Bus to the selected Output BNC. You can select between **Bank1**, **Aux1** through **Bank6**, **Aux8**.

**Note** — If you are using **Aux Buses** to pass non-native video format signals through the switcher, **Output BNC C03** and **C04** on the **QMD/MD** frames cannot be used. Output BNCs **C03** and **C04** cannot pass video that is of a format other than what the switcher is operating in.

- **BNC** XXX Select this option to have an Input BNC routed directly to an Output BNC, where "X" is the number of the Input BNC.
- 5. Press HOME to display the Installation Change Screen.
- 6. Accept or reject these changes as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for setting your Output BNC types.

#### For More Information...

• on default output mapping, or video output cabling, refer to the section "Video Output Cabling" on page Eng 3-15.

- on activating and configuring the MultiDSK option, refer to the section "**MultiDSK**" on page Eng 8-19.
- on setting up an AuxKey, refer to the section "AuxKeys" on page Eng 8-22.
- on activating and configuring the Mix/DSK option, refer to the section "Mix/DSK" on page Eng 8-17.
- on Key 4 Mode, refer to the section "Key 4 Mode" on page Eng 12-7.
- on setting up a Multi-Viewer, refer to the section "Multi-Viewer" on page Eng 8-13.

# **Checking Video Outputs**

Nearly every Output BNC of the Vision switcher can be assigned to any output source, allowing you to assign multiple outputs to a single output signal. After the cable connections to the Output BNCs are completed, and the output signals are assigned to the BNCs, you can check that the proper output signal is being fed out of each Output BNC.

To confirm which output signal is being sent to which Output BNC, use the **Aux Bus Outputs Menu 2-2** in conjunction with the Output BNC Verification table (**Table 8.1**).



**Operating Tip** — The **Aux Bus Outputs Menu 1-2** lists the selected outputs for all the Aux Buses on the switcher.

Use the following procedure to confirm the outputs on the Output BNCs:

1. Navigate to the Aux Bus Outputs Menu 2-2 as follows:

I01: Program         I05: MLE 1 PRV           I02: PNV w/ OVL         I06: MLE 2 PGM           I03: PNV w/o OVL         I07: MLE 2 PRV           I04: MLE 1 PGM         I08: MLE 3 PGM	I01: Program I02: PRV w/ OVL I03: PRV w/o OVL I04: MLE 1 PGM	105: 106: 107:	MLE 1 PRV MLE 2 PGM MLE 2 PRV		
IO4: MLE 1 PGM	104: MLE 1 PGM				
		1001	mile 3 Pum		

• Press HOME  $\Rightarrow$  More  $\Rightarrow$  Aux Bus  $\Rightarrow$  More.

Aux Bus Outputs Menu 2-2

**2.** Press the button corresponding to the Output BNC range that you want to check. The video signal for each of the Output BNC in the selected range is shown on the menu.

This completes the procedure for confirming the outputs on the Output BNCs.

To Verify This Output	Do This
Program	Select different crosspoint buttons on the <b>PGM Bus</b> . Depending on the number of MLEs you have, you may have to assign the Program MLE to a Panel Row on your panel.
Preview without Overlay	Select different crosspoint buttons on the <b>PV Bus</b> . Depending on the number of MLEs you have, you may have to assign the Preview MLE to a Panel Row on your panel.
Preview with Overlay	Select <b>Source ID</b> and <b>Safe Title</b> in the <b>Preview Overlay Module</b> to place these elements on the <b>Preview Monitor</b> . Perform the same test as outlined in the <b>Preview without Overlay</b> section.
Clean Feed	On the half MLE switchers ( <b>2.5 MLE</b> for example), or switchers with the <b>MultiDSK</b> <sup>TM</sup> option installed, the clean feed is fixed to specific BNCs. A monitor must be connected to these BNC to test the output. Refer to the section " <b>Configuring Video Outputs</b> " on page Eng 8-2 for more information. Refer to the section " <b>Clean Feed Setup</b> " on page Eng 8-7 for more information on the clean feed.

Table 8.1 Output BNC Verification

To Verify This Output	Do This
MLE PGM	Select different crosspoint buttons on the <b>PGM Bus</b> of <b>MLE 1</b> . Repeat for each MLE installed on your switcher.
MLE PV	Select different crosspoint buttons on the <b>PV Bus</b> of <b>MLE 1</b> . Repeat for each MLE installed on your switcher.
MLE Clean Feed	Put all Keys on-air with a different source and select each of the clean feed positions in turn. As you go from <b>Before Keys</b> to <b>Between Keys</b> <i>X</i> & <i>Y</i> , you will see the keys appear on-air. Repeat for each MLE installed on your switcher.
MLE LkAhd	Select different crosspoint buttons on the <b>PGM Bus</b> of <b>MLE 1</b> . Re-enter <b>MLE 1</b> onto the <b>PGM/PST MLE</b> . Select different crosspoints buttons on the <b>PV Bus</b> of <b>MLE 1</b> . Repeat for each MLE installed on your switcher.
MV <sup>a</sup>	Connect an monitor to the Output BNC that the Multi-Viewer is assigned to and load a layout into the Multi-Viewer. Refer to the section " <b>Multi-Viewer</b> " on page Eng 8-13 for more information on setting up a Multi-Viewer.
Bank <i>X</i> , Aux <i>Y</i> $(X:Y)^{b}$	Use the <b>MLE SEL Button Menu</b> to assign the Key Bus of an MLE to <b>Bank</b> <i>X</i> , <b>Aux</b> <i>Y</i> .

 Table 8.1 Output BNC Verification

a. The Multi-Viewer option must be installed in order to be able to test this output.

b. Where *X* represents the number of the Bank, and *Y* the number of the Aux Bus you want to check.

# **Additional Video Output Configuration**

This section provides information on how to finalize the Video Output setup of the Vision switcher. This includes setting up the Clean Feed outputs, Fade to Black, and MLE Tallies.

## **Clean Feed Setup**

The FlexiClean<sup>TM</sup> feature allows you to create a secondary program output that is taken from a different location in the video layering for the selected MLE. The Clean Feed for each MLE can be configured to take the video signal before any of the keys (**Figure 8.1**). This does not include the specific Clean Feed outputs provided by the MultiDSK<sup>TM</sup> or Mix/DSK options.

**Important** — If you have a 4-Keyer MLE, the clean feeds that are available to that MLE depend on the Key 4 Mode that you have set up. Always check your Key 4 Mode before using the clean feed output in your production. If the active Key 4 Mode does not support one or both clean feeds, alternate video will be fed out of the Clean Feed output BNCs.



Figure 8.1 Clean Feed can be taken from before or between the keys (4-Keyer Shown)

**Note** — If you set up a Clean Feed for the Program/Preset MLE with MultiDSK or Mix/DSK active, only the before **Key 1** output is shown, even if before **Key 2** is selected.

Use the following procedure to set up a Clean Feed output:

- 1. Navigate to the **Output Menu** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Output.
- 2. Press Clean Feed on the Output Menu 1-2.

Output (1-2)		44 Back	( PP Terment )	· · · · · · · · · · · · · · · · · · ·		MLE: MLE 1 MLE 2	6
Use this menu the clean fee and type.	i to set up d source					Numbe CleanFe CleanFe	ed 1 ed 2
						insert B Key 1 Key 2 Key 3	efore:
Mix/DSK MultiDSK	Output Boards	Output BNCs	Aux Key Configure	Clean Feed	4 fi	ide To lack	More Nore

Clean Feed Setup — Output Menu 1-2

- **3.** Use the **MLE** knob on the **Output Menu 1-2** to select the MLE from which the clean feed originates.
- **4.** Use the **Number** knob on the **Output Menu 1-2** to select the Clean Feed output you want to set up.

- **5.** Use the **Insert Before** knob on the **Output Menu 1-2** to select the point from which the output is taken in the video path of the MLE (**Figure 8.1**). You can choose between the following:
  - **Key 1** Select this option to have the clean feed output pulled after the program/preset bus of the MLE, but before the keys are added.
  - **Key 2** Select this option to have the clean feed output pulled downstream of the first key, but before the second key.
  - **Key 3** Select this option to have the clean feed output pulled downstream of the second key, but before the third key.
  - **Key 4** Select this option to have the clean feed output pulled downstream of the third key, but before the fourth key.
- 6. Press HOME to display the Installation Change Screen.
- 7. Accept or reject these changes as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for setting up a Clean Feed output.

#### For More Information...

- on the Program Bus Clean Feeds for the half MLE switcher, the Mix/DSK options, refer to the section "**Mix/DSK**" on page Eng 8-17.
- on the Program Bus Clean Feeds for the MultiDSK option, refer to the section "**MultiDSK**" on page Eng 8-19.
- on setting up an Output BNC for Clean Feed, refer to the section "**Configuring Video Outputs**" on page Eng 8-2.
- on default output mapping, or video output cabling, refer to the section "Video Output Cabling" on page Eng 3-15.
- on video layering, refer to the section "Video Layering" on page Ops 4-3.
- on Key 4 modes, refer to the section "Key 4 Mode" on page Eng 12-7.

## **Fade to Black Setup**

Fade to Black allows you to have one or all MLEs fade to black with a single button press. Pressing the button again returns the outputs of the MLEs from black to their previous state.

In an MultiPanel configuration, the fade to black only affects the MLEs that are assigned to the control panel that the fade to black is performed on, and that fade to black is turned on for. Each control panel has a unique fade to black rate, but which MLEs that fade to black is turned on for is common across all control panels.

Use the following procedure to select the MLEs that you want to include in a fade to black:

- 1. Navigate to the **Output Menu** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Output.
- 2. Press Fade To Black on the Output Menu 1-2.

ade lo blaci	¢	44 Back	1 99 Tormani	A conversion	03	

Fade To Black Menu

- **3.** Toggle the desired MLEs **On** or **Off**, as required. Setting an MLE to **Off** will not fade the MLE to black when the transition is performed.
- 4. Press HOME to display the Installation Change Screen.
- **5.** Accept or reject these changes as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for selecting MLE that you want to include in a fade to black.

#### For More Information...

• on using Fade to Black, refer to the section "Fade to Black" on page Ops 4-35.

## **MLE Tally Setup**

The **MLE Tally** feature allows you to force a selected MLE to always function as if it is on air, regardless of whether or not it is re-entered on the **Program/Preset Bus**. For example, you may want to send the output of **MLE 1** to an external device, such as a VTR, while the Program/Preset bus is on-air. In this configuration, you may want both MLE 1 and the Program/Preset Bus to be tallied. To achieve this, the **MLE Tally** feature must be used.

In a MultiPanel configuration, the highest number MLE assigned to each panel is tallied as the Program MLE (**Always**).

Use the following procedure to set up an MLE tally:

- 1. Navigate to the **Output Menu** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Output ⇒ More.
- 2. Press MLE Tally on the Output Menu 2-2.

Output (2-2)	19. SI	44 Back	Witemand	<ul> <li>Control with</li> </ul>	93	MLE: MLE 1 MLE 2	0
This menu whether an ML tallied, or whe is tallied only is on air.	selects E is always other it when it					Tally: Always On Air	0
Switch on F1/F2	Aux Bus Format	MLE Tally		Ancillary Data	) Det		다. More

MLE Tally Setup — Output Menu 2-2

- **3.** Use the **MLE** knob on the **Output Menu 2-2** to select the MLE for which you want to assign a tally function.
- **4.** Use the **Tally** knob on the **Output Menu 2-2** to select the desired tally function. You can choose between the following:
  - **Always** Select this option to tally the selected MLE regardless of what is selected on the highest number MLE. The crosspoint selection will always be lit red, and all sources selected on the MLE will tally accordingly.
  - **On Air** Select this option when you want an MLE to be tallied only when it is selected on the highest number MLE.
- 5. Press HOME to display the Installation Change Screen.
- 6. Accept or reject these changes as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for setting up an MLE tally.

# **Ancillary Data Setup**

The **Ancillary Data** setup allows you to select which lines in the vertical and horizontal blanking area (**Figure 8.2**) can be stripped or passed, as well which line the video image starts on. This allows you to protect and pass information such as embedded audio, or closed captioning, with the video signal.

Field and Frame line numbers depends on the video format the switcher is operating in. If the switcher is operating in a Progressive Scan video format, no even or odd information is displayed.



Figure 8.2 Vertical and Horizontal Blanking Area — 480i

Ancillary data parameters are set independently for each video format. Changing video formats recalls the last saved parameters for the selected video format.

Use the following procedure to set the ancillary data parameters:

- **1.** Navigate to the **Output Menu** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Output ⇒ More.
- 2. Press Ancillary Data on the Output Menu 1-2.

Output (2-2)  LEGEND Current video for Passed Stripped Stripped (Switching line, carrt be	44 Back mat: 480i passed)	Heromanda Horizontal Blanking	<b>9</b> (2019) (2011)	93	Fiek Odd Even Pass Strip	d (Line) (1) (264)
1 5 10 15 264 268 273 278 Switch on Aux Bus	MLE Tally		Ancillary	Def	Imag Odd Even	e Starts ( 20) ( 283)

Ancillary Data Setup — Output Menu 2-2

- **3.** Use the **Field (Line)** knob on the **Output Menu 2-2** to select a particular line across the field, or the entire horizontal blanking region, that you want to adjust the Pass or Strip setting for.
- 4. Use the **Pass/Strip** knob on the **Output Menu 2-2** to select either Pass or Strip.
  - **Pass** Select this option to have any information in the selected lines, or the entire horizontal blanking region, remain in with the video signal. Use this setting if there is embedded audio.
  - **Strip** Select this option to have any information in the selected lines, or the entire horizontal blanking region, stripped from the video signal.
- 5. Select the field, or line, that the video image starts on as follows:
  - Use the **Image Starts** knob on the **Output Menu 2-2** to select the lines that are the first line of Active Video. If closed captioning is present in the video signal, set the Image Start to the line after the closed captioning line.

 $\checkmark$ 

**Operating Tip** — Press **Default Anc Data** on the **Output Menu 2-2** to restore the ancillary data setting to their default values for the current video format.

- 6. Press HOME to display the Installation Change Screen.
- 7. Accept or reject these changes as follows:

- Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
- Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
- Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for setting the ancillary data parameters.

## **Switch on Field Setup**

The **Switch On** feature allows you to set on which field the switcher will perform a transition in an Interlaced video format. This option is not available if the switcher is operating in a Progressive Scan video format.

Use the following procedure to set which field a transition is performed on:

- 1. Navigate to the **Output Menu** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Output ⇒ More.

Output (2-2)	8. See	44 Back	- PF Torward (	<ul> <li>Control total</li> </ul>	98	MLE MLE 1 MLE 2 MLE 2
Use this menu the clean feed and type.	to set up I source					Clean from Before Keys Btwn Key 162
Switch on F1/F2	Aux Bus Format	MLE Tally		Ancillary Data	) Det	More

Output Menu 2-2

- 2. Toggle Switch on on the Output Menu 2-2 to F1 or F2 to select which field a transition is performed on.
  - **F1** Select **Field 1** (**Odd Field**) to have transitions performed after odd field of the source video is drawn. This is the default setting.
  - **F2**—Select **Field 2** (**Even Field**) to have transitions performed after the even field of the source video is drawn.
- 3. Press HOME to display the Installation Change Screen.
- **4.** Accept or reject these changes as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for setting which field a transition is performed on.

# **Multi-Viewer**

The Multi-Viewer allows you to view ten video sources from a single output BNC, or have the Multi-Viewer output routed to an Aux Bus. Any video source on the switcher, including Program, Preview, Media-Store channels, and MLE re-entries, can be assigned to any box on the Multi-Viewer. All the boxes on the Multi-Viewer include mnemonic source names and red and green tallies.



**Note** — Multi-Viewer cannot be used with a **1080p** video format. If the switcher is operating in this video format, the Multi-Viewer feature will not be available.

Sour	ce 1	Sour	rce 2
Source 3	Source 4	Source 5	Source 6
Source 7	Source 8	Source 9	Source 10

Figure 8.3 Multi-Viewer Layout Example

# **Multi-Viewer Assignment**

The Multi-Viewer options allow you to assign up to two Multi-Viewers to each Video Processor Board. When a Multi-Viewer is assigned to a Video Processor Board, the MLEs provided by that board are unavailable.



**Note** — When an MLE is assigned as a Multi-Viewer, or back to an MLE, the Video Processor Board providing the MLE must reboot for the change to take effect.

Use the following procedure to assign a Multi-Viewer to a Video Processor Board:

- 1. Navigate to the Video Processor Config Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ More ⇒ Video Processor.

Video Proces	sor Config	44 Bac	k   Mitomenti	Copy Up	33 Swap	
MLE 7	Multi-Viewe	r2				
MLE 8	Multi-Viewe	r 1				
MLE 1 MLE 2	MLE 3 MLE 4	MLE 5 MLE 6	Multi-Viewer 2 Multi-Viewer 1			-

Video Processor Config Menu

- Press the MLE X/MLE Y button for the Video Processor Board that you want to assign a Multi-Viewer to. For example, if you want to assign the Video Processor Board supporting MLEs 7 and 8 as a Multi-Viewer, press the MLE 7/MLE 8 button.
- **3.** Press the **Multi-Viewer** *X* button for the MLE that you want to assign as a Multi-Viewer.
- 4. Press HOME to display the Installation Change Screen.
- 5. Accept or reject these changes as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports. All Video Processor Board that changes were made on will reboot.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support. All Video Processor Board that changes were made on will reboot.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for assigning a Multi-Viewer to a Video Processor Board.

## **Multi-Viewer Layouts**

Each Multi-Viewer is assigned a layout that specifies how the boxes are arranged and what source is assigned to each box in the layout. The size and number of boxes in the layout depends on the layout that is selected.

## Assigning a Layout to a Multi-Viewer

Use the following procedure to assign a layout to a Multi-Viewer:

- 1. Navigate to the Multi-Viewer Layout Assign. Menu as follows:
  - Press HOME  $\Rightarrow$  More  $\Rightarrow$  Setup  $\Rightarrow$  More  $\Rightarrow$  Multi-Viewer.

Multi-Viewer 1	THERE MANY CONTRACT &	Layouts:		
Lavout 3	a married	Layout 1	Layout 11	ń
Layout 1		Layout 2	Layout 12	
Multi-Viewer 2	Manisynwei an	Layout 3	Layout 13	
Layout 1		Layout 4	Layout 14	Scroll Windo
Spiniohormiter		Layout 5	Layout 15	
		Layout 6	Layout 16	
		Layout 7	Layout 17	
		Layout 8	Layout 18	
	110,424 1 1	I surred Q	Fauruat 10	

Multi-Viewer Layout Assign. Menu

- 2. Select the **Multi-Viewer** X that you want to assign a layout to, where X is the number of the Multi-Viewer.
- **3.** Select the **Layout XX** on the **Multi-Viewer Layout Assign. Menu** that you want to assign to the selected Multi-Viewer.

This completes the procedure for assigning a layout to a Multi-Viewer.

## **Editing a Multi-Viewer Layout**

Use the following procedure to edit a layout:

- 1. Navigate to the Multi-Viewer Layout Editor Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ More ⇒ Multi-Viewer ⇒ Multi-Viewer Editor.

Multi-Viewer	Layout Edito	r 4	Back	Copy Up	p 13 Swap	Layouts:
				Source 1 Program	Source 6 Bnk1Aux4(1:4)	Layout 1 Layout 2 Layout 3
Sou	rce 1	Sou	rce 2	Source 2 PRV w/ OVL	Source 7 Bnk1Aux5(1:5)	
				Source 3 Bnk1Aux1(1:1)	Source 8 Bnk1Aux6(1:6)	
Source 3	Source 4	Source 5	Source 6	Source 4 plasma (1:2)	Source 9 Bnk1Aux7(1:7)	Source:
Source 7	Source 8	Source 9	Source 10	Source 5 Bnk1Aux3(1:3)	Source 10 Bnk1Aux8(1:8)	Program PRV w/ OVL PRV w/o OVL
			4 Layo Nam	ut Save e Chang	es Can	cel of me

Multi-Viewer Layout Editor Menu

- **2.** Use the **Layouts** knob on the **Multi-Viewer Layout Editor Menu** to select the layout you want to edit.
- **3.** Select the **Source** *X*, or box, that you want to assign a video source to, where *X* is the number of the box.
- **4.** Use the **Source** knob on the **Multi-Viewer Layout Editor Menu** to select the video source that you want to be shown in the select box.

✓

**Operating Tip** — If you don't want to save your current changes, you can navigate away from the menu or press **Cancel Changes**.

5. Press Save Changes on the Multi-Viewer Layout Editor Menu to save all the changes to the edited layouts.

This completes the procedure for editing a layout.

#### **Naming a Layout**

Use the following procedure to name a Multi-Viewer layout:

- 1. Navigate to the Multi-Viewer Layout Editor Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ More ⇒ Multi-Viewer ⇒ Multi-Viewer Editor.
- **2.** Use the **Layouts** knob on the **Multi-Viewer Layout Editor Menu** to select the layout you want to name.
- 3. Press Layout Name on the Multi-Viewer Layout Editor Menu.



Change Layout Name Menu

**Operating Tip** — Refer to the section "Using the Naming Menus" on page Eng 5-16 for more information on using the Change Layout Name Menu to enter a name.

- 4. Enter the new name for the layout in the **New Name** field. The name can be no more than **32** characters in length.
- 5. Press Accept New Name on the Change Layout Name Menu to store the new name.

This completes the procedure for naming a Multi-Viewer layout.

#### For More Information...

• on assigning a Multi-Viewer to an output BNC, refer to the section "Configuring Video Outputs" on page Eng 8-2.

# Mix/DSK

The Mix/DSK option provides a mixer and keyers for the bottom (Program/Preset) MLE in a half MLE switcher. This option must be installed in order to use the Program/Preset MLE on a half MLE switcher, such as a **2.5 QMD-X**.

The Mix/DSK feature can only be activated if a Multi-Definition Video Output Board is installed in the following slot of your frame:

- Octane/QMD-X Slot K
- MD-X Slot K
- QMD Slot B
- MD Slot B

**Note** — If you also have the MultiDSK option, the assignment of the BNCs on the Video Output Board is different. Refer to the section "**Mix/DSK and MultiDSK**" on page Eng 8-21 for more information.

The Mix/DSK option assigns and locks certain BNCs on the Video Output Board to the main switcher output video signals (**Table 8.2**).

BNC	Octane/QMD-X	MD-X	QMD	MD
	Slot K	Slot K	Slot B	Slot B
Output #01	Program	Program	Program	Program
Output #02	Program	Program	Program	Program
Output #03	Mix Preview	Mix Preview	Mix Preview	Mix Preview
Output #04	Mix Preview	Mix Preview	Mix Preview	Mix Preview
Output #05	Mix Clean 1	Mix Clean 1	Mix Clean 1	Mix Clean 1
Output #06	Mix Clean 2	Mix Clean 2 Mix Clean 2 N		Mix Clean 2
Output #07	PRV w/ OVL	PRV w/ OVL	PRV w/ OVL	PRV w/ OVL

Table 8.2 Mix/DSK Output BNC Assignment

 $\checkmark$ 

**Operating Tip** — Output **#07** is automatically set to Preview with Overlay when you set up a Mix/DSK. This can be changed later.

## Mix/DSK Setup

Setting up the Mix/DSK option activates the Program/Preset MLE on your half MLE switcher, and assign the Output BNC as indicated. The Mix/DSK software option must be installed in order to activate it.

 $\bigcirc$ 

**Note** — Turning this option Off for your half MLE switcher will prevent you from using your Program/Preset MLE. Turning this feature On for a full MLE switcher reverts your full Program/Preset MLE to a half MLE.

Use the following procedure to enable the Mix/DSK option:

- 1. Navigate to the **Output Menus** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Output.
- 2. Press Mix/DSK MultiDSK on the Output Menu 1-2.

Output (1-2)		44 Back	W Tormani (	A copy set 1 1	Sirent:	
This menu sel configuration of output board.	lects the f the DSK				Mio No Yes	
					Mu No Yes	bosk.
Mix/D5K MubiD5K	Output Boards	Output BNCs	Aux Key Configure	Clean Feed	Fade To Black	More

Mix/DKS Setup — Output Menu 1-2

- **3.** Enable the Mix/DSK option as follows:
  - Use the Mix/DSK knob on the Output Menu 1-2 to select Yes.
- 4. Press HOME to display the Installation Change Confirmation Screen.
- 5. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for turning the Mix/DSK option on.

## **Mix/DSK Operation**

The Mix/DSK option provides a limited Mixer and Keyers to the Program/Preset MLE of your switcher. For the operation of the Program/Preset MLE on a half MLE switcher, the following restrictions apply:

- You can perform Cuts and Dissolves, but not Wipes, DVE or SEQ effects.
- You can perform Auto Select Keys and Self Keys, but not Chroma Keys or Preset Pattern Keys.
- You can perform Mask and Key Invert effects, but not Matte Fill or Wash effects.

#### For More Information ...

- on performing a factory recall, refer to the section "**Factory Default Settings**" on page Eng 12-27.
- on using the Mix/DSK MLE, refer to the section "Panel Row" on page Ops 4-5.
- on using clean feed outputs, refer to the section "Clean Feed Setup" on page Eng 8-7.

# **MultiDSK**

The MultiDSK<sup>TM</sup> option provides 2 additional Downstream Keyers for your Program/Preset MLE (highest number MLE).

The MultiDSK feature can only be activated if a Multi-Definition Video Output Board is installed in the following slot in your frame:

- Octane/QMD-X Slot K
- **MD-X** Slot K
- QMD Slot B
- MD Slot B

**S** 

**Note** — If you also have the Mix/DSK option, the assignment of the BNCs on the Video Output Board is different. Refer to the section "Mix/DSK and MultiDSK" on page Eng 8-21 for more information.

The MultiDSK option assigns and locks certain BNCs on the Video Output Board to the main switcher output video signals (**Table 8.3**).

BNC	Octane/QMD-X	MD-X	QMD	MD
	Slot K	Slot K	Slot B	Slot B
Output #01	Program	Program	Program	Program
Output #02	Program	Program	Program	Program
Output #03	Multi Preview	Multi Preview	Multi Preview Multi Preview	
Output #04	Multi Preview	Multi Preview	Multi Preview	Multi Preview
Output #05	Multi Clean 5	Multi Clean 3	Multi Clean 5	Multi Clean 3
Output #06	Multi Clean 6	Multi Clean 4 Multi Clean 6		Multi Clean 4
Output #07	PRV w/ OVL	PRV w/ OVL	PRV w/ OVL	PRV w/ OVL

Table 8.3 MultiDSK Output BNC Assignment

## **MultiDSK Setup**

Setting up the MultiDSK option adds **2** additional Downstream Keyers to the Program/Preset MLE, and assign the Output BNC as indicated. The MultiDSK software option must be installed in order to activate it.



**Note** — Turning this option Off makes the two additional keys of the MultiDSK option unavailable.

Use the following procedure to enable the MultiDSK option:

- 1. Navigate to the **Output Menus** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Output.
- 2. Press Mix/DSK MultiDSK on the Output Menu 1-2.

Output (1-2)		44 Back	PP Tormanu	a conversion of	13 POLICE		
This menu sel configuration of output board.	ects the the DSK					Mix/DSK No Yes	
						MultiDSK No Yes	4 0
Mix/D5K MultiD5K	Output Boards	Output BNCs	Aux Key Configure	Clean Feed	⊕ Fa	de To ack	More

MultiDSK Setup — Output Menu 1-2

- **3.** Enable the MultiDSK option as follows:
  - Use the MultiDSK knob on the Output Menu 1-2 to select Yes.
- 4. Press HOME to display the Installation Change Confirmation Screen.
- **5.** Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for turning the MultiDSK option on.

#### For More Information...

- on using the MultiDSK, refer to the section "MultiDSK Operation" on page Ops 7-37.
- on using clean feed outputs, refer to the section "Clean Feed Setup" on page Eng 8-7.

# Mix/DSK and MultiDSK

If you have the MultiDSK option installed on your half MLE switcher, certain Output BNCs are assigned and locked to the main switcher output video signals (**Table 8.4**).

BNC	Octane/QMD-X	MD-X	QMD	MD
	Slot K	Slot K	Slot B	Slot B
Output #01	Program	Program	Program	Program
Output #02	Program	Program	Program	Program
Output #03	Mix/Multi Preview	Mix/Multi Preview	Mix/Multi Preview	Mix/Multi Preview
Output #04	Mix/Multi Preview	Mix/Multi Preview	Mix/Multi Preview	Mix/Multi Preview
Output #05	Mix/Multi Clean 1	Mix/Multi Clean 1	Mix/Multi Clean 1	Mix/Multi Clean 1
Output #06	Mix/Multi Clean 2	Mix/Multi Clean 2	Mix/Multi Clean 2	Mix/Multi Clean 2
Output #07	Mix/Multi Clean 3	Mix/Multi Clean 3	Mix/Multi Clean 3	Mix/Multi Clean 3
Output #08	Mix/Multi Clean 4	Mix/Multi Clean 4	Mix/Multi Clean 4	Mix/Multi Clean 4
Output #09	Program	Program	Program	Program
Output #10	Program	Program	Program	Program

Table 8.4 Mix/DSK and MultiDSK Output BNC Assignment



**Note** — The Mix/Multi Preview output is a dedicated preview for the Mix/DSK and MultiDSK keys. This preview is not assignable to any other Output BNC, and only includes the Mix/DSK and MultiDSK keys.

#### For More Information...

- on the restrictions of the Mix/DSK option, refer to the section "Mix/DSK Operation" on page Eng 8-18.
- on using the MultiDSK, refer to the section "MultiDSK Keys" on page Ops 7-37.
- on using clean feed outputs, refer to the section "Clean Feed Setup" on page Eng 8-7.

# AuxKeys

The AuxKeys<sup>™</sup> option can be used as either an A/B Mixer (Mix between two Aux Buses) or a Mixer/Keyer (Mix and Auto Select Key). Switcher outputs are assigned to AuxKeys in groups of four. Mix or Key operations can be previewed and clean feed is also available, similar to a standard MLE.



**Important** — *AuxKeys* cannot be used to pass or manipulate non-native video format signals. If you are using an Aux Bus as a video pass-through for a non-native video format signal, you cannot apply AuxKeys to that Aux Bus.

The AuxKeys option allows you to assign and lock certain BNCs on the Video Output Board to the main switcher outputs. The BNCs on each Video Output Board are separated into groups of 4. Assigning one of these groups to either Aux Keys or Aux Mix/Keys locks the first few BNCs in that group, depending on which option you select.

The AuxKey feature can only be activated on a Multi-Definition Video Output Board.

An example of possible Output BNC assignments are as follows:

### **Aux Mixer Example**

- Output #K09 This output is locked to Aux Program.
- Output #K10 This output is locked to Aux Preview.

#### Aux Mix/Keyer Example

- Output #K09 This output is locked to Aux Program.
- Output #K10 This output is locked to Aux Program.
- Output #K11 This output is locked to Aux Preview.
- Output #K12 This output is locked to Aux Clean Feed.

## **AuxKeys Setup**

Setting up the AuxKey option adds an Aux Mixer, or Aux Mixer/Keyer to the selected Aux Bus, and assign the Output BNCs as indicated. The AuxKey software option must be installed in order to activate it.

**Note** — The AuxKeys outputs are only available to the Output BNCs that you assign them to and cannot be routed to the main switcher output internally. Refer to the section "AuxKey Pre Mixer/Keyer" on page Eng 8-24 for information on re-entering an AuxKey externally to the switcher.

Use the following procedure to set up an AuxKey:

- 1. Navigate to the **Output Menus** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Output.
- 2. Press Output Boards on the Output Menu 1-2.

Output (1-2)		44 Back	- W Torsard	a coby ob	03	Output Group K:BNC 9-12 K:BNC 13-16	0.0
						Configuration Aux Mix Aux Mix/Key Aux Mix/Pre	2 Q 5
Mix/DSK MultiDSK	Output Boards	Output BNCs	Aux Key Configure	Clean Feed	) o f	ade To lack	More

Output Boards — Output Menu 1-2

- **3.** Activate the AuxKeys option as follows:
  - Use the **Output Group** knob on the **Output Menu 1-2** to select the group of 4 BNCs that you want to assign to the Aux Mixer or Aux Mixer/Keyer. Output BNCs on Video Output Boards that are not installed on the frame appear gray.
  - Use the **Configuration** knob on the **Output Menu 1-2** to select the AuxKey configuration you want. You can choose between the following:
    - > Outputs Select this option to assign the selected output group as standard outputs. This frees up the output group to allow you to assign standard switcher outputs to all the BNCs in the group.
    - Aux Mix Select this option to assign the selected output group as an Aux Mixer. This will allow you to perform Background dissolves in the aux bus.
    - Aux Mix/Key Select this option to assign the selected output group as an Aux Mixer/Keyer. This allows you to perform Background and Key 1 dissolves in the aux bus.
    - Aux Mix/Pre Select this option to assign the selected output group as an Aux Mixer/Keyer that is re-entered into the switcher. This allows you to perform Background and Key 1 dissolves in the aux bus and have them properly timed to be available as a source for the rest of the switcher.
- **4.** Assign which Aux Bus the AuxKey is assigned to as follows:

Output (1-2)	44 Back	- Mitoraami	<ul> <li>Accession</li> </ul>	13	Aux Ke K:BNC	yer: 9-17 13-16	
						Bus: Backgr Preset Key	ound
						Aux Bu NONE Bnk1Au Bnk1Au	s: px1(1:1) px2(1:2)
Mix/DSK MultiDSK	Output Boards	Output BNCs	Aux Key Configure	Clean Feed	4 B	ade To lack	More More

• Press AuxKey Configure on the Output Menu 1-2.

AuxKey Configure — Output Menu 1-2

- Use the **Aux Keyer** knob on the **Output Menu 1-2** to select the AuxKey that you want to set up.
- Use the **Bus** knob on the **Output Menu 1-2** to select the bus that you want to assign to an output. You can choose between the following:

- > **Background** Select this option to have the video signal selected on the Background bus of the AuxKey fed out the selected Aux Bus.
- > **Preset** Select this option to have the video signal selected on the Preset bus of the AuxKey fed out the selected Aux Bus.
- → Key Select this option to have the video signal selected on the Keyer bus of the AuxKey fed out the selected Aux Bus.
- Use the **Aux Bus** knob on the **Output Menu 1-2** to select the Aux Bus output that you want to assign to the selected output. The sources selected on the corresponding bus is fed out of the selected Aux Bus, and does interfere with the dedicated AuxKey output.



**Operating Tip** — If you select different sources on an Aux Bus assigned to the Background, Preset, or Key Bus of the AuxKey, the new source is selected on the corresponding bus of the AuxKey, without having to assign the Crosspoint Group to an AuxKey.

- 5. Press HOME to display the Installation Change Confirmation Screen.
- 6. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for setting up an AuxKey.

# AuxKey Pre Mixer/Keyer

This section describes how to cable and set up an AuxKey Pre Mixer/Keyer. This allows you to assign an Aux Mixer/Keyer that is re-entered into the switcher. The Vision switcher automatically handles any timing issues.



**Important** — The Pre Mixer/Keyer option can only correct the timing for a single pass through the switcher. Do not attempt to re-enter AuxKeys as sources on an AuxKey that you intend to re-enter on an MLE. For example, **AuxKey Pre Mixer/Keyer 1** is re-entered into **AuxKey Pre Mixer/Keyer 2** that is re-entered into **MLE 1**.

An AuxKey Pre Mixer/Keyer is re-entered into the switcher by physically connecting a BNC cable from the dedicated output BNCs of the AuxKey, to the available input BNCs (**Figure 8.4**). For example, if the AuxKey Pre Mixer/Keyer is assigned to output group **#K09-K12**, the BNC cables are connected from those output BNCs to **3** input BNCs. When the input BNCs are selected on the crosspoint bus, the properly timed output of the AuxKey is shown.



Figure 8.4 AuxKey Mix/Pre output re-entered into available input BNCs (QMD Shown)

#### For More Information...

- on setting up an Aux Bus, refer to the section "Aux Bus Setup" on page Eng 12-2.
- on setting up an Aux Panel, refer to the section "Auxiliary Panels" on page Eng 14-1.
- on selecting sources, refer to the section "Panel Row" on page Ops 4-5.

# **Basic Communications Setup**

# **In This Chapter**

This chapter provides general information on installing and initializing FlexDevice<sup>™</sup> drivers, and setting up communication with peripheral equipment. For complete information on setting up a specific class of device, refer to the *Ross Video External Device Setup Sheet* for your particular device.



**Note** — In a MultiPanel configuration, only the Master Panel can interface with and control external devices.

The following topics are discussed in this chapter:

- Communications Overview
- Installing and Managing FlexDevice Drivers
- Setting Up Communications
- · Port Expanders
- External Panel Modules
- Custom Devices
- Extra Options



**Operating Tip** — A **Communications Port Worksheet** is provided to assist you in keeping track of which peripheral devices have been connected to which communications ports. Refer to the section "**Communications Worksheet**" on page Eng 21-11 for a copy of this worksheet.

# **Communications Overview**

The Vision switcher can interface with a number of peripheral devices, such as video servers, audio mixers, routers, character generators, and robotic cameras. These devices interface with the switcher using either serial or ethernet communication. Devices that use serial communication and can be connected to either the control panel or the frame. Ethernet devices must be connected to the same network as the switcher.

## **Device Drivers**

Devices are connected to the switcher using either the built-in device drivers or individual FlexDevice<sup>TM</sup> drivers. Refer to the *Ross Video External Device Setup Sheet* for your device for information on which interface must be used with your device.

Individual FlexDevice drivers are uploaded to the switcher using the QMD/X Web Interface. Once a driver has been uploaded to the switcher, an instance of that driver is initialized and assigned to the port that the device is connected to. A single instance of a FlexDevice driver controls a single device. If you are connecting multiple devices of the same type to the switcher, you must activate multiple instances of that driver.

#### For More Information ...

• on installing a FlexDevice driver, refer to the section "Installing and Managing FlexDevice Drivers" on page Eng 9-4.

## **Control Panel Serial Communications Ports**

Peripheral equipment connected to the control panel, using a serial transmission standard, use the **8 Remote** ports located on the back of the Master Panel (**Figure 9.1**). These ports are set up for communication with the device from the control panel using the menu system on the switcher.



Figure 9.1 Vision 4 Control Panel — Serial Communications (Remote) Ports

## **Frame Serial Communications Ports**

Peripheral equipment connected to the frame, using a serial transmission standard, use the **4 Peripheral** ports located on the CPU Board at the back of the frame (Figure 9.2). These ports are set up for communication with the device from the control panel using the menu system.



Figure 9.2 Frame — Communication Ports

# **Ethernet Communications**

The following section presents a brief overview of the ethernet connection process. The exact steps taken in connecting your peripheral equipment and the Vision switcher via an ethernet network depends on the network topology of your facility.

Use the following procedure to connect your device and the Vision switcher via an ethernet network:

- Connect the device to the same subnet as your Vision switcher or to a network that has a route to the network your switcher is on. Make a note of the IP Address and Port Number of your device as this information is required when configuring the communication settings on your Vision switcher.
  - Network topologies vary greatly between facilities. Contact your IT Department for assistance in connecting your device to the appropriate network at your location.
  - Refer to the documentation that came with your device for instructions on connecting it to your network.
- 2. Configure the ethernet settings on your device to communicate with the Vision switcher.

This completes the procedure for connecting a device and the Vision switcher via an ethernet network.

#### For More Information...

- on the pinouts of the Remote ports, refer to the section "**Control Panel Pinouts**" on page Eng 20-24.
- on the pinouts of the Peripheral ports, refer to the section "**Frame Pinouts**" on page Eng 20-20.

# Installing and Managing FlexDevice Drivers

FlexDevice drivers are individually installed onto the switcher using the QMD/X Web Interface. Once the driver has been installed onto the switcher, you must initialize an instance of the FlexDevice driver for each device you want to control from the switcher.



**Note** — Not all external devices are currently supported by FlexDevice drivers. Refer to the Ross Video External Device Setup Sheet for your device for information on whether there is a FlexDevice driver for your device.

### Installing FlexDevice Drivers

Use the following procedure to install a FlexDevice Driver:

- On your computer, open your Web Browser and, in the address bar, enter the IP address of your frame and press Enter. The QMD/X Web Interface Splash Screen is displayed.
- 2. Enter your username and password as follows when the Login Dialog Box appears. The default Name is user and Password is password.
- 3. Click Other... ⇒ FlexDevices to display the FlexDevice Page. The FlexDevice Page lists all the FlexDevice drivers that are installed on the switcher and their version.

GNDX				
Bysteminto Upgrader File	Sets Other			
FlexDevice				
Install Driver				
The FiexDevice page allows you to up	pload and install Fie	xDevice drivers or	to your switcher.	
	Drivers	Type	Build	Comment
	and the second second	COMPANY OF LAN	Average Chi	design of the local division of the local di
			And in case of the	And a second second second
	Fio	Bowt	a. Hilla One	

FlexDevice Page

- 4. Click **Browse**. A file selection dialog box is displayed.
- **5.** Locate the FlexDevice driver file you want to upload to the switcher on your computer. The file is named *<device>-<version>.tar.gz*.
- 6. Click **Open/Choose** to select the file. The file path and name appears in the **FlexDevice Driver to Upload** field.
- 7. Click Install Driver to upload and install the selected driver to the switcher.

This completes the procedure for installing a FlexDevice driver. Next, you must initialize an instance of the driver to be able to assign it to a port.

#### **Initializing FlexDevice Drivers**

Use the following procedure to initialize a FlexDevice driver:

- 1. Navigate to the FlexDevices Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Comm Setup ⇒ More ⇒ Flex Devices.



Start Driver — FlexDevices Menu

- 2. Press Start Driver on the FlexDevices Menu.
- **3.** Use the **Interface** knob on the **FlexDevices Menu** to select the control panel or frame that you want to initialize the FlexDevice driver on. For example, if you want to control the device from a serial port on the back of the Master Vision control panel, you must select **Panel0**.
- **4.** Use the **Type** knob on the **FlexDevices Menu** to select the type, or class, of driver you want to initialize.
- 5. Use the **Driver** knob on the **FlexDevices Menu** to select the driver that you want to initialize an instance of. If the driver you want to initialize does not appear on the menu, ensure that the driver has been installed.
- **6.** Press **Accept** on the **FlexDevices Menu** to initialize an instance of the selected FlexDevice driver. You must initialize a separate instance of a driver for each device you want to control from the switcher.

This completes the procedure for initializing a FlexDevice driver. With an instance of the driver initialized, you must set the driver up for the port you have the device connected to. Refer to the section "**Setting Up Communications**" on page Eng 9-7 for information on setting up communications.

#### **Stopping FlexDevice Drivers**

Before you can stop a FlexDevice driver, the instance of the driver that you want to stop cannot be assigned to a port. Use the following procedure to stop an instance of a FlexDevice driver:

- **1.** Navigate to the **FlexDevices Menu** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Comm Setup ⇒ More
     ⇒ Flex Devices.

FlexDevices	FlexDevices	44 Back	- He Cormann	<b>9</b> Feb (196	03	interfac panel0 frame	
						Type: Flex Ca	m (0.
Select the speci Driver does not to stop cannot b	fic instance of the d delete the Driver fro re assigned to a port	river you want to s om the switcher. Th L	top and press Acc e instance of the	ept. Stopping a Driver you want		Driver: canon1	e.
Start Driver	Stop Driver	Delete Driver			Ac	cept	

Stop Driver — FlexDevices Menu

- 2. Press Stop Driver on the FlexDevices Menu.
- **3.** Use the **Interface** knob on the **FlexDevices Menu** to select the control panel or frame that the FlexDevice driver you want to stop is running on.
- **4.** Use the **Type** knob on the **FlexDevices Menu** to select the type of driver you want to stop.
- 5. Use the **Driver** knob on the **FlexDevices Menu** to select the driver that you want to stop an instance of.
- 6. Press Accept on the FlexDevices Menu to stop the selected instance of the FlexDevice driver.

This completes the procedure for stopping an instance of a FlexDevice driver.

#### **Deleting FlexDevice Drivers**

Before you can delete a FlexDevice driver, all instances of that driver must be stopped. Use the following procedure to delete a FlexDevice driver:

- 1. Navigate to the FlexDevices Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Comm Setup ⇒ More ⇒ Flex Devices.

FlexDevices	lexDevices	44 Back	- Witermann	Steel & call	13 - 17-11	interfa panel0 frame	ce
					Type: Flex Ca	im (D	
Select the Drive Driver before yo	r you want to delete ou can remove the Dr	and press Accept. river.	You must stop all	instances of the		Driver: canon1	į.
Start Driver	Stop Driver	Delete Driver			Ac	cept	Mitter

Delete Driver — FlexDevices Menu

- 2. Press **Delete Driver** on the **FlexDevices Menu**.
- 3. Use the Interface knob on the FlexDevices Menu to select the control PanelO.
- **4.** Use the **Type** knob on the **FlexDevices Menu** to select the type of driver you want to delete.
- 5. Use the **Driver** knob on the **FlexDevices Menu** to select the driver that you want to delete.
- 6. Press Accept on the FlexDevices Menu to delete the selected FlexDevice driver.

This completes the procedure for deleting a FlexDevice driver.
# **Setting Up Communications**

External device communication is set up from the **Communications Menu**. This menu allows you to initialize an instance of a FlexDevice driver, select the communications port that a device is connected, or assigned to, the type of device it is, the transmission standard that is used, and the communications protocol.

For specific information on setting up a particular external device with the Vision switcher, refer to the *Ross Video External Device Setup Sheet* for your device.

## **Setting Up Serial Communications**

Use the following procedure to set up serial communications with an external device:

- 1. Navigate to the Communications Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Comm Setup.
- 2. Press Type on the Communications Menu 1-2.

Part Device Comm Type Comm Settings	ype:
REMOTE 1 NONE	ype:
REMOTE 2 NONE	F.F
VID	rr .
REMOTE 3 NONE	TR (CLIP)
REMOTE 4 NONE	
REMOTE 5 NONE	
REMOTE 6 NONE	
REMOTE 7 NONE	

Device Type — Communications Menu 1-2

- **3.** Assign a device to a communications port as follows:
  - Use the **Com Port** knob on the **Communications Menu 1-2** to select the communications port that you are connecting the device to. You can choose between the following:
    - REMOTE (R1-R8) Select this option if you are connecting a device to a Remote port on the back of a Vision control panel.

**Note** — Only the Remote ports on the back of the Master Panel can be used to connect to external devices at this time.

- ExtLnk (L2-L4) Select this option if you are connecting a device to an External Link port on the back of a Vision control panel.
- > PERIPH (P1-P4) Select this option if you are connecting a device to a Peripheral port on the back of the frame.
- Use the **Device** knob on the **Communications Menu 1-2** to select the device you are connecting to the select port. If the device you are connecting to the switcher uses a FlexDevice driver, the device type is proceeded by Flex. For example, FlexCam for Robotic Cameras.
- 4. Press Select Device on the Communications Menu 1-2.

Comm	unications (1-	2)	44 Back	] Monana i	A GRAVIER	193 (COVER	Com Por	t.
This mer	u lets you set up	which devices are c	ontrolled by	which ports.			Betacam	(R1)
Port	Device	Comm Type	Com	m Settings		JA		e
C	3 Betucam	. K5-422	3840	0,000			VTR I	o Preroll: ( 0) rames
Тур	e Se	ect Com	Туре	Com Settings	Custom Devices	Extr	ons	More

Device Selection — Communications Menu 1-2

- 5. Select the driver you want to assign to the communications port as follows:
  - Use the **Device** knob on the **Communications Menu 1-2** to select the FlexDevice driver, or communications protocol, you are using. If a message stating that the FlexDevice driver is missing or damaged is displayed, you must re-install the driver.

**Note** — If you are connecting a VTR or Video Server, use the **VTR Preroll** knob on the **Communications Menu 1-2** to select the pre-roll interval, in frames, for your specific Video Server.

6. Press Com Type on the Communications Menu 1-2.

Comm	unications (1-	2)	44 Back	- Mitagaagai		193 (CONT)	Com Port:	G
This mer	10 lets you set up	your com port ty	pes				VUCF (n1)	0
Port	Device	Comm Typ	e Com	m Settings		Já		e
NEMOTO	E 1 - VDCPT	RS-422	384	60, O II D		ž	Type: RS-232 RS-422 RS-422 Null	0.
Typ	sel Sel	ect co	om Type	Com Settings	Custom     Devices	Extra		More

Com Type — Communications Menu 1-2

- **7.** Select the type of communication that is used to communicate with your device as follows:
  - Use the **Type** knob on the **Communications Menu 1-2** to select the type of communications for the selected communications port. You can choose between the following:
    - > RS-232 Select this option if your device is connected to a remote port or peripheral port and uses the RS-232 (TIA/EIA-232) transmission standard.
    - > RS-422 Select this option if your device is connected to a remote port or peripheral port and uses the RS-422 (TIA/EIA-422) transmission standard.
    - > RS-422 Null Select this option if your device is connected to a remote port or peripheral port and uses the RS-422 (TIA/EIA-422) transmission standard. This option changes the signals on the pinouts of the port for use with a null modem cable.
- 8. Press Com Settings on the Communications Menu 1-2.

Commu	unications (1-	2)	44 Back	I III Tormani I	. A SHEW VER	1 <b>93</b> /2004	Com Port: VDCP (P	1) 🖸
This men	nu lets you set up	your com port p	parameters.					
Part	Device	Comm Ty	pe Con	nm Settings		18		~
NEHOTE	I 3 VDCP	R5-422	384	00 000			Baud: 19200 38400 57600	• 0 •
-							Parity: NONE ODD EVEN	
Тур	e Sel	lect c	Com Type	Com Settings	Custom     Devices	Ext	na ions	More

Com Settings (Serial) — Communications Menu 1-2

- **9.** Set the communications protocols for the serial device as follows:
  - Use the **Baud** knob on the **Communications Menu 1-2** to select the baud rate for communicating with your device.
  - Use the **Parity** knob on the **Communications Menu 1-2** to select the parity for communicating with your device.



**Operating Tip** — If you are creating a custom device protocol, refer to the section "**Custom Devices**" on page Eng 9-22 for information on creating the protocol.

**10.** Press **Extra Options** on the **Communications Menu 1-2**. Some classes of devices support extra options that must be set. Refer to the Ross Video External Device Setup Sheet for your particular device for more information.

**Note** — If you are setting up a **Monitor Wall**, you must set the IP Address and Port Number of the Monitor Wall device. If you are not setting up a Monitor Wall, proceed to **Step** (13.).

#### **11.** Press More $\Rightarrow$ Mon Wall Setting on the Communications Menu 2-2.

Monitor Wall Device IP Settings IP Address:  I 0 0 0 Monitor Wall: Device 1 Device 2 Device 3 V	Communications (2-2)	44 Back	PP Tormani	 193 Francis	Device: Kaleido (R1)	e
IP Address:	Monitor Wall Devic	e IP Settings				۲
	IP Address:	0.00	.[0		Monitor Wall Device 1 Device 2 Device 3	

Monitor Wall Settings — Communications Menu 2-2

**12.** Select the IP address of the monitor wall device you want to control as follows:

- Use the **Monitor Wall** knob on the **Communications Menu 2-2** to select the specific monitor wall connected to the dispatcher computer that you want to control.
- In the **IP** Address field, enter the IP Address of the specific monitor wall you want to control from the selected communications port.
- In the **Port Number** field, enter the port number of the monitor wall you want to control.

- **13.** Press **HOME** to display the **Installation Change Confirmation Screen**.
- 14. Accept or reject the changes you have made as follows:
  - Press Confirm to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for setting up serial communications with an external device.

## **Setting Up Ethernet Communications**

Use the following procedure to set up ethernet communications with an external device:

- 1. Navigate to the **Communications Menus** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Comm Setup.
- 2. Press Type on the Communications Menu 1-2.

Comm	unications ()	-2)	44 Back	M Toppage	A SERVICE	93 Freet	Com Port:
This mer	u lets you set u	p what each of	the com ports ar	e used for.			REMOTE 1 (R1) REMOTE 2 (R2) REMOTE 3 (R3)
Port	Device	Comm T	ype Com	m Settings		16	increase a treat
REMOTE							Type:
REMOTE	2 NONE					0	OFF
REMOTE	3 NONE						Router
REMOTE	4 NONE						
REMOTE	5 NONE						
REMOTE	6 NONE						
REMOTE	7 NONE						
REMOTE	7 NONE						
Тур	e Si	elect evice	Com Type	Com Settings	Custom     Devices	Ext	ions Mor

Device Type — Communications Menu 1-2

- **3.** Assign a device to a communications port as follows:
  - Use the **Com Port** knob on the **Communications Menu 1-2** to select the communications port that you are connecting the device to. You can choose between the following:
    - REMOTE (R1-R8) Select this option if you are assigning a device to a Remote port on the back of a Vision control panel.

1

**Note** — Only the Remote ports on the back of the Master Panel can be used to connect to external devices at this time.

- > PERIPH (P1-P4) Select this option if you are assigning a device to a Peripheral port on the back of the frame.
- > **NET (N1-N8)** Select this option if you are assigning a device to the switcher through a network port.
- Use the **Device** knob on the **Communications Menu 1-2** to select the device you are assigning to the select port. If the device you are connecting to the switcher uses a FlexDevice driver, the device type is proceeded by Flex. For example, FlexCam for Robotic Cameras.

4. Press Select Device on the Communications Menu 1-2.



Device Selection — Communications Menu 1-2

- 5. Select the driver you want to assign to the communications port as follows:
  - Use the **Device** knob on the **Communications Menu 1-2** to select the FlexDevice driver, or communications protocol you are using.



**Note** — If you are connecting a VTR or Video Server, use the **VTR Preroll** knob on the **Communications Menu 1-2** to select the pre-roll interval, in frames, for your specific Video Server.

6. Press Com Type on the Communications Menu 1-2.

Comm	unications (1-	2)	44 Back	- Promenti	A conversion of	13 Com	Port:
This mer	nu lets you set up	your com port	ypes				e
Part	Device	Comm Ty	pe Com	nm Settings		Já	
NEMOTO	E 3. VDCP	Network	TCP Clie	nt - IP:0,0,0,0,0 Por	t.0	Type Netw Netw	ork UDP
Тур	be Se De	lect vice	Com Type	Com Settings	Custom     Devices	Extra Options	More

Com Type — Communications Menu 1-2

- **7.** Select the type of communication that is used to communicate with your device as follows:
  - Use the **Type** knob on the **Communications Menu 1-2** to select the type of communications for the selected communications port. You can choose between the following:
    - > **Network UDP** Select this option if your device is connected to the switcher through a network and uses the UDP/IP transmission standard.
    - Network TCP Select this option if your device is connected to the switcher through a network and uses the TCP/IP transmission standard.
- 8. Press Com Settings on the Communications Menu 1-2.

Communicati	ions (1-2)	44 Back	- Witemanni	A convious 1 1	Com	Port: etston(P1)
	On Frame(F	P1) IP Settings				
	Remote I Remote P	P Address: 55777	0.0.0	5	Clien Clien Serve	it/Server
	Local Por	ddress: 0.0.	0. 0			
Туре	Select Device	Com Type	Com Settings	Custom     Devices	Extra	W More

Com Settings (Ethernet) — Communications Menu 1-2

- **9.** Use the **Client/Server** knob on the **Communications Menu 1-2** to select whether the switcher should act as a client or server. Enter the port settings as follows:
  - **Client** Select this option if the switcher should act as the client when communicating with the device. Enter the settings for the switcher as follows:
    - > In the **Remote IP Address** field, enter the IP address of the external device.
    - > In the **Remote Port** field, enter the port on the external device that the switcher must connect to.
  - **Server** Select this option if the switcher should act as the server when communicating with the device. Enter the settings for the switcher as follows:
    - > In the **Local IP Address** list, select the IP address of the switcher that you want to use to connect with the external device.
    - > In the **Local Port** field, enter the port on the switcher that the external device must connect to.

**Note** — Do not change the **Local Port** value unless instructed to do so by Ross Video Technical Support.

**10.** Press **HOME** to display the **Installation Change Confirmation Screen**.

- **11.** Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press Confirm w/o Reset to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for setting up ethernet communications with an external device.

Eng 9–12 • Basic Communications Setup

# **Port Expanders**

Port Expanders allow you to increase the number of external devices that can be connected to the switcher. Port Expanders can be connected to one of the remote ports on the back of a Vision control panel, or connected as an ethernet device, depending on the Port Expander you have.

The Vision switcher supports communications with a number of Port Expanders. The following devices are currently supported by your Vision switcher (**Table 9.1**).

Port Expander	Comm	Protocol (Device)	Software Option
RS-422 Four Port Buffered Smart Switch (RS422BSS4)	RS-422	BSS4	n/a
Net Expander	Network TCP	NetExp	n/a
Comtrol® DeviceMaster®	Network TCP	n/a	n/a

Table 9.1 Supported Port Expanders

#### **Port Expander Cable Pinouts**

Use the information in this section to connect the Interface Cable from the Vision switcher to the Port Expander. If you are connecting an ethernet device (Network TCP/UDP) no interface cable is required.

For ethernet devices, the pinouts of the serial ports on the device are provided.

#### For More Information...

• on connecting an ethernet device to the Vision switcher, refer to the section "Ethernet Communications" on page Eng 9-3.

#### **BSS4 Serial Port Expander**

The Vision switcher connects to the BSS4 Serial Port Expander via the Remote ports on the Vision control panel and the **Master Port** on the BSS4.

Cable connections on the following table (**Table 9.2**) refer only to those between the Vision switcher and the BSS4 Serial Port Expander. Other cable connections present on the BSS4 Serial Port Expander can be found in the BSS4 Serial Port Expander documentation.

Vision Swit	cher		BSS4 Serial Port	Expander
Remote Port	Signal		Master Port	Signal
1				
2	RxA (Rx-)	•	2	TxA (Tx-)
3	TxB (Tx+)	•	3	RxB (Rx+)
4	Ground			
5	Ground	•	5	Ground
6				
7	RxB (Rx+)	•	7	TxB (Tx+)
8	TxA (Tx-)	•	8	RxA (Rx-)
9				

Table 9.2 Vision -to- BSS4 Serial Port Expander Wiring Chart

#### **NetExp Port Expander**

The Net Expander is a virtual port expander that allows you to simulate Remote ports on the Vision control panel that can be assigned to Ethernet devices. No cable connections are required.

#### **Comtrol DeviceMaster**

The Comtrol® DeviceMaster® allows you to connect a number of serial devices to the switcher through a single ethernet connection. Serial devices connect to the DeviceMaster using a RS-232 or RS-422 connection, and then the DeviceMaster connects to the switcher using a single ethernet TCP connection. Individual devices are identified by a port number on the DeviceMaster.

**Note** — If you are using a Cisco Systems® brand router, or switch, to connect the Comtrol DeviceMaster to the switcher, you must disable the BPDU Guard on the Cisco Systems® brand router or switch to ensure proper communications

The Comtrol DeviceMaster uses a different pinout than the Remote Ports on the Vision control panel, and supports both the RS-232 (TIA/EIA-232) and RS-422 (TIA/EIA-422) transmission standards (**Table 9.3**).

Pin	RS-232	RS-422
1	CD	n/c
2	Rx	RxA (Rx-)
3	Tx	TxA (Tx-)
4	DTR	n/c
5	Ground	n/c
6	DSR	n/c
7	RTS	TxB (Tx+)
8	CTS	RxB (Rx+)
9	RI	n/c

Table 9.3 Comtrol DeviceMaster Port Pinouts (Male)

## **Switcher Communications Setup**

The Vision switcher needs to be set up with the communications port that the Port Expander is on, as well as the type, transmission standard, and the protocols for the communications between the Port Expander and switcher.

If you are using a Comtrol DeviceMaster, use the Net Expander to create the ports on the DeviceMaster. If you are setting up a DeviceMaster that has more than 4 ports, you must set up additional Net Expanders. Each Net Expander creates 4 ports.

Use the following procedure to configure the Vision switcher to communicate with a Port Expander:

- 1. Navigate to the **Communications Menus** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Comm Setup.
- 2. Press Type on the Communications Menu 1-2.

Commu	unications (1	-2)	44 Back	M Termerel	A CONVER	193 (CONT)	Com Port
This men	nu lets you set up	what each of	the com ports a	re used for.			REMOTE 1 (R1) REMOTE 2 (R2) REMOTE 3 (R3)
Part	Device	Comm	Type Con	nm Settings		16	incrite a (ris)
							Type:
REMOTE	2 NONE					0	Diagnostic 8
REMOTE	3 NONE						Expander
REMOTE	4 NONE						
REMOTE	5 NONE						
REMOTE	6 NONE						
REMOTE	7 NONE						
[2] <b>(</b>							
Тур	e Se	lect	Com Type	Com Settings	Custom     Devices	Ext	ions More

Type — Communications Menu 1-2

- **3.** Use the **Com Port** knob on the **Communications Menu 1-2** to select the communications port that you are connecting the Port Expander to.
  - **BSS4** Select the Remote port on the back of the control panel that you connected the BSS4 to.
  - NetExp Select the port that you want to assign the Net Expander ports to. The expanded ports can be used directly from the switcher, or on the Comtrol DeviceMaster.
- 4. Use the **Device** knob on the **Communications Menu 1-2** to select **Expander**.
- 5. Press Select Device on the Communications Menu 1-2.

Commun	lets you set up v	()	44 Back	which ports.		93	Com Port BSS4 (P	u) (c
Port NEMOTE 1	Device BSS4	Comm Ty R5-422	ype Con 115	im Settings 200 NONE		Î	Device: BS54 NetExp	
Туре	Sele	ct	Com Type	Com Settings	Custom Devices	Exti	a ions	🕶 More

Select Device — Communications Menu 1-2

6. Assign the port expander to the Expander communications port as follows:

- Use the **Device** knob on the **Communications Menu 1-2** to select the Port Expander you want to use. You can choose between from the following:
  - > BSS4 Select this option to assign a BSS4 Serial Port Expander to the selected port.
  - > **NetExp** Select this option to assign a Net Expander to the selected port.
- 7. Press **Com Type** on the **Communications Menu 1-2**.

Commu	unications (1	-2)	44 Back	- • • Tomenti	alcebach	193 (1991)	Com Port: BSS4 (R	1) (°
This men	u lets you set up	your com por	t types					
Port	Device	Comm T	ype Cor	mm Settings		Jâ		
-						10	rype: RS-232 RS-422 RS-422 Nu	
Тур	e Se	elect evice	Com Type	Com Settings	Custom Devices	Exti	na ions	More

Com Type — Communications Menu 1-2

- **8.** Select the type of serial communication that will be used to communicate with the Port Expander as follows:
  - Use the Type knob on the Communications Menu 1-2 to select the type of communications for the selected port. Refer to the section "Communication Settings" on page Eng 9-18 for the specific settings for your Port Expander.
- 9. Press Com Settings on the Communications Menu 1-2.

Communications (1-2) This menu lets you set up your com port par		44 Back	PPTerment)	<b>3</b> 649 (46)	93	Com Por BSS4	t (R1)	
Port	Device	Comm Typ	e Com	m Settings		16		
NEMOTE 1	8554	R5-422	1157	(00 NONE:			Baud: 57600 115200 Parity (F NONE ODD EVEN	ixed):
Туре	Se	elect Co	om Type	Com Settings	Custom Devices	Extr	ra ions	i Mor

Com Settings — Communications Menu 1-2

- **10.** Set the communications settings for the Port Expander as follows:
  - Use the **Baud** knob on the **Communications Menu 1-2** to select the baud rate for the Port Expander. Refer to the section "**Communication Settings**" on page Eng 9-18 for the specific settings for your Port Expander.
  - Use the **Parity** knob on the **Communications Menu 1-2** to select the parity for the Port Expander.
- **11.** Press **HOME** to display the **Confirm Changes Screen**.
- **12.** Press **Confirm** to accept the changes you have made to the communications set up of the switcher. If you are setting up a BSS4, a screen is displayed prompting you to program the BSS4 Serial Port Expander

This completes the procedure for configuring the Vision switcher to communicate with a Port Expander. If you are setting up a BSS4 or a Comtrol DeviceMaster, next you must program the expander.

## **Port Expander Programming**

Some Port Expanders must be programmed to be able to communicate with the devices and the switcher.

#### **BSS4** Programming

Once the switcher has been set up to communicate with the BSS4, you need to program the BSS4. The Vision switcher will start the programming after you confirm the installation change.

Use the following procedure to program the BSS4:

1. Press **Continue** to start programming the BSS4.

**Note** — If you press **Cancel**, a warning message is displayed and you will have to perform the set up of the BSS4 again.

2. Move the SET UP SWITCH on the BSS4 to PROG (Figure 9.3).



Figure 9.3 BSS4 Serial Port Expander — Set Up Switch

- 3. Disconnect the BSS4 Power Supply from the BSS4 to cycle the power Off.
- 4. Reconnect the BSS4 Power Supply to the BSS4 to cycle the power On.
- **5.** Press **Continue** on the Vision control panel. A screen will be displayed informing you that the BSS4 Serial Port Expander has been successfully programmed.

**S** 

**Note** — If you get an error message stating that the BSS4 could not be programmed, you should confirm your settings and try to program the BSS4 again.

- 6. Move the SET UP SWITCH on the BSS4 to NORM.
- 7. Disconnect the BSS4 Power Supply from the BSS4 to cycle the power Off.
- 8. Reconnect the **BSS4 Power Supply** to the BSS4 to cycle the power **On**.
- 9. Press Continue on the Vision control panel.

This completes the procedure for programming the BSS4.

#### **Comtrol DeviceMaster Programming**

Once the Net Expander ports have been created, you must set up Comtrol DeviceMaster. Refer to the documentation that came with the DeviceMaster for information on using the Comtrol® PortVision® software to set up the DeviceMaster.

Use the following information to set up your DeviceMaster:

- You must use a Static IP address for the DeviceMaster. You need to enter this address into the switcher so that it can connect to the DeviceMaster.
- You must set up each serial port on the DeviceMaster for the device you are connecting to it. Ensure the following is set up on the Comtrol PortVision software:

- > Serial Configuration Use the Transmission Standard, Baud, Parity, Data Bits, and Stop Bits information provided by Ross Video.
- TCP Connection Configuration For each serial port on the DeviceMaster, ensure that Enable and Listen are checked and enter a port number for the serial port. Ross Video suggests that you start numbering the ports at 1001. Leave all other setting at their default values.

**Note** — If you are connecting a device using the **RAP** protocol to the DeviceMaster, you must have **Listen** unchecked and enter the **IP address** of the Master Panel in the **Connect To:** field, as well as the **Local IP Port** in the **To Port:** field. The Local Port is found on the **Communications Menu**.

> **UDP Connection Configuration** — For each serial port on the DeviceMaster, ensure that Enable Serial to Ethernet, Enable Ethernet to Serial, and Enable Ethernet Receive from any IP address are unchecked. Leave all other setting at their default values.

## **Communication Settings**

In order to have the Vision switcher communicate with a Port Expander, the Port Expander and the switcher must be set up to communicate with each other.

Use the following communications settings (**Table 9.4**) when connecting your Port Expander to the Vision switcher. Refer to your Port Expander documentation for additional information on setting up your Port Expander.

Device	Trans Standard	Baud Rate	Parity	Data Bits	Stop Bits	Com Protocol
RS-422 Four Port Buffered Smart Switch	RS-422 (TIA/EIA-422)	38400	None	8	1	Native
Net Expander	Network TCP	n/a	n/a	n/a	n/a	Ethernet
Comtrol DeviceMaster	Network TCP	n/a	n/a	n/a	n/a	Ethernet

Table 9.4 Port Expander Communications Settings

## **Assigning Devices to Port Expander Ports**

You will now notice that there are four new serial ports on the **Communications Menu**. These ports are labelled **A**, **B**, **C** and **D**, corresponding to the **Slave Ports** on the Port Expander, and will start with the number of the serial port that the Port Expander is connected to.

For example, if the BSS4 is connected to **Remote 1** port on the control panel, then the four **Extended Remote Ports** will be **Remote 1A**, **Remote 1B**, **Remote 1C**, and **Remote 1D**.

Please note the following about each Port Expander:

- **BSS4** The BSS4 only supports the RS-422 transmission standard. Any device using the RS-232 transmission standard requires a RS-422 to RS-232 converter. Refer to the documentation for your device to ensure you are using the correct type of serial communications.
- **NetExp** The NetExp allows you create virtual serial ports that can be assigned to ethernet based external devices. For example, if you are controlling four channels on an ethernet controlled Character Generator, you can assign each channel to a NetExp port, and only consume a single Remote port.

• **Comtrol DeviceMaster** — The DeviceMaster uses the virtual serial ports of the NetExp to assign serial devices to the serial ports on the DeviceMaster. When you set up a device on one of the virtual serial ports, you must assign it to the IP address of the DeviceMaster and the port number that you assigned to the serial port on the DeviceMaster. The IP address and port number are set up on the DeviceMaster using the Comtrol® PortVision® software that came with the DeviceMaster.

#### Assigning Devices to DeviceMaster Net Expander Ports

Use the following procedure to assign a device to a Net Expanded port on a DeviceMaster:

- 1. Navigate to the Communications Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Comm Setup.
- 2. Select one of the virtual serial ports and set up the device as normal. The **Com Type** must be set to **Network TCP**.
- **3.** Press **More**  $\Rightarrow$  **Device Network** on the **Communications Menu 2-2**.

Communications (1-	2) 44 B	ack IPToment	P PERVICE     193 Prov	Com Port: NetExp (R1)
or	n Panel(R1) IP Settings			
	Remote IP Address:	0.00.0		Client/Server Client Server
	Local IP Address: 0. Local Port: 0	. 0. 0. 0		
Turn Sel	ect Com Ture		Custom	Extra

IP Settings — Communications Menu 1-2

- **4.** Use the **Client/Server** knob on the **Communications Menu 1-2** to select whether the switcher should act as a client or server. Enter the port settings as follows:
  - **Client** Select this option if the switcher should act as the client when communicating with the device. Enter the settings for the switcher as follows:
    - In the **Remote IP Address** field, enter the IP address of the external device.
    - > In the **Remote Port** field, enter the port on the external device that the switcher must connect to.
  - **Server** Select this option if the switcher should act as the server when communicating with the device. Enter the settings for the switcher as follows:
    - > In the **Local IP Address** list, select the IP address of the switcher that you want to use to connect with the external device.
    - > In the **Local Port** field, enter the port on the switcher that the external device must connect to.



**Note** — Do not change the **Local Port** value unless instructed to do so by Ross Video Technical Support.

- 5. Press HOME to display the Installation Change Confirmation Screen.
- 6. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.

- Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
- Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for assigning a device to a Net Expander port on a DeviceMaster.

# **External Panel Modules**

External Vision panel modules, such as the SideBox, must be set up on the external link port that it is connected to.

For information on cabling your external panel module to the Vision control panel, refer to the documentation that came with your external panel module.

Use the following procedure to setup switcher communication with an external panel module:

- 1. Navigate to the **Communications Menus** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Comm Setup.
- 2. Press Type on the Communications Menu 1-2.

Communications (1-2) This menu lets you set up what each of the com ports are used for.	44 Back	(Whitemand)	★ cov/top	03	Com Port REMOTE 8 (R8) ExtLnk 2 (L2) ExtLnk 3 (L3) Device: Automation Ext Module	0.0 3.08
Туре		(contype	-		Mor	*

Device Type — Communications Menu 1-2

- **3.** Assign an External Link port to the external panel module as follows:
  - Use the **Com Port** knob on the **Communications Menu 1-2** to select the communications port on the Vision switcher that is connected to the external panel module.
  - Use the Device knob on the Communications Menu 1-2 to select Ext Module. If the OverDrive Production Control System is set up with the switcher, you cannot assign ExtLnk 2 to Ext Module.
- 4. Press HOME to display the Installation Change Confirmation Screen.
- **5.** Accept or reject the changes you have made as follows:
  - Press Confirm to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for setting up switcher communication with an external panel module. Next you must map the module to a panel row on the Vision control panel.

#### For More Information...

- on assigning modules to a panel row, refer to the section "Mapping a Module to a Row" on page Eng 17-5.
- on how GPIs are assigned by panel row, refer to the section "Auxiliary Control Panel GPIs" on page Eng 14-11.

## **Custom Devices**

The Custom Device setup feature allows you to program serial command protocols for controlling external devices not otherwise supported by the Vision switcher. Custom Devices are also useful in testing currently unsupported commands to external devices, as well as other communications testing.

Custom Device Protocols are supported for the following device classes:

- VTRs
- Video Servers
- Audio Server

**Important** — The option for the external device you want to program a custom device protocol for must be purchased and installed before you can use the custom device protocol.



**Note** — Refer to the specific chapter on the device you are using for information on setting up communications for the custom device.

Custom Device commands allow you to select the signals that the switcher will send to the custom device when you select a command on the switcher.

The supported custom device commands are as follows:

- Seek Timecode
- Rewind
- Frame Reverse
- Play Reverse
- Pause
- Stop
- Play
- Frame Advance
- Fast Forward
- Record
- Diagnostic 1
- Diagnostic 2
- Diagnostic 3

#### **Programming Custom Device Commands**

The **CUSTOM0** and **CUSTOM1** protocols can be programmed for a number of commands that the switcher will send to the custom device. Refer to the documentation that came with your custom device for information on the input signals that the device requires to perform the desired command.



**Note** — Custom Device protocols support only one-way communication. The switcher does not record, or act upon, signals being returned from the custom device.



**Operating Tip** — For more information on the use and limitations of the custom device protocol, refer to the section "**Custom Devices** – **Uses and Limitations**" on page Eng 23-2.

Use the following procedure to program a command for a custom device protocol:

- 1. Navigate to the Communications Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Comm Setup.
- 2. Press Custom Devices on the Communications Menu 1-2.
- **3.** Use the **Custom** knob on the **Custom Device Menu** to select the custom device protocol (**CUSTOM0** or **CUSTOM1**) that you want to program.
- 4. Press Modify on the Custom Device Menu.

Custom Devi	ces Modify	44 Back	•••	1 1000 (m)	13-000		
				Asci/Pr	iram.	Choose Line	0.0
	1 1 2	345678	9 A 8 C D 8	F		Set Nybble	0.0
						Command T SEEK TIMECO REWIND FRAME REVE	ag: DOE Ø RSE 🐑
insert Une	Toggle Nybble	Delete	Toggle Special	a steam	Clea	r mand a	iner:

Custom Devices Modify Menu

- 5. Use the **Command Tag** knob on the **Custom Device Modify Menu** to select the command you want to set up. You can chose between the following:
  - **SEEK TIMECODE** This command applies to VTRs, video servers and audio servers, and is run from the **VTR Remote Menu** and custom controls. When executed, the command sends the VTR Clip Time as a packed BCD of the form HHMMSSFF.
  - **REWIND** This command applies to VTRs, video servers and audio servers and is run from the **VTR Remote Menu** and custom controls.
  - **FRAME REVERSE** This command applies to VTRs, video servers, and audio servers and is run from the **VTR Remote Menu** and custom controls.
  - **PAUSE** This command applies to VTRs, video servers, and audio servers, and is run from the **VTR Remote Menu** and custom controls.
  - **STOP** This command applies to VTRs, video servers, and audio servers, and is run from the **VTR Remote Menu** and custom controls.
  - **PLAY** This command applies to VTRs, video servers, and audio servers, and is run from the **VTR Remote Menu** and custom controls.



**Note** — The **PLAY** command requires the **Roll Clip** feature (**ROLL CLP**) in order to the the command to a transition.

- FRAME ADVANCE This command applies to VTRs, video servers, and audio servers, and is run from the VTR Remote Menu and custom controls.
- **FAST FORWARD** This command applies to VTRs, video servers, and audio servers, and is run from the **VTR Remote Menu** and custom controls.

• **RECORD** — This command applies to VTRs, video servers, and audio servers, and is run from the **VTR Remote Menu** and custom controls.



**Note** — The **FADER POSITION** command is not currently supported by the Vision QMD/X or MD/X switcher.

- **DIAGNOSTIC 1** This command applies to VTRs, video servers, and audio servers, and is run from custom controls only.
- **DIAGNOSTIC 2** This command applies to VTRs, video servers, and audio servers, and is run from custom controls only.
- **DIAGNOSTIC 3** This command applies to VTRs, video servers, and audio servers, and is run from custom controls only.

**Operating Tip** — You can use the **Clear Command** button to erase all the entries you have made for the selected command.

- **6.** Insert a byte into the signal for the selected command as follows:
  - Press **Insert Line** on the **Custom Device Modify Menu** to insert a line, or byte, to the command signal.

Custom Devi	ces Modify	44 Back	•••Termine		93-0000			
Press Insert Line	to create a new Cor	mmand for the selecte	ed Tag			Choose	: Line	0
						Comm SEEK T REWING FRAME	and Tag: MECODE D REVERSE	0.0
inseit Line	Toggle Nybble	Delete	Toggle Special	a dedit	Clea	r mand	)	

Coding a Byte — Custom Devices Modify Menu

- Use the **Set Nybble** knob on the **Custom Device Modify Menu** to select the Hexidecimal value you want to insert in the first nybble of the byte.
- Press **Toggle Nybble** on the **Custom Device Modify Menu** to select the second nybble of the byte.
- Use the **Set Nybble** knob on the **Custom Device Modify Menu** to select the Hexidecimal value you want to insert in the second nybble of the byte.
- **7.** Press **Insert Line** on the **Custom Device Modify Menu** to add additional bytes to the command. Each byte is coded in the same way.



**Operating Tip** — You can use the **Choose Line** knob on the **Custom Device Modify Menu** to select the different bytes for editing.

- 8. Insert a packed Command Flag as follows:
  - Use the **Choose Line** knob on the **Custom Device Modify Menu** to select the byte you want to place the command flag in.
  - Press Toggle Special on the Custom Device Modify Menu.

Custom Devices Modify	44 Back		Asci/Pi	Ø3 Karn	Choose	Line P
					Break O Break O Checksi	
					Comma SEEK TR REWIND FRAME F	IND Tag: MECODE REVERSE
insert Line	Delete Line	Toggle Special	Special Options	Clea	r nmand	-

Toggle Special Setup — Custom Devices Modify Menu

- Use the **Command Flag** knob on the **Custom Device Modify Menu** to select the command flag you want to insert. You can choose between the following:
  - > [Break On] This command flag forces the output to data low.

**Note** — For RS-232 communication, data low is a positive voltage.

- > **[Break Off]** This command releases the Break On command, allowing the output to go off of data low.
- > [Checksum] This command inserts an 8-bit additive checksum byte.



**Note** — The **Posn X**, **Posn Y**, and **Posn Z** command flags are not currently supported by the Vision switcher.

- > [Param...] The Parameter command allows you to insert special parameters into the signal. This command is to be used in conjunction with the Special Options Menu. Refer to the section "Advanced Topics and Tables" on page Eng 23-3 for a description of the available commands.
- 9. Press HOME to display the Installation Change Confirmation Screen.
- **10.** Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for programming a command for a custom device protocol.

#### For More Information...

- on the uses and limitations of the custom device protocol, refer to the section "Custom Devices Uses and Limitations" on page Eng 23-2.
- on the settings available for the protocols, refer to the section "Advanced Topics and Tables" on page Eng 23-3.

# **Extra Options**

The Communications Menu allows you to set up an external device to operate with the Vision switcher. This section (**Table 9.5**) describes each of the extra options on the Communications Menu.

Not all devices support all extra options. For information on a specific device, refer to the Ross Video External Device Setup Sheet for your device.

Audio Mixer Options	Values
Germanter	The Converter option allows you to select the MIDI to Serial converter that you are using to connect to the audio mixer. You can choose between the following:
Converter	• MIDIator — MIDIator <sup>TM</sup> Systems MS-124W
	• SMC — Ross GearLite SMC-9901
Max Channels	The Max Channels option allows you to select the maximum number of channels installed on your audio mixer.
Mixers	The Mixers option allows you to select the number of audio mixers you are connecting together and controlling from the same communications port. You can connect up to two audio mixers together to a single serial communications port.
OD Master	The OD Master option allows you to select the master level on the audio mixer that the OverDrive Production Control System should be controlling.
PGM Output	The PGM Output option allows you select the master level control the switcher is assigned to.
Version	The Version option allows you to select the version number of the audio mixer you are connecting to the selected communications port.
Freq	The Frequency option allows you to select the length of time, in fields, that the switcher will wait between polling the audio mixer for status information.
Audio Server Options	
Bus Address	The Bus Address option allows you to select the Remote Control Address that the audio server is set to.
CG Options	
	The Back-to-Back option allows the switcher to preload the second CG page if OverDrive has back-to-back CG pages in a rundown.
BackToBack	• <b>No</b> — Select this option to have the switcher pause to load the second CG page in a back-to-back CG rundown from OverDrive.
	• Yes — Select this option to have the switcher preload the second CG page in a back-to-back CG rundown from OverDrive.
	The Display Mode option allows you to select how the CG takes a template to the program channel when the Take command is issued. You can choose between the following:
Display Mode	• <b>On Trigger</b> — Select this option to have the template remain hidden until the Play command is sent.
	• <b>Immediately</b> — Select this option to have the template taken on-air as soon as the Take command is issued.
PlayTime	The Play Time option allows you to select the maximum duration for playing an animation, in seconds.

Table 9.5 Extra Option Settings

CG Options	
	The Show on Preview option allows you to have a CG page shown on the preview of the CG when it is prepped by OverDrive.
Show On PV	• <b>NO</b> — Select this option to have the switcher take CG pages directly to air when the take command is received, and not show the page on preview when it is prepped.
	• <b>Yes</b> — Select this option to have the switcher tell the CG to show the page on preview when the page is prepped by OverDrive. The page is taken to program when the take command is received from OverDrive.
	The Software Version option allows you to select the version of software being used on your CG. You can choose between the following:
	• Before 5.0 — Select this option if your CG uses .ins or .icg files.
Software Ver	• 5.0 or later — Select this option if your CG uses .scribe or .scribelist files.
	• XML type — Select this option if your CG uses .xml files.
	• Non-Pro — Select this option for all non-professional versions of the character generator.
	• <b>Pro</b> — Select this option for all professional versions of the character generator.
Timeout	The Timeout option allows you to set the length of time that the switcher will wait for a response from a CG before reporting communication lost.
Editor Options	
	The Custom Control MLE option allows you to select whether memory recalls on a particular MLE perform a custom control rather than recalling the memory. The specific custom control that is run is based on the memory that is being recalled. Memories 1-19 correspond to Bank 1, Custom Controls 1-20; memories 20-39 correspond to Bank 2, Custom Controls 1-20; and so on. You can choose between the following:
	• <b>Any</b> — Select this option to have memory recalls for any MLE run a custom control rather than recall a memory.
CustCtrl MLE	• <b>Pgm-Pst</b> — Select this option to have memory recalls for the Main Program MLE run a custom control rather than recall a memory.
	• <b>MLE1</b> — Select this option to have memory recalls MLE 1 run a custom control rather than recall a memory.
	• <b>MLE2</b> — Select this option to have memory recalls MLE 2 run a custom control rather than recall a memory.
	• <b>MLE3</b> — Select this option to have memory recalls MLE 3 run a custom control rather than recall a memory.
Editor Type	The Editor Type option allows you to select the type of editor you are connecting to the selected communications port.
	The Pattern option allows you to select how you want to access wipe patterns. You can choose between the following:
Pattern	• <b>Pattern #</b> — Select this option to use the wipe pattern numbers to select the wipe on the editor.
	• Wipe Bttn — Select this option to use the wipe button numbers to select the wipe on the editor.
	The Use Break option allows you to select whether the switcher must receive a break command before going into Active Mode. You can choose between the following:
Use Break	• <b>Yes</b> — Select this option to enable the switcher to go into Active Mode once a Break and an Address is received.
	• No — Select this option to enable the switcher to go into Active Mode but the editor sends commands and messages without Breaks.

Pbus Options	
Query Cmd	<ul> <li>The Query Cmd option allows you to select the type of query commands supported by the Pbus device. You can choose between the following:</li> <li>Relaxed — Select this option to be able to control all devices connected to the Pbus device whether they respond to the query command or not.</li> <li>Strict — Select this option to be able to control only devices connected to the Pbus device that respond to query commands.</li> <li>Silent — Select this option to be able to control all devices connected to the Pbus device, without using query commands. The switcher does not sent query commands.</li> </ul>
Robotic Camera Options	
Focus Speed	The Focus Speed option allows you to select the maximum focus speed.
Iris Control	<ul> <li>The Iris Control option allows you to select what you want to control the iris of the camera. You can choose between the following:</li> <li>Lens — Select this option to have the iris controlled by the lens of the camera.</li> <li>Camera — Select this option to have the iris controlled by the camera controller.</li> </ul>
Iris Speed	The Iris Speed option allows you to set the speed at which the iris opens and closes.
Iris Mode	<ul> <li>The Iris Mode option allows you to select how the iris opening is changed. You can choose between the following:</li> <li>Velocity — Select this option to have the iris opening changed by the velocity at which the iris ring is turned. Use this option unless the camera is controlling the iris itself.</li> <li>Incremental — Select this option to have the iris opening changed incrementally by a value. Use this option only if the camera is controlling the iris itself.</li> </ul>
Iris Res	The Iris Res option allows you to select the number of bits in the camera control signal. Different camera head controllers use different numbers of bits. Choose the value that gives you a 100% display when the iris is fully open.
Joystick	<ul> <li>The Joystick option allows you to select the protocol that is used by the positioner on your camera controller. You can choose between the following:</li> <li>Disabled — Select this option to disable joystick/positioner control.</li> <li>Protocol 1 — Select this option to enable Pan, Tilt, Zoom, and Focus control.</li> <li>Protocol 3 — Select this option to enable Pan, Tilt, Zoom, Focus, Iris, Mped (Black Level) and Elevation control.</li> </ul>
Lens Type	<ul> <li>The Lens Type option allows you to select the type of lens that is being used on the camera. You can choose between the following:</li> <li>Rainbow — Select this option if the camera uses a Rainbow-CCTV Lens.</li> <li>Fujinon — Select this option if the camera uses a Fujinon/Canon Telecon Lens.</li> </ul>
Master Ped	The Master Pedestal option allows you to add ( <b>Yes</b> ) or remove ( <b>No</b> ) the Pedestal (Black) button from the <b>Camera Head Control Menu</b> .
Pan/Tilt Damping	The Pan/Tilt Damping option allows you to select the amount of damping you want on pan and tilt movements. The higher the value, the more damping is applied.
Pan/Tilt Speed	The Pan/Tilt Speed option allows you to select the maximum pan and tilt speed. The higher the value, the faster the pan and tilt speed.
Pan Invert	The Pan Invert option allows you to select whether the positioner movement is inverted for panning.
Panel ID	The Panel ID option allows you to select a unique ID that the camera uses to identify the Vision switcher.

Robotic Camera Options	
RclTime	The RclTime option allows you to select the amount of time that the switcher allows for a camera to recall a shot.
Poll	<ul> <li>The Poll option allows you to select which camera is polled. You can choose between the following:</li> <li>Selected — Select this option to have only the currently selected camera polled. Only use this option if instructed to do so by Ross Video Technical Support.</li> <li>All — Select this option to have all cameras polled.</li> </ul>
Select Delay	The Select Delay option allows you select the length of time, in fields, that the switcher will wait after selecting a camera.
SerialSwitch	<ul> <li>The SerialSwitch option allows you to select the type of serial switch you are using to connect to your camera. You can choose between the following:</li> <li>STS-12 — Select this option to assign an STS-12 Serial Control Transfer Switch to the selected port.</li> <li>CP-RMR-S — Select this option to assign a CP-RMR-S Serial Receiver to the selected port.</li> <li>DS-4 — Select this option to assign a DS-4 Device Server to the selected port.</li> </ul>
ShotOffset	The ShotOffset option allows you to select whether shots are indexed based on 0 or 1.
Tilt Invert	The Tilt Invert option allows you to select whether the positioner movement is inverted for panning.
Zoom Speed	The Zoom Speed option allows you to select the maximum zoom speed.
Z Speed	The Z Speed option allows you to select the speed that height or elevation changes are performed.
Router Options	
Base	The Base option allows you to select whether the router starts counting crosspoints at $0$ or $1$ .
Level Base	The Level Base option allows you to select whether the router starts counting levels at <b>0</b> or <b>1</b> .
Num Levels	The Num Level option allows you to select the number of levels that the router is using. This sets the number of levels that the router switches when the input BNC from the router is set to All levels.
Src & Dest Base	The Src & Dest Base option allows you to select whether the router starts counting source and destinations at <b>0</b> or <b>1</b> .
Xpts	The Xpts option allows you to select the number of crosspoints that are available on the router.
Serial Tally Options	
Rate	The Rate option allows you to select the rate, in fields, between update messages sent by the switcher to the tally device.
Data Txfr	The Data Txfr option allows you to set the message size protocol for the tally device. You can select <b>Minimal</b> , <b>Normal</b> , or <b>Complete</b> .
Start	The Start option allows you to select <b>None</b> or <b>Init</b> as the start message for the tally device.

Serial Tally Options					
	The At Black option allows you to set the at black action for the tally interface. You can select between the following:				
At Black	• All Off — Select this option to have the switcher report that nothing is on-air when the switcher is as black.				
	• Active On — Select this option to have the switcher not report anything different when the switcher is at black.				
	The Source Name option allows you to set the input name that the switcher passes to the tally device. You can choose between the following:				
Source Name	• <b>Router Src</b> — Select this option to use the router source names that are being passed through the switcher from a router.				
	• <b>BNC Name</b> — Select this option to use the input BNC name.				
Slot 1	The Slot 1 option allows you to select the MLE that you want to assign to the first MLE Slot on the tally device.				
Slot 2	The Slot 2 option allows you to select the MLE that you want to assign to the second MLE Slot on the tally device.				
Slot 3	The Slot 3 option allows you to select the MLE that you want to assign to the third MLE Slot on the tally device.				
Slot PGM	The Slot PGM option allows you to select the MLE that you want to assign to the Program MLE Slot on the tally device.				
Video Server Options					
TargetMachine	The TargetMachine option allows you to select the video server that you are assigning to the selected communications port.				
Madia IDL anoth	The MediaIDLength option allows you to select the maximum character length of the clip IDs displayed on the <b>VTR Clips, Inpoint/Outpoint</b> , and <b>Remote Control Menus</b> . You can choose between the following:				
WediarDLengui	• Short IDs — Select this option if your device uses an ID length of up to 8 characters.				
	• Long IDs — Select this option if your device uses an ID length of up to 32 characters.				
TimeOut	The TimeOut option allows you to select the specify the length of time, in fields, that the switcher will wait for a reply from the Video Server before trying to send a command again.				
Send Tries	The Send Tries option allows you to specify the number of times that the switcher will try to send the same command to the Video Server if the switcher has not received a confirmation response.				
	The Cmd Queuing option allows you to select whether the switcher must receive replies for every command sent to the Video Server. You can choose between the following:				
Cmd Queuing	• <b>Strict</b> — Select this option to have the switcher require a confirmation message from the Video Server for each command. The switcher will re-send a command (as set by the Send Tries value) until it receives a confirmation message from the Video Server.				
	• <b>Relaxed</b> — Select this option to have the switcher not require a confirmation message from the Video Server for each command.				
Record Time	The Record Time option allows you to set the maximum number of minutes that the Video Server will record for when it received the Record custom control command.				

Video Server Options	
Playback Mode	<ul> <li>The Playback Mode option allows you to set the playback mode that your Video Server is using. You can choose between the following:</li> <li><b>PB</b> — Select this option if your device does not go to Electronic-to-Electronic (EE) mode.</li> <li><b>PB/EE</b> — Select this option if your device does go to EE mode. If you select this option, you enable the serial device to automatically go into PB/EE mode. If a stop command is issued, the device enters EE mode. If a pause command is issued, the device stays in Playback mode.</li> </ul>
Play w/Alpha	<ul> <li>The Play with Alpha option allows you to have the switcher play both the video and alpha channels from a video server. Both the video and alpha input BNCs must have the video server assigned to them, and must be set up as an auto key to associate the video with the alpha.</li> <li>No — Select this option to not have the associated alpha video channel played on the video server when the video channel is played.</li> <li>Yes — Select this option to have both the video and alpha channels played on the video server at the same time. The switcher does not check the status of the video server channels before sending the play command in this mode.</li> </ul>
Port Cmds	<ul> <li>The Port Cmds option allows you to set whether your Video Server supports the Open Port, Select Port, and Close Port commands. You can choose between the following:</li> <li>No — Select this option if your device does not support port commands.</li> <li>Yes — Select this option if your device does support port commands.</li> </ul>
ExtendedChar	<ul> <li>The ExtendedChar option allows you to set whether the switcher allows non-printing characters for clip IDs. You can choose between the following:</li> <li>No — Select this option to have the switcher replace non-printing characters with spaces.</li> <li>Yes — Select this option to have the switcher use the extended character set.</li> </ul>
LoopRecueTime	The LoopRecueTime option allows you to set the amount of time, in frames, before the end of a clip that the switcher sends a loop command.
Clip List	The Clip List option allows you to associate a Video Server with either Clip List A or Clip List B, or use the Floating list. Clip List A and Clip List B are cached for fast access when the associated Video Server is selected. Each Clip List can only be associated with one physical device.
LoopMinLength	The LoopMinLength option allows you to set the minimum length of a clip, in seconds, that can be looped. The minimum length is three (3) seconds.
VTR Options	
TargetMachine	The TargetMachine option allows you to select the video server that you are assigning to the selected communications port.
Decode NAKs	<ul> <li>The Decode NAKs (Not Acknowledgement) option allows you to have the switcher decode the NAK messages sent from the VTR to the switcher. The NAK messages must be decoded for the switcher to act on them. You can choose between the following:</li> <li>No — Select this option to have the switcher not decode the NAK messages. Only select this option if you are encountering problems using the Play command with your device or as advised by Ross Video Technical Support.</li> <li>Yes — Select this option to have the switcher decode the NAK messages.</li> </ul>
Wait nFields	The Wait nFields option allows you to set the length of time the switcher waits before assuming that a Play command failed, or was not received by the VTR.
NPlayRetries	The NPlayRetries option allows you to set the number of times the switcher attempts to send a Play command to the VTR.

# **Custom Controls**

## In This Chapter

This chapter provides general information on setting up and naming custom control banks, as well as programming, naming, and editing custom control buttons.

The following topics are discussed in this chapter:

- Custom Controls
- Custom Control Interfaces
- Custom Control Banks
- Programming Control Panel Functions
- Programming Special Functions
- Attaching Custom Controls to Panel Buttons
- Naming Custom Controls
- Editing Custom Controls
- Managing Custom Controls
- Deleting Custom Controls
- Custom Control Shortcuts



**Operating Tip** — A **Custom Control Worksheet** is provided to assist you in keeping track of which custom control have been programmed. Refer to the section "**Custom Control Worksheets**" on page Eng 21-18 for a copy of this worksheet.

# **Custom Controls**

Once programmed, a custom control can be played back by pressing a button. The custom control can be as simple as triggering an output GPI pulse, or as complex as recalling a specific memory register, performing a switcher transition, and flying a group of Keys.

Custom Control functions can be broken down into the following groups:

- **Custom Control Banks** Up to **12** custom control buttons can be set up as Bank buttons. Each bank can contain a complete set of custom controls. When you select, or press, a custom control Bank button, all the non-Bank custom control buttons switch to the custom controls that were recorded in that Bank.
- **Control Panel Functions** A custom control can be programmed to play back a series of control panel button presses. Menu selections, however, cannot be recorded.
- VTR Functions A custom control can be programmed to send specific commands, such as play, cue or rewind, to a VTR or Video Server. The targeted server or VTR must be installed before you are able to record a custom control for it. Refer to the following sections for more information on VTR custom controls:
- **DVE Functions** A custom control button can be programmed to send specific commands, such as play effect, frame advance or stop, to the Primary External DVE. The DVE functions do not apply to the Internal Squeeze & Tease DVE.
- **Time Clock Functions** A custom control can be programmed to start, stop, or reset the preview overlay clock.
- **Pbus Functions** A custom control can be programmed to send commands to a Pbus device.
- **Special Functions** A custom control can be programmed with a number of special functions, such as fire GPIs, goto Menus, and pause a custom control. Refer to the section "**Programming Special Functions**" on page Eng 10-15 for more information on special functions.
- **Monitor Wall Functions** A custom control can be programmed to load a monitor wall layout, assign channels, and modify text on a monitor wall. The targeted monitor wall must be installed before you are able to record a custom control for it.
- Audio Server Functions A custom control can be programmed to send specific commands, such as play, cue or rewind, to an Audio Server. The targeted server must be installed before you are able to record a custom control for it.

**Note** — When recording a memory recall in a custom control, it may be necessary to add a pause of between 1-10 frames after the memory recall.

#### For More Information...

- on storing custom controls, refer to the section "Storing and Recalling Files and Setups" on page Eng 13-4.
- on programming custom control buttons, refer to the section "**Programming Control Panel Functions**" on page Eng 10-8.
- on creating a custom control bank, refer to the section "Custom Control Bank Setup" on page Eng 10-5.
- on Video Checksum custom controls, refer to the section "Video Checksum Custom Controls" on page Eng 17-33.

# **Custom Control Interfaces**

Each switcher supports up to **12** banks of **48** custom controls. These custom controls can be accessed either from the Custom Control Bus, the Soft Shot Box Menu, or from the optional Custom Control Shot Box Module.

#### **Custom Control Bus**

The custom control bus on the Vision switchers is located just above the Program/Preset MLE (**Figure 10.1**), and has the same number of number of buttons as a crosspoint group. Up to **12** of the custom control buttons can be assigned as **Bank** buttons, allowing you to increase the total number of custom control you can have.



Figure 10.1 Vision 2X Custom Control Bus

## **Custom Control Soft Shot Box**

The Custom Control Soft Shot Box allows you access to all forty custom controls that can be programmed per Custom Control Bank on the Touchscreen Display. From the menu, you select the Bank you want to use and the Custom Control on that Bank that you want to run.

The Custom Control mnemonic names and colors are shown on the buttons.

Navigate to the **Custom Control Soft Shot Box Menu** as follows:

• Press HOME ⇒ Effects ⇒ More ⇒ CC Soft Shot Box.





If you are recording, or inserting into, a custom control, all of the custom control buttons on the Custom Control Soft Shot Box Menu appear gray, except for the button for the custom control

being recorded. A red Record icon is shown on the custom control that is being recorded, or inserted into. Pressing that button will stop the recording.

### **Custom Control Shot Box Module**

The Custom Control Shot Box Module (**Figure 10.2**) allows you to map custom controls from various banks to any of the **28** buttons on the Shot Box Module. Each custom control is mapped to a position on a Shot Box Page that corresponds to a button on the Shot Box. When the button on the Shot Box is pressed, the corresponding custom control is run. Additional commands such as selecting other pages can also be assigned to buttons on a page.



Figure 10.2 Shot Box Module

The active Shot Box Page is indicated in reverse text on the mnemonic button. The currently running custom control is indicated by the mnemonic text flashing between reverse text and normal. To avoid confusion, choose fonts and colors so the page buttons look different from the custom control buttons, and so you can tell the active page button from the other page buttons (its font is reversed between normal and inverted).

#### For More Information...

- on setting up the Custom Control Shot Box Module, refer to the section "Custom Control Shot Box Module Setup" on page Eng 15-2.
- on setting up Shot Box Pages, refer to the section "Creating Shot Box Pages" on page Eng 15-4.

# **Custom Control Banks**

Before programming the actual custom controls themselves, you must determine whether or not you want to enable custom control banks. **Custom Control Banks** allow you to group custom controls together, separate from custom controls on other banks. Up to **12** custom control banks can be created. Each bank is assigned to a custom control button, similar to how a custom control is recorded to a custom control button. When you select different Banks, the remaining custom control buttons switch to the custom controls that were recorded to the selected bank.

Two types of banks are available; **Normal** and **Audio**. Normal banks are for storing normal custom controls dealing with typical switcher video functions such as recalling memories and performing a transition. Audio banks are used when custom controls are created for use when the switcher is in **Audio Custom Control** mode, and remotely operates an audio mixing board through the PGM and PST bus crosspoints.

#### **Custom Control Bank Setup**

Use the following procedure to set up a custom control bank:

- 1. Navigate to the Custom Controls Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ More ⇒ Custom Controls.

Custom Controls		44 Back	Winneni a	HER WARE IN STREET	Bank:
Use this menu to assign custom control buttons to banks and assign bank types, or to assign the quick record function to a custom control button. Buttons with 4* or '@' have macros assigned.	Record: Pause:	40 NONE	Bank 1 bttn: Bank 2 bttn: Bank 3 bttn: Bank 4 bttn: Bank 5 bttn: Bank 6 bttn: Bank 7 bttn: Bank 9 bttn: Bank 10 bttn: Bank 11 bttn: Bank 12 bttn:	NONE 02 03 04 05 NONE NONE NONE NONE NONE NONE NONE	Bank 2 (2) Bank 3 (3) Bttn. NONE *Button # 1 *Button # 6
Setup Banks And Bank N	ame ame	etup Shot ox Modules			

Custom Controls Menu

- **2.** Assign a custom control bank type as follows:
  - Use the **Bank** knob on the **Custom Controls Menu** to select the bank you want to enable.
  - Use the **Button** knob on the **Custom Controls Menu** to select the custom control button that you want to assign as the bank. The custom control button you have selected lights up on the control panel.



**Operating Tip** — Select **NONE** if you want to disable a bank that you have previously set up. This does not delete the custom controls on that bank. Assigning that bank to a button again, allows the custom controls on that bank to be accessible again.

- Use the **Type** knob on the **Custom Controls Menu** to select the custom control bank type you want to create. You can choose between the following:
  - > **Audio** Select this option for custom controls that communicate with external audio mixers.
  - Normal Select this option for custom controls that perform any function except communicating with external audio mixers.

- 3. Press HOME to display the Installation Change Confirmation Screen.
- 4. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedures for setting up a custom control bank. Once you have created all the custom control banks you need, you should name them.

#### **Naming Custom Control Banks**

The name you apply to a custom control bank appears on the menus, the mnemonic above the custom control bank button, and the buttons on the Shot Box Menu. This allows you to easily distinguish between different custom control banks, and between banks and custom controls.



**Operating Tip** — You can revert the name of a bank to the default at any time by pressing **Default** on the **Bank Names Menu**. This will not default any custom mnemonic settings.

Use the following procedure to name custom control banks:

- 1. Navigate to the Custom Controls Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ More ⇒ Custom Controls.
- 2. Press Modify Bank Name on the Custom Controls Menu.



Bank Names Menu

- **3.** Name a custom control bank as follows:
  - Use the **Bank number** knob on the **Bank Names Menu** to select the custom control bank you want to name.

**Operating Tip** — Refer to the section "Using the Naming Menus" on page Eng 5-16 for more information on using the **Bank Names Menu** to enter a name, or set up the mnemonics for the custom control button.

Enter the new name for the custom control bank in the **New Name** field. The name can be no more than **8** characters in length.

- **4.** Press **Accept New Name** on the **Bank Names Menu** to store the new name and mnemonic settings.
- 5. Press HOME to display the Installation Change Confirmation Screen.
- 6. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for naming a custom control bank.

# **Programming Control Panel Functions**

This section provides information on programming standard control panel functions, such as crosspoint selection and other button presses. Refer to the section "**Programming Special Functions**" on page Eng 10-15 for information on programming special functions.

If you are creating a custom control that contains re-entered MLEs and intend to use the custom control on different switchers, or you are creating a custom control for use with an OverDrive® Production Control System, you should create a Relative Custom Control. Refer to the section "**Relative Custom Controls**" on page Eng 10-11 for more information.

In a MultiPanel configuration, custom controls only record actions for the MLEs that are assigned to the control panel that the custom control is being recorded on. If that custom control is run on a different control panel, with different MLEs assigned to it, the custom control still performs actions on the MLEs that were assigned to the original control panel.



**Note** — Entering the **Custom Control Menu** stops all custom controls that were started from that control panel, but does not affect running custom controls that were started from other control panels. You can still start a custom control from another control panel.



**Operating Tip** — You can record a custom control to a Bank button, however, you will not be able to run that custom control directly from the control panel.

Use the following procedure to program a custom control:

- 1. Navigate to the Custom Controls Menus as follows:
  - Press **HOME** ⇒ **Custom Controls**. If the **Custom Control** button is grayed out, the **Custom Control Menu** is being displayed on another panel connected to the system.

Custom Contr	ols (1-2)	44 Back		Copy Up	<b>13</b> Swap	Bank: Bank 1	(1)
Custom Control t	ouffers are empty						6
Selected: Bank 1	Button 1 (Custom0	1]				Button	
Custom Control L # = norma	egend: I Custom Control bx	utton				Custon Custon	n02 # 2 0 n03 # 3 0
Start	Modify	<b>&amp;</b> (10)	Start Relative	Copy / Mov	e Deletr	e Macro	More

Custom Controls Menu 1-2

- 2. Select the custom control button you want to record to as follows:
  - Use the **Bank** knob on the **Custom Controls Menu 1-2** to select the bank that you want to record the custom control on.
  - Use the **Button** knob on the **Custom Controls Menu 1-2** to select the custom control button you want to record to.

**Important** — Custom Control buttons with an **\*** or an **@** next to them have already been programmed. For information on editing this custom control, refer to the section **"Editing Custom Controls**" on page Eng 10-25.



**3.** Press **Start Recording** on the **Custom Controls Menu 1-2**. The custom control button that is being recorded to starts to flash, indicating that a custom control is being recorded to that custom control button.

**Note** — If you do not want to save the custom control you just recorded, or you do not want to record a custom control, press **Cancel Recording**.

Custom Controls (1-2)	44 Back	- PP Tormard	Copy Up	33 Swap	Bank: Bank 1 (1)
Recording					
Selected: Bank 1 Button 5 [Custom05]					Button:
Custom Control Legend:					Custom04 # 4 Custom05 # 5
Finish Recording	Cancel	Insert			More Nore

Recording — Custom Controls Menu 1-2

- **4.** Press the buttons on the control panel that you want to have recorded in the custom control. Refer to the section "**Tips for Creating Custom Controls**" on page Eng 10-9 for more information on what types of actions can be recorded into a control panel custom control.
- 5. Press **Finish Recording** on the **Custom Control Menu 1-2** to finish recording to the custom control. The custom control button will stop flashing.

This completes the procedure for programming a custom control.

#### For More Information...

- on storing custom controls, refer to the section "Storing and Recalling Files and Setups" on page Eng 13-4.
- on the setting the Multiple Custom Control option, refer to the section "**Personality List**" on page Eng 11-2.

## **Tips for Creating Custom Controls**

A control panel custom control allows you to automate a series of button presses into a single macro. There are, however, a number of things that you must keep in mind when creating a custom control in order to create a custom control that will produce the desired effect. These tips are as follows:

- Certain custom control functions can be assigned to shortcut buttons, allowing quick access to these functions from control panel buttons. Refer to the section "Custom Control Shortcuts" on page Eng 10-30 for more information on custom control shortcuts.
- If you are including a memory recall in the custom control, you must ensure the Auto Recall settings are the same as when the memory was stored. This ensures a consistent output.
- For non crosspoint buttons, a custom control only records that a specific button was pressed, and does not record the state that the button was in. For example, if you press the **TIME CLOCK** button on the **Preview Overlay** module while recording a custom

control, the custom control will only record that the button was pressed. If you run the custom control immediately after recording it, **TIME CLOCK** is turned off.

- A custom control records the specific bus map source that is mapped to the crosspoint button that is selected, and not the specific crosspoint button. This allows a custom control created with one bus map to be run with a different bus map, as long as the same bus map source exists in the different bus map.
- To program a custom control that will recall a memory and then perform a transition, you must recall the memory on the MLE you want to perform the transition on, then use the **Cut** or **Auto Trans** buttons to perform the transition. A custom control cannot record the movement of a fader.
- A custom control will not automatically compensate for the time a memory recall or transition will require to complete. In these cases, you must insert a custom control pause after the event that requires time to complete.
- You can insert a **Custom Control Hold** command into a custom control that will hold the custom control at a specific point until the continue command is received. The custom control is continued by either pressing the custom control button again, or by a GPI Input trigger.
- You can create a **Looping Custom Control** by inserting a **Loop CC** event into the custom control.
- If you are creating a long or **Looping Custom Control**, you can stop that custom control by pressing the custom control button. This applies only to the custom control assigned to that button.
- You can insert a **Run Custom Control** command into a custom control that will automatically run another custom control. If the **Multiple Custom Control** feature is active, both custom controls can run at the same time. If the **Multiple Custom Control** feature is turned off, inserting a Run Custom Control command ends the recording, and playing, of the first custom control. Refer to the section "**Running Multiple Custom Controls**" on page Eng 10-13 for information on running multiple custom controls. If a custom control starts multiple custom controls, you must stop each one individually, or use the **Stop Other Custom Control** command.
- You can run multiple custom controls at the same time by pressing the corresponding custom control button. If a custom control is already running, pressing the button again will stop it.
- You can insert a Select Memory Bank command into a custom control that will select different memory bank(s) when the custom control is run. To insert the Select Memory Bank command into a custom control, select the memory bank(s) you want to select as you are recording the custom control. A custom control can have multiple Select Memory Banks. If you only press the BANK button, the next successive Bank is recorded, depending on what Memory Bank Cycle is set to. Refer to the section "Personality List" on page Eng 11-2 for more information on Memory Bank Cycle.
- You can create a custom control that will affect an MLE that is not assigned to your control panel by creating the custom control on a control panel that does have the MLE assigned to it.
- A custom control that selects a source on an MLE will select the correct source when a different bus map is used, only if the original bus map still exists on the switcher.
- If you include a button in a custom control that has another custom control attached to it, the command to run the second custom control is ignored when the initial custom control is run. This does not apply to actual custom control buttons.
#### **Relative Custom Controls**

Relative Custom Controls store the MLE re-entry position so that they can be taken on-air from any MLE that is re-entered on the **PGM/PST MLE**. For example, if you have **MLE 2** re-entered into **MLE 3** (**Figure 10.3**), of a **Vision 2.5**, and record a standard custom control event for **MLE 2**, that custom control event will only run on **MLE 2**. The standard custom control will only record that the buttons on **MLE 2** were pressed, and does not record that the MLE was re-entered into **MLE 3**.



Figure 10.3 MLE 2 Re-entered into MLE 3, the Program/Preset MLE

If you record the same events as a relative custom control, you could recall the button presses made on MLE 2 on MLE 1 (Figure 10.4), if MLE 1 is re-entered into MLE 3.



Figure 10.4 MLE 1 Re-entered into MLE 3, the Program/Preset MLE

**Note** — Relative Custom Controls can only be properly recorded and run on upper MLEs that are re-entered onto the PGM/PST MLE. If the MLE is not re-entered, you will not be able to properly record or run a relative custom control. Instead, the relative custom control will act like a normal custom control when run.

Relative custom controls are not MLE specific, as normal custom controls, but instead are re-entry specific. This means that the re-entry order, or levels that the relative custom control was recorded on, do not need to be the same in order to run that custom control. For example, if we again record a relative custom control on **MLE 2**, which is re-entered into **MLE 3** (**Figure 10.3**), we can run that relative custom control with more or fewer MLEs. If we have **MLE 1** re-entered into **MLE 2** and **MLE 2** re-entered into **MLE 3** (**Figure 10.5**), the relative custom control is run on **MLE 1**.



Figure 10.5 MLE 1 Re-entered into MLE 2, Re-entered into MLE 3, the Program/Preset MLE



**Important** — If you record a relative custom control across multiple re-entered MLEs, at least the same number of MLEs must be re-entered in order to run the entire custom control. For example, if a relative custom control that uses 2 MLEs is run on a one MLE switcher, the actions to be run on the second MLE are ignored.

If we have no MLEs re-entered (Figure 10.6), the relative custom control is run on MLE 3.



Figure 10.6 MLE 3, the Program/Preset MLE with no Re-entry

You can run the same relative custom control on multiple control panels at the same time. However, a relative custom control can only be stopped from the control panel that it was started on. The same relative custom control is treated as an independent custom on each control panel.

#### **Programming Relative Custom Controls**

Use the following procedure to program a relative custom control:

- 1. Set up your MLE re-entry configuration to record the relative custom control at the re-entry level you want. Refer to the section "**Re-entry**" on page Ops 4-12 for more information on MLE re-entry.
- 2. Navigate to the Custom Controls Menus as follows:
  - Press **HOME** ⇒ **Custom Controls**. If the **Custom Control** button is grayed out, the **Custom Control Menu** is active on another panel connected to the system.

Custom Controls (1-2)	44 Back	)   PP Tormand	Copy Up	93 Swap	Bank: Bank 1	(1)
Custom Control buffers are empty						
Selected: Bank 1 Button 1 [Custom01]					Button	
Custom Control Legend:					Custon	n02 # 2
					Custon	
2000 ( 10) ( 100 ( 100 ( 100 ( 100 ( 100 ( 100 ( 100 ( 100 ( 100 ( 100 ( 100 ( 100 ( 100 ( 100 ( 100 ( 100 ( 100 ( 100 ( 100 ( 10) ( 100 ( 10) ( 100 ( 100 ( 100 ( 100 ( 100 ( 10) ( 100 ( 100 ( 100 ( 100 ( 10) ( 100 ( 10) ( 100 ( 10) ( 100 ( 100 ( 100 ( 10) ( 100 ( 10) ( 100 ( 10) ( 100 ( 10) ( 100 ( 10) ( 10) ( 10) ( 10) ( 10) (	~	These Balabas	Concernation			
Recording Name	<b>₽</b> ((a)	Recording	Macros	Delete	Macro	More

Custom Controls Menu 1-2

- **3.** Select the custom control button you want to record to as follows:
  - Use the **Bank** knob on the **Custom Controls Menu 1-2** to select the bank that you want to record the custom control on.
  - Use the **Button** knob on the **Custom Controls Menu 1-2** to select the custom control button you want to record to.

 $\wedge$ 

**Important** — Custom Control buttons with an **\*** or an **@** next to them have already been programmed. For information on editing this custom control, refer to the section **"Editing Custom Controls**" on page Eng 10-25.

4. Press **Start Relative Recording** on the **Custom Controls Menu 1-2**. The custom control button that is being recorded to starts to flash, indicating that a custom control is being recorded to that custom control button.

- **5.** Press the buttons on the control panel that you want to have recorded in the custom control. Refer to the section "**Tips for Creating Custom Controls**" on page Eng 10-9 for more information on what types of actions can be recorded into a control panel custom control.
- **6.** Press **Finish Recording** on the **Custom Control Menu 1-2** to finish recording to the custom control. The custom control button stops flashing.

This completes the procedure for programming a relative custom control.

### **Running Multiple Custom Controls**

The Multiple Custom Controls feature allows you to have a single custom control start multiple other custom controls, or you can manually start multiple custom controls using the corresponding custom control buttons. All the custom controls will continue to play out until they reach the end, or loop (**Figure 10.7**).

**Important** — The switcher does not track custom controls that are started as part of another custom control. Running multiple custom controls that start the same custom control, or editing a custom control that is run by another custom control, could produce unexpected results. Only Relative custom controls can have multiple instances of the same custom control running at the same time.



**Operating Tip** — You can insert a **Stop Other Custom Controls** command that will stop all other running custom controls, except the one that is currently running.



Figure 10.7 Multiple Custom Controls Feature On

If the Multiple Custom Controls feature is turned off, a Run Custom Control command ends the current custom control. Pressing another custom control button also stops the first custom control and starts the second (**Figure 10.8**).



Figure 10.8 Multiple Custom Controls Feature Off

You must have the multiple custom controls feature enabled from the Personality Menu to be able to run multiple custom controls.

#### For More Information...

- on the custom control bus, refer to the section "Custom Controls" on page Eng 10-2.
- on programming special custom control commands, refer to the section "**Programming Special Functions**" on page Eng 10-15.

- on naming a custom control, refer to the section "Naming Custom Controls" on page Eng 10-24.
- on storing custom controls, refer to the section "Storing and Recalling Files and Setups" on page Eng 13-4.
- on setting the Multiple Custom Control feature, refer to the section "**Personality List**" on page Eng 11-2.

# **Programming Special Functions**

Special functions allow you to include events not associated with a button press into a custom control, such as a Time Clock function. A special function can be inserted into any existing custom control, or used when creating a new custom control.



**Note** — Entering the **Custom Control Menu** stops all custom controls that were started from that control panel, but does not affect running custom controls that were started from other control panels.

Use the following procedure to insert a special custom control function:

- 1. Navigate to the Custom Controls Menus as follows:
  - Press HOME ⇒ Custom Controls. If the Custom Control button is grayed out, the Custom Control Menu is active on another panel connected to the system.
- 2. Select the custom control you want to record to.

#### 3. Press Start Recording ⇒ Insert Special.

Insert Specia	ni (1-2)	44 Back	] ₩foreard (	Copy Up	93,5wap	
4 VTR	DVE	Time Clock	Special	Pbus	ð cg	More
Insert Specia	1 (2-2)	44 Back	I PP Tormacori	Copy Up	13 Swap	
Router	Monitor Wall	Audio Server	Robotic     Camera	Video Checksun	15.)	위 More

Insert Special Menus

- 4. Select the **Device** or **BNC** that you want to apply the command to.
- **5.** Select the command you want to insert into the custom control. Refer to the following table (**Table 10.1**) for a list of available commands for your device.
- 6. Press **Insert** to insert the selected command into the custom control.
- 7. Press HOME.
- 8. Press Custom Controls on the Main Menu 1-2.

**9.** Press **Finish Recording** on the **Custom Controls Menu 1-2**, or the flashing custom control button, to finish recording to the selected custom control. The custom control button stops flashing.

This completes the procedure for inserting a special custom control function.

Class	Commands	Sub-Menu	Description				
External Devic	es						
Audio Mixer	Assign Audio	Special	The Assign Audio custom control has two roles when working with audio. In normal mode, it allows you to access the levels for the audio channel or group you have assigned to that button. In audio override mode, it allows you to perform audio only transition and override the normal audio follow video operation.				
	Audio All Off		The Audio All Off custom control allows you to fade all audio channels on either the program or preset bus off. This can be useful for quickly removing all audio from either bus, or taking all audio channels off-air after you have performed an Audio Memory Recall.				
Audio Memory Audio CH On			The Audio Memory custom control allows you to recall a memory that has been stored on the Audio Mixer. This can be used to take a number of audio channels on-air at different levels all at once. Refer to the documentation that came with your Audio Mixer for more information on storing audio memories.				
			The Audio Channel On custom control allows you to turn an audio channel or group, on at the level it was last on at, or leave it unchanged as the chann is already on-air. This can be useful if you want to take an audio channel, o group, on-air at once. You can use the Audio Channel On for either the program or preset buses.				
			You can include a number of Audio Channel On events in a single custom control, allowing you to turn multiple audio channels, or groups, on for either the program or preset buses. Unlike the <b>Audio Memory</b> function, the Reset Audio will return the switcher to audio follow video operation.				
Audio CH Off			The Audio Channel Off custom control allows you to turn an audio channel, or group, off. This can be useful if you want to take an audio channel, or group, off-air at once. You can use the Audio Channel Off for either the program or preset buses.				
			You can include a number of Audio Channel Off events in a single custom control, allowing you to turn multiple audio channels, or groups, off for either the <b>Program</b> or <b>Preset</b> buses.				
	PGM Audio Lvl		The PGM Audio Level custom control allows you to override the levels for audio channels on the <b>Program</b> bus. If the audio channel is already on-air, you can change the level or take it off-air, if the channel is off, you can take the channel on-air as an override. <b>PGM Audio Level</b> custom controls differ from <b>Audio Channel On</b> custom controls in that you select the level that you want the audio channel to be set to. When run, the custom control will alter the level of the channel, even if it is on-air. <b>Audio CH On</b> will only take the channel on-air if it is off and will not change the level. This could be useful when you want to alter the levels of a number of channels, or groups, at the same time.				
			You can include a number of PGM Audio Level events in a single custom control, allowing you to alter multiple audio channels, or groups, at the same time.				

Table 10.1 Insert Special Custom Control Commands

Class	Commands	Sub-Menu	Description		
	PST Audio Lvl		The PST Audio Level custom control allows you to override the levels for audio channels on the preset bus. If the audio channel is already on-air, you can change the level or take it off-air, if the channel is off, you can take the channel on-air as an override. <b>PST Audio Level</b> custom controls differ from <b>Audio Channel On</b> custom controls in that you select the level that you want the audio channel to be set to. When run, the custom control will alter the level of the channel, even if it is on-air. <b>Audio CH On</b> will only take the channel on-air if it is off and will not change the level. This could be useful when you want to alter the levels of a number of channels, or groups, at the same time. You can include a number of PST Audio Level events in a single custom control, allowing you to alter multiple audio channels, or groups, at the same time.		
	Reset Audio		The Reset Audio custom control allows you to return to the normal audio follow video mode and remove all currently selected overrides. This can be performed for either the program or the preset bus. You must set up two custom controls if you want to perform both independently.		
Audio Server	Go To Cut	Insert Audio Server	The Go To Cut custom control allows you to have the Audio Server cue to a selected cut or track. You must select the clip		
	Play		The Play custom control allows you to have the Audio Server go into play mode, or $1\times$ forward		
	Pause		The Pause custom control allows you to have the Audio Server go into pause mode.		
	Stop		The Stop custom control allows you to have the Audio Server stop.		
Character Generator	Character Generator		The Resume custom control allows you to resume playing an animation that was paused.		
	Play		The Play custom control allows you to play an animation.		
	Take		The Take custom control allows you to play the next effect that is cued up on the Character Generator. The next effect will be on the preview (PV) of the Character Generator and will be taken to the program (PGM) of the Character Generator with this custom control.		
	Set Folder		The Set folder custom control allows you to set the default folder for pages or templates.		
	Read		The Read custom control allows you to load a page or template into the Character Generator Preview channel. Use the keypad on the Global Memory Module to select the template you want.		
	Load		The Load custom control allows you to load a page or template into the Character Generator Program channel. Use the keypad on the Global Memory Module to select the template you want.		
	Take Out		The Take Out custom control allows you to clear all graphics from the specified channel.		
DVE	Frame Advance	Insert DVE	The Frame Advance custom control advances the DVE effect forward by one frame.		
	Frame Reverse		The Frame Reverse custom control allows you to reverse the DVE effect backwards by one frame.		
	Go To Start		The Go To Start custom control cues the DVE to the start of its effect.		
	Go To End		The Go To End custom control allows you to cue the DVE to the end of its effect.		
	Key Frame Adv		The Key Frame Adv custom control allows you to cue the DVE effect to the next Keyframe boundary.		
	Key Frame Rev		The Key Frame Rev custom control allows you to cue the DVE effect to the previous Keyframe boundary.		

Table 10.1 Insert Special Custom Control Commands

Class	Commands	Sub-Menu	Description
	Play		The Play custom control plays the DVE effect forward.
	Play Rev		The Play Rev custom control allows you to play the DVE effect in reverse.
	Recall		The Recall custom control allows you to recall a selected DVE effect (from <b>1</b> to <b>99</b> ).
	Rewind		The Rewind custom control allows you to rewind the DVE effect (simulates a shuttle reverse).
	Stop		The Stop custom control allows you to top the DVE effect.
	Pause		The Pause custom control allows you to pause the DVE effect.
GPI	Reset GPI	Special	The Reset GPI custom control allows you to reset the state of an output GPI connection. This can be used to return an output GPI to a known state if there is a problem.
	Trigger GPI		The Trigger GPI command allows you to trigger a pre-selected output GPI using a custom control.
	Simulate GPI		The Simulate GPI custom control allows you to manually trigger a GPI input on the switcher using a custom control. The switcher reacts as if a trigger was received on the selected input GPI.
Monitor Wall	Load Layout	Insert Monitor Wall Control	The Layout custom control allows you to program a custom control to load a specific layout on a Monitor Wall. A Monitor Wall can have several different layouts created, each with a variety of monitors and inputs.
	Assign Chan		The Assign Channel custom control allows you to program a custom control to assign a specific input channel to a particular monitor on the Monitor Wall. Each monitor in a layout requires an input channel for the video it displays.
			The Modify Dynamic Text custom control allows you to program a custom control to assign specific, pre-defined, Dynamic text to a particular text address on a Monitor Wall layout. The text address will have to be assigned to a template for a custom control to be able to change the text.
	Modify Text		There are two types of text labels used on a Monitor Wall: Static and Dynamic. Static text labels are set during the creation of the Monitor Wall setup and can only be modified using the tools provided with the Monitor Wall. Dynamic text labels can be modified at any time from the Vision switcher.
OverDrive®	Automation: Keys Off Air	Special	The Keys Off Air custom control allows you to have all the on-air keys, on all MLEs that are contributing to the program output of the switcher, dissolved off-air. MultiDSK keys are not affected by this custom control.
	Automation: Act MLE Trans		The Act MLE Trans custom control allows you to have all MLEs that are contributing to the program output of the switcher, except for the program MLE, to be transitioned according to the settings in the <b>MLE Transition Module</b> .
Pbus	Trigger	Insert Pbus	The Trigger custom control allows you to have a trigger value sent to the selected port on the Pbus device when the custom control is run. You can choose between $0$ and $15$ .
	Store		The Store custom control allows you to have the Pbus device store a memory to the selected register when the custom control is run. You can choose between <b>0</b> and <b>4095</b> .
	Recall		The Recall custom control allows you to have the Pbus device recall a memory from the selected register when the custom control is run. You can choose between <b>0</b> and <b>4095</b> .
Robotic Camera	Recall Shot	Insert Robotic Camera Control	The Recall Shot custom control allows you to recall a shot on a particular robotic camera with a specific duration for the recall to be performed. When programming this custom control, you are recalling a specific camera on a remote port by selecting its BNC, or BNC name.

Table 10.1 Insert Special Custom Control Commands

Class	Commands	Sub-Menu	Description				
	Cam All Stop		The Cam All Stop custom control allows you to quickly stop all robotic camera operations. Use this command to stop all motion of a robotic camera with a single command.				
	Deselect Cam		The Deselect Cam custom control allows you to deselect the robotic camera that was last selected. When a camera is selected by the switcher, that camera remains selected until another camera is selected, or the Deselect Cam custom control is run.				
Router	Take XPT	Insert Router Control	The Take XPT custom control allows to you change the source and destination on the router with a single custom control.				
	Fire Salvo		The Fire Router Salvo custom control allows to fire a salvo on the router. You will have to program your salvos on the router itself in order to be able to fire them. Refer to your router documentation for information on storing a salvo on your particular router.				
Video Server/ VTR	Fast Forward	Insert VTR	The Fast Forward custom control allows you to have the VTR go into full fast forward mode.				
	Frame Advance		The Frame Advance custom control allows you to have the VTR move (jog) the video one frame forward.				
	Frame Reverse		The Frame Reverse custom control allows you to have the VTR move (jog) the video one frame reverse.				
	Go To Clip		Select this command to have the VTR cue to a selected clip. When you select Go To Clip, the <b>Clip</b> knob appears, allowing you to select the number (00-99) for the clip you want to cue up.				
	Rewind		The Rewind custom control allows you to have the VTR go into full fast rewind mode.				
	Stop		The Stop custom control allows you to have the VTR perform a stop and eject. This command stops the selected channel, and unloads the clip.				
	Record		The Record custom control allows you to have the VTR go into record mode. You must use the Stop custom control to stop the recording. It is a good practice to create a Stop custom control before creating the Record custom control so that you can stop the recording.				
	Play		The Play custom control allows you to have the VTR go into play mode, or $1 \times$ forward.				
	Play w/Alpha		The Play w/ Alpha custom control allows you to play two video clips at once (a video and an alpha). The video input BNC must have an associated alpha input BNC and the correct clip must be cued on both.				
	Pause		The Pause custom control allows you to have the VTR to into pause mode.				
	Play Loop On		The Play Loop On custom control allows you to have the currently cued and playing clip loop back to the beginning when it finished playing.				
	Play Loop Off		The Play Loop Off custom control allows you to have a currently looping clip stop playing the next time it reaches the end.				
Internal Device	es and Command	ls					
Time Clock	Count Up	Time Clock	The Count Up custom control allows you to have the custom control start the time clock counting up from <b>0</b> .				
	Count Down		The Count Down custom control allows you to have the custom control start the time clock counting down from a preset time to <b>0</b> . The preset starting time is set using either the <b>Reset</b> custom control, or from the <b>Time Clock Menu</b> .				
	Count Down/Up		The Count Down/Up custom control allows you to have the custom control start the time clock counting down from a preset time to <b>0</b> , and then back. This will continue until the <b>Reset</b> or <b>Stop</b> command is given.				
	Stop		The Stop custom control allows you to have the custom control stop the time clock.				

Table 10.1 Insert Special Custom Control Commands

|--|

Class	Commands	Sub-Menu	Description				
	Reset		The Reset custom control allows you to have the custom control reset the time clock to the time selected using the <b>Reset Time</b> knob on the <b>Insert Time Clock Menu</b> .				
Menus	Go To Menu	Special	The Go To Menu command allows you to use a custom control to navigate a particular menu. This allows you to quickly jump between frequently us menus without having to navigate through the menu system.				
Transitions	Cut Keys	Special	The Cut Keys custom control allows you create a custom control that will cut keys on or off on a particular MLE, or for the MultiDSK Keyers.				
	Trans Keys		The Transition Keys custom control allows you create a custom control that will transition keys on or off on a particular MLE, or for the MultiDSK Keyers.				
Safe Title	Safe Title	Special	The Safe Title custom control allows you to create a custom control that will recall a specific safe title configuration on the preview overlay.				
Custom Control	Loop CC	Special	The Loop CC custom control allows you to have a custom control run continuously until you stop it, or a Stop Custom Control command is executed from another custom control.				
	Stop Other CC		The Stop Other CC custom control allows you place a command in a custom control that will stop all other running custom controls, except the one the command is in. This can be used to stop other looping custom controls at a specific point.				
	Notify End CC		The Notify End CC custom control is for internal use only. Only use this custom control if instructed to do so by Ross Video Technical Support.				
	Hold CC		The Hold CC custom control allows you place a command in a custom control that will stop a custom control where the hold is placed in the custom control. To continue the custom control, you must press the custom control button again, or use a GPI trigger.				
	Pause CC		The Pause CC custom control allows you to place a command in a custom control that will stop a custom control where the pause is placed in the custom control. The length of time that the custom control is paused is set when the pause event is inserted into the custom control.				
Sequences	Run Sequence	Special	The Run Sequence custom control allows you to have a custom control run a sequence on the selected MLE and Keyer. This allows you to run a dissolve or wipe and still run a sequence in the same MLE. If you are using a Relative Custom Control, you must select the PGM/PST MLE as the MLE to run the sequence on. You do not need to have <b>SEQ</b> selected on the Transition Module.				
Video Checksums	n/a	Insert Video Checksum	Refer to the section " <b>Video Checksum Custom Controls</b> " on page Eng 17-33 for more information on using this diagnostic tool.				

### **Attaching Custom Controls to Panel Buttons**

The Attach Custom Control feature allows you to attach a custom control to any button on the control panel or auxiliary control panel mapped to an internal panel row. This does not include the buttons on the touchscreen display, custom control bus, or Shotbox.

Custom controls are attached to the physical button on the MLE, and not the function of the button. This means that if a custom control is attached to a crosspoint button, changing the bus map, or using the shifted bus, does not affect the custom control attachment to the original button. For example, if you attach a custom control to a crosspoint button on MLE 1, the custom control runs if you press that button, or Shift and that button. If you assign the MLE to a different panel row, the custom control attachment follows the MLE to the new panel row.

If you include a button in a custom control that has another custom control attached to it, the command to run the second, attached, custom control is ignored when the initial custom control is run. This does not apply to actual custom control buttons.

**Note** — The **CC/Macro Attachments** personality option must be set to on for custom controls attached to control panel buttons to be executed when that button is pressed.

#### Attaching a Custom Control to a Panel Button

Custom controls are attached either after (Post-Attach), before (Pre-Attach), or instead-of (Replace) the function of the button.

Use the following procedure to attach a custom control to a control panel button:

1. Navigate to the Attach Custom Controls Menu as follows:



• Press HOME ⇒ Custom Controls ⇒ More ⇒ Attach Macros.

Attach Custom Controls Menu

**2.** Select the button on the Vision control panel or local Auxiliary Control Panel that you want to attach a custom control to. Only Auxiliary Control Panels that are mapped to internal panel rows can have custom controls attached to the buttons.



**Operating Tip** — Toggle **Show Attach** on the **Attach Custom Controls Menu** to **On** to show the control panel button that you are attaching the custom control to.

- 3. Select the custom control that you want to attach to the selected button as follows:
  - Use the **Bank** knob on the **Attach Custom Controls Menu** to select the custom control bank that you want to select the custom control from.

0

- Use the **Macro** knob on the **Attach Custom Controls Menu** to select the custom control that you want to attach.
- **4.** Use the **Attachment Type** knob on the **Attach Custom Controls Menu** to select how the custom control is attached to the button as follows:
  - **Post-Attach** Select this option to attach the custom control after the normal action of the button. When the control panel button is pressed, the normal function of the button is executed, followed by the custom control.
  - **Pre-Attach** Select this option to attach the custom control before the normal action of the button. When the control panel button is pressed, the custom control is run, followed by the normal function of the button. The switcher does not wait for the custom control to complete before executing the normal function of the button.
  - **Replace** Select this option to attach the custom control instead of the normal action of the button. When the control panel button is pressed, the custom control is run. The normal function of the button is not executed.
- 5. Press Attach on the Attach Custom Controls Menu.

**Operating Tip** — If you attach a custom control to a crosspoint button on the keyer bus, the **Show CC's on Key Bus** personality option allows you to have the name of the custom control shown on the mnemonic for that button.

This completes the procedure for attaching a custom control to a control panel button.

#### For More Information...

- on CC/Macro Attachment, refer to the section "Personality List" on page Eng 11-2.
- on Show CC's on Key Bus, refer to the section "Personality List" on page Eng 11-2.

#### **Deleting Custom Control Attachment to Panel Buttons**

Use the following procedure to delete the attachment of a custom control to a panel button:

- 1. Navigate to the Attach Custom Controls Menu as follows:
  - Press HOME ⇒ Custom Controls ⇒ More ⇒ Attach Macros.
- 2. Toggle Show List on the Attach Custom Controls Menu to On.

Attach Custom Con	trols	44 Back PP To	Copy Up	33 Swap Bank:
Number of Macros Attach	ed: 1			Bank 1 (1) Bank 2 (2)
Button Macro Name		Bank/Macro	Туре	Bank 3 (3)
				Macro: Custom01 + 1 1 Custom02 # 2 Custom03 # 3
				with Knob 3

Show List — Attach Custom Controls Menu



**Operating Tip** — You can delete all the attachments of custom controls to control panel buttons by pressing **Delete All Attachments** on the **Attach Custom Controls Menu**.

- **3.** Use the **Scroll list with Knob 3** knob on the **Attach Custom Controls Menu** to select the custom control attachment that you want to remove.
- 4. Press Delete Attachment on the Attach Custom Controls Menu.

This completes the procedure for deleting the attachment of a custom control to a panel button.

# **Naming Custom Controls**

When a custom control has been programmed, it can be named. This name appears on the menus, the mnemonics, and the Shot Box buttons for the custom controls. This is useful when working with multiple custom control banks. As you switch banks, the mnemonics display the names for the custom controls on the selected bank.

Use the following procedure to name a custom control button:

- 1. Navigate to the **Custom Controls Menu** as follows:
  - Press HOME ⇒ Custom Controls.
- 2. Select the custom control button you want to name.

**Note** — If the custom control that you want to change the name for is already running, the **Modify Name** button is gray, and you cannot modify the name until the custom control has stopped.



#### 3. Press Modify Name on the Custom Control Menu.



Custom Control Name Menu

**Operating Tip** — Refer to the section "Using the Naming Menus" on page Eng 5-16 for more information on using the **Custom Control Name Menu** to enter a name, or set up the mnemonics for the custom control button.

- 4. Enter the new name for the custom control bank in the New Name field. The name can be no more than 8 characters in length.
- 5. Press Accept New Name on the Custom Control Name Menu to store the new name and mnemonic settings.

This completes the procedure for naming a custom control button.

# **Editing Custom Controls**

Once a custom control has been created, you can go back and edit that custom control by inserting or removing events. Editing a custom control also allows you to view the sequence of events that were added, and then insert pauses, holds, or special functions or commands, where they are needed.

You cannot edit a custom control if the custom control is running on another panel connected to the system.

If a custom control contains pauses or holds, a timeline is shown, indicating the duration of the custom control, and at which points different events will occur.

Edit Custom	Control	44 Back	- Hermani (	Copy Up	<b>13</b> Swap	Pause	64 p
Event: 1 of 1 Duration (ss:ff)	2:04	64 Pause Length	(ss-ff): 2-04				
Go To Start	insert Events	Delete Event	Modify Event	Run Single Event	Run From	Here	

Edit Custom Control Menu

The rest of the menu provides additional information on the currently selected event and the total duration of the custom control. This information is provided as follows:

- **Event** The event field indicates the currently selected event, and the total number of events in the custom control.
- **Duration** The duration field indicates the total time (seconds:fields) for the custom control to play out.
- Event Information The event information is located at the bottom center of the menu and provides information on the MLE, key, or memory that is being used in the selected event. If more than one MLE is involved in the event, then the number for the lowest number MLE is displayed.

**Important** — You can only edit a custom control on the same panel it was recorded on, or a panel with the exact same settings, including MLE assignments and bus maps.

Use the following procedure to edit a custom control:

- 1. Navigate to the Custom Controls Menus as follows:
  - Press HOME ⇒ Custom Controls.
- 2. Select the custom control you want to edit.
- **3.** Press **Edit** on the **Custom Controls Menu 1-2**.

**S** 

\*

**Note** — If you are editing a Relative Custom Control, **<relative>** appears next to the Bank and Button identification, and the relative MLE level (**R LVL**) is displayed instead of the MLE number.

Edit Custom	Control	44 Back	De Tormerd I	Copy Up	13 Swap	Pause	a d
Bank 1 Button	[ [Custom01]					END	0
	<b></b>	64					
Event: 1 of 1 Duration (ss:ff)	2:04	Pause Length	(ss:ff): 2:04				
Go To Start	Insert	Delete	Modify     Event	Run Single Event	Run	Here	-

Edit Custom Controls Menu

**Operating Tip** — You can test a single event in a custom control by selecting the event you want to test and pressing **Run Single Event**. You can use this feature to step through a custom control to check for errors. Similarly, the **Run From Here** function allows you to run the custom control from the currently selected event to the end.

- **4.** Modify an event as follows:
  - Use the **Event** knob on the **Edit Custom Control Menu** to select the event that you want to edit.
  - Press Modify Event on the Edit Custom Control Menu.

Modify Event	:	44 Back	- Milonava -	Copy Up	13Swap	
						( 0) Seconds
						(1) Frames
Accept	Cancel					4

Modify Event Menu

- Modify the event in the same way it was originally inserted.
- Press Accept on the Modify Event Menu to save your changes. The Edit Custom Control Menu is displayed.
- **5.** Insert a control panel button event as follows:
  - Use the **Event** knob on the **Edit Custom Control Menu** to select the location in the custom control that you want to insert the event. The new event is inserted before the selected event.
  - Press Insert Event on the Edit Custom Control Menu.

Edit Custom Control		44 Back	PP Forward	Copy Up	13Swap	
Bank 1 Button 2 [Custom Inserting	02]					

Inserting — Edit Custom Control Menu

- Press the buttons on the control panel that you want to record to the custom control. Refer to the section "**Programming Control Panel Functions**" on page Eng 10-8 for more information on inserting control panel events.
- Press Finish Inserting on the Edit Custom Control Menu to save your changes. The Edit Custom Control Menu is displayed.
- **6.** Insert a special function event as follows:
  - Use the **Event** knob on the **Edit Custom Control Menu** to select the location in the custom control that you want to insert the event. The new event is inserted before the selected event.
  - Press Insert Event on the Edit Custom Control Menu.
  - Press Insert Special on the Edit Custom Control Menu.
  - Insert the special events that you want to record to the custom control. Refer to the section "**Programming Special Functions**" on page Eng 10-15 for more information on inserting special events.
  - Press **UP ONE** to display the **Custom Controls Menus**.
  - Press Finish Inserting on the Edit Custom Control Menu to save your changes. The Edit Custom Control Menu is displayed.
- **7.** Delete an event as follows:
  - Use the **Event** knob on the **Edit Custom Control Menu** to select the event you want to delete.
  - Press **Delete Event** on the **Edit Custom Control Menu** to delete the selected event.

This completes the procedure for editing a custom control.

# **Managing Custom Controls**

When a custom control has been programmed, the commands in that custom control can be copied, moved, or swapped with other custom controls on the switcher. This allows you to duplicate custom controls on different banks, or re-organize the custom controls.

You cannot copy, move, or swap a custom control if the custom control is running on another panel connected to the system.

Use the following procedure to copy, move, or swap a custom control:

- 1. Navigate to the Manage Custom Controls Menu as follows:
  - Press HOME ⇒ Custom Controls ⇒ Copy/Move Macros.

Manage Cust	tom Controls	44 Back	M Tormare	Copy Up	33 Swap	Source:	
				("Custom02"	#)	8nk 1 8tn 01 8nk 1 8tn 02 8nk 1 8tn 03	0.0.5
i	Select a source and d press Copy, Move, or	iestination macro ar r Swap.	nd			Destination: Bnk 1 Btn 02	
Macro Legend # = norm	al Custom Control bi	utton		("Custom03"	*)	8nk 1 8tn 03 8nk 1 8tn 04	0.
Сору	Move	Swap					

Manage Custom Controls Menu

- **2.** Use the **Source** knob on the **Manage Custom Controls Menu** to select the custom control you want to copy, move, or swap.
- **3.** Use the **Destination** knob on the **Manage Custom Controls Menu** to select the custom control that you want to copy, or move, the source custom control to.
- 4. Copy, Move, or Swap a custom control as follows:
  - Press **Copy** on the **Manage Custom Controls Menu** to copy the source custom control to the destination. Both custom controls will contain the same commands.
  - Press **Move** on the **Manage Custom Controls Menu** to move the source custom control to the destination. The commands in the source custom control are moved to the destination. The source custom control will be empty after the move.
  - Press **Swap** on the **Manage Custom Controls Menu** to swap the source custom control and the destination.

This completes the procedure for copying, moving, or swapping a custom control.

# **Deleting Custom Controls**

Once a custom control have been created, you can delete the entire custom control from the **Custom Controls Menu**.

You cannot delete a custom control if the custom control is running on another panel connected to the system.

Use the following procedure to delete a custom control:

- 1. Navigate to the Custom Controls Menus as follows:
  - Press HOME ⇒ Custom Controls.
- **2.** Select the custom control button you want to delete as follows:
  - Use the **Bank** knob on the **Custom Controls Menu 1-2** to the select the bank that the custom control you want to delete is on.
  - Use the **Button** knob on the **Custom Controls Menu 1-2** to select the custom control you want to delete. Only custom controls that have been programmed can be deleted.
- **3.** Press **Delete Macro** on the **Custom Controls Menu 1-2**. The **Delete Custom Control Confirmation Screen** is displayed.

warn	ING				
e you sure yo	u want to delete Custo	om Control Bank 1 E	Button 1 (Custon	01]7	

Delete Custom Control Confirmation Screen

- Press **Confirm** to delete the custom control.
- Press **Cancel** to cancel deleting the custom control.

This completes the procedure for deleting a custom control.

# **Custom Control Shortcuts**

Shortcuts for common custom control commands can be mapped to custom control panel buttons. This allows you to perform tasks, such as recording and saving a custom control, right from the control panel, without having to use the menu system.



**Important** — Custom Control Shortcuts require the mnemonics option for the custom control bus be installed.



**Note** — The Custom Control Shortcuts do not support the CC Soft Shot Box, the Custom Control Shot Box, or the Auxiliary Control Panels.

Use the following procedure to set up a custom control shortcut:

- 1. Navigate to the Custom Controls Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ More ⇒ Custom Controls.

Custom Controls		44 Back	Proment 3		193 (CONT)	Banka	
Use this menu to assign custom control buttons to banks and assign bank types, or to assign the quick record function to a custom control button. Buttons with '*' or '@' have macros assigned.	Record: Pause:	40 NONE	Bank 1 bttn Bank 2 bttn Bank 3 bttn Bank 4 bttn Bank 5 bttn Bank 6 bttn Bank 6 bttn Bank 9 bttn Bank 10 bttn Bank 11 bttn Bank 12 bttn	NONE 02 03 04 05 NONE NONE NONE NONE NONE NONE		Bank 1 (1) Bank 2 (2) Bank 3 (3) Bith: NONE *Button # 1 *Button # 6	.0.
Setup Banks Ø Modify Bank N	ame 🕹 🖁	etup Shot lox Modules				44	

Custom Controls Menu

- **2.** Use the **Bank** knob on the **Custom Controls Menu** to select the shortcut you want to assign to a button.
  - **Record** Select this option to create a custom control shortcut that allows you to record a custom control without using the menu system. To record a custom control using the shortcut, press and hold the **Record** button and select the custom control you want to record to. Both buttons flash red while recording. Press the **Record** (**Cancel**) button again to cancel the recording, or the custom control button you are recording to (**Save**), to save the recording.
  - **Pause(Hold)** Select this option to create a custom control shortcut that allows you to insert a pause into a custom control you are recording, without using the menu system. To insert a pause into a custom control using the shortcut, press and hold the **Pause** button. A series of durations, in fields, and Hold are shown on the mnemonics for the custom control bus. Press the custom control button below the pause duration to insert that pause into the custom control.
- **3.** Use the **Button** knob on the **Custom Controls Menu** to select the custom control button that you want to assign as the shortcut. The custom control button you have selected lights up on the control panel.
- 4. Press HOME to display the Installation Change Confirmation Screen.
- 5. Accept or reject the changes you have made as follows:

- Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
- Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
- Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for setting up a custom control shortcut.

# **Switcher Personality**

# In This Chapter

This chapter provides information on finalizing the setup of the personality settings of your switcher, as well as the color schemes use for the control panel.

The following topics are discussed in this chapter:

- Personality List
- Control Panel Button Color Schemes
- Mnemonic Color Schemes
- Control Panel Display Brightness
- Loading Color Schemes
- Lock/Unlock Personality

# **Personality List**

There are a number of settings for how the switcher will react to different situations, or how switcher elements appear to the operator. All these settings are grouped together into the Switcher Personality. These settings include double press rates, memory bank cycling, and sleep time, among others.

This section covers the items on the Personality Scroll List only.

Use the following procedure to set up your switcher personality:

- 1. Navigate to the **Personality Menus** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Personality.

Personality (1-2)	44 Back	M Formatol	Copy Up	<b>D3</b> Swap	Option:	
Audio Cut Only On	The Audio transitions transitions transition Note that one channe is taken on- On: Select cut, regard	The Audio Cut Only features sets whether audio transitions occur at the same rate as the video transition, or whether the audio transitions cut. Note that this is not a true cut as the speed that one channel is taken off-air and the next channel is taken on-air depends on the Audio Mixer. On: Select this option to have audio transition cut, regardless of the type or rate of the video			AudioCutr Value: On	Daily D V
3D Pattern     Bttn Assign     Mnemonics	Transition. Off: Select the same ra	this option to ha te as the video to Color Scheme	ve audio transitio ransition.	n at s Prev Cok	view Font	🐳 More

Personality Menu 1-2

- Use the Option knob on the Personality Menu 1-2 to select the option you want to set. Refer to the following table (Table 11.1) for a list of options and values.
- **3.** Use the **Value** knob on the **Personality Menu 1-2** to select the value you want to set for the selected option.

This completes the procedure for setting up your switcher personality.

#### For More Information...

- on **3D Pattern Button Assign**, refer to the section "**Squeeze & Tease MD Pattern Button Assignment**" on page Ops 15-12.
- on **Standard Mnemonics**, refer to the section "**Default Mnemonic Appearance**" on page Eng 5-12.
- on **Assign Bus Maps**, refer to the section "**Assigning Panel Bus Maps**" on page Eng 7-19.
- on **Color Scheme**, refer to the section "**Control Panel Button Color Schemes**" on page Eng 11-14.
- on **MLE Maps**, refer to the section "**Default MLE Map Assignment**" on page Eng 12-4.
- on **Preview Font Colors**, refer to the section "**Preview Overlay Setup**" on page Eng 12-30.
- on Autofollow Setup, refer to the section "Auto Follow" on page Eng 12-40.
- on Squeeze & Tease Mode, refer to the section "Squeeze & Tease Mode" on page Eng 12-5.

Personality Option	Description	Values
Audio Cut Only (AudioCutOnly)	The Audio Cut Only features sets whether audio transitions occur at the same rate as the video transition, or whether the audio transitions cut. Note that this is not a true cut as the speed that one channel is taken off-air and the next channel is take on-air depends on the Audio Mixer. When <b>Editor Remote Enable</b> is <b>Enabled</b> , and OverDrive is controlling the switcher, the audio transition rate for the PGM MLE is set from OverDrive.	<ul> <li>On — Select this option to have audio transition cut, regardless of the type or rate of the video transition.</li> <li>Off — Select this option when using OverDrive, or to have the audio transition at the same rate as the video or at the Audio Fade rate.</li> </ul>
Audio Transition (AudioTrans)	Depending on how you want audio transitions to be performed, you can set up the switcher so that it will either perform an audio transition when a transition is performed on any MLE, or only when a transition is performed on an on-air MLE. <b>Note:</b> If <b>OverDrive</b> is controlling the switcher, this is locked to <b>All</b> .	<ul> <li>All — Select this option to have the switcher perform an audio transition when any MLE is transitioned.</li> <li>Pgm — Select this option to have the switcher perform an audio transition only when an on-air MLE is transitioned. An MLE is considered to be on-air when it is re-entered onto the Program/Preset MLE.</li> </ul>
Autofollow Custctrl (Autofolw Cust)	The Auto Follow Custom Control feature allows you to select whether or not custom control events are included in the auto follow command echoing. Refer to the section " <b>Auto Follow</b> " on page Eng 12-40 for more information.	<ul> <li>Off — Select this option to have the switcher not perform any command echoing for active custom controls.</li> <li>On — Select this option to have the switcher perform command echoing for the active custom control. Any commands recorded in the custom control for an MLE, bus, or Transition Module, will be echoed on the auto follow.</li> </ul>
Autofollow Editor (Autofolw Edtr)	The Auto Follow Editor feature allows you to select whether or not external editor commands are included in the auto follow command echoing. Refer to the section " <b>Auto Follow</b> " on page Eng 12-40 for more information.	<ul> <li>Off — Select this option to have the switcher not perform any command echoing for external editor commands.</li> <li>On — Select this option to have the switcher perform command echoing for external editor commands.</li> </ul>
Autofollow Control Panel (Autofolw Pnl)	The Auto Follow Control Panel feature allows you to select whether or not control panel button presses are included in the auto follow command echoing. Refer to the section " <b>Auto Follow</b> " on page Eng 12-40 for more information.	<ul> <li>Off — Select this option to have the switcher not perform any command echoing for control panel button presses.</li> <li>On — Select this option to have the switcher perform command echoing for control panel button presses. This includes memory recalls, transitions, and crosspoint button selection. Custom control or editor based commands are not included.</li> </ul>

#### Table 11.1 Personality Option Settings

Personality Option	Description	Values
Auto Recall (Auto Recall)	The Auto Recall feature sets whether or not the switcher includes switcher settings, such as Effects Dissolve on or off, with the memory.	<ul> <li>Off — Select this option to have memories not recall KEYS ONLY, Effects Dissolve and DVE Wipe settings with the memory. These attributes must be turned on manually before the memory is recalled. This is the default setting.</li> <li>On — Select this option to have memories also recall the KEYS ONLY, Effects Dissolve (EFF DISS) settings stored with the memory from the Global Memory Module.</li> </ul>
Auto Remove Key (AutoRemoveKey)	The Auto Remove Key feature allows you to have the switcher remove a Keyer from the Next Transition after that Keyer has been transitioned off-air from the Keyers Module. For example, Key 2 is on-air and it is selected as part of the next transition on the Transition Module. If you cut or dissolve Key 2 off-air from the Keyers Module, Key 2 will be de-selected for the next transition on the Transition Module. If Key 2 was the only selected item for the next transition, the background will be selected instead.	<ul> <li>Off — Select this option to have the switcher not remove the Keyer from the next transition selection if it has just been transitioned off-air from the Keyers Module.</li> <li>On — Select this option to have the switcher remove the Keyer from the next transition selection if it has just been transitioned off-air from the Keyers Module.</li> </ul>
Bank 0 Lit (Bank 0 Lit)	The Bank 0 Lit feature sets whether or not the <b>Bank</b> button on the <b>Memory</b> <b>Modules</b> is lit when <b>Bank 0</b> is selected.	<ul> <li>Off — Select this option to have the BANK button not lit when Bank 0 is selected.</li> <li>On — Select this option to have the BANK button lit when Bank 0 is selected in the Memory Module, or Global Memory Module.</li> </ul>
CC/Macro Attachments (CCAttchments)	The Custom Control/Macro Attachment feature sets whether or not custom controls that are attached to control panel buttons using the <b>Attach Custom</b> <b>Controls Menu</b> are run when the button is pressed.	<ul> <li>Off — Select this option to have custom controls attached to control panel buttons not run when the button is pressed.</li> <li>On — Select this option to have custom controls attached to control panel buttons run when the button is pressed.</li> </ul>
Clear Bus Hold on All-All (Clear BusHold)	The Clear Bus Hold on All-All feature sets whether or not the <b>Bus Hold</b> selection on an bus is cleared when a soft-reset is performed.	<ul> <li>Off — Select this option to have the Bus Hold feature not cleared when a software reset is performed.</li> <li>On — Select this option to have the Bus Hold feature cleared on every bus when a software reset is performed.</li> </ul>

Table 11.1 Personality Option Settings

Personality Option	Description	Values
Default Trans Rate Active (DfltTrnsActiv)	The Default Transition Rate Active feature allows you to set a default transition rate for switcher transitions, effects, and sequences.	<ul> <li>Off — Select this option to use the video format based default transition rates when you default an MLE or the entire switcher.</li> <li>On — Select this option to use the selected default transition rates when you default an MLE or the entire switcher.</li> </ul>
Default Trans Eff Rate (Dflt Trns Eff)	The Default Transition Effects Dissolve Rate feature allows you to set a default effects dissolve rate. This rate is only used if the <b>Default</b> <b>Trans Rate Active</b> feature is set to <b>On</b> .	• Use the <b>Rate</b> knob to set a default rate, in frames.
Default Trans FTB Rate (Dflt Trns FTB)	The Default Transition Fade to Black Rate feature allows you to set a default fade to back rate. This rate is only used if the <b>Default</b> <b>Trans Rate Active</b> feature is set to <b>On</b> .	• Use the <b>Rate</b> knob to set a default rate, in frames.
Default Trans Key Rate (Dflt Trns Key)	The Default Transition Key Rate feature allows you to set a default Keyer transition rate. This rate is only used if the <b>Default</b> <b>Trans Rate Active</b> feature is set to <b>On</b> .	• Use the <b>Rate</b> knob to set a default rate, in frames.
Default Trans PGM Rate (Dflt Trns PGM)	The Default Transition PGM(MLE) Rate feature allows you to set a default MLE transition rate. This rate is only used if the <b>Default</b> <b>Trans Rate Active</b> feature is set to <b>On</b> .	• Use the <b>Rate</b> knob to set a default rate, in frames.
Default Trans Seq Rate (Dflt Trns Seq)	The Default Transition Sequence Rate feature allows you to set a default sequence rate. This rate is only used if the <b>Default</b> <b>Trans Rate Active</b> feature is set to <b>On</b> .	• Use the <b>Rate</b> knob to set a default rate, in frames. If you set the rate to <b>1</b> , the transition uses the duration set in the sequence.
Double Press Rate (DbIPress Rate)	The Double-Press Rate feature sets the length of time that you have to press a button a second time in order for the switcher to treat it as a double-press.	• Use the <b>Value</b> knob on the <b>Personality</b> <b>Menu 1-2</b> to select the amount of time, in frames, that you are given to press a button again for the switcher treat it as a double-press.
Double Press BKGD (DbIPress Bkgd)	The Double-Press Background feature allows you to have a double-press of the <b>BKGD</b> button on a <b>Transition Module</b> select background and all on-air keyers as part of the next transition.	<ul> <li>Do Nothing — Select this option to not include the on-air keyers with the next transition when the BKGD button is double-pressed.</li> <li>Trans Clean — Select this option to include all on-air keyers with the next transition when the BKGD button is double-pressed.</li> </ul>

Table 11.1 Personality Option Settings

Personality Option	Description	Values
DSK 1 Auto Cut		
(DSK1 Auto Cut)		
DSK 2 Auto Cut		• Off — Select this option to have the
(DSK2 Auto Cut)	The Downstream Keyer Auto Cut feature sets whether or not the DSKs are cut	Downstream Keyers not affected by selections made directly on the
DSK 3 Auto Cut		Program Bus of the Program/Preset
(DSK3 Auto Cut)	off-air when a source is selected directly	MLE.
DSK 4 Auto Cut	Note: The DSK Auto Cut feature is not available for MultiDSK Keys if the Isolate MultiDSKs feature is turned On.	• <b>On</b> — Select this option to have the selected Downstream Keyers
(DSK4 Auto Cut)		automatically taken off-air when any
DSK 5 Auto Cut		source is selected directly on the
(DSK5 Auto Cut)		MLE.
DSK 6 Auto Cut		
(DSK6 Auto Cut)		
Editor Pattern Codes (Editor Codes)	The Editor Pattern Codes feature sets whether or not the GVG100, GVG100/200, or GVG4000 editor pattern codes are displayed on the pattern buttons. When active for a particular editor protocol, the plain or hexidecimal pattern code is shown on the pattern buttons on the <b>Pattern Selection Menu</b> .	<ul> <li>None — Select this option to have no pattern code numbers on the pattern buttons.</li> <li>GVG100 Bttn# — Select this option to have the GVG100 button number, for the pattern, displayed on the pattern button.</li> <li>GVG100 Bttn#H — Select this option to have the GVG100 button number, for the pattern, displayed in hexidecimal on the pattern button.</li> <li>GVG100/200 — Select this option to have the GVG100/200 pattern code displayed on the pattern button.</li> <li>GVG100/200 H — Select this option to have the GVG100/200 pattern code displayed in hexidecimal on the pattern button.</li> <li>GVG100/200 H — Select this option to have the GVG100/200 pattern code displayed on the pattern button.</li> <li>GVG4000 — Select this option to have the GVG4000 pattern code displayed in hexidecimal on the pattern button.</li> <li>GVG4000 H — Select this option to have the GVG4000 pattern code displayed on the pattern button.</li> <li>GVG4000 H — Select this option to have the GVG4000 pattern code displayed on the pattern button.</li> <li>GVG4000 H — Select this option to have the GVG4000 pattern code displayed on the pattern button.</li> </ul>
Edge Width Default (Width Default)	The UltraChrome Edge Width Default feature sets whether or not the Edge Sensitivity is set to High or Low when the chroma key is initialized.	<ul> <li>On — Select this option to have Edge Sensitivity set to Low and the Width set to 2 when the key is initialised.</li> <li>Off — Select this option to have Edge Sensitivity set to High and the Width set to 0 when the key is initialised.</li> </ul>

Table 11.1 Personality Option Settings

Personality Option	Description	Values
Editor Trans Rates (Editor Trans)	The Editor Transition Rates feature sets whether transition rates that are set from an external editor are doubled or not.	<ul> <li>Normal — Select this option to have the transition rates that are set from an external editor not changed.</li> <li>Double — Select this option to have the transition rates that are set from an external editor doubled.</li> </ul>
Fixed Memories (Fixed Mem)	The Fixed Memory feature allows you to select whether memories are recalled on the MLEs that they were recorded on, or whether they are recalled on MLEs relative to the PGM MLE.	<ul> <li>Off — Select this option to have memories recalled on MLEs that are the same relative distance from the PGM MLE as they were recorded. For example, if MLE 4 is the Program MLE and you store a memory on MLE 2. If you change the Program MLE to MLE 8, the memory is recalled on MLE 6.</li> <li>On — Select this option to have memories recalled on same MLE they were recorded on.</li> </ul>
FTB Display (FTB Display)	The Fade to Black Display Mode sets whether the display on the Fade to Black Module will display the current fade rate, or the number of Up/Down Converters available on the switcher. Refer to the section " <b>Fade to Black</b> <b>Display Mode for Up/Down</b> <b>Converters</b> " on page Eng 16-7 for information on setting the Fade to Black Display feature.	<ul> <li>SmrtConv — Select this option to have the display on the Fade to Black Module show the number of available up/down converters for SmartConversion to use.</li> <li>FTB — Select this option to have the display on the Fade to Black Module show the transition rate for a Fade to Black transition.</li> </ul>
Global Mem Num Entry (Glob NumEntry)	The Global Memory Number Entry Mode sets whether the keypad on the Global Memory Module can be used to enter Punchpad values.	<ul> <li>Off — Select this option to not be able to use the keypad on the Global Memory Module to enter Punchpad values.</li> <li>On — Select this option to be able to use the keypad on the Global Memory Module to enter Punchpad values.</li> </ul>
Global-Store 4 Mode (GlobStorChan4)	The Global-Store 4 Mode option sets whether or not the 4th channel of Global-Store is available or not. This channel is shared by the Preview Overlay. When Global-Store channel 4 is active, the Preview Overlay is not available.	<ul> <li>Still-Store — Select this option to enable Global-Store channel 4. Preview Overlay is disabled.</li> <li>Pvw Overlay — Select this option to disable Global-Store channel 4. The Preview Overlay is enabled.</li> </ul>

Table 11.1 Personality Option Settings

Personality Option	Description	Values
Isolate MultiDSK (ISO MultiDSK)	You can isolate the two MultiDSKs to prevent them from being affected by memory recalls and soft-resets of the switcher. If you isolate the MultiDSKs, you will not be able to include them in a transition on the <b>Transition Module</b> . You will only be able to transition the MultiDSKs from the Keyers Module.	<ul> <li>Off — Select this option to include the MultiDSKs with the rest of the MLE.</li> <li>On — Select this option to isolate the MultiDSKs from the rest of the MLE. The MultiDSKs will not be affected by memory recalls, soft resets, or Program/Preset MLE Transitions.</li> </ul>
Key Cut Then Fade (KeyCutThenDis)	The Key Cut then Fade feature allows you to change the behavior of the <b>CUT</b> button on the <b>Keyers</b> module. When this feature is active, the <b>CUT</b> button on the <b>Keyers</b> module will cut a key on-air, but dissolve, or fade, the key off-air. This allows you to use the same button to cut a key on-air and then transition is off-air. If you press <b>CUT</b> as the key is being transitioned off-air, a cut is immediately performed to take the key off-air.	<ul> <li>Off — Select this option to have the CUT button on all Keyers modules operate normally.</li> <li>On — Select this option to have the CUT button on all Keyers modules will cut keys on-air, but dissolve them off-air.</li> </ul>
Keypad Clip IDs Entry (KeypadCliplDs)	The Keypad Clip IDs Entry feature allows you to specify whether the keypad on the Global Memory or Effects Memory Modules will allow you to select a new clip on a video server.	<ul> <li>None — Select this option to not have the keypads on the Global Memory or Effects Memory Modules allow you to load a clip on the selected video server.</li> <li>MLE — Select this option to have only the keypads on the Effects Memory Modules allow you to load a clip on the selected video server.</li> <li>Global — Select this option to have only the keypad on the Global Memory Module allow you to load a clip on the selected video server.</li> <li>Both — Select this option to have the keypads on both the Global Memory and Effects Memory Modules allow you to load a clip on the selected video server.</li> </ul>
Log OverDrive Messages (OverDriveLog) Important: Do not turn this feature On unless instructed to do so by Ross Video Technical Support.	The Log OverDrive Messages features allows you to include interface messages between the switcher and OverDrive in the frame log file. Refer to the section " <b>Communication Port Monitor</b> " on page Eng 17-37 for information on this log file. <b>Note:</b> Do not leave the OverDriveLog feature turned On for an extended period of time.	<ul> <li>Off — Select this option to not have the interface messages between the switcher and OverDrive recorded in the log file.</li> <li>On — Select this option to have the interface messages between the switcher and OverDrive recorded in the log file.</li> </ul>

Table 11.1 Personality Option Settings

Personality Option	Description	Values
Matte Limit (Matte Limit)	The Matte Limit feature sets whether or not the Matte Generators on the switcher are limited to the RGB color space or not.	<ul> <li>Off — Select this option to have the color range of the matte generators not limited to the RGB color space. This is the default setting.</li> <li>On — Select this option to have the color range of the matte generators limited to the RGB color space.</li> </ul>
Memory Bank Cycle ( <b>MemBank Cycle</b> )	The Memory Bank Cycle feature sets the maximum number of memory banks that you will cycle through when pressing the <b>Bank</b> button on a <b>Memory Module</b> . <b>Note:</b> This feature is disabled if <b>Quick</b> <b>Bank Select</b> is set to <b>On</b> .	<ul> <li>Use the Value knob on the Personality Menu 1-2 to select the maximum number of Memory Banks you want to cycle through, starting from Bank00. By repeatedly pressing the BANK button on the keypad of the Memory Modules or Global Memory Module, you can jump from bank to bank. The Cycle Max value sets how many Banks you can cycle through, starting at Bank00, before jumping back to Bank00.</li> </ul>
Mouse Sensitivity (Mouse Speed)	The Mouse Sensitivity feature allows you to set the speed that the mouse pointer moves around the screen when you move the mouse.	• Use the <b>Value</b> knob on the <b>Personality</b> <b>Menu 1-2</b> to select a sensitivity, or speed, for the mouse.
Multiple Customs (Multiple CCs)	The Multiple Custom Controls feature allows you to set whether the switcher can run multiple custom controls simultaneously or only one at a time. <b>Note:</b> If <b>OverDrive</b> is controlling the switcher, this is locked to <b>Off</b> .	<ul> <li>On — Select this option to allow multiple custom controls to run simultaneously. Starting a custom control while a custom control is running does not stop the other custom control and the currently selected one starts.</li> <li>Off — Select this option to allow only one custom control to run at a time. Starting a custom control while a custom control is running stops the running custom control and starts the new one.</li> </ul>
Panel Sleep Time (Pnl SleepTime)	The Panel Sleep Time feature sets the length of time before the switcher goes into sleep mode.	• Use the <b>Value</b> knob on the <b>Personality</b> <b>Menu 1-2</b> to select the amount of time, in minutes, that the control panel will go without being use before entering sleep mode. Selecting a sleep time of <b>0</b> prevents the control panel from entering sleep mode.

Table 11.1 Personality Option Settings

Personality Option	Description	Values
Pbus Memory (Pbus Memory)	The Pbus Memory feature allows you to store or recall memories on a Pbus device when you store or recall memories on the switcher.	<ul> <li>No Send — Select this option to have the switcher not tell the Pbus devices to store or recall memories.</li> <li>Send — Select this option to have the switcher tell all connected Pbus devices to perform a memory store or recall when one is performed on the switcher. The memory number is the same as the one used on the switcher.</li> </ul>
Quick Bank Select (QuickBank Sel)	The Quick Bank Select feature allows you to select a memory bank by either holding the <b>BANK</b> button and selecting the bank, or by pressing the <b>BANK</b> button, and then selecting the bank. You can always select a bank by pressing and holding the <b>BANK</b> button and selecting the bank.	<ul> <li>Off — Select this option to select a memory bank by pressing and holding the BANK button, and selecting the bank.</li> <li>On — Select this option to select a memory bank by pressing and releasing the BANK button, and selecting the bank.</li> </ul>
Recall Global-Store (RecallGlblSto)	The Recall Global-Store Memory Mode sets whether the Global-Store settings are included with memory recalls always, only when turned on from the <b>MLE</b> <b>Memory Attributes Menu</b> , or never.	<ul> <li>Never — Select this option to have Global-Store settings never included during memory recalls. The stills loaded in the Global-Store channels are not replaced with those included in the memory.</li> <li>Always — Select this option to have Global-Store settings always included during memory recalls. The stills loaded in the Global-Store channels are replaced with those included in the memory.</li> <li>Attributes — Select this option to have Global-Store setting included during memory recalls if the Global-Store channel is turned on from the MLE Memory Attributes Menu.</li> </ul>
Recall MLE-Store (RecallMLEStor)	The Recall MLE-Store Memory Mode sets whether the MLE-Store settings are included with memory recalls always, only when turned on from the <b>MLE</b> <b>Memory Attributes Menu</b> , or never.	<ul> <li>Never — Select this option to have MLE-Store settings never included during memory recalls. The stills loaded in the MLE-Store channels are not replaced with those included in the memory.</li> <li>Always — Select this option to have MLE-Store settings always included during memory recalls. The stills loaded in the MLE-Store channels are replaced with those included in the memory.</li> <li>Attributes — Select this option to have MLE-Store setting included during memory recalls if the MLE-Store channel is turned on from the MLE Memory Attributes Menu.</li> </ul>

Table 11.1 Personality Option Settings

Personality Option	Description	Values
Re-entry Depth (Re-entryDepth)	The Re-entry Depth feature allows you to have the switcher either prevent or allow re-entry chains of more than 4 MLEs. For example, MLE 1 -> MLE 2 -> MLE 3 -> MLE 4. <b>Note:</b> Re-entry chains of more than 4 MLEs can cause line drops.	<ul> <li>Prevent — You can only create re-entry chains up to 4 MLEs deep.</li> <li>Warn — You can create re-entry chains over 4 MLEs deep, but a pop-up is displayed.</li> <li>Allow — You can create re-entry chains over 4 MLEs deep.</li> </ul>
<b>Re-entry Loops</b> ( <b>Re-entry Loops</b> )	The Re-entry Loops feature allows you to have the switcher either prevent or allow an MLE re-entry feedback loop. If Re-entry Loops is set you On, you are able to re-enter MLE 1 into MLE 2, and re-enter MLE 2 into MLE 1.	<ul> <li>Off — Select this option to have the switcher block re-entry loops. If a crosspoint is selected that would cause a re-entry loop, a popup is displayed and the crosspoint is not selected. If the crosspoint selection is contained in a memory, Black is selected instead.</li> <li>On — Select this option to have the switcher not block re-entry loops. A popup is displayed.</li> </ul>
Roll Clip Mode (RollClip Mode)	The Roll Clip Mode determines how the <b>ROLL CLIP</b> button behaves when a server is selected. This setting is applied to all MLEs on the switcher. <b>Note:</b> If <b>OverDrive</b> is controlling the switcher, this is locked to <b>Arm</b> .	<ul> <li>Play — This mode allows you to play a server clip directly by pressing the ROLL CLIP button on the Transition Module. Once pressed, the clip will start to play and will have to be taken on-air manually with a transition.</li> <li>Arm — This mode allows you to have the server play the clip with the next transition performed in the Transition Module that the ROLL CLIP button is on, or lit, in. This can be used to roll multiple servers if they are re-entered. Once pressed, the clip will only start to play when a Cut or Auto-Transition is performed. You can also play the clip by double-pressing the crosspoint button on the same MLE.</li> <li>Armed Always — This selection locks the switcher in Arm and does not allow the ROLL CLIP button to be turned off.</li> </ul>
Shift Locking (Shift Locking)	The Shift Locking feature sets whether double-pressing the <b>SHIFT</b> button on a crosspoint bus toggles shift on. <b>Note</b> : If Shift Lock is active on an MLE, the mnemonics for that MLE switch to a two-line format.	<ul> <li>Off — Select this option to have the Shift button function normally.</li> <li>On — Select this option to have the bus remain shifted when the SHIFT button is double-pressed. Pressing the SHIFT button again returns the bus to unshifted.</li> </ul>

Table 11.1 Personality Option Settings

Personality Option	Description	Values
Show CC's on Key Bus (ShowCCAttach)	The Show CC's on Key Bus feature sets whether or not custom controls that are attached to crosspoint buttons on the keyer bus are shown on the keyer mnemonics.	<ul> <li>Off — Select this option to not show the custom control name on the mnemonic.</li> <li>On — Select this option to show the name of the custom control attached to a crosspoint button on the mnemonic.</li> </ul>
Squeeze & Tease Mode (S&T Mode)	Refer to the section " <b>Squeeze &amp; Tease Mode</b> " on page Eng 12-5 for information on this personality setting.	
Store Mode (Store Mode)	The Store Mode sets whether or not a memory module remains in Store Mode after a memory has been stores, or switch to Recall Mode.	<ul> <li>Hold — Select this option to have the Global Memory Module, or the Memory Module, stay in Store mode after a memory has been stored.</li> <li>1-Time — Select this option to have the Global Memory Module, or the Memory Module, switch to Recall mode after a memory has been stored.</li> </ul>
Swap Keyer Cut & Auto (SwapKeyC/A)	The Swap Keyers Cut & Auto feature allows you to swap the behavior of the <b>CUT</b> and <b>Auto TRANS</b> buttons on the <b>Keyers</b> module. When this feature is set to swap, the <b>CUT</b> button performs an auto transition, and the <b>AUTO TRANS</b> button performs a cut.	<ul> <li>Swap — Select this option to have the CUT and AUTO TRANS buttons on all Keyers modules swap their functions. The CUT button performs an Auto Trans.</li> <li>Normal — Select this option to have the transition buttons on the Keyers modules keep their original functions.</li> </ul>
Swap PGM/PST Buses (SwapPGM/PST)	The Swap Program and Preset Buses feature allows you to swap the functions of the Program bus to the Preset bus on all MLEs. When this feature is turned on, the sources that you select on the preset bus act as if they are being selected on the program bus, and the sources selected on the program bus act as if they are being selected on the preset bus.	<ul> <li>Swap — Select this option to have the Program and Preset buses on all MLEs swapped.</li> <li>Normal — Select this option to have the Program and Preset buses keep their original functions.</li> </ul>
Swap Trans Cut & Auto (SwapTransC/A)	The Swap Trans Cut & Auto feature allows you to swap the behavior of the <b>CUT</b> and <b>Auto TRANS</b> buttons on the <b>Transition</b> module. When this feature is set to swap, the <b>CUT</b> button performs an auto transition, and the <b>AUTO TRANS</b> button performs a cut.	<ul> <li>Swap — Select this option to have the CUT and AUTO TRANS buttons on all Transition modules swap their functions. The CUT button performs an Auto Trans.</li> <li>Normal — Select this option to have the transition buttons on the Transition modules keep their original functions.</li> </ul>

 Table 11.1 Personality Option Settings

Personality Option	Description	Values
Time Clock Source (TimeClock Src)	The Time Clock Source feature allows you to set the source for the Preview Overlay Time Clock. This source can either be internally generated, or generated from an external UMD device. An external UMD device must be set up on a Remote port in order for the switcher to receive time clock data.	<ul> <li>Internal — Select this option to have the switcher use the internally generated time clock data.</li> <li>UMD Input — Select this option to have the switcher use data from an external UMD device for the time clock. You must use the Time Clock UMD Number feature to set which UMD Address that the time clock data should come from.</li> </ul>
Time Clock UMD Number (TimeClock UMD)	The Time Clock UMD Number feature allows you to set the specific address of the UMD input that you want to get the time clock data from.	• Use the <b>Value</b> knob on the <b>Personality</b> <b>Menu 1-2</b> to select the address, or UMD input number, that you want to get the time clock data from.
UltraChrome Dflt Color (UChrome Color)	The UltraChrome Default Color feature allows you to set the default color that the UltraChrome will be set to when the keyer has been defaulted. Once a different color is set for the UltraChrome, that new color remains until the keyer is defaulted, or until a different UltraChrome color is set manually.	• Use the <b>Value</b> knob on the <b>Personality</b> <b>Menu 1-2</b> to select the default color you want to use for UltraChrome.
UltraChrome Dflt Mode (UChrome Mode)	The UltraChrome Default Mode feature allows you to set the default mode that UltraChrome operates in. Once a different mode is set for the UltraChrome, that mode remains until the keyer is defaulted, or until a different UltraChrome mode is set manually.	• Use the Value knob on the Personality Menu 1-2 to select the default mode for UltraChrome. Refer to the section "UltraChrome Operating Modes" on page Ops 7-11 for more information on the UltraChrome modes.
Wake Up On Command (Wakeup On Cmd)	The Wake Up On Command feature allows you to specify whether the control panel will wake from sleep mode when it receives a command from OverDrive.	<ul> <li>On — Select this option to have the control panel wake up when it received a command from OverDrive.</li> <li>Off — Select this option to have the control panel not wake up when it received a command from OverDrive.</li> </ul>
VTR POL On-air Display (VTR On-air)	The VTR On-air feature allows you to specify whether the current timecode or the remaining time (for a video server) of the currently loaded clip is displayed on the On-air line on the Preview Overlay when VTR TC is active.	<ul> <li>Current — Select this option to use the current timecode of the VTR, or Video Server.</li> <li>Remaining — Select this option to use the remaining time of the currently loaded clip. Cannot be used for VTRs, on Video Servers.</li> </ul>
VTR POL Prep'd Display (VTR On-air)	The VTR Prepared feature allows you to specify whether the current timecode or the remaining time (for a video server) of the currently loaded clip is displayed on the Prepared line on the Preview Overlay when VTR TC is active.	<ul> <li>Current — Select this option to use the current timecode of the VTR, or Video Server.</li> <li>Remaining — Select this option to use the remaining time of the currently loaded clip. Cannot be used for VTRs, on Video Servers.</li> </ul>

Table 11.1 Personality Option Settings

### **Control Panel Button Color Schemes**

The current color selection for the buttons on the control panel can be edited at any time during operation. This allows you to change the glow color for MLEs and AuxKeys, as well as the on-air crosspoints, or apply a specific color to an input. The color of the control buttons on the control panel modules can also be edited.

### **General Color Usage Setup**

There are a number of options for how the colors of the buttons on the Vision control panel can be organized. Each MLE can have a unique color, or they can all be the same. Unique colors can also be applied to the buttons on the touchscreen display, and the auxiliary control panels, as well as the selected crosspoint or function buttons. The MLE re-entry buttons and specific crosspoint buttons can have unique colors as well.

The color usage for the control panel must be set up before the individual colors can the edited.

Use the following procedure to set up the general color usage for the control panel:

- 1. Navigate to the Color Scheme Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Personality ⇒ Color Scheme.



Color Scheme Menu 1-3

- 2. Toggle the MLEs Same Clr on the Color Scheme Menu 1-3 to On or Off to apply the same color all MLEs:
  - Off Select this option to use individual color schemes for each MLE on the switcher. Each MLE will have the current color scheme that is assigned to it displayed on the menu.
  - **On** Select this option to use the same color scheme for all MLEs on the switcher. The individual color schemes for each MLE are replaced with a single global color scheme on the menu.
3. Press Set Up User Colors on the Color Scheme Menu 1-3.

Color Scheme	9 (1-3)	44 Back	PP Forward	Copy Up	13 Swap	Option: Selected	Xpts
Monitor Skin:	Sapphire					Selected	Controls
MLE 1 Glow:	ltem (	On Colon	On Air	Brightness: 100.0	0%		
MLE 2 Glow:	User (	Color 1:	Panel I	Brightness: 100.0	0%	Lines	
MLE 3 Glow:	User	Color 2:				item On	Color C
MLE 4 Glow:	User	Color 3:	Select	ed Xpts: Item	On Color	MLE Col	or 🖸
MLE 5 Glow:	User	Color 4:	Custor	n Controls: Diso	Color		۲
MLE 6 Glow:	User	Color 5:	Re-ent	ry Glow: Yes			
MLE 7 Glow:	User (	Color 6:	Xpt Co	lours: Yes			
MLE 8 Glow:	User (	Color 7:					
Aux Glow:	User (	Color 8:					
Disp/CC Glow:	User (	Color 9:					
Select Buttons	4 Modify Color	Set Up User Colors	MLEs Same Cir On/Off	Setup Xp Colors	t 🕹 Lo	ad Color heme	More

Set Up User Colors — Color Scheme Menu 1-3

- 4. Assign a color for selected crosspoint buttons as follows:
  - Use the **Option** knob on the **Color Scheme Menu 1-3** to select **Selected Xpts**.
  - Use the **Use** knob on the **Color Scheme Menu 1-3** to select which color you want to use for the selected buttons. You can choose between the following:
    - Item On Color Select this option to apply the Item On Color to the selected crosspoints buttons.
    - > **MLE Color** Select this option to apply the **MLE Glow** color to the selected crosspoint buttons.
- 5. Assign a color for selected non-crosspoint buttons on each module as follows:
  - Use the **Option** knob on the **Color Scheme Menu 1-3** to select **Selected Bttns**.
  - Use the **Use** knob on the **Color Scheme Menu 1-3** to select which color you want to use for the selected buttons. You can choose between the following:
    - Item On Color Select this option to apply the Item On Color to the selected buttons.
    - > **MLE Color** Select this option to apply the **MLE Glow** color to the selected buttons.
- 6. Assign a color for the custom control buttons as follows:
  - Use the **Option** knob on the **Color Scheme Menu 1-3** to select **Custom Controls**.
  - Use the **Use** knob on the **Color Scheme Menu 1-3** to select which color you want to use for the custom control buttons. You can choose between the following:
    - > **Disp Color** Select this option to apply the **Display Glow Color** to the custom control buttons.
    - > **MLE Color** Select this option to apply the **MLE Glow** color to the selected buttons.
- 7. Assign a color for the re-entry buttons as follows:
  - Use the **Option** knob on the **Color Scheme Menu 1-3** to select **Re-entry Glow**.
  - Use the **Use** knob on the **Color Scheme Menu 1-3** to turn this feature on or off:
    - > No Select this option to not assign a different color to the re-entry buttons.
    - Yes Select this option to assign the MLE Glow color to the re-entry button for that MLE. For example, if the glow color for MLE 1 is blue, and the glow color for MLE 2 is yellow. The re-entry button for MLE 1 is blue on MLE2, instead of the yellow glow color for MLE 2.

- **8.** Assign a color for the select crosspoint buttons as follows:
  - Use the **Option** knob on the **Color Scheme Menu 1-3** to select **Xpt Colors**.
  - Use the Use knob on the Color Scheme Menu 1-3 to turn this feature on or off.
    - > **No** Select this option to not use a different color for specific video inputs.
    - Yes Select this option to allow a User Color to be applied to the crosspoint button for a specific video input. Refer to the section "Assigning a Crosspoint Color" on page Eng 11-16 for information on assigning a color to a video input.

This completes the procedure for setting up the general color usage for the control panel

## Assigning a Crosspoint Color

Each video source on the switcher can have one of six user assignable colors assigned to the crosspoint button for that source.

To assign a user color to a specific crosspoint button, the Xpt Colors option must be turned on. Refer to the section "General Color Usage Setup" on page Eng 11-14 for information on turning on the Xpt Color option.

Use the following procedure to assign a user color to a crosspoint button:

- 1. Navigate to the Setup Xpt Colors Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Personality ⇒ Color Scheme ⇒ Setup Xpt Colors.

Setup Xpt Colors	44 Back	PF Forward	Copy Up	13 Swap	Input:
Use this menu to assign a user c	olor for Xpts that you w	ish to be differe	nt than the glow	color.	BNC C01 (C01) O BNC C02 (C02)
To enable user colors for Xpts: The <b>Xpt Colors</b> option in t	he Color Scheme menu	must be set to 1	res.		Color: User Color 9 Default

Setup Xpt Colors Menu

- **2.** Use the **Input** knob on the **Setup Xpt Colors Menu** to select the button, or input, that you want to assign a user color to.
- **3.** Use the **Color** knob on the **Setup Xpt Colors Menu** to assign a user color to the selected input.

This completes the procedure for assigning a user color to a crosspoint button.

## **Selecting a Color**

Any of the glow or user colors for the buttons on the control panel can be adjusted.



**Note** — With some pre-loaded color schemes, or user created color schemes, the **Item On Color** or **On-Air** colors may not be easily distinguishable from the **Glow** color. Make sure to test a color scheme with each MLE and Aux before using it. Use the following procedure to select a color:

- 1. Navigate to the Color Scheme Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Personality ⇒ Color Scheme.
- 2. Press Select Buttons on the Color Scheme Menu 1-3.

Color Scheme	(1-3)	44 Back	PForward	Copy Up	33 Swap		100.0%)
Monitor Skin:	Sapphire					B	on Air rightness
MLE 1 Glow: MLE 2 Glow: MLE 3 Glow: MLE 4 Glow: MLE 5 Glow: MLE 6 Glow:	Item On Co User Color User Color User Color User Color User Color	llon 1: 2: 3: 4: 5:	On Air Panel Selecti Selecti Custor Re-ent	Brightness: 100, Brightness: 100, ed Xpts: Item ed Bttns: Item n Controls: Disp try Glow: Yes	0% 0% On Color On Color Color	Color: MLE 1 G MLE 2 G MLE 3 G	ilow o
MLE 7 Glow: MLE 8 Glow: Aux Glow: Disp/CC Glow:	User Color User Color User Color User Color	6: 7: 8: 9:	Xpt Co	ilours: Yes			100.0%) Panel rightness
Select Buttons	Modify     Se     Color     Us	t Up er Colors	MLEs Same Cir On/ <b>Off</b>	Setup Xp Colors	t 🕹 Los	nd Color heme	More

Color Scheme Menu 1-3

- **3.** Adjust the Glow color of the MLEs and Aux Buses as follows:
  - Use the **Color** knob on the **Color Scheme Menu 1-3** to select the element that you want to change the color for.
  - Press Modify Color on the Color Scheme Menu 1-3.

Color Selection	44 Back M Torregal A Depty App	Swap
MLE Glow:		Luminance
Red Green Blue -11.0% 4.8% 76.7%	B Color 1	1 (100.0%) Saturation
G	C C	(94.6%) Hue
RGB HSL		<b>4</b> Pro-

HSL Color Space — Color Selection Menu

- Select the color space that you want to edit the button color in as follows:
  - RGB Press RGB on the Color Selection Menu to display the RGB color space. This allows you to edit the button color by mixing Red, Green, and Blue together.
  - HSL Press HSL on the Color Selection Menu to display the HSL color space. This allows you to edit the button color by adjusting the Hue, Saturation, and Luminance of the color.
- Modify a color as follows:
  - > HSL Color Space Use the Luminance, Saturation, and Hue knobs on the Color Selection Menu to adjust the color of the selected element.
  - RGB Color Space Use the Red, Green, and Blue knobs on the Color Selection Menu to adjust the color of the selected element.
- Press UP ONE to accept the color selection and display the Color Scheme Menus.

This completes the procedure for selecting a color.

# **Mnemonic Color Schemes**

The current color selection for the mnemonics on the buses of the control panel can be edited at any time during operation. By adjusting the brightness of the color LEDs in the mnemonics, you can create a new, custom color for the mnemonics.

Custom colors for individual Input BNCs can be created for each video source. Refer to the section "**Naming Video Inputs**" on page Eng 7-2 for more information on editing mnemonic colors for individual Input BNCs.

Use the following procedure to set the default color for the mnemonics on the buses of the control panel:

- 1. Navigate to the Color Scheme Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Personality ⇒ Color Scheme.
- 2. Press More.
- **3.** Select the mnemonic color that you want to adjust as follows:
  - Orange Press Mnemonic Orange and use the Orange Gain knob on the Color Scheme Menu 2-3 to adjust the gain of the orange LED in the mnemonics.



Orange Mnemonic Brightness — Color Scheme Menu 2-3

- Yellow Press Mnemonic Yellow and use the Yellow Gain knob on the Color Scheme Menu 2-3 to adjust the gain of the yellow LED in the mnemonics.
- Green Press Mnemonic Green and use the Green Gain knob on the Color Scheme Menu 2-3 to adjust the gain of the green LED in the mnemonics.
- 4. Press Panel Mnemonic Bright/Contrast on the Color Scheme Menu 2-3.

Color Schem	lor Scheme (2-3)		< Provincial Contraction of the	Copy Up	3 Swap	( 50.0%) Mnemonic Brightness
			Adjj and mn	ust the overall brigh contrast of the pan emonic displays	tness el	( 75.0%) Mnemonic Contrast
Mnemonic Orange	Mnemonic Yellow	Mnemonic Green	Panel Mnemonic Bright / Contrast	Ext. Mnemonic Bright / Contrast	Display Bright / Contrast	More Nore

Panel Mnemonic Brightness and Contrast Settings - Color Scheme Menu 2-3

- **5.** Adjust the Brightness and Contrast of the mnemonic display on the control panel as follows:
  - Use the **Mnemonic Brightness** knob on the **Color Scheme Menu 2-3** to adjust the brightness of the mnemonics.
  - Use the **Mnemonic Contrast** knob on the **Color Scheme Menu 2-3** to adjust the contrast of the mnemonics.
- 6. Press Extern Mnemonic Bright/Contrast on the Color Scheme Menu 2-3.

Color Schem	olor Scheme (2-3)		< De l'emane il	Copy Up	13 Swap	( 50.0%) Mnemonic Brightness
			Adj and mn	ust the overall b I contrast of the emonic displays	rightness external	(25.0%) Meemonic Contrast
Mnemonic Orange	Mnemonic Yellow	Mnemonic Green	Panel Mnemonic Bright / Contrast	Ext. Mnemani Bright / Contra	c Display Bright / f	Contrast

Extern Mnemonic Brightness and Contrast Settings - Color Scheme Menu 2-3

- **7.** Adjust the Brightness and Contrast of the mnemonic display on external panels, such as the Auxiliary Control Panel, as follows:
  - Use the **Mnemonic Brightness** knob on the **Color Scheme Menu 2-3** to adjust the brightness of the mnemonics.
  - Use the **Mnemonic Contrast** knob on the **Color Scheme Menu 2-3** to adjust the contrast of the mnemonics.

This completes the procedure for setting the default color for the mnemonics on the buses of the control panel.

# **Control Panel Display Brightness**

You can adjust the brightness of the Control Panel Displays from the menu. These displays include all the module displays found on the control panel, but not the Touchscreen Display.



**Operating Tip** — Lower **Display Brightness** settings will prolong the life of the displays on the control panel.

Use the following procedure to adjust the brightness of the displays on the control panel:

- 1. Navigate to the Color Scheme Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Personality ⇒ Color Scheme.
- 2. Press More ⇒ Display Bright./Contrast on the Color Scheme Menu 2-3.

Color Schem	or Scheme (2-3)		k De formard (	Copy Up	13 Swap	( 75.0%) Display Brightness
			Adji and disp	ust the overall brig contrast of the pa plays	htness nel text	(75.0%) Display Contrast
Mnemonic Orange	Mnemonic Yellow	Mnemonic Green	Panel Mnemonic Bright / Contrast	Ext. Mnemonic Bright / Contrast	Display Bright / C	ontrast

Display Brightness and Contrast Settings - Color Scheme Menu 2-3

- **3.** Use the **Display Brightness** knob on the **Color Scheme Menu 2-3** to adjust the brightness of the displays.
- **4.** Use the **Display Contrast** knob on the **Color Scheme Menu 2-3** to adjust the contrast of the displays.

This completes the procedure for adjusting the brightness of the displays on the control panel.

#### For More Information ...

• on menu themes, refer to the section "Menu Skins" on page Eng 5-11.

# **Loading Color Schemes**

The Vision switcher comes pre-installed with a number of different color schemes that you can use.

Each color scheme contains the button color settings, mnemonic brightness and contrast, as well as the brightness and contrast of the displays. Monitor Skins are not included in Color Schemes

Use the following procedure to load a color scheme:

- 1. Navigate to the Color Scheme Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Personality ⇒ Color Scheme.
- 2. Press Load Color Scheme on the Color Scheme Menu 1-2.

Load Color Scheme Monitor Skin: MLE 1 Glow: MLE 2 Glow: MLE 3 Glow: MLE 4 Glow: MLE 5 Glow:	44 Back Item On Color: User Color 1: User Color 2: User Color 3: User Color 4:	Custo	Copy Up     Brightness: 100     Brightness: 100     ed Xpts: Item     ed Bttns: Item     n Controls: Disp	13 Swap 0% 0% 0 On Color 0 On Color 0 On Color	Scheme: BlueMachine BoysAndGirls Classic Default Desert GirlsAndBoys Golf Holes HotPink Hulk	00
MLE 7 Glow: MLE 8 Glow: Aux Glow: Disp/CC Glow:	User Color 6: User Color 7: User Color 8: User Color 9:	Xpt Co	Undo Changes	Sele	Incandescent Island JuliePink Kahuna Koffee	

Load Color Scheme Menu

- **3.** Use the **Scheme** (middle) knob on the **Load Color Scheme Menu** to select the color scheme you want to load.
- **4.** Press **Select This Scheme** on the **Load Color Scheme Menu** to apply the selected color scheme to the switcher.



**Operating Tip** — If you do not want to use the selected color scheme, you can press **Undo Changes** on the **Load Color Scheme Menu** to revert back to the previous color scheme.

This completes the procedure for loading a color scheme.

# Lock/Unlock Personality

The Lock/Unlock Personality feature allows you to lock-out changes to the **Personality Menus** on the switcher with a password. This prevents anyone from changing settings on the **Personality Menus** without first unlocking the personality settings. This also included the recalling of a personality register.

A **Warning Screen** is displayed when you attempt to navigate to the **Personality Menu** stating that the personality settings are locked and any changes will not be saved.

Use the following procedure to lock or unlock the personality settings of the switcher:

- 1. Navigate to the Lock/Unlock Personality Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ More ⇒ Lock/Unlock Personality.

**Note** — If the Lock/Unlock Personality feature is active, and a password has been set up, the **Enter Personality Password Menu** is displayed. Enter the password in the **New Name** field and press **Accept New Name** to display the **Lock/Unlock Personality Menu**.

Lock/Unlock Personality	44 Back	PPT control 1	\$ 540X (48.1	13 Swap	
No password is set.					
You can still lock/unlock the Personalit	y settings.				
Personality Lock Add					

Lock/Unlock Personality Menu

- **2.** Turn the personality lock on or off as follows:
  - Toggle Personality Lock on the Lock/Unlock Personality Menu to On or Off:
    - > **On** Select this option to turn the personality lock feature on.
    - > **Off** Select this option to turn the personality lock feature off.



**Operating Tip** — You can delete the current password by pressing **Clear Password** on the **Lock/Unlock Personality Menu**.

- **3.** Set a password for the personality lock as follows:
  - Press Add/Change Password on the Lock/Unlock Personality Menu to display the Change Personality Password Menu. If a password has already been set, the button is labelled Change Password.

Change Personality Password	44 Back	W Tormani	A SHEW GE	03 Swap		
1 0 <b>* \$</b> % ^ 1 2 3 4 5 6	& * 7 8	( ) 9 0	: :	Backspace		
Q W E R T Y	UI	0 P				
Caps Lock A 5 D F	G H	J K	L :	; DEL		
Shift Z X C V	BN	M <	7			
🤞 🔶 Si	sace	w Password (M/	X 8 Characters	N		
Clear				Accept New Pass	sword	And the second

Change Personality Password Menu

- Enter the new password in the **New Password** field on the **Change Personality Password Menu**.
- Press Accept New Password on the Change Personality Password Menu to save the new password.

This completes the procedure for locking or unlocking the personality settings of the switcher.

# **Completing Setup**

# In This Chapter

This chapter provides information on finalizing the setup of the Vision switcher. This includes setting up Aux Buses, including the installation of remote aux panels, recalling factory setting, personality setup, and setting up the preview overlay.

The following topics are discussed in this chapter:

- Aux Bus Setup
- Default MLE Map Assignment
- Squeeze & Tease Mode
- Key 4 Mode
- Standard GPI Setup
- Clip Setup
- Audio Channel Setup
- Factory Default Settings
- Preview Overlay Setup
- Set System Time
- Auto Follow
- Lock/Unlock Installation

## **Aux Bus Setup**

An Aux Bus allows you to use the additional Output BNC of the Vision switcher to pass video signals out to other external equipment. There are a total of **48** Aux Buses available on the switcher, that have access to all the same video signals that are available to an MLE. The Aux Buses are organized into **6 Banks**, with **8 Aux Buses** per bank.

If you have the AuxKey option installed, Aux Bus outputs can be used to pass dedicated mixed video signals, including keys, out to other external equipment, or back into the switcher as an additional mixer/keyer.

An Aux Bus can be accessed in a number of ways, either through the Auxiliary Control Panels, or by assigning a crosspoint group to an Aux Bus.

#### **Setting up Aux Buses**

Use the following procedure to assign the Crosspoint Group to an Aux Bus:

- 1. Press the **SEL** button on the **Crosspoint Group** that you want to assign the Aux Bus to. The **MLE SEL Button Menu** for the selected **Crosspoint Group** is displayed.
- 2. Press Select Aux Bus on the MLE SEL Button Menu.

MLE Sel E	Button		44 Ba	ck 🖗	nerst erer (	Copy Up	33 Swa	p	
Quick Prese	ets	Switcher	Row 3: Curre	ent Selection	n: AuxBus 8	ank1Aux2(1:3	23		
AUXBUS Audius 1.1 Bink1Aux1 BLACK	AUXBUS AuxBus 1.2 Bink1Aux2 BLACK	BANK 1	BANK 2	BANK 3	BANK 4	BANK 5	BANK 6		
AUXBUS AuxBes 1.3 Brk1Aux3 BLACK	AUXBUS AuxBus 1 4 BrklAux4 BLACK	AUX 1 BoklAux1 BLACK	AUX 2 Brik1Acx2 BLACK	AUX 3 BrklAux3 BLACK	AUX 4 BinklAux4 BLACK	AUX 5 Brik1Aux5 BLACK	AUX 6 BeklAux6 BLACK	AUX 7 Brik1Aux7 BLACK	AUX 8 Brk1Auxt BLACK
Select Key/Util Bu		ct Bus	Key 4 Flexi Mode	SK M	lect	Assign As Prese		Lock Bus On/ <b>Off</b>	) 

Aux Bus Selection - MLE SEL Button Menu

- **3.** Press the **Aux Bus Bank** *X* button on the **MLE SEL Button Menu** to select the Aux Bus Bank that you want to use, where *X* is the number of the bank.
- 4. Press the Aux Bus X or AuxKey X button on the MLE SEL Button Menu to select the Aux Bus that you want to use, where X is the number of the aux bus.

This completes the procedure for assigning the Crosspoint Group to an Aux Bus.

#### For More Information...

• on using an Aux Bus, refer to the section "Assigned to Aux Bus" on page Ops 4-7.

#### Naming Aux Buses

Each Aux Bus on the Vision switcher can be given a specific name that is displayed on the menus for that source.

Use the following procedure to modify the name of an aux bus:

- 1. Navigate to the Aux Bus Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Aux Bus.

2. Press Modify Name on the Aux Bus Menu.

Aux Bus Names	44 Back	• • Termerer	- 4 1997/1991	193 (CONT)		
! @ <b>\$ \$ \$ \$</b> 6	& * 7 8	( ) 0 e		Backspace		
Q W E R T Y Caps Lock A 5 D F	G H	I K				
Shift Z X C V	BN	M <	> 7		_	
<b>4 5</b>	pace	New Name (MAX B Birk 1Aux 1	Charactersk		Aux Bus	.(1:1)
Clear			Default	Accept New N	ame	Anton

Aux Bus Names Menu

**Operating Tip** — Refer to the section "Using the Naming Menus" on page Eng 5-16 for more information on using the Aux Bus Names Menu to enter a name.

- 3. Use the Aux Bus knob to select the Aux Bus you want to name.
- 4. Enter the new name you want to use in the New Name field.
- 5. Press Accept New Name to assign the name to the Aux Bus.

This completes the procedure for naming an Aux Bus.

#### For More Information...

- on setting up an Output BNC as an Aux Bus output, refer to the section "Configuring Video Outputs" on page Eng 8-2.
- on setting up and using the AuxKeys option, refer to the section "AuxKeys" on page Eng 8-22.
- on setting up an Auxiliary Control Panel, refer to the section "Auxiliary Panels" on page Eng 14-1.
- on assigning Bus Maps to all or individual Aux Buses, refer to the section "Assigning Panel Bus Maps" on page Eng 7-19.

# **Default MLE Map Assignment**

The Default MLE Map Assignment feature allows you to specify the default MLE that each Crosspoint Group, or row, on the switcher, and external to the switcher, is assigned to.

Use the following procedure to set the default MLE map assignment:

- 1. Navigate to the MLE Map Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Personality ⇒ MLE Maps.



MLE Map Menu

- 2. Use the **Panel Row** knob on the **MLE Map Menu** to select the Crosspoint Group, or row, that you want to assign an MLE to. You can choose between the following:
  - **Row X** Select the row on the control panel (**1** through **8**) that you want to assign an MLE to, where **X** is the number of the row.
  - Ext Row X Select the external row (1 through 16) on an Auxiliary Control Panel, for example, that you want to assign an MLE to, where X is the number of the row.
- **3.** Use the **Mapped to MLE** knob on the **MLE Map Menu** to select the MLE that you want to assign to the selected row to.

**Note** — The Default MLE Map Assignment is only applied after a restart or **ALL+ALL** software reset. Refer to the section "**Resetting the Switcher**" on page Eng 4-25 for more information on performing a restart or software reset.

This completes the procedure for setting the default MLE map assignment.

# Squeeze & Tease Mode

The Squeeze & Tease Mode sets how Squeeze & Tease resources are allocated or shared among MLE-pairs on the switcher.

Use the following procedure to set up the Squeeze & Tease Mode:



**Important** — The **OverDrive Production Control System** requires the **Squeeze & Tease Mode** to be set to **Fixed**.

- 1. Navigate to the **Personality Menus** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Personality.
- 2. Use the Option knob on the Personality Menu 1-2 to select S&T Mode.



Squeeze & Tease Mode — Personality Menu 1-2

3. Use the Value knob on the Personality Menu 1-2 to toggle to Fixed or Float.



**Note** — Squeeze & Tease MD DVE channel resources are available to MLE-pairs. How many DVE channel resources are available to each MLE-pair depends on the configuration of your switcher. Refer to the section "**Squeeze & Tease**" on page Eng 2-27 for more information on the different configurations.

- **Fixed** Select this option to have the Squeeze & Tease DVE channel resources and WARP resources locked to specific MLEs in the MLE-pair as follows:
  - > Octane/QMD-X MLEs 1-4 have 4 DVE channel resources locked to them, and MLEs 5-8 have 2 DVE channel resources locked to them. MLE 6 and MLE 8 each have a single WARP resource locked to them.
  - > **QMD-X** Each MLE has **4** DVE channel resources locked to it.
  - > MD-X Each MLE has 4 DVE channel resources locked to it.
  - > QMD Each MLE has 2 DVE channel resources locked to it. The PGM MLE and second highest numbered MLE each have a single WARP resource locked to them.
  - > MD Each MLE has 4 DVE channel resources locked to it.
- **Floating** Select this option to have the Squeeze & Tease DVE channel resources and WARP resources float across the MLE-pair as follows:
  - > Octane/QMD-X MLEs 1-4 have access to all 8 DVE channel resources provided by the Squeeze & Tease Carrier Board, and MLEs 5-8 have access to 4 DVE channel resources, and a single WARP resource.

- > QMD-X Each MLE-pair has access to all 8 DVE channel resources provided by the Squeeze & Tease Carrier Board.
- > **MD-X** Each MLE-pair has access to all **8** DVE channel resources provided by the **Squeeze & Tease Carrier Board**.
- > QMD Each MLE-pair has access to 4 DVE channel resources, and a single WARP resource. For example, MLE 1 and MLE 2 share 4 DVE channel resources and 1 WARP resource, and MLE 3 and MLE 4 share the remaining 4 DVE channel resources and 1 WARP resource.

**Note** — If there is only **1 Squeeze & Tease MD WARP** card installed in the QMD frame, that WARP resource floats between all MLES on the switcher. If there is only **1 Video Processor Board** board installed in the QMD frame, WARP resources float between both MLES on the switcher.

> **MD**—Each MLE-pair has access to all **8** DVE channel resources provided by the **Squeeze & Tease Carrier Board**.

This completes the procedure for setting up the Squeeze & Tease Mode.

#### For More Information...

- on MLEs and video routing, refer to the section "Video Routing" on page Eng 2-20.
- on Squeeze & Tease DVE Channel Resources, refer to the section "Flying Keys" on page Ops 12-10.

# Key 4 Mode

The Key 4 Mode sets how many Utility Buses, Aux Bus Color Correctors and Clean Feeds are available to the selected MLE when Key 4 is using internal or external video sources.

Key 4 Mode is only available on 4-Keyer Octane/QMD-X and QMD switchers.

 $\bigcirc$ 

**Note** — You must have the XFX Board with MLE-Stores option installed for the selected MLE to have MLE-Store sources available to Key 4. If the MLE-Store option is not installed, Black is selected for Key 4.

Use the following procedure to set up the Key 4 Mode:

- 1. Navigate to the Key 4 Configuration Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Key 4 Config.

 ingurati		-	, over					
MLE 1	MLE 2	MLE 3	MLE 4	MLE 5	MLE 6	MLE 7	MLE 8	
Flexi Mode	External Mode	Internal Mode 1	Internal Mode 2	Internal Mode 3				
	Fixed intern Key 4 sourc 1 Utility Bus 1 Color Corr 1 Clean Fee	al Mode 3 es restricted to ector for Aux E d available	o MLE-Stores lus outputs					

Flexi Mode — Key 4 Configuration Menu

- 2. Press the MLE X button on the Key 4 Configuration Menu to select the MLE that you want to set up the Key 4 Mode for.
- **3.** Select the mode that you want to assign to the selected MLE as follows:
  - Flexi Mode Select this option to be able to switch between External Mode and Internal Mode 1 from the MLE Sel Button Menu.
  - External Mode Select this mode to allow Key 4 to have access to all video sources. The selected MLE has access to 0 Utility Buses, 0 Aux Bus Color Correctors, and 2 Clean Feeds.
  - Internal Mode 1 Select this mode to restrict Key 4 to have access to MLE-Stores only. The selected MLE has access to 2 Utility Buses, 0 Aux Bus Color Correctors, and 2 Clean Feeds.
  - Internal Mode 2 Select this mode to restrict Key 4 to have access to MLE-Stores only. The selected MLE has access to 0 Utility Buses, 2 Aux Bus Color Correctors, and 0 Clean Feeds.
  - Internal Mode 3 Select this mode to restrict Key 4 to have access to MLE-Stores only. The selected MLE has access to 1 Utility Bus, 1 Aux Bus Color Corrector, and 1 Clean Feed.
- 4. Press HOME to display the Installation Change Confirmation Screen.
- 5. Accept or reject the changes you have made as follows:
  - Press Confirm to accept the changes and reset all Remote, Peripheral, and Net ports.

- Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
- Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for setting up the Key 4 Mode.

#### For More Information...

• on using the Flexi Mode, refer to the section "Selecting a Key 4 Flexi Mode" on page Ops 4-9.

# **Standard GPI Setup**

The Vision switcher uses General Purpose Interface (GPI) input and output signals to trigger events on external equipment, or have external equipment trigger events on the switcher. All of these signals are passed through a single DB25 port on the **Frame CPU Board**. This port provides the **10 GPI Inputs** and **10 GPI Outputs** of the standard GPIs, with a single **Ground** pin.



**Operating Tip** — A **GPI Output Worksheet** and a **GPI Input Worksheet** are provided to assist you in setting up your GPIs. Refer to the section "**Standard GPI I/O Input Worksheets**" on page Eng 21-13 for a copy of the GPI Input worksheet. Refer to the section "**Standard GPI I/O Output Worksheets**" on page Eng 21-14 for copy of the GPI Output worksheet.

### **GPI I/O Information**

You can use the GPI I/O Information to check the settings of all the GPI I/Os on the switcher. This allows you to quickly determine which GPI I/O is being used for what, and which GPI I/Os are still available for use.

Use the following procedure to display the GPI I/O Information:

- 1. Navigate to the GPI I/O Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ GPI I/O.
- 2. Press View GPI I/O on the GPI I/O Menu.

GPI I/O		44 Back	M Tormard	@ Rep/1921	93 COMP.	
	Information					
GPI#				Polarity		
GPI 1 Unassig	ned					
GPI 2 Unassig	ned					Use knob 2 to
GPI 3 Unassig	ned					scroll through
GPL 5 Unassig	ned					the list.
GPI 6 Unassig	ned					
GPI 7 Unassig	ned					
Inputs	GPI Polarity	a Name	Outputs	Tally on	Vie	W.

GPI I/O Information - GPI I/O Menu

- **3.** Use the **Scroll** knob on the **GPI I/O Menu** to scroll through the list of input and GPI Outputs. The following information is provided:
  - GPI Information
    - → GPI # This column provides the GPI number and assignment of each GPI Input on the switcher. GPIs that are not assigned are also indicated.
    - Polarity This column provides the current level, or signal polarity, of each GPI Input on the GPI I/O port.

#### • GPO Information

- > GPO # This column provides the GPO number for each GPI Output on the switcher.
- > **Name** This column provides the name of each GPI Output.
- Trigger This column provides the trigger effect that is used for each GPI Output.

> **Level** — This column provides the current level, or signal polarity, of each GPI Output on the GPI I/O port.

This completes the procedure for displaying the GPI I/O Information.

## **GPI I/O Connection**

You can connect a single DB25, male, connector to the **GPI I/O** port on the **CPU Board** frame of your Vision switcher (**Figure 12.1**). The **GPI I/O** port provides **10 GPI Input** pins, **10 GPI Output** pins, plus a single **Ground** pin.



Figure 12.1 GPI I/O Port on Frame CPU Board

To connect to a specific GPI Input or GPI Output, locate the wire connected to the pin for the GPI I/O you want to use (**Table 12.1**).

GPI Input Pin #	Signal	GPI Output Pin #	Signal
1	Ground	1	Ground
2	n/c	14	n/c
3	n/c	15	n/c
4	GPI In 10	16	GPI Out 10
5	GPI In 9	17	GPI Out 9
6	GPI In 8	18	GPI Out 8
7	GPI In 7	19	GPI Out 7
8	GPI In 6	20	GPI Out 6
9	GPI In 5	21	GPI Out 5
10	GPI In 4	22	GPI Out 4
11	GPI In 3	23	GPI Out 3
12	GPI In 2	24	GPI Out 2
13	GPI In 1	25	GPI Out 1

Table 12.1 Pinouts — GPI I/O Port

#### For More Information ...

• on the GPI I/O port, refer to the section "GPI I/O Ports" on page Eng 20-21.

## Setting Up GPI Inputs

GPI Inputs can be used to trigger a number of events on the switcher from a GPI I/O device. An example of a commonly used GPI Input is the small, hand-held, trigger a weather forecaster uses to advance though the different backgrounds in the weather forecast.



**Note** — The GPI Interface must be enabled in order to control the switcher using GPI Inputs. Refer to the section "**GPI Interface Control**" on page Ops 10-2 for more information on turning the GPI Interface on.

Use the following procedure to set up an GPI Input:

- 1. Navigate to the GPI I/O Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ GPI I/O.
- 2. Press Inputs on the GPI I/O Menu.
- 3. Assign a Memory Recall event to an GPI Input as follows:
  - Use the **GPI Input** knob on the **GPI I/O Menu** to select the GPI Input that you want to configure.
  - Use the **Function** knob on the **GPI I/O Menu** to select the function you want to assign to the selected GPI Input. You can choose between the following:
    - > Off Select this option to have the switcher perform no function when a trigger signal is received by the selected GPI Input.
    - Mem Recall Select this option to have the memory recalled across all MLEs when a trigger signal is received by the selected GPI Input.

GPI 1/0	44 Back	PP Forward	A CORVER	13	GR input: GR #1 GR #2	0
Use this menu to match GP in Cut, Auto Transition, Custom Con Memory Recalls.	puts to specific trol buttons, and				GPI #3 Function: Cust Ctrl Mem Recall	0.0
					Memory: Memory00 (0 Memory01 (0 Memory02 (0)	0) 1) 2)
Inputs GPI Polarity	Name     Outputs	Outputs	Tally on QPIs	VH	tw 1/0	

Memory Recall — GPI I/O Menu

- Use the **Memory** knob on the **GPI I/O Menu** to select the memory register that you want to be recalled on all MLEs when the GPI Input signal is received.
- 4. Assign a Transition event to an GPI Input as follows:



**Operating Tip** — A GPI triggered transition will only transition the selected Key or Background buses on the target MLE. If you want to ensure that only a particular transition is performed when the GPI signal is received, have a memory recalled before the transition.

- Use the **GPI Input** knob on the **GPI I/O Menu** to select the GPI Input that you want to configure.
- Use the **Function** knob on the **GPI I/O Menu** to select the function you want to assign to the selected GPI Input. You can choose between the following:
  - > **Off** Select this option to have the switcher perform no function when a trigger signal is received by the selected GPI Input.
  - Auto Select this option to have an auto transition performed in the MLE, or Fade to Black Module, that you select when a trigger signal is received by the selected GPI Input.

Cut — Select this option to have a cut performed in the MLE, or Fade to Black Module, that you select when a trigger signal is received by the selected GPI Input.

GPI I/O Use this menu to match GP input Cut, Auto Transition, Custom Control Memory Recalls.	44 Back	D Forward	<b>9</b> Conv., o	13	GP input: GP #1 GP #2 GP #3 Function: Off Auto Cut Area: MLE 1 MLE 2 MLE 3	.0.
Inputs GPI Polarity	Name     Outputs	Outputs	Tally on OPs	Vie	w Wo	<b>4</b> 100

Transition Function - GPI I/O Menu

- Use the **Area** knob on the **GPI I/O Menu** to select the MLE, or Fade to Black Module, that you want the selected function to be performed when the GPI Input signal is received.
- 5. Assign a Run Custom Control event to an GPI Input as follows:

**Operating Tip** — If you have a custom control with a number of holds in it, the GPI Run Custom Control trigger can be used to start the custom control, and continue it at each hold.

- Use the **GPI Input** knob on the **GPI I/O Menu** to select the GPI Input that you want to configure.
- Use the **Function** knob on the **GPI I/O Menu** to select the function you want to assign to the selected GPI Input. You can choose between the following:
  - > **Off** Select this option to have the switcher perform no function when a trigger signal is received by the selected GPI Input.
  - > **Cust Ctrl** Select this option to have the custom control you select run when a trigger signal is received by the selected GPI Input.



Run Custom Control Function — GPI I/O Menu

- Use the **Cust Ctrl** knob on the **GPI I/O Menu** to select the custom control bank and button you want to run when the GPI I/O signal is received. The Bank is indicated by the number before the **#** sign, and the button by the number after the **#** sign. For example, custom control button **12** on bank **3** is shown as **3#12**.
- 6. Press GPI Polarity on the GPI I/O Menu.



GPI I/O	44 Back	PP Forward	<b>9</b> (2017) (1	13	GPI Input GPI #1 GPI #2	6
Use this menu to set up GR polarity.					Polarity Low High	6
inputs GR Polarity		Outputs	Tally on QPs	Vie	w ivo	- 

GPI Input Polarity - GPI I/O Menu

- 7. Assign a trigger signal polarity to an GPI Input as follows:
  - Use the **GPI Input** knob on the **GPI I/O Menu** to select the GPI Input that you want to configure.
  - Use the **Polarity** knob on the **GPI I/O Menu** to select the trigger signal polarity you want to assign to the selected GPI Input. You can choose between the following:
    - > **Low** Select this option to have the GPI I/O triggered when a low signal is received. The GPI Input should be receiving a constant high signal. When the signal goes low (0 Volts), the GPI I/O will respond to the trigger.
    - High Select this option to have the GPI I/O triggered when a high signal is received. The GPI Input should be receiving a constant low signal. When the signal goes high (+5 Volts), the GPI I/O will respond to the trigger.
- 8. Press HOME to display the Installation Change Confirmation Screen.
- **9.** Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for setting up an GPI Input.

### **GPI Input Tallies**

You can associate a particular GPI Input with a standard parallel tally. This allows you to force the switcher to toggle a tally on or off when an GPI Input signal is received, even if the tally is associated to a BNC that is not on-air.

Use the following procedure to set up an GPI Input tally:

- 1. Navigate to the GPI I/O Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ GPI I/O.
- 2. Press Tally on GPIs on the GPI I/O Menu.



GPI Input Tallies — GPI I/O Menu

**3.** Use the **Tally** knob on the **GPI I/O Menu** to select the tally you want to associate with an GPI Input.

**Note** — You can assign a tally to a GPI Input that is already assigned to an Input BNC. The switcher will not distinguish between a tally that is activated because of a GPI trigger, or because the Input BNC is on-air.

- **4.** Use the **GPI Input** knob on the **GPI I/O Menu** to select the GPI Input that you want to assign to the selected tally. The tally remains on as long as the GPI I/O trigger remains on.
- 5. Press HOME to display the Installation Change Confirmation Screen.
- 6. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for setting up an GPI Input tally.

#### For More Information...

• on assigning tallies to Input BNCs, refer to the section "Assigning Tallies to Video Inputs" on page Eng 7-23.

### **Setting Up GPI Outputs**

GPI Outputs can be used to trigger events on an external GPI I/O device from the switcher. An example of an Output GPI I/O would be the use of an GPI Output to trigger a transition on a Character Generator. Refer to the documentation that came with your device for more information on what commands you can trigger with a GPI I/O.

Use the following procedure to set up an GPI Output:

- 1. Navigate to the GPI I/O Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ GPI I/O.
- 2. Press Outputs on the GPI I/O Menu.



GPI Outputs — GPI I/O Menu

- **3.** Use the **GPI Output** knob on the **GPI I/O Menu** to select the GPI Output that you want to configure.
- **4.** Use the **Trigger** knob on the **GPI I/O Menu** to select the trigger signal type you want to assign to the selected GPI Output. You can choose between the following:
  - **Pulse Low** Select this option to have the GPI Output send a momentary low (0 Volts) trigger and then return to the base high (+5 Volts) level. The duration of the trigger is set with the **Pulse Dur'n** knob.
  - **Pulse High** Select this option to have the GPI Output send a momentary high (+5 Volts) trigger and then return to the base low (0 Volts) level. The duration of the trigger is set with the **Pulse Dur'n** knob.
  - **Level Low** Select this option to have the GPI Output toggle from the base high (+5 Volts) level to the low level (0 Volts). The GPI Output signal remains at this level until reset.
  - Level High Select this option to have the GPI Output toggle from the base low (0 Volts) level to the high level (+5 Volts). The GPI Output signal remains at this level until reset.
- 5. Use the **Pulse Dur'n** knob on the **GPI I/O Menu** to select the duration of the trigger signal, in frames, that you want to use.
- 6. Press HOME to display the Installation Change Confirmation Screen.
- 7. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for setting up an GPI Output.

Trigger

Trigger

Trigger

Trigge

Duration

Duration

## **Naming GPI Outputs**

Each GPI Output can be named. This name is displayed on all the menus for the selected GPI I/O.

Use the following procedure to name an GPI Output:

- 1. Navigate to the GPI I/O Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ GPI I/O.
- 2. Press Name Outputs on the GPI I/O Menu.



Name Outputs Menu

**Operating Tip** — Refer to the section "Using the Naming Menus" on page Eng 5-16 for more information on using the Name Outputs Menu to enter a name for the GPI I/O.

- **3.** Use the **Output number** knob on the **Name Outputs Menu** to select the GPI Output you want to name.
- 4. Enter the new name you want to use in the New Name field.
- 5. Press Accept New Name on the Name Outputs Menu to assign the new name to the GPI Output.
- 6. Press HOME to display the Installation Change Confirmation Screen.
- 7. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for naming an GPI Output.

# **Clip Setup**

In order to easily recall clips on the VTR or Video Server from the Vision switcher, you must store the clips you want to use to **Clip Registers** on the switcher. These Clip Registers store the location, or timecode, on the device for the clip, and the name of the clip.

In a MultiPanel configuration, only the Master Panel can access the VTR Clips Menus.

The VTR Clips Menu allows you to perform the following functions:

- Select a VTR or Video Server and a clip number.
- Grab or enter a timecode (and other device specific data), name the clip, and store it in a clip register. Up to **100** clip registers can be stored (using registers **00** to **99**).
- Cue and preview each clip.
- Modify the inpoint and outpoint of a clip.

### **Programming Clips**

Use the following procedure to program a clip:

- 1. Navigate to the VTR Clips Menus as follows:
  - Press HOME ⇒ More ⇒ Clips ⇒ Assign Clips.
- 2. Press Clip Type on the VTR Clips Menu 1-2.

VTR Clips (1-2) Clip: 00 Clip Name: "V-Vegas2"	44 Back	- Mericana	Copy Up	13 Swap	Clip V-Vegas2(00) V-Vegas7(01) O-A-Home(02)	6.03
Device: Ross SMS (R1) ID: "V-Vegas2" Duration: 00:00:32:16	Start	00:00:00:00		End	Device NONE BNC C01 (01) BNC C02 (02)	0.0.0
				_	Looping Disabled Enabled	0.0
Clip Type & Name Clip	Enter ID	Refresh Choose ID	Inpoint     Outpoint		Cue 🌒 🖓 Mo	ore

Clip Type — VTR Clips Menu 1-2

- 3. Select the Clip Register you want to store a VTR clip to as follows:
  - Use the **Clip** knob on the **VTR Clips Menu 1-2** to select the clip register that you want to store the clip information to (**00** through **99**).
  - Use the **Device** knob on the **VTR Clips Menu 1-2** to select the device you want to store the clip information for. A device is selected by the input BNC that it is assigned to. Select **NONE** to disable a clip and have it not displayed on the **Remote Control Menu**.
  - Use the **Looping** knob on the **VTR Clips Menu 1-2** to select if you want the clip to loop by default. This turns the **Loop** button on the **Remote Control Menu** on or off when the clip is cued.

**Note** — Only VDCP video servers support the looping of clips. If the clip is from a VTR or Betacam video server, you cannot enable looping.

- 4. Name the **Clip Register** as follows:
  - Press **Name Clip** on the **VTR Clips Menu 1-2**. The Clip Name is the name that is shown for the register on all the displays on the switcher.



Clip Name Menu

**Operating Tip** — Refer to the section "Using the Naming Menus" on page Eng 5-16 for more information on using the Clip Name Menu to enter a name for a clip.

- Enter the new name for the clip in the **New Name** field. The name can be no more than **8** characters in length and cannot contain a leading or trailing space.
- Press Accept New Name on the Clip Name Menu to store the new name and display the VTR Clips Menu 1-2.
- 5. Select a clip on the VTR or Video Server as follows:
  - Press Choose ID on the VTR Clips Menu 1-2.

**Operating Tip** — If you know the name of the clip, press **Enter ID** and enter the name of the clip directly from the **Enter Clip ID Menu**. Only clip names up to **31** characters long are supported.





**Note** — If you want to refresh the list of clips returned by the VTR or Video Server, press **Refresh & Choose ID** on the **VTR Clips Menu 1-2** to poll the device for a current list of clips. The total number of clips returned is indicated under the **Showing** heading.

• Use the **×1**, **×10**, or **×100** knobs on the **VTR Clips Menu 1-2** to select the clip on the VTR or Video Server that you want to use. The **ID** and **Duration** of the currently selected clip is shown in the respective fields.

- 6. Modify the Inpoint and Outpoint of the clip as follows:
  - Press Inpoint/Outpoint on the VTR Clips Menu 1-2.

**Note** — If you select different start and end frames to use on-air, the original inpoint and outpoint for the clip will remain unchanged on the device. This allows you to create sub-clips from a longer master clip directory on the switcher.

Inpoint / Outp	point	44 Back	- PP Tormani	A 1990 MR	<b>13</b> (1997)	
Clip: 00 Clip Device: Ross SM	Name: "W-A-Bank" 45 (R2)					
ID: "W-A-Bank" Duration: 00:00:	45:11					
Inpoint: 00:00:0 Outpoint: 00:00	00:00 45:11	In	00:00:45:10		Out	
Enabled Yes/No	Edit In/Out	Hours Minutes	Seconds Frames	Grab Timecode	Cue to Outpoint	

Inpoint/Outpoint Menu

- Toggle **Enable** on the **Inpoint/Outpoint Menu** to enable the Inpoint/Outpoint overrides.
  - No Select this option to use the default inpoint and outpoint of the clip on the VTR or Video Server. If you have made changes to the inpoint of outpoint of the clip, these values are saved, but not applied to clip until you select Yes.
  - Yes Select this option to override the inpoint and outpoint of the clip on the VTR or Video Server. When you select Yes, the Inpoint/Outpoint Menu changes to allow you to modify the start and stop positions of the clip.
- Toggle **Edit** on the **Inpoint/Outpoint Menu** to select either the inpoint or outpoint for editing.
  - > In Select this option to modify the inpoint, or start position, of the clip.
  - > **Out** Select this option to modify the outpoint, or stop position, of the clip.

**Operating Tip** — You can cue the clip to the current Inpoint or Outpoint by pressing **Cue to Inpoint** when **Edit** is set to **In**, or **Cue to Outpoint** when **Edit** is set to **Out**.

Inpoint / Outp	oint	44 Back	• • • • • • • • • •	A count with	93 (mm)		
Clip: 00 Clip Device: Ross SM	Name: "W-A-Bank" IS (R2)						
ID: "W-A-Bank" Duration: 00:00:	45:11	Start	00-00-45-10		End		( 0) fours
Inpoint: 00:00:0 Outpoint: 00:00:	0:00 45:11	In	00.00.00.00		Out		
						м	( 0) inutes
Enabled Yes/No	Edit	Hours	Seconds Frames	Grab Timecode	Cue Outr	to	Alteres

#### Press Hours/Minutes on the Inpoint/Outpoint Menu.

Hours/Minutes — Inpoint/Outpoint Menu



- > Use the **Hours** knob on the **Inpoint/Outpoint Menu** to adjust the value in the hours field of the **Inpoint** or **Outpoint**.
- > Use the **Minutes** knob on the **Inpoint/Outpoint Menu** to adjust the value in the minutes field of the **Inpoint** or **Outpoint**.
- Press Seconds/Frames on the Inpoint/Outpoint Menu.

Inpoint / Outpoin	t	44 Bac	k i Mitomanu i	A COLONNEL	1 <b>93</b> (4) (1)		
Clip: 00 Clip Nam Device: Ross SMS (R	e: "W-A-Bank" 2)						
ID: "W-A-Bank" Duration: 00:00:45:1	i.	Start	00:00:45:10		End	5	(45) Jeconds
Inpoint: 00:00:00:00 Outpoint: 00:00:45:1	1	In			Out		
							(11) Frames
Enabled Yes/No	Edit In/ <b>Out</b>	Hours Minutes	Seconds Frames	Grab Timecode	Cu	e to tpoint	) .

Seconds/Frames — Inpoint/Outpoint Menu

- > Use the Seconds knob on the Inpoint/Outpoint Menu to adjust the value in the seconds field of the Inpoint or Outpoint.
- > Use the **Frames** knob on the **Inpoint/Outpoint Menu** to adjust the value in the frames field of the **Inpoint** or **Outpoint**.

**Operating Tip** — You can preview the timecode location by selecting the VTR or Video Server on the Preset (PST) Bus and pressing **Cue to Timecode** on the **VTR Clips Menu 1-2**.

• Press **Grab Timecode** to use the new **Inpoint** or **Outpoint** value for the clip registers.

This completes the procedure for programming a clip.

#### **Grabbing a Timecode**

If you do not know the timecode for the inpoint or outpoint you want to store, you can manually scan the video using the commands on the **VTR Clips Menu 2-2** and grab the timecode.

Use the following procedure to grab a timecode:

- 1. Navigate to the VTR Clips Menus as follows:
  - Press HOME ⇒ More ⇒ Clips ⇒ Assign Clips.
- 2. Select the clip register and VTR or Video Server you want to store.

**3.** Grab a timecode as follows:

(	44 Back DP Torma		Antonic I
W-A-Bank*			
Start	00:00:45:1	0 End	
	W-A-Bank* Start	W-A-Bank* Start 00:00:45:1	W-A-Bank* Start 00:00:45:10 End

Transport Controls — VTR Clips Menu 2-2

- Cue the VTR or Video Server to the desired clip location using the transport controls: **Rewind**, **Back Frame**, **Pause**, **Play**, **Ahead Frame**, and **Fast Forward**.
- Press **Pause** on the **VTR Clips Menu 2-2** to hold the device at the desired timecode.
- Press **Grab Timecode** on the **VTR Clips Menu 1-2** to grab the current timecode. The new timecode is displayed on the **Timecode** field.

This completes the procedure for grabbing a timecode.

# **Audio Channel Setup**

Audio from a remote mixer can be configured as individual channels or grouped together, with up to three channels per group. When you set up the audio channels, you also set the **Default Levels** for the individual channels. These default levels are the ones that the switcher will set the channels to when you perform an audio reset custom control.

## **Setting Up Audio Sources**

For the some audio mixers, each audio source needs to be assigned to an audio channel that is controlled by the switcher. This allows you to select specific audio sources to be controlled when there are more audio sources than input channels on the Audio Mixer.

Use the following procedure to assign an audio source to an audio channel:

- **1.** Navigate to the **Audio Menu** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ More ⇒ Audio ⇒ Assign Source.

Assign Audio Source	44 Back	₩Tormani	. A convicto	93	Audio Channel: Channel 1
Use this menu to associate audio source to audio channel, and to assign the association to audio mixer.					Audio Source: No Src 1 Src 2
Name     Select     Source		Assign All			

Assign Audio Source Menu

- 2. Assign as audio source to an audio channel as follows:
  - Use the **Audio Channel** knob on the **Assign Audio Source Menu** to select the input audio channel you want to assign an audio source to. The number of channels listed is the number of channels you selected when setting the **Max Channels** extra options for your Audio Mixer.
  - Use the **Audio Source** knob on the **Assign Audio Source Menu** to select the audio source that you want to assign to the selected input audio channel.
- **3.** Name an audio source as follows:
  - Press Name Channel on the Assign Audio Source Menu.



Audio Source Names Menu

**Operating Tip** — Refer to the section "Using the Naming Menus" on page Eng 5-16 for more information on using the Audio Source Names Menu to enter a name for the audio group.

- Use the **Audio Src** knob on the **Audio Source Names Menu** to select the audio source you want to name.
- Enter the new name you want to use in the **New Name** field. The name can be no longer than eight characters.
- Press **Accept New Name** on the **Audio Source Names Menu** to assign the name to the audio source.
- **4.** Press **Assign All** on the **Assign Audio Source Menu** to send the audio input channel to audio source assignments to the Audio Mixer.
- 5. Press HOME to display the Installation Change Confirmation Screen.
- 6. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for assigning an audio source to an audio channel.

## **Setting Up Audio Channels**

Each audio channel can be set with a custom audio level that is used when the channel is taken on-air. This level can be adjusted manually using the sliders on the Audio Mixer, or by selecting the level on the menu. The default audio level for each channel is **75%**.

Use the following procedure to set up the default audio levels for a channel:

- 1. Navigate to the Audio Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ More ⇒ Audio.
- 2. Press Audio Level on the Audio Menu.



Audio Level — Audio Menu

- **3.** Include audio channels from the control of the switcher as follows:
  - Use the **Audio Channel** knob on the **Audio Menu** to select the audio channel that you want to remove from the control of the switcher. All channels are included by default.

**Note** — If you have programmed **Audio Assign Custom Controls**, the **Audio Channel** knob on the **Audio Menu** will display the custom control that you assigned the channel to.

- Use the **Include** knob on the **Audio Menu** to select **Yes**, to include the channel, or **No**, to not include the channel. If the channel is not included, the switcher will not control the audio levels for that channel.
- 4. Set the level for each audio channel as follows:
  - Use the **Audio Channel** knob on the **Audio Menu** to select the audio channel that you want to set the default level for.
  - Use the **Level** knob on the **Audio Menu** to select the default level for the selected channel. All channels are initially set at **75%**.
- 5. Press HOME to display the Installation Change Confirmation Screen.
- 6. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for setting up the default audio levels for audio channels.

## **Setting Up Audio Groups**

Up to three audio channels, or groups, can be grouped together. This allows you to assign multiple audio channels to a single Input BNC. Assigning audio channels will not change the default audio levels that have been set for each of the channels. When the group is taken on-air, each audio channel is taken up to the level set for that particular channel.



**Note** — Assigning audio channels to groups does not alter the default or custom levels that you have set for them.

Use the following procedure to assign audio channels to groups:

- 1. Navigate to the Audio Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ More ⇒ Audio.
- 2. Press Audio Groups on the Audio Menu.

Audio Use this menu to assign audio channels to groups.	44 Back	) Miromann (		<b>13</b> (map)	Audio Channel 1: NONE Channel 1 Channel 2 Audio Channel 2: NONE Channel 1 Channel 2
					Audio Channel 3: NONE Channel 1 Channel 2
Group 1 Group 2	Group 3	Group 4	Group 5	Gro	op 6

Audio Groups — Audio Menu

- **3.** Press **Group 1** to assign audio channels to that group. There are a total of **6** audio groups that you can assign audio channels to.
- 4. Assign up to **3** audio channels to the selected group as follows:

**Note** — If you have programmed **Audio Assign Custom Controls**, the **Audio Channel** knobs on the **Audio Menu** will display the custom control that you assigned the channel to.

- Use the **Audio Channel 1** knob on the **Audio Menu** to select the first audio channel that you want to assign to the group.
- Use the **Audio Channel 2** knob on the **Audio Menu** to select the second audio channel that you want to assign to the group.
- Use the **Audio Channel 3** knob on the **Audio Menu** to select the third audio channel that you want to assign to the group.
- 5. Press HOME to display the Installation Change Confirmation Screen.
- 6. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for setting up the default audio levels for audio channels.

#### **Setting Audio Fade Rate**

Each audio channel can be set to use either the video transition rate, or a unique fade-in and fade-out rate when the audio channel is transitioned on, or off, air.

Use the following procedure to set the audio fade rate for an audio channel:

- 1. Navigate to the Audio Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ More ⇒ Audio.
- 2. Toggle Fade Rate on the Audio Menu to Audio.

Audio Use this met default audio and fade-out r Use a knob t rate or use F Video/Audio select video ra	nu to set fade-in rate: to set fade ade Rate button to te	44 Back	He Tormand (	9.007.00	93	Audio Channel: Channel 1 Channel 2 Channel 3 Fade-in Rate: Image: (12) Frames Fade-out Rate: Image: (12) Frames
Audio Level	Audio     Groups	Assign Source	Fade Rate Video/Audio			

Audio Fade Rate — Audio Menu

- **3.** Use the **Audio Channel** knob on the **Audio Menu** to select the audio channel that you want to set the audio fade rate for.
- 4. Use the **Fade-in Rate** knob on the **Audio Menu** to set the audio fade-in fate, in frames, for the selected audio channel.
- 5. Use the **Fade-out Rate** knob on the **Audio Menu** to set the audio fade-in fate, in frames, for the selected audio channel.

**Operating Tip** — Toggle **Fade Rate** to **Video** to set the selected channel back to the video transition rate.

- 6. Press HOME to display the Installation Change Confirmation Screen.
- 7. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for setting the audio fade rate for an audio channel.
# **Factory Default Settings**

Each Vision switcher comes pre-configured from the factory with a number of default settings. Recalling these default settings allows you to return the switcher to a known state for diagnostic purposes, creating new Setups, or if advised to do so by Ross Technical support. The following are some of the situations where you may want to perform a recall of the factory default settings:

- If you sense a problem with one of the registers.
- If you need to create a new switcher Setup and want to start from the default state.
- If you need to delete all entries in a particular register. For example, if you needed to delete all memories on the switcher.
- If you need to reset all control panel values.

The recalling of factory default setting is performed on individual register types. Defaulting one of these register types will return all the entries stored in registers of that type to the factory installed state. Any entries in the registers are destroyed.

**Note** — If the Installation is locked, you cannot recall the factory default settings for Installation, but all other registers will recall normally.

## **Recalling Factory Default Settings**

When you perform a recall of the factory default settings, each register must be recalled individually. This allows you to recall the factory default setting for only those registers that need to be defaulted. Factory default settings only apply to the active Setup on the switcher. Additional Setups that are stored on the switcher are not affected.



**Important** — You should back up any of your registers that you want to keep to a Setup before performing the recall of the factory default setting. Refer to the section "**Storing and Recalling Files and Setups**" on page Eng 13-4 for more information on storing registers to switcher Setups.

Use the following procedure to recall the factory default settings of your switcher:

- 1. Navigate to the Recall Factory Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ More ⇒ More ⇒ Recall Factory.

Recall Facto	ry (1-3)	44 Back	- Witemani	A COLOR	113	
This menu switcher ti	lets you reset diffe o their factory defau	rent parts of the ilt settings.				
Personality	Memories	Switcher	Installation	Custom Controls	VTR Clips	More More

Recall Factory Menu 1-3

- **2.** Recall a factory default setting by pressing the corresponding button for the register you want to default. You are prompted to confirm the factory default. The following registers can be factory defaulted:
  - **Personality** The personality registers contain all the user interface settings. These registers contain items such as mnemonic settings, preview overlay positions and settings, and transition rates. As a rule, anything that is set up from the **Personality Menus** is stored in these registers. If you recall the factory default setting for the personality registers, all these settings are returned to the default state.
  - **Memories** The memory registers contain all the memories that are stored on the switcher. If you recall the factory default settings for the memory registers, all the memories that have been stored on the switcher are erased.
  - **Switcher** The switcher registers contain information on the configuration of the control panel. If you recall the factory default settings for the switcher registers, all keyer settings and MLE settings are reset.
  - **Installation** The installation registers contain all the external device setup, and software configuration settings for the switcher. As a rule, anything that is set up from the **Installation Menus** is stored in these registers. If you recall the factory default settings for the installation registers, all the external devices you have set up and software configurations you have made are erased. In a multipanel configuration, the master panel is assigned all installed MLEs, with the highest numbered MLE as the Program MLE. For satellite panels, only the lowest number MLE installed is assigned to the panel and set as the Program MLE.
  - **Custom Controls** The custom control registers contain all the custom controls that have been stored on the switcher. If you recall the factory default setting for the custom control registers, all the custom controls that have been recorded on the switcher are erased. Custom control banks are stored in the Installation Registers.
  - **Default VTR Clips** The clip registers contain all the VTR and video server timecode and clip information stored on the switcher. If you recall the factory default settings for the clip registers, all clip information are erased. This will not affect the clip information on the external device.
  - **Default NV-RAM** The Non-Volatile RAM on the Vision switcher contains information such as active key effects and some personality settings. If you recall the factory default setting for the NV-RAM, all the information stored in the NV-RAM is erased.
  - **Default S&T** The Squeeze & Tease registers contain all the Squeeze & Tease sequences that have been stored on the switcher. If you recall the factory default settings for the Squeeze & Tease registers, all the sequences that have been recorded on the switcher are erased.
  - **Default Bus Maps** The Bus Maps registers contain all the user defined bus maps that have been stored on the switcher. If you recall the factory default settings for the Bus Map registers, all the custom bus mappings that have been created on the switcher are erased.
  - **Default Shot Box Pages** The Shot Box Pages registers contain all the user defined Shot Box Pages that have been stored on the switcher. If you recall the factory default settings for the Shot Box Pages registers, all the Shot Box Pages that have been created on the switcher are erased.
  - **Camera File** The Camera File registers contain all the camera shots that have been stored on the switcher. If you recall the factory default settings for the Camera File registers, all the camera shots that have been stored on the switcher are erased.
  - **CC/Macro Attachments** The Custom Control Attachments registers contain all the attachments of custom controls to control panel buttons. If you recall the factory default settings for the CC/Macro Attachments registers, all the assignments

of custom controls to control panel buttons are erased. The custom control that are attached to buttons are not defaulted.

- **Default Multi-Viewer** The default Multi-Viewer option defaults both the Multi-Viewer Assignment registers and the Multi-Viewer Layout registers. If you recall the factory default settings for the Multi-Viewer, the mapping of layouts to Multi-Viewers, as well as the actual layouts and sources assigned to the boxes in the layout are defaulted.
- 3. Press HOME to display the Installation Change Confirmation Screen.
- **4.** Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for recalling the factory default settings for the switcher.

# **Preview Overlay Setup**

The Preview Overlay allows you to view information such as Source ID, Safe Title area, and Time Clock on the preview monitor of your Vision switcher. With the exception of the **Preview Overlay Module** on the **Vision 1** control panel (**Figure 12.2**), all of these features can be turned on or off by pressing the associated button on the **Preview Overlay Module** (**Figure 12.3**).

The Preview Overlay is only available to the highest number MLE. If your control panel does not have that MLE assigned to it, the Preview Overlay is not available.



**Note** — If Global-Store channel 4 is enabled, the Preview Overlay feature is not available. Refer to the section "**Personality List**" on page Eng 11-2 for more information on Global-Store 4 Mode.



Figure 12.2 Vision 1 Preview Overlay Module



Figure 12.3 Vision Preview Overlay Module for all other switchers



**Operating Tip** — On the **Vision 1**, the **Preview Overlay** functions can be turned off and on from the **Preview Overlay Menus**.

# **Preview Overlay Font Color**

You can adjust the color of the font used for various elements of the preview overlay. Color selections are applied to the fonts, and not to the safe title or other graphical elements.

Use the following procedure to set the color of the fonts used for preview overlay elements:

- 1. Navigate to the Preview Overlay Font Color Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Personality ⇒ Preview Font Colors.



Preview Overlay Font Color Menu

- **2.** Use the **Font** knob on the **Preview Overlay Font Color Menu** to select the preview overlay element that you want to change the font color for. You can choose between the following:
  - **Time Up** Select this option to set the color of the **Time Clock** text when the time clock is counting up.
  - **Time Down** Select this option to set the color of the **Time Clock** text when the time clock is counting down.
  - VTR On Air Select this option to set the color of the VTR Timecode text when a VTR is contributing to the Program output.
  - **VTR Active** Select this option to set the color of the **VTR Timecode** text when a VTR is selected on the Preset bus of the Program MLE.
  - **VTR Inactive** Select this option to set the color of the **VTR Timecode** text when a VTR is not selected.
  - **Source ID** Select this option to set the color of the program video on the **Source ID** text.
  - **Tran ID** Select this option to set the color of the transition type on the **Source ID** text.
  - **Dest ID** Select this option to set the color of the preset video on the **Source ID** text.
- **3.** Use the **Color** knob on the **Preview Overlay Menu** to select the color that you want to apply to the text of the selected preview overlay element.

This completes the procedure for setting the color of the fonts used for preview overlay elements.

### **Preview Overlay Component Setup**

From the **Preview Overlay Menus**, you can adjust the color, size, and appearance of many of the components used in the Preview Overlay.

Use the following procedure to navigate to the **Preview Overlay Menu**:

- 1. Navigate to the **Preview Overlay Menu** as follows:
  - Press HOME ⇒ Preview Overlay.



Preview Overlay Menu

- 2. Use the following sections to set up the Preview Overlay element you want to use:
  - VTR Timecode
  - Source ID
  - Safe Title

- Center
- Time Clock

This completes the procedure for navigating to the **Preview Menu**.

#### For More Information...

• on using the preview overlay, including the preview mask, refer to the section "**Preview Overlay**" on page Ops 4-16.

### **VTR Timecode**

The VTR Timecode element shows the current timecode, or remaining time, of the VTR or Video Server currently selected on the **Program/Preset MLE**.

Use the following procedure to set up the VTR Timecode from the Preview Overlay Menus:

1. Press VTR on the Preview Overlay Menu.

TR Position	44 Back	)   Mitoraard	Copy Up	133 Swap	⇔ <sup>(3,3%)</sup> ×
					3 (82,3%) Y
					() 50) Size
Done					-

VTR Position Menu

- **2.** Adjust the **VTR TC** element as follows:
  - Use the **X** knob, or the positioner, on the **VTR Position Menu** to select the horizontal position on the Preview Overlay that the VTR Timecode text appears.
  - Use the **Y** knob, or the positioner, on the **VTR Position Menu** to select the vertical position on the Preview Overlay that the VTR Timecode text appears.
  - Use the **Size** knob, or the positioner, on the **VTR Position Menu** to select the size (**20** to **350**) of the VTR Timecode text on the Preview Overlay.
- **3.** Press **Done** on the **VTR Position Menu** to save the current settings and display the **Preview Overlay Menu**.

This completes the procedure for setting up the VTR Timecode.

### Source ID

The Source ID element shows the name of the current on-air video signal, the transition type that is currently selected, and the video signal that is taken on-air with the next transition.

Use the following procedure to set up the Source ID from the Preview Overlay Menus:

1. Press Source ID on the Preview Overlay Menu.

Source ID Position	44 Back	) Witerward (	Copy Up	13 Swap	⇔ <sup>(51,5%)</sup> X
					\$ (82.3%) Y
					( 50) Size
Done					

Source ID Position Menu

- 2. Adjust the Source ID element as follows:
  - Use the **X** knob, or the positioner, on the **Source ID Position Menu** to select the horizontal position on the preview overlay that the Source ID text appears.
  - Use the **Y** knob, or the positioner, on the **Source ID Position Menu** to select the vertical position on the preview overlay that the Source ID text appears.
  - Use the **Size** knob, or the positioner, on the **Source ID Position Menu** to select the size (**20** to **350**) of the Source ID text on the preview overlay.
- **3.** Press **Done** on the **Source ID Position Menu** to save the current settings and display the **Preview Overlay Menus**.

This completes the procedure for setting up the Source ID.

#### Safe Title

The Safe Title element shows guides for **Safe Title**, **Safe Action** and **Minimum Text Size** (**Figure 12.4**) using the SMPTE standards. A number of pre-defined Safe ID setups are stored on the switcher. The size and position of the elements for these Safe ID setups can be adjusted and stored.



Figure 12.4 Safe Title Preview Overlay elements

Use the following procedure to set up the Safe Title from the Preview Overlay Menus:

1. Press Safe Title Center Pos on the Preview Overlay Menu.

Safe Title Setup	44 Back	• De Coresant (	🔮 Сору Up	13 Swap	\$	( 50.0%) X
	+	]			3 Safe ID Safe 2	( 50.0%) Y
					Safe 3 Safe 4	
Center Top / Left	Bottom / Right		Modify Name	Re	eset	

Safe Title Setup Menu

- **2.** Use the **Safe ID** knob on the **Safe Title Setup Menu** to select the Safe ID that you want to adjust the values for.
- **3.** Adjust the position of the **Top** and **Left** sides of the **Safe Title** and **Safe Action** elements as follow:
  - Press Top/Left on the Safe Title Setup Menu.
  - Use the **Left** knob, or the Positioner, on the **Safe Title Setup Menu** to adjust the horizontal position of the left side of the Safe Title and Safe Action elements.
  - Use the **Top** knob, or the Positioner, on the **Safe Title Setup Menu** to adjust the vertical position of the top side of the Safe Title and Safe Action elements.
- **4.** Adjust the position of the **Bottom** and **Right** sides of the **Safe Title** and **Safe Action** element as follow:
  - Press Bottom/Right on the Safe Title Setup Menu.
  - Use the **Right** knob, or the Positioner, on the **Safe Title Setup Menu** to adjust the horizontal position of the right side of the Safe Title and Safe Action elements.
  - Use the **Bottom** knob, or the Positioner, on the **Safe Title Setup Menu** to adjust the vertical position of the bottom side of the Safe Title and Safe Action elements.
- **5.** Name the **Safe ID** as follows:

**Operating Tip** — Refer to the section "Using the Naming Menus" on page Eng 5-16 for more information on using the Change Safe Title Name Menu to enter a name.

- Press Modify Name on the Safe Title Setup Menu.
- Use the **Safe Title** knob on the **Change Safe Title Name Menu** to select the Safe ID you want to name.

Change Safe Title Name	44 Back	M Tormers	- 4 64900 (49)	13 Swap	
1 0 <b>* \$</b> 1 2 3 4 5 6	& * 7 8		: *	Backspace	
Q W E R T Y	U	1 0 P			
Caps Lock A 5 D F	G H	J K	L	, DEL	
Shift Z X C V	BN	M <	] ] ]		(1)
🥥 🐳 😽	pace	iew Name (MAX 8 Safe 1	Characters):		Safe Title
Clear			Default	Accept	and ale

Safe Title Setup Menu

- Enter the new name you want to use in the New Name field.
- Press Accept New Name on the Change Safe Title Name Menu to assign the name to the Safe ID.

This completes the procedure for setting up the Safe Title.

#### Center

The Center element shows a crosshairs on the Preview Overlay to indicate the center of the picture. The position of the crosshairs can be adjusted and stored.

Use the following procedure to set up the Center from the Preview Overlay Menus:

1. Press Safe Title Center Pos on the Preview Overlay Menu.

Safe Title Setup	44 Back	VP Constant	py Up	p ⇔ (50.0%) X
	+			3 (50,0%) Y
				Safe 1D Safe 2 (A) Safe 3 (C) Safe 4 (V)
Center Top / Left	Bottom / Right	0	Modify Name	Reset

Safe Title Setup Menu

- 2. Use the **Safe ID** knob on the **Safe Title Setup Menu** to select the Safe ID that you want to adjust the values for.
- **3.** Adjust the position of the **Center** element as follows:
  - Press Center on the Safe Title Setup Menu.
  - Use the X knob, or the positioner, on the **Safe Title Setup Menu** to adjust the horizontal position of the Center element.
  - Use the **Y** knob, or the positioner, on the **Safe Title Setup Menu** to adjust the vertical position of the Center element.

This completes the procedure for setting up the Center.

### **Time Clock**

The Time Clock element shows a count-down, count-up, or count-down-then-up timer on the Preview Overlay. The Time Clock can be set up to start counting down, or up, on every transition, from a preset start time. This can be tied to any MLE, or a particular MLE, or Fade to Black transition.

Use the following procedure to set up the Time Clock from the Preview Overlay Menus:

1. Press **Time Clock** on the **Preview Overlay Menu**.

Time Clock Setup	44 Back	)   ₩Tormard	Copy Up	93 Swap	
Stop/Start Reset	Direction	Transition	Position		Alteres

Time Clock Menu

- 2. Adjust the **Position** of the **Time Clock** element as follows:
  - Press Position on the Time Clock Menu.
  - Use the **X** knob, or the positioner, on the **Time Clock Position Menu** to select the horizontal position on the Preview Overlay that the Time Clock appears.
  - Use the **Y** knob, or the positioner, on the **Time Clock Position Menu** to select the vertical position on the Preview Overlay that the Time Clock appears.
  - Use the **Size** knob, or the positioner, on the **Time Clock Position Menu** to select the size (**20** to **350**) of the Time Clock on the Preview Overlay.
  - Press **Done** on the **Time Clock Position Menu** to save the current settings and display the **Time Clock Menu**.
- **3.** Select the MLEs that the **Time Clock** will activate on when a transition is performed as follows:
  - Press Transition on the Time Clock Menu.

ransition (1	-2)	44 Back	• • Tomani	Copy Up	33 Swap	

Preview Trans Menu

Toggle **Master** on the **Transition Menu 1-2** to **On** to allow the Time Clock to be tied to an MLE.



**Note** — You must have **Master** set to **On** in order to be able to tie the operation of the Time Clock to an MLE or Fade to Black transition.

- Toggle MLE X on the Transition Menus to On to tie the operation of the Time Clock to the selected MLE, where "X" represents the MLE number. Turning this feature Off will not have the Time Clock reset when a transition is performed in this MLE.
- Toggle **FTB** on the **Transition Menu 1-2** to **On** to tie the operation of the **Time Clock** to a **Fade to Black** transition. Turning this feature **Off** will not have the Time Clock reset when a Fade to Black transition is performed.
- **4.** Set up the direction that the **Time Clock** will count as follows:
  - Press Direction on the Time Clock Menu.
  - Use the **Going** knob on the **Time Clock Menu** to select the direction you want the Time Clock to count in. You can choose between the following:
    - > **Up** Select this option to have the Time Clock count up from zero when reset and started.
    - > **Down** Select this option to have the Time Clock count down to zero when reset and started. The starting time is set from the **Reset Time Menu**.
    - > **Down->Up** Select this option to have the Time Clock count to zero, and then count up from zero when reset and started. The starting time is set from the **Reset Time Menu**.
- 5. Set up the **Reset Time**, or starting time, for the **Time Clock** as follows:
  - Press **Reset Time** on the **Time Clock Menu**.
  - Use the **Hours** knob on the **Time Clock Menu** to set the number of hours you want the Time Clock to count down from.
  - Use the **Minutes** knob on the **Time Clock Menu** to set the number of minutes you want the Time Clock to count down from.
  - Use the **Seconds** knob on the **Time Clock Menu** to set the number of seconds you want the Time Clock to count down from.

This completes the procedure for setting up the Time Clock.

#### For More Information...

- on using the preview overlay, refer to the section "Video Preview" on page Ops 4-14.
- on using time clock custom controls, refer to the section "**Programming Special Functions**" on page Eng 10-15.

# Set System Time

The System Time allows you to set the current date and time on the hardware clocks on both the frame and the Vision control panel.

The System Time can be set manually from the Master Panel, or automatically from a Network Time Protocol (NTP) server. The **Set System Time Menu** is not available to the Satellite Panels.

### **Setting System Time Manually**

The **Set System Time Menu** allows you to manually set the system time for the switcher when a NTP server is not available. If an NTP server is set up, the current date and time entered into the **Set System Time Menu** is overwritten the next time the NTP time is updated.

Use the following procedure to set the system time manually:

- 1. Navigate to the Set System Time Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ More ⇒ Set System Time.

Set System Time	44 Back	) i Mitoraani	<b>3</b> (1997) (1971)	98.000	(2010) Year
Mon jan 18 11:04:38 2010					
					(1) Month
					(18) Day
Date Time				Se	t Mitter

Set System Time Menu

**Note** — If there are **NTP Servers** listed on the **Set System Time Menu**, the switcher is getting system time information from the listed NTP Servers. You cannot set the time manually when an NTP Server is active.

- **2.** Set the current date as follows:
  - Press Date on the Set System Time Menu.
  - Use the Year knob on the Set System Time Menu to select the current year.
  - Use the Month knob on the Set System Time Menu to select the current month.
  - Use the Day knob on the Set System Time Menu to select the current day.
- **3.** Set the current time as follows:
  - Press Time on the Set System Time Menu.
  - Use the Hour knob on the Set System Time Menu to select the current hour.
  - Use the **Minute** knob on the **Set System Time Menu** to select the current minute.
  - Use the Second knob on the Set System Time Menu to select the current second.
- **4.** Press **Set** on the **Set System Time Menu** to set the hardware clock on the Vision control panel and frame to the selected date and time.

This completes the procedure for setting the system time manually.

## **Setting System Time Automatically**

The system time can be set automatically by entering the IP address of up to three (3) Network Time Protocol (NTP) servers. The switcher must be able to access the IP addresses to get the time from an NTP server.

Use the following procedure to set the system time automatically using an NTP server:

- On your computer, open your Web Browser and, in the address bar, enter the IP address of your frame and press Enter. The QMD/X Web Interface Splash Screen is displayed.
- 2. Enter your username and password as follows when the Login Dialog Box appears. The default Name is user and Password is password.
- 3. Click **Other** ⇒ **Time** to display the **Time Page**. All NTP servers that have been set up on the switcher are listed.

ONDAX		
Systeminto Upgrade File 5	es Oter	
Time		
This page allows the Frame's time serv	er configuration to be modified	
	NTP Time Server	
	IP Address	Status Action
	1000-00	Burnet Canana
	1	
It may take five to ten minutes for the t again to update the server status	rame to sync after adding or deleting a server, or restarting	g the frame. Reload this page by selecting $\mbox{Other} \Rightarrow \mbox{Time}$ from the menutur
Copyright 1995-2010 Roes Video Limit	ed. All rights reserved.	

Time Page

**4.** In the blank **Time Servers** field, enter the IP Address of the NTP server you want to add. IP addresses in the range of **169.254**.*x*.*x* are reserved by the switcher and cannot be used as a time server address.



**Operating Tip** — To remove an NTP server from the list, click **DELETE** next to the time server you want to remove.

**5.** Click **ADD**. You are asked to confirm the addition of the time server once it is validated, click **OK** to add the server.

This completes the procedure for setting the system time automatically using an NTP server. Once the switcher is synchronized to the new NTP server, **Okay** appears in the **Status** column. If **Okay** is not shown next the IP address, check that the IP address is correct, or that the switcher has access to the address.

# **Auto Follow**

The Auto Follow feature allows you to set one part, or many parts, of an MLE or Aux Bus to follow the operation of another part (**Table 12.2**). For example, you can have one Transition Module follow another, a Keyer bus follow another Keyer bus, or have an entire MLE or Aux Bus follow another. Both parts of the auto follow must be of the same type, a crosspoint bus can only follow another crosspoint bus.

Operations, such as crosspoint selection or transitions, that are performed on part are repeated on the other part.

Module	Action			
Memory	Memory Recall			
ivicinor y	Reset MLE (Store+Recall)			
Keyers	Cut and Auto Transition			
	Next Transition Selection			
	Transition Type			
	Cut, Auto, Fader Transitions			
Transition	Preset Black			
manshion	Key Priority			
	Transition Limit			
	Roll Clip			
	Transition PV			
Crosspoint	Source Selection			

 Table 12.2 Supported Auto Follow Actions

Auto follow actions only echo commands, and do not echo the state. For example, if a transition is performed on an MLE, the auto follow MLE also performs a transition, regardless of what is currently on-air on that MLE. If Key 1 is on-air on MLE 1 but off-air on MLE 2, the transition takes Key 1 off-air on MLE 1, but on-air on MLE 2.

The same is true for memory recalls. If a memory register contains different setting on each MLE, the local settings will be used. Auto Recall for memories only ensures that the same memory register is recalled on the **Echo To** MLE. For example, if memory register 09 is recalled on the **Echo From** MLE, memory register 09 is also recalled on the **Echo To** MLE. These two memory registers may contain different commands.

### **Turning On Auto Follow**

The Auto Follow feature can be independently turned off and on from the **Personality Menu** for control panel functions, custom controls, and editor commands.



**Operating Tip** — When an Auto Follow is turned on, the word **Active** appears on the **Main Menu 1-2** next to the **Auto Follow** under the **Remote Enables**. Use the following procedure to turn on Auto Follows:

- **1.** Navigate to the **Personality Menus** as follows:
  - Press HOME ⇒ Setup ⇒ Personality.
- 2. Use the Option knob on the Personality Menu to select Autofolw Panel.

Personality (1-2) Autofollow Panel Off	44 Back This op follows operate	tion enables auto from panel ons.	(the Copy Up)	tt Swap	Option Autofolw Panel
3D Pattern     Bttn Assign     Mnemonics	Assign Bus Maps	Color     Scheme	🚯 MLE Map	s Prev	view Font

Auto Follow Panel — Personality Menu

- 3. Use the Value knob on the Personality Menu to toggle to Off or On.
  - **Off** Select this option to have the switcher not perform any command echoing for control panel button presses.
  - **On** Select this option to have the switcher perform command echoing for control panel button presses. This includes memory recalls, transitions, and crosspoint button selection. Custom control or editor based commands are not included.
- 4. Use the Option knob on the Personality Menu to select AutofolwCustctrl.

Personality (1-2	2)	44 Back	] i 🍽 Termenti	Copy Up	33 Swap	Option:
Autofoliow Custctrl	Off	This op follows control	ition enables aut from custom macros.	a		value: off on
3D Pattern     Bttn Assign	Standard Mnemonics	Assign Bus Maps	Color     Scheme	MLE Maps	Prev Cold	view Font More

Auto Follow Custom Control — Personality Menu

- 5. Use the Value knob on the Personality Menu to toggle to Off or On.
  - **Off** Select this option to have the switcher not perform any command echoing for active custom controls.
  - **On** Select this option to have the switcher perform command echoing for the active custom control. Any commands recorded in the custom control for an MLE, bus, or Transition Module, will be echoed on the auto follow.
- 6. Use the Option knob on the Personality Menu to select Autofolw Editor.

Personality (1-2)		44 Back	Option				
Autofoliow Editor	off	This op follows device	Value:				
Auto Annual Mag Audo Cut Doly Name 7 (ut Doly Disease 7 (ut Doly Disea	1111111					Un	6
3D Pattern     Bttn Assign	Standard Mnemonics	♣ Assign Bus Maps	Color     Scheme	MLE Map	S Prev Cok	view Font	More

Auto Follow Editor — Personality Menu

- 7. Use the Value knob on the Personality Menu to toggle to Off or On.
  - **Off** Select this option to have the switcher not perform any command echoing for external editor commands.
  - **On** Select this option to have the switcher perform command echoing for external editor commands.

This completes the procedure for turning on Auto Follows. Next, you must set up which MLEs, Transition Modules, buses, or keyers, or memory recalls will follow each other.

### **Auto Follow Setup**

The Auto Follow feature must be turned on from the Personality Menu. Once turned on, you can specify the buses, keyers, transitions, and memory recalls that follow.

An auto follow can be set up for an entire MLE at once, or for the individual elements of an MLE.

Use the following procedure to set up Auto Follow:

- 1. Navigate to the Auto Follow Setup Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Personality ⇒ More ⇒ Auto Follow Setup.

**Operating Tip** — The currently active Auto Follows are listed on the **Auto Follow Setup Menu 2-2**. Press **Buses** to view the bus follows, **Keyers** to view the keyer follows, **Transitions** to view transition follows, and **Mem Recalls** to view memory recall follows.

- 2. Set up an auto follow for an entire MLE at once as follows:
  - Press MLEs on the Auto Follow Setup Menu 1-2.



MLEs — Auto Follow Setup Menu 1-2

- Use the **Echo From** knob on the **Auto Follow Setup Menu 1-2** to select the MLE that you want to be followed. This is the MLE that you perform the actions on that you want to be repeated on the **Echo To** MLE.
- Use the Echo To knob on the Auto Follow Setup Menu 1-2 to select the MLE that you want to follow the select MLE. This is the MLE that repeats the actions performed on the Echo From MLE.
- Press Set on the Auto Follow Setup Menu 1-2 to apply changes.

**Operating Tip** — You can clear the currently selected MLE auto follow by pressing **Clear** on the **Auto Follow Setup Menu 1-2**.

- 3. Press More.
- **4.** Set up a Bus auto follow as follows:
  - Press Buses on the Auto Follow Setup Menu 2-2.



Buses — Auto Follow Setup Menu 2-2

- Use the **Echo From** knob on the **Auto Follow Setup Menu 2-2** to select the bus that you want to be followed. You can choose between the following:
  - > **AuxBus Y** Select this option to assign an Aux Bus as the bus that you want followed, where "**Y**" represents the number of the Aux Bus.
  - MLE X PGM Select this option to have the Program Bus of an MLE as the bus that you want followed, where "X" represents the number of the MLE.
  - > MLE X PST Select this option to have the Preset Bus of an MLE as the bus that you want followed, where "X" represents the number of the MLE.
  - MLE X Key #V Select this option to have the Key Video Bus of an MLE as the bus that you want followed, where "X" represents the number of the MLE and "#" represents the number of the Keyer.



- > MLE X Key #A Select this option to have the Key Alpha Bus of an MLE as the bus that you want followed, where "X" represents the number of the MLE and "#" represents the number of the Keyer.
- > **MLE X Util 1** Select this option to have Utility Bus 1 of an MLE as the bus that you want followed, where "**X**" represents the number of the MLE.
- > MLE X Util 2 Select this option to have Utility Bus 2 of an MLE as the bus that you want followed, where "X" represents the number of the MLE.
- Use the **Echo To** knob on the **Auto Follow Setup Menu 2-2** to select the bus that you want to follow the **Echo From** bus.
- Press Set Bus Follow on the Auto Follow Setup Menu 2-2 to apply changes.



**Operating Tip** — You can clear the currently selected Bus auto follow by pressing **Clear Bus Follow** on the **Auto Follow Setup Menu 2-2**, or you can clear all the Bus auto follows by pressing **Clear All Bus Follows** on the **Auto Follow Setup Menu 2-2**.

- **5.** Set up a Keyer auto follow as follows:
  - Press Keyer on the Auto Follow Setup Menu 2-2.

Auto Follow Setu Active Keyer Follows	ıp (2-2)	44 Back	- Milanara (	Copy Up	13 Swap	Echo From: MLE 1 Key 1
Echo From	Echo To					MLE 1 Key 3
Buses	Keyers	Transitions	Mem Recalls	Set Keyer Follow	Clear / Keyer	All Follows

Keyers — Auto Follow Setup Menu 2-2

- Use the **Echo From** knob on the **Auto Follow Setup Menu 1-2** to select the keyer that you want to be followed.
- Use the **Echo To** knob on the **Auto Follow Setup Menu 1-2** to select the keyer that you want to follow the **Echo From** keyer.
- Press Set Keyer Follow on the Auto Follow Setup Menu 2-2 to apply changes.



**Operating Tip** — You can clear the currently selected Bus auto follow by pressing **Clear Keyer Follow** on the **Auto Follow Setup Menu 2-2**, or you can clear all the Keyer auto follows by pressing **Clear All Keyer Follows** on the **Auto Follow Setup Menu 2-2**.

- 6. Set up a Transition auto follow as follows:
  - Press Transitions on the Auto Follow Setup Menu 2-2.

uto Follow Setup (2-2) Active Transition Follows:		44 Back	)   🕪 Carmeral (	Copy Up	13 Swap	Echo From: MLE 1 MLE 2	00
Echo From	Echo To					MLE 3 Echo To: MLE 1 MLE 2	

Transitions — Auto Follow Setup Menu 2-2

- Use the **Echo From** knob on the **Auto Follow Setup Menu 1-2** to select the Transition Module that you want to be followed.
- Use the **Echo To** knob on the **Auto Follow Setup Menu 1-2** to select the Transition Module that you want to follow the **Echo From** Transition Module.
- Press Set Trans Follow on the Auto Follow Setup Menu 2-2 to apply changes.

**Operating Tip** — You can clear the currently selected Transition auto follow by pressing **Clear Trans Follow** on the **Auto Follow Setup Menu 2-2**, or you can clear all the Transition auto follows by pressing **Clear All Trans Follows** on the **Auto Follow Setup Menu 2-2**.

- 7. Set up a Memory Recall auto follow as follows:
  - Press Mem Recalls on the Auto Follow Setup Menu 2-2.

Auto Follow Setu Active Mem Recall Fo	tto Follow Setup (2-2) tive Mem Recall Follows:		ow Setup (2-2) 44 Back W Torreson 3		Copy Up	Echo From: MLE 1 MLE 2	00
Echo From	Echo To				]	MLE 3	۲
						Echo To: MLE 1 MLE 2 MLE 3	10 s
Buses	Keyers	Transitions	Mem Recalls	Set Mem Follow	Clear Mem	All Follows	re

Memory Recalls — Auto Follow Setup Menu 2-2

- Use the **Echo From** knob on the **Auto Follow Setup Menu 1-2** to select the MLE that you want memory recalls to be followed from. Memory registers that are recalled on this MLE are also recalled on the Echo To MLE.
- Use the **Echo To** knob on the **Auto Follow Setup Menu 1-2** to select the MLE that you want to follow the **Echo From** MLE.
- Press Set Mem Follow on the Auto Follow Setup Menu 2-2 to apply changes.

 $\checkmark$ 

**Operating Tip** — You can clear the currently selected Memory auto follow by pressing **Clear All Mem Follows** on the **Auto Follow Setup Menu 2-2**, or you can clear all the Memory auto follows by pressing **Clear All Mem Follows** on the **Auto Follow Setup Menu 2-2**.

This completes the procedure for setting up Auto Follow.



# Lock/Unlock Installation

The Lock/Unlock Installation feature allows you to lock-out changes to the **Installation Menus** on the switcher with a password. This prevents anyone from changing settings on the **Installation Menus** without first unlocking the installation settings. This also included the recalling of an installation register. Other registers, such as Personality, can be recalled when the installation menu is locked.

A **Warning Screen** is displayed when you attempt to navigate to the **Installation Menu** stating that the installation settings are locked and any changes will not be saved.

Use the following procedure to lock or unlock the installation settings of the switcher:

- 1. Navigate to the Lock/Unlock Installation Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ More ⇒ Lock/Unlock Installation.

**Note** — If the Lock/Unlock Installation feature is active, and a password has been set up, the **Enter Installation Password Menu** is displayed. Enter the password in the **New Name** field and press **Accept New Name** to display the **Lock/Unlock Installation Menu**.

LOCK/OTHOCK INStandton	44 Back		Copy Up	13 Swap	
No password is set.					
You can still lock/unlock the Installation	on settings.				

Lock/Unlock Installation Menu

- **2.** Turn the installation lock on or off as follows:
  - Toggle Install'n Lock on the Lock/Unlock Installation Menu to On or Off:
    - > **On**—Select this option to turn the installation lock feature on.
    - > **Off** Select this option to turn the installation lock feature off.

**Operating Tip** — You can delete the current password by pressing **Clear Password** on the **Lock/Unlock Installation Menu**.

- **3.** Set a password for the installation lock as follows:
  - Press Add/Change Password on the Lock/Unlock Installation Menu to display the Change Installation Password Menu. If a password has already been set, the button is labelled Change Password.

Change Installation Password	44 Back	M Termary	A SHAWAR	13 Swap		
1 0 <b>* \$ %</b> ^ 1 2 3 4 5 6	6 * 7 8		: :	Backspace		
Q W E R T Y		O P				
Caps Lock A 5 D F	6 H	J K	L :	; DEL		
Shift Z X C V	BN	M <	<b>&gt;</b> 7			
🧳 🔶 Si	pace	ew Password (M/	X 8 Characters	N		
Clear				Accept New Pass	sword	A too

Change Installation Password Menu

- Enter the new password in the **New Password** field on the **Change Installation Password Menu**.
- Press Accept New Password on the Change Installation Password Menu to save the new password.

This completes the procedure for locking or unlocking the installation settings of the switcher.

# **File and Setup Storage**

# In This Chapter

This chapter provides information on storing files and registers to the internal hard drive, a USB flash drive, or directly to an external computer for backup.

The following topics are discussed in this chapter:

- File Storage Overview
- Storing and Recalling Files and Setups
- Managing Setups with an External Computer

# **File Storage Overview**

The Vision switcher stores configuration and operation data in a number of registers that contain the individual entries for items such as memories or personality settings. These registers can be stored as a single archive file, as a register set that contains all the individual register of that type, or as all individual registers. These files can be stored into Setups on the Hard Drive of the switcher, or as files onto a USB flash drive. Setups allow you to store a complete set of switcher files on the hard drive. Different Setups can be created for different shows or applications, allowing you to quickly locate and recall the switcher configurations.

The following Register Types are present on the Vision switcher:

- **Memory Registers** The memory registers contain all the memories that are stored on the switcher. The memory registers can be stored and recalled as a set of all the memories on the switcher, or as individual memory registers (**0** to **99**). Memory registers are stored and recalled across all MLEs on the switcher, even if the same memory register contains different settings for each MLE.
- **Custom Control Registers** The custom control registers contain all the custom controls that are stored on the switcher. The custom control registers can be stored and recalled as a set of all the custom controls on the switcher, or as individual custom controls. Custom control registers are stored and recalled by Bank and Custom Control. If there are more or fewer custom control buttons on the switcher you are recalling the custom control registers on, you may want to store and recall individual custom controls. Custom Control Bank information is stored in the installation registers.
- **Personality Registers** The personality registers contain all the user interface settings. These registers contain items such as mnemonic settings, preview overlay positions and settings, and transition rates. As a rule, anything that is set up from the **Personality Menus** is stored in these registers. The following items are stored in the Personality Registers:
  - > Personality settings
  - > Preview Overlay setting
  - > Default Mnemonics settings
  - > Pbus Memory settings
  - > Character Generator settings
  - > Memory Attributes
  - Bus Map Assignment
- **Clip Registers** The clip registers contain all the VTR and video server timecode and clip information stored on the switcher.
- **Installation Registers** The installation registers contain all the external device setup, and software configurations settings for the switcher. As a rule, anything that is set up from the **Installation Menus** is stored in this register. The following items are stored in the installation registers:
  - > Input BNC settings (including tally and crosspoint button assignments)
  - > Output BNC settings
  - > Aux Bus settings
  - > GPI I/O settings
  - Clean Feed settings
  - > Device communication settings
  - > Custom Control Bank settings (not including custom controls)
  - > Bus Maps

- Squeeze & Tease Registers The Squeeze & Tease registers contain all the Squeeze & Tease sequences that have been stored on the switcher.
- **Bus Maps Registers** The Bus Map registers contain all the Bus Maps that have been stored on the switcher.
- Shot Box Pages Registers The Shot Box Pages registers contain all the Shot Box Pages that have been stored on the switcher.
- **Camera Registers** The Camera registers contain all the stored shots for cameras that do not store shots on the camera or camera head controller. Refer to the Ross Video External Device Setup Sheet for your camera for information on whether it uses the Camera registers.
- **CC/Macro Attachments** The Custom Control Attachments registers contain all the mappings of custom controls that are attached to control panel buttons.
- **Multi-Viewer Assignment** The Multi-Viewer Assignment registers contain all the mapping of what layout is assigned to each Multi-Viewer.
- **Multi-Viewer Layout** The Multi-Viewer Layout registers contain all the layouts and assigned sources for the Multi-Viewer that have been stored on the switcher. The assignment of a Multi-Viewer to output BNCs is stored in the Installation Register.

The Memory, Custom Control and Squeeze & Tease registers can all be stored as individual files for each value on the switcher. This allows you to store a particular Memory, Custom Control, or Squeeze & Tease sequence to a Setup on the Hard Drive, or to the USB flash drive, and recall it to another register position on the same or a different switcher. For example, Custom Control **Bank 3 Button 9** can be stored on the USB flash drive and then recalled into **Bank 1 Button 3**. This allows you to organize these registers on a single switcher, or transfer only the registers you need to another switcher.

#### For More Information...

- on recalling the factory default settings for the switcher registers, refer to the section "Factory Default Settings" on page Eng 12-27.
- on attaching custom controls to panel buttons, refer to the section "Attaching Custom Controls to Panel Buttons" on page Eng 10-21.

# **Storing and Recalling Files and Setups**

The Vision switcher allows you to store and recall the various installation setting, custom controls, memories, sequences, and bus maps to either the hard drive, or USB flash drive. This can be to backup your settings, or to copy your settings from one switcher to another.

The Vision switcher can store files and setups on either the internal hard drive, located in the frame, or a USB flash drive that is inserted into the USB port on the **Fade To Black Module**.

Only the Master Panel can store or recall files or setups to either the internal hard drive, or a USB flash drive.

### **Storing Registers**

You can store your switcher settings and files either to the internal hard drive, or to an external USB flash drive from the Master Panel.

Use the following procedure to store switcher registers:

- 1. Press **Disk** on the **Main Menu 1-2**.
- 2. Press Dest/Source on the Disk Menu.

Disk Current Switcher Setup Chosen		44 Back 14 19 19 19 19 19 19 19 19 19 19 19 19 19		a convert	103.Swap	Disk Type Hard Drive USB		1.0.5
Hard (	Drive - SETUP (52)					Set Nar SETUP SETUP SETUP	mes: (51) (52) (53)	<b>30</b> .0
Recall	♣ Store		Recall individual	Store Individua	De	st / urce	4	

Destination/Source — Disk Menu

- **3.** Select the storage device that you want to store your files to as follows:
  - Use the **Disk Type** knob on the **Disk Menu** to select the storage device you want to store your files on. You can choose between the following:
    - Hard Drive Select this option to store the files to one of the setups on the hard drive. There are 100 setups available to store files.
    - > USB Select this option to store the files to a USB flash drive inserted in the USB port on the control panel.
  - If you are storing files to the internal hard drive, use the Set Names knob on the Disk Menu to select the Setup, or location, that you want to store the files in.

**Important** — Do not remove the USB flash drive from the control panel during a store or recall. If the USB flash drive is removed during a store or recall, the panel may need to be restarted to restore proper functionality.

4. Press **Store** on the **Disk Menu**.

/\*/

Disk Store	(1-3)	44 Back	M Tega age	A REPART	13 Swap	
Storing To: Ha	nd Drive - SETUP (2:	2)				
		Disk Co	ntents			
		There are no Vision	files on this disk			

Disk Store Menus

**5.** Select the switcher registers that you want to store to the selected Setup, or USB flash drive, as follows:

**Note** — If a  $\square$  is shown above a register type, then a switcher configuration file for that type is already present on the storage device. Confirm that you want to overwrite this file, or select a different Setup.

- All Select this option to store all categories of registers to the storage device.
- Memories Select this option to store only Memory Registers.
- Custom Controls —Select this option to store only Custom Control Registers.
- **Personality** Select this option to store only Personality Registers.
- VTR Clips Select this option to store only VTR Clip Registers.
- Installation Select this option to store only Installation Registers.
- Press **More** to view the following options.
- **S&T MD Sequences** Select this option to store only Squeeze & Tease Sequences.
- **Bus Maps** Select this option to store only Bus Map Registers.
- Shot Box Pages Select this option to store only Custom Control Shot Box Page Registers.
- **Camera** Select this option to store only Camera Shot Registers.
- **CC/Macro Attachments** Select this option to store only the custom control attachments to control panel buttons.
- **Multi-Viewer Assignment** Select this option to store only the Multi-Viewer Assignment Registers.
- **Multi-Viewer Layout** Select this option to store only the Multi-Viewer Layout Registers.
- 6. Name your Setup as follows:
  - Press Name Setup on the Disk Store Menu 3-3.

7

**Operating Tip** — Refer to the section "Using the Naming Menus" on page Eng 5-16 for more information on using the **Setup Name Menu** to enter a name for a Setup.

- Enter the new name for the Setup in the New Name field. The name can be no more than
   8 characters in length.
- 8. Press Accept New Name on the Setup Names Menu to store the new name.

This completes the procedure for storing switcher registers.

#### **Storing Individual Registers**

When you store an individual register, the switcher allows you to select into which register that entry is stored and recalled. For example, this allows you to store the memory in register **06**, and then recall it to Memory register **35**. This can be useful for organizing your registers, or for copying only select registers onto a new switcher.

Use the following procedure to store an individual switcher register:

- 1. Press **Disk** on the **Main Menu 1-2**.
- 2. Press Dest/Source on the Disk Menu.

Disk Current Switcher Setup Chosen:	44 Back	) <b>W</b> issiana	<ul> <li>B rout for 1</li> </ul>	103 Swap	Disk Ty Hard Di USB	/pe tve	• 0 •
Hard Drive - SETUP (52)					Set Na SETUP SETUP SETUP	mes. (51) (52) (53)	
The Recall The Store		Recall individual	Store Individua	I De So	ist / urce	4	per .

Destination/Source — Disk Menu

- 3. Select the storage device that you want to store your files to as follows:
  - Use the **Disk Type** knob on the **Disk Menu** to select the storage device you want to store your files on. You can choose between the following:
    - Hard Drive Select this option to store the files to one of the setups on the hard drive. There are 100 setups available to store files.
    - > USB Select this option to store the files to a USB flash drive inserted in the USB port on the control panel.
  - If you are storing files to the internal hard drive, use the **Set Names** knob on the **Disk Menu** to select the Setup, or location, that you want to store the files in.
- 4. Press Store Individual on the Disk Menu.
- 5. Store an individual Memory Register as follows:
  - Press Memory Register on the Store Individual Items Menu 1-2.

Store Individual Items ( Storing To: Hard Drive - SETUP	1-2) 4 (52)	Back DF Forward	[]   <b>4</b> Convert [	103 Swap	To Disk:
Memory Legend:	on disk.				From Switcher Memory00(00) Memory02(02)
Memory Register Register	Sequen	ce Bus Maps	Shot Box Pages	St	iore em

Memory Registers — Store Individual Items Menu 1-2

- Use the **From Switcher** knob on the **Store Individual Items Menu** to select the switcher memory register that you want to save.
- Use the **To Disk** knob on the **Store Individual Items Menu 1-2** to select the register on the storage device to save the file to.
- Press **Store Item** on the **Store Individual Items Menu 1-2** to store the memory register to the selected location.
- 6. Store an individual Custom Control Register as follows:
  - Press CustCtrl Register on the Store Individual Items Menu 1-2.

Store Individual Items (1-2) Storing To: Hard Drive - SETUP (10) Custom Control Legend: @ = Custom control contains macm # = Normal custom control button 7 = Custom control button has no + = Custom control button is a bar - = Custom control button does no = Custom control exists on disk.	dd Back o. bank configur nk selector, ot exist on pa	net.	9 con en	13 Swap	To Disk: Bnk 1 B Bnk 1 B Bnk 1 B From Sw Bnk 1 B Bnk 1 B	tn 03 tn 04 tn 05 vitcher: tn 03 tn 04 tn 05 v
Memory Register Register Se	equence	Bus Maps	Shot Box Pages	Sto	ore m	

Custom Control Registers — Store Individual Items Menu 1-2

- Use the **From Switcher** knob on the **Store Individual Items Menu 1-2** to select the custom control register that you want to save. This list does not distinguish between relative and normal custom controls.
- Use the **To Disk** knob on the **Store Individual Items Menu 1-2** to select the register on the storage device to save the file to.
- Press **Store Item** on the **Store Individual Items Menu 1-2** to store the custom control register to the selected location.
- 7. Store an individual Sequence Registers as follows:
  - Press Sequence on the Store Individual Items Menu 1-2.

Store Individual Items (1-2) Storing To: Hard Drive - SETUP (52)	44 Back	Forward	a Contrati	03 Swap	To Disk: Sequence 0 Sequence 1 Sequence 2
Sequence Legend:	sk.				From Switchen New Seq (00) New Seq (02) New Seq (02)
Memory Register Register	Sequence	Bus Maps	Shot Box Pages	St	ore 斗

Sequence — Store Individual Items Menu 1-2

- Use the **From Switcher** knob on the **Store Individual Items Menu 1-2** to select the sequence that you want to save.
- Use the **To Disk** knob on the **Store Individual Items Menu 1-2** to select the register on the storage device to save the file to.
- Press **Store Item** on the **Store Individual Items Menu 1-2** to store the sequence to the selected location.

- 8. Store an individual **Bus Map** as follows:
  - Press Bus Maps on the Store Individual Items Menu 1-2.

Store Individ	ual Items (1-2)	44 Back	P Forward		10,Swap	To Disk:
Storing To: Hard I	Drive - SETUP (52)					Map 01 Map 02
Bus Map Le	gend: map is used. map file exists on di	sx.				Prom Switcher @Map01 (01) Map02 (02) Map03 (03)
Memory Register	CustCtri Register	Sequence	Bus Maps	Shot Box Pages	S	tore 🛁 斗

Bus Maps — Store Individual Items Menu 1-2

- Use the **From Switcher** knob on the **Store Individual Items Menu 1-2** to select the bus map that you want to save.
- Use the **To Disk** knob on the **Store Individual Items Menu 1-2** to select the register on the storage device to save the file to.
- Press **Store Item** on the **Store Individual Items Menu 1-2** to store the bus map to the selected location.
- 9. Store an individual Shot Box Page as follows:
  - Press Shot Box Pages on the Store Individual Items Menu 1-2.

Store Individ	Drive - SETUP (0.	) 44 Back 3)	]   ₩Tanaard (	A PERSON	13 Swap	To Dis Page Page Page	01 02 03	10.
ShotboxPa	ge Legend: s map file exists on	disk.				From S Page 1 Page 2 Page 3	(01) (02) (03)	0.0
Memory Register	CustCtri Register	Sequence	Bus Maps	Shot Box Pages	SI	tore	-	

Shot Box Pages — Store Individual Items Menu 1-2

- Use the **From Switcher** knob on the **Store Individual Items Menu 1-2** to select the shot box page that you want to save.
- Use the **To Disk** knob on the **Store Individual Items Menu 1-2** to select the register on the storage device to save the file to.
- Press **Store Item** on the **Store Individual Items Menu 1-2** to store the shot box page to the selected location.

10. Store an individual Multi-Viewer Layout as follows:

• Press Multi-Viewer Layouts on the Store Individual Items Menu 2-2.



Multi-Viewer Layouts - Store Individual Items Menu 2-2

- Use the **From Switcher** knob on the **Store Individual Items Menu 2-2** to select the Multi-Viewer layout that you want to save.
- Use the **To Disk** knob on the **Store Individual Items Menu 2-2** to select the register on the storage device to save the file to.
- Press **Store Item** on the **Store Individual Items Menu 2-2** to store the Multi-Viewer layout to the selected location.

This completes the procedure for storing an individual switcher register. With your individual registers stored, you can recall them onto the same switcher in different locations, or recall them onto a different switcher. Recalling your registers in different locations on the same switcher allows you to organize your memories, sequences, or custom controls in a different order.

### **Recalling Registers**

When you recall switcher registers by type, the switcher extracts the individual register items from the register type files and replaces the existing register entries with the new ones.



**Important** — A **Recall** cannot be undone. Ensure that you have **Stored** your current switcher configuration before recalling a new Setup so that you can revert to the previous configuration if needed.

Use the following procedure to recall switcher registers:

- 1. Press **Disk** on the **Main Menu 1-2**.
- 2. Press Dest/Source on the Disk Menu.

Disk	44 Back	•••	<b>4</b> (Sola Vili	00,Swap	Disk Ty	pe.	e
Current Switcher Setup Chosen:					US8		0.
Hard Drive - SETUP (52)					Set Nar	mes	
					SETUP	(51)	ø
					SETUP	(52)	0
- Aecal - Store		Recall     Individual	Store     Individual		est / surce	4	

Destination/Source — Disk Menu

- **3.** Select the storage device that you want to recall your files from as follows:
  - Use the **Disk Type** knob on the **Disk Menu** to select the storage device you want to recall your files from. You can choose between the following:
    - > **Hard Drive** Select this option to recall the files from one of the setups on the hard drive.
    - > **USB** Select this option to recall the files from a USB flash drive inserted in the USB port on the control panel.
  - If you are recalling files from the internal hard drive, use the **Set Names** knob on the **Disk Menu** to select the Setup, or location, that you want to recall the files from.

**Important** — Do not remove the USB flash drive from the control panel during a store or recall. If the USB flash drive is removed during a store or recall, the panel may need to be restarted to restore proper functionality.

4. Press Recall on the Disk Menu.

Disk Recall	(1-3)	44 Back	De Toppiert	A REPART	33 Swap	
Recalling from	Hard Drive - SETUP	(99)				
		Disk C	ontents			
		Disk C	ontents		•	

Disk Recall Menus

**5.** Select the switcher registers that you want to recall from the selected Setup or USB flash drive as follows:

**Note** — If a  $\square$  is shown above a register type, then a switcher configuration file for that type is already present on the storage device.

- All Select this option to recall all categories of registers.
- **Memories** Select this option to recall only Memory Registers.
- **Custom Controls**—Select this option to recall only Custom Control Registers.
- **Personality** Select this option to recall only Personality Registers.
- VTR Clips Select this option to recall only VTR Clip Registers.
- Installation Select this option to recall only Installation Registers. If the Lock/Unlock Installation feature is active, you cannot recall an installation register.
- **S&T MD Sequences** Select this option to recall only Squeeze & Tease Sequences.
- **Bus Maps** Select this option to recall only Bus Map Registers.
- Shot Box Pages Select this option to recall only Custom Control Shot Box Page Registers.
- **Camera** Select this option to recall only Camera Shot Registers.
- **CC/Macro Attachments** Select this option to recall only the custom control attachments to control panel buttons.



- **Multi-Viewer Assignment** Select this option to recall only the Multi-Viewer Assignment Registers.
- **Multi-Viewer Layout** Select this option to recall only the Multi-Viewer Layout Registers.

This completes the procedure for recalling switcher registers.

#### For More Information...

 on the Lock/Unlock Installation feature, refer to the section "Lock/Unlock Installation" on page Eng 12-46.

### **Recalling Individual Registers**

When you recall an individual register, the switcher allows you to select into which register that entry is recalled. For example, this allows you to store the memory in register **06**, and then recall it to Memory register **35**. This can be useful for organizing your registers, or for copying only select registers onto a new switcher.

Use the following procedure to recall an individual switcher register:

- 1. Press **Disk** on the **Main Menu 1-2**.
- 2. Press Dest/Source on the Disk Menu.

Disk		44 Back		<b>3</b> (2017) (11)	03.Swap	Disk Type Hard Drive US8	6
Current Switcher Setup Chosen: Hard Drive - SETUP (52)						Set Names SETUP (51) SETUP (52) SETUP (53)	9 0 S
Recall	.istore	[	Recall individual	Store individual	De	st/	

Destination/Source — Disk Menu

- 3. Select the storage device that you want to recall your files from as follows:
  - Use the **Disk Type** knob on the **Disk Menu** to select the storage device you want to store your files on. You can choose between the following:
    - > **Hard Drive** Select this option to recall the files from one of the setups on the hard drive.
    - > **USB** Select this option to recall the files from a USB flash drive inserted in the USB port on the control panel.
  - If you are recalling files from the internal hard drive, use the **Set Names** knob on the **Disk Menu** to select the Setup, or location, that you want to recall the files from.
- 4. Press Recall Individual on the Disk Menu.
- 5. Recall an individual Memory Register as follows:
  - Press Memory Register on the Recall Individual Items Menu 1-2.

Recall Individual Items (2-2) Recalling from: Hard Drive - SETUP (52)	44 Back	PP Forward	<b>4</b> Conv.(m)	ttt).Swap	Rom Disk: Memory00 Memory01 Memory02
Memory Legend:					To Switcher: Memory00(00) Memory01(01) Memory02(02)
Memory CustCtrl Register Register S	equence	Bus Maps	Shot Box Pages	Re	ecall of

Memory Registers — Recall Individual Items Menu 1-2

- Use the **From Disk** knob on the **Recall Individual Items Menu 1-2** to select the memory register on the storage device to recall.
- Use the **To Switcher** knob on the **Recall Individual Items Menu 1-2** to select the switcher memory register that you want recall to.
- Press **Recall Item** on the **Recall Individual Items Menu 1-2** to recall the memory register to the selected location.
- 6. Recall an individual Custom Control Register as follows:
  - Press CustCtrl Register on the Recall Individual Items Menu 1-2.

Recall Individual Items (2-2) Recaling from: Hard Drive - SETUP (52) Custom Control Legend: @ = Custom control contains macro. # = Normal custom control button = Custom control exists on disk	44 Back	PP Forward	9.000	th Swap	Prom Disk: Brik 1 Btn 01 (C) Brik 1 Btn 02 (D) Brik 1 Btn 03 (P) Brik 1 Btn 03 (P) To Switchen: Custom01 1#01 (C) Custom03 1#03 (P)
Memory CustCbi Register Register Set	quence	Bus Maps	Shot Box Pages	Re	ecall al

Custom Control Registers — Recall Individual Items Menu 1-2

- Use the **From Disk** knob on the **Recall Individual Items Menu 1-2** to select the custom control register on the storage device to recall.
- Use the **To Switcher** knob on the **Recall Individual Items Menu 1-2** to select the custom control register that you want recall to.
- Press **Recall Item** on the **Recall Individual Items Menu 1-2** to recall the custom control register to the selected location.
- 7. Recall an individual Sequence Registers as follows:
  - Press Sequence on the Recall Individual Items Menu 1-2.

Recall Individual Items (2-2) Recaling from: Hard Drive - SETUP (52)	44 Back	PP Forward	<b>4</b> Conv. (4)	100 Swap	From Disk: Sequence 0 Sequence 1 Sequence 2
Sequence Legend:					To Switcher. New Seq (00) New Seq (01) New Seq (02)
Memory Register Register	Sequence	Bus Maps	Shot Box Pages	Re	ecall 위

Sequence — Recall Individual Items Menu 1-2

- Use the **From Disk** knob on the **Recall Individual Items Menu 1-2** to select the sequence on the storage device to recall.
- Use the **To Switcher** knob on the **Recall Individual Items Menu 1-2** to select the sequence that you want recall to.
- Press **Recall Item** on the **Recall Individual Items Menu 1-2** to recall the sequence to the selected location.
- 8. Recall an individual **Bus Map** as follows:
  - Press Bus Maps on the Recall Individual Items Menu 1-2.

Recall Individ Recaling from: Ha Bus Map Le @ = Bus D = Bus	Iual Items (2-2 rd Drive - SETUP ( gend: map is used, map file exists on d	2) 44 Back 52) isk	₩ Forward	9.000,0	ttg Swap	Prom Disk: Map 01 Map 02 Map 03 To Switcher @Map03 (01) Map03 (03) *
Memory Register	CustCtri Register	Sequence	Bus Maps	Shot Box Pages	Re	ecall 🚽 🗠

Bus Maps — Recall Individual Items Menu 1-2

- Use the **From Disk** knob on the **Recall Individual Items Menu 1-2** to select the bus map on the storage device to recall.
- Use the **To Switcher** knob on the **Recall Individual Items Menu 1-2** to select the bus map that you want recall to.
- Press **Recall Item** on the **Recall Individual Items Menu 1-2** to recall the bus map to the selected location.
- 9. Recall an individual Shot Box Pages as follows:
  - Press Shot Box Pages on the Recall Individual Items Menu 1-2.

Recall Individual Recalling from: Hard	I <b>Items (2-2)</b> Drive - SETUP	44 Back (51)	) ( Miromani (	- <b>9</b> Centry (19)	13 Swap	From Disk: Page 01 Page 02 Page 03
ShotboxPage Le	gend: o file exists on di	sk.				To Switcher: Page 1 (01) Page 2 (02) Page 3 (03)
Memory Register	CustCtrl . Register	Sequence	Bus Maps	Shot Box Pages	Ra	ecall and House

Shot Box Pages — Recall Individual Items Menu 1-2

- Use the **From Disk** knob on the **Recall Individual Items Menu 1-2** to select the shot box page on the storage device to recall.
- Use the **To Switcher** knob on the **Recall Individual Items Menu 1-2** to select the shot box page that you want recall to.
- Press **Recall Item** on the **Recall Individual Items Menu 1-2** to recall the shot box page to the selected location.

10. Recall an individual Multi-Viewer Layout as follows:

• Press Multi-Viewer Layouts on the Recall Individual Items Menu 2-2.

Recall Individual Items (2-2) Recalling from: Hard Drive - SETUP (99)	<b>∜</b> Back	Forward	9 ang 100	₿3 Swap	From Disk: Layout00 Layout01 Layout01 Layout02 To Switcher: Layout (00) Layout (01) Layout (02)	.0.
Multi-Viewet Layouts				Re	call 🙀 M	tore

Multi-Viewer Layouts - Recall Individual Items Menu 2-2

- Use the **From Disk** knob on the **Recall Individual Items Menu 2-2** to select the Multi-Viewer layout on the storage device to recall.
- Use the **To Switcher** knob on the **Recall Individual Items Menu 2-2** to select the Multi-Viewer layout that you want recall to.
- Press **Recall Item** on the **Recall Individual Items Menu 2-2** to recall the Multi-Viewer layout to the selected location.

This completes the procedure for recalling an individual switcher register.
## Managing Setups with an External Computer

The web interface of the frame allows you to not only upgrade the software on the switcher, but also to manage the Setups you have stored on the hard drive of the switcher. Using a computer on the same sub-net of a network as the frame, you can browse to the frame, log in, and either download or upload Setups from or to the frame.

## **Downloading Setups to an External Computer**

Downloading Setups from the frame allows you to back up different switcher configurations off of the switcher. These Setups can then either be archived, or uploaded to a different switcher.

Use the following procedure to download a Setup from the switcher:

- 1. On your computer, open your Web Browser and, in the address bar, enter the IP address of your frame and press **Enter**. The **QMD/X Web Interface Splash Screen** is displayed.
- 2. Enter your username and password as follows when the Login Dialog Box appears. The default Name is user and Password is password.
- **3.** Click **File Sets** to display the **File Sets Page**. All the populated Setups on the switcher are shown in blue. If the Setup that you want to download does not appear, verify the Setup number on the switcher and refresh your browser.

				-
System who U	porade Fee Se	ta Other_		
File Sets				
Sets shown in blue	e have data in them. To	o make a backup of the set.	click on the blue link and then select "Save as* in your browser	
	10101-002		IN COLUMN ADDRESS ADDR	
			Hide Names Show Names	
Restore Sets			Hole Names - Show Hames	
Restore Sets	store a set from your i	PC back to the switcher. The	Hide Names 2hoe Sames	
Restore Sets Use this form to re	store a set from your i	PC back to the switcher. The	Hide Names 2hos banes n will overwrite any previous contents of the set on the switcher [.ferees.][.lippoint etc.]	
Restore Sets Use this form to re Delete Sets	store a set from your i	PC back to the switcher. The Persette	Hide Names Shoe Names a will overwrite any previous contents of the set on the switcher [Brower.][Japont art.]	
Restore Sets Use this form to re Delete Sets	ntone a set from your i foundor:	PC back to the switcher. The Plename	Hide Names Shoe Names a will overwrite any previous contents of the set on the switcher	
Restore Sets Use this form to re Delete Sets Use this form to de	atore a set from your i faunther: eate a file set from the	PC back to the switcher. The Plename : switcher: Plenae note:	Hide Names Shoe Names a will overwrite any previous contents of the set on the switcher	
Restore Sets Use this form to re Delete Sets Use this form to de • Verify which th • A devined th • File set name	etone a set from your I feamber; nete a file set from the lies set is active on you set can not be restor is are not delivited.	PC back to the switcher. The Flename switcher. Please note or switcher before doiving. I od	Hide Names 2hoe banes a will overwrite any previous contents of the set os the switcher	
Restore Sets Use this form to re Delete Sets Use this form to de • Verify which th • A device th • File set name	Notes a set from your i furnitor: notes a file set from the set can not be restor as an not deleted.	PC back to the switcher. The Filename: switcher, Please note ar switcher please note ar switcher before deixing. I od	Hide Names 2hoe hannes a will overwrite any previous contents of the set on the switcher	

File Sets Page

- 4. Download a Setup from the switcher to your computer as follows:
  - Click on the blue Setup number that corresponds to the Setup you want to download. A Save dialog box is displayed.
  - Select the folder, or directory, on your computer to save the Setup to. The switcher will compress the contents of Setup into a single file and download it to the selected folder, or directory.

This completes the procedure for downloading a Setup from the switcher.

## **Uploading Setups from an External Computer**

Uploading Setups to the frame allows you to restore different switcher configurations that you backed up off of the switcher, or transfer Setups from one switcher to another on the same network.

Use the following procedure to upload a Setup to the switcher:

- On your computer, open your Web Browser and, in the address bar, enter the IP address of your frame and press Enter. The QMD/X Web Interface Splash Screen is displayed.
- 2. Enter your username and password as follows when the Login Dialog Box appears. The default Name is user and Password is password.
- **3.** Click **File Sets** to display the **File Sets Page**. All the populated Setups on the switcher are shown in blue.

				2
Bysten who	Upgrade Fee Sets	Other		
File Sets				
Sets shown in blu	an have data in them. To m	ake a backup of the set	, click on the blue link and then select "Save as" In your browser	
	#100.000		and a second party storage	
	And and the second second			
			Hide Names Shoe Names	
Restore Sets	5			
Use this form to n	vestore a set from your PC	back to the switcher. Th	in will overwrite any previous contents of the set on the switcher	
	Number:	Fiename.	[Browen, ] [ Lapond Left.]	
Delete Sets				
	folate a file and house the sea	and a state		
The state in case and other	TOWARD 9 ING AND TOTAL TIME THE	NUTRY, Pressee 10.00		
Use this form to a	the act is action on your a	whether halfors desired	his second is also if inter delate the actual fits and	
<ul> <li>Verify which</li> <li>A deleted \$ </li> <li>File set name</li> </ul>	tile set is active on your s le set can not be restored nes are not deleted.	witcher before deleting	No warring is given if you delete the active file set	

File Sets Page

- **4.** Upload a Setup to the switcher from your computer as follows:
  - In the **Number** field, enter the 2-digit number for the Setup on the switcher that you want to upload the Setup files to. If any Setup files exist in that location, they will be replaced with the new files. All the populated Setups on the switcher are shown in blue.
  - In the **Filename** field, enter the location and name of the Setup on the computer that you want to upload to the selected Setup on the switcher.

**Operating Tip** — You can use the **Browse...** button to display file browser dialog, and then locate the file you want to upload.

• Click Upload set and OK to upload the Setup to the switcher.

This completes the procedure for uploading a Setup to the switcher

#### For More Information...

• on logging into the frame, refer to the section "Vision Web Interface Account" on page Eng 6-2.

# **Auxiliary Panels**

## In This Chapter

This chapter provides information on setting up an Auxiliary Control Panel or a Remote Aux Panel with the Vision switcher.

The following topics are discussed:

- Auxiliary Panel Overview
- Installing Auxiliary Panels
- Communications Connections
- Communications Setup
- Auxiliary Panel GPIs

## **Auxiliary Panel Overview**

The Vision switcher supports both the Vision Auxiliary Control Panel and the Remote Aux Panels used with the Ross Synergy family of switchers.

## **Auxiliary Control Panel**

The Auxiliary Control Panel (**Figure 14.1**) is available in either a 16, 24, 32, or 40 button version to match the size of your Vision control panel, and can be installed either on the back of the control panel or into the desk. The 24-button Auxiliary Control Panel can also be installed into a 19-inch rack frame. For information on installing and cabling your Auxiliary Control Panel, refer to the documentation that came with your Auxiliary Control Panel.

**Note** — An Auxiliary Control Panel that does not match the size of your control panel can be used; however, a different bus map will have to be assigned to the Auxiliary Control Panel to properly map all the crosspoint buttons.



Figure 14.1 Auxiliary Control Panel (24-Button Shown)

#### **Auxiliary Control Panel Components**

The Auxiliary Control Panel has a number of functional components that allow you to select the mode the panel is operating in, and perform various operations when in each mode.



Figure 14.2 Auxiliary Control Panel Components (24-Button Shown)

1)	Aux Bank Select Buttons	3) Command Buttons	4) Crosspoint Buttons
2)	Aux Select Buttons		

#### 1. Aux Bank Select Buttons

These buttons are used to select the Aux Bus Bank that the Auxiliary Control Panel is currently assigned to.

#### 2. Aux Select Button

These buttons are used to select the Aux Bus that the Auxiliary Control Panel is currently assigned to.

#### 3. Command Buttons

These mnemonic buttons are used to switch between operational modes and perform specific functions based on the operational mode the Auxiliary Control Panel is in.

#### 4. Crosspoint Buttons

The crosspoint buttons are used to select video sources. The number of crosspoint buttons depends on the model of Auxiliary Control Panel you have.

#### **Remote Aux Panels**

The Vision switcher supports the **Assignable** (Figure 14.3) Remote Aux Panel. The Remote Aux Panels are self-contained units that have their own power supply and connect to the control panel through one of the External Link ports.

Even though an unlimited number of Remote Aux Panels can be connected to the switcher, a practical limit of **24** panels should be observed. This limit will minimize delay, and allows **8** panels to be daisy-chained to each of the three External Link ports.

BLCK																		
					SHIFT	PV	MLE 1	MLE 2	MLE 3	CLEAN FEED	PGM	0	ASSIGN +4	ASSIGN +8	ASSIGN 1	ASSIGN 2	ASSIGN 3	ASSIGN 4

Figure 14.3 Assignable Remote Aux Panel

#### **Remote Aux Panel Connections**

The Remote Aux Panel has a number of connections on the back of the panel that allow you to connect it to the switcher, as well as provide GPI and power connections.



Figure 14.4 Remote Aux Panel Rear Connections

1) Power Connector	3) Main Connector	4) Echo Connector	
2) GPI Connector			

#### 1. Power Connector

A single DC power connector is provided for the +5 VDC power supply. An AC Adapter (90-264 VAC) is provided with each Remote Aux Panel to provide the +5 VDC power for the panel.

#### 2. GPI Connector

A single DB9 GPI connector is provided for special GPI triggers that allows a camera operator to manually override the Aux panel selection.

#### 3. Main Connector

A single RJ-12 connector is provided for connecting the Remote Aux Panel to the External Link port on the back of the control panel.

#### 4. Echo Connector

A single RJ-12 connector is provided for daisy-chaining the Remote Aux Panel to the next Remote Aux Panel in the chain.

## **Installing Auxiliary Panels**

The Remote Aux Panel is **1** RU high, and is designed to install into a standard 19-inch equipment rack.

1

**Note** — For information on installing and cabling your **Auxiliary Control Panel**, refer to the documentation that came with your Auxiliary Control Panel.

Use the following procedure to install a Remote Aux Panel:

- 1. Disconnect all cables from the Remote Aux Panel.
- 2. Place the Aux Panel into the rack where you want to install it.
- **3.** Using standard rack mounting bolts, attach the Remote Aux Panel to the equipment rack.

**Caution** — Always connect the External Power Supply to the Remote Aux Panel before connecting the AC mains power. Connecting the power supply to the AC mains power before connecting to the Remote Aux Panel could damage the Remote Aux Panel.

4. Connect the AC Adapter to the **Power** port on the Aux Panel and to the appropriate AC outlet.

This completes the procedure for installing a Remote Aux Panel into an equipment rack.

## **Communications Connections**

This section outlines how to connect a Remote Aux Panel to one of the Aux ports on the Vision control panel.

For information on installing and cabling your **Auxiliary Control Panel**, refer to the documentation that came with your Auxiliary Control Panel.

In order to properly complete this procedure you will need the following cables:

- **Remote Aux Panel Cable Adapter** This is a short TIA/EIA-568-B (CAT5e) cable with an RJ-45 connector on one end and an RJ-12 connector on the other. (Ross Part Number 4800CR-370)
- Aux Cable This is a shielded, 6-conductor telco cable with an RJ-12 connector on each end.

Use the following procedure to connect two Remote Aux Panels to the switcher:

1. Connect and secure the **RJ-45** end of the **Remote Aux Panel Cable Adapter** to one of the **External Link Ports** on the back of the control panel (**Figure 14.5**).

**Note** — *External Link Port 1* must be used to connect to the Touchscreen display, and *External Link Port 2* is used to connect to the OverDrive Production Control System. If OverDrive is set up on any Vision control panel connected to the switcher, *External Link Port 2* cannot be used for Remote Aux Panels.



Figure 14.5 Vision Control Panel — Remote Aux Connection

- 2. Connect and secure one of the **RJ-12** ends of the **Aux Cable** to the **RJ-12** end of the **Remote Aux Panel Cable Adapter**.
- **3.** Connect and secure the other **RJ-12** end of the **Aux Cable** to the **MAIN** port on the back of the **Remote Aux Panel**.
- **4.** Connect and secure one end of the **Aux Cable** to the **ECHO** port on the back of the Remote Aux Panel.
- 5. Connect and secure the other end of the **Aux Cable** to the **MAIN** port on the back of the second Remote Aux Panel.

This completes the procedure for connecting two Remote Aux Panels to the switcher. You can connect up to **8** Remote Aux Panels to a single **Aux Port** on the switcher.

## **Remote Aux Cable Pinouts**

Use the information in this section to connect the Remote Aux Panel Interface Cable from the Vision switcher to the Remote Aux Panel.

#### **Remote Aux Panel Cabling**

The Vision switcher connects to the Remote Aux Panel via the External Link ports on the Vision control panel, and the Main port on the Remote Aux Panel.



**Note** — Ross Video provides a **Remote Aux Panel Cable Adapter** (#4800CR-370) that plugs into the RJ-45 External Link ports and provides an RJ-12 Remote Aux port for a standard aux cable.

Cable connection in the following table (**Table 14.1**) refer only to those between the Vision switcher and the Remote Aux Panel. Refer to the section "**Remote Aux Panel Pinouts**" on page Eng 20-30 for information on other cable connections present on the Remote Aux Panel.

Vision Swit	cher		Remote Aux	Panel
External Link Port	Signal		Main Port	Signal
1	RxB (Rx+)	•	2	TxB (Tx+)
2	RxA (Rx-)	•	1	TxA (Tx-)
3	TxB (Tx+)	•	4	RxB (Rx+)
4				
5				
6	TxA (Tx-)	•	3	RxA (Rx-)
7	Reset	•	5	Reset
8				

Table 14.1 Vision -to- Remote Aux Panel Wiring Chart

## **Communications Setup**

The Vision switcher needs to be set up with the Auxiliary Control Panel or Remote Aux Panel to allow proper control and monitoring, as well as tally and GPI communications.

## **Auxiliary Control Panel**

The Auxiliary Control Panel can be assigned to either an Internal Panel Row, or an External Panel Row, depending on the functionality you want.



**Note** — Only Auxiliary Control Panels assigned to Internal Panel Rows can be used for menu auto follows, double press actions, or recording custom controls.

#### **Internal Panel Row Assignment**

Assign the Auxiliary Control Panel to an Internal Panel Row if you need menu follows and double press actions. Actions such as double-pressing a crosspoint button to assign a Color Corrector to that video source must be done on an internal panel row.

To set up an Auxiliary Control Panel on an internal panel row, ensure that the Auxiliary Control Panel is connected to the **NEXT** port on the back of the Touchscreen Display, and assign the Auxiliary Control Panel to one of the Internal Panel Rows.

#### **External Panel Row Assignment**

Assign the Auxiliary Control Panel to an External Panel Row if you do not need menu follows or double press action.

To set up an Auxiliary Control Panel on an external panel row, ensure that the Auxiliary Control Panel is connected to **External Link Ports 2**, **3**, or **4**, and assign the Auxiliary Control Panel to one of the External Panel Rows.

#### For More Information...

- on installing and cabling up your Auxiliary Control Panel, refer to the documentation that came with your Auxiliary Control Panel.
- on assigning modules to a panel row, refer to the section "Mapping a Module to a Row" on page Eng 17-5.
- on how GPIs are assigned by panel row, refer to the section "Auxiliary Control Panel GPIs" on page Eng 14-11.
- on setting an External Link Port to External Module, refer to the section "External Panel Modules" on page Eng 9-21.

#### **Remote Aux Panel**

To set up a Remote Aux Panel, you must first assign an External Link port to Remote Aux Panels, and then assign each Remote Aux Panel to an Aux Bus.

Use the following procedure to configure the switcher to communicate with a Remote Aux Panel:

- 1. Navigate to the **Communications Menus** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Comm Setup.
- 2. Press **Type** on the **Communications Menu 1-2**.

Communications (1-2)	44 Back	M Tormani	A REPORTED IN	193 (CONTAIL)	Com Port:	
					REMOTE 8 (R	B) 🕑
					ExtLnk 2 (L2)	0
					ExtLnk 3 (L3)	0
This menu lets you set up	and a second				-	
what each of the com ports are use	tor.				Device:	-
					OFF	- (P)
					Remote Aux	Ø
					Automation	۲
					2002030-	
					Aux Buses:	1
					1:1 to 2:4	0
					2:1 to 3:4	1
					3:1 to 4:4	(2)
Tune Select	ComTune	Com Settinos	Custom	Ext	n. ) [	More
1717	contrype	Com Seconda	Photo Laboration of the second	0.00	in her	HOLD I

Device Type — Communications Menu 1-2

- **3.** Assign a Remote Aux port to the Remote Aux Panel as follows:
  - Use the **Com Port** knob on the **Communications Menu 1-2** to select the communications port on the Vision switcher that is connected to the Remote Aux Panel.
  - Use the **Device** knob on the **Communications Menu 1-2** to select **Remote Aux**. If the OverDrive Production Control System is set up with the switcher, you cannot assign **ExtLnk 2** to **Remote Aux**.
  - Use the **Aux Buses** knob on the **Communications Menu 1-2** to select the range of aux buses that you want to make available to the remote aux panels connected to the selected External Link port.

**Note** — All the Remote Aux Panels that are connected to the selected External Link port, or to other Remote Aux Panels that are connected to the port, are restricted to Aux Buses in the range you select.

- 4. Press HOME to display the Installation Change Confirmation Screen.
- 5. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.
- 6. Navigate to the **Remote Panels Menus** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Aux Bus ⇒ Remote Panels.
- Press Remote Panel Setup on the Remote Panels Menu. This places all the Remote Aux Panels connected to the switcher into assignment programming mode. The red On-Air indicator on the Remote Aux Panels flash (Figure 14.6).



Remote Panel Setup Menu



Figure 14.6 On-Air Indicator (Tally)

8. In assignment programming mode, the first **12** crosspoint buttons (Figure 14.7) represent Aux Bus outputs in the range specified in Step (3.) above.

	2	3	4	5	Ĵ	Ĭ	Å		Ĵ	10	11 ↓	12												
BLACK																								
								) [			SHIFT	PV	MLE 1	MLE 2	MLE 3	CLEAN FEED	PGM	0	ASSIGN +4	ASSIGN +8	ASSIGN 1	ASSIGN 2	ASSIGN 3	ASSIGN 4

Figure 14.7 Aux Bus Output Buttons

- **9.** Each aux panel can be assigned to all the available aux buses. The aux panel can be set up for each aux bus in one of three modes. Press the Aux Bus Output buttons on the Remote Aux Panel repeatedly until the required mode is selected for the aux bus. You can choose between the following:
  - Off The aux panel is not assigned to the selected aux bus. The button is not lit.
  - **Regular** The aux panel is assigned to the selected aux bus, allowing full control. The button is lit steadily.
  - **Follow** The aux panel is assigned to the selected aux bus, allowing you to view what crosspoints are selected on that aux bus, but you cannot control the aux bus. The button is flashing.
- **10.** Press **Accept** on the **Remote Panel Setup Menu** to store the new settings and exit programming mode.

This completes the procedure for configuring the switcher to communicate with a Remote Aux Panel.

## **Auxiliary Panel GPIs**

Using the **16** GPIs on each Auxiliary Control Panel, or the **8** GPIs on each Remote Aux Panel, a camera operator can manually override the aux panel selection using a GPI trigger. For purposes of matching or monitoring cameras, the camera operator can override the selected aux bus crosspoint and manually switch to a selected output BNC using a button on the joystick or camera control unit.

Each aux panel can be programmed to ignore all the GPIs if required. Remote GPIs cannot be used for any other function other than aux bus signal selection.

#### For More Information...

- on the GPI Ports on the Remote Aux Panel, refer to the section "GPI Port" on page Eng 20-30.
- on the programming mode of the Remote Aux Panel, refer to the section "Aux Panel **Programming Mode Summary**" on page Eng 20-32.

#### **Auxiliary Control Panel GPIs**

The **16** GPIs on each Auxiliary Control Panel are assigned based on the GPI group that the Auxiliary Control Panel was assigned to. For example, if an Auxiliary Control Panel is assigned to **GPI Group 1**, **GPIs 1-16** are used.

Use the following procedure to assign a GPI group to a Auxiliary Control Panel:

- 1. Navigate to the Panel Modules Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ More ⇒ Panel Modules. A warning is displayed, asking you if you want to enter the menu. Press Yes to display the Panel Modules Menu.
- 2. Use the Link/Node knob on the Panel Modules Menu to select the module on the Auxiliary Control Panel that has the command buttons on it. You can also press a button on the module to jump to the link and node.
- 3. Press Custctrl & GPI Group on the Panel Modules Menu.

Panel Modules	44 Back MP Formand	- <b>3</b> FOLV (12)	93	Link/Node: L:1/ N:1 L:1/ N:2 L:1/ N:3	• 0.0
25 modules round Link 1 Node 2 Primary Auxbus Crosspoint Main module, FPGA version 4, rev. B; External type,	issue 2A, mnem. 2G PCB issue 2, ver. 0				
First crosspoint: 17 GPI group: 1				GPI Grout (1)	
Quick     Panel Row &     Crosspoint	ustetri & PI Group		Upg PMC	prade a	artery.

Custctrl & GPI Group (Auxiliary Control Panel Module) — Panel Modules Menu

**4.** Use the **GPI Group** knob on the **Panel Modules Menu** to select the GPI group that you want to assign to the Auxiliary Control Panel.

This completes the procedure for assigning a GPI group to an Auxiliary Control Panel.

#### For More Information...

• on assigning modules to a panel row, refer to the section "Mapping a Module to a Row" on page Eng 17-5.

#### **Remote Aux Panel GPIs**

The **8** GPIs on each Remote Aux Panel can be offset by multiples of **8**, allowing each remote panel to use different GPIs, to the maximum of **64**. For example, **Remote Aux Panel 1** can be set to use **GPIs 1-8**. By setting **Remote Aux Panel 2** to an offset of **1**, it will use **GPIs 9-16**.

In order to gain access to all 64 GPIs, you must program the offset and group for each Remote Aux Panel.

Use the following procedure to program a Remote Aux Panel GPI:

- 1. Navigate to the **Remote Panels Menus** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Aux Bus ⇒ Remote Panels.
- 2. Press **Remote Panel Setup** on the **Remote Panels Menu**. This places all the Remote Aux Panels connected to the switcher into programming mode. The **On-Air** indicators on the Remote Aux Panels flash.

Remote Panel Setup	44 Back	• • • • • • • • • • • • •	A (1997) 1991	103 (control)	
Remote AUX	Panels are in pro	ogramming mode	15		
Remote GPIs:       1       2       3       4       5       6       7       8         GPI Group 1:       Image: Complex of the second seco	Oldest Firm Aux1: Rem.A Aux2: Rem.A	ware Versions ux. No Version re ux. No Version re	eturned eturned		
Inquire GPIs			Cancel	Accept	

Remote Panel Setup Menu

- **3.** Press **CLEAN FEED** on the Remote Aux Panel to switch the panel from assignment programming mode to GPI programming mode. The **CLEAN FEED** button flashes.
- **4.** In GPI programming mode, the first **8** crosspoint buttons (**Figure 14.8**) on the Remote Aux Panel allow you to select the **GPI Group** you want to assign to the aux panel.



Figure 14.8 GPI Programming Buttons

- **5.** Select the GPI Group you want to assign to the Remote Aux Panel, by selecting the appropriate crosspoint button (offset). Only one GPI Group can be assigned to a Remote Aux Panel at a time.
  - GPIs 1-8 Select GPI Group 1 (Offset 0) to assign these GPIs.
  - GPIs 9-16 Select GPI Group 2 (Offset 1) to assign these GPIs.

- GPIs 17-24 Select GPI Group 3 (Offset 2) to assign these GPIs.
- GPIs 25-32 Select GPI Group 4 (Offset 3) to assign these GPIs.
- GPIs 33-40 Select GPI Group 5 (Offset 4) to assign these GPIs.
- GPIs 41-48 Select GPI Group 6 (Offset 5) to assign these GPIs.
- GPIs 49-56 Select GPI Group 7 (Offset 6) to assign these GPIs.
- GPIs 57-64 Select GPI Group 8 (Offset 7) to assign these GPIs.
- 6. Test the GPIs on the Remote Aux Panel as follows:
  - Press the GPI buttons on the CCU joystick. The crosspoint button that corresponds to the GPI (**Figure 14.9**) will light up, indicating that the GPI has been shorted to ground.



Figure 14.9 GPI Testing

- **7.** Press **Accept** on the **Remote Panel Setup Menu** to store the new settings and exit programming mode.
- 8. Press HOME to display the Installation Change Confirmation Screen.
- 9. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for programming a Remote Aux Panel GPI. Once the GPIs have been set up, you will have to set up the CCU Joystick controls.

## Setting Up CCU Joystick Control

Once the aux panel GPIs have been set up, and the panels have been set up with the proper group and offsets, you can assign each aux panel GPI to an aux bus and an input BNC, as well as setting the trigger type.

Use the following procedure to configure your CCU joystick aux panel control:

- 1. Navigate to the **Remote Panels Menus** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Aux Bus ⇒ Remote Panels.
- 2. Press Remote GPI Assignment on the Remote Panels Menu.



Remote GPI Assignment — Remote Panels Menu

- 3. Assign a remote GPI input to an Aux Bus and Input as follows:
  - Use the **Remote** knob on the **Remote Panels Menu** to select the Auxiliary Panel GPI that you want to assign an aux bus to.
  - Use the **Aux Bus** knob on the **Remote Panels Menu** to select the aux bus that you want to assign the GPI input to.
  - Use the **Source** knob on the **Remote Panels Menu** to select the video source that you want to be selected on the Auxiliary Panel when the selected GPI is triggered.
- 4. Press Remote GPI Type on the Remote Panels Menu.

Remote Panels	44 Back	M Topping	A 1997/199	13 FORE	Remote:	
Remot	e GPIs / CCU Joysti	ck Control			GPI #1 GPI #2	0
Use this menu to set the trigger type for the selected Remote GPI Aux Bu	s: 1, BNC; BNC C	01 (C01)			Type: Low-Override Low-Toggle High-Toggle	0.000
Remote     Remote GPI     Assaument	Remote GPI	External     Bow Setup			4	

Remote GPI Type — Remote Panels Menu

- **5.** Set the type of GPI trigger as follows:
  - Use the **Remote** knob on the **Remote Panels Menu** to select the Auxiliary Panel GPI that you want to set up.
  - Use the **Type** knob on the **Remote Panels Menu** to select the type of control that you want to assign to the selected GPI. You can choose between the following:
    - Low-Override Select this option to set the trigger as a temporary override when the circuit is closed (high to low signal). When the circuit opens again (low to high signal), the aux bus output returns to the selected video signal.
    - Low-Toggle Select this option to set the trigger as a toggle when the circuit closes (high to low signal). Every time the circuit closes, the override state will toggle.
    - > **High-Toggle** Select this option to set the trigger as a toggle when the circuit opens (low to high signal). Every time the circuit opens, the override state will toggle.

- Latch Select this option to set the trigger to latch when the circuit opens or closes. Once latched, the trigger cannot be released except by selecting a different source on the Auxiliary Panel itself.
- > **Off** Select this option to disable the GPI trigger.

**Operating Tip** — The **Remote Panel Setup Menu** shows which Auxiliary Panel GPIs are currently closed. You can update the list by pressing the **Inquire GPIs** button.

- 6. Press HOME to display the Installation Change Confirmation Screen.
- 7. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for configuring your CCU joystick aux panel control.

#### For More Information...

• on naming an external panel row, refer to the section "Naming an External Row" on page Eng 17-8.

## **Custom Control Shot Box Module**

## In This Chapter

This chapter provides information on setting up a Custom Control Shot Box Module with the Vision switcher.

The following topics are discussed:

- Custom Control Shot Box Module Setup
- Creating Shot Box Pages
- Naming Shot Box Pages
- Copying or Moving Shot Box Pages

#### For More Information...

- on installing the Custom Control Shot Box Module, refer to the documentation that came with your Shot Box Module.
- on storing and recalling shot box pages, refer to the section "Storing and Recalling Files and Setups" on page Eng 13-4.

## **Custom Control Shot Box Module Setup**

To set up the Shot Box Module, you must first assign each Shot Box Module to a panel row. Once the Shot Box Module is assigned to a panel row you can assign Shot Box Pages to the buttons.

Assigning Shot Box Pages to buttons allows you to switch between pages by pressing the button on the Shot Box Module, just like switching between custom control banks on the custom control bus.



**Note** — If more than one Shot Box Module is assigned to the same panel row, both modules will mirror each other. You cannot have two Shot Box Modules operate independently if they are assigned to the same panel row.

Shot Box Pages can also be assigned to the control buttons on the Auxiliary Control Panel when it is in Aux Bus mode.

#### For More Information...

- on assigning a module to a panel row, refer to the section "**Mapping a Module to a Row**" on page Eng 17-5.
- on the control buttons on the Auxiliary Control Panel, refer to the section "Auxiliary Control Panel Operation" on page Ops 11-2.

Use the following procedure to assign a Shot Box Page to a button on the Shot Box Module:

- 1. Navigate to the Custom Controls Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ More ⇒ Custom Controls
     ⇒ Setup Shot Box Modules.

Shot Box Module Setup	44 Back	IF Tormarp	a copy set	93.000	Module Row Row 1 Row 2 Row 3	( Q )
					Page: Page 1 (1) Page 2 (2) Page 3 (3)	.0.
					Button: NONE Button # 1 Button # 2	0
					-	

Shot Box Module Setup Menu

- 2. Use the **Module Row** knob on the **Shot Box Module Setup Menu** to select the Shot Box Module that you want to assign buttons to pages on. Individual Shot Box Modules are identified by the panel row that they are assigned to. If you are setting up an Auxiliary Control Panel, the Panel Row is the row that the Auxiliary Control Panel is assigned to.
- **3.** Use the **Page** knob on the **Shot Box Module Setup Menu** to select the shot box page that you want to assign to a button.
- Use the Button knob on the Shot Box Module Setup Menu to select the button that you want to assign the select shot box page to. The name of the page appears on the selected button on the menu. Only buttons 1 through 14 are available on the Auxiliary Control Panel.
- 5. Press HOME to display the Installation Change Confirmation Screen.

- **6.** Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for assigning a Shot Box Page to a button on the Shot Box Module.

## **Creating Shot Box Pages**

When you create a Shot Box Page, you assign custom controls to the buttons on the page. The text on the buttons shows the mnemonic text for the custom control.

Use the following procedure to create a Shot Box Page:

- 1. Navigate to the Shot Box Page Setup Menu as follows:
  - Press HOME ⇒ Custom Controls ⇒ More ⇒ Setup Shot Box Pages.

Page Set	tup	E	44 Back	M Termer	Copy	Up 33Swap	Page: Page 1 (1)	6
Warptest	Mtrxwipe	HartStar	CoolLoop	DEMO	Custom07		Page 2 (2) Page 3 (3)	0.0
Robo 1 H	Robo 2 H	EVS H	SMS H	GeeVs H	360 H	ĺ	Button: Button # 1 Button # 2	0.0
VizRt H	Routr H	DVE H	Time Clk	Custom20	Custom21		Button # 3	
Custom23	Custom24	Custom25	Custom26	Custom27	Custom28	("Custom01" #*)	Cust Ctri Bnk 1 Btn 01 Bnk 1 Btn 02 Bnk 1 Btn 03	0.0
	Page Set Warptest Robo 1 H VizRt H Custom23	Page Setup       Warptest     Mtrxwipe       Robo 1 H     Robo 2 H       VizRt H     Routr H       Custom23     Custom24	Page Setup       Warptest     Mtrxwipe     HartStar       Robo 1 H     Robo 2 H     EVS H       VizRt H     Routr H     DVE H       Custom23     Custom24     Custom25	Page Setup     44 Back       Warptest     Mtrxwipe     HartStar     Cooil.cop       Robo 1 H     Robo 2 H     EVS     H     SMS     H       VizRt H     Routr H     DVE     H     Time Clk       Custom23     Custom24     Custom25     Custom26	Page Setup     44 Back     P       Warptest     Mtrxwipe     HartStar     CoolLoop     DEMO       Robo 1 H     Robo 2 H     EVS     H     SMS     H     GeeVs     H       VizRt H     Routr H     DVE     H     Time Clk     Custom20       Custom23     Custom24     Custom25     Custom26     Custom27	Page Setup     Image	Page Setup       44 Back       14 Copy Up       13 Swap         Warptest       Mtrxwipe       HartStar       CooilLoop       DEMO       Custom07         Robo 1 H       Robo 2 H       EVS       H       SMS       H       GeeVs       H       360       H         VizRt       H       Routr       H       DVE       H       Time Clk       Custom20       Custom21         Custom23       Custom24       Custom25       Custom26       Custom27       Custom28       ("Custom01" #*)	Page Setup       44 Back       IP       Or Copy Up       13 Swap       Page:       Page 1 (1)       Page 2 (2)       Page 2 (2)       Page 3 (3)         Warptest       Mtrxwipe       HartStar       CoolLoop       DEMO       Custom07       Page 3 (3)         Robo 1 H       Robo 2 H       EVS       H       SMS       H       GeeVs       H       360       H       Button:       Button:

Shot Box Page Setup Menu

- 2. Use the **Page** knob on the **Shot Box Page Setup Menu** to select the shot box page that you want to assign custom controls to.
- **3.** Use the **Button** knob on the **Shot Box Page Setup Menu** to select the button on the Shot Box Module that you want to use to run a custom control when the selected page is used.
- 4. Use the **Cust Ctrl** knob on the **Shot Box Page Setup Menu** to select the custom control that you want to assign to the selected page and button.

This completes the procedure for creating a Shot Box Page.

## **Naming Shot Box Pages**

The Shot Box Page names appear on the menus the mnemonics, and the Shot Box buttons for that page. This is useful when working with multiple pages.

Use the following procedure to name a Shot Box Page:

- 1. Navigate to the Shot Box Page Setup Menu as follows:
  - Press HOME ⇒ Custom Controls ⇒ More ⇒ Setup Shot Box Pages.
- 2. Use the **Page** knob on the **Shot Box Page Setup Menu** to select the shot box page that you want to change the name for.
- 3. Press Modify Page Name on the Shot Box Page Setup Menu.

Page Name	44 Back	M Tomary	- 4 (999 / 1999 )	13 Swap	Font:	
1 0 <b># \$ %</b> ^ 1 2 3 4 5 6	6 * 7 8		· *	Backspace	Standard Small Small Invert	0.
O W E R T I					Color: Standard Green	6
Caps Lock A 5 D F	GH	IK		, DEL	Yellow	۲
Shift Z X C V	BN	M <	> 7 . 1	Page		
	ipace	iew Name (MAX 9 Page 1	Characters):	1		
Clear Prev Mnem Ne Start Pos Sta	xt Mnem art Pos		Default	Acce	pt Name 刘	

Page Name Menu

**Operating Tip** — Refer to the section "Using the Naming Menus" on page Eng 5-16 for more information on using the **Page Name Menu** to enter a name, or set up the mnemonics for the custom control button.

- Enter the new name for the page in the New Name field. The name can be no more than
   8 characters in length.
- 5. Press Accept New Name on the Page Name Menu to store the new name and mnemonic settings.

This completes the procedure for naming a Shot Box Page.

## **Copying or Moving Shot Box Pages**

Each Shot Box page can be copied or moved to any other page location. The contents of the destination page is lost when a page is copied or moved to it. This allows you to duplicate or re-organize the Shot Box Pages.

Use the following procedure to copy or move a Shot Box Page:

- 1. Navigate to the Shot Box Page Setup Menu as follows:
  - Press HOME ⇒ Custom Controls ⇒ More ⇒ Setup Shot Box Pages.
- 2. Press Copy/Move Pages on the Shot Box Page Setup Menu to display the Manage Shot Box Pages Menu.

<b>Aanage Shot Box Pages</b> Select a source and destin page and press Copy or M	44 Back	) i 🍽 Consanni	Copy Up	93 Swap	Source Page 1 Page 2 Page 3	(01) (02) (03)	1.0.1
Select a source and dest page and press Copy or	nation Move				Destin Page 1 Page 2 Page 3	ation: (01) (02) (03)	(-O-)
Copy Move						-01	

Manage Shot Box Pages Menu

- **3.** Use the **Source** knob on the **Manage Shot Box Pages Menu** to select the shot box page you want to copy or move.
- **4.** Use the **Destination** knob on the **Manage Shot Box Pages Menu** to select the shot box page that you want to copy, or move, the source page to.
- **5.** Copy a shot box page as follows:
  - Press **Copy** on the **Manage Shot Box Pages Menu** to copy the source shot box page to the destination.
- **6.** Move a shot box page as follows:
  - Press **Move** on the **Manage Shot Box Pages Menu** to move the source shot box page to the destination. The commands in the source shot box page are moved to the destination. The source shot box page will be empty after the move.

This completes the procedure for copying or moving your Shot Box Pages.

# SmartConversion and Up/Down Converters

## **In This Chapter**

This chapter provides instructions for connecting, and setting up an Up/Down Converter with your Vision switcher. Before you begin, ensure that the **SmartConversion™** option is installed. If not, please contact **Ross Video** for details. Refer to the section "**Installed Options**" on page Eng 6-14 for instructions on verifying the status of installed options.

The following topics are discussed in this chapter:

- Setting Up a Conversion Loop
- Switcher Setup



**Operating Tip** — A Conversion Loop Worksheet is provided to assist you in keeping track of which inputs and outputs have been assigned to the Up/Down Converters. Refer to the section "Conversion Loop Worksheets" on page Eng 21-20 for a copy of this worksheet.

#### For More Information...

• on operating an Up/Down Converter with SmartConversion, refer to the section "SmartConversion<sup>™</sup>" on page Ops 4-23.

## **Setting Up a Conversion Loop**

Each conversion loop has an Output BNC that goes to the Up/Down Converter and an Input BNC that comes from the Up/Down Converter. Along with the input and output BNCs, each conversion loop is assigned an input and output video format. This allows SmartConversion to route video signal that need to be converted to the proper Up/Down Converters.

ß	Q	5		٦
Г	1	S	Я	
L		-	4	١

**Note** — Up/Down Converters can only be used on a single video signal at a time. You should plan ahead to ensure that you will have enough Up/Down Converters of each video format for all the video signals you will want on-air at any one time. This includes video signals that are being transitioned off-air.

A conversion loop ties an Aux Bus output and an Input BNC together so that when SmartConversion sends a video signal out to an Up/Down Converter, it knows on which Input BNC the converted video signal is returned on.



**Note** — If you want the video selections for the Aux Buses that you are using for Up/Down Converters to be stored in memories, you must enable Aux Bus in the memory. Refer to the section "**MLE Memory Attributes**" on page Ops 8-10 for more information on using this feature.

Use the following procedure to assign Input and Output BNCs to an Up/Down Converter:

- 1. Ensure that the **Output BNCs** that you want to use for your Up/Down Converter have been set up as **Aux Bus** outputs. Refer to the section "**Configuring Video Outputs**" on page Eng 8-2 for information on assigning an Aux Bus to an Output BNC.
- 2. Navigate to the Aux Bus Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Aux Bus.
- 3. Press Ext Device Assign on the Aux Bus Menu.



External Device Assignment — Aux Bus Menu

- 4. Assign Input and Output BNCs to a particular Up/Down Converter as follows:
  - Use the **Aux Bus** knob on the **Aux Bus Menu** to select the Aux Bus Output BNC that is connected to the input of your Up/Down Converter. This is the video signal that needs to be converted. The Aux Bus name and number is used to identify the conversion loop on the switcher.
  - Use the **BNC** knob on the **Aux Bus Menu** to select the Input BNC that is connected to the output of your Up/Down Converter. This is the video signal that has been converted.

- Use the **Tally when** knob on the **Aux Bus Menu** to select **XPT On Air**. This allows the switcher to identify when a video signal is going on-air, and needs to be converted.
- 5. Press SmartConversion on the Aux Bus Menu.
- 6. Press Aux To Converters on the SmartConversion Menu.

SmartConversi	on	44 Back	W Tomary	A 1999 199	198 FORT	Aux B	i5:
		Total Co	nverters: 1			Bnk1A Bnk1A Bnk1A	ux2(1:2) ux3(1:3)
Aux Bus Bhstatus2(1:1) BhktAus2(1:2) BhktAus2(1:3) BhktAus3(1:3) BhktAus5(1:5) BhktAus6(1:6) BhktAus7(1:7)	NO NO NO NO NO NO	Video Input 1080/59.94 1080/59.94 1080/59.94 1080/59.94 1080/59.94 1080/59.94 1080/59.94				Used f No Yes	or Converter.
Aux To Converters	Converter Formats			Bus Disabling	Con	verter king	-

Aux To Converters Setup — SmartConversion Menu

- 7. Activate a particular conversion loop as follows:
  - Use the **Aux Bus** knob on the **SmartConversion Menu** to select the Aux Bus Output BNC that is connected to the input of your Up/Down Converter.
  - Use the **Used for Converter** knob on the **SmartConversion Menu** to toggle the conversion loop on or off.
    - Yes Select this option to activate the selected conversion loop. SmartConversion will now be able to use this Up/Down Converter. Once activated, you will have to set the input and output video formats for each Up/Down Converter. Refer to the section "Assigning Buses to Use SmartConversion" on page Eng 16-5 for more information on assigning video formats to an Up/Down Converter.
    - No Select this option to not activate the selected conversion loop. SmartConversion will not use this Up/Down Converter.
- 8. Set the delay for a particular Up/Down Converter as follows:
  - Use the **Delay** knob on the **SmartConversion Menu** to select the amount of time that is required for the Up/Down Converter to convert the video signal and send it back to the switcher. Refer to your Up/Down Converter documentation for specific delay values.
- 9. Press Converter Format on the SmartConversion Menu.

SmartConversion		44 Back	)   🍽 Tormani i	(a) copy sep	93	Aux Bus: Bnk1Aux1(1)	0 6
Aux Bus Input Format InterAucerates 2000(159:92		Outr	nut Format	2		Input Format 1080i 60 1080i 59.94 1080i 50	10.0
						Output Form 1080i 60 1080i 59.94 1080i 50	st: (4) (9)
Aux To Converters	onverter			Bus Disabling	Con	verter 🐳	

Format Setup — SmartConversion Menu

- **10.** Assign input and output video formats to a conversion loop as follows:
  - Use the **Aux Bus** knob on the **SmartConversion Menu** to select the conversion loop you want to assign the input and output video formats for.
  - Use the **Input Format** knob on the **SmartConversion Menu** to select the video format that is being sent to the Up/Down Converter.

**Note** — The **Converter Output Format** does not change the video format of the Input BNC used by the conversion loop. When the conversion loop is activated, the video format of the Input BNC is overridden by the **Converter Output Format**. Refer to the section "**Configuring Video Inputs**" on page Eng 7-4 for more information on setting up Input BNCs.

• Use the **Output Format** knob on the **SmartConversion Menu** to select the video format that the Up/Down Converter is converting the input video signal to. This is the output video signal of the Up/Down Converter.

#### 11. Press HOME to display the Installation Change Confirmation Screen.

**12.** Accept or reject the changes you have made as follows:

- Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
- Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
- Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for assigning Input and Output BNCs to an Up/Down Converter. Next you must set up how the switcher will use the converters, and on which buses.

#### For More Information...

- on video formats, refer to the section "Video Formats" on page Eng 2-31.
- on setting specific video formats for Input BNCs, refer to the section "Configuring Video Inputs" on page Eng 7-4.
- on resetting the video format of all Input BNCs, refer to the section "**Reference Connection and Setup**" on page Eng 4-12.
- on defaulting the video format of all Aux Bus outputs, refer to the section "**Reference Connection and Setup**" on page Eng 4-12.

 $\bigcirc$ 

## **Switcher Setup**

You can specify which MLEs and video feeds that SmartConversion is used on. This allows you to turn SmartConversion on or off for Specific MLE video feeds or lock a specific conversion loop to an MLE or key. The display on the Fade to Black Module can be used to show the number of conversion loops that are still available.

## Assigning Buses to Use SmartConversion

Assigning which buses, or video signals, SmartConversion can convert, allows you to prevent SmartConversion from converting video signals that you want to remain in non-native video format. This will also help to limit the usage of conversion loops for buses that do not need to be converted.

Use the following procedure to assign a bus to use SmartConversion:

- 1. Navigate to the Aux Bus Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Aux Bus.
- 2. Press SmartConversion on the Aux Bus Menu.
- 3. Press Bus Disabling on the SmartConversion Menu.

SmartConvers	iion	44 Back	]   ₩ Tornardi	<ul> <li>Beauty and</li> </ul>	93	Bus: MLE1 Program MLE1 Preset
Switcher Bus MLE1 Program MLE1 Preset MLE1 K1 Video MLE1 K1 Alpha MLE1 K2 Video MLE1 K2 Alpha MLE1 Utility1	Enabled Yes Yes Yes Yes Yes Yes Yes					MLE1 K1 Video
Aux To Converters	Converter Formats			Bus Disabling	Con	verter 🖓 🕬

Bus Disabling Setup — SmartConversion Menu

- **4.** Use the **Bus** knob on the **SmartConversion Menu** to select the Bus or Video Signal that you want to assign the SmartConversion usage to. You can choose between the following for each MLE:
  - MLE X Program Select this option to select whether the Program bus on the selected MLE can use SmartConversion, where "X" represents the number of the MLE.
  - MLE X Preset Select this option to select whether the Preset bus on the selected MLE can use SmartConversion, where "X" represents the number of the MLE.
  - MLE X KEY YV Select this option to select whether the Key Video Signal for the selected MLE can use SmartConversion, where "X" represents the number of the MLE, and "Y" is the number of the keyer.
  - MLE X KEY YA Select this option to select whether the Key Alpha Signal for the selected MLE can use SmartConversion, where "X" represents the number of the MLE, and "Y" is the number of the keyer.

**Note** — If you have disabled Keyer 4 to activate Utility Bus 1 and 2, Key 4V and Key 4A will be replaced with U1 and U2.

- MLE X KEY U1 Select this option to select whether the Utility 1 bus on the selected MLE can use SmartConversion, where "X" represents the number of the MLE.
- MLE X KEY U2 Select this option to select whether the Utility 2 bus on the selected MLE can use SmartConversion, where "X" represents the number of the MLE.
- MLE X Key Y BackV Select this option to select whether the Key Y Backside Video Signal for the selected MLE can use SmartConversion, where "X" represents the number of the MLE, and "Y" is the number of the keyer.
- MLE X Key Y BackA Select this option to select whether the Key 1 Backside Alpha Signal for the selected MLE can use SmartConversion, where "X" represents the number of the MLE, and "Y" is the number of the keyer.
- **Aux Buses** Select this option to select whether a particular Aux Bus can use SmartConversion. Aux Buses assigned to a conversion loop will not appear in the list.

**Note** — If an Aux Bus is assigned to an AuxKey, it is set to **Conversion Enabled** by default, all other Aux Buses are set to **Conversion Disabled** by default.

- 5. Use the **Conversion Enabled** knob on the **SmartConversion Menu** to toggle SmartConversion **On** or **Off**.
  - **On** Select this option to allow the selected bus, or video signal, to use SmartConversion.
  - **Off** Select this option to prevent the selected bus, or video signal, from using SmartConversion.
- 6. Press HOME to display the Installation Change Confirmation Screen.
- 7. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for assigning a bus to use SmartConversion.

## Locking Conversion Loops to Buses

You can lock a specific conversion loop to a bus. This dedicates that Up/Down Converter to the selected bus preventing SmartConversion from using it somewhere else.

Use the following procedure to lock a conversion loop to a bus:

- 1. Navigate to the Aux Bus Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Aux Bus.
- 2. Press SmartConversion on the Aux Bus Menu.





3. Press Converter Locking on the SmartConversion Menu.

SmartConvers	sion	44 Back	]   PP Tormani	Stratik shi (	98	Aux Bus: Bnk1Aux1(1:1)
Converter Entitionation Factorian NOTE: It is recor Refer to Visi	Locked MONE mmended to lock two o on Manual for more de	To Bus	s pair.			Lock To Bus / Pain NONE MLE1 BKGD+PST MLE1 Key1
Aux To Converters	Converter Formats			Bus Disabling	Con	verter winner

Converter Locking Setup — SmartConversion Menu

- **4.** Use the **Aux Bus** knob on the **SmartConversion Menu** to select the conversion loop you want to lock to an MLE bus.
- 5. Use the Lock To Bus/Pair knob on the SmartConversion Menu to select the bus, or bus pair that you want to lock the selected conversion loop to. You can choose between the following for each MLE:
  - **None** Select this option to not lock the conversion loop to a bus.
  - **MLE** *X* **BKGD+PST** Select this option to lock the conversion loop to the **Program** and **Preset** bus of the select MLE, where "*X*" represents the number of the MLE.

**Note** — If you are locking a conversion loop to the **BKGD+PST** bus pair, you should lock **2** conversion loops to the bus pair. One conversion loop for each bus.

- MLE X KEY Y Select this option to lock the conversion loop to the Key bus of the selected MLE, where "X" represents the number of the MLE, and "Y" is the number of the keyer.
- Aux Buses Select this option to lock the conversion loop to an Aux Bus.
- 6. Press HOME to display the Installation Change Confirmation Screen.
- 7. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.
  - Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
  - Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for locking a conversion loop to a bus.

#### Fade to Black Display Mode for Up/Down Converters

The Fade to Black Display Mode sets whether the display on the Fade to Black Module will display the current fade rate, or the number of Up/Down Converters available on the switcher.

Use the following procedure to set up the Fade to Black Display Mode for the switcher as follows:

- 1. Navigate to the **Personality Menus** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Personality.
- 2. Use the Option knob on the Personality Menu 1-2 to select FTB Display.



FTB Display — Personality Menu 1-2

- 3. Use the Value knob on the Personality Menu 1-2 to toggle between SmrtConv or FTB.
  - **SmrtConv** Select this option to have the display on the **Fade to Black Module** show the number of available up/down converters for SmartConversion to use.
  - **FTB** Select this option to have the display on the Fade to Black Module show the transition rate for a Fade to Black transition.

This completes the procedure for setting up the Fade to Black Display Mode.

# Switcher Calibration and Diagnostics

## In This Chapter

This chapter provides information on performing calibration and diagnostic tests on your Vision switcher.

The following topics are discussed in this chapter:

- Switcher Software Version
- Switcher Calibration
- Mapping a Module to a Row
- Fail Indicators Diagnosis
- Communication Status and Errors
- Non-Sync Status
- Control Panel Diagnostic Tools
- Frame Diagnostic Tools
- Video Checksum Custom Controls
- Communication Port Monitor
- Switcher Logs

## **Switcher Software Version**

The Version Information shows the version number and date of the software that is currently running on the control panel and frame.

Use the following procedure to view the Software Version of the control panel and frame:

- 1. Navigate to the **Status Menu** as follows:
  - Press **HOME** ⇒ **More** ⇒ **Status**.
- 2. Press Version Info on the Status Menu.

Status	44 Back	Mit provand	Copy Up	13Swap	
Panel Info	Frame Info	6115 611 100. 608 2000			
Copyright 1998-2009 Ross Video Lin This product is protected by the foll 5,280,346, 5,561,404, 7,034,886, 7	nted All rights reserved wing US Patients: 4,205,346, 3 508,455. This product is prote 7, 1237518, 1127289. Other pat	115,314, cted by the ents pending			

Version Information — Status Menu

This completes the procedure for viewing the switcher information.

#### For More Information...

• on finding the current version of the Vision Operating System, refer to the section "**Panel Boards Menu**" on page Eng 6-14.

## **Switcher Calibration**

Calibration allows you to reset the limits of the faders on the control panel, re-center the positioner with X, Y and Z limits, and align the touchscreen display.

Calibration can also be used to have the LEDs in the buttons of the control panel display in a calibrated, or uncalibrated mode. When the control panel is manufactured, the LEDs for each button are calibrated to a single standard so that all the buttons appear as a consistent color. This color offset is stored in each module.

Use the following procedure to calibrate your switcher:

- 1. Navigate to the ADC Calibration Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ More ⇒ Calibration.

Calibration	44 Back	) (Promant)	93	Led Calibration: No Yes
ADC Touch Screen Calibration				-

Calibration Menu

- **2.** Use the **LED Calibration** knob on the **Calibration Menu** to turn LED calibration on or off.
  - **No** Select this option to not have the LEDs light as normal.
  - **Yes** Select this option to have the LEDs light in an uncalibrated state. Any calibration color offsets are ignored.
- 3. Press ADC Calibration on the Calibration Menu.

ADC Calibra	tion	44 Back	•••===================================	♣ ⊠ay /@	13	
LINK: 8 NODE: 1 ADC: 0 VALUE: 0xt	992F					
				Cancel	Accept	

ADC Calibration Menu



**Operating Tip** — For more information on the Node and Link values for the module you are calibrating, refer to the section "**Module Control Link Backbone**" on page Eng 20-12.

4. Calibrate a Fader as follows:

- Move the fader from one limit to the other and back again. Be sure not to pressure the fader into the stop. Doing so may make it difficult to end a transition, or cause the fader to accidentally start a new transition when it is released.
- **5.** Calibrate the **Positioner** as follows:
  - Move the positioner forwards and backwards along the Y-axis to calibrate the Y limits of the positioner.
  - Move the positioner left and right along the X-axis to calibrate the X limits of the positioner.
  - Twist the positioner clockwise and counter-clockwise to calibrate the Z limits of the positioner.
- 6. Press Accept on the Calibration Menu to accept the new calibration limits.
- **7.** Calibrate the **Touchscreen** as follows:
  - Press **Touch Screen Calibration** on the **Calibration Menu**. The calibration screen is displayed.
  - Follow the on-screen instructions.

This completes the procedure for calibrating your switcher.
# Mapping a Module to a Row

Control Panel Mapping allows you to assign modules to Panel Rows, or control panel rows. This is used to assign a newly installed module to a row of modules on the control panel, or to assign an Auxiliary Control Panel to the switcher.

You can install a single module, or multiple at the same time, depending on how you want to install the modules.

#### For More Information ...

- on installing a module, refer to the section "**Replacing a Control Panel Module**" on page Eng 18-18.
- on assigning a GPI to an Auxiliary Control Panel, refer to the section "Auxiliary Control Panel GPIs" on page Eng 14-11.
- on assigning an external module to an External Link Port, refer to the section "External Panel Modules" on page Eng 9-21.

## **Mapping Multiple Modules**

If you are mapping several modules to a panel row, you can use the Quick Module Configuration to quickly map modules to a row by pressing button on each row in succession.

Use the following procedure to assign a module to a panel row:

- 1. Navigate to the Panel Modules Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ More ⇒ Panel Modules. A warning is displayed, asking you if you want to enter the menu. Press Yes to display the Panel Modules Menu.



**Important** — Do not use the **Remove Unfound Module Cfgs** button on the **Panel Modules Menu** unless instructed to do so by Ross Video Technical Support.



Panel Modules Menu

2. Press Quick Configure on the Panel Modules Menu.

Externa Rows			row. to right, order.	modules on iodules left ules in any	Select all rosspoint m other mod	c		al	Intern Rows
17	s starting a	ittons	e has bu	t modul	rosspoin	Next C	I Row 2.	Interna	
	rt v 8	Start Row 8	Start Row 7	Start Row 6	Start Row 5	Start Row 4	Start Row 3	Start Row 2	Start Row 1

Panel Module Quick Configure Menu

- **3.** Select the panel row that you want to start assigning modules to as follows:
  - Select the type of panel row you want to program. You can choose between the following:
    - Internal Rows Select this option to program a row on the Vision control panel. You can choose between Row 1 and Row 8.
    - External Rows Select this option to program a row on an Auxiliary Control Panel, or other external module, not including the Touchscreen Display. You can choose between Row 1 and Row 16.
- **4.** Press any button on the panel row module that you want to map buttons starting at **1** to. All the buttons on the module will light up.
- **5.** Press any button on the next panel row module that you want to map the next set of buttons to. All the buttons on this module will light up.
- **6.** Continue selecting modules until all the Crosspoint Modules and control modules, including the Transition Module and Memory Module, that you want to assign to the row, have been selected.
- 7. Configure additional rows as needed.
- 8. Press Exit on the Panel Module Quick Configure Menu to exit the menu.

This completes the procedure for assigning a module to a panel row.

## Mapping a Single Module

If you are mapping a single module to a panel row, you can use select the link and node that you installed the module on and assign it to a panel row.

Use the following procedure to assign a module to a panel row:

- 1. Navigate to the **Panel Modules Menu** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ More ⇒ Panel Modules. A warning is displayed, asking you if you want to enter the menu. Press Yes to display the Panel Modules Menu.

 $\land$ 

**Important** — Do not use the **Remove Unfound Module Cfgs** button on the **Panel Modules Menu** unless instructed to do so by Ross Video Technical Support.

2. Use the Link/Node knob on the Panel Modules Menu to select the link and node that the module you want to assign to a row is installed on. You can also press a button on the module to jump to the link and node.



Panel Row & Crosspoint — Panel Modules Menu

- 3. Press Panel Row & Crosspoint on the Panel Modules Menu.
- 4. Use the **Panel Row** knob on the **Panel Modules Menu** to select the panel row that you want to assign the module to. You can select either an internal row (**Row 1** to **Row 8**), or an external row (**Row 1** to **Row 16**).
- 5. Use the **First Crosspoint** knob on the **Panel Modules Menu** to select the number of the first crosspoint button on the module you are setting up. Each Crosspoint Module has 8 buttons, so the first button on module 1 is 1, the first button on module 2 is 9. If the module does not have crosspoint buttons, this knob is gray.

Note — If you are programming an Auxiliary Control Panel, the modules have 16 buttons.

- **6.** Set up a Custom Control module as follows:
  - Use the Link/Node knob on the Panel Modules Menu to select the link and node that the module you want to assign to a row is installed on. You can also press a button on the module to jump to the link and node.
  - Press Custctrl & GPI Group on the Panel Modules Menu.



Custctrl & GPI Group (Custom Control Module) — Panel Modules Menu



**Operating Tip** — The Custom Control module number will follow the numbering of the Crosspoint modules by default.

• Use the **First Custctrl** knob on the **Panel Modules Menu** to select the number of the first custom control button on the module you are setting up. Each custom control module has 8 buttons, so the first button on module 1 is 1, the first button on module 2 is 9. If the module does not have custom control buttons, this knob is gray.

This completes the procedure for assigning a module to a panel row.

## Naming an External Row

Each external row can be given a unique name that appears on the **Assign Bus Maps Menu**, as well as the **Panel Module Quick Configuration Menu**.

Use the following procedure to name an external row:

- 1. Navigate to the External Rows Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Installation ⇒ Aux Bus ⇒ Remote Panels ⇒ External Row Setup.



External Rows Menu

**2.** Use the **External Row** knob on the **External Rows Menu** to select the external row that you want to name.

Clear			Default	Accept New Na	me
<b>F</b>	Space	New Name (MAX 8 ExtRow01	Characters):		Ext. Row Number
Shift Z X C	V B	N M <	<b>&gt;</b> 7 . 7	1	(01)
Caps Lock A S D F	GH	J K	L	, DEL	
Q W E R T	YU	1 0 P			
! 0 * \$ % 1 2 3 4 5	6 <b>6</b> 7	* ( ) 9 0		Backspace	
External Row Names	44 Back	M Terman		193 (contra	

3. Press Rename Row on the External Rows Menu.

External Row Names Menu



**Operating Tip** — Refer to the section "Using the Naming Menus" on page Eng 5-16 for more information on using the **External Row Names Menu** to enter a name.

- 4. Enter the new name for the external row in the New Name field. The name can be no more than 8 characters in length.
- 5. Press Accept New Name on the External Row Names Menu to store the new name.
- 6. Press HOME to display the Installation Change Confirmation Screen.
- 7. Accept or reject the changes you have made as follows:
  - Press **Confirm** to accept the changes and reset all Remote, Peripheral, and Net ports.

- Press **Confirm w/o Reset** to accept the changes without resetting all Remote, Peripheral, and Net ports. Only use this if told to do so by Ross Video Technical Support.
- Press **Cancel** to exit the menus safely, without making any changes. The system returns to the previously stored settings.

This completes the procedure for naming an external row.

# **Fail Indicators Diagnosis**

The touchscreen display has two fail indicators (**Figure 17.1**) that are used to identify a possible problem with either a power supply or fan in either the control panel or frame.



Figure 17.1 Panel and Frame Power Fail Indicators

When either of these indicators is lit, the switcher has detected a possible problem with either the frame or control panel. With either of these fail indicators, pressing the lit indicator displays the **Status Menus**.

## **Complete Status**

The Complete Status shows the current operational status of the fans and power supplies in the frame and control panel, as well as the temperature and communications status of the panel.

Use the following procedure to view the Complete Status of the control panel and frame:

- 1. Navigate to the Status Menu as follows:
  - Press **HOME** ⇒ **More** ⇒ **Status**.
- 2. Press Complete Status on the Status Menu.

Status	44 Back	- Promane	Copy Up	33 Swap	
Frame Present:	Frame	s present and con	nmunicating		
C Frame Fans:	Unknov	n # of fans failed	, inlet temperatu	re O'C	
Frame Power Supplies:	ок				Use knob 2 to
😑 Frame Graphics Buffer FPGA tem	perature: 47°C				scroll through
A Hard Drive Status:	Hard Dr	ive has 5.M.A.R.T	warnings	9	the list.
😑 Panel Fans:	1 fans i	unning property		- 11	
Panel Power Supplies:	1 suppl	ies running prope	rty	- 11	
Panel PCH Temperature:	38°C			- 11	
👼 Banal Modula Discourse	Modula	diernuant doae n	nt match installat	inn 💌	
Marries Complete		Non Cune	1	1	1 1 1
info Status	Warnings	Status	TxRx Stat	us 🚯 TxR	x Errors

Complete Status — Status Menu

**3.** Refer to the section "**Status Components and Conditions**" on page Eng 17-11 for information on the status conditions.

This completes the procedure for viewing the complete status information.

## Warnings

The Warnings list shows all the warnings or errors that have been generated by the switcher. This can include fan or power supply failures, or communications problems.

Use the following procedure to view the Warnings generated by the control panel and frame:

- 1. Navigate to the **Status Menu** as follows:
  - Press HOME ⇒ More ⇒ Status.
- 2. Press Warnings on the Status Menu.

atus		44 Back	PP Coman	Copy Up	13 Swap	J
<ul> <li>Frame Fans:</li> <li>Hard Drive Sta</li> <li>Panel Module t</li> </ul>	Unknown tus: Hard Driv Discovery: Module d	ve has 5.M.A.R.T. iscovery does no	, inlet temperatum warnings at match installatio	e 0'C	Ĩ	Use knob 2 to scroll through the list.
Version Info	Complete Status	Warnings	Non-Sync     Status	TxRx Stat	us 🗗 TxP	tx Errors

Warnings — Status Menu

**3.** Refer to the section "**Status Components and Conditions**" on page Eng 17-11 for information on the status conditions.

This completes the procedure for viewing the warnings generated by the control panel and frame.

## **Status Components and Conditions**

There are a number of components and conditions that the switcher monitors and reports on. These items are as follows:

**S** 

**Note** — If a board, card, or power supply is not present in the system, it is not shown on the *list*.

- Frame Present This item indicates whether a frame has been detected and is communicating with the Vision control panel. If the message, **Unsupported frame board configuration.** is displayed, one or more of the boards in the frame is in the wrong slot. Refer to the section "**Removing and Installing Frame Boards**" on page Eng 4-18 for information on the supported board locations for your frame.
- **Reference** This item indicates whether the current input reference format is properly locked.
- Frame Fans This item indicates whether the cooling fans in the frame are operating normally, or that a number of fans have failed. Refer to the section "Frame Fan Failure" on page Eng 18-8 for more information on replacing a fan.

- Frame Power Supplies This item indicates whether there are enough power supplies in the frame, that they are operating normally, or that one, or more, of them has failed. Refer to the section "Frame Power Supply Failure" on page Eng 18-6 for more information on replacing a power supply.
- Frame Graphics Buffer FPGA Temperature This item indicates whether the graphics buffer FPGA is operating in the normal temperature range.
- **Hard Drive Status** This item indicates whether the hard drive on the frame CPU Board is reporting any Self-Monitoring, Analysis, and Reporting Technology (S.M.A.R.T.) warnings or has experiences a complete failure. If a warning or failure is displayed, contact Ross Video Technical Support for information on diagnosing the warning or replacing your hard drive.
- **Panel Fans** This item indicates whether the cooling fans in the control panel are operating normally, or that one, or more, of them has failed. The **Power Supply Modules** that contain the cooling fans are closed units and not field serviceable. If a fan needs to be replaced, the entire module is replaced. Refer to the section "**Control Panel Power Supply Failure**" on page Eng 18-2 for more information on replacing a fan.
- **Panel Power Supplies** This item indicates whether the power supplies in the Vision control panel are operating normally, or that one, or more, of them has failed. Refer to the section "**Control Panel Power Supply**" on page Eng 18-9 for more information on replacing a power supply.
- **Panel PCH Temperature** This item indicates whether the Panel Communications Hub is operating in a safe temperature range.
- **Panel Module Discovery** This item indicates whether or not all the modules on the control panel have been successfully discovered and set up. If a module is not properly set up, or is not present, a warning is displayed. Refer to the section "**Replacing a Control Panel Module**" on page Eng 18-18 for more information on setting up a control panel module.
- **PMC Status** This item indicates whether Panel Module Controller are running the current version of software. Refer to the section "**Upgrading PMCs**" on page Eng 18-21 for information on updating the software on a PMC.
- **Panel and Frame Software Versions** This item indicates if the software version on the control panel is not the same as the software version on the frame. An upgrade must to be performed so that both the frame and the control panel are on the same software version. Refer to the section "**Software Upgrade**" on page Eng 6-3 for more information on performing a software upgrade.
- **Panel OS Version** This item indicates if the current version of the Operating System running on the control panel CPU Module is up to date.
- **SBC CPU Temperature** This item indicates whether the CPU in the Control Panel CPU Module is operating in the normal temperature range.
- **SBC Motherboard Temperature** This item indicates whether the motherboard in the Control Panel CPU Module is operating in the normal temperature range.
- **Stuck Buttons** This item indicates whether there are any stuck buttons on the Vision control panel. Refer to the section "**Stuck Button Test**" on page Eng 17-19 for more information on stuck buttons.
- Vid Card Temperatures This item indicates whether the Video Processor Board in the frame is operating in the normal temperature range.

#### **Status Icons**

There are **3** types of status icons that indicate the current status of each component or condition that the switcher is monitoring. These icons are as follows:



• **Good** — This icon indicates that a component or condition is operating properly.

• **Warning** — This icon indicates that a condition is outside of the normal operating parameters. For example, the temperature inside the panel may be slightly above or below the safe operating temperature.

• **Failure** — This icon indicates a major problem with a component or condition that the switcher is monitoring. For example, the temperature inside the control panel could be dangerously above or below the safe operating temperature. The fail icon will also indicate control panel modules that are not properly assigned to MLEs.

# **Communication Status and Errors**

The Vision switcher provides a number of status and error detection menus that allow you to troubleshoot and diagnose communication problems.

## **Control Panel Communication Status**

The **TX/RX Status Menu** allows you to view the current communication status of the communication ports on the control panel.

Use the following method to view the communication status of the ports on the control panel:

• Press HOME ⇒ More ⇒ Status ⇒ TxRx Status.

FX/RX S	Status	Menu	1		-	44 Back		Prenae		Copyi	qt	33 Swap	
The ligh	ts on th	is men	ı will ind	licate w	hen dat	a is bein	g transi	nitted o	r receive	ed from	each Pa	mei Port	
	81	R2	Н3	84	RS	R6	R7	P.8	EPL2	EPL3	EPL4	Panel / Frame	
тх	۲	۲	۲	۰	۰	۲	۲	۰	۲	۲	۹	•	
RX	۲	۲	۹	۲	۲	۲	۲	۲	۲	۲	۲	۲	
													-

TX/RX Stats Menu

• The **TX/RX Status Menu** shows the current status of the Remote ports (**R1-R8**), the External Link ports (**ELP2-ELP4**), and the communication between the control panel and the frame (**Panel/Frame**).

This completes the method for viewing the status of the communication ports on the control panel.

## **Serial Communication Errors**

The **TxRx Errors Menu** shows all the errors that have been reported for the serial communications from the frame and the control panel. The errors can be shown for all the serial communications ports on the control panel and frame, or for a specific port on either.

Use the following procedure to view the Warnings generated by the control panel and frame:

- 1. Navigate to the **RxTx Errors Menu** as follows:
  - Press HOME ⇒ More ⇒ Status ⇒ TxRx Errors.

TxRx Errors	44 Back	M Tennand	Copy Up	13 Swap	Panel
Total Panel Errors Bad byte counts: 0 Bad checksums: 0 Parity errors: 0 Framing errors: 0 Over runs: 0 NACKS received: 0 Other errors: 0	Communication Com Total Frame Errors Bad byte counts: Bad checksums: Parity errors: Framing errors: Over runs: NACKs received: Other errors:	Port Stats 0 0 0 0 0 0 0			Total Errors ExtLnk 2 (L2) ExtLnk 3 (L3) Frame Total Errors FRM2PAN (FP) PERIPH 1 (P1)
Refresh Frr Stats Reset Cou	Int				-

TxRx Errors Menu

**Operating Tip** — You can reset the error count by pressing the **Reset Count** button on the **TxRx Errors Menu**. This will clear all the error counters on the control panel and frame.

- 2. Use the **Panel** knob on the **TxRx Errors Menu** to select the serial communications port on the control panel that you want to view the errors for. You can choose between the following:
  - **Total Errors** Select this option to view the total number of errors for all the serial communication ports on the control panel.
  - **AUXPAN** X (AX) Select this option to view the errors for the selected Auxiliary serial communications port, where X represents the number of the port.
  - **REMOTE** *X* (**RX**) Select this option to view the errors for the selected Remote serial communications port, where *X* represents the number of the port.
- **3.** Use the **Frame** knob on the **TxRx Errors Menu** to select the serial communications port on the frame that you want to view the errors for. You can choose between the following:
  - **Total Errors** Select this option to view the total number of errors for all the serial communication ports on the frame.
  - FRM2PAN (FP) Select this option to view the errors for the PANEL port.
  - **PERIPH** X (PX) Select this option to view the errors for the selected Peripheral serial communications port, where X represents the number of the port.

This completes the procedure for viewing the warnings generated by the control panel and frame. If you want more information on the serial communication errors that have occurred, you can view the error statistics.

# **Non-Sync Status**

The **Non-Sync Status Menu** allows you to check if a video signal selected on a crosspoint bus, or the video outputs of the switcher, is synchronized with the switcher reference format. The Non-Sync indicators serve as a warning only, indicating that the timing of the input should be fixed at the source. If the source is non-synchronous with the switcher reference format, cuts, dissolves and other effects can still be performed, but the source is shifted vertically.

If a non-synchronous source is selected on a crosspoint bus, and the non-sync detection feature is turned on, the crosspoint button flashes, indicating that the source is mis-timed.

Use the following procedure to view the Non-Sync Status Menu:

**1.** Press HOME  $\Rightarrow$  More  $\Rightarrow$  Status  $\Rightarrow$  Non-Sync Status  $\Rightarrow$  MLEs.

Non-Sync St	tatus M	enu	E	44 Back	)   Marena	-erei 1 😰	Сору Up	33 Swap	
Program Preset Key 1 V/A Key 2 V/A Key 3 V/A Key 4 V/A Utility 1/2	MLE 1 0 0/0 0/0 0/0 0/0 0/0	MLE 2 0 0/0 0/0 0/0 0/0 0/0	MLE 3 0 0/0 0/0 0/0 0/0 0/0	MLE 4 0 0/0 0/0 0/0 0/0 0/0	MLE 5 0 0/0 0/0 0/0 0/0 0/0	MLE 6 0 0/0 0/0 0/0 0/0 0/0	MLE 7	MLE 0 000 000 000	
Legend SyncM Non Sy	le ync								
MLES		utput bards							<b>4</b> 100

Non-Sync Status Menu (4-Keyer, QMD-X shown)

- **2.** A Green or Yellow indicator is shown for each bus on each MLE. As you select different sources on each bus, the indicator updates, showing if the source is synchronized or not.
  - **Green** A green indicator shows that the source selected on the corresponding bus and MLE is synchronized with the switcher reference.
  - **Yellow** A yellow indicator shows that the source selected on the corresponding bus and MLE is not synchronized with the switcher reference. This source should be synchronized to the switcher reference from the source.
- 3. Press Output Boards on the Non-Sync Status Menu.

Non-Sync Status	Menu	44 Back	WTormann QC	opy Up	13 Swap	
	Output Board I	Output Board J	Output Board K			
BNC 1/9	010	00	0/0			
BNC 2/10	010	00	010			
BNC 3/11	010	00	00			
BNC 4/12	Q1Q	00	00			
BNC 5/13	010	00	010			
BNC 6/14	010	00	@/@			
BNC 7/15	010	00	0/0	Legend	È	
BNC 8/16	0/0	00	0/0	Sy No	nc on Sync	
MLES	Output					-

Non-Sync Status Menu (QMD-X shown)

- **4.** A Green or Yellow indicator is shown for each output BNC on each Video Output Board installed in the frame.
  - **Green** A green indicator shows that the video being output on the corresponding output BNC is synchronized with the switcher reference.

• **Yellow** — A yellow indicator shows that the video being output on the corresponding BNC is not synchronized with the switcher reference.

This completes the procedure for viewing the Non-Sync Status Menu.

#### For More Information...

• on turning Non-Sync detection on or off, refer to the section "Non-Sync Detection" on page Eng 7-9.

# **Control Panel Diagnostic Tools**

The Vision control panel supports a number of diagnostic tests that can be used to identify issues with your switcher.

These tests are designed to be used by Ross Video Technical Support and other qualified Ross Video personnel.

The control panel diagnostic tests are grouped into the following categories:

- Module Tests
- Panel Communications Hub Tests
- Control Panel SBC Test
- Touchscreen Tests
- Burn Mode

## **Module Tests**

The Module Tests allow you to test the functionality of the knobs, buttons, faders, and positioner of the switcher, as well as test the color of the buttons. Additional tests are provided for the control panel displays and the memory for each module.

#### **Button Color Test**

The button color test allows you to test the LEDs in each button on a module. Each Button LED on the module illuminates, and then transition to the next LED, cycling through the different colors. The brightness of the LEDs is also be cycled between max and min brightness.

Use the following procedure to perform a button color test:

- 1. Navigate to the **Module Test Menu** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Panel Diagnostics ⇒ Module Test.
- 2. Press LED Test on the Module Test Menu to enter Button Color Display Mode.
- **3.** Press any button on the control panel module you want to test.
- **4.** Confirm that all buttons on the module are changing at the same time, and that the colors and brightness are consistent.

This completes the procedure for performing a button color test.

#### **Button Function Test**

The button function test allows you to test if the buttons on the control panel are working properly or not. This test requires you to press the button that you want to test and the switcher reports where and what that button is.

Use the following procedure to perform a button function test:

- 1. Navigate to the Module Test Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Panel Diagnostics ⇒ Module Test.
- 2. Press **Device Test** on the **Module Test Menu**.
- **3.** Press the button that you want to test. The **Button Test Information** is displayed with the name, or function, of the button is listed on the menu, as well as the module and hardware location of the button.

Device Test	.,	44 Back	•••	a conver	13-000	
Double press	Exit (F6) to quit					
LINK NODE BUTTON LAST ACTION: MODULE: LABEL:	#08 #02 #10 Button Up MLE Memory 5					
	] [				Ext	- <b>(</b>

Button Test Information - Device Test Menu

- **4.** Confirm that the button you pressed is shown on the menu.
- 5. Double-press Exit on the Device Test Menu to stop the test.

This completes the procedure for performing a button function test.

### **Stuck Button Test**

The stuck button test allows you to identify any and all buttons that the switcher reports as being stuck. A button is considered to be stuck when it is held for more than **30** seconds.

Use the following procedure to perform a stuck button test:

- 1. Navigate to the Module Test Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Panel Diagnostics ⇒ Module Test.
- 2. Press Stuck Buttons on the Module Test Menu to display a list of any stuck buttons.

Module Test	44 Back	PP Forward	4 (13	
Stuck buttons: None detected				
LED Test     Device	e Test 🕘 Display Test	Knob Test	Memory Test	Stuck Buttons

Stuck Button — Module Test Menu

**3.** Any buttons that the switcher reports as being stuck is listed on the menu. The button is identified by the **Module** it is on, as well as the **Label** of the button.

This completes the procedure for performing a stuck button test.

#### **Fader Test**

The fader test allows you to test the functionality of the faders on the control panel. This test requires you to move the fader that you want to test from one limit to the other. The switcher reports where that fader is, and whether the fader has been moved from one limit to the other.

Use the following procedure to perform a fader test:

- 1. Navigate to the Module Test Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Panel Diagnostics ⇒ Module Test.
- 2. Press Device Test on the Module Test Menu.
- **3.** Move the fader that you want to test. The **Fader Test** is displayed with an illustration of the fader, and the transition indicators on the **Transition Module** light. The module and hardware location of the fader are also be displayed on the menu.

Device Te	st	44 Back	P Forward	<b>a</b> (2017-00)	13	
Double pres LINK NODE ADC MODULE: VALUE:	es Exit (F6) to quit #07 #02 #0 MLE Trans 2 Keyer OxOFFF					
					Ext	- Al

Fader Test — Device Test Menu

- 4. Confirm that the fader you moved is shown on the menu.
- 5. Double-press Exit on the Device Test Menu to stop the test.

This completes the procedure for performing a fader test.

#### **Positioner Test**

The positioner test allows you to test the functionality of the positioner on the control panel. This test requires you to move the positioner left and right, as well as twist it. The switcher reports where that positioner is, and how it is being moved.

Use the following procedure to perform a positioner test:

- 1. Navigate to the Module Test Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Panel Diagnostics ⇒ Module Test.
- 2. Press Device Test on the Module Test Menu.
- **3.** Move the positioner **forward** and **backward** to display the **Positioner Test**. An illustration of the positioner appears on the menu. As you move the positioner, the **Y** value for the positioner is displayed on the menu.

Device Te	st	44 Back	PP Forward	<b>3</b> (2017)	93/00/00	
Double pres	is Exit (F6) to quit					
UNK NODE ADC MODULE: X: Y: Z:	#06 #04 # 1 Positioner 0x0000 0x0000 0x7FFF	C	)			
					Ext	4

Fader Test — Device Test Menu

- **4.** Move the positioner **left** and **right**. As you move the positioner, the **X** value for the positioner is displayed on the menu.
- 5. Twist the positioner clockwise and counter-clockwise. As you twist the positioner, the Z value for the positioner is displayed on the menu.
- 6. Double-press Exit on the Device Test Menu to stop the test.

This completes the procedure for performing a positioner test.

#### **Control Panel Display Test**

The control panel display test allows you to test the color pixel functionality of all the displays and mnemonics on the control panel. Each display and mnemonic on the control panel is illuminate, and then transitions to the next color, cycling through the different colors. The brightness of the displays and mnemonics is also cycled between max and min brightness.

Use the following procedure to perform a control panel display test:

- 1. Navigate to the Module Test Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Panel Diagnostics ⇒ Module Test.
- 2. Press Display Test on the Module Test Menu to enter Display Test Mode.
- **3.** Confirm that all displays and mnemonics are changing at the same time, and that the colors and brightness are consistent.

This completes the procedure for performing a control panel display test.

#### **Knob Test**

The knob test allows you to test the functionality of the knobs on the touchscreen display of the control panel. The Vision control panel supports either haptic knobs, with force feedback on the knob, or optical knobs, without feedback on the knob.

Use the following procedure to perform a knob test:

- 1. Navigate to the Module Test Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Panel Diagnostics ⇒ Module Test.
- **2.** Press **Knob Test** on the **Module Test Menu**. In the center of the menu is a position graph for the knob. As you rotate the knob, the slider moves along the position graph.

**Note** — If your Vision control panel uses **optical** knobs, only the **Change Only** button is available. All other knob tests are unavailable.

Knob Test		44 Back	M Tormert	A copy op 11	STORE	
Knob Test						
Link: 1 Node: 1 Knob: 1 Change: 0	-	ĸ	nob Position			
Position: 0		K	nob Button Up			
	Wran in	Banne with	Ranne with	Detects	Ballistics	

Change Only — Knob Test Menu



**Operating Tip** — Select **Change Only** on the **Knob Test Menu** to show only the changes in the knob position. Any range or boundary information is ignored. Select **Wrap in Range** on the **Knob Test Menu** to show the range for the knob. When the knob reaches the end of the range, it wraps around on the position graph.

- **3.** Test the **Boundaries** functionality of the knob as follows:
  - Press Range with Boundaries on the Knob Test Menu.
  - Rotate the knob you want to test. The knob should become increasingly difficult to turn at the end of the position graph.
- 4. Test the **Barrier** functionality of the knob as follows:
  - Press Range with Barriers on the Knob Test Menu.
  - Rotate the knob you want to test. The knob should stop at the end of the position graph.
- 5. Test the Knob Button as follows:
  - Press the knob you want to test. The text under the knob should change to **Knob Button Down** while the knob button is being pressed.

This completes the procedure for performing a knob test.

#### **Module Memory Test**

The module memory test allows you to test the integrity of the button and mnemonic memory used in a module.

Use the following procedure to perform a module memory test:

- 1. Navigate to the Module Test Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Panel Diagnostics ⇒ Module Test.
- 2. Press **Memory Test** on the **Module Test Menu**. The switcher tests each module on the control panel, including the touchscreen display, and report any errors on the menu.

This completes the procedure for performing a module memory test.

## **Panel Communications Hub Tests**

The Panel Communications Hub (PCH) Tests allow you to test the functionality of the PCH communication links with the various components of the switcher. Some of these tests require the use of a loopback adapter on the communications port.

#### **PCH Transmit/Receive Test**

The PCH Tx/Rx test allows you to test the various serial communications ports on the control panel. This test helps to diagnose communication problems with external devices that you may be having on a particular serial communications port on the control panel.

These do not include the ports on the Control Panel CPU. Refer to the section "**Control Panel SBC Test**" on page Eng 17-25 for more information on testing the Control Panel CPU ports.

Use the following procedure to perform a control panel PCH Tx/Rx test:

- 1. Navigate to the Panel Communications Hub Test Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Panel Diagnostics ⇒ PCH Test.
- 2. Press TX/RX Test on the PCH Test Menu.



Panel TX/RX Test Menu

- **3.** Connect a loopback adapter to the port that you want to test.
- **4.** Use the **Com Port** knob on the **Panel TX/RX Test Menu** to select the serial communications port on the frame you want to test. You can choose between the following:
  - AUXPAN X (AX) Select this option to test one of the Aux ports on the control panel, where X represents the port number.
  - **REMOTE X (RX)** Select this option to test one of the **Remote** ports on the control panel, where **X** represents the port number.

**Operating Tip** — If you want to monitor the communications on one of the communications ports, you can select **Monitor** on the **Panel CPU TX/RX Test Menu** to view the communications on that port. Refer to the section "**Communication Port Monitor**" on page Eng 17-37 for more information on using the Communications Port Monitor.

5. Use the **Mode** knob on the **Panel TX/RX Test Menu** to select the transmission standard you want to use to test the selected port. You can choose between the following:

**S** 

**Note** — The **External Link** port on the Vision control panel only support the RS-422 (TIA/EIA-422) transmission standard.

- **RS-422** Select this option to test the selected serial communications port using the RS-244 (TIA/EIA-422) transmission standard.
- **RS-422 Null** Select this option to test the selected serial communications port using the RS-422 (TIA/EIA-422) transmission standard. This option changes the signals on the pinouts of the port for use with a null modem cable.
- **RS-232** Select this option to test the selected serial communications port using the RS-232 (TIA/EIA-232) transmission standard.
- **6.** Press **Test** on the **Panel TX/RX Test Menu** to run the test on the selected serial communications port. The outcome of the test is reported on the menu as Passed or Failed.

This completes the procedure for performing a control panel PCH Tx/Rx test.

#### **LVDS Test**

The Low Voltage Differential Signalling (LVDS) test allows you to test the various communications between the **Panel Communications Hub** (**PCH**) and all the **Panel Module Controllers** (**PMC**) installed on the switcher. This test includes both internal and external modules.

Use the following procedure to perform an LVDS test:

- 1. Navigate to the Panel Communications Hub Test Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Panel Diagnostics ⇒ PCH Test.
- 2. Press LVDS Test on the PCH Test Menu.
- **3.** Test the internal LVDS links as follows:
  - Toggle LVDS Links on the LVDS Test Menu to Intern display the Internal LVDS Test. The switcher tests the integrity of all the communications connections between the PCH and each PMC.

LVDS Test		44 Back DD F	orward the Drawnon	13	
Link 5	Link 6	Link 7	Link 8	Link 9	
+ 0 Modules	+ 4 Modules	+ 3 Modules	+ 3 Modules	+ 0 Modules	
Link 10	Link 11	Link 12	Link 13	Link 14	
+ 0 Modules	+ 0 Modules	+ 4 Modules	+ 4 Modules	+ 4 Modules	
LVDS Links	Use Dongles Yes/No			Run Test	

Internal LVDS Test — LVDS Test Menu

- Confirm that all the modules that are installed on your control panel pass. If you want to test LVDS links that are not connected to a PMC, you must use a loopback adapter.
- **4.** Test the external LVDS links as follows:
  - Toggle LVDS Links on the LVDS Test Menu to Extern display the External LVDS Test Menu. The switcher tests the integrity of all the communications connections between the PCH and each external PMC.

LVDS Test Link 1 + 1 Modules	Lin + 0	44 Back k 2 Modules	Unk 3 + 0 Modules	13 Link 4 + 0 Modules	
LVDS Uniks	Use Dongles			Run	्रि

External — LVDS Test Menu

• Confirm that all the external modules that are installed on your control panel pass. If you want to test LVDS links that are not connected to a PMC, you must use a loopback adapter.

This completes the procedure for performing an LVDS test.

#### For More Information...

• on the LVDS Backbone, refer to the section "Module Control Link Backbone" on page Eng 20-12.

## **Tally Test**

The tally test allows you to test the standard parallel tally system of the switcher. A Tally Test Box is required to ensure that the tally relays are operating properly. The number of tallies you have available to test depends on whether you have the Extended Tallies option installed.

Use the following procedure to perform a tally test:

- 1. Navigate to the Panel Communications Hub Test Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Panel Diagnostics ⇒ PCH Test.
- 2. Press Tally Test on the PCH Test Menu.

Tally Test		44 Back	P Forward	<b>4</b> (Set 1/4)	93	
Current it taily A	II Off					
Prev	Next	All On	All Off			41027

Tally Test Menu

- **3.** Test your Tallies as follows:
  - Press **Prev** on the **Tally Test Menu** to select and test the previous tally.
  - Press Next on the Tally Test Menu to select and test the next tally.
  - Press All On on the Tally Test Menu to turn all tallies on.
  - Press All Off on the Tally Test Menu to turn all tallies off.

This completes the procedure for performing a tally test.

#### **PCI Bridge Test**

The Peripheral Component Interconnect (PCI) Bridge test allows you to test the PCI Bridge that is used to pass information between the Control Panel CPU and the PCH.

Use the following procedure to perform a PCI Bridge test:

- 1. Navigate to the Panel Communications Hub Test Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Panel Diagnostics ⇒ PCH Test.
- 2. Press **PCI Test** on the **Panel Communications Hub Test Menu**. The switcher will test the PCI Bridge and report any errors on the menu.

This completes the procedure for performing a PCI Bridge test. The outcome of the test is reported on the menu as Passed or Failed.

## **Control Panel SBC Test**

The Control Panel Single Board Computer (SBC) Tests allow you to test the functionality of the external ports on the Control Panel SBC. Some of these tests require the use of the a loopback adapter on the communications port.

### **Control Panel SBC Transmit/Receive Test**

The Control Panel SBC Tx/Rx Test allows you to test the various communications ports on the control panel SBC.

Use the following procedure to perform a control panel SBC Tx/Rx test:

- 1. Navigate to the **SBC Test Menu** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Panel Diagnostics ⇒ SBC Test.
- 2. Press TX/RX Test on the SBC Test Menu.



SBC TX/RX Test Menu

- **3.** Connect a loopback adapter to the port that you want to test.
- 4. Use the Com Port knob on the Panel SBC TX/RX Test Menu to select the serial communications port on the control panel you want to test. You can choose between the following:
  - **Com 1** Select this option to test the **Serial 1** port on the control panel.
  - **Com 2** Select this option to test the **Serial 2** port on the control panel.
  - **Parallel** Select this option to test the **Parallel 1** port on the control panel.
- 5. Press **Test** on the **SBC TX/RX Test Menu** to run the test on the selected communications port.

This completes the procedure for performing a control panel SBC Tx/Rx test. The outcome of the test is reported on the menu as Passed or Failed.

## **Touchscreen Tests**

The Touchscreen tests allow you to test the functionality and performance of the touchscreen display. These tests include how well the touchscreen displays content, and if the touch sensor is properly calibrated.

#### **Pattern Test**

The pattern test allows you to visually check the performance of the touchscreen as it cycles through a number of patterns and colors.

Use the following procedure to perform a Pattern test:

- 1. Navigate to the **Touchscreen Test Menu** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Panel Diagnostics ⇒ Touch Screen.
- **2.** Press **Test Pattern** on the **Touch Screen Menu**. The touchscreen cycles through a number of test patterns of different colors.

- **3.** Confirm that the touchscreen is displaying the pattern correctly, and that the colors and brightness are consistent.
- **4.** Tap the touchscreen anywhere to stop the test.

This completes the procedure for performing a Pattern test.

#### **Draw Test**

The Draw Test allows you to visually check the functionality of the touchscreen by having it feedback the location of where you touch with an X on the screen.

Use the following procedure to perform a Draw test:

- 1. Navigate to the Touchscreen Test Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Panel Diagnostics ⇒ Touch Screen.
- **2.** Press **Draw Test** on the **Touch Screen Menu**. The touchscreen goes blank for the duration of the test.
- **3.** Tap the touchscreen to test it. A red **X** will appear where you start. Trace the yellow line from the red **X** to the blue **O**.
- 4. Press Quit, or press Esc on the keyboard, to stop the test.

This completes the procedure for performing a Draw test.

## **Burn Mode**

The burn mode performs a number of tests on the control panel to ensure that all internal memory and communications ports are operating properly. To ensure that all external communications ports are operating properly, a loopback adapter must be installed on each port.

Use the following procedure to put the control panel in burn mode:

- 1. Navigate to the **Burn Mode Menu** as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Panel Diagnostics ⇒ Burn Mode.



Burn Mode Menu 1-2

Burn Mode (2	-2)	44 Back	•••	\$ 1000 Viti	13-000	
Test: Stopped Component: LVDS	5 Test					
Component	Status		_		6	
UVDS Link 1	NOT TESTED YET					
U LVD5 Link 2	NOT TESTED YET				U	Use knob to scrol
U LVDS Link 3	NOT TESTED YET					856
UVDS Link 4	NOT TESTED YET					
UVDS Link 5	NOT TESTED YET					
UVD5 Link 6	NOT TESTED YET					
UVDS Link 7	NOT TESTED YET					
LVDS Dongles Yes/No	RS422 Dongles Yes/No					AN More

Burn Mode Menu 2-2

- **2.** Set the dongle usage as follows:
  - LVDS Ports Toggle the LVDS Dongle to Yes on the Burn Mode Menu 2-2 if you have connected a loop back dongle to the LVDS ports, including the Aux ports, that you want to test.
  - Serial Ports Toggle the **RS422 Dongle** to **Yes** on the **Burn Mode Menu 2-2** if you have connected a loop back dongle to the serial ports, including the Remote ports, that you want to test.

**Operating Tip** — The **View Summary** and **View Log** options allow you to view the outcome of the test on the menu. The Log can then be saved to a USB flash drive by pressing **Save Log** to USB.

- **3.** Press **Start Test** on the **Burn Mode Menu 1-2** to start the test. The switcher cycles through the LED tests, Display and Mnemonics tests, LVDS tests, Memory tests, and all the Tx/Rx tests for the control panel. The tests continues until stopped.
- 4. Press Stop Test on the Burn Mode Menu to stop the test.

This completes the procedure for putting the control panel into burn mode.

# **Frame Diagnostic Tools**

The QMD/X and MD/X frames support a number of diagnostic tests that can be used to identify issues with your switcher. Some tests require a loopback adapter, or other external device, to confirm the diagnostics outcome.

These tests are designed to be used by Ross Video Technical Support and other qualified Ross Video personnel.

In a MultiPanel configuration, only the Master Panel can access the Frame Diagnostics Menu.

## Frame Transmit/Receive Test

The frame Tx/Rx test allows you to test the various serial communications ports on the frame. This helps to diagnose communications problems with external devices that you may be having on a particular serial communications port on the frame.

Use the following procedure to perform a frame Tx/Rx test:

- 1. Navigate to the Frame TX/RX Test Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Frame Diagnostics ⇒ TX/RX Test.

Frame TX/RX Test	44 Back	₩ forward .		11	Com Port. FIM29AN (FP) PERP 1 (P1) PERP 2 (P2) PERP 3 (P3) PERP 4 (P4)
		<b>4</b> (1999)	Loop Yes/No	Т	est 🖓

Frame TX/RX Test Menu

**2.** Use the **Com Port** knob on the **Frame TX/RX Test Menu** to select the serial communications port on the frame you want to test.

**Operating Tip** — You can have the test run continuously by toggling **Loop** to **On**, on the **Frame TX/RX Test Menu**. When the test reaches the end, it starts over from the beginning until **Loop** is toggled to **Off**.

**3.** Press **Test** on the **Frame TX/RX Test Menu** to run the test on the selected serial communications port.



**Operating Tip** — If you want to monitor the communications on one of the communications ports, you can select **Monitor** on the **Frame TX/RX Test Menu** to view the communications on that port. Refer to the section "**Communication Port Monitor**" on page Eng 17-37 for more information on using the Communications Port Monitor.

This completes the procedure for performing a frame Tx/Rx test.

## **GPI Test**

The GPI test allows you to test the functionality of each GPI input and output on the switcher. A graphical representation of each GPI indicates whether a particular GPI is on or off. Refer to the section "**Standard GPI Setup**" on page Eng 12-9 for more information on setting up and using GPIs.

Use the following procedure to perform a GPI test:

- 1. Navigate to the GPI Test Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Frame Diagnostics ⇒ GPI Test.



GPI Test Menu

- **2.** Test your GPIs as follows:
  - Press **Prev** on the **GPI Test Menu** to select and test the previous GPI input or output.
  - Press Next on the GPI Test Menu to select and test the next GPI input or output.
  - Press All On on the GPI Test Menu to turn all GPI inputs and outputs on.
  - Press All Off on the GPI Test Menu to turn all GPI inputs and outputs off.

This completes the procedure for performing a GPI test.

## **LEDs Test**

The LEDs test allows you to confirm the functionality of the diagnostic LEDs on the frame CPU Board. In order to complete this test you need to access the internal boards of the frame.



**Note** — You must remove the front door of the frame to perform this test. Refer to the section "**Opening and Closing the Frame Door**" on page Eng 3-3 for more information on removing and installing the frame door.

Use the following procedure to perform an LEDs test:

- 1. Navigate to the Frame LEDs Test Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Frame Diagnostics ⇒ LEDs Test.
- **2.** Check the LEDs on the frame.
- 3. Press UP ONE to stop the test and display the Frame Diagnostics Menu.

This completes the procedure for performing an LEDs test.

## **DIP Switch Test**

The DIP test allows you to verify the current settings of the DIP Switch on the Frame CPU Board (**4800A-001**). To confirm this test, you must remove the Frame CPU Board to verify the setting of the DIP Switch. Contact Ross Video Technical Support before attempting to change any DIP switch setting on the Frame CPU Board. Refer to the section "**Frame CPU Board DIP Switch**" on page Eng 20-11 for more information on the Frame CPU Board and the DIP Switch.

Use the following procedure to perform a DIP test:

- 1. Navigate to the Frame DIP Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Frame Diagnostics ⇒ DIP Test.



Frame DIP Test Menu

This completes the procedure for performing a DIP test.

## **Graphics Buffer Test**

The GfxBuffDDR test allows you to test the performance of the graphics buffer RAM. The test verifies both read and write functionality of the graphics buffer.

Use the following procedure to perform a graphics buffer test:

- 1. Navigate to the Frame GfxBufDDR Test Menu as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ Frame Diagnostics ⇒ GfxBuffDDR Test.

Frame GfxBu	fDDR Test	44 Back	PP Forward	<b>4</b> COUVE	93	
Test graphics b	uffer ddr meimory on Fram	ie.				

Frame GfxBuffDDR Test Menu

- 2. Perform a quick Bus Test on the graphics buffer as follows:
  - Press **Bus Test** on the **Frame GrfxBuffDDR Test Menu** to perform the test. This test verifies the performance of the bus between the DRR and the switcher. The results of the test are shown on the menu.

- **3.** Perform a full Device Test on the graphics buffer as follows:
  - Press **Device Test** on the **Frame GrfxBuffDDR Test Menu** to perform the test. This test verifies the performance of the graphics buffer DDR. The results of the test are shown on the menu.

This completes the procedure for performing a graphics buffer test.

# **Video Checksum Custom Controls**

The Video Checksums custom control is a diagnostic tool that allows Ross Video Technical Support and other Ross Video staff to diagnose the operation of specific switcher functions based on the video output of the MLEs. When a checksum is inserted into a custom control, the switcher records the values that are returned at that point. When the custom control is run again, the switcher compares the new values that are returned against the stored values and reports either an error or a validation at the end of the custom control.

These tests are designed to be used by Ross Video Technical Support and other qualified Ross Video personnel.

## Setting Up a Checksum Custom Control

**Note** — In order for the checksum value to be validated, the video signal used when running the test must be the same that was used when the custom control was recorded. Only stills or internally generated signals, such as color patterns, should be used.

Use the following procedure to add a checksum to a custom control:

- 1. Navigate to the Custom Controls Menus as follows:
  - Press HOME ⇒ Custom Controls.
- 2. Select the custom control button you want to record to as follows:
  - Use the **Bank** knob on the **Custom Controls Menu 1-2** to select the bank that you want to record the custom control on.
  - Use the **Button** knob on the **Custom Controls Menu 1-2** to select the custom control button you want to record to.
- **3.** Press More  $\Rightarrow$  Checksums.

Checksums		🐳 Back	IP Torment	Copy Up	13 Swap	
Checksums On/Off	Checksum Diff Action	Short				44100

Checksums Menu

- 4. Toggle Checksums on the Checksums Menu to On to activate this feature.
- **5.** To perform a **Short Checksum**, press **Short** on the **Checksums Menu** to have a short checksum performed. When you choose a short checksum, you have to select the type of checksum to perform, and which input or output video signal to perform the test on.
  - Use the **Checksum reg** knob on the **Checksums Menu** to select the Checksum Register you want to use. You can choose between the following:
    - FE out Select this option to have the checksum calculated at the output of the Video Interface FPGAs on the Video Processor Board.

- Vid in Select this option to have the checksum calculated at the input of the Video Core FPGA on the Video Processor Board.
- > Vid out Select this option to have the checksum calculated at the output of the Video Core FPGA on the Video Processor Board.
- > **FE in** Select this option to have the checksum calculated at the input of the **Video Interface FPGAs** on the **Video Processor Board**.
- > **All** Select this option to have the checksum calculated on all the checksum registers.
- If you selected **FE out** or **Vid in**, use the **Input video** knob on the **Checksums Menu** to select the video signal that you want to perform the checksum on. You can choose between the following:
  - > **Background** Select this option to perform the checksum on the Background video signal.
  - > **Preset** Select this option to perform the checksum on the preset, or Preview, video signal.
  - K1V Select this option to perform the checksum on the Video Fill signal of Key 1.
  - > **K1A/K2A** Select this option to perform the checksum on the Alpha signal for all the Keys.
  - > **Trans\_mix 0/1** Select this option to perform the checksum on the video signals as a transition is being performed.
  - K2V Select this option to perform the checksum on the Video Fill signal of Key 2.
- If you selected **FE in** or **Vid out**, use the **Output video** knob on the **Checksums Menu** to select the video signal that you want to perform the checksum on. You can choose between the following:
  - > **Program** Select this option to perform the checksum on the Program video signal coming out of the MLE.
  - > **Preview** Select this option to perform the checksum on the Preview video signal coming out of the MLE.
  - > **Clean** Select this option to perform the checksum on the Clean Feed video signal coming out of the MLE.
- 6. Press Up One ⇒ More ⇒ Start Recording on the Custom Controls Menu 1-2.
- Add events into the custom control. Refer to the section "Programming Control Panel Functions" on page Eng 10-8 for more information on adding events into a custom control.



**Important** — A **4** frame **Custom Control Pause Command** should be added to the custom control before each checksum point if the video signal has been changed. This ensures that enough time has passed to allow the new video signals to propagate through the switcher.

- 8. Add a Checksum event to the custom control as follows:
  - Press HOME ⇒ Custom Controls ⇒ Insert Special ⇒ More ⇒ Video Checksums.

Insert Video Checksum (1-2)	44 Back	• • • • • • • • • • • • • • • • • • •	Copy Up	93 Swap	
MLE1 MLE2	MLE3	MLE4		All MLEs	More

Insert Video Checksum

- 9. Select the MLE, or MLEs, that you want to calculate a checksum for.
- **10.** Add events into the custom control as needed.

#### 11. Press Finish Recording on the Custom Controls Menu 1-2.

This completes the procedure for adding a checksum to a custom control.

#### For More Information...

• on the different video signals used by the switcher, refer to the section "Video Routing" on page Eng 2-20.

## **Using a Checksum Custom Control**

The Checksum custom control records and display the checksum validation on one of four different ways. This option must be set before the custom control is run to have the validation perform the actions you want.

Use the following procedure to use a checksum custom control:

- 1. Navigate to the Custom Controls Menus as follows:
  - Press HOME ⇒ Custom Controls ⇒ More ⇒ Checksums ⇒ Checksum Diff Action.

Checksums	44 Back	• • Toppegal	Copy Up	13 Swap	Action on error:
Checksum mode: Short					Log change Halt macro
Checksums Checksum Diff Action	Short				-

Checksum Difference Settings - Checksums Menu

**2.** Use the **Action on error** knob on the **Checksums Menu** to select the action you want the switcher to take when a checksum is performed. You can choose between the following:



- **No action** Select this option to have no action taken when the checksum custom control is run.
- **Log change** Select this option to have any changes in the checksum values recorded to a system log that can be viewed by a Ross Video employee. A pop-up is displayed when the custom control is finished. This is the default setting.
- **Halt macro** Select this option to have any changes in the checksum values halt the custom control and display the checksum event that returned the incorrect value. A pop-up is displayed, indicating the problem.
- **Recalc c'sums** Select this option to have the checksum values that are returned the next time the checksum custom control is run saved as the new checksum values. The existing checksum values is replaced with the new values. A pop-up is displayed if any of the checksum values were replaced.
- 3. Press HOME.
- **4.** Run the checksum custom control.

This completes the procedure for running a checksum custom control.

# **Communication Port Monitor**

The communications port monitor allows you to view the information that is being sent to or received by the switcher. This information can then be saved to a file that can be sent to Ross Video Technical Support if required.

The **Com Port Monitor Menu** is accessed through the **Panel TX/RX Test Menu** or the **Frame Tx/RX Test Menu**. On that menu you must select which port you want to monitor.

#### For More Information...

- on selecting a communications port on the frame, refer to the section "Control Panel SBC Transmit/Receive Test" on page Eng 17-26.
- on selecting a communications port on the frame, refer to the section "PCH Transmit/Receive Test" on page Eng 17-22.

**Note** — You cannot **Save** or turn on **Streaming** for a communications port that has been set to a **Baud Rate** of **115200**.

Use the following procedure to monitor the selected serial communications port:

- 1. Toggle **Freeze** to **Yes** to stop data from being displayed.
- 2. Press **Clear** on the **Com Port Monitor Menu** to remove any existing data stored in the monitor buffer.

Frame Com Po	ort Monitor	44 Back	•••	Copy Up	103 Swap	

Com Port Monitor Menu

- **3.** Toggle **Format** to **Hex** or **ASCII** on the **Com Port Monitor Menu** to select how you want the data displayed.
  - **Hex** Select this option to have the data displayed in a Hexidecimal format.
  - **ASCII** Select this option to have the data displayed in an ASCII format.
- 4. Toggle View to Tx or Rx on the Com Port Monitor Menu to select which data is displayed.
  - **Tx** Select this option to monitor the data that is being transmitted from the selected serial communications port.
  - **Rx** Select this option to monitor the data that is being received by the selected serial communications port.

 $\checkmark$ 

**Operating Tip** — Toggle **Streaming** to **Yes** to store all the data being transmitted from or received by the selected communications port. Streaming stores data for a maximum of **1** hour, at which point **Streaming** is toggled to **No**.

- 5. Toggle **Freeze** to **No** on the **Com Port Monitor Menu** to start viewing the data that is being sent to or received by the selected port.
- 6. Send or receive the commands you want to monitor.
- 7. Toggle Freeze to Yes to stop displaying the data on screen. At this point you can save

**Operating Tip** — At this point you can save the data displayed on screen by pressing **Save** on the **Com Port Monitor Menu**.

This completes the procedure for monitoring the selected serial communications port. If you saved, or streamed, the data to a file, you will have to navigate to the frame to view the file.

## **Port Monitor Data Files**

After you have saved the port monitor data to the hard drive on the frame, you have to navigate to the frame to access the data file.

Use the following procedure access a port monitor data file:

- 1. On your computer, open your Web Browser and, in the address bar, enter the IP address of your frame and press **Enter**. The **QMD/X Web Interface Splash Screen** is displayed.
- 2. Enter your username and password as follows when the Login Dialog Box appears. The default Name is user and Password is password.
- 3. Click Other... ⇒ PMBrowser to display the Port Monitor File Browser Page. This page allows you to download all the port monitor log files.

Bysteminto Upgrade File Sete	Other	· · · · · · · · · · · · · · · · · · ·
Port Monitor File Browser		
	File name	
	Ohm02ra.tet	
	Chm02ts fat	
	OtmOleatel	
	OhmObulat	
	Controlat	
	OpenOdtx.tet	
	Cumpites hat	
	Comptotexted	
	Constitut	
	OpentOte tel	
	OpenLinet	
	Open13te.tet	
	Centra Solution Fin   (Furtean Files.)	
	Because and a construction of the second second	

Port Monitor File Browser Page

**4.** Click on the file you want to view. Files are identified by where they come from, what port they are from, and whether they are transmit or receive data.

 $\bigcirc$ 

**Note** — Port Monitor file number is offset by three (3). For example, the file **pan04tx.txt** is from the control panel, remote port 1, transmit data.

**Operating Tip** — Press the **Refresh Files** button updates the list of port monitor files. You can also delete a file by selecting the file and pressing the **Delete Selected Files** button.

This completes the procedure for accessing a port monitor data file.

# **Switcher Logs**

Switcher logs are used by Ross Video Technical Support to track and diagnose possible problems you might be having with your switcher. When asked for your switcher logs, you must log into the frame and download the logs.

Use the following procedure to download your switcher logs:

- 1. On your computer, open your Web Browser and, in the address bar, enter the IP address of your frame and press Enter. The QMD/X Web Interface Splash Screen is displayed.
- 2. When the Login Dialog Box appears, enter your username and password as follows:
  - In the Name field enter **user**. This is the factory default name.
  - In the **Password** field enter **password**. This is the factory default password.
  - Click **OK** to display the **System Info Page**.
- 3. Click Other... ⇒ All Logs to display the Get Switcher Log Files Page. This page allows you to download all the log files from the switcher.

GM/G/X	A noss
Bystens who Upgrade File Sets Other	140
Get Switcher Log Files	
The page gathers all of the switcher log files and places them into an archive file. The anchive file can be copied to your local machine and then sent to ross video technical support.	
(368 Teacher Cap Pers)	
Copyright 1998-2009 Ross Video Limited. All rights reserved.	

Get Switcher Log Files Page

**4.** Click **Get Switcher Log Files**. The switcher collects all the log files into a single archive file for you to download. This process may take several seconds to complete.

ONDX						- ANDER
Bysterkinto Upgrade	File Sets	Other_				Help
Get Switcher Log File	15					
tmp/suig_lift mars.hadlag/shiwaga.lagi mars.hadlag/shiwaga.lagi mars.hadlag/shiwaga.lagi mars.hadlag/shiwaga.lagi mars.hadlag/shiwaga.lagi mars.hadlag/shiwaga. mars.hadl	8					
Other sectors for other	tion tor out want o	created Please copy	y to your computer and	send to Ross Video Te	ectinical support	

Get Switcher Log Files Page

5. Click the stills/logs.tar.gz link to open or download the archive to your computer.

This completes the procedure for downloading your switcher logs.
# **Switcher Maintenance**

# In This Chapter

This chapter provides information on maintaining and replacing the power supplies, fans, faders and control panel modules of the Vision switcher. This includes diagnosing and replacing a failed power supply, cleaning the filters and replacing a fader assembly. General information is also provided for replacing a control panel module.

The following topics are discussed in this chapter:

- Control Panel Power Supply Failure
- Frame Power Supply Failure
- Frame Fan Failure
- Control Panel Power Supply
- Frame Power Supply
- Cleaning the Frame Air Filter
- Replacing the Hard Drive
- Replacing a Control Panel Module
- Dusting Mode



**Warning Hazardous Voltage** — Hazardous voltages are present in the control panel as long as any of the power supplies are connected to the AC power.



**ESD Susceptibility** — Static discharge can cause serious damage to sensitive semiconductor devices. Avoid handling the switcher circuit boards in high static environments such as carpeted areas and when synthetic fiber clothing is worn. Touch the frame to dissipate static charge before removing boards from the frame and exercise proper grounding precautions when working on circuit boards.

# **Control Panel Power Supply Failure**

When a control panel power supply or cooling fan fails, the switcher will identify the failed component on the **Status Menu**. Use this information to trouble-shoot the Power Supply Module and replace it if required.



**Note** — The Vision control comes with a single power supply. If you purchased the Redundant Power option, a second power supply is installed in the control panel.

### **Troubleshooting a Failed Power Supply**

When the switcher reports that a power supply has failed, the failure could be in the power supply, or in the **Power Distribution Board** for the control panel.

Use the following procedure to troubleshoot a failed power supply:

The Status Menu identifies which power supply is reporting a failure (Figure 18.1). If you have the Redundant Power option installed, Power Supplies 1 and 2 are located in the Primary Power Supply Module and Power Supplies 3 and 4 are located in the Secondary Power Supply. If you do not have the Redundant Power option, only the Primary Power Supply Module is present with Power Supplies 1 and 2.

		Primary Secondary Power Supply Power Supply

Figure 18.1 Power Supply Modules

- **2.** Check the AC power cords for the failed Power Supply Modules. Ensure that they are securely plugged into the control panel power supply, as well as the power outlet.
- **3.** If each Power Supply Module is connected to separate circuits, check that there has not been an interruption to the AC power for the failed power supply.
- 4. Lift up on the control panel lid to gain access to the control panel tub.
- 5. Locate the **Power Distribution Board** (Figure 18.2) at the back of the tub above the **Control Panel CPU Module**.





Figure 18.2 Power Distribution Board — Power Supply Indicators

- 6. Using the **Power Supply Indicators** (Figure 18.2), identify the power supply that has failed. If a power supply is not providing power, or is not installed, the **Power Supply Indicator** will not be lit.
  - Vision 3 and 4 Power Supplies 1 and 2 are located in the Primary Power Supply Module and Power Supplies 3 and 4 are located in the Secondary Power Supply Module.
  - Vision 1 and 2 Power Supply 1 is located in the Primary Power Supply Module and Power Supply 2 is located in the Secondary Power Supply Module.

**Note** — If all the **Power Supply Indicators** are lit, check the cables between the power supplies and the **Power Distribution Board**.

 Remove the failed Power Supply Module. Refer to the section "Replacing a Power Supply Module" on page Eng 18-4 for information on replacing a power supply module.

This completes the procedure for troubleshooting a failed power supply.

#### **Troubleshooting a Failed Cooling Fan**

When the switcher reports that a cooling fan has failed, the failure could be in the power supply, or in the fan itself.

Use the following procedure to troubleshoot a failed cooling fan:

 The Status Menu identifies which cooling fan is reporting a failure. Locate that fan on the control panel (Figure 18.3). If you have the Redundant Power option installed, Cooling Fans 1 and 2 are located in the Primary Power Supply Module and Cooling Fans 3 and 4 are located in the Secondary Power Supply. If you do not have the Redundant Power option, only the Primary Power Supply Module is present.



Figure 18.3 Power Supply Modules

**2.** Place a small piece of paper in front of each cooling fan in the **Power Supply Module** to determine if the fan is moving air.

**3.** If a cooling fan is *not* moving air, or is moving much less than the other fans, that **Power Supply Module** must be replaced. Refer to the section "**Replacing a Power Supply Module**" on page Eng 18-4 for information on replacing a **Power Supply Module**.

**Note** — If all the cooling fans appear to be moving air properly, check that the cables between the **Power Supply Module** and the **Power Distribution Board** are not damaged.

This completes the procedure for troubleshooting a failed cooling fan.

### **Replacing a Power Supply Module**

To replace a **Power Supply Module** in the control panel, you must power down the control panel, disconnect all the cables and remove the old the **Power Supply Module**.

Use the following procedure to replace a **Power Supply Module**:

1. Toggle the **Primary** and, if installed, **Secondary AC Power** switches for the control panel to **OFF** (**Figure 18.4**).



Figure 18.4 Power Supplies Inside The Control Panel Tub — Vision 4

- **2.** Disconnect the AC power cords from the back of the **Power Supply Module** that contains the failed power supply.
- **3.** Label and remove the **Power Supply Status Cables** and **Power Supply Cables** for each power supply in the **Power Supply Module** before you remove them. If there is only power supply in the module, you do not need to label the cables.
- **4.** Disconnect the **Power Supply Status Cables** and **Power Supply Power Cables** for the power supplies in the **Power Supply Module** that you want to remove.
- 5. Remove the 2 retaining screws along the front flange of the Power Supply Module.
- **6.** Slide the *failed* **Power Supply Module** out of the control panel tub and place on a clean, dry surface.
- **7.** Slide the *new* **Power Supply Module** into the open slot in the control panel tub that you just removed the failed **Power Supply Module** from.
- **8.** Replace the **2** retaining screws along the front flange of the **Power Supply Module**.



**Note** — If you do not connect the cables to the proper power supplies, you may cause the **Status Menu** to give false readings.

- Reconnect the Power Supply Status Cables and Power Supply Power Cables for each power supply in the Power Supply Module according to how you marked them in Step (3.) above.
- **10.** Reconnect the AC power cords from the back of the **Power Supply Module**.

This completes the procedure for replacing a Power Supply Module.

# Frame Power Supply Failure

In order to diagnose a power supply failure you must remove the door from the frame, and identify the failed power supply using the status indicators on each power supply.

Use the following procedure to diagnose a power supply failure:

- **1.** Check the network status between the control panel and frame. If there has been a network interruption, the switcher may report a power failure of the frame power supplies.
- **2.** Check the AC power cords for all power supplies. Ensure that they are securely plugged into each receptacle.
- **3.** If each of your power supplies are connected to separate circuits, check that there has not been an interruption to the AC power on either of those circuits.
- **4.** Check if there are enough power supplies installed in your frame. Refer to the section "**Frame Power Supplies**" on page Eng 20-4 for the minimum number of power supplies required.
- **5.** Check if there is a power supply mismatch. The 500 Watt (4800AR-014) and 700 Watt (4800AR-024) power supplies cannot be used in the same frame at the same time.
- **6.** Remove the front door of the frame. Refer to the section "**Opening and Closing the Frame Door**" on page Eng 3-3 for more information.
- 7. Locate the frame power supplies (Figure 18.5).

0	0	Slot 1
		Slot 2
0	0	Slot 3

Figure 18.5 Frame Power Supplies (QMD Shown)

**8.** Use the following table (**Table 18.1**) to diagnose the status of each power supply and determine the corrective action.

Power Switch	Green Power Indicator	Yellow Standby Indicator	Red Fail Indicator	Status
On	On	Off	Off	<b>Normal Operation</b> — Check the network connection between control panel and frame.
Off	Off	On	Off	Standby Mode (QMD/MD)
				• Toggle the power switch on the power supply <b>On</b> for normal operation.
On	Off	On	Off	Standby Mode (QMD-X/MD-X)
				• Toggle the power switch on the power supply <b>On</b> for normal operation.
				• Check that the Main Power switch is on.
On	Off	Off	On	Fail
				• Check the AC power cable and building circuit breakers.
				• Replace the power supply if needed.
On	Off	Off	Off	Fail
				• Check the AC power cable and building circuit breakers.
				• Check the AC power input fuse and replace if needed.
				• Replace the power supply if needed.
Off	Off	Off	Off	Fail
				• Check the AC power cable and building circuit breakers.
				• Check the AC power input fuse and replace if needed.
				• Replace the power supply if needed.

 Table 18.1 Panel Power Supply Diagnosis

**9.** Replace the power supply if needed. Refer to the section "**Replacing a Frame Power Supply**" on page Eng 18-12 for information on replacing a power supply.

This completes the procedure for diagnosing a power supply failure.

## **Frame Fan Failure**

In order to diagnose a cooling fan failure, you must remove the door from the frame, and identify the failed fans by removing the fan carrier and locating the fans that are not spinning.

Use the following procedure to diagnose a cooling fan failure:

- **1.** Shut down the switcher. Refer to the section "**Powering Down the Switcher**" on page Eng 4-3 for information on powering down the switcher.
- **2.** Remove the front door of the frame. Refer to the section "**Opening and Closing the Frame Door**" on page Eng 3-3 for more information.
- **3.** The **System Status Indicators** on the left side of the frame changes from **Green** to **Red**, indicating that it is safe to turn the power off.

**Note** — You must remove the Fan Carrier Board immediately after powering down the frame. If too much time has passed, you may not be able to identify the fan, or fans, that were not spinning.

- 4. Remove the Fan Carrier Board from the frame.
- **5.** Identify the fan, or fans, that are not spinning.
- 6. Replace the failed fans as required.

This completes the procedure for diagnosing a cooling fan failure.

# **Control Panel Power Supply**

The **Power Supply Modules** in the Vision control panel can operate in a primary, or load sharing mode, if the **Redundant Power** option is installed. The Redundant Power option allows all the **Power Supply Modules** in the frame to share the power load of the frame. In this configuration, if one of the **Power Supply Modules** fails, the remaining **Power Supply Module** can maintain the operation of the frame.

This section provides information on the functional components of a Power Supply Module.

#### **Control Panel Power Supply Functional Components**

The Vision control panels use a **250** or **500** (Figure 18.6) Watt Power Supply Module, depending on the control panel you have. The **250** Watt Power Supply Module is similar to the **500** Watt Power Supply Module, but has only the single power supply inside.

#### For More Information...

• on which power supply module each control panel requires, refer to the section "Control Panel Power Supplies" on page Eng 20-3.

**Warning Hazardous Voltage** — Hazardous voltages are present within the power supply for a short period of time after removal from the control panel. The power supply cover is intended to protect the user from access to these areas, and should not be removed. Ross Video Power Supply Module are intended to be factory serviced by qualified Ross Video service personnel only.



Figure 18.6 Control Panel 500 Watt Power Supply Module

1) Power Supply 1 Power Connector	4) Power Supply 2 Status Connector	7) Power Supply 2 Cooling Fan
2) Power Supply 1 Status Connector	5) Power Switch	8) AC Plug
3) Power Supply 2 Power Connector	6) Power Supply 1 Cooling Fan	

#### 1. Power Supply 1 Power Connector

The power connector for **Power Supply 1** uses a 14-Pin, keyed locking Molex connector to interface with the **Power Distribution Board** to provide power to the control panel.

#### 2. Power Supply 1 Status Connector

The status connector for **Power Supply 1** uses a 9-Pin, friction fit Molex header to interface with the **Power Distribution Board** to pass status information on the power supply and cooling fan.

#### 3. Power Supply 2 Power Connector

The power connector for **Power Supply 2** uses a 14-Pin, keyed locking Molex connector to interface with the **Power Distribution Board** to provide power to the control panel.

#### 4. Power Supply 2 Status Connector

The status connector for **Power Supply 2** uses a 9-Pin, friction fit Molex header to interface with the **Power Distribution Board** to pass status information on the power supply and cooling fan.

#### 5. Power Switch

The Power Switch is used to turn the individual **Power Supply Modules** on and off. The single switch turns both power supplies on and off for the **500** Watt **Power Supply Module**.

#### 6. Power Supply 1 Cooling Fan

The single fan provides cooling for **Power Supply 1**.

#### 7. Power Supply 2 Cooling Fan

The single fan provides cooling for **Power Supply 2**.

#### 8. AC Plug

The single AC port is used to connect the mains or AC power in the facility to the control panel.

# **Frame Power Supply**

The power supplies in the frame can operate in a primary, or load sharing mode, if the **Redundant Power** option is installed. The redundant power option allows all the power supplies in the frame to share the power load of the frame. In this configuration, if one of the power supplies fails, the remaining power supplies can maintain the operation of the frame.

This section provides information on the functional components of a power supply, as well as information on how to replace a power supply.

#### **Frame Power Supply Functional Components**

There are a number of important components of the Frame Power Supply that are discussed in this section. These components include the power switch, the status indicators, and the midplane connectors.

#### For More Information...

• on which power supply module each frame requires, refer to the section "Control Panel Power Supplies" on page Eng 20-3.



**Warning Hazardous Voltage** — Hazardous voltages are present within the power supply for a short period of time after removal from the frame. The power supply cover is intended to protect the user from access to these areas, and should not be removed. Ross Video power supplies are intended to be factory serviced by qualified Ross Video service personnel only. Service or any component replacement other than the AC input fuse is not advised.



Figure 18.7 Frame Power Supply Front

1) Power Switch	3) Yellow Standby Indicator	4) Red Fail Indicator
2) Green Power Indicator		

#### 1. Power Switch

The Power Switch is used to turn the individual power supplies on and off. The switch is in the off position when it is toggled down.

#### 2. Green Power Indicator

This green indicator illuminates to show that the power supply is functioning properly.

#### 3. Yellow Standby Indicator

This yellow indicator illuminates to show that the power supply is in standby mode. A power supply will be in standby mode because the master power switch or the power switch on the power supply has been turned off.

#### 4. Red Fail Indicator

This red indicator illuminates to show that the power supply is not operating. This is because the power supply has failed or is installed incorrectly.

### **Replacing a Frame Power Supply**

The power supplies in the frame are hot-swappable only if the Redundant Power option is installed. If you do not have redundant power supplies, you must power down the frame before attempting to remove a power supply.

Â

**Warning Hazardous Voltage** — Hazardous voltages are present on the pins of supply mating connectors within the frame power supply housing area. To reduce the risk of electric shock, keep clear of mating connectors within the supply area when power supplies modules are not installed.

Use the following procedure to replace a frame power supply:

- 1. Remove the front door of the frame. Refer to the section "**Opening and Closing the Frame Door**" on page Eng 3-3 for more information.
- **2.** Locate the power supply to be replaced.

**Important** — If you do not have redundant power installed in your frame, you must power down the frame before proceeding, if it is not already off.

- 3. Switch the power supply Off by toggling the power switch down.
- 4. Loosen the 2 screws holding the slider catch in place until the catch moves freely (Figure 18.8).



Figure 18.8 Power Supply Protective Cage

**5.** Move the slider catch all the way to the right.

**Caution** — The metal cage surrounding the power supply may be hot after prolonged switcher operation.

- **6.** Grasp the tab and gently pull the power supply out of the frame.
- 7. Switch the replacement power supply Off by toggling the power switch down.

**Warning** — The 500 Watt (4800AR-014) and 700 Watt (4800AR-024) power supplies cannot be used in the same frame at the same time; doing so may damage the power supply, the frame, or both.

- **8.** Install the new power supply by sliding it into the open slot and pushing it firmly into place.
- **9.** Move the slider catch to the left until it hooks the side of the slot.
- **10.** Tighten the screws to secure the slider catch in place.



- **11.** Switch the new power supply **On** by toggling the power switch up. The switcher will automatically detect the new power supply and clear the fail message.
- **12.** Install the front door of the frame.

This completes the procedure for replacing a frame power supply.

# **Cleaning the Frame Air Filter**

The frame has a single air filter that is used to prevent dust and airborne particulates from contaminating the frame. This filter should be cleaned at least once a year; but may need to be cleaned more frequently in some environments.

Use the following procedure to clean the air filter:

- **1.** Remove the front cover of the frame.
- **2.** Locate the air filter on the far left side of the frame (**Figure 18.9**), next to the Fan Carrier assembly.
- **3.** Grasp the end of the filter and gently pull it out of the frame.



Figure 18.9 Fan Carrier and Filter (QMD Shown)

- **4.** While servicing the air filter, replace the front cover of the frame to ensure not dust or debris falls into the frame.
- **5.** Brush any loose dust off of the filter.
- **6.** Place the filter under warm running water to remove any remaining dust. On one side of the filter is a "bug screen" mesh. When rinsing, water should flow out of this side.
- 7. Remove the filter from the water and pat dry with a towel to remove any moisture.
- **8.** Remove the front cover of the frame.
- **9.** Replace the clean, dry filter back into the air filter slot in the frame. Ensure that the side with the mesh is facing the outer wall of the frame, and the edge *without* the foam is situated at the front of the frame.
- **10.** Replace the front cover of the frame.

This completes the procedure for cleaning the air filter. With the air filter cleaned, it is a good idea to record how dirty it was and how long it has been since the last cleaning. If the filter was very dirty, you should shorten the interval between cleanings to compensate for your particular conditions.

# **Replacing the Hard Drive**

In the event that the hard drive installed in your frame needs to be replaced, a spare hard drive, with the current shipping version of the software on it, is provided in the spare parts kit.

1

**Note** — The software provided on the spare hard drive should be the current shipping version at the time the hard drive was imaged. This may not be the newest version of software available. Once you have installed the spare hard drive, you should contact Ross Video for the most current version of the software.

#### For More Information...

- on performing a software upgrade, refer to the section "**Software Upgrade**" on page Eng 6-3.
- on backing up your switcher setups, refer to the section "Storing and Recalling Files and Setups" on page Eng 13-4.

Use the following procedure to replace the Frame CPU Hard Drive:

- **1.** Power down the switcher. Refer to the section "**Shutting Down the Switcher**" on page 4-5 for information on shutting down switcher.
- **2.** Remove the **Frame CPU Board** from **Slot A** at the back of the frame. Refer to the section "**Removing and Installing Frame Boards**" on page Eng 4-18 for more information on locating and removing this board.
- 3. Locate the Hard Drive on the Frame CPU Board (Figure 18.10).



Figure 18.10 CPU Board — Hard Drive Location

4. Release the **Ribbon Cable** from the **Ribbon Cable Connector** by pressing down and out on the **Ejector Tabs** at either end of the **Ribbon Cable Connector** (**Figure 18.11**).



Figure 18.11 Releasing the Ribbon Cable

- 5. Flip the CPU Board over so that the Hard Drive is facing down.
- 6. Locate the four Retaining Screw securing the Hard Drive in place (Figure 18.12).



Figure 18.12 CPU Board — Retaining Screws Location

- 7. Using a non-magnetic (electronics safe) screwdriver, remove the **4 Retaining Screws** securing the **Hard Drive**.
- **8.** While holding the **Hard Drive** to the **CPU Board**, flip the **CPU Board** back over so that the **Hard Drive** is facing up again.

**Note** — Ensure that you do not damage the rubber spacers located at each screw hole when you remove the **Hard Drive**.

- 9. Remove the Hard Drive from the CPU Board and place in a safe location.
- **10.** Remove the **Ribbon Cable** from the **Hard Drive** you just removed and install it onto the replacement **Hard Drive**. Ensure that the stripe on the **Ribbon Cable** is aligned towards the four unused pins as illustrated (**Figure 18.13**).





Figure 18.13 CPU Board — Ribbon Cable Alignment

**Caution** — Ensure that you connect the **Ribbon Cable** to the pins illustrated (**Figure 18.13**). If the **Ribbon Cable** is not properly connected, your **Hard Drive** could be damaged when the switcher is powered On.

**11.** Ensuring that the **Rubber Spacers** are in place, install the replacement **Hard Drive** using the **4 Retaining Screws** you removed (**Figure 18.14**).



Figure 18.14 CPU Board — Retaining Screws



**Caution** — Do not over tighten the **Retaining Screws**. These screws only need to be snug in order to secure the **Hard Drive** in place.

- **12.** Push the **Ribbon Cable** into the **Ribbon Cable Connector** until the **Ejector Tabs** at either end of the **Ribbon Cable Connector** close together, securing the **Ribbon Cable** in place.
- **13.** Re-install the **Frame CPU Board** into the same slot in the frame that you removed it from. Refer to the section "**Installing a Rear Frame Board**" on page 4-33 for more information on installing the Frame CPU Board.

This completes the procedure for replacing the Frame CPU Hard Drive. You may have to reset your network configurations or update your software version. Refer to the section "**Software Upgrade**" on page 5-9 for more information.

# **Replacing a Control Panel Module**

Each module on the Vision control panel can be removed and replaced as required with the exceptions of the **Preview Bus Module** and the **Positioner Module**.



**Note** — Installing control panel modules in different locations than the default is not supported at this time.

#### **Removing a Control Panel Module**

To remove a module, you will have to power down the control panel, disconnect the power and communications cables to the module, and then un-bolt it from the control panel.

Use the following procedure to remove a control panel module:

- 1. Power down the control panel. The frame can remain on during this procedure. Refer to the section "**Powering Down the Switcher**" on page Eng 4-3 for information on shutting down the control panel.
- 2. Unplug the Primary and Redundant (if installed) power from the control panel.
- 3. Lift up on the control panel lid to gain access to the control panel tub.
- 4. Identify the module that you want to replace from inside the control panel tub.
- Disconnect the Module Power Cable from the module you want to remove (Figure 18.15). This 4-conductor ribbon cable delivers power to all the modules in the row, when removing it, ensure that you do not accidentally unplug it from any neighboring modules.



Figure 18.15 Effects Keyer Module — Power Connector

**Note** — The **Preview Bus Module** connects to the Module Control Link Backbone through the **Positioner Module**. To remove either of these modules, the 26-Pin ribbon cable between the two modules must be removed. The **Preview Bus** will not operate properly if it is not connected to the **Positioner Module**.

**6.** Disconnect the Module Control Link **Cables** from the module you want to remove (**Figure 18.16**). This CAT5 (TIA/EIA-568-B) cable delivers all the command signals to and from the module, as well as other modules in the same row.



Figure 18.16 Panel Module Controller (PMC) — Module Control Link Connectors

- **7.** Remove the **Retaining Bolts** located at each corner of the module and keep them in a safe place. A <sup>1</sup>/<sub>4</sub> inch hex driver or wrench is required.
- 8. Remove the module from the control panel and place it on a clean, static free surface.

**Important** — If a replacement module is not available, you must install and secure a blank module cover plate to replace the module until the new module is available.

This completes the procedure for removing a control panel module. Next, you will have to install the new control panel module.

### **Installing a Control Panel Module**

To install a module, you will have to power down the control panel, disconnect the communications cables, remove the blank cover plate if installed, install the new module, and then connect the power and communications cables.

Use the following procedure to remove a control panel module:

- 1. Power down the control panel. The frame can remain on during this procedure. Refer to the section "**Powering Down the Switcher**" on page Eng 4-3 for information on shutting down the control panel.
- 2. Unplug the Primary and Redundant (if installed) power from the control panel.
- 3. Lift up on the control panel lid to gain access to the control panel tub.
- 4. Identify the module that you want to replace from inside the control panel tub.
- 5. Remove the blank cover plate, if one was installed in the module opening.
- 6. Slide the new module into the module opening. Ensure that the module opening is of the correct size for the module you are trying to install. Refer to the section "Control Panel Dimensions" on page Eng 20-6 for more information.
- Install the Retaining Bolts located at each corner of the module to a maximum torque of 5 in-lbs (6 cm-kg). A <sup>1</sup>/<sub>4</sub> inch hex driver or wrench is required.

**Note** — The **Preview Bus Module** connects to the Module Control Link Backbone through the **Positioner Module**. To remove either of these modules, the 26-Pin ribbon cable between the two modules must be removed. The **Preview Bus** will not operate properly if it is not connected to the **Positioner Module**.

**8.** Connect and secure the Module Control Link **Cables** to the module you are installing (**Figure 18.17**). This CAT5 (TIA/EIA-568-B) cable delivers all the command signals to and from the module, as well as other modules in the same row.





Figure 18.17 Panel Module Controller (PMC) — Module Control Link Connectors

Connect and secure the Module Power Cable to the module you want to install (Figure 18.18). This 6-conductor ribbon cable delivers power to all the modules in the row, when installing it, ensure that you do not accidental unplug it from any neighboring modules.



Figure 18.18 Effects Keyer Module — Power Connector

- **10.** Close the control panel lid and reconnect the Main and Redundant (if installed) power to the control panel.
- **11.** Power up the control panel. Refer to the section "**Powering Up the Switcher**" on page Eng 4-2 for information on powering up the control panel.
- If the message PMCs need to be upgraded; please go to Panel Modules menu is shown on the Main Menus, you need to upgrade your PMC. Refer to the section "Upgrading PMCs" on page Eng 18-21 for information on upgrading PMCs.
- Test the functionality of the new module. Refer to the section "Control Panel Diagnostic Tools" on page Eng 17-18 for more information on performing control panel diagnostics.
- **14.** Assign the module to a Crosspoint Group, or row, on the control panel. Refer to the section "**Mapping a Module to a Row**" on page Eng 17-5 for more information on assigning a module to a crosspoint group.

This completes the procedure for installing a control panel module.

### **Upgrading PMCs**

The **Panel Module Controllers (PMCs)** may need to be upgraded if you perform a software upgrade or replace a module. If PMCs need to be upgraded, the message **PMCs need to be upgraded; please go to Panel Modules menu** is shown on the **Main Menus**.

Use the following procedure to upgrade the control panel module PMCs:

- 1. Navigate to the Panel Modules Menus as follows:
  - Press HOME ⇒ More ⇒ Setup ⇒ More ⇒ Panel Modules. A warning is displayed, asking you if you want to enter the menu. Press Yes to display the Panel Modules Menu.

Panel Modules	44 Back 10	alawa ( Section of the	93.000	Link/Ne L:6/ N:	ode:
9 modules found Link 9 Node 1 Primary Global Memory module, I FPGA version 4, rev. B; Interna	ssue 3, disp. OLED Il type, PCB issue 2, ver. 2			L-9/ N Panel F Row 1 Row 2 Row 3	2 6
Quick     Panel Row &     Crosspoint	Guitent &	Remove Unfour Module Cfgs	nd Up	grade Cs	-44 Hone

Panel Modules Menu

2. Press Upgrade PMCs on the Panel Modules Menu. The switcher starts upgrading the PMC on the control panel.

This completes the procedure for upgrading the control panel module PMC.

#### For More Information...

• on mapping a module to a control panel row, refer to the section "Mapping a Module to a Row" on page Eng 17-5.

# **Dusting Mode**

Dusting Mode allows you to clean the surface of the Vision control panel, including the touchscreen display, without the switcher reacting to any accidental pressing of buttons. Dusting Mode does not affect the operation of the switcher, but prevents the switcher from acting upon button presses.



**Caution** — Do not use water, or any other liquid cleaner, to clean the surface of the control panel. Doing so can cause personal injury and/or damage to the control panel itself. A dry duster, vacuum, or low pressure compressed air should be used to clean the surface of the control panel.

Use the following procedure to clean the surface of the Vision control panel:

1. Navigate to the **Dusting Menu** as follows:

Dusting	44 Back	)   ₩Torsami	a convert	93	
To exit menu, press	F1 and F6 at the same time.				
Evit				Exit	-

Press HOME ⇒ More ⇒ Remote Enables ⇒ Dust.

Dusting Menu

- **2.** Dust the surface of the control panel as required. In dusting mode the switcher will not act upon any input from the control panel.
- Press the F1 and F6 buttons simultaneously to take the control panel out of dusting mode. The F1 and F6 buttons are the two physical buttons located below the two EXIT buttons on the Dusting Menu.

This completes the procedure for dusting the surface of the Vision control panel.

# **Appendix A. Menu Trees**

# **In This Appendix**

This appendix provides information on the various branches of the Vision menu system.

The following menu trees are discussed in this appendix:

- Setup and Installation Menu Trees
- Input BNC Menu Tree
- Output BNC Menu Tree
- Communications Menu Tree
- Custom Control Bank Menu Tree
- Custom Controls Menu Tree
- File Storage Menu Tree
- Recall Factory Menu Tree
- Squeeze & Tease and Effects Menu Tree

# **Setup and Installation Menu Trees**

### **Setup Menu Tree**

Controls Disk	Attributes	4 Help	Preview Overlay	Effects	More
Main Menu (2-2)					
Clips     Syst     Shull	tem 🕹 Status	Aux Bus	Remote     Enables	4 Setup	More Nore
(1-3)	Frame	Installed	nana la		1000
(1-3) Panel Diagnostics	Frame Diagnostics	Installed Options	Personality	nstallation	4ore
(1-3) Panel Diagnostics Setup (2-3)	Frame Diagnostics	Installed Options	Personality	nstallation	Mare
(1-3) Panel Diagnostics Setup (2-3) Bus Maps Net	twork	Installed Options	Personality	nstallation	More
(1-3) Panel Diagnostics Setup (2-3) Bus Maps Setup (3-3)	twork	Installed Options	Personality	nstallation	More

Figure 19.1 Setup Menu Tree

### **Installation Menu Tree**



Figure 19.2 Installation Menu Tree

# Input BNC Menu Tree



Figure 19.3 Input BNC Menu Tree

# **Output BNC Menu Tree**



Figure 19.4 Output BNC Menu Tree

# **Communications Menu Tree**



Figure 19.5 Communications Menu Tree

# **Custom Control Bank Menu Tree**

Main Menu (2-2)     Installed     Remote     Setup     M <ul> <li>Clips</li> <li>Shutdown</li> <li>Status</li> <li>Aux Bus</li> <li>Personality</li> <li>Installed</li> <li>Personality</li> <li>Installation</li> <li>More</li> <li>Installation (1-3)</li> <li>BNC</li> <li>Key 4</li> <li>Aux Bus</li> <li>Comm</li> <li>Output</li> <li>GPI I/O</li> <li>More</li> <li>Installation (2-3)</li> <li>Custom</li> <li>Reference</li> <li>Calibration</li> <li>MultiPanel</li> <li>Audio</li> <li>Video</li> <li>Processor</li> <li>M</li> <li>Audio</li> <li>Video</li> <li>Processor</li> <li>M</li> <li>Stature</li> <li>Audio</li> <li>Video</li> <li>Video</li> <li>Processor</li> <li>M</li> <li>MultiPanel</li> <li>Audio</li> <li>Video</li> <li>Processor</li> <li>M</li> <li>Stature</li> <li>Audio</li> <li>Video</li> <li>Processor</li> <li>M</li> <li>M</li> <li>Stature</li> <li>MultiPanel</li> <li>Audio</li> <li>Video</li> <li>Stature</li> <li>Sta</li></ul>	Main Menu (	2-2)		MANAGED -	Overlay	Carrier Control ( )	and the second se
	Main Menu (	1-11				/:	Concernance of the
Clips System Status Aux Bus Frame Panel Diagnostics Frame Diagnostics Options Personality Installation More Installation (1-3) BNC Config Aux Bus Comm Output GPI 1/0 More Installation (2-3) Custom Controls	The second						
etup (1-3) Panel Diagnostics Frame Diagnostics Options Personality Installation More istallation (1-3) BNC Config Aux Bus Comm Output GPI I/O More Installation (2-3) Custom Reference Calibration MultiPanel Audio Video Processor MM	Clips	System Shutd	m 🚯 Statu	s 🕹 Aux I	Bus & Remo	les 🕹 Setu	p 🖬 Mor
etup (1-3) Panel Diagnostics Prame Diagnostics Options Personality Installation More istallation (1-3) BNC Config Aux Bus Comm Output GPI I/O More Installation (2-3) Custom Reference Calibration MultiPanel Audio Video Processor MM	- Contraction						
etup (1-3) Panel Prame Installed Personality Installation More Diagnostics Diagnostics Options Personality Installation More Installation (1-3) BNC Key 4 Aux Bus Comm Output GPI I/O More Installation (2-3) Custom Reference Calibration MultiPanel Audio Video Processor MM							
Panel Panel Prame Prame Prame Personality Installation More Installation (1-3) BNC Key 4 Aux Bus Comm Output Or GPI 1/0 More Installation (2-3) Custom Reference Calibration MultiPanel Audio Processor M	(1,2)			+			
Panel Diagnostics Parme Diagnostics Personality Installation More  stallation (1-3) BNC Key 4 Aux Bus Config Aux Bus Config Aux Bus Controls Reference Calibration MultiPanel Audio Video Processor M Installation Stallation Controls	rup (1-3)						
Installation (1-3) BNC Key 4 Config Aux Bus Comm Output Output Output Installation (2-3) Custom Reference Calibration MultiPanel Audio Video Processor MM	0	Panel	Frame     Diagnostics	3 Installed			More
stallation (1-3) BNC Key 4 Config Aux Bus Comm Output GPI I/O M More Installation (2-3) Custom Reference Calibration MultiPanel Audio Processor M M stom Controls		Disgliostics	Diagnostics	options			
Installation (1-3) BNC Key 4 Config Aux Bus Comm Output GPI I/O More Installation (2-3) Custom Reference Calibration MultiPanel Audio Processor MM Installation Setup							
Stallation (1-3)  BNC  Key 4  Aux Bus  Comm  Output  GPI I/O  More  Installation (2-3)  Custom  Controls  Reference  Calibration  MultiPanel  Audio  Video Processor  M M  Istom Controls				-			
BNC Key 4 Config Aux Bus Comm Controls Comm Comm Controls Comm Con	istallation (1-3)			•			
Installation (2-3) Custom Controls Reference Calibration MultiPanel Audio Processor MM ustom Controls	4 BNC	a Key 4	4 Aux Bus	3 Comm	- Output	4 GPI 1/0	More
Custom Controls  Reference Calibration MultiPanel Audio Processor		(C COINTY		Secup			Concerning and
Controls Reference Calibration MultiPanel Audio Processor	Installation	(2-3)					
Istom Controls	Custom	3 Refere	ance & Calibrat	ion 🚯 MultiP	anel 🚯 Aud	is Video	Mor
ustom Controls	controns		ine Diseator and			Proces	Isor
ustom Controls				-			
ustom Controls							
Setup Modify Setup Shot	istom Controls						

Figure 19.6 Custom Control Bank Menu Tree

# **Custom Controls Menu Tree**



Figure 19.7 Custom Controls Menu Tree

# File Storage Menu Tree



### **Disk Store Menu Tree**

Figure 19.8 Disk Store Menu Tree

### **Disk Recall Menu Tree**





### **Disk Store Individual Item Menu Tree**

Custom Controls	ð Disk	Attributes	Help	Preview     Overlay		Mare Nore
Disk			+			
4 Recall			Recall     Individual	Store     Individual	Dest /	41
-		k				
itore Individu Memory Register	al Items (1-2) CustCtrl Register	Sequence	Bus Maps	Shot Box Pages	Store	) w
Store Individu Memory Register Store Ind	al Items (1-2) CustCtri Register dividual Items	Sequence (2-2)	Bus Maps	Shot Box Pages	Store	) <b>4</b>

Figure 19.10 Disk Store Individual Item Menu Tree

### **Disk Recall Individual Item Menu Tree**



Figure 19.11 Disk Recall Individual Item Menu Tree

# **Recall Factory Menu Tree**

Custom Controls Disk Attributes Help Preview Corrisy Effects Mare Verlay Effects	Main Menu (1-2)						
Main Menu (2-2) Clips System Status Aux Bus Aux Bus Enables Setup Wilder etup (1-3) Panel Diagnostics Frame Diagnostics Options Personality Installation BNC Config Aux Bus Comm Controls Reference Calibration MultiPanel Installation (2-3) Custom Controls Reference Calibration MultiPanel Installation (3-3) Personality Memories Switcher Installation Recall Factory (1-3) Default Default Default Default Default Bus Maps Default Shot Recall Factory (3-3) Default Default Default Bus Maps File Recall Factory (3-3) Default Default Bus Maps File Recall Factory (3-3) Default More	Custom Controls	4 Disk	Attributes	4 Help	Preview Overlay	Effects	More
Clips Stylem Status Aux Bus Remote Setup Winne etup (1-3) Panel Diagnostics Frame Diagnostics Panel Pinel Diagnostics Frame Diagnostics Pinel Pinel <td>Main Menu (</td> <td>2-2)</td> <td></td> <td></td> <td></td> <td></td> <td></td>	Main Menu (	2-2)					
eecall Factory (1-3) Personality Memories Switcher Installation Custom Recall Factory (2-3) Default Recall Factory (2-3) Default Recall Factory (3-3) Default Recall Factory (3-3) Recall Factory	Clips	System Shutdown	• Status	Aux Bus	Remote Enables	4 Setup	More
Panel Diagnostics Diagnostics Options Personality Installation More Installation (1-3) BNC Config Aux Bus Comm Output GPI I/O More Installation (2-3) Custom Controls Reference Calibration MultiPanel Audio Processor More Installation (3-3) Personality Memores Switcher Installation Controls Video Processor More Recall Factory (1-3) Personality Memores Switcher Installation Recall Factory (2-3) Default Default Default Default Bus Maps Box Pages File Recall Factory (3-3) Default Default Bus Maps Box Pages File Recall Factory (3-3) Default Default Bus Maps Box Pages File Recall Factory (3-3) Default Default Bus Maps Box Pages File	Setup (1-3)	100					
Installation (1-3) BNC Config Aux Bus Comm Setup Output GPI (IO Installation (2-3) Custom Controls Reference Calibration MultiPanel Audio Video Processor More Installation (3-3) Recall Factory (1-3) Personality Memories Switcher Installation Recall Factory (2-3) Default Default Default Default Default Shot Camera Recall Factory (3-3) Default Recall Factory (3-3) Default More	3	Panel Diagnostics	Frame Diagnostics	Options 3	Personality	Installation	Mare
Installation (1-3)     BNC     Config     Aux Bus     Comm     Output     Installation (2-3)     Custom     Custom     Recall     Personality     Memories     Switcher     Installation     Custom     Personality     Memories     Switcher     Installation     Custom     Personality     Memories     Switcher     Installation     Custom   Personality     Memories     Switcher     Installation     Custom   Default   Default   Default   Default   Default   Mutri-Viewer     Wore     Processor     Wide     Processor     Personality     Memories     Switcher   Installation   Custom   Default   Default   Default   More     Processor     Processor     Personality     Memories     Switcher     In							_
Installation (2-3) Custom Controls Reference Installation (3-3) Recall Factory (1-3) Personality Memories Recall Factory (2-3) Default NV:RAM Default More	BNC	Key 4     Config	🕹 Aux Bus	Comm Setup	Output	🚯 GPI I/O	Mare
Custom Controls Reference Calibration MultiPanel Audio Video Processor More Installation (3-3) Recall Factory (1-3) Personality Memories Switcher Installation Recall Factory (2-3) Default NV:RAM Default Default NV:RAM SaT Bus Maps Default Shot Recall Factory (3-3) Default NV:RAM SaT Bus Maps Default Shot Recall Factory (3-3) Default More Recall Factory (3-3) Default Multi-Viewer	Installation	(2-3)					-
Installation (3-3) Recall Factory (1-3) Personality Memories Switcher Installation Custom Default Recall Factory (2-3) Default Default Default Bus Maps Box Pages File Attachments Minine Recall Factory (3-3) Default Shot Camera CC / Macro Attachments Minine Recall Factory (3-3) Default Multi-Viewer	Custom     Controls	- Reference	Calibration	4 MultiPanel	🕹 Audio	Video Processo	, More
Personality Memories Switcher Installation Custom Default Personality Memories Switcher Installation Custom Default Recall Factory (2-3) Default Default Default Bus Maps Box Pages File Attachments More Recall Factory (3-3) Default Multi-Viewer More	Install	ation (3-3)					-
Personality Memories Switcher Installation Custom Default Windre Recall Factory (2-3) Default Default Default Bus Maps Box Pages File Attachments Windre Recall Factory (3-3) Default Multi-Viewer					- Ja	4 f	actory Mor
Personality     Memories     Switcher     Installation     Custom Controls     Default VTR Clips     More       Recall Factory (2-3)     Default     Default     Default     Camera     CC / Macro Attachments     More       NV-RAM     S6T     Bus Maps     Box Pages     File     Attachments     More       Recall Factory (3-3)     Default Multi-Viewer     Offault Multi-Viewer     More	Recall Factory (1-	3)					_
Recall Factory (2-3)         Default       Default         NV-RAM       SGT         Bus Maps       Box Pages         File       Attachments         Recall Factory (3-3)         Default       More         Multi-Viewer       Image: State S	Personality	Memories	Switcher	stallation	Custom Controls	Default VTR Clips	Mare
Default         Default         Default         Default Shot         Camera         CC / Macro         More           NV-RAM         SGT         Bus Maps         Box Pages         File         Attachments         More           Recall Factory (3-3)         Default         Multi-Viewer         Image: Source State Stat	Recall Facto	ry (2-3)					_
Recall Factory (3-3) Default Multi-Viewer	Default NV-RAM	Default S&T	Default Bus Maps	Default Shot Box Pages	Camera File	CC / Macro Attachments	More
Default Multi-Viewer	Recall	Factory (3-3)			_	_	_
	Defau Multi-V	t Ziewer					Mor

Figure 19.12 Recall Factory Menu Tree

# Squeeze & Tease and Effects Menu Tree

### **Effects Menu Tree**

Main Mer	u (1-2)
Custo Contr	m Disk Attributes 4 Help Overlay 6 Effects 6 More
_	
Effects (1	-3)
	tup Border Still Store Squeeze & BKGD Gen Pattern Min Mare
Effe	ects (2-3)
4	Remote Ctrl & Mask & MultiDSK & Audio Video CC Shot Box @ More
100	Effects (3-3)
	MLE     A Positioner     A WhiteFlash     Key     GPI     GPI     GPI     GPI     GPI     GPI

Figure 19.13 Effects Menu Tree

### Squeeze & Tease MD Position/Crop Menu Tree



Figure 19.14 Squeeze & Tease MD Position/Crop Menu Tree

### Squeeze & Tease MD Border Menu Tree

Border	and a second		pro-		
	Sequence	Channel Management	Preprocessor	♣ Lighting	More More
		<u>۲</u>			_
		•			
Style	Color	Advanced	Auto Defaults	Channel 1	-
	Style	style Color	Style Color Advanced	Style Color Advanced Auto Defaults	Style Color Advanced Auto Defaults Channel

Figure 19.15 Squeeze & Tease MD Border Menu Tree

### Squeeze & Tease MD Sequence Menu Tree

Position / Crop	4 Border	Sequence	Channel Management	Preprocessor	Lighting	Mare Mare
						_
&T MD Sequer	nce (1-2)					
&T MD Sequer	nce (1-2)	Next Keyframe	Insert Keyframe	Duration	Overwrite Keyframe	More
&T MD Sequer	nce (1-2)	Next Keyframe	Insert Keyframe	Duration	Overwrite Keyframe	More

Figure 19.16 Squeeze & Tease MD Sequence Menu Tree

### **Channel Management Menu Tree**

Position / Crop	4 Border	Sequence	Channel     Management	Preprocessor	Lighting	Mare
_			7			
annel Manag	jement (1-2)		<b>•</b>			
annel Manaç Channel 1 <b>On</b> /off	Channel 2 On/Off				Layering	More
annel Manag Channel 1 On/off Channel I	Channel 2 Channel 2 On/ <b>Off</b> Management (2	2-2)			Layering	More

Figure 19.17 Channel Management Menu Tree

### Squeeze & Tease MD Preprocessor Menu Tree

Position / Crop	4 Border	Sequence	Channel     Management	Preprocessor	Lighting	🖏 Man
&T MD Prepr	ocessor					_

Figure 19.18 Squeeze & Tease MD Preprocessor Menu Tree

### Squeeze & Tease MD Lighting Menu Tree



Figure 19.19 Squeeze & Tease MD Lighting Menu Tree

### Squeeze & Tease WARP Menu Tree



Figure 19.20 Squeeze & Tease WARP Menu Tree
# **Appendix B. Specifications**

## In The Appendix

This appendix provides technical specifications and connector pinout diagrams for the Vision switcher.

The following topics are discussed in this appendix:

- Standard Components
- General Switcher Specifications
- Physical Specifications
- Communication Specifications
- Video Characteristics
- Frame Pinouts
- Control Panel Pinouts
- Control Panel CPU Module Ports
- Remote Aux Panel Pinouts
- Aux Panel Programming Mode Summary

## **Standard Components**

The following components are standard on all models:

- Complete Control Panel
- 2 UltraChrome<sup>TM</sup> Chroma keys per full MLE
- 8 Pattern Generators per full MLE
- Wipes in full Program/Preset
- 32 Timed Aux Buses
- Hard Disk Drive and USB Ports for file storage
- Touchscreen Display
- Custom Control Macro Buttons
- 100 Event Memory System
- 10 GPI Inputs and 10 GPI Outputs
- 72 Tally Outputs
- Switcher Manuals
- 1 Year Transferable Warranty

## **General Switcher Specifications**

The information provided in the following table (**Table 20.1**) lists the general specifications of the switcher with all options installed.

Switcher	MLEs	Input BNCs	Buttons/Bus	Output BNCs	Keys/MLE
8 MLE Octane/QMD-X	8	96	40	48	4
7 MLE Octane/QMD-X	7	96	40	48	4
6 MLE Octane/QMD-X	6	96	40	48	4
5 MLE Octane/QMD-X	5	96	40	48	4
4 MLE QMD-X	4	96	40	48	4
4 MLE MD-X	4	96	40	48	2
4 MLE QMD	4	48	40	16	4
3 MLE QMD-X	3	96	32	48	4
3 MLE MD-X	3	96	32	48	2
3 MLE QMD	3	48	32	16	4
2 MLE QMD-X	2	96	16	48	4
2 MLE MD-X	2	96	16	48	2
2 MLE QMD	2	48	16	16	4
2 MLE MD	2	32	16	16	2
1 MLE QMD-X	1	96	16	48	4
1 MLE MD-X	1	96	16	48	2
1 MLE QMD	1	48	16	16	4
1 MLE MD	1	32	16	16	2

Table 20.1 General Specifications

## **Control Panel Power Supplies**

The Vision control panels use a 250 or 500 Watt Power Supply Module, depending on the control panel you have (**Table 20.2**).

Table 20.2 Control Panel Power Supply Modules

	Vision 4	Vision 3	Vision 2X	Vision 3M	Vision 2M	Vision 2	Vision 1M	Vision 1
Power Supply	500W	500W	250W	500W	250W	250W	250W	250W

### **Power Consumption – Control Panel**

The information provided in the following table (**Table 20.3**) lists power consumption for each Vision control panel at average (8% Panel Glow) and peak power (100% Panel Glow) consumption.

Parameter	Power Consumption (average) / (peak)
Input Voltage	90V~250V AC, 47~63Hz
Vision 4	206W / 526W
Vision 3M	150W / 340W
Vision 3	161W / 379W
Vision 2X	133W / 289W
Vision 2M	120W / 247W
Vision 2	111W / 216W
Vision 1M	99W / 177W
Vision 1	94W / 159W

Table 20.3 Vision Control Panel Power Consumption

## **Frame Power Supplies**

The Octane/QMD/X and MD/X frames use a 500 or 700 Watt Power Supply, depending on the frame you have (**Table 20.4**). The following table provides the number of power supplies that are required for a fully populated frame.

Table 20.4 Frame Power Supply Modules for Fully Populated Frame

	Octane/QMD-X	MD-X	QMD	MD
Power Supply Watts	700W	500W	700W	500W
Number of Supplies (Min/Max)	2/4	3/4	1/2	1/2

### **Power Consumption – Frame**

The information provided in the following table (**Table 20.5**) lists power consumption for the Octane/QMD/X and MD/X frames.

Frame	Parameter	Power Consumption				
		100-120V~				
		220-240V~				
Power Supply F	Power Supply Rating	47-63 Hz				
Octane/OMD-X	9A 650W	9A 650W				
		(Canada 120V~ only)				
	Base System	~225W				
	Fully Loaded	~1160W				

Table 20.5	Frame	Power	Consumptio	on
10010 2010	<i>i</i> i anio	1 01101	oonoumpac	

Frame	Parameter	Power Consumption		
		100-120V~		
		220-240V~		
	Power Supply Rating	47-63 Hz		
MD-X QMD		9A 650W		
		(Canada 120V~ only)		
	Base System	~225W		
	Fully Loaded	~975W		
OMD		100-120V~		
		220-240V~		
	Power Supply Rating	47-63 Hz		
		9A 650W		
<b>C</b>		(Canada 120V~ only)		
	Base System	~150W		
	Fully Loaded	~500W		
		100-120V~		
		220-240V~		
MD	Power Supply Rating	47-63 Hz		
		9A 650W		
		(Canada 120V~ only)		
	Base System	~150W		
	Fully Loaded	~500W		

Table 20.5 Frame Power Consumption

## **Operating Environment Requirements**

The information provided in the following table (**Table 20.6**) lists operating environment requirements for the Vision control panel and frame.

Parameter	Specification
Ambient Temperature Range	$0 - 35^{\circ}C$
Ambient Frame Cooling	Side-to-Side airflow
Frame Power Supply Cooling	<ul><li> 500W - Passive</li><li> 700W - Active left-to-right</li></ul>
Ambient Control Panel Cooling	Passive
Control Panel Power Supply Cooling	Front-to-Back airflow

Table 20.6 Vision Operating Environment Requirements

## **Physical Specifications**

This section provides information on the physical dimensions of the control panel and frame, as well as the module sizes for the control panel.

## **Control Panel Dimensions**

The dimensions (**Figure 20.1**) of the Vision control panels are listed in the following table (**Table 20.7**) and do not include the extra height of the positioner or fader above the control panel surface.



Figure 20.1 Control Panel Dimensions

Panel	Width	Depth	Height
Vision 4	55.5 inches (1409.7 mm)	26 inches (660.4 mm)	7.9 inches (200.7 mm)
Vision 3M	45.3 inches (1150.6 mm)	20.5 inches (520.7 mm)	6.7 inches (170.2 mm)
Vision 3	51.0 inches         20.5 in           (1295.4 mm)         (520.7		6.7 inches (170.2 mm)
Vision 2X	51.0 inches         16.5 inches           (1295.4 mm)         (419.1 mm)		6.0 inches (152.4 mm)
Vision 2M	39.5 inches (1003.3 mm)	16.5 inches (419.1 mm)	6.0 inches (152.4 mm)
Vision 2	sion 2 34.0 inches (863.6 mm)		6.0 inches (152.4 mm)
Vision 1M 35.0 inches (889 mm)		16.5 inches (419.1 mm)	6.0 inches (152.4 mm)
Vision 1 28.5 inches (723.9 mm)		16.5 inches (419.1 mm)	6.0 inches (152.4 mm)

#### Table 20.7 Control Panel Dimensions

## **Control Panel Desk Cutout Dimensions**

The desk cutout dimensions of the Vision control panels are the same if you are installing the control panel in-desk or flush mounted.



Figure 20.2 Vision 4 Desk Cutout Dimensions



Figure 20.3 Vision 3M Desk Cutout Dimensions







Figure 20.5 Vision 2X Desk Cutout Dimensions







Figure 20.8 Vision 1M Desk Cutout Dimensions



Figure 20.9 Vision 1 Desk Cutout Dimensions

## **Frame Dimensions**

The information provided in the following table (**Table 20.8**) lists the frame dimensions for the frame.

Frame	Rack Units	Height	Width	Depth
Octane/QMD-X	8RU	14.13 inches (35.9 cm)	19.00 inches (48.3 cm)	26.00 inches (66.0 cm)
MD-X	8RU	14.13 inches (35.9 cm)	19.00 inches (48.3 cm)	26.00 inches (66.0 cm)
QMD	3RU	5.25 inches (13.34 cm)	19.00 inches (48.3 cm)	26.00 inches (66.0 cm)
MD	3RU	5.25 inches (13.34 cm)	19.00 inches (48.3 cm)	26.00 inches (66.0 cm)

Table 20.8 Frame Dimensions

## **Communication Specifications**

This section provides information on the default network addresses of the control panel and frame, the Module Control Link backbone of the control panel, as well as the different connector types on the control panel and frame.

### **Default Network Settings**

The Vision control panel and frame are set with default network addresses from the factory. These specific setting are listed in the table below (**Table 20.9**). The frame can be manually configured to these settings using a DIP switch on the **Frame CPU Board**.

	Frame Settings (LAN 1)	Panel Settings				
IP Address	192.168.1.1	192.168.1.2				
Subnet Mask	255.255.0.0	255.255.0.0				
Gateway	0.0.0.0	0.0.0.0				

Table 20.9 Default Network Settings

#### Frame CPU Board DIP Switch

This 8 switch DIP sets various system configurations and operational modes for the entire switcher. All DIP switches should be in the OFF position for normal operation.



Figure 20.10 Frame CPU Board — DIP Switch Location

This 8 switch DIP sets various system configurations and operational modes for the entire switcher. All DIP switches should be in the OFF position for normal operation.

Setting DIP switch **1** to **ON** defaults the IP address and netmask of the frame the next time the frame is restarted. This allows you to connect to the frame with the control panel to change the network address. Any changes to the network address will not be applied until the next time the frame is restarted.



**Caution** — Incorrect DIP switch settings may make your switcher inoperable. If your switcher does not appear to boot properly, and will not pass video, check that all DIP switches are in the **OFF** position. Do not change the position of the DIP switches unless instructed to do so by Ross Video Technical Support.

## **Module Control Link Backbone**

The Module Control Link Backbone allows the switcher to identify where a particular module has been installed by the Link and Node address it has been assigned. All modules, external and internal, for the switcher have a link and node number.

### External Links

The External Link Ports are located on the back of the control panel and support the Touchscreen Display, Auxiliary Control Panels, and any External Modules that are connected to the switcher.

The **Touchscreen Display** must be connected to **External Link Port 1** (Link 1) in order to operate properly.

### **Internal Links**

The internal links support all the modules in the Vision control panel, including the crosspoint, and custom control buttons. The module that is assigned to a particular link and node will depend on the control panel that you are using.

Link5	Link5	Link5	Link5	Link5	Link9	Link9	Link9		Link9
Node4	Node3	Node2	Node1	Node0	Node0	Node1	Node2		Node3
Link6	Link6	Link6	Link6	Link6	Link10 Link10		Link10	L	.ink10
Node4	Node3	Node2	Node1	Node0	Node0 Node1		Node2		Node3
Link7	Link7	Link7	Link7	Link7	Link11	Link11 Link11		L	.ink11
Node4	Node3	Node2	Node1	Node0	Node0	Node0 Node1			Node3
Link8	Link8	Link8	Link8	Link8	Link12	Link12	Link12		Link12
Node4	Node3	Node2	Node1	Node0	Node0	Node1	Node2		Node3

Figure 20.11 Vision 4 Control Panel — Module Control Link Backbone

Link5 Node2	Link5 Node1	Link5 Node0	Link8 Node0	Link8 Node1	Link8 Node2	Link8 Node3
Link6 Node2	Link6 Node1	Link6 Node0	Link9 Node0	Link9 Node1	Link9 Node2	Link9 Node3
Link7 Node2	Link7 Node1	Link7 Node0	Link10 Node0	Link10 Node1	Link10 Node2	Link10 Node3

Figure 20.12 Vision 3M Control Panel — Module Control Link Backbone

Link5 Node3	Link5 Node2	Link5 Node1	Link5 Node0	Link8 Node0	Link8 Node1	Link8 Node2	Link8 Node3
Link6 Node3	Link6 Node2	Link6 Node1	Link6 Node0	Link9 Node0	Link9 Node1	Link9 Node2	Link9 Node3
Link7 Node3	Link7 Node2	Link7 Node1	Link7 Node0	Link10 Node0	Link10 Node1	Link10 Node2	Link10 Node3

Figure 20.13 Vision 3 Control Panel — Module Control Link Backbone

Link5	Link5	Link5	Link5	Link7	Link7	Link7	Link7
Node3	Node2	Node1	Node0	Node0	Node1	Node2	Node3
Link6	Link6	Link6	Link6	Link8	Link8	Link8	Link8
Node3	Node2	Node1	Node0	Node0	Node1	Node2	Node3

Figure 20.14 Vision 2X Control Panel — LVDS Backbone

Link5	Link5	Link5	Link7	Link7	Link7
Node2	Node1	Node0	Node0	Node1	Node2
Link6	Link6	Link6	Link8	Link8	Link8
Node2	Node1	Node0	Node0	Node1	Node2





Figure 20.16 Vision 2 Control Panel — Module Control Link Backbone

Link5	Link5	Link5	Link7	Link7
Node2	Node1	Node0	Node0	Node1
Link6	Link6	Link6	Link8	Link8
Node2	Node1	Node0	Node0	Node1

Figure 20.17 Vision 1M Control Panel — Module Control Link Backbone



Figure 20.18 Vision 1 Control Panel — Module Control Link Backbone

#### For More Information...

• on the Aux Ports, refer to the section "Communication Ports" on page Eng 2-15.

## Frame Connector Types

The information provided in the following table (**Table 20.10**) lists the connector types for each connection on the frame.

Parameter	Specification
Video	BNC Type (Female)
Reference	BNC Type (Female)
Peripheral Ports	DB9 (Female)
GPI I/O	DB25 (Female)
Panel Port (legacy control panel)	RJ-45
LAN Ports	RJ-45
USB Ports	USB 1.1 Compatible, Type A (host)
AC Power (primary, redundant)	3-Pin IEC

Table 20.10 Frame Connector Specifications

## **Control Panel Connector Types**

The information provided in the following table (**Table 20.11**) lists the connector types for each connection on the control panel.

Parameter	Specification
Remote Ports	DB9 (Female)
Tally Ports	DB25 (Female)
External Link Ports	RJ-45
Ethernet Port	RJ-45
USB Ports	USB 1.1 Compatible, Type A (host)
AC Power (primary, redundant)	3-Pin IEC
DVI Video	DVI-D
Mouse Port	PS/2
Keyboard Port	PS/2

Table 20.11 Control Panel Connector Specifications

## **Video Characteristics**

This section provides information on the video formats, timing, and input and outputs that the Vision switcher uses.

## **Video Processing**

The Vision switcher has the following video processing characteristics:

- 10 bit 4:2:2 Component Digital Video and Key Processing
- 4:3 and Anamorphic 16:9 switchable Aspect Ratio where applicable

### **Video Formats**

The Vision switcher supports the following Input Reference and Video Formats (Table 20.12).

Input Reference	Usable Format
	• 480i
480i	• 480i 16:9
	• 1080i 59.94 Hz*
	• 576i
576i	• 576i 16:9
	• 1080i 50 Hz*
720p 59.94 Hz	• 720p 59.94 Hz
720p 50 Hz	• 720p 50 Hz
	• 480i
1090: <b>5</b> 0 04 Hz	• 480i 16:9
10801 39.94 HZ	• 720p 59.94 Hz
	• 1080i 59.94 Hz
	• 576i
1080; 50 Ц7	• 576i 16:9
10801 30 HZ	• 720p 50
	• 1080i 50 Hz
1080p 24 Hz	• 1080p 24 Hz
1080pSF 24 Hz	• 1080pSF 24 Hz
1080pSF 23.98 Hz	• 1080pSF 23.98 Hz

Table 20.12 Compatible Video Formats



\*Important — It is not recommended that you operate the switcher in these video formats when you are using a composite sync (480i or 576i) reference signal.

## Timing

The Vision switcher has the following system timing characteristics:

- All video inputs are zero-time relative to reference input
- Auto timing correct for inputs out of sync by up to  $\pm \frac{1}{4}$  line (16us)

## LTC Timecode Input

The information provided in the following table (**Table 20.11**) lists the LTC Timecode specifications.

Parameter	Specification		
Signal Level	0.5 - 2.0V (1.0V nominal)		
Termination	600 ohm, soft-selectable		

Table 20.13 LTC Timecode Specifications

## **Video Input Signal Characteristics**

The information provided in the following table (**Table 20.14**) lists the video input signal characteristics.

Parameter	Specification
Equalization (using Belden 1694 cable)	>75m @ 1.5 Gb/s >150m @ 270 Mb/s
Impedance	75 ohm, terminating
Return Loss	>20 dB @ 1.5 GHz
Video Inputs	SMPTE 259M/292M serial digital (non-looping)
Reference Inputs (non-terminating, looping)	<ul> <li>Standard Definition — analog black</li> <li>High Definition — tri-level sync</li> </ul>

Table 20.14 Video Input Signal Characteristics

## **Video Output Signal Characteristics**

The information provided in the following table (**Table 20.15**) lists the video output signal characteristics.

	Julpul Signal Characteristics
Parameter	Specification
Return Loss	>18 dB @ 1.5 GHz
Output Jitter	<130 ps
	800 ps ± 10% (SD)
Rise and Fall times	240 ps ± 10% (HD)
Signal Level	$800 \text{ mV} \pm 10\%$
DC Offset	0 volts
Overshoot	<8%
Video Outputs (serial	• SD Mode — 10-bit SMPTE 259M-C
digital)	• HD Mode — 10-bit SMPTE 292M

Table 20.15 Video Output Signal Characteristics



**Note** — In SD Mode, Error Detection and Handling (EDH) signals are inserted into all video outputs, and can be disabled. Aux Bus outputs do not have EDH insertion, but do pass previously inserted EDH.

## **Frame Pinouts**

This section provides pinout information for the ports found on the frame.

## **Peripheral Ports**

The **4** DB9 Peripheral ports (**Figure 20.19**) on the back of the frame support both the RS-232 (TIA/EIA-232) and RS-422 (TIA/EIA-422) transmission standards. The following table (**Table 20.16**) lists the signal pinouts for the Peripheral ports.



Figure 20.19 Peripheral Port — Female

Pin	RS-232	RS-422
1	n/c	Odd/Even Tx+
2	Rx	TxA (Tx-)
3	Tx	RxB (Rx+)
4	Ground	Ground
5	Ground	Ground
6	n/c	Odd/Even Tx-
7	n/c	TxB (Tx+)
8	n/c	RxA (Rx-)
9	n/c	5V 1K Pull-up

#### Table 20.16 Peripheral Port Pinouts

## **Panel Port**



**Note** — The Panel port is not used by the Vision control panel. The Panel port is only used to connect to the Synergy control panel.

The single RJ-45 Panel port (**Figure 20.20**) on the back of the frame supports the RS-422 transmission standard for direct connection to the control panel. The following table (**Table 20.17**) lists the signal pinouts for the Panel ports.



Figure 20.20 Panel Port — Female

Pin	Signal
1	TxB (Tx+)
2	TxA (Tx-)
3	RxB (Rx+)
4	RxA (Rx-)
5	Odd/Even+ (Transmit)
6	Odd/Even- (Transmit)
7	Ground (AC coupled)
8	Ground (AC coupled)

#### Table 20.17 Panel Port Pinouts

### **GPI I/O Ports**

The single DB25 GPI I/O port (**Figure 20.21**) on the back of the frame supports a total of **10 GPI Inputs** and **10 GPI Outputs**. The following table (**Table 20.18**) lists the signal pinouts for the GPI I/O port.

- **GPI Inputs** Active Drive 5V TTL-compatible signal
- **GPI Outputs** 5V TTL-compatible edge or level trigger



Figure 20.21 GPI I/O Port — Female

#### Table 20.18 GPI I/O Port Pinouts

Pin	Signal
1	Ground
2	n/c
3	n/c
4	GPI In 10
5	GPI In 9
6	GPI In 8
7	GPI In 7
8	GPI In 6
9	GPI In 5
10	GPI In 4
11	GPI In 3
12	GPI In 2
13	GPI In 1

Pin	Signal
14	n/c
15	n/c
16	GPI Out 10
17	GPI Out 9
18	GPI Out 8
19	GPI Out 7
20	GPI Out 6
21	GPI Out 5
22	GPI Out 4
23	GPI Out 3
24	GPI Out 2
25	GPI Out 1

#### Table 20.18 GPI I/O Port Pinouts

### **LAN Ports**

The **2** RJ-45 LAN ports (**Figure 20.22**) on the back of the frame support 10Base-T and 100Base-TX Ethernet communication. The following table (**Table 20.19**) lists the signal pinouts for the LAN port.



Figure 20.22 LAN Port — Female

#### Table 20.19 LAN Port Pinouts

Pin	Signal
1	Tx+
2	Tx-
3	Rx+
4	n/c
5	n/c
6	Rx-
7	n/c
8	n/c

### **AC Power Ports**

The 3-pin IEC AC Power ports (**Figure 20.23**) on the back of the frame deliver AC power to the power supplies in the frame. The following table (**Table 20.20**) lists the signal pinouts for the AC Power ports.



Figure 20.23 AC Power Port — Male

#### Table 20.20 AC Power Port Pinouts

Pin	Signal
1	Neutral/Line 2
2	Line
3	Ground

## **Control Panel Pinouts**

This section provides pinout information for the ports found on the Vision control panel.

### **Remote Ports**

The **8** DB9 Remote ports (**Figure 20.24**) on the back of the control panel support both the RS-232 (TIA/EIA-232) and RS-422 (TIA/EIA-422) transmission standards. The following table (**Table 20.21**) lists the signal pinouts for the Remote ports.



Figure 20.24 Remote Port — Female

Pin	RS-232	RS-422		
1	n/c	n/c		
2	Tx	RxA (Rx-)		
3	Rx	TxB (Tx+)		
4	Ground	Ground		
5	Ground	Ground		
6	n/c	n/c		
7	n/c	RxB (Rx+)		
8	n/c	TxA (Tx-)		
9	n/c	n/c		

#### Table 20.21 Remote Port Pinouts

## **External Link Ports**

The **4** RJ-45 External Link ports (**Figure 20.25**) on the back of the frame support the Touchscreen Display, the external control panel modules, Remote Aux Panels, and the Auxiliary Control Panels. The following table (**Table 20.22**) shows the signal pinouts for the External Link ports.



Figure 20.25 External Link Port — Female



**Note** — The Touchscreen Display must be connected to External Link port 1 (Link 1) in order to operate properly.

Pin	Signal
1	RxB (Rx+)
2	RxA (Rx-)
3	TxB (Tx+)
4	PMC_SDI_Load+
5	PMC_SDI_Load-
6	TxA (Tx-)
7	PMC_SDI_Latch+
8	PMC_SDI_Latch-

Table 20.22 External Link Port Pinouts

### **Tally Ports**

The DB25 Tally ports (**Figure 20.26**) on the back of the control panel provide the solid state contact closure to tally common tally signals. The following table (**Table 20.23**) lists the signal pinouts for the Aux ports.

• Tally Rating: 150mA @ 100V DC (25°C operating temperature)



Figure 20.26 Tally Port — Female



**Note** — Tally Ports **3** through **8** are used for the extended tallies option and require the extended tallies hardware to be installed before they can be used.

Pin	Tally Port 1	Tally Port 2	Tally Port 3	Tally Port 4	Tally Port 5	Tally Port 6	Tally Port 7	Tally Port 8
1	Tally 1	Tally 19	Tally 37	Tally 55	Tally 73	Tally 91	Tally 109	Tally 127
2	Tally 3	Tally 21	Tally 39	Tally 57	Tally 75	Tally 93	Tally 111	Tally 129
3	Tally 5	Tally 23	Tally 41	Tally 59	Tally 77	Tally 95	Tally 113	Tally 131
4	Tally 7	Tally 25	Tally 43	Tally 61	Tally 79	Tally 97	Tally 115	Tally 133
5	Tally 9	Tally 27	Tally 45	Tally 63	Tally 81	Tally 99	Tally 117	Tally 135
6	Tally 11	Tally 29	Tally 47	Tally 65	Tally 83	Tally 101	Tally 119	Tally 137
7	Tally 13	Tally 31	Tally 49	Tally 67	Tally 85	Tally 103	Tally 121	Tally 139
8	Tally 15	Tally 33	Tally 51	Tally 69	Tally 87	Tally 105	Tally 123	Tally 141
9	Tally 17	Tally 35	Tally 53	Tally 71	Tally 89	Tally 107	Tally 125	Tally 143
10	Common							
11	Common							
12	Common							
13	Common							

Table 20.23 Tally Port Pinouts

Pin	Tally Port 1	Tally Port 2	Tally Port 3	Tally Port 4	Tally Port 5	Tally Port 6	Tally Port 7	<b>Tally Port 8</b>
14	Tally 2	Tally 20	Tally 38	Tally 56	Tally 74	Tally 92	Tally 110	Tally 128
15	Tally 4	Tally 22	Tally 40	Tally 58	Tally 76	Tally 94	Tally 112	Tally 130
16	Tally 6	Tally 24	Tally 42	Tally 60	Tally 78	Tally 96	Tally 114	Tally 132
17	Tally 8	Tally 26	Tally 44	Tally 62	Tally 80	Tally 98	Tally 116	Tally 134
18	Tally 10	Tally 28	Tally 46	Tally 64	Tally 82	Tally 100	Tally 118	Tally 136
19	Tally 12	Tally 30	Tally 48	Tally 66	Tally 84	Tally 102	Tally 120	Tally 138
20	Tally 14	Tally 32	Tally 50	Tally 68	Tally 86	Tally 104	Tally 122	Tally 140
21	Tally 16	Tally 34	Tally 52	Tally 70	Tally 88	Tally 106	Tally 124	Tally 142
22	Tally 18	Tally 36	Tally 54	Tally 72	Tally 90	Tally 108	Tally 126	Tally 144
23	Common							
24	Common							
25	Common							

Table 20.23 Tally Port Pinouts

### **AC Power Ports**

The **2** 3-pin IEC AC Power ports (**Figure 20.27**) on the back of the control panel deliver AC power to the power supplies in the control panel. The following table (**Table 20.24**) lists the signal pinouts for the AC Power ports.



Figure 20.27 AC Power Port — Male

#### Table 20.24 AC Power Port Pinouts

Pin	Signal	
1	Neutral/Line 2	
2	Line	
3	Ground	

## **Control Panel CPU Module Ports**

The Control Panel CPU Module houses the Single Board Computer (SBC) and the Panel Communications Hub (PCH). This module performs all the command and control functions between the different modules on the control panel, and the frame.

This section identifies and describes the various functional components and rear panel connections found on the Control Panel CPU Module.



**Important** — The Control Panel CPU Module is designed to be a closed module and should not be opened or serviced except by Ross Video Technical Support.

## **Control Panel CPU Module Functional Components**

The top of the Control Panel CPU Module (Figure 20.28) has a number of different ports and connections.



Figure 20.28 Control Panel CPU Module — Functional Components

1) Power Connector	4) Power Status Port	7) Reset Button
2) Module Control Link Ports	5) Tally Interface Port	8) Power Switch
3) Fan Status Port	6) Tally Power Connector	9) DIP Switches

#### 1. Power Connector

The power connector uses a single 4-Pin, friction fit Molex connector to provide 12V DC to the Control Panel CPU Module from the Power Distribution Board.

#### 2. Module Control Link Ports

The Module Control Link backbone uses 10, independent, 8-Pin, RJ-45 connectors to interface to the various internal PMCs on the control panel modules.

#### 3. Fan Status Port

The Fan Status Port uses a single 8-Pin, RJ-45 connector to interface with the Power Distribution Board to pass fan status information from the individual cooling fans.

#### 4. Power Status Port

The Power Status Port uses a single 8-Pin, RJ-45 connector to interface with the Power Distribution Board to pass power supply status information from the individual power supplies.

#### 5. Tally Interface Port

The Tally Interface Port uses a single 8-Pin, RJ-45 connector to interface with the tally board.

#### 6. Tally Power Connector

The tally power connector uses a single 2-Pin, friction fit Molex connector to provide power to the **Tally Boards**.

#### 7. Reset Button

The Reset Button performs a hard reset of the Single Board Computer (SBC). This will re-start the control panel software.

#### 8. Power Switch

The Power Switch will power on and off the Single Board Computer (SBC).

#### 9. DIP Switch

This 8 switch DIP sets various control panel configurations and operational modes. Switches **2** through **8** should be in the **OFF** position for normal operation.

If you have a **Vision 1** or **Vision 2** control panel, switch 1 should be in the **OFF** position. If you have a **Vision 3** or **Vision 4** control panel, switch 1 should be in the **ON** position.

## **Control Panel CPU Module Rear Panel**

The rear panel of the Control Panel CPU Module (Figure 20.29) has a number of different ports and connections



Figure 20.29 Control Panel CPU Module — Rear Panel

1)	Serial Communications Ports	4) Keyboard Port	7) Ethernet Port
2)	External Link Ports	5) DVI Port	
3)	USB Ports	6) Mouse Port	

<sup>1</sup> 

**Note** — Other ports found on the Control Panel CPU Module are not supported at this time and should not be used.

#### 1. Serial Communications Ports

The **8** Serial Communications Ports, or Remote Ports, use 9-Pin, DB9 connectors to interface with external devices using either an RS-232 (TIA/EIA-232) or RS-422 (TIA/EIA-422) transmission standard.

#### 2. External Link Ports

The **4** External Link Ports use 8-Pin, RJ-45 connectors to interface with the Touchscreen Display, Auxiliary Control Panels, and Remote AUX Panels.

#### 3. USB Ports

The **2** USB Ports use 4-Pin, USB Type-A connectors to interface with the touchscreen controller on the Touchscreen Display, as well as other supported USB devices.

#### 4. Keyboard Port

The Keyboard Port uses a purple, 6-Pin, PS/2 connector to interface with a standard keyboard.

#### 5. DVI Port

The DVI Port uses a single 24-Pin, DVI-D connector to interface with the LCD display on the Touchscreen Display.

#### 6. Mouse Port

The Mouse Port uses a green, 6-Pin, PS/2 connector to interface with a standard mouse.

#### 7. Ethernet Port

The Ethernet Port uses a single 8-Pin, RJ-45 connector to interface with a local network, and the control panel, using a 10/100 BASE-T network.

## **Remote Aux Panel Pinouts**

## **GPI Port**

The DB9 GPI port (**Figure 20.30**) on the back of the Remote Aux Panel provide a total of **8** GPI Inputs. The following table (**Table 20.25**) lists the signal pinouts for the GPI I/O port.





**Important** — Remote Aux Panel GPI inputs are only intended for connection to "dry contact", open collector type transistor outputs, or +5 VDC signals. Application of any negative voltages, or voltages in excess of +5 VDC, may damage the GPI inputs.

Pin	Signal
1	GPI 1
2	GPI 2
3	GPI 3
4	GPI 4
5	GPI 5
6	GPI 6
7	GPI 7
8	GPI 8
9	Ground

### Table 20.25 GPI I/O Port Pinouts

### **Main Port**

The RJ-12 Main port (**Figure 20.31**) on the back of the Remote Aux Panel connects to the Aux port on the control panel, or the Echo port on the previous aux panel in the daisy-chain. The following table (**Table 20.27**) shows the signal pinouts for the Aux ports.



Figure 20.31 Main Port — Female

Pin	Signal
1	TxA (Tx-)
2	TxB (Tx+)
3	RxA (Rx-)
4	RxB (Rx+)
5	RESET (In)
6	Ground

Table 20.26 Main Port Pinouts

## **Echo Port**

The RJ-12 Echo port (**Figure 20.32**) on the back of the Remote Aux Panel connects to the Main port on the next aux panel in the daisy-chain. The following table (**Table 20.26**) shows the signal pinouts for the Aux ports.



Figure 20.32 Echo Port — Female

#### Table 20.27 Echo Port Pinouts

Pin	Signal
1	RxA (Rx-)
2	RxB (Rx+)
3	TxA (Tx-)
4	TxB (Tx+)
5	RESET (Out)
6	Ground

## Aux Panel Programming Mode Summary

This section describes the normal, GPI, and diagnostic Remote Aux Panel programming modes.

Button/ LED	Normal Mode	Programming Mode Bus Assignment <sup>a</sup>	Programming Mode GPI Offset	Power Up Diagnostics	
1	Select Crosspoint 1	Display/Modify Access Right to Aux Bus 1	Set GPI to group 1, offset 0 b	Start Walking LED Test <sup>c</sup>	
2	Select Crosspoint 2	Display/Modify Access Right to Aux Bus 2	Set GPI to group 2, offset 1	Start Button LED Test	
3	Select Crosspoint 3	Display/Modify Access Right to Aux Bus 3	Set GPI to group 3, offset 2	Start DUART Test <sup>d</sup>	
4	Select Crosspoint 4	Display/Modify Access Right to Aux Bus 4	Set GPI to group 4, offset 3	Start EEPROM Test	
5	Select Crosspoint 5	Display/Modify Access Right to Aux Bus 5	Set GPI to group 5, offset 4		
6	Select Crosspoint 6	Display/Modify Access Right to Aux Bus 6	Set GPI to group 6, offset 5		
7	Select Crosspoint 7	Display/Modify Access Right to Aux Bus 7	Set GPI to group 7, offset 6		
8	Select Crosspoint 8	Display/Modify Access Right to Aux Bus 8	Set GPI to group 8, offset 7		
9	Select Crosspoint 9	Display/Modify Access Right to Aux Bus 9	GPI 8 Status (on = shorted)		
10	Select Crosspoint 10	Display/Modify Access Right to Aux Bus 10	GPI 7 Status (on = shorted)		
11	Select Crosspoint 11	Display/Modify Access Right to Aux Bus 11	GPI 6 Status (on = shorted)		
12	Select Crosspoint 12	Display/Modify Access Right to Aux Bus 12	GPI 5 Status (on = shorted)		
13	Select Crosspoint 13		GPI 4 Status (on = shorted)		
14	Select Crosspoint 14		GPI 3 Status (on = shorted)		
15	Select Crosspoint 15		GPI 2 Status (on = shorted)		
16	Select Crosspoint 16		GPI 1 Status (on = shorted)	LED used in EEPROM test	
17/Shift	Select Crosspoint 17 or Shift	Allow access to Shifted Crosspoints <sup>e</sup>			
Clean Feed		GPI Programming Mode	Assignment Programming Mode		
Program		Send Software Version to panel.	Send Software Version to panel.		
Active LED	Selected aux crosspoint is used in Program output	Flashing	Flashing (along with Clean Feed button)	Test Fail Status <sup>f</sup>	

#### Table 20.28 Remote Aux Panel Programming Mode Button Assignment

- a. For the first 12 indicators in the column, information applies to the Vision 3 and 4 Assignable Remote Aux Panels only. The Vision 2 Assignable Remote Aux Panels use the 12 Assignment buttons on the bottom row of the panel.
- b. Indicator show the current group setting. Only one indicator in the first eight buttons can be on at a time. A panel that has never been programmed my have all the indicators off at first.
- c. On the Vision 3 Remote Aux Panel, the indicator is button Shift/30. On the Vision 4, the indicator is button Shift/35.
- d. Requires a special Loop Back Adapter.
- e. Does not show special shifted modes, such as Reverse Shift.
- f. In the EEPROM and DUART tests, the Active LED indicates that the test failed. If the crosspoint 1 button is lit, the test passed.

# **Appendix C. Worksheets**

## In The Appendix

This appendix provides worksheets that can be used when setting up and using your Vision switcher.

The following worksheets are provided:

- Video Input Worksheet
- Bus Map Worksheet
- Video Output Worksheet
- Communications Worksheet
- Standard GPI I/O Input Worksheets
- Standard GPI I/O Output Worksheets
- Aux Panel GPI I/O Worksheet
- Custom Control Worksheets
- Conversion Loop Worksheets
- Custom Device Protocol Worksheets

## Video Input Worksheet

The video input worksheet (**Table 21.2**) helps you to identify which video source is connected to which Input BNC, and what device that source is coming from.

Input BNC	Source/ Device	Video Format	Serial Port	Device Address	Input Name	Input Type	Tally Number	Alpha Type	Auto Key	Audio Channel
X1	VTR 1	1080i 50	R1		VTR Blue	VTR	12			
X2	CG Alpha	720p 60	R2		CG Alpha	Alpha		Unshaped	C15	

Table 21.1 Sample Video Input Worksheet

Table 21.2	Video	Input	Worksheet
------------	-------	-------	-----------

Input BNC	Source/ Device	Video Format	Serial Port	Device Address	Input Name	Input Type	Tally Number	Alpha Type	Auto Key	Audio Channel
Input BNC	Source/ Device	Video Format	Serial Port	Device Address	Input Name	Input Type	Tally Number	Alpha Type	Auto Key	Audio Channel
--------------	-------------------	-----------------	----------------	-------------------	---------------	---------------	-----------------	---------------	-------------	------------------

Table 21.2 Video Input Worksheet

Input BNC	Source/ Device	Video Format	Serial Port	Device Address	Input Name	Input Type	Tally Number	Alpha Type	Auto Key	Audio Channel

 Table 21.2
 Video Input Worksheet

Table 21.2 Video Input Worksheet

Input BNC	Source/ Device	Video Format	Serial Port	Device Address	Input Name	Input Type	Tally Number	Alpha Type	Auto Key	Audio Channel

## **Bus Map Worksheet**

The bus map worksheet (**Table 21.4**) helps you to identify which sources you have mapped to each crosspoint button for a given bus map. Additional bus map worksheets will have to be created for each bus map.

Crosspoint Button	Input BNC	Input Name	Internal Signal	Shift to Map #
5	C06	VTR-1		
24				Map 5
1			MLE-Store 1	

Table 21.3	Sample Bus	Map	Worksheet
10010 21.5	oumpic bus	map	<b>WORKSHEEL</b>

Bus Map: \_\_\_\_\_

		.4 Dus Map W	UINSIIEEL	
Crosspoint	Input	Input	Internal	Shift to
Button	BNC	Name	Signal	Map #
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				

Table 21.4 Bus Map Worksheet

Crosspoint Button	Input BNC	Input Name	Internal Signal	Shift to Map #
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				
51				
52				
53				
54				
55				
56				
57				

Table 21.4 Bus Map Worksheet

Crosspoint Button	Input BNC	Input Name	Internal Signal	Shift to Map #
58				
59				
60				
61				
62				
63				
64				
65				
66				
67				
68				
69				
70				

Table 21.4 Bus Map Worksheet

# Video Output Worksheet

The video output worksheet (**Table 21.6**) helps you to identify which video signals have been assigned to which Output BNCs.

Output BNC	Locked Mix/DSK	Locked MultiDSK	Locked Mix/DSK and MultiDSK	Output Type	Video Format	Destination
X1				Program	1080i 50	Master Control
X2				Aux Bus 1:3	720p 60	Monitor 6

### Table 21.5 Sample Video Output Worksheet

### Table 21.6 Video Output Worksheet

Output BNC	Locked Mix/DSK	Locked MultiDSK	Locked Mix/DSK and MultiDSK	Output Type	Video Format	Destination
	Program	Program	Program			
	Mix Preview w/o Overlay	Program	Program			
	Mix Clean 1	Multi Preview w/o Overlay	Preview w/o Overlay			
	Mix Clean 2	Multi Preview w/o Overlay	Preview w/o Overlay			
	Mix Clean 3	Multi Clean 5	Clean 1			
	Mix Clean 4	Multi Clean 6	Clean 2			
			Clean 3			
			Clean 4			
			Clean 5			
			Clean 6			

Output BNC	Locked Mix/DSK	Locked MultiDSK	Locked Mix/DSK and MultiDSK	Output Type	Video Format	Destination

Table 21.6 Video Output Worksheet

## **Communications Worksheet**

The communications worksheet (**Table 21.8**) helps you to identify which external device is connected to which serial communications port, or ethernet IP address.

Port	IP Address	Device	Port on Device
Remote 1B		Router - Philips Jupiter	Port 1
Peripheral 3	192.168.1.5	Audio Mixer - Wheatstone	

Table 21.7 Sample Communications Worksheet

### Table 21.8 Communications Worksheet

1011	IF Address	Device	Port on Device

Port	IP Address	Device	Port on Device

 Table 21.8 Communications Worksheet

# Standard GPI I/O Input Worksheets

The GPI I/O Input worksheet (**Table 21.10**) helps you to identify what events or actions have been assigned to each GPI I/O input.

GPI Input	Event Type	Event Area	Polarity
GPI 1	Auto	MLE 1	Low
GPI 6	Cut	Fade-to-Black	High

### Table 21.10 GPI I/O Input Worksheet

GPI Input	Event Type	Event Area	Polarity
GPI 1			
GPI 2			
GPI 3			
GPI 4			
GPI 5			
GPI 6			
GPI 7			
GPI 8			
GPI 9			
GPI 10			

# Standard GPI I/O Output Worksheets

The GPI I/O Output worksheet (**Table 21.12**) helps you to identify what events or actions have been assigned to each GPI I/O input.

|--|

<b>GPI Output</b>	Output Name	Trigger Type	Level
GPI 1	PrevStill	Edge	Low
GPI 6	Roll VTR	Level	High

### Table 21.12 GPI I/O Output Worksheet

<b>GPI</b> Output	Event Type	Event Area	Level
GPI 1			
GPI 2			
GPI 3			
GPI 4			
GPI 5			
GPI 6			
GPI 7			
GPI 8			
GPI 9			
GPI 10			

## Aux Panel GPI I/O Worksheet

The Aux Panel GPI I/O Input worksheet (**Table 21.14**) helps you to identify what Remote Aux Panel events or actions have been assigned to each GPI input.

Aux GPI	Group	Offset	GPI	Aux Bus (BNC)	Event Area	Polarity
GPI 5	1	0	5	Bnk: Aux1 (C03)	Cam 4 joystick	

Aux GPI	Group	Offset	GPI	Aux Bus (BNC)	Event Area	Polarity
GPI 1						
GPI 2						
GPI 3						
GPI 4						
GPI 5						
GPI 6						
GPI 7						
GPI 8						
GPI 9						
GPI 10						
GPI 11						
GPI 12						
GPI 13						
GPI 14						
GPI 15						
GPI 16						
GPI 17						
GPI 18						
GPI 19						
GPI 20						
GPI 21						
GPI 22						
GPI 23						
GPI 24						
GPI 25						

### Table 21.14 Aux Panel GPI I/O Input Worksheet

Aux GPI	Group	Offset	GPI	Aux Bus (BNC)	Event Area	Polarity
GPI 26						
GPI 27						
GPI 28						
GPI 29						
GPI 30						
GPI 31						
GPI 32						
GPI 33						
GPI 34						
GPI 35						
GPI 36						
GPI 37						
GPI 38						
GPI 39						
GPI 40						
GPI 41						
GPI 42						
GPI 43						
GPI 44						
GPI 45						
GPI 46						
GPI 47						
GPI 48						
GPI 49						
GPI 50						
GPI 51						
GPI 52						
GPI 53						
GPI 54						
GPI 55						
GPI 56						
GPI 57						

Table 21.14 Aux Panel GPI I/O Input Worksheet

Aux GPI	Group	Offset	GPI	Aux Bus (BNC)	Event Area	Polarity
GPI 58						
GPI 59						
GPI 60						
GPI 61						
GPI 62						
GPI 63						
GPI 64						

Table 21.14 Aux Panel GPI I/O Input Worksheet

## **Custom Control Worksheets**

The custom control worksheet (**Table 21.16**) helps you to identify which custom controls are assigned to which button for each custom control bank. Additional worksheets will have to be created for each bank.

Number	Button	Name	Function	Device	
5	13	Shot 1	Recall Shot 1 on Camera	Telemetrics (Remote 2)	
37		Opening	Play Opening Sequence		

Custom Control Bank Name/Number: \_\_\_\_

Table 21.16         Custom Control Worksheet	
--	--

Number	Button	Name	Function	Device
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				

Number	Button	Name	Function	Device
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				

Table 21.16 Custom Control Worksheet

# **Conversion Loop Worksheets**

The conversion loop worksheet (**Table 21.18**) helps you to identify each conversion loop from the switcher, to the Up/Down Converter and back to the switcher.

Aux Bus	Output Video Format	Output Video Format	Output BNC	Input BNC	Locked to Bus	
Bank 1: Bus 1	480i 60	1080i 59.94	I16	H16		
Bank 1: Bus 2	720p 59.94	1080i 59.94	I15	H15	MLE 3 – BKGD+PST	

### Table 21.17 Sample Conversion Loop Worksheet

### Table 21.18 Conversion Loop Worksheet

Aux Bus	Output Video Format	Output Video Format	Output BNC	Input BNC	Locked to Bus
Bank 1: Bus 1					
Bank 1: Bus 2					
Bank 1: Bus 3					
Bank 1: Bus 4					
Bank 1: Bus 5					
Bank 1: Bus 6					
Bank 1: Bus 7					
Bank 1: Bus 8					
Bank 2: Bus 1					
Bank 2: Bus 2					
Bank 2: Bus 3					
Bank 2: Bus 4					
Bank 2: Bus 5					
Bank 2: Bus 6					
Bank 2: Bus 7					
Bank 2: Bus 8					
Bank 3: Bus 1					
Bank 3: Bus 2					
Bank 3: Bus 3					
Bank 3: Bus 4					
Bank 3: Bus 5					
Bank 3: Bus 6					
Bank 3: Bus 7					
Bank 3: Bus 8					
Bank 4: Bus 1					

Aux Bus	Output Video Format	Output Video Format	Output BNC	Input BNC	Locked to Bus
Bank 4: Bus 2					
Bank 4: Bus 3					
Bank 4: Bus 4					
Bank 4: Bus 5					
Bank 4: Bus 6					
Bank 4: Bus 7					
Bank 4: Bus 8					
Bank 5: Bus 1					
Bank 5: Bus 2					
Bank 5: Bus 3					
Bank 5: Bus 4					
Bank 5: Bus 5					
Bank 5: Bus 6					
Bank 5: Bus 7					
Bank 5: Bus 8					
Bank 6: Bus 1					
Bank 6: Bus 2					
Bank 6: Bus 3					
Bank 6: Bus 4					
Bank 6: Bus 5					
Bank 6: Bus 6					
Bank 6: Bus 7					
Bank 6: Bus 8					

Table 21.18 Conversion Loop Worksheet

### **Custom Device Protocol Worksheets**

The custom device protocol worksheet (**Table 21.19**) helps you to keep track of the custom commands you have created for a Custom Device Protocol.

#1	Description						Tag	Tag		
Bytes										
Bytes										
#2	Descripti	on						Tag		
Bytes										
Dytes										
#3	Descripti	on						Tag		
Bytes										
29000										
#4	Descripti	on		-	-	-		Tag	-	
Bytes										
#5	Descripti	on						Tag		
Bytes										
#6	Descripti	on		r	<b>-</b>	r		Tag		
Bytes										
#7	Descripti	on						Tag		
Bytes										
#8	Descripti	on						Tag		
Bytes										
	<b>D</b>									
#9	Descripti	on						Tag		
Bytes										
//10	D							<b>—</b>		
#10	Descripti	on						lag		
Bytes										

 Table 21.19 Custom Device Protocol Worksheet — CUSTOM0

#1	Description						Tag			
D /										
Bytes										
#2	Descripti	Description								
Dertes										
Bytes										
#3	Descripti	on		•	•			Tag		
Dutos										
Bytes										
#4	Descripti	on						Tag		
Bytes										
Dytes										
#5	Descripti	on						Tag		
Bytes										
Dytes										
#6	Descripti	on						Tag		
Bytes										
Dytes										
#7	Descripti	on						Tag		
Bytes										
#8	Descripti	on		r	r			Tag		
Bytes										
<b>#9</b>	Description						Tag			
Bytes										
#10	Descripti	on						Tag		
Bytes										
Dytes										

Table 21.20 Custom Device Protocol Worksheet — CUSTOM1



**Operating Tip** — Helpful Abbreviations: H=Hex, B=BCD, AH=ASCII Hex, AB=ASCII BCD / 1-8 (digits) or 4,8...32 (bits) /M=Mot, I=Int., /S=Sca, E=Ext, +=Sign

# **Appendix D. Software Licenses**

### **In This Appendix**

The Vision switcher uses software under one or more of the following licence agreements:

- GNU General Public License
- Lesser GNU Public License (LGPL)
- BSD License
- Apache License
- Expat License
- Imlib2

**Note** — As required by the GNU General Public License, and the Lesser GNU Public License (LGPL), source code can be obtained from Ross Video for at least 3 years. Contact Ross Video Technical Support for more information.

### **GNU General Public License**

#### GNU GENERAL PUBLIC LICENSE

#### Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc. 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

#### Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributes of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all. The precise terms and conditions for copying, distribution and modification follow.

#### TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

- 2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:
  - a. You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
  - **b.** You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
  - C. If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.) \_\_\_\_

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

- 3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:
  - a. Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
  - **b.** Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
  - **c.** Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

- 4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.
- 5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.
- 6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.
- 7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program. If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

- 8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.
- 9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### NO WARRANTY

- 11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.
- 12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE POGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

### Lesser GNU Public License (LGPL)

GNU LESSER GENERAL PUBLIC LICENSE

Version 2.1, February 1999

Copyright (C) 1991, 1999 Free Software Foundation, Inc. 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

[This is the first released version of the Lesser GPL. It also counts as the successor of the GNU Library Public License, version 2, hence the version number 2.1.]

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public Licenses are intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users.

This license, the Lesser General Public License, applies to some specially designated software packages--typically libraries--of the Free Software Foundation and other authors who decide to use it. You can use it too, but we suggest you first think carefully about whether this license or the ordinary General Public License is the better strategy to use in any particular case, based on the explanations below.

When we speak of free software, we are referring to freedom of use, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish); that you receive source code or can get it if you want it; that you can change the software and use pieces of it in new free programs; and that you are informed that you can do these things.

To protect your rights, we need to make restrictions that forbid distributors to deny you these rights or to ask you to surrender these rights. These restrictions translate to certain responsibilities for you if you distribute copies of the library or if you modify it.

For example, if you distribute copies of the library, whether gratis or for a fee, you must give the recipients all the rights that we gave you. You must make sure that they, too, receive or can get the source code. If you link other code with the library, you must provide complete object files to the recipients, so that they can relink them with the library after making changes to the library and recompiling it. And you must show them these terms so they know their rights.

We protect your rights with a two-step method: (1) we copyright the library, and (2) we offer you this license, which gives you legal permission to copy, distribute and/or modify the library.

To protect each distributor, we want to make it very clear that there is no warranty for the free library. Also, if the library is modified by someone else and passed on, the recipients should know that what they have is not the original version, so that the original author's reputation will not be affected by problems that might be introduced by others.

Finally, software patents pose a constant threat to the existence of any free program. We wish to make sure that a company cannot effectively restrict the users of a free program by obtaining a restrictive license from a patent holder. Therefore, we insist that any patent license obtained for a version of the library must be consistent with the full freedom of use specified in this license.

Most GNU software, including some libraries, is covered by the ordinary GNU General Public License. This license, the GNU Lesser General Public License, applies to certain designated libraries, and is quite different from the ordinary General Public License. We use this license for certain libraries in order to permit linking those libraries into non-free programs.

When a program is linked with a library, whether statically or using a shared library, the combination of the two is legally speaking a combined work, a derivative of the original library. The ordinary General Public License therefore permits such linking only if the entire combination fits its criteria of freedom. The Lesser General Public License permits more lax criteria for linking other code with the library.

We call this license the "Lesser" General Public License because it does Less to protect the user's freedom than the ordinary General Public License. It also provides other free software developers Less of an advantage over competing non-free programs. These disadvantages are the reason we use the ordinary General Public License for many libraries. However, the Lesser license provides advantages in certain special circumstances.

For example, on rare occasions, there may be a special need to encourage the widest possible use of a certain library, so that it becomes a de-facto standard. To achieve this, non-free programs must be allowed to use the library. A more frequent case is that a free library does the same job as widely used non-free libraries. In this case, there is little to gain by limiting the free library to free software only, so we use the Lesser General Public License.

In other cases, permission to use a particular library in non-free programs enables a greater number of people to use a large body of free software. For example, permission to use the GNU C Library in non-free programs enables many more people to use the whole GNU operating system, as well as its variant, the GNU/Linux operating system.

Although the Lesser General Public License is Less protective of the users' freedom, it does ensure that the user of a program that is linked with the Library has the freedom and the wherewithal to run that program using a modified version of the Library.

The precise terms and conditions for copying, distribution and modification follow. Pay close attention to the difference between a "work based on the library" and a "work that uses the library". The former contains code derived from the library, whereas the latter must be combined with the library in order to run.

GNU LESSER GENERAL PUBLIC LICENSE

#### TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

**0.** This License Agreement applies to any software library or other program which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this Lesser General Public License (also called "this License"). Each licensee is addressed as "you".

A "library" means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executable.

The "Library", below, refers to any such software library or work which has been distributed under these terms. A "work based on the Library" means either the Library or any derivative work under copyright law: that is to say, a work containing the Library or a portion of it, either verbatim or with modifications and/or translated straightforwardly into another language. (Hereinafter, translation is included without limitation in the term "modification".)

"Source code" for a work means the preferred form of the work for making modifications to it. For a library, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the library.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running a program using the Library is not restricted, and output from such a program is covered only if its contents constitute a work based on the Library (independent of the use of the Library in a tool for writing it). Whether that is true depends on what the Library does and what the program that uses the Library does.

- 1. You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library. You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.
- 2. You may modify your copy or copies of the Library or any portion of it, thus forming a work based on the Library, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:
  - **a.** The modified work must itself be a software library.
  - **b.** You must cause the files modified to carry prominent notices stating that you changed the files and the date of any change.
  - c. You must cause the whole of the work to be licensed at no charge to all third parties under the terms of this License.

**d.** If a facility in the modified Library refers to a function or a table of data to be supplied by an application program that uses the facility, other than as an argument passed when the facility is invoked, then you must make a good faith effort to ensure that, in the event an application does not supply such function or table, the facility still operates, and performs whatever part of its purpose remains meaningful.

(For example, a function in a library to compute square roots has a purpose that is entirely well-defined independent of the application. Therefore, Subsection 2d requires that any application-supplied function or table used by this function must be optional: if the application does not supply it, the square root function must still compute square roots.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Library, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Library, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Library.

In addition, mere aggregation of another work not based on the Library with the Library (or with a work based on the Library) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may opt to apply the terms of the ordinary GNU General Public License instead of this License to a given copy of the Library. To do this, you must alter all the notices that refer to this License, so that they refer to the ordinary GNU General Public License, version 2, instead of to this License. (If a newer version than version 2 of the ordinary GNU General Public License has appeared, then you can specify that version instead if you wish.) Do not make any other change in these notices.

Once this change is made in a given copy, it is irreversible for that copy, so the ordinary GNU General Public License applies to all subsequent copies and derivative works made from that copy. This option is useful when you wish to copy part of the code of the Library into a program that is not a library.

4. You may copy and distribute the Library (or a portion or derivative of it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange.

If distribution of object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place satisfies the requirement to distribute the source code, even though third parties are not compelled to copy the source along with the object code.

5. A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is called a "work that uses the Library". Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License.

However, linking a "work that uses the Library" with the Library creates an executable that is a derivative of the Library (because it contains portions of the Library), rather than a "work that uses the library". The executable is therefore covered by this License. Section 6 states terms for distribution of such executables.

When a "work that uses the Library" uses material from a header file that is part of the Library, the object code for the work may be a derivative work of the Library even though the source code is not. Whether this is true is especially significant if the work can be linked without the Library, or if the work is itself a library. The threshold for this to be true is not precisely defined by law.

If such an object file uses only numerical parameters, data structure layouts and accessors, and small macros and small inline functions (ten lines or less in length), then the use of the object file is unrestricted, regardless of whether it is legally a derivative work. (Executables containing this object code plus portions of the Library will still fall under Section 6.)

Otherwise, if the work is a derivative of the Library, you may distribute the object code for the work under the terms of Section 6. Any executables containing that work also fall under Section 6, whether or not they are linked directly with the Library itself.

6. As an exception to the Sections above, you may also combine or link a "work that uses the Library" with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer's own use and reverse engineering for debugging such modifications.

You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License. You must supply a copy of this License. If the work during execution displays copyright notices, you must include the copyright notice for the Library among them, as well as a reference directing the user to the copy of this License. Also, you must do one of these things:

- a. Accompany the work with the complete corresponding machine-readable source code for the Library including whatever changes were used in the work (which must be distributed under Sections 1 and 2 above); and, if the work is an executable linked with the Library, with the complete machine-readable "work that uses the Library", as object code and/or source code, so that the user can modify the Library and then relink to produce a modified executable containing the modified Library. (It is understood that the user who changes the contents of definitions files in the Library will not necessarily be able to recompile the application to use the modified definitions.)
- **b.** Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (1) uses at run time a copy of the library already present on the user's computer system, rather than copying library functions into the executable, and (2) will operate properly with a modified version of the library, if the user installs one, as long as the modified version is interface-compatible with the version that the work was made with.
- **c.** Accompany the work with a written offer, valid for at least three years, to give the same user the materials specified in Subsection 6a, above, for a charge no more than the cost of performing this distribution.
- d. If distribution of the work is made by offering access to copy from a designated place, offer equivalent access to copy the above specified materials from the same place.
- e. Verify that the user has already received a copy of these materials or that you have already sent this user a copy.

For an executable, the required form of the "work that uses the Library" must include any data and utility programs needed for reproducing the executable from it. However, as a special exception, the materials to be distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

It may happen that this requirement contradicts the license restrictions of other proprietary libraries that do not normally accompany the operating system. Such a contradiction means you cannot use both them and the Library together in an executable that you distribute.

- 7. You may place library facilities that are a work based on the Library side-by-side in a single library together with other library facilities not covered by this License, and distribute such a combined library, provided that the separate distribution of the work based on the Library and of the other library facilities is otherwise permitted, and provided that you do these two things:
  - a. Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities. This must be distributed under the terms of the Sections above.
  - **b.** Give prominent notice with the combined library of the fact that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.
- 8. You may not copy, modify, sublicense, link with, or distribute the Library except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, link with, or distribute the Library is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.
- 9. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Library or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Library (or any work based

on the Library), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Library or works based on it.

- **10.** Each time you redistribute the Library (or any work based on the Library), the recipient automatically receives a license from the original licensor to copy, distribute, link with or modify the Library subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties with this License.
- 11. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Library at all. For example, if a patent license would not permit royalty-free redistribution of the Library by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Library.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply, and the section as a whole is intended to apply in other circumstances. It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

- 12. If the distribution and/or use of the Library is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Library under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.
- 13. The Free Software Foundation may publish revised and/or new versions of the Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Library specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Library does not specify a license version number, you may choose any version ever published by the Free Software Foundation.

14. If you wish to incorporate parts of the Library into other free programs whose distribution conditions are incompatible with these, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### NO WARRANTY

- 15. BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE LIBRARY "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LIBRARY IS WITH YOU. SHOULD THE LIBRARY PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.
- 16. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE LIBRARY AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE LIBRARY (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE LIBRARY TO OPERATE WITH ANY OTHER SOFTWARE), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

# **BSD License**

### General

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- 3. The name of the author may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

### **Apache License**

Apache License

Version 2.0, January 2004

http://www.apache.org/licenses/

#### TERMS AND CONDITIONS FOR USE, REPRODUCTION, AND DISTRIBUTION

1. Definitions.

"License" shall mean the terms and conditions for use, reproduction, and distribution as defined by Sections 1 through 9 of this document.

"Licensor" shall mean the copyright owner or entity authorized by the copyright owner that is granting the License.

"Legal Entity" shall mean the union of the acting entity and all other entities that control, are controlled by, or are under common control with that entity. For the purposes of this definition, "control" means (i) the power, direct or indirect, to cause the direction or management of such entity, whether by contract or otherwise, or (i) ownership of fifty percent (50%) or more of the outstanding shares, or (iii) beneficial ownership of such entity.

"You" (or "Your") shall mean an individual or Legal Entity exercising permissions granted by this License.

"Source" form shall mean the preferred form for making modifications, including but not limited to software source code, documentation source, and configuration files.

"Object" form shall mean any form resulting from mechanical transformation or translation of a Source form, including but not limited to compiled object code, generated documentation, and conversions to other media types.

"Work" shall mean the work of authorship, whether in Source or Object form, made available under the License, as indicated by a copyright notice that is included in or attached to the work (an example is provided in the Appendix below).

"Derivative Works" shall mean any work, whether in Source or Object form, that is based on (or derived from) the Work and for which the editorial revisions, annotations, elaborations, or other modifications represent, as a whole, an original work of authorship. For the purposes of this License, Derivative Works shall not include works that remain separable from, or merely link (or bind by name) to the interfaces of, the Work and Derivative Works thereof.

"Contribution" shall mean any work of authorship, including the original version of the Work and any modifications or additions to that Work or Derivative Works thereof, that is intentionally submitted to Licensor for inclusion in the Work by the copyright owner or by an individual or Legal Entity authorized to submit on behalf of the copyright owner. For the purposes of this definition, "submitted" means any form of electronic, verbal, or written communication sent to the Licensor or its representatives, including but not limited to communication on electronic mailing lists, source code control systems, and issue tracking systems that are managed by, or on behalf of, the Licensor for the purpose of discussing and improving the Work, but excluding communication that is conspicuously marked or otherwise designated in writing by the copyright owner as "Not a Contribution."

"Contributor" shall mean Licensor and any individual or Legal Entity on behalf of whom a Contribution has been received by Licensor and subsequently incorporated within the Work.

- 2. Grant of Copyright License. Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable copyright license to reproduce, prepare Derivative Works of, publicly display, publicly perform, sublicense, and distribute the Work and such Derivative Works in Source or Object form.
- 3. Grant of Patent License. Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable (except as stated in this section) patent license to make, have made, use, offer to sell, sell, import, and otherwise transfer the Work, where such license applies only to those patent claims licensable by such Contributor that are necessarily infringed by their Contribution(s) alone or by combination of their Contribution(s) with the Work to which such Contribution(s) was submitted. If You institute patent litigation against any entity (including a cross-claim or counterclaim in a lawsuit) alleging that the Work or a Contribution within the Work constitutes direct or contributory patent infringement, then any patent licenses granted to You under this License for that Work shall terminate as of the date such litigation is filed.
- 4. Redistribution. You may reproduce and distribute copies of the Work or Derivative Works thereof in any medium, with or without modifications, and in Source or Object form, provided that You meet the following conditions:
  - a. You must give any other recipients of the Work or Derivative Works a copy of this License; and
  - b. You must cause any modified files to carry prominent notices stating that You changed the files; and
  - **c.** You must retain, in the Source form of any Derivative Works that You distribute, all copyright, patent, trademark, and attribution notices from the Source form of the Work, excluding those notices that do not pertain to any part of the Derivative Works; and
  - d. If the Work includes a "NOTICE" text file as part of its distribution, then any Derivative Works that You distribute must include a readable copy of the attribution notices contained within such NOTICE file, excluding those notices that do not pertain to any part of the Derivative Works, in at least one of the following places: within a NOTICE text file distributed as part of the Derivative Works; within the Source form or documentation, if provided along with the Derivative Works; or, within a display generated by the Derivative Works, if and wherever such third-party notices normally appear. The contents of the NOTICE file are for informational purposes only and do not modify the License. You may add Your own attribution notices within Derivative Works that You distribute, alongside or as an addendum to the NOTICE text from the Work, provided that such additional attribution notices cannot be construed as modifying the License.

You may add Your own copyright statement to Your modifications and may provide additional or different license terms and conditions for use, reproduction, or distribution of Your modifications, or for any such Derivative Works as a whole, provided Your use, reproduction, and distribution of the Work otherwise complies with the conditions stated in this License.

- 5. Submission of Contributions. Unless You explicitly state otherwise, any Contribution intentionally submitted for inclusion in the Work by You to the Licensor shall be under the terms and conditions of this License, without any additional terms or conditions. Notwithstanding the above, nothing herein shall supersede or modify the terms of any separate license agreement you may have executed with Licensor regarding such Contributions.
- 6. Trademarks. This License does not grant permission to use the trade names, trademarks, service marks, or product names of the Licensor, except as required for reasonable and customary use in describing the origin of the Work and reproducing the content of the NOTICE file.
- 7. Disclaimer of Warranty. Unless required by applicable law or agreed to in writing, Licensor provides the Work (and each Contributor provides its Contributions) on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied, including, without limitation, any warranties or conditions of TITLE, NON-INFRINGEMENT, MERCHANTABILITY, or FITNESS FOR A PARTICULAR PURPOSE. You are solely responsible for determining the appropriateness of using or redistributing the Work and assume any risks associated with Your exercise of permissions under this License.
- 8. Limitation of Liability. In no event and under no legal theory, whether in tort (including negligence), contract, or otherwise, unless required by applicable law (such as deliberate and grossly negligent acts) or agreed to in writing, shall any Contributor be liable to You for damages, including any direct, indirect, special, incidental, or consequential damages of any character arising as a result of this License or out of the use or inability to use the Work (including but not limited to damages for loss of goodwill, work stoppage, computer failure or malfunction, or any and all other commercial damages or losses), even if such Contributor has been advised of the possibility of such damages.
- 9. Accepting Warranty or Additional Liability. While redistributing the Work or Derivative Works thereof, You may choose to offer, and charge a fee for, acceptance of support, warranty, indemnity, or other liability obligations and/or rights consistent with this License. However, in accepting such obligations, You may act only on Your own behalf and on Your sole responsibility, not on behalf of any other Contributor, and only if You agree to indemnify, defend, and

hold each Contributor harmless for any liability incurred by, or claims asserted against, such Contributor by reason of your accepting any such warranty or additional liability.

### **Expat License**

Copyright (c) 1998, 1999, 2000 Thai Open Source Software Center Ltd. and Clark Cooper

Copyright (c) 2001, 2002, 2003 Expat maintainers.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

- 1. The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.
- 2. THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

# Imlib2

#### Copyright (C) 2000 Carsten Haitzler and various contributors (see AUTHORS)

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies of the Software and its Copyright notices. In addition publicly documented acknowledgment must be given that this software has been used if no source code of this software is made available publicly. Making the source available publicly means including the source for this software with the distribution, or a method to get this software via some reasonable mechanism (electronic transfer via a network or media) as well as making an offer to supply the source on request. This Copyright notice serves as an offer to supply the source on request as well. Instead of this, supplying acknowledgments of use of this software in either Copyright notices, Manuals, Publicity and Marketing documents or any documentation provided with any product containing this software. This License does not apply to any software that links to the libraries provided by this software (statically or dynamically), but only to the software provided.

#### Please see the COPYING-PLAIN for a plain-english explanation of this notice and its intent.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

# Appendix E. Custom Device Protocols

# In This Appendix

This appendix provides information for setting up a custom device and programming a serial protocol to communicate with that device from a Vision peripheral or remote port.

The following topics are discussed in this appendix:

- Custom Devices Uses and Limitations
- Advanced Topics and Tables

### **Custom Devices – Uses and Limitations**

Custom Device commands allow you to select the signals that the switcher sends to the custom device when you select a command on the switcher. For example, when you create a Play DVE custom control for **CUSTOM0**, the signal that you coded for that command is sent to the **CUSTOM0** device when that custom control is run.



**Operating Tip** — You can control devices other than VTRs, Video Servers, Audio Servers or External DVEs by substituting their commands for those in the Command-tag list of the **Custom Device Menu**. Make sure to note these substitution on the Custom Device Protocol Worksheet.

When working with a custom device protocol, the following limitations apply:

- The custom device protocol supports only one way communication. The switcher will not record or act upon signals being returned from the custom device. Therefore, queries for Current-time-sense (such as grab timecode), Inpoint, Outpoint and Clip-ID-names are not supported.
- Some protocol signals may exceed the maximum number of bytes (**19**) allocated per command. In cases where a custom control is used, **2** command slots (and **2** tags) can be used and a custom control programmed to run both of them in immediate succession. Each user-programmed device supports a maximum of **10** command slots. There may be other practical problems with the protocol you are trying to reproduce that may render custom devices unsuitable.
# **Advanced Topics and Tables**

Besides strings of constant Hex values (bytes), commands can be programmed with special characters and with converted parameter values. Examples of the special characters include the two special values to perform a communications break. The communications break is formed by a data zero event that extends beyond the normal data bit length permitted in the serial data word (for example, serial word length of 8-Odd-1Stop bit is 1+8+1+1 = 11 bits long). The commonly used minimum length for break is 17 bits long or one and a half to two data-words. To implement a break in custom devices, there needs to be a **[Break On]**, a **[Break Off]**, and an optional delay in between.

Certain commands pass a parameter to the custom device driver that can be converted into a string of bytes using a special packed command in place of a single byte. Only one of these special command lines may appear in any given command slot (since only one parameter is ever passed). This command line is converted during runtime into the specified one to four bytes of parameter data, and included at that location in the command string. One command tag that gets a parameter is the Cue to Clip command. The value passed when a Cue to Clip command is triggered is the desired cue time as represented in a packed word timecode format. Typically, this value must then be converted into some representation of packed timecode bytes to be sent to the external device. The packed command flags are described in the following table. You may want to use the Panel Diagnostic\RX/TX\Monitor to view the results when using parameters in commands.

Special Names	Function
[Break On]	Force the outputs to data low value (for RS-232 data low is a positive voltage)
[Break Off]	Release the outputs from a forced data low
[Checksum]	Insert the checksum byte (currently supports only simple 8-bit additive checksum)
[Posn X]	Not currently supported
[Posn Y]	Not currently supported
[Posn Z]	Not currently supported
[Param]	Parameter (refer to the <b>Parameter Formatting Flags</b> ( <b>Table 23.2</b> ))

#### Table 23.1 Packed Command Flags

#### Table 23.2 Parameter Formatting Flags

Special Names	Function
Hex	Parameters take as-is and are converted into string of bytes (1-4). If the parameter is already in a packed BCD format then using Hex format will preserve the BCD format of the parameter.
ASCII Hex	Text representation of the above "Hex" format.
BCD	Binary Coded Decimal (each nybble represents 1 digit 0-9). This command converts a parameter that is in non-BCD format to a BCD format.
ASCII BCD	Text representation of the above "BCD" format. This command converts a parameter from a non-BCD format to a text representation of the equivalent BCD format.

Table 23.3	Special	Options
------------	---------	---------

Selection	Description
Mot	Motorola ordering. Most Significant Byte (MSB) first, LSB last.
Int	Intel ordering. Least Significant Byte (LSB) first, MSB last.
Scaled (Sca)	Re-scales a 12-bit parameter to fit output range.
ASCII Extended (Ext)	Extends up the output to an even number of digits/characters without changing the output range.
Signed (Sign)	Internal use — sign conversion.

#### Table 23.4 BCD Width Descriptions

BCD Width	Motorola Description
1 Digit	1 byte of 1 digit, [00] to max [09]
2 Digits	1 bytes of 2 packed digits each, [00] to max [99]
3 Digits	1 bytes of 2 packed digits and 1 byte of 1 digit, [00][00] to max[09][99]
4 Digits	2 bytes of 2 packed digits each, [00][00] to max[99][99]
5 Digits	2 bytes of 2 packed digits and 1 byte of 1 digit, max [09][99][99]
6 Digits	3 bytes of 2 packed digits each, max [99][99][99]
7 Digits	3 bytes of 2 packed digits and 1 byte of 1 digit, max [09][99][99][99]
8 Digits	4 bytes of 2 packed digits each, max [99][99][99][99]

Hex Width	Description
4 Bits	[00] to [0F]
8 Bits	[00] to [FF]
12 Bits	[00][00] to [0F][FF] (or Intel [FF][0F])
14 Bits	[00][00] to [3F][FF] (or Intel [FF][3F])
15 Bits	[00][00] to [7F][FF] (or Intel [FF][7F])
16 Bits	[00][00] to [FF][FF]
24 Bits	[00][00] to [FF][FF][FF]
32 Bits	[00][00][00][00] to [FF][FF][FF]

Decimal	Hex	ASCII	Decimal	Hex	ASCII	Decimal	Hex	ASCII	Decimal	Hex	Decimal	Hex	Decimal	Hex
0	00		43	2B	+	86	56	V	129	81	172	AC	215	D7
1	01		44	2C	,	87	57	W	130	82	173	AD	216	D8
2	02		45	2D	-	88	58	Х	131	83	174	AE	217	D9
3	03		46	2E		89	59	Y	132	84	175	AF	218	DA
4	04		47	2F	/	90	5A	Ζ	133	85	176	B0	219	DB
5	05		48	30	0	91	5B	[	134	86	177	B1	220	DC
6	06		49	31	1	92	5C	/	135	87	178	B2	221	DD
7	07		50	32	2	93	5D	]	136	88	179	B3	222	DE
8	08		51	33	3	94	5E	^	137	89	180	B4	223	DF
9	09		52	34	4	95	5F	_	138	8A	181	B5	224	E0
10	0A		53	35	5	96	60	`	139	8B	182	B6	225	E1
11	0B		54	36	6	97	61	а	140	8C	183	B7	226	E2
12	0C		55	37	7	98	62	b	141	8D	184	B8	227	E3
13	0D		56	38	8	99	63	с	142	8E	185	B9	228	E4
14	0E		57	39	9	100	64	d	143	8F	186	BA	229	E5
15	0F		58	3A	:	101	65	e	144	90	187	BB	230	E6
16	10		59	3B	;	102	66	f	145	91	188	BC	231	E7
17	11		60	3C	<	103	67	g	146	92	189	BD	232	E8
18	12		61	3D	=	104	68	h	147	93	190	BE	233	E9
19	13		62	3E	>	105	69	i	148	94	191	BF	234	EA
20	14		63	3F	?	106	6A	j	149	95	192	C0	235	EB
21	15		64	40	@	107	6B	k	150	96	193	C1	236	EC
22	16		65	41	А	108	6C	1	151	97	194	C2	237	ED
23	17		66	42	В	109	6D	m	152	98	195	C3	238	EE
24	18		67	43	С	110	6E	n	153	99	196	C4	239	EF
25	19		68	44	D	111	6F	0	154	9A	197	C5	240	F0
26	1A		69	45	Е	112	70	р	155	9B	198	C6	241	F1
27	1B		70	46	F	113	71	q	156	9C	199	C7	242	F2
28	1C		71	47	G	114	72	r	157	9D	200	C8	243	F3
29	1D		72	48	Н	115	73	S	158	9E	201	C9	244	F4
30	1E		73	49	Ι	116	74	t	159	9F	202	CA	245	F5
31	1F		74	4A	J	117	75	u	160	A0	203	CB	246	F6
32	20	space	75	4B	K	118	76	v	161	A1	204	CC	247	F7
33	21	!	76	4C	L	119	77	w	162	A2	205	CD	248	F8
34	22	"	77	4D	М	120	78	Х	163	A3	206	CE	249	F9
35	23	#	78	4E	Ν	121	79	у	164	A4	207	CF	250	FA
36	24	\$	79	4F	0	122	7A	Z	165	A5	208	D0	251	FB
37	25	%	80	50	Р	123	7B	{	166	A6	209	D1	252	FC
38	26	&	81	51	Q	124	7C		167	A7	210	D2	253	FD
39	27	'	82	52	R	125	7D	}	168	A8	211	D3	254	FE
40	28	(	83	53	S	126	7E	~	169	A9	212	D4	255	FF
41	29	)	84	54	Т	127	7F		170	AA	213	D5		
42	2A	*	85	55	U	128	80		171	AB	214	D6		

Table 23.6 Decimal to Hexadecimal to ASCII Conversion Table



**Note** — 7-bit printable ASCII range from 32 to 126 decimal. The Custom device menus represent text values outside that range with a period (.).

# **Glossary of Terms**

Active Video Lines — All video lines not occurring in the vertical blanking interval. The portion of the video signal that contains picture information.

Aspect Ratio — The numerical ratio of picture width to height, for example, 4:3 or 16:9.

**Auto Transition** — An automatic transition in which the manual movement of the fader handle is simulated electronically. The transition starts when the **AUTO TRANS** button is pressed and takes place over a pre-selected time period, measured in frames.

**Border** — Effects created around the edges of a pattern or on a keyer. If an optional Dual Border Generator Card is installed, several border, shadow, and outline effects are available on that keyer as well.

**Border Generator** — Circuitry that generates various border effects on keys created by the switcher.

**Chroma Key** — An effect in which video from one source replaces video of a specific hue in a second video source. The blue and green hues are most commonly used for chroma keying.

**Chrominance** — The "depth" or saturation of a color. The three characteristics of a TV color signal are chrominance, luminance, and hue.

Cut — An instantaneous switch from one video signal to another.

**Dissolve** — A transition from one video signal to another in which one signal is faded down, while the other is simultaneously faded up. The term "mix" is often used interchangeably with "dissolve".

**Downstream Keyer (DSK)** — A keyer that places a key "downstream" of the MLE effects system output. This "top level" effect usually consists of a character generator title.

**External Key** — A video input (non-primary video) used to produce a key effect. Examples of external key sources are character generators and cameras.

Fade-to-Black — A controlled change of the on-air picture signal level down to black level.

**Field** — One half of a complete picture (or frame) interval containing all of the odd, or all of the even, lines in interlaced scanning. One scan of a TV screen is called a "field"; two fields are required to make a complete picture (which is a "frame").

**Field Frequency** — The rate at which one complete field is scanned, approximately 50 times per second in 625 video, or 60 times per second in 525 video.

Frame — One complete picture consisting of two fields of interlaced scanning lines.

**GPI** — An abbreviation for General Purpose Interface, a device which typically allows switcher automatic transition functions to be controlled remotely.

**Hue** — The characteristic of a color signal that determines whether the color is red, yellow, green, blue, purple, etc. (the three characteristics of a TV color signal are chrominance, luminance, and hue). White, black, and gray are not considered hues.

Internal Key — The use of a primary input to produce a key effect.

**Key** — An effect produced by "cutting a hole" in the background video, then filling the hole with video or matte from another source. Key source video cuts the hole, key fill video fills the hole. The video signal used for cut and fill can come from the same, or separate, sources.

**Key Fill** — A video input which is timed to "fill the hole" provided by the key source video. An example of key fill is the video output of a character generator.

**Key Invert** — An effect that reverses the polarity of the key source so that the holes in the background are cut by dark areas of the key source instead of bright areas. The **KEY INV** button selects this effect.

**Key Mask** — A keying technique in which a pattern is combined with the key source to block out unwanted portions of the key source.

**Key Source** — The video signal which "cuts a hole" in the background video to make a key effect possible. Also called "Key Video". In practice, this signal controls when a video mixer circuit will switch from background to key fill video.

Key Video — See Key Source.

**Linear Keys** — Linear keys make it possible to fully specify the transparency of a key from opaque, through transparent, to fully off. The transparency is specified by the key signal (also known as the "hole cutter" or "alpha channel") that is associated with the key fill. A keyer capable of a linear key converts the key signal voltage directly to the transparency effect on the screen. The **KEY MEM** button allows the user to store the Clip and Gain settings required to match the incoming key signal to your requirements.

**Line Frequency** — The number of horizontal scans per second. For 525 line 60 Hz systems, this is approximately 15734 scans per second.

**Luminance Key** — An effect in which video from one source is replaced by video that exceeds a set level in a second video source.

Mask — See Key Mask.

**Matte** — A solid color signal that is generated by the switcher and can be adjusted for hue, saturation, and luminance levels.

**Matte Key** — A key effect in which the fill video is a matte, provided by one of the internal matte generators.

Memory — The memory feature provides storage and recall of complete switcher setups.

MIX — See Dissolve.

MLE — An abbreviation for multi-level effects.

**PGM Output** — The on-air video output of the system.

**Primary Input** — Video sources selected by the control panel push-buttons for the crosspoint buses. These buses are normally labelled "KEY", "PGM", and "PST".

**PV Output** — A switcher output that shows the scene that will go on-air when the next automatic or manual transition takes place.

**Self Key** — A key effect in which the same video signal serves as both the key signal and key fill.

**Soft Edge** — A pattern edge effect produced by mixing key source and key fill signals in such a way that the edge of the pattern is not sharp.

**Split Screen** — An effect in which a wipe pattern provides the key source signal. This is known as a "preset pattern" key.

**Tally** — An indicator which illuminates when the associated button, or control, is selected or is on-air.

**Termination** — A means of closing a circuit by connecting a resistive load to it. In video systems, a termination is typically a 75 ohm resistive load.

**Transition** — A controlled change from one video input to another video input or black. The change can occur through a wipe, cut, dissolve or "DVE Send" effect.

**Transition Preview** — A transition seen only on the preview monitor. It may be observed and adjusted without disturbing the program or "on-air" output.

**Video** — The electrical signal produced by a camera, character generator or other image source. The signal amplitude varies in relation to the tonal scale from black to white presented at the source. White produces the highest amplitude; black produces the lowest signal amplitude.

# Index

#### Numerics

1080i explained	Eng 2-31
4400AR-061	Eng 2-12
4400AR-062	Eng 2-12
4800AR-001	Eng 2-12
4800AR-020	Eng 2-13
4800AR-040	Eng 2-13
4800AR-047	Eng 2-13
4800AR-060A	Eng 2-12
4800AR-060B	Eng 2-12
4800AR-060C	Eng 2-12
4800AR-061A	Eng 2-12
4800AR-061B	Eng 2-12
4800AR-061C	Eng 2-12
4800AR-064	Eng 2-12
4800AR-065	Eng 2-12
4800AR-066	Eng 2-12
4800AR-067	Eng 2-12
4-Keyers option	. Eng 2-2, Eng 6-17
720p explained	Eng 2-31
	U

# Α

Abbreviations	Eng 1-5
AC Power Ports Eng 20-22	2, Eng 20-26
Act MLE Trans (Automation) Custom Co	ontrol Eng
10-18	-
A-D, definition	Eng 1-5
Additional output BNC setup	Eng 8-7
Adjusting, Touchscreen Display	Eng 5-3
Air Filter Cleaning	Eng 18-14
Alpha	-
Input BNC	Eng 7-6
Input BNC Type	Eng 7-5
shaped	Eng 7-7
unshaped	Eng 7-7
Ancillary Data	Eng 8-10
Apache License	Eng 22-8
Architecture	
CPU	Eng 2-36
system	Eng 2-1
Arm, Mounting (Touchscreen)	Eng 3-9
Assign	
AuxBkgdCut button	Eng 7-15
AuxBkgdTrans button	Eng 7-15
AuxKeyCut button	Eng 7-15
AuxKeyTrans button	Eng 7-15
black	Eng 7-14

Bus Hold button	Eng 7-15
Bus Maps	Eng 7-19
Bus Maps to Multiple Buses	Eng 7-20
color background	Eng 7-14
global-store button	Eng 7-14
MLE Re-entry	Eng 7-14
MLE-store button	
shift	Eng 7-14
Assign Audio Custom Controls	Eng 10.16
Assign Channel Custom Control	Eng 10-10
Assign Loueut to Multi Viewer	Enc 9 14
Assign Layout to Multi-viewer	Ellg 8-14
Assign Multi-viewer	Eng 8-13
Assigning Crosspoint Colors	Eng 11-16
Assigning Individual Bus Maps	Eng 7-19
At Black Extra Option	Eng 9-30
Attach Custom Control to Button	Eng 10-21
Post-Attach	Eng 10-22
Pre-Attach	Eng 10-22
Replace	Eng 10-22
Audio All Off Custom Controls	Eng 10-16
Audio channel assignment	
Audio Channel Off Custom Controls	Eng 10-16
Audio Channel On Custom Controls	Eng 10 16
Audio Cut Only, Demonality getting	Eng 11 2
Audio Cut Olly, reisonality setting	Elig 11-5
	Eng 12-25
Audio Memory Custom Controls	Eng 10-16
Audio Mixers	
Audio Fade Rate	Eng 12-25
channel and group setup	Eng 12-22
channel assignment	Eng 7-11
Custom Controls	
banks	Eng 10-5
PGM Audio Level	Eng 10-16
default levels	Eng 12-23
Groups	Eng 12-24
source assignment	Eng 12-22
Audio Remote Control Setup	Eng 12-22
Audio Server Control option	Eng 6-17
Audio Server BNC Type see VTP	
Audio Sorvers	
Audio Servers	Eng 10.2
Audio Servers custom control functions	Eng 10-2
Audio Servers custom control functions Audio Source Assignment	Eng 10-2 Eng 12-22
Audio Servers custom control functions Audio Source Assignment Audio Transitions Personality setting	Eng 10-2 Eng 12-22 Eng 11-3
Audio Servers custom control functions Audio Source Assignment Audio Transitions Personality setting Auto Follow	Eng 10-2 Eng 12-22 Eng 11-3 Eng 12-40
Audio Servers custom control functions Audio Source Assignment Audio Transitions Personality setting Auto Follow Bus Follow	Eng 10-2 Eng 12-22 Eng 11-3 Eng 12-40 Eng 12-43
Audio Servers custom control functions Audio Source Assignment Audio Transitions Personality setting Auto Follow Bus Follow Custom Control Commands Eng 11	Eng 10-2 Eng 12-22 Eng 12-22 Eng 11-3 Eng 12-40 Eng 12-43 I-3, Eng 12-41
Audio Servers custom control functions Audio Source Assignment Audio Transitions Personality setting Auto Follow Bus Follow Custom Control Commands Eng 11 Editor Commands	Eng 10-2 Eng 12-22 Eng 11-3 Eng 12-40 Eng 12-43 I-3, Eng 12-41 -3, Eng 12-41
Audio Servers custom control functions Audio Source Assignment Audio Transitions Personality setting Auto Follow Bus Follow Custom Control Commands Eng 11 Editor Commands Eng 11 Keyer Follow	Eng 10-2 Eng 12-22 Eng 11-3 Eng 12-40 Eng 12-43 I-3, Eng 12-41 -3, Eng 12-41 Eng 12-44
Audio Servers custom control functions Audio Source Assignment Audio Transitions Personality setting Auto Follow Bus Follow Custom Control Commands Eng 11 Editor Commands Eng 11 Keyer Follow Memory Recall	Eng 10-2 Eng 12-22 Eng 12-22 Eng 11-3 Eng 12-40 Eng 12-43 I-3, Eng 12-41 -3, Eng 12-41 Eng 12-44 Eng 12-44 Eng 12-45
Audio Servers custom control functions Audio Source Assignment Audio Transitions Personality setting Auto Follow Bus Follow Custom Control Commands Eng 11 Editor Commands Eng 11 Keyer Follow Memory Recall MLE Follow	Eng 10-2 Eng 12-22 Eng 12-22 Eng 12-40 Eng 12-40 Eng 12-43 I-3, Eng 12-41 -3, Eng 12-41 Eng 12-44 Eng 12-44 Eng 12-45 Eng 12-42
Audio Servers custom control functions Audio Source Assignment Audio Transitions Personality setting Auto Follow Bus Follow Custom Control Commands Eng 11 Editor Commands	Eng 10-2 Eng 12-22 Eng 12-3 Eng 12-40 Eng 12-43 I-3, Eng 12-41 Eng 12-41 Eng 12-44 Eng 12-45 Eng 12-42 -3, Eng 12-41
Audio Servers custom control functions Audio Source Assignment Audio Transitions Personality setting Auto Follow Bus Follow Custom Control Commands Eng 11 Editor Commands Eng 11 Keyer Follow Memory Recall MLE Follow Panel Commands	Eng 10-2 Eng 12-22 Eng 11-3 Eng 12-40 Eng 12-43 l-3, Eng 12-43 l-3, Eng 12-41 Eng 12-44 Eng 12-44 Eng 12-42 3, Eng 12-44 Eng 12-44
Audio Servers custom control functions Audio Source Assignment Audio Transitions Personality setting Auto Follow Bus Follow Custom Control Commands Eng 11 Editor Commands Eng 11 Keyer Follow Memory Recall MLE Follow Panel Commands Eng 11 Transition Module	Eng 10-2 Eng 12-22 Eng 11-3 Eng 12-40 Eng 12-43 I-3, Eng 12-43 I-3, Eng 12-44 Eng 12-44 Eng 12-45 Eng 12-42 -3, Eng 12-41 Eng 12-44 Eng 12-44 Eng 12-44
Audio Servers custom control functions Audio Source Assignment Audio Transitions Personality setting Auto Follow Bus Follow Custom Control Commands Eng 11 Editor Commands Eng 11 Keyer Follow Memory Recall MLE Follow Panel Commands Eng 11 Transition Module Auto Key	Eng 10-2 Eng 12-22 Eng 11-3 Eng 12-40 Eng 12-43 I-3, Eng 12-41 -3, Eng 12-41 Eng 12-44 Eng 12-44 Eng 12-45 Eng 12-42 -3, Eng 12-41 Eng 12-44 Eng 7-4 Eng 7-8
Audio Servers custom control functions Audio Source Assignment Audio Transitions Personality setting Auto Follow Bus Follow Custom Control Commands Eng 11 Editor Commands Eng 11 Keyer Follow Memory Recall MLE Follow Panel Commands Eng 11 Transition Module Auto Key Global-Store setup	Eng 10-2 Eng 12-22 Eng 11-3 Eng 12-40 Eng 12-43 I-3, Eng 12-43 I-3, Eng 12-41 Eng 12-44 Eng 12-44 Eng 12-42 I-3, Eng 12-42 I-3, Eng 12-42 I-3, Eng 12-44 Eng 7-4 Eng 7-8 Eng 7.8
Audio Servers custom control functions Audio Source Assignment Audio Transitions Personality setting Auto Follow Bus Follow Custom Control Commands Eng 11 Editor Commands Eng 11 Keyer Follow MLE Follow Panel Commands Eng 11 Transition Module Auto Key Global-Store setup MLE-Store setup Auto Recall Personality setting	Eng 10-2 Eng 12-22 Eng 12-43 I-3, Eng 12-43 I-3, Eng 12-44 Eng 12-44 Eng 12-44 Eng 12-44 Eng 12-42 -3, Eng 12-41 Eng 12-44 Eng 7-4 Eng 7-8 Eng 7-8 Eng 11 4
Audio Servers custom control functions Audio Source Assignment Audio Transitions Personality setting Auto Follow Bus Follow Custom Control Commands Eng 11 Editor Commands Eng 11 Keyer Follow MLE Follow Panel Commands Eng 11 Transition Module Auto Key Global-Store setup MLE-Store setup Auto Recall, Personality setting	Eng 10-2 Eng 12-22 Eng 12-22 Eng 11-3 Eng 12-40 Eng 12-43 1-3, Eng 12-41 Eng 12-44 Eng 12-44 Eng 12-42 -3, Eng 12-41 Eng 12-44 Eng 7-4 Eng 7-8 Eng 7-8 Eng 11-4
Audio Servers custom control functions Audio Source Assignment Audio Transitions Personality setting Auto Follow Bus Follow Custom Control Commands Eng 11 Editor Commands Eng 11 Keyer Follow Memory Recall MLE Follow Panel Commands Eng 11 Transition Module Auto Key Global-Store setup MLE-Store setup Auto Recall, Personality setting Auto Remove Key	Eng 10-2 Eng 12-22 Eng 11-3 Eng 12-40 Eng 12-43 I-3, Eng 12-41 -3, Eng 12-41 Eng 12-44 Eng 12-44 Eng 12-44 Eng 12-42 -3, Eng 12-42 -3, Eng 12-41 Eng 7-4 Eng 7-4 Eng 7-8 Eng 7-8 Eng 11-4

Auto Select Keys	Eng 7-4
setup	Eng 7-8
Automated Testing Tool, see Checksums	
Aux Buses	
Aux Monitor Output BNCs	Eng 8-3
AuxKeys	Eng 12-2
Output BNCs	Eng 8-3
Output Menu	Eng 8-5
Outputs Menu	Eng 8-5
Quick NavigationEng 5-	9, Eng 5-10
setup	Eng 12-2
shifted MLE key bus	Eng 12-2
Aux Mix/Key setup	Eng 8-22
Aux Mix/Pre Cabling and Setup	Eng 8-24
Aux Mix/Pre Setun	Eng 8-23
Aux Monitor Output BNCs	Eng 8-3
Aux Panel GPL I/O	Eng 0 5
CCU joystick control	Eng 1/-13
Worksheet	Eng 14-15
Aux Papala	Elig 21-15
Aux Fallels	
Folts	$E_{ma} = 20.21$
ECII0	Eng 20-31
GP1	Eng 20-30
Main	Eng 20-30
Aux Ports	Eng 20-25
Aux, definition	Eng I-5
AuxBkgdCut, button	Eng 7-15
AuxBkgdTrans, button	Eng 7-15
Auxiliary Control PanelsEng 14-	1, Eng 14-2
External Row	
comm setup	Eng 14-8
GPIs	Eng 14-11
Internal Row	
comm setup	Eng 14-8
Auxiliary Panels	
Auxiliary Control Panels	Eng 14-2
overview	Eng 14-2
Remote Aux Panels	Eng 14-3
AuxKeyCut, button	Eng 7-15
AuxKeys	
option	Eng 8-22
setup	Eng 8-22
AuxKeys option	Eng 6-17
AuxKeyTrans, button	Eng 7-15
-	-
В	
Back Button	Eng 5-5
Back-to-Back Extra Option	Eng 9-26
Bank 0 Lit Personality setting	Eng 11-4
Banks	
audio versus normal	Eng 10-5
custom control functions Eng 10	Eng 10-5
Select Memory Bank event	Eng 10-0
setun custom control	Eng 10-10
types	Eng 10-5
cypes	Liig 10-J

IX-2 • Index	Vision Engin
Basics	Button mapping, default
Dase Exha OpuoliElig 9-29	Dutton manning default
Page Extra Option Enc 0.20	specifications
types Eng 10.5	size
setun, custom control Eng 10-10	installing
Select Memory Bank event Eng 10-2, Elig 10-3	Button Insert Films
custom control functions Eng 10-2 Eng 10.5	Button Cap Assembly, remo
audio versus normal Eng 10.5	Swap Program and Pres
Banks	Buses
Back O L it Personality setting Eng 11-4	Worksheet
Back-to-Back Extra Ontion Eng 9-26	Storing individual
- Eng 5-5	Shift
В	Registers
<b>,</b> ,	Recalling individual
AuxKeyTrans, buttonEng 7-15	naming
AuxKeys optionEng 6-17	editing
setupEng 8-22	defaulting
optionEng 8-22	Defaulting
AuxKeys	copying
AuxKeyCut, buttonEng 7-15	multiple buses
U	

Switcher	Eng 2-1
BKGD 1, 2	Eng 7-14
BLACK	Eng 7-14
BNC	Eng 7-4
configuration	Eng 8-1
Names	Eng 7-2
	Eng 8 2
	Elig 6-2
	Eng 8-5
Setup	/
input	Eng 7-4
input types	Eng 7-4
setup types	Eng 8-2
Tally	Eng 7-4
Туре	Eng 7-4
type menu	Eng 8-2
Video Mode	Eng 7-4
Boards	8
frame location	Eng 4-18
front (frama)	Eng 4 21
lab alling	Eing 4-21
labelling	Eng 2-37
Power Distribution	Eng 2-11
rear (frame)	Eng 4-22
Bottom MLE	
reference description	Eng 1-4
Brightness, Setting Display	Eng 11-20
BSD License	Eng 22-7
BSS4	C
cabling	Eng 9-13
communications settings	Eng 9-18
programming	$Eng 9_17$
Bus Address Extra Option	Eng 0.26
Bus Dischling, Conversion Loops	$\operatorname{Eng} 16.5$
Bus Disability, Conversion Loops	Eng 10-3
Bus Hold Clear, Personality setting	Eng 11-4
Bus Hold, button	Eng 7-15
Bus Maps	Eng 7-13
Assigning	Eng 7-19
individual bus	Eng 7-19
multiple buses	Eng 7-20
copying	Eng 7-16
Defaulting	Eng 12-28
defaulting	Eng 7-17
editing	Eng 7-13
naming	Eng 7-22
Recalling individual	Eng 13-13
Pogistors	Eng 12 2
Sh:f4	$\operatorname{Eng} 7 16$
Shift	Eng /-10
Storing individual	Eng 13-8
Worksheet	Eng 21-6
Buses	
Swap Program and Preset	Eng 11-12
Button Cap Assembly, removing	Eng 3-17
Button Insert Films	Eng 3-17
installing	Eng 3-17
size	Eng 3-17
specifications	<b>Б</b> 2 17
1	Eng 3-17
Button mapping, default	Eng 3-17
Button mapping, default	Eng 3-17 Eng 3-13

menu system .....Eng 5-4

#### Buttons

Back	Eng 5-5
Bus Map	Eng 7-13
Copy Down	Eng 5-5
Copy Up	Eng 5-5
Forward	Eng 5-5
programming a custom control bu	tton Eng 10-8
Swap	Eng 5-5

#### **C** Cables

Cables	
control (Touchscreen)Eng 3	3-9
DVIEng 3	3-9
Frame/Control Panel Eng 3-	11
power (Touchscreen)Eng 3-	20
USB (Touchscreen)Eng 3	3-9
Cabling	
Aux Mix/PreEng 8-	24
BSS4Eng 9-	13
DeviceMasterEng 9-	14
frame to control panel	11
NetExp Eng 9-	14
remote aux panels Eng 14	1-7
Calibration Eng 1	., 7-1
Fader Eng 17	7_3
Positioner Eng 17	, J 7_/
Touchscreen Eng 17	7- <del>4</del> 7/1
Call Custom Control event Eng 10	10
Can Custom Controls Eng 10-	10
Cam All Stop Custom ControlsEng 10-	19
Camera File	20
DefaultingEng 12-	28
Capture, screen	18
Card, System Information Page Eng 6-	12
Carrier, Squeeze & Tease Board . Eng 2-27, Eng 2-	28
CC/Macro Attachments Eng 13-5, Eng 13-	10
Registers Eng 13	3-3
CC/Macro Attachments, Personality setting Eng 11	l-4
Center	
Preview Overlay SetupEng 12-	35
CG, definitionEng	l-5
Char Gen, Input BNC TypeEng 7	7-5
Character Generators Eng 6-	17
Check, Keys Eng 7-	26
Checksum Custom ControlEng 17-	33
shortEng 17-	33
usingEng 17-	35
Choose Clip IDEng 12-	18
Circuit Boards	
installing (frame)Eng 4-	18
labelling	37
removing (frame)Eng 4-	18
Clean Feed Eng 8	3-8
MLE Fng S	3-3
output BNC Fng S	
setun Fng S	3_7
Cleaning Air Filter Eng 18	
	14
Clear Bus Hold Eng 11	·14  _4

Clip ID
setupEng 12-18
Clip Inpoint/Outpoint, video servers Eng 12-19
Clip List Extra Option
Clip Registers Eng 12-17. Eng 13-2
timecode grab Eng 12-20
Clip Sotup Eng 12 17
Clip SetupElig 12-17
Defaulting
Keypad Clip IDs Entry Eng 11-8
Cmd Queuing Extra Option Eng 9-30
Color Correction Eng 6-18
Color Scheme Quick Navigation Eng 5-9
Color Schemes
All MLEs the Same Eng 11-14
editing buttons Eng 11-14
editing mnemonics Eng 11-18
Loading Eng 11 21
LoadingEng 11-21
User Colors Eng 11-15
Custom Control Buttons Eng 11-15
Re-entry Eng 11-15
Selected Buttons Eng 11-15
Selected Xpt Eng 11-15
Xpt ColorsEng 11-16
Communication Errors Eng 17-14
Communication Port Monitor
Data File Eng 17-38
Communication Ports Eng 2-15
Device Drivers Eng 0 2
Ethermot
EulernetElig 9-3
Serial, Frame Eng 9-2
Serial, Panel Eng 9-2
Communication StatusEng 17-14
Communication StatusEng 17-14 CommunicationsEng 9-1
Communication StatusEng 17-14 CommunicationsEng 9-1 Extra OptionsEng 9-26
Communication StatusEng 17-14 CommunicationsEng 9-1 Extra OptionsEng 9-26 SetupEng 9-7
Communication StatusEng 17-14 CommunicationsEng 9-1 Extra OptionsEng 9-26 SetupEng 9-7 Com SettingsEng 9-8, Eng 9-11
Communication StatusEng 17-14 CommunicationsEng 9-1 Extra OptionsEng 9-26 SetupEng 9-7 Com SettingsEng 9-8, Eng 9-11 Com TypeEng 9-8, Eng 9-11
Communication StatusEng 17-14 CommunicationsEng 9-1 Extra OptionsEng 9-26 SetupEng 9-7 Com SettingsEng 9-8, Eng 9-11 Com TypeEng 9-8, Eng 9-11 RS-232Eng 9-8
Communication StatusEng 17-14 CommunicationsEng 9-1 Extra OptionsEng 9-26 SetupEng 9-7 Com SettingsEng 9-8, Eng 9-11 Com TypeEng 9-8, Eng 9-11 RS-232Eng 9-8 RS-422 Eng 9-8
Communication Status   Eng 17-14     Communications   Eng 9-1     Extra Options   Eng 9-26     Setup   Eng 9-7     Com Settings   Eng 9-8, Eng 9-11     Com Type   Eng 9-8, Eng 9-11     RS-232   Eng 9-8     RS-422   Eng 9-8     RS-422   Eng 9-8
Communication StatusEng 17-14 CommunicationsEng 9-1 Extra OptionsEng 9-26 SetupEng 9-7 Com SettingsEng 9-8, Eng 9-11 Com TypeEng 9-8, Eng 9-11 RS-232Eng 9-8, Eng 9-8 RS-422 NullEng 9-8 TCP/IP
Communication StatusEng 17-14 CommunicationsEng 9-1 Extra OptionsEng 9-26 SetupEng 9-7 Com SettingsEng 9-8, Eng 9-11 Com TypeEng 9-8, Eng 9-11 RS-232Eng 9-8, Eng 9-8 RS-422Eng 9-8 RS-422 NullEng 9-8 TCP/IPEng 9-11
Communication Status Eng 17-14   Communications Eng 9-1   Extra Options Eng 9-26   Setup Eng 9-7   Com Settings Eng 9-8, Eng 9-11   Com Type Eng 9-8, Eng 9-11   RS-232 Eng 9-8   RS-422 Eng 9-8   TCP/IP Eng 9-11   UDP/IP Eng 9-11
Communication Status Eng 17-14   Communications Eng 9-1   Extra Options Eng 9-26   Setup Eng 9-7   Com Settings Eng 9-8, Eng 9-11   Com Type Eng 9-8, Eng 9-11   RS-232 Eng 9-8   RS-422 Eng 9-8   TCP/IP Eng 9-11   UDP/IP Eng 9-7, Eng 9-11   Device Eng 9-7, Eng 9-11
Communication Status Eng 17-14   Communications Eng 9-1   Extra Options Eng 9-26   Setup Eng 9-7   Com Settings Eng 9-8, Eng 9-11   Com Type Eng 9-8, Eng 9-11   RS-232 Eng 9-8   RS-422 Eng 9-8   TCP/IP Eng 9-11   UDP/IP Eng 9-7, Eng 9-11   Device Eng 9-7, Eng 9-11   VTR Preroll Eng 9-8, Eng 9-9, Eng 9-11
Communication Status Eng 17-14   Communications Eng 9-1   Extra Options Eng 9-26   Setup Eng 9-7   Com Settings Eng 9-8, Eng 9-11   Com Type Eng 9-8, Eng 9-11   RS-232 Eng 9-8   RS-422 Eng 9-8   RS-422 Null Eng 9-8   TCP/IP Eng 9-11   UDP/IP Eng 9-7, Eng 9-11   VTR Preroll Eng 9-8, Eng 9-9, Eng 9-11 ethernet communications
Communication Status Eng 17-14   Communications Eng 9-1   Extra Options Eng 9-26   Setup Eng 9-7   Com Settings Eng 9-8, Eng 9-11   Com Type Eng 9-8, Eng 9-11   RS-232 Eng 9-8   RS-422 Eng 9-8   RS-422 Eng 9-8   TCP/IP Eng 9-11   UDP/IP Eng 9-7, Eng 9-11   VTR Preroll Eng 9-8, Eng 9-9, Eng 9-11 ethernet communications   Extra Options Eng 9-9
Communication StatusEng 17-14 CommunicationsEng 9-1 Extra OptionsEng 9-26 SetupEng 9-7 Com SettingsEng 9-8, Eng 9-11 Com TypeEng 9-8, Eng 9-11 RS-232Eng 9-8 RS-422 NullEng 9-8 RS-422 NullEng 9-8 TCP/IPEng 9-11 UDP/IPEng 9-7, Eng 9-11 DeviceEng 9-8, Eng 9-9, Eng 9-11 VTR Preroll Eng 9-8, Eng 9-9, Eng 9-11 ethernet communicationsEng 9-9 FlexDeviceEng 9-4
Communication StatusEng 17-14 CommunicationsEng 9-1 Extra OptionsEng 9-26 SetupEng 9-7 Com SettingsEng 9-8, Eng 9-11 Com TypeEng 9-8, Eng 9-11 RS-232Eng 9-8, Eng 9-8 RS-422 NullEng 9-8 TCP/IPEng 9-11 UDP/IPEng 9-11 DeviceEng 9-7, Eng 9-11 VTR Preroll Eng 9-8, Eng 9-9, Eng 9-11 ethernet communicationsEng 9-9 FlexDeviceEng 9-4 Mon Wall SettingsEng 9-9
Communication StatusEng 17-14 CommunicationsEng 9-1 Extra OptionsEng 9-26 SetupEng 9-7 Com SettingsEng 9-8, Eng 9-11 Com TypeEng 9-8, Eng 9-11 RS-232Eng 9-8, Eng 9-8 RS-422 NullEng 9-8 RS-422 NullEng 9-8 TCP/IPEng 9-11 UDP/IPEng 9-7, Eng 9-11 DeviceEng 9-8, Eng 9-9, Eng 9-11 ethernet communicationsEng 9-9 FlexDeviceEng 9-4 Mon Wall SettingsEng 9-7
Communication StatusEng 17-14 CommunicationsEng 9-1 Extra OptionsEng 9-26 SetupEng 9-7 Com SettingsEng 9-8, Eng 9-11 Com TypeEng 9-8, Eng 9-11 RS-232Eng 9-8, Eng 9-8 RS-422 NullEng 9-8 TCP/IPEng 9-11 UDP/IPEng 9-7, Eng 9-11 DeviceEng 9-8, Eng 9-9, Eng 9-11 VTR Preroll Eng 9-8, Eng 9-9, Eng 9-10 Extra OptionsEng 9-4 Mon Wall SettingsEng 9-7 Eng 9-7 TypeEng 9-10
Communication StatusEng 17-14 CommunicationsEng 9-1 Extra OptionsEng 9-26 SetupEng 9-7 Com SettingsEng 9-8, Eng 9-11 Com TypeEng 9-8, Eng 9-11 RS-232Eng 9-8, Eng 9-8 RS-422 NullEng 9-8 RS-422 NullEng 9-8 TCP/IPEng 9-11 UDP/IPEng 9-7, Eng 9-11 VTR Preroll Eng 9-8, Eng 9-9, Eng 9-11 ethernet communicationsEng 9-9 FlexDeviceEng 9-9 Serial communicationsEng 9-7 TypeEng 9-7, Eng 9-10 external link portEng 9-7
Communication StatusEng 17-14 CommunicationsEng 9-1 Extra OptionsEng 9-26 SetupEng 9-7 Com SettingsEng 9-8, Eng 9-11 Com TypeEng 9-8, Eng 9-11 RS-232Eng 9-8, Eng 9-8 RS-422 NullEng 9-8 RS-422 NullEng 9-8 TCP/IPEng 9-11 UDP/IPEng 9-7, Eng 9-11 DeviceEng 9-8, Eng 9-9, Eng 9-11 ethernet communicationsEng 9-9 FlexDeviceEng 9-9 FlexDeviceEng 9-7 Mon Wall SettingsEng 9-7 TypeEng 9-7 Eng 9-10 external link portEng 9-10
Communication StatusEng 17-14 CommunicationsEng 9-1 Extra OptionsEng 9-26 SetupEng 9-7 Com SettingsEng 9-8, Eng 9-11 Com TypeEng 9-8, Eng 9-11 RS-232Eng 9-8, Eng 9-8 RS-422 NullEng 9-8 RS-422 NullEng 9-8 TCP/IPEng 9-11 UDP/IPEng 9-7, Eng 9-11 DeviceEng 9-8, Eng 9-9, Eng 9-11 ethernet communicationsEng 9-9 FlexDeviceEng 9-8 Mon Wall SettingsEng 9-7 TypeEng 9-7 Eng 9-7, Eng 9-10 external link portEng 9-7 network portEng 9-10
Communication Status
Communication StatusEng 17-14 CommunicationsEng 9-1 Extra OptionsEng 9-26 SetupEng 9-7 Com SettingsEng 9-8, Eng 9-11 Com TypeEng 9-8, Eng 9-11 RS-232Eng 9-8, Eng 9-8 RS-422 NullEng 9-8 RS-422 NullEng 9-8 TCP/IPEng 9-11 UDP/IPEng 9-7, Eng 9-11 VTR Preroll Eng 9-8, Eng 9-9, Eng 9-11 ethernet communicationsEng 9-9 FlexDeviceEng 9-9 Serial communicationsEng 9-7 TypeEng 9-7, Eng 9-10 external link portEng 9-7 network portEng 9-7, Eng 9-10 remote portEng 9-7, Eng 9-10

remote aux panels	Eng 14-6
Communications Settings	U
BSS4	Eng 9-18
NetExp	Eng 9-18
Communications Worksheet	Eng 21-11
Complete Status	Eng 17-10
Completing Setup	Eng 12-1
Composite Sync reference signal	Eng 4-13
Comtrol DeviceMaster	
programming	Eng 9-17
Configuration	
BNC	Eng 8-1
control panel DIP	Eng 20-28
frame DIP	Eng 20-20
Configuring video inputs	Eng $7.4$
types	Eng 7 4
Connecting to the GPL I/O port	Eng 12 10
Connecting to the GFT I/O point	Elig 12-10
connections	$E_{max} = 2 + 12$
mput	$E_{\rm H} = 2.15$
Output	Eng 3-15
Connector Types	E 20.16
control panel	Eng 20-16
frame	Eng 20-15
Console Cutout Dimensions	Eng 20-7
Console-Top, control panel installation	Eng 3-7
Control Cable	Eng 3-11
Control cable (Touchscreen)	Eng 3-9
Control Panel	
Auto Follow	Eng 11-3
boards	Eng 6-14
buttons	Eng 1-3
color scheme	
editing buttons	Eng 11-14
editing mnemonics	Eng 11-18
connecting to frame	Eng 3-11
connector Types	Eng 20-16
custom control functions	Eng 10-2
Dimensions	Eng 20-6
dimensions	Eng 20-6
displays	Eng 5-15
brightness	Eng 11-20
installation	Eng 3-7
Maintenance	
Hard Drive replacement	Eng 18-15
mapping	Eng 17-5
Quick Module Configure	Eng 17-5
Single Module Configure	Eng 17-6
overview	Eng 2-2
port	Eng 2-16
power connection	Eng 3-20
power fail indicators	Eng 3-21
reference description	Eng 1-4
restart	Eng 4-26
Touchscreen installation	Eng 3-9
tub installation (console-top)	Eng 3-7
tub installation (flush mounted)	Eng 3-8
tub installation (in-console)	Eng 3-7

Vision 1
V1S10n TMEng 2-5
Vision 2Eng 2-5
Vision 2MEng 2-4
Vision 2XEng 2-3
Vision 3Eng 2-2
Vision 3M Eng 2-4
Vision 4 Eng 2-2
Control Panel Diagnostics Eng 17-18
Burn Mode Eng 17-27
Button Color Test Eng 17-18
Button Function Test Eng 17-18
Display Test Eng 17-21
Fader Test Eng 17-19
Knoh Tost Eng 17-19
knob TestElig 17-21
bainer Eng 17-22
boundaryEng 17-22
buttonEng 17-22
PCH Memory TestEng 1/-22
LVDS TestEng 17-23
PCI Bridge TestEng 17-25
Tally TestEng 17-25
Tx/Rx TestEng 17-22
Positioner TestEng 17-20
SBC Tx/Rx TestEng 17-26
Stuck Button Test Eng 17-19
Touchscreen
Draw Test Eng 17-27
Pattern Test Eng 17-26
Control Panel Ports
AC powerEng 20-26
AC powerEng 20-26 auxEng 20-25
AC powerEng 20-26 auxEng 20-25 external linkEng 20-24
AC powerEng 20-26 auxEng 20-25 external linkEng 20-24 remoteEng 20-24
AC powerEng 20-26 auxEng 20-25 external linkEng 20-24 remoteEng 20-24 Control Panel Power SupplyEng 18-9
AC powerEng 20-26 auxEng 20-25 external linkEng 20-24 remoteEng 20-24 Control Panel Power SupplyEng 18-9 replacingEng 18-4
AC powerEng 20-26 auxEng 20-25 external linkEng 20-24 remoteEng 20-24 Control Panel Power SupplyEng 18-9 replacingEng 18-4 Control Panel Power Supply FailureEng 18-2
AC powerEng 20-26 auxEng 20-25 external linkEng 20-24 remoteEng 20-24 Control Panel Power SupplyEng 18-9 replacingEng 18-4 Control Panel Power Supply FailureEng 18-2 troubleshootingEng 18-2, Eng 18-3
AC powerEng 20-26 auxEng 20-25 external linkEng 20-24 remoteEng 20-24 Control Panel Power SupplyEng 18-9 replacingEng 18-9 troubleshootingEng 18-2 troubleshootingEng 18-2, Eng 18-3 Conventions, documentationEng 1-3
AC powerEng 20-26 auxEng 20-25 external linkEng 20-24 remoteEng 20-24 Control Panel Power SupplyEng 18-9 replacingEng 18-9 replacingEng 18-2 troubleshootingEng 18-2, Eng 18-3 Conventions, documentationEng 18-2, Eng 18-3 Conversion Loop WorksheetEng 21-20
AC powerEng 20-26 auxEng 20-25 external linkEng 20-24 remoteEng 20-24 Control Panel Power SupplyEng 18-9 replacingEng 18-9 troubleshootingEng 18-2 troubleshootingEng 18-2, Eng 18-3 Conventions, documentationEng 18-2, Eng 18-3 Conversion Loop WorksheetEng 21-20 Conversion LoopsEng 16-2
AC powerEng 20-26 auxEng 20-25 external linkEng 20-24 remoteEng 20-24 Control Panel Power SupplyEng 18-9 replacingEng 18-9 troubleshootingEng 18-2, Eng 18-2 troubleshootingEng 18-2, Eng 18-3 Conventions, documentationEng 18-2, Eng 1-3 Conversion Loop WorksheetEng 21-20 Conversion LoopsEng 16-2 activationEng 16-3
AC powerEng 20-26 auxEng 20-25 external linkEng 20-24 remoteEng 20-24 Control Panel Power SupplyEng 18-9 replacingEng 18-4 Control Panel Power Supply FailureEng 18-2 troubleshootingEng 18-2, Eng 18-3 Conventions, documentationEng 18-2, Eng 18-3 Conversion Loop WorksheetEng 21-20 Conversion LoopsEng 16-2 activationEng 16-3 Bus DisablingEng 16-5
AC powerEng 20-26 auxEng 20-25 external linkEng 20-24 remoteEng 20-24 Control Panel Power SupplyEng 18-9 replacingEng 18-4 Control Panel Power Supply FailureEng 18-2 troubleshootingEng 18-2, Eng 18-3 Conventions, documentationEng 18-2, Eng 18-3 Conversion Loop WorksheetEng 21-20 Conversion LoopsEng 16-2 activationEng 16-3 Bus DisablingEng 16-3
AC powerEng 20-26 auxEng 20-25 external linkEng 20-24 remoteEng 20-24 Control Panel Power SupplyEng 18-9 replacingEng 18-4 Control Panel Power Supply FailureEng 18-2 troubleshootingEng 18-2, Eng 18-3 Conventions, documentationEng 18-2, Eng 18-3 Conversion Loop WorksheetEng 18-2 activationEng 16-2 activationEng 16-3 Bus DisablingEng 16-3 Include AuxEng 16-2
AC powerEng 20-26 auxEng 20-25 external linkEng 20-24 remoteEng 20-24 Control Panel Power SupplyEng 18-9 replacingEng 18-9 troubleshootingEng 18-2, Eng 18-2 troubleshootingEng 18-2, Eng 18-3 Conversion Loop WorksheetEng 18-2 Conversion LoopsEng 16-2 activationEng 16-3 Bus DisablingEng 16-3 Include AuxEng 16-2 Locking to BusesEng 16-6
AC powerEng 20-26auxEng 20-25external linkEng 20-24remoteEng 20-24Control Panel Power SupplyEng 18-9replacingEng 18-4Control Panel Power Supply FailureEng 18-2troubleshootingEng 18-2, Eng 18-3Conventions, documentationEng 1-3Conversion Loop WorksheetEng 21-20Conversion LoopsEng 16-2activationEng 16-3Bus DisablingEng 16-5delayEng 16-5Locking to BusesEng 16-6setunEng 16-7
AC powerEng 20-26auxEng 20-25external linkEng 20-24remoteEng 20-24Control Panel Power SupplyEng 18-9replacingEng 18-2troubleshootingEng 18-2, Eng 18-3Conventions, documentationEng 1-3Conversion Loop WorksheetEng 16-2activationEng 16-3Bus DisablingEng 16-3Include AuxEng 16-2Locking to BusesEng 16-2switcher setupEng 16-2Switcher setupEng 16-2
AC powerEng 20-26auxEng 20-25external linkEng 20-24remoteEng 20-24Control Panel Power SupplyEng 18-9replacingEng 18-2troubleshootingEng 18-2, Eng 18-3Conventions, documentationEng 18-2, Eng 18-3Conversion Loop WorksheetEng 21-20Conversion LoopsEng 16-2activationEng 16-3Bus DisablingEng 16-3Include AuxEng 16-3Locking to BusesEng 16-6setupEng 16-5video formatsEng 16-5
AC powerEng 20-26auxEng 20-25external linkEng 20-24remoteEng 20-24Control Panel Power SupplyEng 18-9replacingEng 18-4Control Panel Power Supply FailureEng 18-2troubleshootingEng 18-2, Eng 18-3Conventions, documentationEng 16-2Conversion Loop WorksheetEng 16-2activationEng 16-3Bus DisablingEng 16-5delayEng 16-5delayEng 16-5setupEng 16-6setupEng 16-7switcher setupEng 16-5video formatsEng 16-3Converter Extra OptionEng 20-24
AC powerEng 20-26auxEng 20-25external linkEng 20-24remoteEng 20-24Control Panel Power SupplyEng 18-9replacingEng 18-4Control Panel Power Supply FailureEng 18-2troubleshootingEng 18-2, Eng 18-3Conventions, documentationEng 12-20Conversion Loop WorksheetEng 16-2activationEng 16-3Bus DisablingEng 16-5delayEng 16-5delayEng 16-5video formatsEng 16-5video formatsEng 16-3Converter Extra OptionEng 9-26Converter LookingConversion LoopsEng 16-3Eng 16-3
AC powerEng 20-26auxEng 20-25external linkEng 20-24remoteEng 20-24Control Panel Power SupplyEng 18-9replacingEng 18-2troubleshootingEng 18-2, Eng 18-3Conventions, documentationEng 16-2Conversion Loop WorksheetEng 16-2activationEng 16-3Bus DisablingEng 16-3Include AuxEng 16-2Locking to BusesEng 16-5video formatsEng 16-3Converter Extra OptionEng 16-3Converter Locking, Conversion LoopsEng 16-6Converter Locking, Conversion LoopsEng 16-6
AC powerEng 20-26auxEng 20-25external linkEng 20-24remoteEng 20-24Control Panel Power SupplyEng 18-9replacingEng 18-9troubleshootingEng 18-2, Eng 18-3Conventions, documentationEng 18-2, Eng 18-3Conversion Loop WorksheetEng 21-20Conversion LoopsEng 16-2activationEng 16-3Bus DisablingEng 16-3Include AuxEng 16-3Locking to BusesEng 16-5video formatsEng 16-3Converter Extra OptionEng 9-26Converter Locking, Conversion LoopsEng 18-8Converter Locking, Conversion LoopsEng 18-8
AC powerEng 20-26auxEng 20-25external linkEng 20-24remoteEng 20-24Control Panel Power SupplyEng 18-9replacingEng 18-9replacingEng 18-2troubleshootingEng 18-2, Eng 18-3Conventions, documentationEng 12-20Conversion Loop WorksheetEng 21-20Conversion LoopsEng 16-2activationEng 16-3Bus DisablingEng 16-5delayEng 16-5delayEng 16-5video formatsEng 16-6switcher setupEng 16-3Converter Extra OptionEng 9-26Converter Locking, Conversion LoopsEng 16-6Cooling Fan Failure, FrameEng 18-8Copy Bus MapsEng 7-16
AC powerEng 20-26auxEng 20-25external linkEng 20-24remoteEng 20-24Control Panel Power SupplyEng 18-9replacingEng 18-4Control Panel Power Supply FailureEng 18-2troubleshootingEng 18-2, Eng 18-3Conventions, documentationEng 16-2activationEng 16-3Bus DisablingEng 16-5delayEng 16-5delayEng 16-5video formatsEng 16-5video formatsEng 16-5video formatsEng 16-5Converter Locking, Conversion LoopsEng 16-6Converter Locking, Conversion LoopsEng 16-6Converter Locking, Conversion LoopsEng 16-6Converter Locking, Conversion LoopsEng 16-6Converter Locking, Conversion LoopsEng 16-6Copy Bus MapsEng 7-16Copy Down ButtonEng 5-5Conv Lu PuttonEng 5-5
AC powerEng 20-26auxEng 20-25external linkEng 20-24remoteEng 20-24Control Panel Power SupplyEng 18-9replacingEng 18-2troubleshootingEng 18-2, Eng 18-3Conventions, documentationEng 18-2, Eng 18-3Conversion Loop WorksheetEng 21-20Conversion LoopsEng 16-2activationEng 16-3Bus DisablingEng 16-3Include AuxEng 16-3Locking to BusesEng 16-5video formatsEng 16-5video formatsEng 16-5video formatsEng 16-6Souverter Extra OptionEng 16-6Converter Locking, Conversion LoopsEng 16-6Converter Locking, Conversion LoopsEng 16-6Copy Bus MapsEng 7-16Copy Down ButtonEng 5-5Copy Up ButtonEng 5-5
AC powerEng 20-26auxEng 20-25external linkEng 20-24remoteEng 20-24Control Panel Power SupplyEng 18-9replacingEng 18-2troubleshootingEng 18-2, Eng 18-3Conventions, documentationEng 18-2, Eng 18-3Conversion Loop WorksheetEng 21-20Conversion LoopsEng 16-2activationEng 16-3Bus DisablingEng 16-3Include AuxEng 16-3Locking to BusesEng 16-5video formatsEng 16-5video formatsEng 16-5Converter Locking, Conversion LoopsEng 16-6Converter Locking, Conversion LoopsEng 16-6Converter Locking, Conversion LoopsEng 16-5Converter Locking, Conversion LoopsEng 16-6Copy Bus MapsEng 18-8Copy Up ButtonEng 5-5Copying Custom ControlsEng 10-28

Copying Shot Box Pages	Eng 15-6
Count Down Custom Control	Eng 10-19
Count Down/Up Custom Control	Eng 10-19
Count Up Custom Control	Eng 10-19
CPU	Ling IO I
architecture	Eng 2-36
structure	Eng 2-35
Creating Custom Controls, tips	Eng 10-9
Creating Shot Box Pages	Eng 15-4
Crosspoint Board	Eng 2-13
Crosspoint Bus Map	Eng 7-13
Crosspoint Colors	Eng 11-16
Crosspoint Matrix overview	Eng 2-20
Crosspoints	Eng 2 20
Button Color	Eng 11-16
Currently used storage capacity	Eng 6-13
CustCtrl MI E Extra Option	Eng 9-27
Custom Control Attachments	Ling <i>J-21</i>
Defaulting	Eng 12 28
Custom Control Shot Box Modules	Eng $12-20$
custom Control Shot Box Modules	Eng 15-1
Custom Control Workshoot	$E_{\rm Eng} 21.19$
Custom Controls	Eng 10 1
Assign Audio	Elig 10-1
Assign Audio	Eng 10-10
Assign Channel	Eng 10-18
attach to panel buttons	Eng 10-21
Post-Attach	Eng 10-22
Pre-Attach	Eng 10-22
Replace	Eng 10-22
Audio All Off	Eng 10-16
Audio Channel Off	Eng 10-16
Audio Channel On	Eng 10-16
Audio Memory	Eng 10-16
audio server clips	Eng 10-2
Auto Follow Eng 11-3,	Eng 12-41
Automation	
Act MLE Trans	Eng 10-18
Keys Off Air	Eng 10-18
bank functions	Eng 10-2
bank naming	Eng 10-6
bank types	Eng 10-5
banks	Eng 10-5
banks setup	Eng 10-5
Button Color	Eng 11-15
Cam All Stop	Eng 10-19
Checksums	Eng 17-33
short	Eng 17-33
using	Eng 17-35
control panel functions Eng 10-2	2, Eng 10-8
copying	Eng 10-28
Count Down	Eng 10-19
Count Down/Up	Eng 10-19
Count Up	Eng 10-19
custom control bus	Eng 10-3
Cut Keys	Eng 10-20
Defaulting	Eng 12-28
Deleting	Eng 10-29

	Eng 10-19
Editing	Eng 10-25
delete event	Eng 10-27
insert event, control panel	Eng 10-26
insert special event	Eng 10-27
modify event	Eng 10-26
Run From Here	Eng 10-26
Run Single Event	Eng 10-26
External DVE functions	Eng $10-20$
External DVE functions	Elig 10-2
Fast Forward	Eng 10-19
Fire Salvo	Eng 10-19
Frame Advance Eng 10-17,	Eng 10-19
Frame Reverse Eng 10-17,	Eng 10-19
Go To Clip	Eng 10-19
Go To Cut	Eng 10-17
Go To End	Eng 10-17
Go To Menu	Eng 10-20
Go To Start	Eng 10-17
Hold CC	Eng 10-20
Key Frame Adv	Eng 10-17
Key Frame Rev	Eng 10-17
Load (CG)	Eng 10 17
Load Lavout	Eng 10-17
Load Layout	Eng 10-18
	Eng 10-20
looping	Eng 10-10
Modify Dynamic Text	Eng 10-18
moving	Eng 10-28
Multiple	Eng 11-9
naming buttons	Eng 10-24
Notify End CC	Eng 10-20
Pause	Eng 10 17
	Eng 10-17
Pause CC	Eng 10-17 Eng 10-20
Pause CC Pause DVE	Eng 10-17 Eng 10-20 Eng 10-18
Pause CC Pause DVE Pause VTR	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-19
Pause CC Pause DVE Pause VTR Phys protocol functions	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-19 Eng 10-2
Pause CC Pause DVE Pause VTR Pbus protocol functions PGM Audio Level	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-19 Eng 10-2 Eng 10-16
Pause CC Pause DVE Pause VTR Pbus protocol functions PGM Audio Level Play. Eng 10, 17, Eng 10, 18	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-19 Eng 10-2 Eng 10-16
Pause CC Pause DVE Pause VTR Pbus protocol functions PGM Audio Level Play	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-19 Eng 10-19 Eng 10-16 Eng 10-19
Pause CC Pause DVE Pause VTR Pbus protocol functions PGM Audio Level Play	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-19 Eng 10-2 Eng 10-16 Eng 10-19 Eng 10-17
Pause CC Pause DVE Pause VTR Pbus protocol functions PGM Audio Level Play	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-19 Eng 10-2 Eng 10-16 Eng 10-19 Eng 10-17 Eng 10-19
Pause CC Pause DVE Pause VTR Pbus protocol functions PGM Audio Level Play Eng 10-17, Eng 10-18, Play (CG) Play Loop Off Play Loop On	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-19 Eng 10-2 Eng 10-16 Eng 10-19 Eng 10-17 Eng 10-19 Eng 10-19
Pause CC Pause DVE Pause VTR Pbus protocol functions PGM Audio Level Play Eng 10-17, Eng 10-18, Play (CG) Play Loop Off Play Loop On Play Rev	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-19 Eng 10-2 Eng 10-16 Eng 10-19 Eng 10-17 Eng 10-19 Eng 10-19 Eng 10-19
Pause CC Pause DVE Pause VTR Pbus protocol functions PGM Audio Level Play Eng 10-17, Eng 10-18, Play (CG) Play Loop Off Play Loop On Play Rev Play w/ Alpha	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-19 Eng 10-2 Eng 10-16 Eng 10-19 Eng 10-17 Eng 10-19 Eng 10-19 Eng 10-18 Eng 10-19
Pause CC Pause DVE Pause VTR Pbus protocol functions PGM Audio Level Play Eng 10-17, Eng 10-18, Play (CG) Play Loop Off Play Loop On Play Rev Play Rev Play w/ Alpha PST Audio Level	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-19 Eng 10-2 Eng 10-16 Eng 10-19 Eng 10-17 Eng 10-19 Eng 10-19 Eng 10-18 Eng 10-19 Eng 10-19 Eng 10-17
Pause CC Pause DVE Pause VTR Pbus protocol functions PGM Audio Level Play Eng 10-17, Eng 10-18, Play Loop Off Play Loop Off Play Loop On Play Rev Play Rev Play w/ Alpha PST Audio Level Quick Navigation Button	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-19 Eng 10-2 Eng 10-16 Eng 10-19 Eng 10-17 Eng 10-19 Eng 10-19 Eng 10-18 Eng 10-19 Eng 10-17 Eng 5-10
Pause CC Pause DVE Pause VTR Pbus protocol functions PGM Audio Level Play Eng 10-17, Eng 10-18, Play (CG) Play Loop Off Play Loop Off Play Rev Play Rev Play Rev Play w/ Alpha PST Audio Level Quick Navigation Button Read (CG)	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-19 Eng 10-2 Eng 10-16 Eng 10-19 Eng 10-17 Eng 10-19 Eng 10-19 Eng 10-19 Eng 10-19 Eng 10-17 Eng 5-10 Eng 10-17
Pause CC Pause DVE Pause VTR Pbus protocol functions PGM Audio Level Play Eng 10-17, Eng 10-18, Play (CG) Play Loop Off Play Loop Off Play Loop On Play Rev Play Rev Play w/ Alpha PST Audio Level Quick Navigation Button Read (CG) Recall (CG)	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-19 Eng 10-2 Eng 10-16 Eng 10-19 Eng 10-17 Eng 10-19 Eng 10-19 Eng 10-19 Eng 10-19 Eng 10-17 Eng 5-10 Eng 10-17 Eng 10-17
Pause CC Pause DVE Pause VTR Pbus protocol functions PGM Audio Level Play Eng 10-17, Eng 10-18, Play (CG) Play Loop Off Play Loop Off Play Loop On Play Rev Play Rev Play w/ Alpha PST Audio Level Quick Navigation Button Read (CG) Recall (CG) Recall DVE	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-19 Eng 10-2 Eng 10-16 Eng 10-19 Eng 10-17 Eng 10-19 Eng 10-19 Eng 10-18 Eng 10-17 Eng 5-10 Eng 10-17 Eng 10-17 Eng 10-18
Pause CC Pause DVE Pause VTR Pbus protocol functions PGM Audio Level Play Eng 10-17, Eng 10-18, Play (CG) Play Loop Off Play Loop Off Play Loop On Play Rev Play Rev Play w/ Alpha PST Audio Level Quick Navigation Button Read (CG) Recall (CG) Recall DVE Recall Pbus	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-19 Eng 10-2 Eng 10-16 Eng 10-19 Eng 10-17 Eng 10-19 Eng 10-19 Eng 10-19 Eng 10-17 Eng 5-10 Eng 10-17 Eng 10-17 Eng 10-17 Eng 10-18 Eng 10-18
Pause CC Pause DVE Pause VTR Pbus protocol functions PGM Audio Level Play Eng 10-17, Eng 10-18, Play (CG) Play Loop Off Play Loop Off Play Loop On Play Rev Play Rev Play w/ Alpha PST Audio Level Quick Navigation Button Recall (CG) Recall DVE Recall Pbus Recall Shot	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-18 Eng 10-19 Eng 10-2 Eng 10-16 Eng 10-19 Eng 10-17 Eng 10-19 Eng 10-19 Eng 10-18 Eng 10-17 Eng 10-17 Eng 10-17 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-18
Pause CC Pause DVE Pause VTR Pbus protocol functions PGM Audio Level Play Eng 10-17, Eng 10-18, Play (CG) Play Loop Off Play Loop Off Play Loop On Play Rev Play Rev Play w/ Alpha PST Audio Level Quick Navigation Button Recal (CG) Recall DVE Recall Pbus Recall Shot recalling individual	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-18 Eng 10-19 Eng 10-2 Eng 10-16 Eng 10-19 Eng 10-17 Eng 10-19 Eng 10-19 Eng 10-18 Eng 10-17 Eng 10-17 Eng 10-17 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-18
Pause CC Pause DVE Pause VTR Pbus protocol functions PGM Audio Level Play Eng 10-17, Eng 10-18, Play (CG) Play Loop Off Play Loop Off Play Loop On Play Rev Play Rev Play w/ Alpha PST Audio Level Quick Navigation Button Recal (CG) Recall DVE Recall Pbus Recall Shot recalling individual	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-18 Eng 10-19 Eng 10-2 Eng 10-16 Eng 10-19 Eng 10-17 Eng 10-19 Eng 10-19 Eng 10-18 Eng 10-17 Eng 10-17 Eng 10-17 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-19
Pause CC Pause DVE Pause VTR Pbus protocol functions PGM Audio Level Play Eng 10-17, Eng 10-18, Play (CG) Play Loop Off Play Loop Off Play Loop On Play Rev Play Rev Play w/ Alpha PST Audio Level Quick Navigation Button Recall (CG) Recall DVE Recall Pbus Recall Shot recalling individual Record Pagistars	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-19 Eng 10-2 Eng 10-16 Eng 10-19 Eng 10-17 Eng 10-19 Eng 10-19 Eng 10-18 Eng 10-17 Eng 10-17 Eng 10-17 Eng 10-17 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-19 Eng 10-18 Eng 10-19 Eng 10-17 Eng 10-17 Eng 10-17 Eng 10-17 Eng 10-17 Eng 10-17 Eng 10-17 Eng 10-18 Eng
Pause CC Pause DVE Pause VTR Pbus protocol functions PGM Audio Level Play Eng 10-17, Eng 10-18, Play (CG) Play Loop Off Play Loop Off Play Loop On Play Rev Play w/ Alpha PST Audio Level Quick Navigation Button Read (CG) Recall OVE Recall DVE Recall Pbus Recall Shot recalling individual Record Registers	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-19 Eng 10-2 Eng 10-16 Eng 10-19 Eng 10-19 Eng 10-19 Eng 10-19 Eng 10-19 Eng 10-19 Eng 10-19 Eng 10-17 Eng 10-17 Eng 10-17 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-19
Pause CC Pause DVE Pouse VTR Pbus protocol functions PGM Audio Level Play Eng 10-17, Eng 10-18, Play (CG) Play Loop Off Play Loop Off Play Loop On Play Rev Play w/ Alpha PST Audio Level Quick Navigation Button Read (CG) Recall (CG) Recall DVE Recall Pbus Recall Pbus Recall Shot recalling individual Record Registers Relative	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-18 Eng 10-19 Eng 10-19 Eng 10-19 Eng 10-19 Eng 10-19 Eng 10-19 Eng 10-19 Eng 10-19 Eng 10-19 Eng 10-17 Eng 10-17 Eng 10-17 Eng 10-18 Eng 10-17 Eng 10-18 Eng 10
Pause CC Pause DVE Pause VTR Pbus protocol functions PGM Audio Level Play Eng 10-17, Eng 10-18, Play Loop Off Play Loop Off Play Loop On Play Rev Play w/ Alpha PST Audio Level Quick Navigation Button Read (CG) Recall OVE Recall DVE Recall Pbus Recall Pbus Recall Shot recalling individual Record Relative Relative	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-18 Eng 10-19 Eng 10-19 Eng 10-19 Eng 10-19 Eng 10-19 Eng 10-19 Eng 10-19 Eng 10-19 Eng 10-18 Eng 10-17 Eng 10-17 Eng 10-18 Eng 10-17 Eng 10-18 Eng 10-19 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-19 Eng 10-18 Eng 10
Pause CC Pause DVE Pause VTR Pbus protocol functions PGM Audio Level Play Eng 10-17, Eng 10-18, Play Loop Off Play Loop Off Play Loop On Play Rev Play Rev Play w/ Alpha PST Audio Level Quick Navigation Button Recall (CG) Recall DVE Recall DVE Recall Pbus Recall Shot recalling individual Record Relative Reset Audio Reset GPI	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-18 Eng 10-19 Eng 10-2 Eng 10-16 Eng 10-19 Eng 10-17 Eng 10-19 Eng 10-19 Eng 10-19 Eng 10-18 Eng 10-17 Eng 10-17 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-19 Eng 13-2 Eng 10-17 Eng 10-17 Eng 10-17 Eng 10-17 Eng 10-17
Pause CC Pause DVE Pause VTR Pbus protocol functions PGM Audio Level Play Eng 10-17, Eng 10-18, Play (CG) Play Loop Off Play Loop Off Play Loop On Play Rev Play Rev Play W/ Alpha PST Audio Level Quick Navigation Button Recall (CG) Recall OVE Recall DVE Recall Shot recalling individual Record Reset Audio Reset GPI Reset Time Clock	Eng 10-17 Eng 10-20 Eng 10-18 Eng 10-18 Eng 10-19 Eng 10-2 Eng 10-16 Eng 10-19 Eng 10-17 Eng 10-19 Eng 10-19 Eng 10-18 Eng 10-17 Eng 10-17 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-18 Eng 10-19 Eng 13-2 Eng 10-11 Eng 10-17 Eng 10-18 Eng 10-18 Eng 10-17

Rewind DVE	Eng 10-18
Run Custom Control event	Eng 10-10
Run Sequence	Eng 10-20
Safe Title	Eng 10-20
Select Memory Bank event	Eng 10-10
Server functions	Eng 10-2
Set Folder (CG)	Eng 10-17
shortcuts	Eng 10-30
Pause/Hold	Eng 10-30
Record	Eng 10-30
Shot Box Module	Eng 10-4
Simulate GPI	Eng 10-18
Soft Shot Box	Eng 10-3
Special Commands	-
Pause, modify	Eng 10-26
Special Functions	Eng 10-15
special functions	Eng 10-2
start recording	Eng 10-9
start relative recording	Eng 10-12
StopEng	10-17, Eng 10-19
Stop command	Eng 10-10
Stop DVE	Eng 10-18
Stop Other CC	Eng 10-20
Stop Time Clock	Eng 10-19
Store Pbus	Eng 10-18
storing individual	Eng 13-7
swapping	Eng 10-28
Take	Eng 10-17
Take Out (CG)	Eng 10-17
Take XPT	Eng 10-19
time clock functions	Eng 10-2
tips	Eng 10-9
Transition Keys	Eng 10-20
Trigger GPI	Eng 10-18
Trigger Pbus	Eng 10-18
video server functions	Eng 10-2
VTR functions	Eng 10-2
Custom Device	Eng 9-22
advanced topics and tables	Eng 23-3
commands	Eng 9-22
protocol uses and limitations	Eng 23-2
Protocol Worksheet	Eng 21-22
Customer service	Eng 1-7
Cut Keys Custom Control	Eng 10-20
Cutout Dimensions	Eng 20-7
D	
D-A definition	Eng 1-5

Default NamesEng 4-16
Default Network AddressEng 20-11
Default Trans Rate
ActiveEng 11-5
Effects DissolveEng 11-5
FTBEng 11-5
Kever
MLE Eng 11-5
Sequence Eng 11-5
Defaulting
Bus Mans Eng 12-28
Camera File Eng 12-28
Clins Eng 12-28
Custom Control Attachment Eng 12-28
Custom Controls Eng 12-28
Installation Eng 12-28
Memories Eng 12-28
Multi Viewer Eng 12-20
NV DAM Eng 12-29
Demonality Eng 12-20
Shet Day Dagas
Shot Box PagesEng 12-28
Squeeze & TeaseEng 12-28
SwitcherEng 12-28
Defaulting Bus MapsEng /-1/
Defaults, FactoryEng 12-27
Defaults, recalling factoryEng 12-27
Definitions
abbreviationsEng 1-5
termsEng 1-4
Deleting Custom Control EventsEng 10-27
Deleting Custom ControlsEng 10-29
Deleting FlexDevice DriversEng 9-6
Deleting option codesEng 6-20
Deselect Cam Custom ControlsEng 10-19
Device DriversEng 9-2
Device Drivers, see FlexDevice Drivers
Device, storage capacityEng 6-13
DeviceMaster
cablingEng 9-14
Diagnosis
Fail IndicatorsEng 17-10
DiagnosticsEng 17-1
Checksums Custom ControlsEng 17-33
Com Port MonitorEng 17-37
Data FileEng 17-38
Communication StatusEng 17-14
ErrorsEng 17-14
Status Eng 17-14
Control Panel Eng 17-18
Burn Mode Eng 17-17
Button Color Test Eng 17-18
Button Function Test Fing 17-10
Display Test Eng 17-10
Fader Test Eng 17 10
1 auci 1051
Knoh Test Eng 17 21

output .....Eng 3-15 Default MLE Map Assignment ......Eng 12-4

# D

D-A, definition	Eng 1-5
DA, definition	Eng 1-5
Data Txfr Extra Option	Eng 9-29
Date, System Information Page	Eng 6-13
DDR, definition	Eng 1-5
Decode NAKs Extra Option	Eng 9-31
Default Audio Level, setting	Eng 12-22
Default Audio Levels	Eng 12-23
Default Mapping	
input	Eng 3-13

barrier	.Eng 17-22
boundary	.Eng 17-22
button	.Eng 17-22
Module Memory Test	.Eng 17-22
PCH	•
LVDS Test	.Eng 17-23
PCI Bridge Test	.Eng 17-25
Tally Test	.Eng 17-25
Tx/Rx Test	.Eng 17-22
Positioner Test	.Eng 17-20
SBC	U
Tx/Rx Test	.Eng 17-26
Stuck Button Test	.Eng 17-19
Touchscreen	
Draw Test	.Eng 17-27
Pattern Test	.Eng 17-26
Frame	.Eng 17-29
DIP Switch Test	.Eng 17-31
GPI Test	.Eng 17-30
Graphics Buffer Test	.Eng 17-31
LEDs Test	.Eng 17-30
Tx/Rx Test	Eng 17-29
Non-Sync	Eng 17-16
Ouick Navigation Button	$Eng 5_9$
Switcher Logs	Eng 17 30
Switcher Status	Eng $17 - 37$
Complete Status	Eng 17-10
Loons	Eng 17-10
ICONS	. Eng 17-12
Version Information	Eng 17-2
Warnings	.Eng 1/-11
Digital reference connection	Eng 4-12
	$E_{max} 20.6$
	Eng 20-0
Control panel cutout	Eng 20-7
	. Eng 20-10
DIP Switch	E 00.00
control panel	.Eng 20-28
trame	.Eng 20-11
Display Brightness	.Eng 11-20
Display Mode Extra Option	Eng 9-26
Display, lower region	Eng 5-3
Display, Touchscreen	Eng 2-7
Display, upper region	Eng 5-3
Displays, control panel	Eng 5-15
Documentation	
abbreviations	Eng 1-5
conventions	Eng 1-3
related publications	Eng 1-6
terms	Eng 1-4
Description of the second seco	Eng 3-3
Door, frame	Eng 11-5
Door, frame	
Door, frame Double-Press BKGD, Personality setting Double-Press Rate, Personality setting	Eng 11-5
Door, trame Double-Press BKGD, Personality setting . Double-Press Rate, Personality setting DSK	Eng 11-5
Door, frame Double-Press BKGD, Personality setting Double-Press Rate, Personality setting DSK definition	Eng 11-5
Door, Irame Double-Press BKGD, Personality setting Double-Press Rate, Personality setting DSK definition Mix/DSK	Eng 11-5 Eng 1-5 Eng 8-17
Door, frame Double-Press BKGD, Personality setting Double-Press Rate, Personality setting DSK definition Mix/DSK Mix/DSK and MultiDSK	Eng 11-5 Eng 1-5 Eng 8-17 Eng 8-21
Door, frame Double-Press BKGD, Personality setting Double-Press Rate, Personality setting DSK definition Mix/DSK Mix/DSK and MultiDSK MultiDSK	Eng 11-5 Eng 1-5 Eng 8-17 Eng 8-21 Eng 8-19

DSK 3 and 4 Eng 8-19 DSK Auto Cut, Personality setting Eng 11-6 DSK see Kever Module
Dusting Mode Eng 18-22
definitionEng 1-5
DVE Quick Navigation Button Eng 5-10
DVE Send and Remote Control option Eng 6-17
DVEs
Custom Device Eng 9-22
DVI cableEng 3-9
DVI port Eng 2-15
DVR, definitionEng 1-5

#### Ε

Edit Multi-Viewer Layout Eng 8-15
Editing Bus Maps Eng 7-13
Editing Color Schemes
buttons
mnemonics Eng 11-18
Editing Custom Controls Eng 10-25
Editor Interface option Eng 6-17
Editor Type Extra Option Eng 9-27
Editors
Auto Follow Eng 11-3, Eng 12-41
Pattern Codes Personality setting Eng 11-6
Trans Rate Personality setting Eng 11-7
Fffects Dissolve
Rate
default Eng 11-5
Flectronics frame
reference description Eng $1-4$
Flectronics Frame see Frame
Electrostatic Discharge Suscentibility Eng 3.2
Encrupt code Eng 6 16
Encrypt code Eng 0-10
Environment, operating Eng 20-3
Equipment overview Eng 2-2
Errors, Communications Eng 1/-14
ESDS
Ethernet Communication Eng 9-3
Ethernet port Eng 2-15
Expat License
ExtendedChar Extra Option Eng 9-31
External Computer file storage
downloadingEng 13-15
Frame, web interface Eng 13-15
uploadingEng 13-16
External Device
SmartConversionEng 16-1
Up/Down ConvertersEng 16-1
External Devices
Communications Eng 9-7
Com Settings Eng 9-8, Eng 9-11
Com Type Eng 9-8, Eng 9-11
RS-232 Eng 9-8
RS-422 Eng 9-8
RS-422 Null Eng 9-8

TCP/IP	Eng 9-11
UDP/IP	Eng 9-11
DeviceEn	g 9-7, Eng 9-11
VTR Preroll Eng 9-8, En	g 9-9, Eng 9-11
ethernet	Eng 9-10
Extra Options	Eng 9-9
Mon Wall Settings	Eng 9-9
aprial	Eng 0 7
	Elig 9-7
TypeEn	g 9-7, Eng 9-10
external link port	Eng 9-7
network port	Eng 9-10
peripheral portEn	g 9-7, Eng 9-10
remote portEn	g 9-7, Eng 9-10
Extra Options	Eng 9-26
External DVFs	
custom control functions	$E_{ng} = 10.2$
External Link Darts	Eng 10-2
External Link Ports	Eng 20-24
External Panel Link Ports	Eng 2-15
External Panel Modules	
setup	Eng 9-21
External Panel Row Auxiliary Control	Panels Eng 14-8
External Rows	Eng 17-6
Naming	Eng 17-8
External Still Store Input BNC Type	Eng 7 5
External Sun Store, input Dive Type	Eng 7-5
	Elig 0-17
Extra Option Settings	Eng 9-26
Audio Mixers	
Converter	Eng 9-26
Frequency	Eng 9-26
Max Channels	Eng 9-26
Mixers	Eng 9-26
OD Master	Eng 9-26
DCM Output	Eng 0 26
Yourier	Elig 9-20
Version	Eng 9-26
Audio Servers	
Bus Address	Eng 9-26
Cameras	
Focus Speed	Eng 9-28
Iris Control	Eng 9-28
Iris Mode	Eng 9-28
Iris Res	Eng 0 28
Inis Kes	Eng 9-20
	Elig 9-28
Joystick	Eng 9-28
Lens Type	Eng 9-28
Master Ped	Eng 9-28
Pan Invert	Eng 9-28
Pan/Tilt Damping	Eng 9-28
Pan/Tilt Speed	Eng 9-28
Panel ID	Eng 9-28
Poll	Eng 0.20
	Eilg 9-29
Kc111me	Eng 9-29
Select Delay	Eng 9-29
SerialSwitch	Eng 9-29
ShotOffset	Eng 9-29
Tilt Invert	Eng 9-29
Z Speed	Eng 9-29
Zoom Speed	Eng 9-29
	······································

-		

IX-8 • Index

Back-to-Back	Eng 9-26
Display Mode	Eng 9-26
PlayTime	Eng 9-26
Show on PV	Eng 9-27
Software Ver	Eng 9-27
Timeout	Eng 9-27
Editors	6
CustCtrl MLE	Eng 9-27
Editor Type	Eng 9-27
Pattern	Eng 9-27
Use Break	Eng 9-27
Phus	Eng > 21
Ouery Cmd	Eng 9-28
Routers	Ling <i>J</i> -20
Routers	Eng 0 20
L aval Basa	Eng 0 20
Num Lovela	Eng 0 20
Sra & Dast Pasa	Eng 0 20
SIC & Dest Dase	Eng 0.20
Apts	Elig 9-29
At Dlook	$E_{ma} = 0.20$
At DIACK	Elig 9-30
Data IXII	Eng 9-29
Kate	Eng 9-29
Slot I	Eng 9-30
Source Name	Eng 9-30
Start	Eng 9-29
video Servers	E 0.21
Clip List	Eng 9-31
Cmd Queuing	Eng 9-30
ExtendedChar	Eng 9-31
LoopMinLength	Eng 9-31
LoopRecueTime	Eng 9-31
MediaIDLength	Eng 9-30
Play with Alpha	Eng 9-31
Playback Mode	Eng 9-31
Port Cmds	Eng 9-31
Record Time	Eng 9-30
Send Tries	Eng 9-30
TargetMachine	Eng 9-30
TimeOut	Eng 9-30
VTR	
Decode NAKs	Eng 9-31
NPlayRetries	Eng 9-31
TargetMachine	Eng 9-31
Wait nFields	Eng 9-31
tory Defaults	Eng 12-27
Recalling	Eng 12-27
e to Black	C

**Character Generators** 

# F

Factory Defaults	Eng 12-27
Recalling	Eng 12-27
Fade to Black	
Default Rate	Eng 11-5
Display Mode	Eng 11-7
Display Mode, Personality setting	Eng 16-7
setup	Eng 8-8
Fader Calibration	Eng 17-3
Fail	

Frame Indicator Eng 5-3   Panel Indicators Eng 17-10   Fast Forward Custom Control Eng 17-10   Field 1 and Field 2 Eng 2-32   Field 1 and Frame information Eng 2-32   Field 3 Eng 2-32   Field 3 Eng 2-32   Field 3 Eng 2-32   Field and Frame information Eng 3-15   Downloading Eng 13-15   External Computer Eng 13-15   Overview Eng 13-16   Overview Eng 13-16   Oustom Control Attachments Eng 13-10   Custom Control Attachments Eng 13-11   individual Bus Maps Eng 13-12   individual fegister items Eng 13-13   individual Register items Eng 13-13   individual S&T Sequences Eng 13-11   individual S&T Sequences Eng 13-12   individual S&T Sequences Eng 13-12   individual S&T Sequences Eng 13-16   Multi-Viewer Assignment Eng 13-16   Multi-Viewer Assignment Eng 13-16   Shot box pages Eng 13-26   Shot box pages Eng 13-56	Frame Indicator Eng 5   Panel Indicator Eng 5   Fail Indicators Diagnosis Eng 17-   Fast Forward Custom Control Eng 10-   Field 1 and Field 2 Eng 2-   Field and Frame information Eng 2-   Fields Eng 2-   Field and Setup Storage Eng 13-1, Eng 13-   Downloading Eng 13-   External Computer Eng 13-   Recall all   all Eng 13-	5-3 10 19 32 32 32 32 32 32 32 32 32 32
Panel Indicator Eng 5-3   Fail Indicators Diagnosis Eng 17-10   Fast Forward Custom Control Eng 10-19   Field 1 and Field 2 Eng 2-32   Field and Frame information Eng 2-32   Field and Frame information Eng 2-32   Field and Setup Storage Eng 13-1, Eng 13-4   Downloading Eng 13-15   External Computer Eng 13-15   Overview Eng 13-16   Overview Eng 13-16   Ous maps Eng 13-16   Custom Control Attachments Eng 13-16   Custom Control Attachments Eng 13-11   individual Bus Maps Eng 13-12   individual Custom control Eng 13-13   individual Register items Eng 13-13   individual S&T Sequences Eng 13-13   individual S&T Sequences Eng 13-11   individual S&T Sequences Eng 13-12   individual S&T Sequences Eng 13-12   individual S&T Sequences Eng 13-16   Multi-Viewer Assignment Eng 13-16   Multi-Viewer Assignment Eng 13-16   Shot box pages Eng 13-55	Panel Indicator Eng 5   Fail Indicators Diagnosis Eng 17-   Fast Forward Custom Control Eng 10-   Field 1 and Field 2 Eng 2-   Field and Frame information Eng 2-   Field, Switch on Eng 2-   Fields Eng 13-   Downloading Eng 13-   Overview Eng 13-   Querview Eng 13-   All Eng 13-	5-3 10 19 32 33 12 32 32 32 32 32 32 32 32 32 32 32 32 32
Fail Indicators Diagnosis Eng 17-10   Fast Forward Custom Control Eng 10-19   Field 1 and Field 2 Eng 2-32   Field and Frame information Eng 2-32   Field and Frame information Eng 2-32   Field and Setup Storage Eng 13-1, Eng 13-4   Downloading Eng 13-15   Overview Eng 13-15   Overview Eng 13-16   all Eng 13-17   Custom Control Attachments Eng 13-10   Custom Control Attachments Eng 13-11   individual Bus Maps Eng 13-12   individual Custom control Eng 13-12   individual memory Eng 13-11   individual S&T Sequences Eng 13-12   individual S&T Sequences Eng 13-10   memories Eng 13-10   memories Eng 13-11   individual S&T Sequences Eng 13-11   individual Sot Box Pages Eng 13-10   memories Eng 13-10   memories Eng 13-10   Multi-Viewer Assignment Eng 13-10   Multi-Viewer Assignment Eng 13-10   Store all Eng	Fail Indicators Diagnosis Eng 17-   Fast Forward Custom Control Eng 10-   Field 1 and Field 2 Eng 2-   Field and Frame information Eng 2-   Field, Switch on Eng 8-   Fields Eng 2-   Field and Setup Storage Eng 13-1, Eng 13   Downloading Eng 13-   Overview Eng 13   Recall all	10 19 32 32 32 32 32 32 32 32 32 32 32 32 32
Fast Forward Custom Control Eng 10-19   Field 1 and Field 2 Eng 2-32   Field and Frame information Eng 2-32   Field, Switch on Eng 8-12   Field Switch on Eng 13-15   Downloading Eng 13-15   Overview Eng 13-15   Overview Eng 13-16   Downloading Eng 13-16   Overview Eng 13-16   Downloading Eng 13-16   Overview Eng 13-16   cameras Eng 13-16   custom Control Attachments Eng 13-10   custom controls Eng 13-12   individual Bus Maps Eng 13-12   individual Custom control Eng 13-12   individual Register items Eng 13-12   individual S&T Sequences Eng 13-13   individual S&T Sequences Eng 13-13   installation Eng 13-16   Multi-Viewer Assignment Eng 13-16   Multi-Viewer Assignment Eng 13-16   Multi-Viewer Layout Eng 13-16   syneeze & tease sequences Eng 13-16   register types Eng 13-5   custom co	Fast Forward Custom Control Eng 10-   Field 1 and Field 2 Eng 2-   Field and Frame information Eng 2-   Field, Switch on Eng 8-   Fields Eng 2-   Field and Setup Storage Eng 13-1, Eng 13-   Downloading Eng 13-   External Computer Eng 13-   Overview Eng 13-   Recall all	19 32 33 12 32 -4 15 15 -2 10 10 10 10 10 10 11 11
Field 1 and Field 2 Eng 2-32   Field and Frame information Eng 2-33   Field, Switch on Eng 8-12   Fields Eng 2-33   Field and Setup Storage Eng 13-1, Eng 13-4   Downloading Eng 13-15   Overview Eng 13-15   Overview Eng 13-16   bus maps Eng 13-16   cameras Eng 13-16   custom Control Attachments Eng 13-16   custom controls Eng 13-16   individual Bus Maps Eng 13-17   individual custom control Eng 13-12   individual memory Eng 13-12   individual S&T Sequences Eng 13-12   individual S&T Sequences Eng 13-16   memories Eng 13-17   individual Sot Box Pages Eng 13-17   individual S&T Sequences Eng 13-16   Multi-Viewer Assignment Eng 13-17   memories Eng 13-16   Multi-Viewer Layout Eng 13-16   register types Eng 13-17   Multi-Viewer Layout Eng 13-56   shot box pages Eng 13-57   Custom Control	Field 1 and Field 2 Eng 2-   Field and Frame information Eng 2-   Field, Switch on Eng 8-   Fields Eng 2-   Fields and Setup Storage Eng 13-1, Eng 13-   Downloading Eng 13-   External Computer Eng 13-   Overview Eng 13-   Recall all	32 33 12 32 15 15 5-2 10 10 10 10 10 10 11 11
Field and Frame information Eng 2-33   Field, Switch on Eng 2-32   Fields Eng 13-1, Eng 13-4   Downloading Eng 13-15   External Computer Eng 13-16   Overview Eng 13-17   Recall all   all Eng 13-16   custom Control Attachments Eng 13-10   custom controls Eng 13-10   custom controls Eng 13-10   individual Bus Maps Eng 13-10   individual custom control Eng 13-11   individual custom control Eng 13-12   individual Multi-Viewer layouts Eng 13-13   individual S&T Sequences Eng 13-12   individual Shot Box Pages Eng 13-10   memories Eng 13-10   Multi-Viewer Assignment Eng 13-10   Multi-Viewer Layout Eng 13-10   register types Eng 13-10   shot box pages Eng 13-10   register types Eng 13-10   register types Eng 13-10   shot box pages Eng 13-10   shot box pages Eng 13-50   custom control Attach	Field and Frame information	33 12 32 -4 15 15 -2 10 10 10 10 10 10 10 10
Field, Switch on Eng 8-12   Fields Eng 13-1   File and Setup Storage Eng 13-1   Downloading Eng 13-15   External Computer Eng 13-12   Recall all   all Eng 13-10   cameras Eng 13-10   custom Control Attachments Eng 13-10   custom controls Eng 13-10   custom control Attachments Eng 13-10   individual Bus Maps Eng 13-11   individual custom control Eng 13-12   individual memory Eng 13-13   individual Multi-Viewer layouts Eng 13-13   individual S&T Sequences Eng 13-12   individual S&T Sequences Eng 13-10   memories Eng 13-11   individual Sbot Box Pages Eng 13-12   individual Sbot Box Pages Eng 13-16   memories Eng 13-16   memories Eng 13-16   register types Eng 13-16	Field, Switch onEng 8- FieldsEng 2- File and Setup StorageEng 13-1, Eng 13 DownloadingEng 13- External ComputerEng 13- OverviewEng 13- Recall allEng 13-	12 32 -4 15 15 -2 10 10 10 10 10 10 10 11 11
Fields Eng 2-32   File and Setup Storage Eng 13-1, Eng 13-4   Downloading Eng 13-15   External Computer Eng 13-15   Overview Eng 13-16   Querview Eng 13-17   Recall all   all Eng 13-10   Custom Control Attachments Eng 13-10   custom controls Eng 13-13   individual Bus Maps Eng 13-13   individual Rus Maps Eng 13-13   individual Rus Maps Eng 13-12   individual Rus Maps Eng 13-13   individual Rus Maps Eng 13-14   individual Rus Maps Eng 13-12   individual Rus Maps Eng 13-12   individual S&T Sequences Eng 13-12   individual S&T Sequences Eng 13-16   Multi-Viewer Assignment Eng 13-16   memories Eng 13-16   register types Eng 13-16   shot box pages Eng 13-16   vTR clips Eng 13-5   custom control Attachments Eng 13-5   custom control Attachments Eng 13-5   custom control Attachments	FieldsEng 2- File and Setup StorageEng 13-1, Eng 13- DownloadingEng 13- External ComputerEng 13- OverviewEng 13- Recall allEng 13-	32 -4 15 15 -2 10 10 10 10 10 10 13 12
File and Setup Storage Eng 13-1, Eng 13-4   Downloading Eng 13-15   External Computer Eng 13-15   Overview Eng 13-16   Recall all   all Eng 13-16   Custom Control Attachments Eng 13-10   Custom Control Attachments Eng 13-10   custom controls Eng 13-11   individual Bus Maps Eng 13-12   individual custom control Eng 13-12   individual Rustom control Eng 13-13   individual Rustom control Eng 13-14   individual S&T Sequences Eng 13-13   individual S&T Sequences Eng 13-13   installation Eng 13-16   Multi-Viewer Assignment Eng 13-16   Multi-Viewer Layout Eng 13-16   squeeze & tease sequences Eng 13-16   squeeze & tease sequences Eng 13-16   squeeze & tease sequences Eng 13-16   VTR clips Eng 13-56   bus maps Eng 13-57   custom Control Attachments Eng 13-56   custom Control Attachments Eng 13-56   custom controls Eng 13-	File and Setup Storage Eng 13-1, Eng 13 Downloading Eng 13- External Computer Eng 13- Overview Eng 13 Recall all	5-4 15 15 5-2 10 10 10 10 10 10 13 12
DownloadingEng 13-15External ComputerEng 13-15OverviewEng 13-16SteeallallEng 13-10bus mapsEng 13-10camerasEng 13-10Custom Control AttachmentsEng 13-10custom controlsEng 13-11individual custom controlEng 13-12individual custom controlEng 13-13individual custom controlEng 13-14individual register itemsEng 13-11individual S&T SequencesEng 13-12individual S&T SequencesEng 13-13installationEng 13-11memoriesEng 13-11Multi-Viewer AssignmentEng 13-11personalityEng 13-10register typesEng 13-10shot box pagesEng 13-10shot box pagesEng 13-10StoreallallEng 13-5custom controlsEng 13-5individual Bus MapsEng 13-5custom controlEng 13-5<	DownloadingEng 13- External ComputerEng 13- OverviewEng 13 Recall allEng 13-	15 15 -2 10 10 10 10 10 13 12
External ComputerEng 13-15OverviewEng 13-2RecallallEng 13-10bus mapsEng 13-10camerasEng 13-10Custom Control AttachmentsEng 13-10custom controlsEng 13-10individual Bus MapsEng 13-13individual custom controlEng 13-14individual custom controlEng 13-11individual register itemsEng 13-12individual Register itemsEng 13-13individual S&T SequencesEng 13-12individual Shot Box PagesEng 13-13installationEng 13-11Multi-Viewer AssignmentEng 13-10Multi-Viewer LayoutEng 13-11personalityEng 13-16shot box pagesEng 13-16VTR clipsEng 13-16StoreallallEng 13-5custom controlsEng 13-5custom control AttachmentsEng 13-5custom controlsEng 13-5custom controlsEng 13-5individual Bus MapsEng 13-5custom controlsEng 13-5individual Register items Eng 13-5Eng 13-5individual Multi-Viewer layoutsEng 13-7individual Shot Box PagesEng 13-7individual Sus MapsEng 13-7individual Sus MapsEng 13-7individual Sus MapsEng 13-7individual Sus MapsEng 13-7individual Shot Box PagesEng 13-7individual Shot Box PagesEng 13-7individual Shot Box PagesEng	External ComputerEng 13- OverviewEng 13 Recall allEng 13-	15 -2 10 10 10 10 10 13 12
OverviewEng 13-2RecallallEng 13-10bus mapsEng 13-10Custom Control AttachmentsEng 13-10custom controlsEng 13-13individual Bus MapsEng 13-13individual custom controlEng 13-12individual custom controlEng 13-13individual memoryEng 13-11individual register itemsEng 13-12individual S&T SequencesEng 13-13installationEng 13-16memoriesEng 13-17individual Shot Box PagesEng 13-16Multi-Viewer AssignmentEng 13-17Multi-Viewer LayoutEng 13-16register typesEng 13-16shot box pagesEng 13-16vTR clipsEng 13-16VTR clipsEng 13-16StoreallallEng 13-5custom controlsEng 13-5custom controlsEng 13-5custom controlsEng 13-5custom controlsEng 13-5custom controlsEng 13-5custom controlsEng 13-5custom controlEng 13-5custom controlEng 13-5custom controlsEng 13-5custom controlEng 13-5individual Bus MapsEng 13-5custom controlsEng 13-5individual Custom controlEng 13-5individual SMapsEng 13-5individual SMapsEng 13-5individual Stot Box PagesEng 13-7individual Stot Box PagesEng 13-7individual S	OverviewEng 13 Recall allEng 13	5-2 10 10 10 10 10 13 12
RecallEng 13-10allEng 13-10camerasEng 13-10Custom Control AttachmentsEng 13-10custom controlsEng 13-10individual Bus MapsEng 13-11individual custom controlEng 13-12individual register itemsEng 13-11individual S&T SequencesEng 13-12individual Sohot Box PagesEng 13-13installationEng 13-13installationEng 13-10memoriesEng 13-11Multi-Viewer AssignmentEng 13-10metricsEng 13-10register typesEng 13-10register typesEng 13-10shot box pagesEng 13-10squeeze & tease sequencesEng 13-10VTR clipsEng 13-5custom controlsEng 13-5individual Bus MapsEng 13-5individual custom controlEng 13-6individual custom controlEng 13-7individual S&T SequencesEng 13-7individual S&T SequencesEng 13-7individual S&T SequencesEng 13-7individual Sont Box PagesEng 13-7individual Sont Box PagesEng 13-7individual Sont Box PagesEng 13-7individual Sont Box PagesEng 13-7individual Shot Box PagesEng 13-5	Recall	10 10 10 10 10 13 12
all Eng 13-10   bus maps Eng 13-10   cameras Eng 13-10   Custom Control Attachments Eng 13-10   individual Bus Maps Eng 13-11   individual custom control Eng 13-12   individual custom control Eng 13-13   individual register items Eng 13-11   individual S&T Sequences Eng 13-12   individual S&T Sequences Eng 13-13   installation Eng 13-12   individual S&T Sequences Eng 13-13   installation Eng 13-16   Multi-Viewer Assignment Eng 13-16   memories Eng 13-16   Multi-Viewer Layout Eng 13-16   register types Eng 13-16   shot box pages Eng 13-16   VTR clips Eng 13-5   sub maps Eng 13-5   custom Control Attachments Eng 13-5   custom controls Eng 13-5   custom controls Eng 13-5   custom control Attachments Eng 13-5   custom control series Eng 13-6   individual custom control Eng 13-7   indivi	all Eng 13-	10 10 10 10 10 13 12
bus maps Eng 13-10 cameras Eng 13-10 Custom Control Attachments Eng 13-10 custom controls Eng 13-10 individual Bus Maps Eng 13-13 individual custom control Eng 13-12 individual Multi-Viewer layouts Eng 13-14 individual Multi-Viewer layouts Eng 13-14 individual S&T Sequences Eng 13-12 individual Shot Box Pages Eng 13-13 installation Eng 13-10 Multi-Viewer Assignment Eng 13-11 Multi-Viewer Layout Eng 13-10 register types Eng 13-10 shot box pages Eng 13-10 shot box pages Eng 13-10 VTR clips Eng 13-10 VTR clips Eng 13-10 Store all Eng 13-5 custom Control Attachments Eng 13-5 individual Bus Maps Eng 13-5 custom Control Attachments Eng 13-7 individual Bus Maps Eng 13-8 individual Multi-Viewer Layouts Eng 13-9 shot box pages Eng 13-10 VTR clips Eng 13-5 custom Control Attachments Eng 13-5 individual Bus Maps Eng 13-5 custom Control Attachments Eng 13-7 individual Multi-Viewer Layouts Eng 13-8 individual S&T Sequences Eng 13-9 sindividual S&T Sequences Eng 13-16 individual S&T Sequences Eng 13-17 individual S&T Sequences Eng 13-5 custom Control Attachments Eng 13-5 custom Control Attachments Eng 13-5 individual S&T Sequences Eng 13-7 individual S&T Sequences Eng 13-7 individual S&T Sequences Eng 13-7 individual S&T Sequences Eng 13-5 individual S&T Seq		10 10 10 10 13 12
cameras Eng 13-10 Custom Control AttachmentsEng 13-10 individual Bus MapsEng 13-13 individual custom controlEng 13-12 individual memoryEng 13-11 individual Multi-Viewer layoutsEng 13-14 individual S&T SequencesEng 13-13 installationEng 13-11 individual Shot Box PagesEng 13-12 individual Shot Box PagesEng 13-13 installationEng 13-10 Multi-Viewer AssignmentEng 13-11 personalityEng 13-10 vTR clipsEng 13-10 vTR clipsEng 13-5 custom Control AttachmentsEng 13-5 custom Control AttachmentsEng 13-5 individual Bus MapsEng 13-5 individual Bus MapsEng 13-5 individual Multi-Viewer layoutsEng 13-7 individual Multi-Viewer layoutsEng 13-5 fustom control AttachmentsEng 13-5 individual Bus MapsEng 13-5 individual Multi-Viewer layoutsEng 13-5 individual S&T SequencesEng 13-7 individual Multi-Viewer layoutsEng 13-5 individual S&T SequencesEng 13-5 fustom control AttachmentsEng 13-5 individual S&T SequencesEng 13-5 fustom Control AttachmentsEng 13-5 individual S&T SequencesEng 13-5 individual Multi-Viewer layoutsEng 13-5 individual S&T SequencesEng 13-5 individual S&T Sequence	bus mapsEng 13-	10 10 10 13 12
Custom Control Attachments	cameras Eng 13-	10 10 13 12
custom controls	Custom Control Attachments Eng 13-	10 13 12 11
individual Bus Maps	custom controls Eng 13-	13 12 11
individual custom control	individual Bus Maps Eng 13-	12 11
individual memory	individual custom control	
individual Multi-Viewer layouts Eng 13-14 individual register items	individual memory Eng 13-	11
individual register items	individual Multi-Viewer layouts Eng 13-	14
individual S&T Sequences	individual register items	11
individual Shot Box Pages	individual S&T Sequences	12
Installation	individual Shot Box Pages	13
memoriesEng 13-10Multi-Viewer AssignmentEng 13-11Multi-Viewer LayoutEng 13-10register typesEng 13-10shot box pagesEng 13-10squeeze & tease sequencesEng 13-10VTR clipsEng 13-10StoreallallEng 13-5camerasEng 13-5custom Control AttachmentsEng 13-5custom controlsEng 13-7individual Bus MapsEng 13-8individual Multi-Viewer layoutsEng 13-8individual S&T SequencesEng 13-7individual Shot Box PagesEng 13-5Multi-Viewer AssignmentEng 13-5Multi-Viewer LayoutEng 13-5Multi-Viewer LayoutEng 13-5memoriesEng 13-5Multi-Viewer AssignmentEng 13-5memoriesEng 13-5memoriesEng 13-5memoriesEng 13-5Multi-Viewer AssignmentEng 13-5personalityEng 13-5register typesEng 13-5sot box pagesEng 13-5sot box pagesEng 13-5sot box pagesEng 13-5squeeze & tease sequencesEng 13-5squeeze & tease sequences <td>installationEng 13-</td> <td>10</td>	installationEng 13-	10
Multi-Viewer Assignment	memories Eng 13-	10
Multi-Viewer Layout	Multi-Viewer Assignment	11
personality	Multi-Viewer Layout Eng 13-	11
register typesEng 13-9shot box pagesEng 13-10squeeze & tease sequencesEng 13-10VTR clipsEng 13-10StoreallEng 13-5bus mapsEng 13-5camerasEng 13-5Custom Control AttachmentsEng 13-5custom controlsEng 13-5individual Bus MapsEng 13-6individual custom controlEng 13-7individual memoryEng 13-6individual S&T SequencesEng 13-7individual Shot Box PagesEng 13-5Multi-Viewer AssignmentEng 13-5Multi-Viewer LayoutEng 13-5personalityEng 13-5register typesEng 13-5shot box pagesEng 13-5squeeze & tease sequencesEng 13-5squeeze & tease	personalityEng 13-	10
shot box pages	register types	-9 10
squeeze & tease sequences	snot box pagesEng 13-	10
VTK Chps Eng 13-10   Store all Eng 13-5   bus maps Eng 13-5   cameras Eng 13-5   Custom Control Attachments Eng 13-5   custom controls Eng 13-5   individual Bus Maps Eng 13-7   individual custom control Eng 13-8   individual memory Eng 13-7   individual Multi-Viewer layouts Eng 13-7   individual S&T Sequences Eng 13-7   individual Shot Box Pages Eng 13-5   memories Eng 13-5   Multi-Viewer Assignment Eng 13-5   personality Eng 13-5   register types Eng 13-5   shot box pages Eng 13-5   squeeze & tease sequences Eng 13-5	VTD aline Eng 12	10
all Eng 13-5 bus maps Eng 13-5 cameras Eng 13-5 Custom Control Attachments Eng 13-5 custom controls Eng 13-5 individual Bus Maps Eng 13-7 individual custom control Eng 13-7 individual memory Eng 13-7 individual Multi-Viewer layouts Eng 13-8 individual Multi-Viewer layouts Eng 13-6 individual S&T Sequences Eng 13-7 individual S&T Sequences Eng 13-7 individual Shot Box Pages Eng 13-8 installation Eng 13-5 Multi-Viewer Assignment Eng 13-5 personality Eng 13-5 register types Eng 13-4 shot box pages Eng 13-5 squeeze & tease sequences Eng 13-5	VIR clipsElig 15-	10
an	all Eng 12	5
cameras	allElig 12	-5
Custom Control Attachments Eng 13-5 Custom controls Eng 13-5 individual Bus Maps Eng 13-8 individual custom control Eng 13-7 individual memory Eng 13-6 individual Multi-Viewer layouts Eng 13-8 individual Multi-Viewer layouts Eng 13-6 individual S&T Sequences Eng 13-7 individual Shot Box Pages Eng 13-8 installation Eng 13-5 Multi-Viewer Assignment Eng 13-5 Multi-Viewer Layout Eng 13-5 register types Eng 13-5 squeeze & tease sequences Eng 13-5	comoros Eng 12	-5
custom controls	Custom Control Attachments Eng 13	-5
individual Bus Maps	custom controls Eng 12	-5
individual bus waps	individual Bus Mans Eng 12	-9
individual eustoni contor	individual custom control Eng 13	-0
individual Multi-Viewer layouts Eng 13-8 individual register items Eng 13-5, Eng 13-6 individual S&T Sequences Eng 13-7 individual Shot Box Pages Eng 13-8 installation Eng 13-5 memories Eng 13-5 Multi-Viewer Assignment Eng 13-5 personality Eng 13-5 register types Eng 13-4 shot box pages Eng 13-5 squeeze & tease sequences Eng 13-5	individual memory Eng 13	-6
individual register items Eng 13-5, Eng 13-6 individual S&T Sequences	individual Multi-Viewer layouts Eng 13	-8
individual S&T Sequences	individual register items Eng 13-5 Eng 13	-6
individual Shot Box Pages	individual S&T Sequences Eng 13	-7
installation	individual Shot Box Pages Eng 13	-8
memories	installation Eng 13	-5
Multi-Viewer Assignment	memories Eng 13	-5
Multi-Viewer Layout	Multi-Viewer Assignment Eng 13	-5
personality	Multi-Viewer Layout Eng 13	-5
register typesEng 13-4 shot box pagesEng 13-5 squeeze & tease sequencesEng 13-5	personality	-5
shot box pagesEng 13-5 squeeze & tease sequencesEng 13-5	register types	3-4
squeeze & tease sequences	shot box pages	-5
	squeeze & tease sequences	-5
VTR clips Eng 13-5	VTR clipsEng 12	-
Unloading Eng 13-16	Uploading	-5

Films, button insert	Eng 3-17
Fire Salvo Custom Control	Eng 10-19
Flash full	Eng 6-7
FlexDevice	Eng 9-2
FlexDevice Drivers	Eng 9-4
Deleting	Eng 9-6
Installing	Eng 9-4
Stopping	Eng 9-5
Flexi Mode. Key 4	Eng 12-7
FlexiClean Setun	Eng 8-7
Flush mounted control panel installation	Eng 3-8
Focus Speed Extra Ontion	Eng 9-28
Follow	Eng 12 $40$
Duo	Eng 12-40
Bus	Eng 12-43
Keyer	Eng 12-44
Memory Recall	Eng 12-45
MLE	Eng 12-42
Transition Module	Eng 12-44
Font Color, Preview Overlay Setup	Eng 12-30
Format, Input BNCs	Eng 4-14
Format, Output BNCs	Eng 4-14
Forward Button	Eng 5-5
Frame	
boards menu	Eng 6-15
connecting to control panel	Eng 3-11
CPU, overview	Eng 2-12
front layout	Eng 2-8
GPI I/O port overview	Eng 2-16
installation	Eng 3-5
installing boards	Eng 1-18
I AN port overview	Eng 2 16
concreting anvironment	Eng 2 5
	Ellg 3-3
peripheral ports, overview	Eng 2-10
ports	Eng 2-16
power connection	Eng 3-19
power fail indicators	Eng 3-21
processor	Eng 2-35
rear layout	Eng 2-7
reference description	Eng 1-4
support brackets	Eng 3-5
time code input, overview	Eng 2-16
USP ports, overview	Eng 2-16
web interface	-
downloading	Eng 13-15
uploading	Eng 13-16
Frame Advance Custom Control Eng 10-	17. Eng 10-19
Frame Board rear	Eng 4-22
Frame Boards	Diig + 22
front	Eng 4 21
logations	Eng 4 - 21
	Eing 4-10
Frame Connector Types	Eng 20-15
	Eng 2-12
Frame Diagnostics	Eng 17-29
DIP Switch Test	Eng 17-31
GPI Test	Eng 17-30
Graphics Buffer Test	Eng 17-31
LEDs Test	Eng 17-30

Tx/Rx Test	Eng 17-29
Frame Dimensions	Eng 20-10
Frame Door, opening/closing	Eng 3-3
Frame Fail IndicatorEn	g 5-3, Eng 17-10
cooling fans	Eng 18-8
power supply	Eng 18-6
Frame Ports	-
AC power	Eng 20-22
GPI I/O	Eng 20-21
LAN	Eng 20-22
panel	Eng 20-20
peripheral	Eng 20-20
Frame Power Supplies	Eng 18-11
functional components	Eng 18-11
replacing	Eng 18-12
Frame Rates, using	Eng 2-33
Frame Reverse Custom Control Eng	10-17, Eng 10-19
Frame Serial Ports	Eng 9-2
Frame to Control Panel cabling	Eng 3-11
Frame, overview	Eng 2-7
Frame/Control Panel cabling	Eng 3-11
Frames	Eng 2-32
Frequency Extra Option	Eng 9-26
Frequency, scan	Eng 2-33
Front Frame Boards	Eng 4-21
Full MLE	C
reference description	Eng 1-4
Full reset	Eng 4-25
Function buttons	Eng 5-3
Function, System Information Page .	Eng 6-12
Functional check	Eng 4-17

#### G

General SpecificationsEr	ng 20-3
GfxBuffDDR Test, see Frame Diagnostics	
Global Memory ModuleEr	ng 2-10
Global Memory Number Entry, Personality Er	ng 11-7
Global-Store	
Auto key setupE	Eng 7-8
Enable Channel 4Er	ng 11-7
Memory Recall Mode, PersonalityEng	g 11-10
Global-Store 4 Mode, PersonalityEr	ng 11-7
GNU General Public LicenseEr	ng 22-2
Go To Clip Custom ControlEng	g 10-19
Go To Cut Custom ControlsEng	g 10-17
Go To End Custom ControlEng	g 10-17
Go To Menu Custom ControlEng	g 10-20
Go To Start Custom ControlEng	g 10-17
GP I/O	
portEr	ng 2-19
GPI I/OEr	ng 2-16
Aux Panel setup	
CCU joystick controlEng	g 14-13
Aux PanelsEng	g 14-11
Auxiliary Control Panel setup	
programming GPIEng	g 14-11
Remote Aux Panel setup	

programming GPI	Eng 14-12
GPI I/Os	
Connections	Eng 12-10
Information Menu	Eng 12-9
Input BNC	Eng 7-25
Input GPI I/Os	Eng 12-10
Memory Recall event	Eng 12-11
Run Custom Control	Eng 12-12
Tallies	Eng 12-13
Transition event	Eng 12-11
Trigger Signal Polarity	Eng 12-13
Output GPI I/Os	Eng 12-14
Naming	Eng 12-16
Trigger Signal	Eng 12-15
Ports	Eng 20-21
setup	Eng 12-9
Worksheet	
Input	Eng 21-13
Output	Eng 21-14
Grab a Timecode	
Video Server	Eng 12-20
Grey Input BNC	Eng 7-5
Grouping Audio Channels	Eng 12-24

#### н

Half MLE	
reference description	Eng 1-4
Half MLE, see Mix/DSK	
Hard Drive	
installing	Eng 18-15
Ribbon Cable Connector	Eng 18-15
Hard Restart, switcher	.Eng 6-3, Eng 6-11
HD, definition	Eng 1-5
Help	
online manuals	Eng 5-17
pop-up	Eng 5-17
Quick Navigation Button	Eng 5-9
HOLD button	Eng 5-2
Hold CC Custom Control	Eng 10-20
Hold Quick Navigation Button	Eng 5-9
Hold, Store Mode	Eng 11-12
HOME button	Eng 5-2
Home Quick Navigation Button	Eng 5-9
Horizontal Scan Lines	Eng 2-31

#### l Ic

ICONS	
positioner	Eng 5-8
Status	Eng 17-12
ID, definition	Eng 1-5
Imlib2 License	Eng 22-11
Include Aux	Eng 16-2
In-Console, control panel installation	Eng 3-7
Indicators	
frame power fail	Eng 3-21
panel power fail	Eng 3-21

Power Fail	Eng 3-21
Information, Web Interface	Eng 6-12
Inpoint, Video Server Clip	Eng 12-19
Input BNCs	U
Alpha	Eng 7-6
Auto Key	U
setup	Eng 7-8
Bus Map	Eng 7-13
default mapping	Eng 3-13
GPI Outputs	Eng 7-25
grav	Eng 7-5
Non-Sync Detect	Eng 7-9
Output BNC	Eng 8-3
Tallies	Eng 7-23
Type	Eng 7 23
Alnha	Eng 7-5
Char Gen	Eng 7-5
External Still Store	Eng 7-5
off	Eng 7-5
Robotic Cam	Eng 7-5
Robbite Call	Eng 7-5
Video	Eng 7-6
VID	Eng 7-5
Video Formata	Eng 7-5
Video Formats	Eng 12 10
Sotting up Momory Decell events	Elig 12-10
Setting up Memory Recall events	Eng 12-11
Setting up run custom control events .	Eng 12-12
Setting up transition events	Eng 12-11
Setting up trigger signal priority	Eng 12-13
I allies	Eng 12-13
Input Verification	Eng 4-16
Inputs, configuring (video)	Eng /-4
Inputs, connection	Eng 3-13
Inputs, naming (video)	Eng 7-2
Inserting Custom Control Events	<b>T</b> 10.04
control panel	Eng 10-26
special	Eng 10-27
Inserts, button	Eng 3-17
Install Quick Navigation Button	Eng 5-9
Install serial numbers	Eng 6-16
Installation	
control panel	Eng 3-7
control panel power	Eng 3-20
control panel to frame	Eng 3-11
control panel touchscreen	Eng 3-9
control panel tub Eng 3	8-7, Eng 3-8
Defaulting	Eng 12-28
frame	Eng 3-5
frame power	Eng 3-19
lock/unlock	Eng 12-46
monitor	Eng 3-16
reference	Eng 4-12
Registers	Eng 13-2
serial numbers	Eng 3-2
Installed	
frame boards, option boards	Eng 6-15
panel boards	Eng 6-14

Installed Options	Eng 6-14
Frame Boards	Eng 6-15
Panel Boards	Eng 6-14
Software Options	Eng 6-16
Installing	-
Button Insert Films	Eng 3-17
FlexDevice Drivers	Eng 9-4
frame boards	Eng 4-18
frame door	Eng 3-4
Hard Drive replacement	Eng 18-15
Remote Aux Panels	Eng 14-5
serial numbers	Eng 6-14
software options	Eng 6-16
Installing New Modules	Eng 17-5
Quick Module Configure	Eng 17-5
Single Module Configure	Eng 17-6
Interface, menu	Eng 5-2
Interlaced	. Eng 2-31, Eng 2-32
Internal Panel Row Auxiliary Co	ntrol Panels Eng 14-8
Internal reference	Eng 4-15
Internal Rows	Eng 17-6
Internet Security	Eng 4-9
IP Issues	Eng 4-9
IP, default	Eng 20-11
Iris Control Extra Option	Eng 9-28
Iris Mode Extra Option	Eng 9-28
Iris Res Extra Option	Eng 9-28
Iris Speed Extra Option	Eng 9-28
Isolate MultiDSK	Eng 11-8

#### J

Joystick Extra	Option	 Eng	9-28

# Κ

Key 4 Mode	
External	Eng 12-7
Flexi	Eng 12-7
Internal 1	Eng 12-7
Internal 2	Eng 12-7
Internal 3	Eng 12-7
Key Cut then Fade	Eng 11-8
Key Frame Adv Custom Control	Eng 10-17
Key Frame Rev Custom Control	Eng 10-17
Key, Auto	Ēng 7-4
Keyboard installation	Eng 3-12
Keyboard port	Eng 2-15
Keyer Module	Eng 2-10
Keyer Rate	
default	Eng 11-5
Keyers	
Auto Follow	Eng 12-44
Key Cut then Fade	Eng 11-8
Swap Cut and Auto	Eng 11-12
Keypad Clip IDs Entry	Eng 11-8
Keys	-
check	Eng 7-26

Clip and Gain	Eng 7-27
Key Memory	Eng 7-27
Keys Off Air (Automation) Cu	stom Control Eng 10-18
Knobs	
selection	Eng 5-3

#### L

-	
Labelling boards	Eng 2-37
LAN Ports	Eng 20-22
overview	Eng 2-16
Large Audio Mixer option	Eng 6-17
Layout	C
front frame	Eng 2-8
rear frame	Eng 2-7
Layouts	-
Multi-Viewer	Eng 8-14
assign	Eng 8-14
edit	Eng 8-15
name	Eng 8-15
Lens Type Extra Option	Eng 9-28
Lesser GNU Public License	Eng 22-4
Level Base Extra Option	Eng 9-29
Levels	-
default levels	Eng 12-23
LGPL, see Lesser GNU Public License	-
Limitations	
custom device protocol	Eng 23-2
Link and Node	Eng 20-12
external links	Eng 20-12
internal links	Eng 20-12
Load (CG) Custom Control	Eng 10-17
Load Layout Custom Control	Eng 10-18
Loading Color Schemes	Eng 11-21
Locations, frame boards	Eng 4-18
Lock/Unlock Installation	Eng 12-46
Lock/Unlock Personality	Eng 11-22
Log OverDrive Messages, Personality	Eng 11-8
Logs	Eng 17-39
Look Ahead Preview	
MLE	Eng 8-3
Loop CC Custom Controls	Eng 10-20
Looping Custom Controls	Eng 10-10
LoopMinLength Extra Option	Eng 9-31
LoopRecueTime Extra Option	Eng 9-31
Lower Display Region	Eng 5-3
LTC Timecode Specifications	Eng 20-18

#### Μ

Macros, see Custom Controls	
Main Area	Eng 5-6
Main Area, menu	Eng 5-6
Maintenance	Eng 18-1
control panel module	Eng 18-18
control panel power supplies	Eng 18-9
failure	Eng 18-2
dusting	Eng 18-22

frame fans	
failureEng 18-	8
frame power suppliesEng 18-1	1
failureEng 18-	6
Hard Drive replacementEng 18-1	5
Managing Custom ControlsEng 10-2	8
Managing SetupsEng 13-1	5
downloadingEng 13-1	5
uploadingEng 13-1	6
Managing Web Interface Account	.2
Manuals	
online help Eng 5-1	7
Manning	'
Control Panel Eng 17-	.5
Ouick Module Configure Eng 17	5
Single Module Configure Eng 17	6
crosspoint buttons	2
Moster Denal	5
reference description Engl	1
Master Dad Extra Ontion	4
Master Ped Extra OptionEng 9-2	8
Matrix, crosspointEng 2-2	U
Matte Limit	~
Personality settingEng 11-	.9
Max Channels Extra OptionEng 9-2	6
MD DVE optionEng 6-1	7
MD, definitionEng 1-	-5
MediaIDLength Extra OptionEng 9-3	0
Memories	
DefaultingEng 12-2	8
Recall	
auto followEng 12-4	-5
Recalling individualEng 13-1	1
RegistersEng 13-	2
Store Mode Personality SettingEng 11-1	2
Storing individualEng 13-	6
Memory Bank Cycle, Personality settingEng 11-	.9
Memory, KeyEng 7-2	7
Menu	
BNC typeEng 8-	-2
Menu Locking	
InstallationEng 12-4	-6
PersonalityEng 11-2	2
Menu System	4
Back buttonEng 5-	-5
Copy Down button Eng 5-	.5
Copy Up button Eng 5-	.5
Forward button Eng 5	.5
main area Eng 5-	.6
menu title Eng 5-	5
navigation area Eng 5	6
navigation areaEng 5-	0
positioner iconsEng 5-	0 6
Ouiok Novigation byttong	0
Quick Inavigation buttonsEng 5-	.9 0
screen captureEng 5-1	ð F
selection areaEng 5-	د. ح
Swap buttonEng 5-	د. ح
Ivienu LitleEng 5-	5

#### Menus

Annearance	Eng 5-11
Aux Bus Output	Eng 8 5
Aux Bus Output	Elig 6-3
Aux Bus Outputs	Eng 8-5
control buttons	Eng 5-2
Function buttons	Eng 5-3
Hold button	Eng 5-2
Home button	Eng 5-2
knobs	Eng 5-3
lower display region	Eng 5-3
More button	Eng 5-3
on the touchscreen	Eng 5-2
quick navigation buttons Eng 5	-3 Eng 5-9
Quick Navigation More Button	Eng 5-3
Sking	Eng 5 11
Skills	Elig 5-11
System Power button	Ellg 5-5
Up One button	Eng 5-2
upper display region	Eng 5-3
Midplane	Eng 2-13
Mix/DSK	Eng 8-17
operation	Eng 8-18
setup Eng 8-1	7, Eng 8-19
with MultiDSK	Eng 8-21
Mix/DSK option	Eng 6-17
Mixers Extra Option	Eng 9-26
MLE	e
Auto Follow	.Eng 12-43
definition	
fade to black	Eng 8-8
processor	Eng 2-35
resetting	Eng 4.26
tolly	Eng 8 0
MLE Assignment	Eng 4 10
MLE Assignment	Eng 4-10
MLE MD option	Eng 6-1/
MLE Memory Module	Eng 2-10
MLE Rate	
default	Eng 11-5
MLE Re-entry button	Eng 7-14
MLE reset	
all	Eng 4-26
individual	Eng 4-27
individual (1-4)	Eng 4-27
individual (5-8)	Eng 4-27
MLE SD option	Eng 6-17
MLE-Store	8
Auto key setup	Eng 7-8
MLE-Store option	Eng 6-17
Mnemonic Displays Appearance	Eng 5 12
Mnomonios	Eng 5 12
Mnemonies default names	$\dots$ Eng J-12
Minemonics, default names	Elig 4-10
Modify bank name, custom control	Eng 10-6
Modify Dynamic Text Custom Control	.Eng 10-18
Modifying Custom Control Events	.Eng 10-26
Module Configuration	Eng 17-6
Module Control Link Backbone	. Eng 20-12
external links	. Eng 20-12
internal links	.Eng 20-12

Modules	
Control Panel CPU Eng	2-10, Eng 20-27
Global Memory	Eng 2-10
Keyer Module	Eng 2-10
MLE Memory	Eng 2-10
Panel Communications Hub	Eng 2-10
Panel Communications Hub (PCI	H) Eng 20-27
Panel Module Controller	
Positioner	Eng 2-11
Preview Bus	Eng 2-11
Replacing	
installing	Eng 18-19
removing	Eng 18-18
Transition	Eng 2-11
Monitor Connection	Eng 3-16
Monitor Wall option	Eng 6-18
MORE button	Eng 5-3
Mounting Arm (Touchscreen)	Eng 3-9
Mouse installation	Eng 3 12
Mouse port	Eng 2 15
Mouse Sonsitivity setting	Eng 11 0
Moving Custom Controls	Eng 10.28
Moving Custom Controls	Eng 15 6
Moving Shot Dox Pages	Eng 8 10
	Eng 8-19
isolate	Eng 11-8
option	Eng 0-18
setup	Eng 8-19
with MIX/DSK	Eng 8-21
MultiDSK 5 and 6	Eng 8-19
MultiPanel	F 4.10
MLE Assignment	Eng 4-10
Setup	Eng 4-10
Multiple Custom Controls Eng	10-10, Eng 11-9
running	Eng 10-13
Multi-Viewer Eng 8-13, Eng	13-5, Eng 13-11
Assignment	Eng 8-13
defaulting	Eng 12-29
Layouts	Eng 8-14
assign	Eng 8-14
edit	Eng 8-15
name	Eng 8-15
Recalling individual	Eng 13-14
Storing individual	Eng 13-8
Output BNC	Eng 8-3
Registers	
assignment Eng	12-29, Eng 13-3
layoutEng	12-29, Eng 13-3

#### Ν

Name Multi-Viewer Layout	Eng 8-15
Names, mnemonic default	Eng 4-16
Naming Bus Maps	Eng 7-22
Naming custom control banks	Eng 10-6
Naming Custom Control Buttons	Eng 10-24
Naming External Rows	Eng 17-8
Naming Menus	Eng 5-16
Naming Output GPI I/Os	Eng 12-16

Naming Shot Box Pages	Eng 15-5
Naming video inputs	Eng 7-2
Navigation Area	Eng 5-6
Navigation Area, menu	Eng 5-6
Net Expander	
communications settings	Eng 9-18
NetExp	
cabling	Eng 9-14
Network Address, default	Eng 20-11
Network Security	Eng 4-9
Network Setup	Eng 4-5
Next Page Quick Navigation Button	Eng 5-9
Non-Sync Detect	Eng 7-9
Non-Sync Status	Eng 17-16
Normal custom control banks	Eng 10-5
Notify End CC Custom Control	Eng 10-20
NPlay Retries Extra Option	Eng 9-31
NTP Server Time	Eng 12-39
Num Levels Extra Option	Eng 9-29
NV-RAM	
Defaulting	Eng 12-28

# 0

OD Master Extra Option	Eng 9-26
Off, Input BNC Type	Eng 7-5
Online Manuals	Eng 5-17
Opening/Closing the frame door, QMD/X	Eng 3-3
Operating Environment Requirements	Eng 20-5
Operating Environment, frame	Eng 3-5
Operator	
reference description	Eng 1-4
Option	
Mix/DSK	Eng 8-17
Mix/MultiDSK	Eng 8-21
Options	
codes, deleting	Eng 6-20
codes, store and recall	Eng 6-19
custom control banks, enable	Eng 10-5
installed	Eng 6-14
installed panel boards	Eng 6-14
Outpoint, Video Server Clip	Eng 12-19
Output BNCs	Eng 8-2
- · · · · · · · · · · · · · · · · · · ·	Ling 0-2
additional setup	Eng 8-2
additional setup Aux Bus	Eng 8-7 Eng 8-3
additional setup Aux Bus Aux Monitor	Eng 8-2 Eng 8-7 Eng 8-3 Eng 8-3
additional setup Aux Bus Aux Monitor Clean Feed	Eng 8-2 Eng 8-7 Eng 8-3 Eng 8-3 Eng 8-3
additional setup   Aux Bus   Aux Monitor   Clean Feed   clean feed	Eng 8-2 Eng 8-7 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-7
additional setup   Aux Bus   Aux Monitor   Clean Feed   clean feed   Clean Feed, MLE	Eng 8-7 Eng 8-7 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-7 Eng 8-3
additional setup Aux Bus Aux Monitor Clean Feed clean feed Clean Feed , MLE default mapping	Eng 8-7 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-7 Eng 8-3 Eng 3-15
additional setup Aux Bus Aux Monitor Clean Feed clean feed Clean Feed, MLE default mapping Input BNC	Eng 8-7 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-7 Eng 8-3 Eng 3-15 Eng 8-3
additional setup   Aux Bus   Aux Monitor   Clean Feed   clean feed   Clean Feed, MLE   default mapping   Input BNC   Look Ahead Preview, MLE	Eng 8-7 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-3 Eng 3-15 Eng 8-3 Eng 8-3 Eng 8-3
additional setup   Aux Bus   Aux Monitor   Clean Feed   clean feed   Clean Feed, MLE   default mapping   Input BNC   Look Ahead Preview, MLE   Multi-Viewer	Eng 8-7 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-3
additional setup   Aux Bus   Aux Monitor   Clean Feed   clean feed   Clean Feed, MLE   default mapping   Input BNC   Look Ahead Preview, MLE   Multi-Viewer   Preview, main	Eng 8-7 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-3 Eng 3-15 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-3
additional setup   Aux Bus   Aux Monitor   Clean Feed   clean feed   Clean Feed, MLE   default mapping   Input BNC   Look Ahead Preview, MLE   Multi-Viewer   Preview, main   Preview, MLE	Eng 8-7 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-7 Eng 8-7 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-2 Eng 8-3
additional setup   Aux Bus   Aux Monitor   Clean Feed   clean feed   Clean Feed, MLE   default mapping   Input BNC   Look Ahead Preview, MLE   Multi-Viewer   Preview, main   Preview, MLE   Program, main	Eng 8-7 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-7 Eng 8-3 Eng 3-15 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-3 Eng 8-2
additional setup Aux Bus Aux Monitor Clean Feed clean feed Clean Feed, MLE default mapping Input BNC Look Ahead Preview, MLE Multi-Viewer Preview, main Preview, MLE Program, main Program, MLE	Eng 8-7 Eng 8-3 Eng 8-2 Eng 8-2 Eng 8-2 Eng 8-3

Output Boards Functionality	Eng 2-35
Output Connections	Eng 3-15
Output GPI I/Os	Eng 12-14
Naming	Eng 12-16
Setting up trigger signals	Eng 12-15
OverDrive	
relative custom controls	Eng 10-11
Overlay, Preview	Eng 12-30
Overview	
Equipment	Eng 2-2
Video Formats	Eng 2-31

#### Ρ

Pages, Shot Box	
copying	Eng 15-6
creating	Eng 15-4
moving	Eng 15-6
naming	Eng 15-5
Pan Invert Extra Option	Eng 9-28
Pan/Tilt Damping Extra Option	Eng 9-28
Pan/Tilt Speed Extra Option	Eng 9-28
PANEL	Eng 2-16
Panel Boards Menu	Eng 6-14
Panel buttons	
assign black	Eng 7-14
assign color background	Eng 7-14
AuxBkgdCut	Eng 7-15
AuxBkgdTrans	Eng 7-15
AuxKeyCut	Eng 7-15
AuxKeyTrans	Eng 7-15
Bus Hold	Eng 7-15
Global-Store	Eng 7-14
MLE re-entry	Eng 7-14
MLE-Store	Eng 7-14
Shift	Eng 7-14
Panel Commands Auto Follow	Eng 12-41
Panel Communications Hub	Eng 2-10
Panel Communications Hub (PCH)	Eng 20-27
Panel Fail IndicatorEng 5-	-3, Eng 17-10
Panel ID Extra Option	Eng 9-28
Panel Module Controller	Eng 2-10
Panel Port	Eng 20-20
Panel port on frame	Eng 3-11
Panel Rows	
External	Eng 17-6
Internal	Eng 17-6
Panel Serial Ports	Eng 9-2
Panel Sleep Time, Personality setting	Eng 11-9
Parallel Tallies Overview	Eng 2-18
Pattern Extra Option	Eng 9-27
Pause Audio Server Custom Controls	Eng 10-17
Pause CC Custom Control	Eng 10-20
Pause Custom Controls	-
modify	Eng 10-26
Pause DVE Custom Control	Eng 10-18
Pause VTR Custom Control	Eng 10-19
Pause/Hold Custom Control Shortcut	Eng 10-30

#### Pbus

1005	
custom control functions	Eng 10-2
option	Eng 6-18
Pbus Memory	Eng 11-10
PCH, see Panel Communications Hub	
Percent Used, storage capacity	Eng 6-13
Peripheral Bus II option	Eng 6-18
Peripheral Ports Eng 2-10	6, Eng 20-20
Personality	Eng 11-2
Audio Cut Only	Eng 11-3
Audio Transitions	Eng 11-3
Auto Follow	
Custom Controls	Eng 11-3
Editors	Eng 11-3
Panel	Eng 11-3
Auto Recall	Eng 11-4
Auto Remove Key	Eng 11-4
Bank 0 Lit	Eng 11-4
CC/Macro Attachments	Eng 11-4
Clear Bus Hold	Eng 11-4
Default Trans Rate	
Active	Eng 11-5
Eff Dissolve	Eng 11-5
FTB	Eng 11-5
Keyer	Eng 11-5
MLE	Eng 11-5
Sequence	Eng 11-5
Defaulting	Eng 12-28
Double-Press BKGD	Eng 11-5
Double-Press Rate	Eng 11-5
DSK Auto Cut	Eng 11-6
Edge Width Default	Eng 11-6
Editor Pattern Codes	Eng 11-6
Editor Trans Rate	Eng 11-7
FTB Display Mode Eng 11	-7, Eng 16-7
Global Memory Number Entry	Eng 11-7
Global-Store 4 Mode	Eng 11-7
Isolate MultiDSKs	Eng 11-8
Key Cut then Fade	Eng 11-8
Keypad Clip IDs Entry	Eng 11-8
lock/unlock	Eng 11-22
Log OverDrive Messages	Eng 11-8
Matte Limit	Eng 11-9
Memory Bank Cycle	Eng 11-9
Mnemonics appearance	Eng 5-12
Mouse Sensitivity	Eng 11-9
Multiple Custom Controls	Eng 11-9
Panel Sleep Time	Eng 11-9
Pbus Memory	Eng 11-10
Quick Bank Select	Eng 11-10
Quick Navigation Button	Eng 5-9
Recall Global-Store Memory Mode	Eng 11-10
Recall MLE-Store Memory Mode	Eng 11-10
Re-entry Depth	Eng 11-11
Re-entry Loops	Eng 11-11
Roll Clip Mode	Eng 11-11
Shift Locking	Eng 11-11

Show CC's on Key Bus	Eng 11-12
Squeeze & Tease Mode	Eng 12-5
Store Mode	Eng 11-12
Swap Keyers Cut and Auto	Eng 11-12
Swap Program and Preset	Eng 11-12
Swap Trans, Cut and Auto	Eng 11-12
Time Clock Source	Eng 11-13
Time Clock UMD Number	Eng 11-13
UltraChrome	U
default color	Eng 11-13
default mode	Eng 11-13
VTR POL On-air Display	Eng 11-13
VTR POL Prep'd Display	Eng 11-13
Wake Up On Command Eng 11-7	, Eng 11-13
Personality Registers	Eng 13-2
PGM	U
definition	Eng 1-5
PGM Audio Level Custom Controls	Eng 10-16
PGM Output Extra Option	Eng 9-26
Play (CG) Custom Control	Eng 10-17
Play Audio Server Custom Controls	Eng 10-17
Play Custom Control Eng 10-18	8, Eng 10-19
Play Loop Off Custom Control	Eng 10-19
Play Loop On Custom Control	Eng 10-19
Play Rev Custom Control	Eng 10-18
Play w/ Alpha Custom Control	Eng 10-19
Play w/ Alpha Extra Option	Eng 9-31
Playback Mode Extra Option	Eng 9-31
PlayTime Extra Option	Eng 9-26
PMC, see Panel Module Controller	
PMCs, Upgrading	Eng 18-21
Poll Extra Option	Eng 9-29
Pop-up Help	Eng 5-17
Port Cmds Extra Option	Eng 9-31
Port Expanders	U
BSS4	
Cabling	Eng 9-13
communications settings	Eng 9-18
Programming	Eng 9-17
DeviceMaster	-
Cabling	Eng 9-14
Programming	Eng 9-17
NetExp	
Cabling	Eng 9-14
communications settings	Eng 9-18
Supported	Eng 9-13
Port Monitor Data File	Eng 17-38
Port Monitor, Communication	Eng 17-37
Ports	
Aux Panel	
Echo	Eng 20-31
GPI	Eng 20-30
Main	Eng 20-30
communication, overview	Eng 2-15
Control Panel	
AC power	Eng 20-26
aux	Eng 20-25

external link	Eng 20-24
remote	Eng 20-24
DVIE	ng 2-15. Eng 3-9
Ethernet	Eng 2-15
ethernet (Touchscreen)	Eng 3-9
External Panel Link	Eng 2-15
Frame	
AC power	Eng 20-22
GPI I/O	Eng 20-21
LAN	Eng 20-22
nanel	Eng 20-20
peripheral	Eng 20-20
frame	Eng 2-16
GP I/O	Eng 2-10
GPI/O	Eng 2-16
Keyboard En	$\alpha 2 15 \text{ Eng } 3 12$
	Eng 2-15, Eng 2-16
Mouse En	$\sigma 2_{-15}$ Eng $3_{-12}$
PANEI	g 2-13, Elig 3-12 Eng 3-11
Papal	Eng 2 16
Parimbaral	Eng 2.16
relipiteral	Eng 2 20
power (Touchscreen)	Eng 2 12
PS/2	Ellg 5-12
Reference	Eng 4-12
T-11-	Eng 2-10
Tally	Eng 2-18
time code input	Eng 2-16
USBEn	g 2-15, Eng 2-16
USB (Touchscreen)	Eng 3-9
Positioner	
icon, circular	Eng 5-8
icon, left-right	Eng 5-8
icon, up-down	Eng 5-8
1cons	Eng 5-8
Positioner Calibration	Eng 17-4
Positioner Module	Eng 2-11
Post-Attach Custom Control	Eng 10-22
Power	Eng 4-2
Power Button, touchscreen display	Eng 5-3
Power connection	E 2.00
installing control panel	Eng 3-20
installing frame	Eng 3-19
Power Consumption	
control panel	Eng 20-3
Frame	Eng 20-4
Power Distribution Board	Eng 2-11
Power down, switcher	Eng 4-3
Power Fail indicators	Eng 3-21
Frame	Eng 5-3
Panel	Eng 5-3
Power Failure	Eng 3-21
Power Supplies	Eng 2-13
Control Panel	Eng 18-9
control panel	Eng 20-3
FrameEng	18-11, Eng 20-4
Power Supply (Touchscreen)	Eng 3-20
Power Supply Failure	

Control PanelEng 18-2
troubleshootingEng 18-2, Eng 18-3
FrameEng 18-6
replacingEng 18-4
Pre-Attach Custom ControlEng 10-22
Preview
mainEng 8-2
MLEEng 8-3
overlay optionEng 10-2
Preview Bus ModuleEng 2-11
Preview output, mainEng 8-2
Preview OverlayEng 12-30
Center setupEng 12-35
font colorEng 12-30
Safe Title setupEng 12-33
Safe Title, namingEng 12-34
Source ID setupEng 12-33
Time Clock
Count DirectionEng 12-37
PositionEng 12-36
Reset on TransitionEng 12-36
Reset/Start TimeEng 12-37
setupEng 12-36
VTR Timecode setupEng 12-32
Preview Overlay output
Proc Amps optionEng 6-18
Processor
frameEng 2-35
VideoEng 2-35
Processor, Video Eng 2-24, Eng 2-26
Program output
mainEng 8-2
MLEEng 8-3
Programming BSS4Eng 9-17
Programming Comtrol DeviceMasterEng 9-17
Programming control panel functionsEng 10-8
Progressive ScanEng 2-31, Eng 2-32
Progressive Segmented FramesEng 2-33
PS/2 portEng 2-15
PS/2 portsEng 3-12
PST Audio Level Custom ControlsEng 10-17
PST PATT, definitionEng 1-5
PST, definitionEng 1-5
PunchpadEng 5-6
PV, definitionEng 1-5

**Q** QMD/X

•	
4-Keyers option	Eng 2-2
Query Cmd Extra Option	Eng 9-28
Quick Bank Select Personality	Eng 11-10
Quick Module Configuration	Eng 17-5
Quick Navigation	Eng 5-9
Aux Bus	Eng 5-9, Eng 5-10
Color Scheme	Eng 5-9
Custom Controls	Eng 5-10
Diagnostics	Eng 5-9

DVE	Eng 5-10
Help	Eng 5-9
Hold	Eng 5-9
Home	Eng 5-9
Install	Eng 5-9
Next Page	Eng 5-9
Pers	Eng 5-9
Quick Navigation buttons	Eng 5-3
More	Eng 5-3

# R

Rate Extra Option	Eng 9-29
Rates, Effects Dissolve	U U
default	Eng 11-5
RclTime Extra Option	Eng 9-29
Read (CG) Custom Control	Eng 10-17
Rear connectors, frame	 Eng 2-7
Rear Frame Boards	Eng 4-22
Recall	U
all	Eng 13-10
bus maps	Eng 13-10
cameras	Eng 13-10
cc/macro attachments	Eng 13-10
custom controls	Eng 13-10
Factory Defaults	Eng 12-27
individual Bus Maps	Eng 13-13
individual custom control	Eng 13-12
Individual Items	Eng 13-11
individual memories	Eng 13-11
individual Multi-Viewer Layouts	Eng 13-14
individual S&T Sequences	Eng 13-12
individual Shot Box Pages	Eng 13-13
installation	Eng 13-10
memories	Eng 13-10
multi-viewer assignment	Eng 13-11
multi-viewer layouts	Eng 13-11
option codes	Eng 6-19
personality	Eng 13-10
Register Types	Eng 13-9
shot box pages	Eng 13-10
squeeze & tease sequences	Eng 13-10
VTR clips	Eng 13-10
Recall (CG) Custom Control	Eng 10-17
Recall DVE Custom Control	Eng 10-18
Recall Memories	
Auto Follow	Eng 12-45
Recall MLE-Store	
Memory Recall Mode, Personality	Eng 11-10
Recall Pbus Custom Control	Eng 10-18
Recall Shot Custom Controls	Eng 10-18
recalling assignments from disk	Eng 13-11
recalling from disk	Eng 13-10
recalling layouts from disk	Eng 13-11
Record Custom Control	Eng 10-19
Record Custom Control Shortcut	Eng 10-30
Record Time Extra Option	Eng 9-30
Recording	6-00
2	

custom controls	Eng 10-9
relative custom controls	Eng 10-12
Recording custom controls	Eng 10-8
Redundant Power	Eng 2-13
Redundant power Eng 3-	19, Eng 3-20
Re-entry	· · · ·
MLE Button Color	Eng 11-15
Re-entry Depth. Personality	Eng 11-11
Re-entry Loops, Personality	Eng 11-11
Reference	
Composite	Eng 1-12
connection	Eing 4-12
Imput DNCs reset	$\operatorname{Eng} 4-12$
	Eiig 4-14
Internal	Eng 4-15
Output BINCs reset	Eng 4-14
setting	Eng 4-12
Tri-Level Sync	Eng 4-12
Reference Description	
Bottom MLE	Eng 1-4
Control Panel	Eng 1-4
Frame	Eng 1-4
Full MLE	Eng 1-4
Half MLE	Eng 1-4
Master Panel	Eng 1-4
Operator	Eng 1-4
Satellite Panel	Eng 1-4
SDI	Eng 1-4
Setup	Eng 1-4
Storage Device	Eng 1-4
Switcher	Eng 1-4
User	Eng 1-4
Video System	Eng 1-4
Pagistars	
Bus Mans Eng 12	28 Eng 13 3
Comere	Eng 12-3
Camera Eila	Eng 12 29
	E = 12.2
Clip	Eng 13-2
Clips	Eng 12-28
Custom Control Attachment	Eng 12-28
Custom Control Attachments	Eng 13-3
Custom Controls Eng 12-	28, Eng 13-2
Installation Eng 12-	28, Eng 13-2
Memory Eng 12-	28, Eng 13-2
Multi-Viewer Assigment Eng 12-	29, Eng 13-3
Multi-Viewer Layout Eng 12-	29, Eng 13-3
NV-RAM	Eng 12-28
Personality Eng 12-	28, Eng 13-2
Shot Box Pages Eng 12-	28, Eng 13-3
Squeeze & Tease Eng 12-	28, Eng 13-3
Switcher	Eng 12-28
Related publications	Eng 1-6
Relative Custom Controls	Eng 10-11
Remaining storage capacity	Eng 6-13
Remote audio mixer control	-
setup channels and groups	Eng 12-22
source assignment	Eng 12-22
Remote Aux Panel GPI I/O	-

programming GPI	Eng 14-12
Remote Aux Panels	Eng 14-3
cabling	Eng 14-7
comm setup	Eng 14-8
communications connections	Eng 14-6
GPIs	Eng 14-11
installing	Eng 14-5
Remote Control Port	Eng 2-16
Remote Ports	Eng 20-24
Removing Button Cap Assembly	Eng 3-17
Removing frame boards	Eng 4-18
Removing the frame door, MD/X	Eng 3-3
Replace Custom Control	Eng 10-22
Replacing a Control Panel Module	Eng 18-18
installing	Eng 18-19
removing	Eng 18-18
Replacing a Power Supply Panel	Eng 18-4
Reset	Liig 10-4
	Eng 1 26
	Elig 4-20
	Eng 4-27
Individual MLEs $(1-4)$	Eng 4-27
Individual MLEs (5-8)	Eng 4-27
software	Eng 4-26
system	Eng 4-25
Reset Audio Custom Controls	Eng 10-17
Reset GPI Custom Control	Eng 10-18
Reset Input BNCs Format	Eng 4-14
Reset Output BNCs Format	Eng 4-14
Reset Time Clock Custom Control	Eng 10-20
Reset, full	Eng 4-25
Resetting individual MLEs	Eng 4-26
Restart	-
control panel	Eng 4-26
switcher	Eng 4-25
Rewind Custom Control	Eng 10-19
Rewind DVE Custom Control	Eng 10-18
RGB Color Corrector option	Eng 6-18
Ribbon Cable Connector	Eng 18-15
Robotic Cam Input BNC Type	Eng 7-5
Robotic Cameras	Liig 7-5
Robotic Cameras Degisters	Eng 12 2
Registers	Elig 15-5
Robouc System option	Eng 0-18
Roll Clip Mode, selecting	Eng 11-11
Roll GPO	Eng 7-25
Router option	Eng 6-18
Router, Input BNC Type	Eng 7-5
Routing, video	Eng 2-20
Rsync Failed	Eng 6-7
RU, definition	Eng 1-5
Run Custom Control event, insert	Eng 10-10
Run From Here Custom Control Comma	nd Eng 10-26
Run Sequence Custom Control	Eng 10-20
Run Single Custom Control Event	Eng 10-26
5	č

## S

S.M.A.R.T. warnings	Eng 17-12
Safe Title Custom Control	Eng 10-20

Safe Title, Preview Overlay NamingEng 12-34
Safe Title, Preview Overlay Setup
Satellite Panel
reference description Eng 1-4
Scan
Interlaced Eng 2-31 Eng 2-32
Progressive Eng 2 31 Eng 2 32
Progressive Segmented Frames Eng 2-32
Scan Fraguency Eng 2.33
Scan Lines Eng 2.31
Scan Eraguenay Eng 2.22
Scall, FrequencyElig 2-55
SD DVE option
SD definition
SD, definitionEng 1-5
reference descriptionEng 1-4
Select Delay Extra OptionEng 9-29
Select Memory Bank event, insertEng 10-10
Selected Bttns User ColorEng 11-15
Selected Xpt User ColorEng 11-15
Selection AreaEng 5-5
Selection Area, menuEng 5-5
Selection knobsEng 5-3
Send Tries Extra OptionEng 9-30
Sequence Rate
defaultEng 11-5
Sequences
Recalling individualEng 13-12
Storing individualEng 13-7
Serial numbers, installationEng 3-2, Eng 6-16
Serial numbers, installingEng 6-14
Serial Tally optionEng 6-18
SerialSwitch Extra OptionEng 9-29
Service, customerEng 1-7
Set Folder (CG) Custom ControlEng 10-17
Setting Mouse SensitivityEng 11-9
Setting Time/Date AutomaticallyEng 12-39
Setting Time/Date ManuallyEng 12-38
Setting up Input GPI I/O TalliesEng 12-13
Setting up Input GPI I/OsEng 12-10
Memory Recall eventEng 12-11
Run Custom ControlEng 12-12
Transition eventEng 12-11
Trigger Signal Priority Eng 12-13
Setting up Output GPLI/Os Eng 12-14
Trigger Signal Eng 12-15
Settings
Extra Options Eng 9-26
Setun
auto key $Fn\sigma 7_{-8}$
BNC types $F_{ng} \otimes 2$
Center Preview Overlav Eng 12 25
communications Eng 0 1
custom controls Eng 10.1
Clobal Store auto kay
$CPI Outputs = E_{PA} = 7.25$
$MI = Store auto key \qquad Er = 7.9$
MILE-SIDIE auto keyEng /-8

network	Eng 4-5
Preview Overlay	Eng 12-30
Preview Overlay font color	Eng 12-30
Safe Title Preview Overlay	Eng 12-33
Source ID Preview Overlay	Eng 12-33
tallies	Eng 7-23
Time Clock Preview Overlay	Eng 12-36
VTR Timecode Preview Overlav	Eng 12-32
Setup. completing	Eng 12-1
Setups	6
reference description	Eng 1-4
Shaped. alpha	Eng 7-7
SHIFT	
Shift	
Shift Locking Personality Setting	Eng 11-11
Shift Locking	
Personality setting	Eng 11-11
Shortcuts	
custom controls	Eng 10-30
Pause/Hold	Eng 10-30
Record	Eng 10-30
Shot Boy	Ling 10-50
Shot Box Module	Eng 10-4
Soft Shot Box	Eng 10-4
Shot Box Modules	Eng 15 1
pages	Eng 15-1 Eng 15-4
copying	Eng 15 6
moving	Elig 15-0 Eng 15-6
noming	Eng 15-0
sotup	Eng 15-3
Shot Box Pages	Ling 15-2
Defaulting	Eng 12-28
Recalling individual	Eng 12-20
Registers	Eng 13-13
Storing individual	Eng 13-8
ShotOffset Extra Ontion	Eng 9_29
Show CC's on Key Bus Personality se	tting Eng 11-12
Show on Preview Extra Option	Eng $Q_2 27$
Simulate GPI Custom Control	Eng <i>J</i> -27 Fng 10-18
Skine	Eng 5-11
Slot 1 Extra Ontion	Eng 9-30
Slot System Information Page	Eng 6-12
Small Audio Mixer option	Eng 6-18
SmartConversion option	Eng 6-18
SmartConversion option	Eng 16-1
Soft key labels	Eng 1-3
Software	Ling 1-5
ontions installing	Eng 6-16
reset	Eng $A_2$ ?6
ungrade procedure	112 + 20
Software Licenses	ig 0-3, Elig 0-4
Apache License	Eng 22-8
BSD License	Eng 22-7
Expat License	Eng 22-10
GNU General Public License	Eng 22-2
Imlib2	Eng 22-11
Lesser GNU Public License	Eng 22-4
	-

Character Generator	Eng 6-17
DVE Send and Remote Control	Eng 6-17
Editor Interface	Eng 6-17
Extra Half MLE	Eng 6-17
Large Audio Mixer	Eng 6-17
MD DVE	Eng 6-17
Mix/DSK	Eng 6-17
MLEs in MD Mode	Eng 6-17
MLEs in SD mode	Eng 6-17
MLE-Store	Eng 6-17
Monitor Wall	Eng 6-18
MultiDSK	Eng 6-18
Peripheral Bus II	Eng 6-18
Proc Amps	Eng 6-18
RGB Color Corrector	Eng 6-18
Robotic System	Eng 6-18
Router	Eng 6-18
SD DVE	Eng 6-18
Serial Tally	Eng 6-18
Small Audio Mixer	Eng 6-18
SmartConversion	Eng 6-18
Still Store, external	Eng 6-18
Video Server Control	Eng 6-18
VTR Remote Control	Eng 6-18
Software Ver Extra Option	Eng 9-27
Software Version	Eng 17-2
Source ID, Preview Overlay Setup	Eng 12-33
Source Name Extra Option	Eng 9-30
Special	
custom control Functions	Eng 10-15
custom control functions	Eng 10-2
Specifications	Eng 20-1
Button Insert Films	Eng 3-17
control panel cutout dimensions	Eng 20-7
control panel dimensions	Eng 20-6
frame dimensions	Eng 20-10
general	Eng 20-3
LTC timecode	Eng 20-18
operating environment	Eng 20-5
power consumption	
control panel	Eng 20-3
frame	Eng 20-4
power supplies	
control panel	Eng 20-3
frame	Eng 20-4
standard components	Eng 20-2
timing	Eng 20-18
video formats	Eng 20-17
Video Input Signal	Eng 20-18
Video Input Signal Characteristics	Eng 20-19
video processing	Eng 20-17
Squeeze & Tease	
Defaulting	Eng 12-28
	Index • IX–19

4-Keyers ...... Eng 6-17 Audio Server Control ..... Eng 6-17 AuxKeys ..... Eng 6-17

Software Options

, , , , , , , , , , , , , , , , , , , ,	Elig 12-3
Registers	Eng 13-3
Squeeze & Tease Carrier	Eng 2-13
Squeeze & Tease Carrier Board, overview	v .Eng2-27,
Eng 2-28	0
Squeeze & Tease MD Carrier Board	Eng 2-35
Src & Dest Base Extra Option	Eng 9-29
Start Extra Option	Eng 9-29
Static Discharge	Eng 3-2
Status Icons	Eng 17-12
Status Menu Icons	Eng 17-12
Status Switcher	Eng 17-10
Status, System Information Page	Eng 6-13
Still Store (external) Input BNC Type	Eng 7-5
Still Store option external	Eng 6-18
Stop Audio Server Custom Controls	Eng 10-17
Stop Custom Control Eng 10.10	Eng 10-17
Stop DVE Custom Control	5, Eng 10.19
Stop DVE Custom Control	Elig 10-16
Stop Other CC Custom Control	Eng 10-20
Stop Time Clock Custom Control	Eng 10-19
Stopping FlexDevice Drivers	Eng 9-5
Storage Capacity Page	Eng 6-13
current usage	Eng 6-13
device	Eng 6-13
percent used	Eng 6-13
remaining	Eng 6-13
total size	Eng 6-13
Storage Capacity, Web Interface	Eng 6-13
Storage Device	
8	
reference description	Eng 1-4
reference description Storage, files	Eng 1-4 Eng 13-1
reference description Storage, files Store	Eng 1-4 Eng 13-1
reference description Storage, files Store all	Eng 1-4 Eng 13-1 Eng 13-5
reference description Storage, files Store all bus maps	Eng 1-4 Eng 13-1 Eng 13-5 Eng 13-5
reference description Storage, files Store all bus maps cameras	Eng 1-4 Eng 13-1 Eng 13-5 Eng 13-5 Eng 13-5
reference description Storage, files Store all bus maps cameras cc/macro attachments	Eng 1-4 Eng 13-1 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5
reference description Storage, files Store all bus maps cameras cc/macro attachments custom controls	Eng 1-4 Eng 13-1 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5
reference description Storage, files Store all bus maps cameras cc/macro attachments custom controls individual Bus Maps	Eng 1-4 Eng 13-1 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-8
reference description Storage, files Store all bus maps cameras cc/macro attachments custom controls individual Bus Maps individual custom control	Eng 1-4 Eng 13-1 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-8 Eng 13-7
reference description Storage, files Store all bus maps cameras cc/macro attachments custom controls individual Bus Maps individual custom control Individual ItemsEng 13	Eng 1-4 Eng 13-1 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-8 Eng 13-7 -5, Eng 13-6
reference description Storage, files Store all bus maps cameras cc/macro attachments custom controls individual Bus Maps individual Custom control Individual ItemsEng 13 individual memories	Eng 1-4 Eng 13-1 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-8 Eng 13-7 -5, Eng 13-6 Eng 13-6
reference description Storage, files Store all bus maps cameras cc/macro attachments custom controls individual Bus Maps individual Custom control Individual ItemsEng 13 individual Multi-Viewer Layouts	Eng 1-4 Eng 13-1 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-8 Eng 13-7 -5, Eng 13-6 Eng 13-8 Eng 13-6 Eng 13-8
reference description Storage, files Store all bus maps cameras cc/macro attachments custom controls individual Bus Maps individual Custom control Individual ItemsEng 13 individual Multi-Viewer Layouts individual S&T Sequences	Eng 1-4 Eng 13-1 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-8 Eng 13-7 -5, Eng 13-6 Eng 13-8 Eng 13-8 Eng 13-7
reference description Storage, files Store all bus maps cameras cc/macro attachments custom controls individual Bus Maps individual Custom control Individual Items Eng 13 individual Multi-Viewer Layouts individual S&T Sequences individual Shot Box Pages	Eng 1-4 Eng 13-1 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-7 Eng 13-6 Eng 13-8 Eng 13-8 Eng 13-8 Eng 13-7 Eng 13-8
reference description Storage, files Store all bus maps cameras cc/macro attachments custom controls individual Bus Maps individual Custom control Individual ItemsEng 13 individual Multi-Viewer Layouts individual S&T Sequences individual Shot Box Pages installation	Eng 1-4 Eng 13-1 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-8 Eng 13-7 -5, Eng 13-6 Eng 13-8 Eng 13-8 Eng 13-7 Eng 13-8 Eng 13-8 Eng 13-8 Eng 13-8 Eng 13-8
reference description Storage, files Store all bus maps cameras cc/macro attachments custom controls individual Bus Maps individual Bus Maps individual ltems Individual Items individual Multi-Viewer Layouts individual S&T Sequences individual Shot Box Pages installation memories	Eng 1-4 Eng 13-1 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-7 -5, Eng 13-6 Eng 13-6 Eng 13-8 Eng 13-7 Eng 13-8 Eng 13-8 Eng 13-5 Eng 13-5
reference description	Eng 1-4 Eng 13-1 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-7 -5, Eng 13-6 Eng 13-7 Eng 13-7 Eng 13-7 Eng 13-8 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5
reference description	Eng 1-4 Eng 13-1 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-7 -5, Eng 13-6 Eng 13-6 Eng 13-8 Eng 13-7 Eng 13-8 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5
reference description	Eng 1-4 Eng 13-1 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-8 Eng 13-7 -5, Eng 13-6 Eng 13-6 Eng 13-8 Eng 13-7 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5
reference description	Eng 1-4 Eng 13-1 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-7 -5, Eng 13-6 Eng 13-7 Eng 13-8 Eng 13-7 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-4
reference description	Eng 1-4 Eng 13-1 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-7 -5, Eng 13-6 Eng 13-6 Eng 13-8 Eng 13-7 Eng 13-8 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-4 Eng 13-5
reference description	Eng 1-4 Eng 13-1 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-7 -5, Eng 13-6 Eng 13-6 Eng 13-8 Eng 13-7 Eng 13-8 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-4 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5
reference description	Eng 1-4 Eng 13-1 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-7 -5, Eng 13-6 Eng 13-7 -5, Eng 13-6 Eng 13-8 Eng 13-7 Eng 13-5 Eng 13-5
reference description	Eng 1-4 Eng 13-1 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-7 -5, Eng 13-6 Eng 13-7 -5, Eng 13-6 Eng 13-7 Eng 13-7 Eng 13-5 Eng 13-5
reference description	Eng 1-4 Eng 13-1 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-7 -5, Eng 13-6 Eng 13-7 -5, Eng 13-6 Eng 13-7 Eng 13-8 Eng 13-5 Eng 13-5
reference description	Eng 1-4 Eng 13-1 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-7 -5, Eng 13-6 Eng 13-6 Eng 13-6 Eng 13-7 Eng 13-5 Eng 13-12 Eng 11-12
reference description	Eng 1-4 Eng 13-1 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-5 Eng 13-7 -5, Eng 13-6 Eng 13-6 Eng 13-6 Eng 13-8 Eng 13-7 Eng 13-5 Eng 13-5

Store Pbus Custom Control	Eng 10-18
Store/Recall option codes	Eng 6-19
storing assignments to disk	Eng 13-5
storing layouts to disk	Eng 13-5
storing to disk	Eng 13-5
Structure. CPU	Eng 2-35
Support brackets, frame	Eng 3-5
Support technical	Eng 1-7
Swap Button	Eng 5-5
Swap Kevers Cut & Auto	Eng 11-12
Swap Program and Preset Buses	Eng 11-12
Swap Trans Cut & Auto Personality	Eng 11-12
Swapping Custom Controls	Eng 10-28
Switch on Field	Eng 8-12
Switcher	Ling 0-12
Defaulting	Eng 12 28
reference description	Eng 1 /
software upgrade	Elig 1-4
standard components	Eng 20.2
Standard components	Eng 20-2
Switcher Basics	Eng 2-1
Switcher Format	Eng 4-12
Switcher Logs	Eng 1/-39
Switcher Personality	Eng 11-2
Audio Cut Only	Eng 11-3
Audio Transition	Eng 11-3
Auto Follow	
Custom Controls	Eng 11-3
Editors	Eng 11-3
Panel	Eng 11-3
Auto Recall	Eng 11-4
Auto Remove Key	Eng 11-4
Bank 0 Lit	Eng 11-4
CC/Macro Attachments	Eng 11-4
Clear Bus Hold	Eng 11-4
Default MLE Map	Eng 12-4
Default Trans Rate	
Active	Eng 11-5
Eff Dissolve	Eng 11-5
FTB	Eng 11-5
Keyer	Eng 11-5
MLE	Eng 11-5
Sequence	Eng 11-5
Double-Press BKGD	Eng 11-5
Double-Press Rate	Eng 11-5
DSK Auto Cut	Eng 11-6
Edge Width Default	Eng 11-6
Editor Pattern Codes	Eng 11-6
Editor Trans Rate	Eng 11-7
FTB Display ModeEng	11-7. Eng 16-7
Global Memory Number Entry	Eng 11-7
Global-Store 4 Mode	Eng 11-7
Isolate MultiDSKs	Eng 11-8
Key Cut then Fade	
Keynad Clip IDs Entry	Eng 11-8
lock/unlock	Eng 11_22
Log OverDrive Messages	Eng 11-2
Matte Limit	Eng 11-9
- Lucco Elittic	

Memory Bank Cycle	Eng 11-9
Mouse Sensitivity	Eng 11-9
Panel Sleep Time	Eng 11-9
Pbus Memory	Eng 11-10
Quick Bank Select	Eng 11-10
Recall Global-Store Memory Mode	Eng 11-10
Recall MLE-Store Memory Mode	Eng 11-10
Re-entry Depth	Eng 11-11
Re-entry Loops	Eng 11-11
Roll Clip Mode	Eng 11-11
Shift Locking	Eng 11-11
Show CC's on Key Bus	Eng 11-12
Squeeze & Tease Mode	Eng 12-5
Store Mode	Eng 11-12
Swap Trans Cut & Auto	Eng 11-12
Time Clock Source	Eng 11-13
Time Clock UMD Number	Eng 11-13
UltraChrome	
default color	Eng 11-13
default mode	Eng 11-13
Switcher Power Down	Eng 4-3
Switcher Reference Setup	Eng 4-12
Switcher Restart	Eng 4-25
Switcher Status	Eng 17-10
Communication	Eng 17-14
Status	Eng 17-14
Complete Status	Eng 17-10
Non-Sync	Eng 17-16
Version Information	Eng 17-2
Vision OS	Eng 6-14
Warnings	Eng 17-11
Switcher, hard restart Eng 6	-3, Eng 6-11
Switches	
control panel configuration	Eng 20-28
frame configuration	Eng 20-11
System	
functional check	Eng 4-17
reset	Eng 4-25
turn on power	Eng 4-2
System Architecture	Eng 2-1
System Cards	E 2.20
XFX Extra Effects	Eng 2-29
System Information Page	Eng 6-12
card	Eng 6-12
date	Eng 6-13
function	Eng 6-12
slot	Eng 6-12
status	Eng 6-13
version	Eng 0-13
System Time/Date	Eng 3-3
sotting automatically	Eng 12 20
setting manually	Eng 12-39
seeing manually	Ling 12-30
-	

#### Т

Take Out (CG) Custom Con	ntrolEng 10-1'	7
Take XPT Custom Control	Eng 10-19	9

Take, Custom Control	Eng 10-17
Tallies	
BNCs	Eng 7-4
GPI I/O Inputs	Eng 12-13
Input BNC	Eng 7-23
MLE	Eng 8-9
Ports	Eng 2-18
TargetMachine Extra Option Eng 9-	30, Eng 9-31
TD, definition	Eng 1-5
Technical support	Eng 1-7
Tilt Invert Extra Option	Eng 9-29
Time Clock	e
Count Direction	Eng 12-37
custom control functions	
Position	Eng 12-36
Preview Overlay Setup	Eng 12-36
Reset on Transition	Eng 12-36
Reset/Start Time	Eng 12-37
Time Clock Source Personality	Eng 11 13
Time Clock UMD Number Personality	Eng 11-13
Time Code Input Overview	Eng 2 16
Time Code Input Overview	Elig 2-10
	$E_{22} = 12/20$
setting automatically	Eng 12-39
setting manually	Eng 12-38
TimeOut Extra Option	Eng 9-30
Timeout Extra Option	Eng 9-27
Timing Specifications	Eng 20-18
Title, menu	Eng 5-5
Total storage capacity	Eng 6-13
Touchscreen	
lower display region	Eng 5-3
power button	Eng 5-3
upper display region	Eng 5-3
Touchscreen Calibration	Eng 17-4
Touchscreen Display	Eng 2-7
adjusting	Eng 5-3
Touchscreen Display port	Eng 2-15
Touchscreen installation	Eng 3-9
Touchscreen interface	Eng 5-2
Transition Keys Custom Control	Eng 10-20
Transition Module	Eng 2-11
Auto Follow	Eng 12-44
Trigger GPI Custom Control	Eng 10-18
Trigger Phus Custom Control	Eng 10-18
TxRx Errors	Eng 17-14
Type, BNC	Eng 7-4
Jr . , =	· · · · · · · · · · · · · · · · · · ·

### U

UltraChrome	
Default Color, Personality	Eng 11-13
Default Mode, Personality	Eng 11-13
Edge Sensitivity Default	Eng 11-6
Edge Width Default	Eng 11-6
Unlock Installation	Eng 12-46
Unlock Personality	Eng 11-22
Unshaped, alpha	Eng 7-7
UP ONE button	Eng 5-2

Up/Down Converters	Eng 16-1
Bus Disabling	Eng 16-5
Conversion Loop	Eng 16-2
activation	Eng 16-3
delay	Eng 16-3
setup	Eng 16-2
video formats	Eng 16-3
Locking Conversion Loops	Eng 16-6
Switcher Setup	Eng 16-5
Upgrade procedure	Eng 6-4
Upgrade Status	
Done	Eng 6-13
Failed	Eng 6-13
In Progress	Eng 6-13
No Status	Eng 6-13
Pending	Eng 6-13
Upgrading PMC	Eng 18-21
Upper Display Region	Eng 5-3
USB	
cable (Touchscreen)	Eng 3-9
portsEng 2	-15, Eng 2-16
software upgrade	Eng 6-3
Use Break Extra Option	Eng 9-27
User	
reference description	Eng 1-4
User Colors	Eng 11-15
Custom Control Buttons	Eng 11-15
Re-entry Buttons	Eng 11-15
Selected Buttons	Eng 11-15
Selected Xpt	Eng 11-15
Xpt Colors	Eng 11-16
Using	
custom control, basics	Eng 10-8
Using Frame Rates	Eng 2-33

# ۷

VCR, definition	Eng 1-5
Verification of Inputs	Eng 4-16
Verification of Output BNCs	Eng 8-5
Version Extra Option	Eng 9-26
Version upgrade, software	Eng 6-3
Version, software	Eng 17-2
Version, System Information Page	Eng 6-13
Video Formats	Eng 20-17
explained	Eng 2-31
Input BNC	Eng 7-6
setting	Eng 4-12
Video Input Board	Eng 2-12
10 input	Eng 2-12
16 input with crosspoint	Eng 2-12
Video Input Connections	Eng 3-13
Video Input Signal Characteristics	. Eng 20-18, Eng
20-19	
Video Input WorksheetEn	g 21-2, Eng 21-9
Video Inputs	
configuring	Eng 7-4
configuring types	Eng 7-4

naming
Video Mode BNC Fng 7-4
Video Output Board Fng 2-12
Video Output Connections Eng 3-15
Video Processing Specifications Eng 20-17
Video Processor Board Eng 2-13 Eng 2-24 Eng 2-26
functionality Eng 2 35
Video Pouting Eng 2 20
Crosspoint Eng 2 20
Squarza & Taasa Carrier Eng 2 27 Eng 2 28
Video Processor Eng 2.24 Eng 2.26
Video ProcessorEng 2-24, Eng 2-20
Video Server Chip SetupEng 12-17
Video Server Control optionEng 6-18
Video Server, BNC Type, see VIR
Video Servers
clip timecode, grabEng 12-20
custom control functionsEng 10-2
inpoint/outpointEng 12-19
Video system
reference descriptionEng 1-4
Video, Input BNC TypeEng 7-6
Vision 1
control panelEng 2-6
Vision 1M
control panelEng 2-5
Vision 2
control panelEng 2-5
Vision 2M
control panelEng 2-4
Vision 2X
control panelEng 2-3
Vision 3
control panelEng 2-2
Vision 3M
control panel Eng 2-4
Vision 4
control panel Eng 2-2
Vision OS Version Eng 6.14
VISION OS VEISIONElig 0-14
VTR Clip SetupElig 12-17
VTR POL OII-air DisplayEig 11-15
VTR POL Piep a DisplayEng 11-15
VTR Remote Control optionEng 6-18
VTR Timecode, Preview Overlay Setup Eng 12-32
VIR, definition
VIK, Input BNC TypeEng 7-5
V1Ks
custom control functionsEng 10-2
Custom DeviceEng 9-22

#### W

Wait nFields Extra Option	Eng 9-31
Wake Up On Command	Eng 11-7, Eng 11-13
Warnings	Eng 17-11
Status Icons	Eng 17-12
Web Interface	
Account, managing	Eng 6-2
downloading to Frame	Eng 13-15

FrameEng 13-15
storage capacityEng 6-13
system information pageEng 6-12
upgrading the switcherEng 6-4
uploading to FrameEng 13-16
Web IssuesEng 4-9
WorksheetsEng 21-1
Bus MapEng 21-6
CommunicationsEng 21-11
Conversion Loop Eng 21-20
Custom Control Eng 21-18
Custom Device ProtocolEng 21-22
GPI I/Os
Aux Panel Eng 21-15
InputEng 21-13
Output
Video Input Eng 21-2, Eng 21-9

# Х

XFX Extra Effects	Card	Eng 2-29
Xpts Extra Option		Eng 9-29

# Ζ

Z Speed Extra Option	Eng 9-29
Zoom Speed Extra Option	Eng 9-29