

SONY®

DIGITAL VIDEOCASSETTE PLAYER

DVW-A510

DVW-510

DVW-CA510

AUDIO PROGRAM PLAY BOARD

BKDW-507

PARALLEL (50P) INTERFACE KIT

BKDW-509

CONTROL PANEL EXTENSION KIT

BKDW-510

CONTROL PANEL CASE

BKDW-511

Digital BETACAM™

MAINTENANCE MANUAL Part1

1st Edition (Revised 6)

⚠ 警告

このマニュアルは、サービス専用です。

お客様が、このマニュアルに記載された設置や保守、点検、修理などを行うと感電や火災、人身事故につながる可能性があります。

危険をさけるため、サービストレーニングを受けた技術者のみご使用ください。

⚠ WARNING

This manual is intended for qualified service personnel only.

To reduce the risk of electric shock, fire or injury, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so. Refer all servicing to qualified service personnel.

⚠ WARNUNG

Die Anleitung ist nur für qualifiziertes Fachpersonal bestimmt.

Alle Wartungsarbeiten dürfen nur von qualifiziertem Fachpersonal ausgeführt werden. Um die Gefahr eines elektrischen Schlages, Feuergefahr und Verletzungen zu vermeiden, sind bei Wartungsarbeiten strikt die Angaben in der Anleitung zu befolgen. Andere als die angegeben Wartungsarbeiten dürfen nur von Personen ausgeführt werden, die eine spezielle Befähigung dazu besitzen.

⚠ AVERTISSEMENT

Ce manuel est destiné uniquement aux personnes compétentes en charge de l'entretien. Afin de réduire les risques de décharge électrique, d'incendie ou de blessure n'effectuer que les réparations indiquées dans le mode d'emploi à moins d'être qualifié pour en effectuer d'autres. Pour toute réparation faire appel à une personne compétente uniquement.

DVW-A510	Serial No. 10001 and Higher
DVW-510	Serial No. 10001 and Higher
DVW-CA510	Serial No. 10001 and Higher
BKDW-507	Serial No. 10001 and Higher
BKDW-509	Serial No. 10001 and Higher
BKDW-510	
BKDW-511	

TABLE OF CONTENTS

1. SERVICE OVERVIEW

1-1. NOTES ON POWER SUPPLY BLOCK	1-1
1-1-1. Warning on Primary Circuit and Electric Shock	1-1
1-1-2. Notes on Resetting the Circuit Breaker	1-1
1-2. REMOVAL/INSTALLATION OF CABINET	1-1
1-2-1. Cabinet Removal/Installation	1-1
1-2-2. Cassette Compartment Removal/Installation ..	1-2
1-2-3. Connector Panel Removal/Installation	1-2
1-2-4. Power Supply Panel Removal/Installation	1-3
1-3. REMOVAL/INSTALLATION OF PLATE MD	1-4
1-4. FUNCTIONS OF PRINTED CIRCUIT BOARD	1-5
1-5. LOCATIONS OF MAIN PART	1-6
1-5-1. Printed Circuit Board Locations	1-6
1-5-2. Main Mechanical Part Locations	1-8
1-5-3. Function and Location of Sensors	1-9
1-6. LED INDICATOR INFORMATION ON BOARDS	1-10
1-7. MECHANISM OF CASSETTE	1-12
1-8. HOW TO PULL OUT/PUSH IN THE LOWER CONTROL PANEL	1-14
1-9. REMOVAL/INSTALLATION OF LOWER CONTROL PANEL ASSEMBLY	1-14
1-10. HOW TO TAKE OUT THE CASSETTE WHEN THE TAPE IS SLACKING	1-16
1-11. CLEANING WHEN THE HEADS ARE CLOGGED	1-17
1-11-1. Cleaning by Cleaning Tape	1-17
1-11-2. Cleaning by Cleaning Cloth	1-17
1-12. FIXTURE AND MEASURING EQUIPMENT FOR ADJUSTMENT	1-18
1-12-1. Fixture	1-18
1-12-2. Measuring Equipment	1-20
1-13. ERROR LOGGER FUNCTION	1-20
1-14. SAFETY CHECK-OUT	1-21

2. RECORDING FORMAT, HEAD CONFIGURATION, AND SIGNAL PROCESSING

2-1. OUTLINE	2-1
2-2. RECORDING FORMAT	2-2
2-2-1. Tape Pattern	2-2
2-2-2. Data Arrangement on Program Tracks	2-3
2-2-3. Longitudinal Tracks	2-4
2-3. HEAD CONFIGURATION	2-5
2-4. SIGNAL PROCESSING	2-6
2-4-1. Outline of the Digital Interface Format	2-6
2-4-2. Outline of the Digital Signal Processing	2-8
2-4-3. Error Correction Coding	2-9

3. BLOCK DIAGRAMS AND CIRCUIT DESCRIPTIONS

3-1. OVERALL	3-2
OVERALL (1/2)	3-2
OVERALL (2/2)	3-4
3-2. CIRCUIT BLOCK	3-7
EQ-45B	3-7
DPR-36H	3-11
VPR-1B	3-15
APR-1B	3-19
DIF-16B	3-23
CUE-1B	3-27
DM-89	3-30
TBC-24	3-35
TBC-23	3-39
AP-28	3-45
SS-52B (1/3)	3-49
SS-52B (2/3)	3-53
SS-52B (3/3)	3-57
DR-307/200	3-61
FUNCTION CONTROL	3-64
POWER SUPPLY	3-66
3-3. FRAME	3-68
FRAME WIRING (1/3)	3-68
FRAME WIRING (2/3)	3-70
FRAME WIRING (3/3)	3-72

4. ERROR MESSAGES AND TROUBLESHOOTING

4-1. ERROR MESSAGE	4-1
--------------------------	-----

5. MAINTENANCE MODE

5-1. OUTLINE	5-1
5-2. SERVO/DT SYSTEM CHECK MODE	5-5
5-2-1. Servo System Check 1	5-6
5-2-2. Servo System Check 2	5-10
5-2-3. Servo System Check 3	5-16
5-2-4. Servo System Check 4	5-20
5-2-6. Digital DT System Check	5-23
5-2-7. Analog DT System Check (For DVW-A510P/A510)	5-26
5-3. RF SYSTEM CHECK MODE	5-28
5-4. AUDIO/VIDEO SYSTEM CHECK MODE	5-30
5-5. BETACAM PB SYSTEM CHECK MODE (For DVW-A510P/A510)	5-32
5-6. OTHERS CHECK MODE	5-34
5-7. SERVO/DT SYSTEM ADJUSTMENT MODE	5-39
5-7-1. Servo System Adjustment Mode	5-40
5-7-2. Digital DT System Adjustment Mode	5-51
5-7-3. Analog DT System Adjustment Mode (For DVW-A510P/A510)	5-59
5-8. RF SYSTEM ADJUSTMENT MODE	5-64
5-9. AUDIO/VIDEO SYSTEM ADJUSTMENT MODE	5-74
5-10. BETACAM PB SYSTEM ADJUSTMENT MODE (For DVW-A510P/A510)	5-76

6. REPLACEMENT OF POWER BLOCK AND CIRCUIT BOARDS

6-1. GENERAL INFORMATION FOR POWER/BOARDS REPLACEMENT	6-1
6-1-1. Index for Board Replacement	6-1
6-1-2. Plug-in Board Pulling Out/Inserting	6-2
6-1-3. Flexible Card Wire Replacement	6-4
6-2. POWER BLOCK/BOARD REPLACEMENT	6-5
6-3. HOW TO REPLACE BOARDS	6-8
6-3-1. SWC-17 Board	6-8
6-3-2. FP-58 Board	6-11
6-3-3. VR-152 Board	6-15
6-3-4. VR-153 Board	6-20
6-3-5. KY-231 Board	6-25
6-3-6. DP-176 Board	6-26
6-3-7. SWC-18 Board	6-27
6-3-8. SWC-19 Board	6-28
6-3-9. CP-218 Board	6-30
6-3-10. CP-220 Board	6-32
6-3-11. DR-307/200 Board	6-33
6-3-12. DT-34 Board	6-35
6-3-13. HN-181 Board	6-36
6-3-14. HN-184 Board	6-42
6-3-15. HN-185 Board	6-45
6-4. ADJUSTMENT AND CHECK AFTER DIGITAL BOARD REPLACEMENT	6-49
6-4-1. VPR-1 Board	6-49
6-4-2. APR-1 Board	6-59
6-5. ADJUSTMENT AFTER TBC-23 BOARD REPLACEMENT	6-64

7. PERIODIC MAINTENANCE AND INSPECTION

7-1. CLEANING	7-1
7-1-1. General Information for Cleaning	7-1
7-1-2. Rotary Heads Cleaning	7-3
7-1-3. Upper Drum's Tape Running Surface Cleaning	7-4
7-1-4. Lower Drum's Tape Running Surface and Lead Surface Cleaning	7-5
7-1-5. Stationary Heads Cleaning	7-6
7-1-6. Tape Running System and Tape Cleaner Cleaning	7-7
7-1-7. Fan Motor Cleaning	7-8
7-1-8. Cassette Compartment Cleaning	7-9
7-2. PERIODIC CHECK	7-10
7-2-1. Hours Meter	7-10
7-2-2. Periodic Check List	7-11

8. REPLACEMENT OF PERIODIC MAINTENANCE PARTS

8-1. GENERAL INFORMATION FOR PARTS REPLACEMENT AND ADJUSTMENT	8-1
8-1-1. Basic Knowledge	8-1
8-1-2. Threading End Mode and Unthreading End Mode	8-2
8-1-3. L Cassette Position and S Cassette Position	8-4

8-2. PARTS REPLACEMENT	8-7
8-2-1. Inner Drum Assembly Replacement	8-10
8-2-2. Brush/Slip Ring Assembly Replacement	8-24
8-2-3. Drum Assembly Replacement	8-26
8-2-4. Cleaning Roller and Rotary Head Cleaner Assembly Replacement	8-32
8-2-5. AT Head Cleaner Replacement	8-34
8-2-7. Pinch Roller Replacement	8-38
8-2-8. Audio/TC Head Replacement	8-40
8-2-9. CTL Head Replacement	8-44
8-2-10. Capstan Motor Replacement	8-48
8-2-11. Pinch Solenoid Replacement	8-52
8-2-12. Brake Lining Replacement	8-58
8-2-13. Reel Motor Assembly Replacement	8-60
8-2-14. Fan Motor Replacement	8-69
8-2-15. Filter Replacement	8-70
8-3. MECHANICAL ADJUSTMENT	8-71
8-3-1. Pinch Press Clearance Adjustment	8-73
8-3-2. Reel Motor Shaft Slantness Adjustment	8-75
8-3-3. Cassette Pillar Height Adjustment (L Cassette)	8-77(b)
8-3-3. Cassette Pillar Height Adjustment (S Cassette)	8-77(a)
8-3-4. Reel Table Height Adjustment	8-79
8-3-5. Reel Brake Clearance Check	8-83
8-3-6. Reel Brake Release Amount Adjustment	8-85
8-4. TAPE PATH ADJUSTMENT	8-87
8-4-1. Audio/TC Head Zenith Adjustment	8-91
8-4-2. Tape Running Adjustment	8-93
8-4-3. Video Tracking Adjustment	8-97
8-4-4. CTL Head Height Adjustment	8-107
8-4-5. CTL Head Position Adjustment	8-109
8-4-6. Audio/TC Head Height Adjustment	8-113
8-4-7. Audio/TC Head Azimuth Adjustment	8-119
8-4-8. Audio/TC Head-to-tape Contact Adjustment	8-123
8-4-9. Audio/TC Head Position Adjustment	8-129
8-4-10. Audio Level Adjustment in REV Mode	8-131
8-5. SERVO/DT AND RF ADJUSTMENT	8-137
8-5-1. Drum Phase Adjustment	8-141
8-5-2. Digital DT Adjustment	8-142
8-5-3. Analog DT Adjustment	8-143
8-5-4. ADV Envelope Level Adjustment	8-144
8-5-5. Playback Equalizer Adjustment	8-145
8-6. ADJUSTMENT AFTER DRUM REPLACEMENT (For DVW-A500/A510/CA510)	8-151
8-6-1. EQ RF Output Level Adjustment	8-157
8-6-2. DM OMC Limiter Balance Adjustment	8-161
8-6-2 (1). DM OMC Limiter Balance Adjustment (without Spectrum analyzer)	8-164
8-6-3. Demodulator Limiter Balance Adjustment	8-165
8-6-4. PB Frequency Response Adjustment	8-167
8-6-5. DM RF Output Level Adjustment (For board's No. suffix 11,12)	8-169
8-6-6. DM RF Envelope Check	8-172
8-6-7. TBC Y/C Delay Check	8-173
8-6-8. Y and C Error Offset Check	8-175
8-6-9. AFM RF Level Adjustment	8-176

8-7. ADJUSTMENT AFTER AUDIO/ TC HEAD REPLACEMENT	8-177
8-7-1. Audio PB Frequency Response Adjustment (Oxide) (For DVW-A510/CA510)	8-184
8-7-2. AP Board Dolby Level Adjustment (For DVW-A510/CA510)	8-185
8-7-3. LAU PB Level Adjustment (For DVW-A510/CA510)	8-185
8-7-4. LAU PB Phase Adjustment (For DVW-A510/CA510)	8-186
8-7-5. Cue PB Frequency Response Adjustment ...	8-187
8-7-6. Cue PB Level Adjustment	8-188
8-7-7. LTC PB Level Check	8-189

9. SPARE PARTS

9-1. NOTES ON SPARE PARTS	9-1
9-2. SPARE PARTS LIST – VTR –	9-2
9-2-1. Index	9-2
9-2-2. Exploded Views and Mechanical Parts List ...	9-4
Reel Chassis (S Side) Block	9-4
Reel Chassis (T Side) Block	9-6
Drum and Rotary Head Cleaner Block	9-8
S Tension Regulator Block	9-10
CTL Head Block	9-12
Threading Ring and Pinch Roller Block	9-14
AT Head and Capstan Motor Block	9-16
Pinch Press and Gear Box Block	9-18
T Tension Regulator Block	9-20
Cassette Compartment Block	9-22
Printed Circuit Board (Bottom Side) Block	9-24
Ornamental Panel Block	9-26
Upper Control Panel Block	9-28
Lower Control Panel Block	9-30
Sub Control Panel Block	9-32
Connector Panel Block	9-34
Chassis Block	9-36
9-2-3. Mounted Circuit Board List	9-38
9-2-4. Packing Materials and Supplied Accessories List	9-41
9-3. SPARE PARTS LIST – OPTIONAL ACCESSORIES –	9-42
9-3-1. Index	9-42
9-3-2. BKDW-509	9-43
9-3-3. BKDW-510	9-44
9-3-4. BKDW-511	9-45
9-4. SPARE PARTS LIST	9-46

Manual Structure

Purpose of this manual

This manual is the maintenance manual of digital videocassette player DVW-A510/510 and DVW-CA510.

This manual describes the maintenance information of this unit, and the information on primary services such as the replacement of main blocks and circuit boards.

Contents

The following is a summary of all the sections for understanding the contents of this manual.

Section 1 SERVICE OVERVIEW

Explains the locations of main part, the functions of printed circuit board, the removal and installation of cabinet, and the measures against trouble.

Section 2 RECORDING FORMAT, HEAD CONFIGURATION, AND SIGNAL PROCESSING

Explains the recording format, head configuration, and signal processing.

Section 3 BLOCK DIAGRAMS AND CIRCUIT DESCRIPTIONS

Describes the overall block diagrams, the block diagrams for every circuit block, the frame wiring, and the circuit descriptions.

Section 4 ERROR MESSAGES AND TROUBLESHOOTING

Explains the error messages and troubleshooting.

Section 5 MAINTENANCE MODE

Explains the maintenance mode of this unit.

Section 6 REPLACEMENT OF POWER BLOCK AND CIRCUIT BOARDS

Explains how to replace the power block and circuit boards, and how to adjust them after replacement.

Section 7 PERIODIC MAINTENANCE AND INSPECTION

Explains the cleaning procedure and periodic check.

Section 8 REPLACEMENT OF PERIODIC MAINTENANCE PARTS

Explains how to replace the parts that should be replaced periodically and how to adjust them after replacement.

Section 9 SPARE PARTS

Describes the exploded views for the main unit and optional accessories, mounted circuit boards list, packing materials list, and standard accessories list.

(continue)

Contents (continued)

DVW-CA510

Contains the exclusive information of DVW-CA510.

Please replace or add the corresponding pages from Section 1 to 9 with them .

Note

Some figures in this manual are drawn as the recorder. Please understand in advance.

Relative manual

Besides this “Maintenance Manual Part 1”, the following manuals are available for this unit.

- **Operation Manual (Supplied with this unit.)**

This manual is necessary for application and operation of this unit.

- **Installation Manual (Supplied with this unit.)**

This manual describes the items that are required to install this unit.

- **Maintenance Manual Part 2 (Not supplied with this unit.)**

This manual describes the information items (adjustments, board layouts, schematic diagrams, detailed parts list, etc.) that premise the service based on parts. If this manual is required, please contact to Sony’s service organization.

- **Protocol Manual (Not supplied with this unit.)**

PROTOCOL OF REMOTE-1 (9-Pin) CONNECTOR

This manual explains the protocol for controlling this unit via the RS-422A (9-pin serial remote).

If this manual is required, please contact to Sony’s service organization.

SECTION 1 SERVICE OVERVIEW

1-1. NOTES ON POWER SUPPLY BLOCK

1-1-1. Warning on Primary Circuit and Electric Shock

The power supply block consists of the AC-155 board and primary peripheral components. The whole AC-155 board is on the primary side circuit, so pay careful attention to the electric shock. Since the inside of a switching regulator is also on the primary side circuit, treat it with care.

1-1-2. Notes on Resetting the Circuit Breaker

When the breaker on the power supply panel is activated and the button is ejected, remove the cause of the trouble, then push the button.

1-2. REMOVAL/INSTALLATION OF CABINET


1-2-1. Cabinet Removal/Installation

CAUTION

Always switch off the POWER before removing and installing cabinet.


Upper Control Panel

1. Remove the upper lid.
2. Remove the six control knobs on an upper control panel.
3. Remove the each one screw on the left and right sides.
4. Fingers should be inserted in the space between the upper control panel and chassis, and remove the upper control panel as shown in the figure A.



<Fig. A>

5. When installing, insert the projections of the upper control panel into the holes of the chassis, then fix the panel with the screws as shown in the figure B.



<Fig. B>

Left Side Panel


1. Remove four screws, and remove the handle.
2. Remove four screws and remove the left side panel.

Upper Lid

Loosen three fixing screws, and remove the upper lid by moving in the direction indicated by the arrow.

Right Side Panel

1. Remove four screws, and remove the handle.
2. Remove four screws and remove the right side panel.



Lower Control Panel

1. Remove the lower control panel assembly from the unit. (Refer to section 1-9. Removal/Installation of Lower Control Panel Assembly)
2. Remove five screws on the top and bottom of the lower control panel assembly, then remove the panel.


Bottom Plate

Put the unit on its right side down, remove six screws and remove the bottom plate.

1-2-2. Cassette Compartment Removal/Installation

Removal

1. Press the EJECT button with the power on.
2. Turn off the POWER.
3. Remove the upper lid.
(Refer to section 1-2-1. Cabinet Removal/Installation)
4. Remove the plate MD assembly. (Refer to Section 1-3. Removal/Installation of Plate MD)
5. Loosen two screws, and remove the cassette compartment bracket assembly.
6. Disconnect the connector (CN930) on the CL-29 board.




Removal of the Bracket Assembly

7. Remove the four legs of the Cassette Compartment for fixing the position by lifting the Cassette Compartment slightly and straight with (A) portions (two portions) held.
8. Remove the Cassette Compartment by sliding up it raising up the rear part with the (B) portion held as shown in the figure.

NOTE

In this time, do not move the Cassette Compartment to right and left and do not widen the right and left side panels. If the right and left side panels are widened, a gear position might be changed or some parts might be removed.




Removal of the Cassette Compartment

9. When the Cassette Compartment is put away from the unit after removing, put it in the direction as shown in the figure (If it is put with the cassette lid at the bottom, the flexible card wire might be damaged.)

Installation

10. Set the harness of the connector (CN930) disconnected in step 5 so it is not put between chassis.
11. Install the cassette compartment inserting slantingly in the direction as shown in the figure.
12. Insert the four legs of the Cassette Compartment for fixing the position into the four holes of the mechanical chassis for fixing the position by pressing the (C) portions (two portions) as shown in the figure.
13. After confirming that the cassette compartment is fixed to the chassis, install the cassette compartment bracket assembly.
14. Connect the connector (CN930) on the CL-29 board.




Installation of the Cassette Compartment

10. Set the harness of the connector (CN930) disconnected in step 6 so it is not put between chassis.


1-2-3. Connector Panel Removal/Installation

1. Turn off the POWER.
2. Remove six screws indicated → at the top and bottom on the connector panel.



Removal of Screws


3. Remove the connector panel so as not to stretch the harness as shown in the figure.
4. Install the connector panel in the reverse order of steps 1 through 3.



Removal of the Connector Panel


1-2-4. Power Supply Panel Removal/Installation

1. Turn off the POWER.
2. Remove two screws, and open the power supply panel.



Removal of the Power Supply Panel

3. Remove a screw and a spring washer which secure the ground terminal, then disconnect connector (CN002) on the AC-155 board, then remove the power supply panel.
4. Install the power supply panel in the reverse order of steps 1 through 3.




Disconnecting the Connector

1-3. REMOVAL/INSTALLATION OF PLATE MD

Removal

1. Remove the upper lid. (Refer to 1-2. Removal/Installation of Cabinet.)
2. Slide the knobs of the plate MD each in the direction indicated by the arrows (inside).



Sliding of the Knob Positions


3. Remove the plate MD.

Installation

4. Insert the plate MD into the clearance shown in the figure.


NOTE

Be careful not to put the harness under the plate MD in this case.



Removal/Installation of Plate MD

5. Slide the knobs of the plate MD each in the direction indicated by the arrows (outside), then fix.
6. Install the upper lid.



Fixing of the Plate MD

1-4. FUNCTIONS OF PRINTED CIRCUIT BOARD

The numbers in left columns of the board name are in common with the numbers of Section 1-5-1. Printed Circuit Board Locations.

No.	Board Name	Circuit Function	System Configuration
1	DIF-16	4:2:2 Component Serial Digital Interface with Embedded Audio	Digital Process
2	VPR-1	Video Signal Processor, D/A, HUE, GAIN Ref CK Generator, Composite Encoder	
3	DPR-36	Digital Data Processor (Decode, Error Correction)	
4	APR-1	Audio Signal Processor (D/A, AES/EBU I/F)	RF/Analog Process
5	EQ-45BA (DVW-A510)	PB RF Equalizer, Analog Betacam PB Buff	
	EQ-45B (DVW-510)	PB RF Equalizer	
6	CUE-1BA (DVW-A510)	CUE, TC/PB & LAU PB Circuit	
	CUE-1B (DVW-510)	CUE, TC/PB Circuit	
7	AP-28 (DVW-A510)	AFM Demodulator & LAU Noise Reduction for Analog Betacam (PB)	Analog Betacam Playback
8	DM-89 (DVW-A510)	RF Demodulator for Analog Betacam (PB)	
9	TBC-24 (DVW-A510)	TBC (A/D Conversion & Write Clock Gen. Blocks)	
10	TBC-23 (DVW-A510)	TBC (Sequence & Reference Block)	
12	AC-155	AC Connector Board with Breaker	Power
13	SW REG	Switching Regulator	
14	HN-181	Connection Board (Drum, etc)	Connection
15	HN-185	Connection Board with Dew Sensor	
16	HN-184	Connection Board (Threading Motor,etc)	
17	SS-52	System, Servo, DT Control	System/Servo Control
18	DR-307/200	Motors (Drum, Reel, Capstan, etc) Driver, Solenoids Driver	
19	DT-34	DT Driver	

No.	Board Name	Circuit Function	System Configuration
20	FP-58	Panel Function (SWs, LEDs) Control, CAV Control Level Conversion	Front Panel Function
21	VR-152	Phone level RV, Phone connector	
22	VR-153	Audio PB Level VRs	
23	SWC-17	Upper Panel Function (Switches, LEDs)	
24	SWC-18	Sub Control Panel Function	
25	SWC-19	System Set-up Panel Function Control	
26	KY-231	Lower Panel Function Control	
27	DP-176	Time Counter Display	
28	PTC-69	Search Dial Sensor	Rear Panel Function
29	CP-218	Rear Panel Connector Board (Analog Video Signal Buffer)	
30	CP-220	Rear Panel Connector Board (Analog/Digital Audio,TC)	
31	RM-130	Parallel (50P) Interface (optional accessory BKDW-509)	Option
32	MB-441	Mother Board	Other
33	PTC-54	Threading FG	
34	CCM-15	Threading Motor/Reel Shift Motor	
35	TR-79	T Tension Sensor,Thread/Unthread End Sensor	
36	PTC-59	Cassette's Holes Sensor	
37	RM-141	T Reel Motor	
38	RM-82	S Reel Motor	
39	SE-228	Reel FG	
40	PTC-71	Reel Position Sensor	
41	TR-78	S Tension Sensor	
42	PD-35	Pinch Solenoid Connection	
43	CL-29	Cassette Up/Down Motor, Cassette Down Sensor	Cassette Compartment Driver/Sensor
44	LP-81	Lamp of Cassette Compartment	
45	PC-70	Cassette In Sensor, Cassette Size Sensor	


1-5. LOCATIONS OF MAIN PART

1-5-1. Printed Circuit Board Locations


The numbers in the figures are in common with the numbers in Section 1-4. Functions of Printed Circuit Board.

INDEX


AC-155	⑫
AP-28	⑦
APR-1	④
CCM-15	③④
CL-29	④③
CP-218	②⑨
CP-220	③⑩
CUE-1B/BA	⑥
DIF-16	①
DM-89	⑧
DP-176	②⑦
DPR-36	③
DR-307/200	①⑧
DT-34	①⑨
EQ-45B/BA	⑤
FP-58	②⑩
HN-181	①④
HN-184	①⑥
HN-185	①⑤
KY-231	②⑥
LP-81	④④
MB-441	③②
PC-70	④⑤
PD-35	④②
PTC-54	③③
PTC-59	③⑥
PTC-69	②⑧
PTC-71	④④
RM-130	③①
RM-141	③⑦
RM-82	③⑧
SE-228	③⑨
SS-52	①⑦
SW REG	①③
SWC-17	②③
SWC-18	②④
SWC-19	②⑤
TBC-23	①⑩
TBC-24	①⑨
TR-78	④①
TR-79	③⑤
VPR-1	②
VR-152	②①
VR-153	②②




<Top view>




<Bottom view>




<Front view>



<Rear view>




<Top view>



<Top view of cassette compartment>



1-5-2. Main Mechanical Part Locations



INDEX

- | | |
|---------------------------|---------------------------|
| ① Audio/TC head | ⑭ T worm wheel |
| ② TG-3 tape guide | ⑮ Worm gear |
| ③ Head drum | ⑯ Drive gear |
| ④ Threading ring | ⑰ S worm wheel |
| ⑤ T tension regulator arm | ⑱ S brake assembly |
| ⑥ CTL head | ⑲ S reel table |
| ⑦ TG-2 tape guide | ⑳ S tension regulator arm |
| ⑧ Audio/TC head cleaner | ㉑ TG-0 tape guide |
| ⑨ T drawer arm | ㉒ Capstan shaft |
| ⑩ TG-10 tape guide | ㉓ Cleaning roller block |
| ⑪ Pinch roller | ㉔ Pinch press block |
| ⑫ T reel table | ㉕ TG-4 tape guide |
| ⑬ T brake assembly | ㉖ Threading gear block |

1-5-3. Function and Location of Sensors





- ① **Threading motor rotation sensor**
The threading motor rotation sensor detects the rotation speed of the threading motor.
The FG output signal of this detection sensor is input to the servo circuit to control the threading speed so that the tape is not damaged during threading and unthreading.
- ② **Threading-end/unthreading-end sensor**
This sensor detects whether the threading ring reaches the threading-end or unthreading-end position.
- ③ **T tension regulator arm sensor**
During recording and playback, this sensor detects the tension arm position and controls the reel torque to keep a constant T tape tension.
- ④ **Condensation sensor**
This sensor detects whether the dew condensation occurs in the unit.
- ⑤ **Tape top sensor**
This sensor detects the top of the tape, and in addition detects the tape end of the tape that runs in the reverse direction.
- ⑥ **Reel hub diameter sensor**
The reel hub diameter of a cassette tape varies depending on the length of the tape wound on the cassette tape. The reel hub diameter sensor detects the reel hub diameter using a tub on the back side of the cassette tape. The output signal of this sensor is input to the servo circuit to control the rotation speed and torque of the reel motor.
- ⑦ **Metal tape sensor**
Using a tub on the back side of the cassette tape, this sensor detects whether an oxide tape or metal tape is being inserted into the unit. (Only during analog tape playback)
- ⑧ **Tape thickness sensor**
Using a tub on the back side of the cassette tape, this sensor detects the thickness of the tape wound on a cassette tape that is being inserted into the unit.
- ⑨ **Analog/digital tape sensor**
Using a tub on the back side of the cassette tape, this sensor detects whether an analog tape or digital tape is being inserted into the unit.
- ⑩ **T reel table rotation sensor**
This sensor detects the rotation of the take-up reel table. The FG output signal of this sensor is input to the servo circuit to control the rotation speed of the reel motor.
- ⑪ **S reel table rotation sensor**
This sensor detects the rotation of the supply reel table. The FG output signal of this sensor is input to the servo circuit to control the rotation speed of the reel motor.
- ⑫ **Reel L/S position sensor**
This sensor detects whether the reel table moves to the correct position according to the size of the inserted cassette tape.
- ⑬ **S tension regulator arm sensor**
During recording and playback, this sensor detects the tension arm position and controls the reel torque to keep a constant S tape tension.
- ⑭ **Tape end sensor**
This sensor detects the end of the tape that runs in the forward direction.
- ⑮ **Cassette-in sensor (L)**
This sensor detects whether a cassette is being inserted.
- ⑯ **Cassette L/S size sensor**
This sensor detects whether the inserted cassette tape is an L size or S size.
- ⑰ **Cassette-in sensor (R)**
This sensor detects whether a cassette is being inserted.
- ⑱ **Cassette-down (2) sensor**
- ⑲ **Cassette-down (1) sensor**
The cassette-down (1) sensor detects the movement of the cassette compartment through combined ON/OFF operation of the cassette-down (2) sensor, the cassette-down (1) sensor, and a cassette-in sensor.

1-6. LED INDICATOR INFORMATION ON BOARDS

Lot No. 907 and higher

DVW-A510 (UC): S/N 11514 and higher
DVW-510 (UC): S/N 10758 and higher
DVW-A510 (J): S/N 10685 and higher
DVW-510 (J): S/N 10101 and higher
DVW-CA510 (UC): S/N 10016 and higher
DVW-CA510 (J): S/N 10002 and higher

DVW-A510 (UC): S/N 10001 through 11513
DVW-510 (UC): S/N 10001 through 10757
DVW-A510 (J): S/N 10001 through 10684
DVW-510 (J): S/N 10001 through 10100
DVW-CA510 (UC): S/N 10001 through 10015
DVW-CA510 (J): S/N 10001



DIF-16 Board

LED No.	Name	Color	Description	Normal State
D100	DIF TEST YP	Red	Lights when the Y PARITY test mode is executed in the maintenance mode.	Goes off
D101	PARA IN P ERROR	Red	Lights when an error occurs in the video signal that is sent from VPR board to DIF board.	Goes off
D102	TX625/525	Green	Indicates the state of 4: 2: 2 component serial digital interface output. This state is set 625/50 by C.P.U BUS CONTROL.	Goes off
*D507	ENC1 ADJUST	Green	Lights when the VCO frequency is almost 27 MHz adjusting the D1 ENC1 VCO in the maintenance mode A23 : DIF VR.	Unsettled
*D508	ENC2 ADJUST	Green	Lights when the VCO frequency is almost 27 MHz adjusting the D1 ENC2 VCO in the maintenance mode A23 : DIF VR.	Unsettled

SS-52 Board

LED No.	Name	Color	Description	Normal State
D300	—	—	Unused	—
D301	SYS 1	Amber	Blinks during SYS 1 V25 CPU normal operation.	Blinks
D601	SYS 2	Amber	Blinks during SYS 2 Z80 CPU normal operation.	Blinks
D711	SV	Amber	Checks the ROM and RAM for communication when the power switch is set to ON. Lights for scores ms at intervals 1 to 2 seconds. (For the blinking pattern when abnormality occurred, refer to the figure shown right.)	Blinks
D800	DRUM	Amber	Blinks during drum microcomputer normal operation. Usually lights for 30 msecond at intervals of about one second. The blinking interval is inverted when the drum is locked.	Blinks
D2109	DT	Amber	Blinks during DT microcomputer FMC-16 CPU normal operation.	Blinks

APR-1 Board

LED No.	Name	Color	Description	Normal State
D51	APR 1	Amber **Red	Blinks during APR 1 microcomputer normal operation (when a 1/2VD signal is received from the SS-52 board).	Blinks

DM-89 Board (for DVW-A510)






LED No.	Name	Color	Description	Normal State
D902	ADJUST	Amber	Usually lights for about 10 msecond at intervals of about one second. The blinking interval is inverted when the unit is in the adjustment mode (when switch S901-1 is set to ON).	Blinks

TBC-23 Board (for DVW-A510)

LED No.	Name	Color	Description	Normal State
D200	TBC	Amber	Lights once a second during TBC microcomputer normal operation.	Blinks

* : Lot No. 907 and higher
** : Lot No. 910 and higher


<Blinking Pattern of D711 on SS-51 Board>



1-7. MECHANISM OF CASSETTE


As shown in the figure below, plugs and tabs are provided at the back side of the cassette tape.

Analog cassette tape



- ① S cassette REC inhibit tab (for oxide tape)
- ② Video tape thickness detection tab
- ③ Metal tape detection tab
- ④ Reel hub diameter detection tab
- ⑤ S cassette REC inhibit plug (for metal particle tape)
- ⑥ L cassette REC inhibit plug

Digital cassette tape



- ⑦ S cassette analog REC inhibit plug (originally open)
- ⑧ Video tape thickness detection tab
- ⑨ SPARE ID
- ⑩ Digital tape detection hole
- ⑪ SPARE ID
- ⑫ Reel hub diameter detection tab
- ⑬ S cassette digital REC inhibit plug
- ⑭ L cassette digital REC inhibit plug
- ⑮ L cassette analog REC inhibit plug (originally open)




Fig 1.




Fig 2.

The presence or absence of these plugs and tabs determines the cassette status as shown in the table below.

Analog cassette tape

No.	Plug and tab	Cassette status with or without plugs and tabs	
		With plugs and tabs	Without plugs and tabs
①	S cassette REC inhibit tab (for oxide tape)	Can be recorded (refer to Fig. 1).	Cannot be recorded (refer to Fig. 2).
②	Video tape thickness detection tab	A 20 μm thick tape is wound on the cassette.	A 15 μm thick tape is wound on the cassette.
③	Metal tape detection tab	An oxide tape is wound on the cassette.	A metal tape is wound on the cassette.
④	Reel hub diameter detection tab	For small hub	For large hub
⑤	S cassette REC inhibit plug (for metal particle tape)	Can be recorded (refer to Fig. 1).	Cannot be recorded (refer to Fig. 2).
⑥	L cassette REC inhibit plug		

Digital cassette tape

No.	PLUG AND TAB	CASSETTE STATUS WITH OR WITHOUT PLUGS AND TABS	
		WITH PLUGS AND TABS	WITHOUT PLUGS AND TABS
⑦	S cassette analog REC inhibit plug (originally open)	_____	Analog signals cannot be recorded.
⑧	Video tape thickness detection tab	_____	A 14 μm thick tape is wound on the cassette.
⑨	SPARE ID	_____	_____
⑩	Digital tape detection hole	An analog tape is wound on the cassette.	A digital tape is wound on the cassette.
⑪	SPARE ID	_____	_____
⑫	Reel hub diameter detection tab	For small hub	For large hub
⑬	S cassette digital REC inhibit plug	Can be recorded (refer to Fig. 1).	Cannot be recorded (refer to Fig. 2).
⑭	L cassette digital REC inhibit plug	Can be recorded (refer to Fig. 1).	Cannot be recorded (refer to Fig. 2).
⑮	L cassette analog REC inhibit plug (originally open)	_____	Analog signals cannot be recorded.

1-8. HOW TO PULL OUT/PUSH IN THE LOWER CONTROL PANEL

1. Take both side handles of a lower control panel and pull them slightly forward. Pull them more strongly, then the lower control panel is fixed.
2. Lift the lower control panel. The panel can be moves maximum 90 degrees.


NOTE

The lower control panel can be tilted up to 90 degrees by approximately 15 degree step. When using the lower control panel on the tilt, turn the knobs clockwise to hold the panel firmly.

3. When put back the panel assembly in the unit, replace it horizontally to the front side of the unit and then push it in the unit.

NOTE

Put back the panel assembly in the unit surely after using the unit.




Pulling out/Pushing in the Lower Control Panel

1-9. REMOVAL/INSTALLATION OF LOWER CONTROL PANEL ASSEMBLY


Removal

1. Fix a lower control panel at 90 degrees.
(Refer to Sec. 1-8. How to Pull out/Push in Lower Control Panel.)
2. Disconnect the connector (CN580) on the system set-up panel.
3. Loosen the two black screws on the lower control panel assembly. (Loosen the screws until screw's top are exposed from the lack of the lower control panel assembly.)



Disconnecting the Connector


4. While pushing the loosen black screws in the direction of the arrow, remove the lower control panel assembly from the arms.



Removal of the Panel Assembly

Installation

5. Connect the harness of the panel assembly to the connector (CN580) on the system set-up panel.
6. Fix the arms at 45 degrees.
7. Set the notches of the panel assembly to the claws of the arms and insert the panel assembly until making a click sound. Then fix the assembly with the two screws.
8. When putting back the panel assembly in the unit, replace it horizontally to the front side of the unit and then push it in the unit.



Installation of the Panel Assembly

1-10. HOW TO TAKE OUT THE CASSETTE WHEN THE TAPE IS SLACKING

When the tape is slacked in the VTR, take out the cassette tape in the procedure below while taking care not to damage the tape.

1. Turn off the POWER.
2. Remove the upper lid.
(Refer to Section 1-2. Removal/Installation of Cabinet.)
3. Remove the plate MD.
(Refer to Section 1-3. Removal/Installation of Plate MD.)
4. Rotate the rotation detection pulley of the threading motor block in the direction of the arrow with fingers by about a half turn and slacken the tape.
5. Shift the ME lever toward the front panel and wind the tape inside the cassette.


NOTE

Do not shift the ME lever during normal operation (during reel table operation).


Repeat steps 4 and 5 until the unit is put into the unthreading-end state and until the tape is wound completely.

6. Fix the lower control panel assembly at the position of 90 degrees.
(Refer to Section 1-8. How to Pull out/Push in Lower Control Panel.)

7. Turn the yellow pulley of the cassette compartment motor shown in the figure clockwise until the cassette tape is ejected completely.



Winding of a Tape



Ejection of a Cassette Tape

1-11. CLEANING WHEN THE HEADS ARE CLOGGED

If the video heads are clogged, clean the heads as the following procedure.
If the video heads are clogged after cleaning by cleaning tape, clean them by cleaning piece.

1-11-1. Cleaning by Cleaning Tape

NOTE

Make sure to use the cleaning tape BCT-5CLN. If the cleaning is performed by other cleaning tape, not the BCT-5CLN, unusual friction or damage of the video head may occur.

1. Insert the cleaning tape BCT-5CLN in the unit.
2. Press the EJECT button simultaneously with PLAY button.
Head cleaning starts.
3. After 5 seconds, the cleaning tape will be ejected automatically.

NOTE

Be sure to eject the cleaning tape after cleaning to avoid damages to the heads.

4. Confirm that the head clog is clear.

1-11-2. Cleaning by Cleaning Cloth

Caution

- Turn the power off before cleaning.
- Each block in the mechanical deck consists of a precision part and is adjusted precisely. Be careful not to damage each part and to apply an excessive force during cleaning.
- Do not touch the greased portions during cleaning. If grease attaches to a cleaning cloth, replace the cleaning cloth by new one. If a cleaning cloth smeared with grease is used, grease may attach to the places where it should not.
- Do not insert a cassette tape before a cleaning fluid completely evaporates after cleaning.

Tools

- Cleaning cloth: 3-184-527-01
- Cleaning fluid: 9-919-573-01

Caution

Do not use a cotton swab to clean the rotary heads.

Procedures

1. Turn the power off.
2. Remove the upper lid.
(Refer to Section 1-2-1.)
3. Remove the plate MD.
(Refer to Section 1-3.)
4. Remove the cassette compartment.
(Refer to Section 1-2-2.)
5. Loosen the two screws and remove the upper drum cover.

NOTE

These screws cannot be removed because of stoppers.


6. Press the cleaning cloth moistened with cleaning fluid slightly against the rotary heads.
7. Rotate the inner drum slowly counterclockwise two or three turns and clean the rotary heads.

Caution


Be sure to rotate the inner drum counterclockwise and clean the rotary heads along the circumference. Do not rotate the inner drum in the direction opposite to the specified direction (clockwise) or clean it in the vertical direction. This may damage the rotary heads.

8. After cleaning, wipe it with a dry cleaning cloth two or three times.
9. Tighten the two screws while pressing the upper drum cover towards the drum support direction.

Tightening torque: $14.7 \times 10^{-2} \text{ N} \cdot \text{m}$ (1.5 Kg $\cdot$ cm)



Cleaning by Cleaning Cloth





Removal/Installation of Upper Drum Cover

1-12. FIXTURE AND MEASURING EQUIPMENT FOR ADJUSTMENT

1-12-1. Fixture

Fig. No.	Part No.	Description	Inscription No.	For use
1	J-6001-820-A	Drum Eccentricity Gauge (3)	_____	Inner drum eccentricity adjustment
2	J-6001-830-A	Drum Eccentricity Gauge (2)	_____	
3	J-6001-840-A or J-6325-530-A	Drum Eccentricity Gauge (1) or Drum Eccentricity Gauge (6)	_____	
4	J-6087-000-A	Drum Eccentricity Gauge (5)	_____	
5	J-6324-030-A	Drum Eccentricity Gauge (7)	MW-403	
6	J-6035-070-A	Extraction Tool (for PLCC socket)	_____	Extraction of IC (PLCC type)
7	J-6080-029-A	Small Dental Mirror (Round type ϕ 12)	_____	Cassette pillar height adjustment
8	J-6086-570-A	Reference Flat Plate	SL-657	Audio/TC head zenith adjustment
9	J-6152-450-A	Wire Clearance Check Gauge Set	_____	Clearance check
10	J-6251-090-A	Torque screwdriver's hexagonal bit (d=2.5 mm, l=120 mm)	_____	Tightening screws to fix a drum assembly and inner drum assembly
	J-6323-440-A	Torque screwdriver's hexagonal bit (d=0.89 mm, l=50 mm)	_____	Tightening screws to fix a tension regulator roller
	J-6323-500-A	Torque screwdriver's hexagonal bit (d=2 mm, l=75 mm)	_____	Tightening screws to fix a reel FG sensor
11	J-6323-420-A	Torque screwdriver's bit (+ 2 mm, l=75 mm)	_____	Tightening screws to fix a brush/slip ring assembly
	J-6323-430-A	Torque screwdriver's bit (+ 3 mm, l=90 mm)	_____	Tightening screws to fix a reel motor assembly or a ring roller
12	J-6252-510-A	Torque screwdriver (6 kg•cm)	JB-5251	Tightening screws
	J-6252-520-A	Torque screwdriver (12 kg•cm)	JB-5252	Tightening screws
13	J-6269-800-A	Extension Board (L), EX-365	_____	Large-sized printed circuit board for check and adjustment
14	J-6269-810-A	Extension Board (S), EX-377	_____	Small-sized printed circuit board for check and adjustment
15	J-6320-870-A	Reel Motor Shaft Slantness Check Fixture	MW-087	Reel motor shaft slantness adjustment
16	J-6320-880-A	Cassette Reference Plate (L)	MW-088	Reel table height adjustment, Reel motor shaft slantness adjustment
17	J-6322-610-A	Tape Guide Adjustment Driver	MW-261	Tape path alignment
18	J-6329-350-A	Reel Table Height Gauge	MW-935	Reel table height adjustment
19	J-6420-320-A	Extension Cable Set	_____	Extension of the Switching regulator
20	1-952-684-11	Extension Cable (14 P)	_____	Repair of the TBC-23/24 boards

Fig. No.	Part No.	Description	Inscription No.	For use
21	3-184-527-01	Cleaning Cloth (15 cm × 15 cm)	_____	Cleaning
22	7-432-114-11	Locking Compound 200 g	_____	Inhibits loosening of screws.
23	7-661-018-18	Diamond Oil NT-68 50 ml	_____	
24	7-651-000-10	Sony Grease (SGL-601) 50 g	_____	
25	7-700-736-01	L-shaped Hexagonal Wrench (d: 1.27 mm)	_____	
	7-700-736-05	L-shaped Hexagonal Wrench (d=1.5 mm)	_____	
	7-700-736-06	L-shaped Hexagonal Wrench (d=0.9 mm)	_____	
26	7-700-766-04	Hexagonal Wrench Driver (d=2.5 mm)	_____	
27	8-960-073-01	Alignment Tape, ZR5-1	_____	Digital Video and Audio alignments
	8-960-073-11	Alignment Tape, ZR2-1	_____	Tracking adjustments (for digital)
28	8-960-096-41	Alignment Tape, CR5-1B (metal particle tape)	_____	Analog Video alignments (DVW-A500/A510 only)
	8-960-097-44	Alignment Tape, CR5-2A (oxide tape)	_____	Analog Video alignments (DVW-A500/A510 only)
	8-960-097-45	Alignment Tape, CR8-1A (oxide tape)	_____	Analog Audio alignments (DVW-A500/A510 only)
29	9-911-053-00	Thickness Gauge	_____	Clearance check
30	9-919-573-01	Cleaning Liquid	_____	Cleaning
31	J-6530-760-A	TG-0 Adjustment Fixture	DF-076	TG-0 Adjustment



1-12-2. MEASURING EQUIPMENT

It is recommended to use the measuring equipments listed below or the equivalents.
Each equipment is available as a standard product.

Equipment	Model Name	Remarks
Analog Composite Signal Generator	SONY TEKTRONIX 1410	for VPR-1 board alignment
	SONY TEKTRONIX TSG-170A	
Analog Component Signal Generator	SONY TEKTRONIX TSG-300 or TSG-370	for generating SMPTE/EBU format analog signals
Digital Component Signal Generator	SONY TEKTRONIX TSG-422(OP.1S)	for generating 4:2:2 format digital signals
Spectrum Analyzer	ADVANTEST R3261A	with external trigger function bandwidth: more than 100 MHz
Oscilloscope	SONY TEKTRONIX 2465B	
Component/Composite Wave Form Monitor	SONY TEKTRONIX WFM 300A	for measuring video levels
Wave Form/Vector Monitor	SONY TEKTRONIX 1750 or 1780R	for measuring analog composite SCH
Audio Level Meter	HEWLETT PACKARD HP3400A	
Audio Analyzer	SONY TEKTRONIX AA501A(OP.02)	for measuring distortion and levels
Audio Generator	SONY TEKTRONIX SG505(OP.02)	
Frequency Counter	ADVANTEST TR5821AK	
Digital Voltmeter	ADVANTEST TR6845	
Monitor with Serial Digital Input	SONY BVM-1410 (with optional accessoy BKM-2085-14)	
Network Analyzer	ANRITSU MS-420B	
DA Converter Board (D-1)	SONY BKPF-102CA	for VPR-1 board alignment
Digital Video Interface Unit	SONY PFV-D50/D100/D200	for VPR-1 board alignment


1-13. ERROR LOGGER FUNCTION

- CH COND RED (Channel Condition Red)
When the red CHANNEL CONDITION Lamp on the upper control panel lights;
- REF ALARM (Reference Alarm)
When a reference signal is missing (no signal is input to the INPUT REF VIDEO connector)
- TAPE EJECT
When the cassette tape is ejected;
(If no error is occured from when the cassette tape was ejected last time until it is ejected this time, the preceding time code is overwritten by this time code.)
- ERROR-xx
When a trouble is detected;
(The corresponding error code is recorded.)

When any one of the conditions mentioned above occurs, the corresponding message and time code are stored. After the power switch is turned on, the error logger function always monitors the unit to detect the errors. The contents of these data items can be read and checked in the form of a list.

Error Logger Screen

To enter the error logger screen, press the MENU button while pressing and holding the ENTRY button on the lower control panel.
The error logger data is superimposed on the monitor screen (output to the VIDEO OUTPUT COMPOSITE 3 connector or SERIAL V/A OUTPUT 4 connector). Moreover, the time counter on the lower control panel displays the error logger data by only the number of storage error times.
A maximum of 99 error data items can be stored. To display the error data items that are not displayed on the screen, turn the search dial to scroll up them. When 99 data items are exceeded, the old data is erased and the data sequence is advanced.
To exit the error logger screen, press the MENU button on the lower control panel.





Tape Operation during Error Logger Screen Display

With the error logger screen displayed, press the SET button on the lower control panel to display a block sign on the monitor screen. This enables the tape operation.
To return to the error logger screen, press the MENU button on the lower control panel.

Error Logger Data Erasure

To erase the error logger data, press the RESET button on the lower control panel in the error logger screen display.



1-14. SAFETY CHECK-OUT


After correcting the original service problem, perform the following safety checks before releasing the unit to the customer:

Check the metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.

LEAKAGE TEST

AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis must not exceed 3.5 mA. Leakage current can be measured by any one of three methods.

- (1) A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
- (2) A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
- (3) Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 5.25V; therefore, analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 20V AC range are suitable. (Refer to Fig. A)



RECORDING FORMAT, HEAD CONFIGURATION, AND SIGNAL PROCESSING**2-1. OUTLINE**

This Sony DVW series VTR is a 1/2-inch component digital VTR which uses a new "Digital Betacam" format.

This "Digital Betacam" format has been developed as the digital version of the analog Betacam format that has been now accepted as a standard in the broadcasting, production, and Electronic News Gathering (ENG) fields of the world.

That is, the Digital Betacam VTR can perform high-performance digital recording and playback while keeping the playback compatibility of the conventional analog Betacam tape, and has almost the same operation performance as in the conventional analog Betacam VTR.

To perform such a workhorse VTR, a new bit rate reduction format (i.e., coefficient recording) has been developed. The data rate is compressed into approximately 1/2, and compressed data is recorded on tape. Moreover, the introduction of a high-performance, high-precision heads and drum, and a new automatic tracking system has enabled a drastic reduction of the width of the recording track.

As the result, the Digital Betacam VTR is able to use the same size 1/2-inch Digital Betacam cassette (S and L) as in the conventional Betacam cassette. The L cassette makes continuous recording of more than 120 minutes possible, and even the S cassette can record for 40 minutes continuously.

In the VTR with a Betacam playback function, the analog tape (metal and oxide) recorded based on the Betacam/Betacam SP format can also be played back. Therefore, currently-owned Betacam recorded tapes can also be used directly. Furthermore, an analog Betacam SP VTR (especially Camcorder) can also be jointly used in the Digital Betacam system.

(Note: The player for the cart system uses the S cassette only.)

2-2. RECORDING FORMAT

2-2-1. Tape Pattern

Fig. 2-2-1 shows the tape pattern in the 525/60 system. To explain the operation of the VTR with a Betacam playback function, this figure shows the tape pattern of the Digital Betacam format at right, and the tape pattern of the Betacam SP format at left together.

In the Digital Betacam format, one-field video data is recorded on six helical tracks (program tracks). In other words, since one-field data is recorded while the drum rotates by 1.5, the number of drum rotations is approximately 90 per second. In the Betacam SP format, since one-field data is recorded while the drum rotates by 1/2, the number of drum rotations is approximately 30 per second. As shown in the figure, the tape speed of the Digital Betacam format is lower a little than that of the Betacam SP format.

The VTR with a Betacam playback function detects whether the cassette tape to be played back is based on the Digital Betacam format or the analog Betacam format, by the ID hole of the cassette, and switches the control mode automatically. As the result, the tape is played back at the same drum rotation and tape speed as when it is recorded, and parameters are set so that the optimum tracking is obtained.

The drum diameter of the Digital Betacam VTR is larger about 9% than that of the Betacam SP VTR. Since the relative speed of the head to tape increases proportionally to the drum diameter even if the drum rotation is made same, the signal recorded on the helical track of the Betacam SP tape is played back as time-compressed signal about 9%. In other words, the frequency of the played back RF signal increases. However, the RF signal is processed by a signal processing circuit in the later stage so that it can obtain the same performance as before.

The tape pattern of the Digital Betacam format has three longitudinal tracks (i.e., control track, time code track, and cue audio track). These tracks coincide with the tape pattern of the Betacam SP format. Therefore, the longitudinal tracks of the Betacam SP tape can be played back by the stationary heads of the Digital Betacam VTR. In the Betacam SP format, however, the fourth longitudinal track that records an audio CH1 signal is provided in parallel. The VTR with a Betacam playback function thus has a two-channel audio head.




Fig. 2-2-1. Tape Pattern (525/60)

2-2-2. Data Arrangement on Program Tracks

Fig. 2-2-2 shows the arrangement of data recorded on helical tracks (program tracks). The size of each section in the figure is not the actual dimension ratio. For more information on the size, refer to Fig. 2-2-1.

The Digital Betacam format uses an azimuth recording system to perform high-density recording. Namely, two heads with an azimuth angle of approximately 15 degrees in the opposite direction to each other are paired to record two program tracks (track 0 and 1) while the drum rotates by 1/2. One-field video data and audio data are recorded on six program tracks. Fig. 2-2-2 shows the arrangement of one-frame data. Field 1 data is recorded on the first-half six tracks, and field 2 data is recorded on the latter-half six tracks. Each program track is constructed to have four audio sectors in the center and to have two video sectors beyond the tracking pilot signals put before and behind the audio sectors. In other words, one-field video data is dispersed into twelve video sectors for recording, and four-channel audio data is dispersed into six audio sectors for recording for every channel. As shown in Fig. 2-2-2, each channel for the audio sectors is arranged so that the danger of error generation disperses.

To identify the beginning and end of a sector, preamble and postamble data are added before and behind all the sectors. Also, edit gaps are installed between the sectors so that each channel can be edited independently.

Tracking pilot signals are used in an automatic tracking system that secures high-speed and high-precision tracking during editing.




Fig. 2-2-2. Data Arrangement on Program Tracks

2-2-3. Longitudinal Tracks

As shown in Fig. 2-2-1, a control track, time code track, and cue audio track are provided in the longitudinal direction of the tape.

Fig. 2-2-3 shows the CTL signal and time code signal in the 525/60 system, and the timing relationship between these signals and video reference signals.

The CTL signal is recorded by approximately 60-Hz rectangular pulse in the 525/60 system and controls the start timing of each field data at the rising edge of the pulse. The CTL signal is also modulated the duty cycle of the rectangular wave to 65 : 35 in the first field of a color frame so as to identify the field number and control the color framing. Moreover, the duty cycle is modulated to 35 : 65 in the first field of an audio 5-field sequence (excepting the overlapped field with the first field of a color frame) so as to use for the 5-field sequence control.

The time code signal uses a conventional longitudinal time code based on the SMPTE/EBU standard. One frame consists of 80 bits. Frame number, second, minute, hour, and sync word data items are coded by a biphas mark coding method and recorded for every frame. A user bit is written in the time data as a binary group.

The cue audio signal is recorded by an ordinary AC bias method.




Fig. 2-2-3. Digital Betacam Timing Chart (525/60)

2-3. HEAD CONFIGURATION

Fig. 2-3-1 shows the arrangement of the stationary and rotary heads in the recorder with a Betacam playback function, and its top view. However, the rotary heads can be actually viewed only their tips from the side of the drum.

In the illustration that shows the rotary heads, ADVANCE heads and Y/C heads installed in pairs on the square plates like the bimorph plates are dynamic tracking heads. These heads are used to play back a digital tape and an analog tape respectively. Therefore, the model without a Betacam playback function has no Y/C heads.

Both ADVANCE heads and CONFIDENCE heads are used to play back a digital tape. In usual PB mode, the ADVANCE heads are used to play back. In the REC and INSERT modes, the ADVANCE heads play back the signal before erasure as preread, and the CONFIDENCE heads play back a recorded signal to confirm that the signal has been recorded. For that purpose, the ADVANCE heads and the CONFIDENCE heads are installed in the specified height on the rotary drum so that they can trace the before track and after track respectively toward the REC head.

In Fig. 2-3-1, shaded heads are installed for the recorder only. As for the player, only the stationary heads to play back the longitudinal tracks and only the rotary heads to play back the helical tracks are installed.




Fig. 2-3-1. Arrangement of Stationary and Rotary Heads

2-4. SIGNAL PROCESSING

2-4-1. Outline of the Digital Interface Format

The interface of the Sony Digital Betacam VTR is based on the component serial digital interface format SMPTE 259M/CCIR-656 Part III. The digital audio interface is based on the AES/EBU format.

1. Serial video interface

Each data of a digital component video signal and four-channel digital audio signal is serialized and can be transmitted over a long distance of more than 200 m using one coaxial cable. The transmission rate is 270M bits per second.

This serial interface uses an S-NRZI (Scrambled Non-return to Zero Inversion) channel code system for digital data coding. The NRZI transmission has a merit that the contents of data do not change even if a signal is inverted in polarity. Therefore, this system has the advantage that a spurious radiation can be reduced by using the positive/negative polarity simultaneously for serial signal transmission or that the IC can be constituted by a stable, low-power consumption differential amplifier. Scramble processing also enables a clock to be reproduced on the receiving side even if data "0" continues.

Video data is processed in conformity with the SMPTE 125M/CCIR-601 standard. The luminance signal (Y) is sampled in 13.5 MHz, and the color-difference signals (CR and CB) are sampled in 6.75 MHz. The luminance signal and color-difference signals are then multiplexed in the order of "CB, Y, CR, Y, CB, Y, CR, Y, ..." and transmitted at the rate of 27M words per second.

Fig. 2-4-1 shows the relationship between the video signal level and the quantizing level. Fig. 2-4-2 shows the sampling format in a horizontal line, and Fig. 2-4-3 shows the sampling format in a field.

As shown in Fig. 2-4-2, the four-word timing reference signals (TRS) are added before and behind the digital active line. The top TRS signal defines the start of the active line and is called an SAV (Start of Active Video). The last TRS signal defines the end of the active line and is called an EAV (End of Active Video).

Fig. 2-4-4 shows the format of a timing reference signal corresponding to 10 bits. Since the first three words of four words constitute a unique pattern of 3FF, 000, and 000 (HEX), they can be detected as a sync word. For serial transmission, when this sync word is detected, the bit to be sent next is judged to be an LSB, and becomes a reference for converting the serial bits into every 10 bits of parallel words. The fourth word (XYZ) defines the field status, and vertical and horizontal blanking timing.

2. Digital audio interface

The digital audio interface is classified into the serial digital interface combined with a video signal and the AES/EBU digital interface employing an XLR connector.

In both interfaces, the digital audio data is based on the AES/EBU format, and corresponds with 48 kHz sampling and 20-bit linear quantizing. For the serial digital interface, the digital audio data is inserted into an auxiliary data area during horizontal and vertical blanking periods. For the AES/EBU digital interface, two channels of audio data are multiplexed and stored in a data frame for every audio-sampling period. One frame consists of two subframes. The left channel data in the stereo mode enters into subframe A, and the right channel data enters into subframe B.

Fig. 2-4-5 shows the format of frame and subframes. The subframes contains various data items (shown in the figure) as well as audio data and consist of 32 bits.




Fig. 2-4-1. Relationship between Video Signal Levels and Quantizing Levels




Fig. 2-4-2. Relationship between H Sync and Sampling (525/60)




Fig. 2-4-3. Relationship between Analog Video Signal and Digital Field Blanking (525/60)

		PREAMBLE			TIMING REF.	
WORD ADDRESS	EAV	1440	1441	1442	1443	
	SAV	1712	1713	1714	1715	
HEX VALUE		3FF	000	000	(XYZ)	Definition of (XYZ)
B9 (MSB)		1	0	0	1	Always 1 except for TRS
B8		1	0	0	F	0: 1st field 1: 2nd field
B7		1	0	0	V	1: V blanking
B6		1	0	0	H	1: H blanking
B5		1	0	0	P3	Redundant bits used to correct errors occur in F, V and H.
B4		1	0	0	P2	
B3		1	0	0	P1	
B2		1	0	0	P0	
B1		1	0	0	0	Always 0 except for TRS
B0 (LSB)		1	0	0	0	

Fig. 2-4-4. Timing Reference Signal (525/60)




Fig. 2-4-5. Frame and Subframe Formats

2-4-2. Outline of the Digital Signal Processing

The digital signal processing of the Sony Digital Betacam VTR conforms to the D-1 format except that the bit rate reduction processing is added.

Fig. 2-4-6 shows the block diagram of the recording system, and Fig. 2-4-7 shows the block diagram of the playback system.

1. Outline of the recording system

- (a) Input interface
For the analog or digital video/audio input signals, the video signal is converted into parallel video data, and the audio signal into serial audio data.
- (b) Bit rate reduction encoder
The video data is blocked after it is field-shuffled, then compressed into a data rate of approximate 1/2 according to the newly developed bit rate reduction format.
- (c) Audio data processor
The audio data processor performs the audio data selection, gain control, REC verification, and other data processing.

(d) ECC encoder

The ECC encoder performs the error correction coding for error correction in a playback system. The video data that has been sent after bit rate reduction is added the outer error collection code (ECC) and track-interleaved. The audio data sent from the processor is also added the outer ECC and field-shuffled.

Then, the video data and audio data are multiplexed, added the ID data, and inner ECC encoded. Sync data is also added to the resultant data.

(e) REC driver

The REC driver converts parallel REC data into serial data and sends a channel-encoded REC current to the head.

2. Outline of the playback system

In the playback system, signals are processed in the procedure opposite to the recording system.

The audio data error that couldn't be corrected using inner and outer error correction codes is concealed before the audio data is output from an ECC decoder. The video data error that couldn't be corrected is concealed after the video data is returned to the former video data.




Fig. 2-4-6. Digital Signal Recording System




Fig. 2-4-7. Digital Signal Playback System

2-4-3. Error Correction Coding

In the Sony Digital Betacam format, error correction takes place by means of a two-dimensional product code of the inner and outer codes using the Reed-Solomon code.

The structure of the inner code block that constitutes an ECC block is common in video and audio systems. However, the structure of the outer code block differs in video and audio systems. A data block of 180 bytes obtained when sync data is added to one inner code block data is called a sync block, which is the basic unit of a video sector and audio sector. Fig. 2-4-8 shows the structure of the ECC blocks and sync block in the 525/60 system.

One video sector consists of 106 sync blocks. In other words, one video ECC block constitutes one video sector.

Therefore, the two ECC blocks shown in the figure below are recorded on one track, and one field corresponds to 12 ECC blocks.

One audio sector consists of five sync blocks. For the audio data in one channel, one field consists of six sectors (i.e., 30 sync blocks). Therefore, the three ECC blocks shown in the figure correspond to one field in one audio channel.




Fig. 2-4-8. Structure of ECC Blocks and Sync Block (525/60)

SECTION 3
BLOCK DIAGRAMS AND CIRCUIT DESCRIPTIONS

CONTENTS OF BLOCK DIAGRAMS


- 3-1. OVERALL**
OVERALL (1/2) : Signal Processing System
OVERALL (2/2) : Control System
- 3-2. CIRCUIT BLOCK**
EQ-45B : RF Processor
DPR-36H : Digital Processor
VPR-1B : Video Processor
APR-1B : Audio Processor
DIF-16B : Serial Digital Interface
CUE-1B : CUE/LTC Processor
DM-89 : Betacam PB Demodulator
TBC-24 : Betacam PB TBC (A/D conversion)
TBC-23 : Betacam PB TBC (Sequence/Reference)
AP-28 : Betacam PB AFM Demodulator
SS-52B (1/3) : System Control
SS-52B (2/3) : Servo Control
SS-52B (3/3) : Dynamic Tracking
DR-200 : Servo Driver
FUNCTION CONTROL BLOCK
POWER SUPPLY
- 3-3. FRAME**
FRAME WIRING (1/3) : Drum/Heads
FRAME WIRING (2/3) : Mecha Deck
FRAME WIRING (3/3) : Front/Rear Panels


CONTENTS OF CIRCUIT DESCRIPTIONS


- CIRCUIT DESCRIPTION OF EQ-45B BOARD
- CIRCUIT DESCRIPTION OF DPR-36H BOARD
- CIRCUIT DESCRIPTION OF VPR-1 BOARD
- CIRCUIT DESCRIPTION OF APR-1B BOARD
- CIRCUIT DESCRIPTION OF DIF-16B BOARD
- CIRCUIT DESCRIPTION OF CUE-1B BOARD
- CIRCUIT DESCRIPTION OF DM-89 BOARD
- CIRCUIT DESCRIPTION OF TBC-24 BOARD
- CIRCUIT DESCRIPTION OF TBC-23 BOARD
- CIRCUIT DESCRIPTION OF AP-28 BOARD
- CIRCUIT DESCRIPTION OF SS-52B BOARD (1/3)
- CIRCUIT DESCRIPTION OF SS-52B BOARD (2/3)
- CIRCUIT DESCRIPTION OF SS-52B BOARD (3/3)
- CIRCUIT DESCRIPTION OF DR-200 BOARD


NOTE External connection of each signal is shown by the object board name and the connector-pin number.
If it is shown by "HN" or only connector-pin number, refer to "FRAME WIRING".

3-1. OVERALL









3-2. CIRCUIT BLOCK [CIRCUIT DESCRIPTION OF EQ-45B BOARD]

EQ-45B board is a playback RF processor board that converts the PB RF signal sent from the drum into PB data and sends it to DPR-36H board.

Before the playback process is described, the explanation for IC103 which exists on the upper left side of the circuit block diagram is described.

IC103 is the interface IC in which performs signal conversions between the digital processor (DPR-36H board) and the RF system.

Moreover, IC103 encodes the "MPX" signal multiplexing the head select signals sent from SS-52B board, and sends it to the head drum.

The MPX signal is decoded in the head drum and switches each head amplifier.

In case of the player, IC103 sends the MPX signal to the head drum, and makes it switch the PB head amplifiers.

Then, after the played back PB RF signals have entered EQ-45B board and received RF processing, IC103 adds the parity data to the played back digital data, and sends them to DPR-36H board.

Input signal lines useless for the player, like REC data, are connected to IC103. These are provided for input of test signals, which make "EE2 AC/BD DATA" and the like so as to enable to test the circuits, for the factory production.

Then, the playback process is described below.

The PB RF signals that are played back by PB heads and passed through head amplifiers are sent from the head drum to EQ-45B board.

The signals of heads A and C, and heads B and D, that are switched every time the drum rotates by one half, can be transmitted using the same signal line, respectively.

Therefore, the lines required for the PB RF signal transmission are two pairs of "ADV AC" and "ADV BD".

In case of the player with a Betacam playback function, in the Betacam tape PB mode, head amplifiers in a digital system are turned off.

Therefore, the PB RF signals of Betacam PB heads Y-A and Y-B use the "ADV AC" line in common.

The PB RF signals of heads C-A and C-B use the "ADV BD" line in common.

The PB RF signals input to EQ-45B board are sent each to PB equalizer IC (IC401 or IC501) for VCA, amplitude equalization, and phase equalization.

An envelope is then detected.

In the Betacam tape PB mode, the "PB Y" and "PB C" RF signals that are input through "ADV AC" and "ADV BD" lines to the PB equalizers are output each via only a VCA circuit and sent to DM-89 board (Betacam PB demodulator board). The RF signal output from each PB equalizer branches into two paths.

One is sent to A/D converter (IC802 or IC804).

The another is low-frequency compensated and amplitude limited using a quantizing feedback (QFB) circuit, then sent to the PLL IC (IC801 or IC803).

In consideration of the tape speed information, the PLL IC extracts a PB clock from the input RF signal and sends the clock signal to the A/D converter mentioned above and VITERBI IC (IC805).

The A/D converters are required for the VITERBI processing that is executed in the VITERBI IC in the next stage.

The A/D data of the RF signal output from the A/D converter is input to the VITERBI IC, where a regeneration of the bit is executed by a VITERBI system.

The data is then converted into 4-bit parallel data and sent to the interface IC (IC103) together with the clock signal.


In the interface IC, parity data is added to the data sent from VITERBI IC.

Two groups of PB data ("ADV AC D0 through D3" and "ADV BD D0 through D3") are then output together with their parity data and clock signals and sent to DPR-36H board.


CR5-1B PS

(In only case of the VTR
with a Betacam PB function)

- ① TP103 (C-1) PB mode
TP104 (C-1) PB mode (Lot No. 307 thur. 001)
TP819 (SS-52B) (J-1) (TRIG)



- ② TP401 (F-1) PB mode (B/W LIMIT OFF) (Lot No. 002 or higher)
TP401 (E-1) PB mode (B/W LIMIT OFF) (Lot No. 307 thur.001)
TP103 (C-1) (TRIG)




Measurement Condition

MODE : PB mode

TAPE : ZR5-1


: CR5-1B

EQ-45B Board -A Side- (Lot No. 307 thur. 001)




ZR5-1 PB mode


- ① TP103 (C-1) PB mode
TP104 (C-1) PB mode (Lot No. 307 thur. 001)
TP819 (SS-52B) (J-1) (TRIG)




- ③ TP423 (F-1) PB mode (Lot No. 002 or higher)
TP423 (E-1) PB mode (Lot No. 307 thur. 001)
TP103 (C-1) (TRIG)



- ④ TP808 (F-2) PB mode (Lot No. 002 or higher)
TP808 (G-4) PB mode (Lot No. 307 thru.001)
TP103 (C-1) (TRIG)





EQ-45B Board -A Side- (Lot No. 002 or higher)




Lot No. 002 and higher

DVW-A510P (EK): S/N 14301 and higher
 DVW-A510 (J): S/N 10685 and higher
 DVW-A510 (UC): S/N 11644 and higher
 DVW-510P (EK): S/N 11385 and higher
 DVW-510 (J): S/N 10101 and higher
 DVW-510 (UC): S/N 10763 and higher
 DVW-CA510P (EK): S/N 10076 and higher
 DVW-CA510 (J): S/N 10002 and higher
 DVW-CA510 (UC): S/N 10016 and higher





DVW-A510P (EK): S/N 10001 through 14300
 DVW-A510 (J): S/N 10001 through 10684
 DVW-A510 (UC): S/N 10001 through 11643
 DVW-510P (EK): S/N 10001 through 11384
 DVW-510 (J): S/N 10001 through 10100
 DVW-510 (UC): S/N 10001 through 10762
 DVW-CA510P (EK): S/N 10001 through 10075
 DVW-CA510 (J): S/N 10001
 DVW-CA510 (UC): S/N 10001 through 10015





[CIRCUIT DESCRIPTION OF DPR-36H BOARD]

DPR-36H board is a playback digital processor board that decodes the playback digital data.

The playback process is described below.

The two groups of AC/BD ADVANCE PB data sent from EQ-45B board are input to inner ECC decoder (IC29).

The video data for test use ("REC DATA 2 through 9") sent from VPR-1B board in the test mode is also input to IC29.

The inner ECC decoder selects a necessary data from these input data according to the system mode, detects the sync data, performs the inner correction based on the detected sync data, then extracts the ID information.

Based on the extracted ID information, the inner ECC decoder performs the clock rate transfer and de-interleaving for the data via memory (IC30, 31, 33, and 34).

In this process, the two groups of data are multiplexed, then separated into V data and V/A data.

They are sent to the outer ECC decoder (IC35) with each error flag data added.

In the outer ECC decoder, the video data is outer-corrected, de-shuffled via memory (IC36 and IC37), then sent to video decoder (IC45).

The audio data is outer-corrected, de-shuffled via internal memory, then error-concealed.

The resultant data is transferred the clock rate, then sent to the audio data processing system.

As described above, an ECC decoder consists of an inner ECC decoder and an outer ECC decoder.

The video data input to the video decoder (IC45) is decoded by the bit rate reduction process so as to return to the former data rate, and de-shuffled via memory (IC51 through IC62). The data is then error-concealed via FIFO memory (IC63 through IC67) and sent to VPR-1B board as video PB data ("PB DATA 0 through 9").

Next, the audio data processing system is described below.

IC69 and IC911 are the audio data processor.


The audio data processor performs data processing of digital audio data between the ECC encoder or decoder and the audio system processor boards in the REC or PB mode.


In the PB mode, the decoded audio data is sent to IC73. IC73 is a jog audio processor.

It compensates the noise during jog or shuttle using external memory (IC74), and sends data to the audio data processor.

The audio data processor performs the gain control, phase adjustment, muting, and other data processing.

It then converts the resultant data into serial audio data "DA T 1/2 and 3/4", "MONI L/R" and "AES T 1/2 and 3/4", and sends them to APR-1B board. In addition, it converts the data into serial audio data "SIF T 1/2 and 3/4", and sends it to DIF-16B board.





[CIRCUIT DESCRIPTION OF VPR-1B BOARD]

VPR-1B board is a playback video processor board that converts the playback digital video data into a video signal, and generates timing reference signals for video/audio processing.

Before the playback process is described, the explanation for IC307 which exists on the beginning of the circuit is described.

IC307 is originally "TBC BUFFER IC" in which performs TBC processing to input REC video data at a recorder.

However, not only that also IC307 generates video data for test use under the control of the MPU (IC753), receives the "REC DATA", "PB DATA", and "D1 DATA" (encoder outputs) that are fed back as "multiloops", and executes the diagnosis.

In case of the player, functions of IC307 for test use are utilized.

Video data for test use generated in IC307 is sent to DPR-36H board as "REC DATA 0 through 9".

Then, the playback process is described below.

The decoded video PB data ("PB DATA 0 through 9") sent from DPR-36H board is input to the video process IC (IC504).

In case of the player with a Betacam playback function, the TBC-processed Betacam PB data ("B-CAM DATA 0 through 9") is also sent to IC504 from TBC-23 board.

The "EE data 0 through 9" that is bypassed from output of the video data generator (IC307) is also input to IC504. IC504 selects the input data according to the system mode and sends it to encoder IC (IC505).

The encoder IC converts the input data into various 10-bit parallel data (component Y, R-Y, and B-Y data, composite data, VISC Y data, and D1 data) and outputs them together with the control data and clock signals required for after data processing.

The component Y, R-Y, and B-Y data are converted each from digital to analog so as to produce an analog signal, then output via clamp circuits.

The composite data branches into two paths.

One is converted from digital to analog, clamped, output, and divided on CP-218B board to produce "VIDEO OUT 1 and 2" signals.

The another is converted from digital to analog, superimposed a character signal by the switching of IC514, and output as "VIDEO OUT 3" signal.

The VISC Y data extracted from the Betacam PB data is converted from digital to analog, sent through a low-pass filter to TBC-23 board, and used to adjust the video phase of the Betacam PB signal.

The D1 data is sent directly to DIF-16B board.

Next, the control system is described below.

Two systems (video process control circuit and timing reference signal generator circuit) are provided for the control system.

The video process control is performed by the MPU (IC753) under the command ("SYIF2 CMD") of the serial communication from the main CPU on SS-52B board.


The MPU sends control signals to each main IC on VPR-1B board, and controls each signal level and phase in D/A conversion systems via EVR (IC754).

For the timing reference signal generation, the timing generator IC (IC1019) controls a PLL circuit to generate a 27MHz reference clock signal according to the sync and burst signals separated from an "INPUT REF VIDEO" signal.


The generated signal is sent to each board as the video process timing reference signal.

Moreover, audio clock generator IC (IC1032), while receiving this signal, generates various reference audio clock signals synchronized with the reference video signal and sends them to each board as the audio process timing reference signal.


①TP601(R-1) PB mode




②TP600(R-2) PB mode




③TP602(R-2) PB mode




④TP603(R-3) PB mode




⑤COMPONENT Y OUT PB mode




⑥COMPONENT R-Y OUT PB mode




⑦COMPONENT B-Y OUT PB mode




⑧COMPOSITE OUT PB mode





VPR-1B Board -A Side-



Measurement Condition
MODE : PB mode
SET UP MENU 709 : D-1
(CAV LEVEL FORMAT)
TAPE : ZR5-1







[CIRCUIT DESCRIPTION OF APR-1B BOARD]

APR-1B board is an playback audio processor board that converts the playback digital audio data into analog audio signals and AES/EBU digital audio signals, and also controls the digital audio system.

In case of the player with a Betacam playback function (APR-1BA board), the function which converts the audio signals played back from the analog Betacam tape into digital data so as to enable to adjust the signal level, is added.

First, the playback process to a digital tape is described below.

Audio data ("DA T 1/2 and 3/4", "MONI L/R", and "AES T 1/2 and 3/4") are sent from DPR-36H board to APR-1B board in the form of serial data two by two audio channels.

The "DA T 1/2", "DA T 3/4", and "MONI L/R" data are input each to the audio digital filter to separate two channels, converted from digital to analog for every channel to produce an analog signal, and output through a de-emphasis amplifier. To "MONI L" and "MONI R" output circuits, the CUE MONITOR signals branched from the CUE output circuits on CUE-1B board are mixed, and the signals output as "MONITOR OUT" are selected by control signals ("DA MUTE" and "CUE MUTE ON") from the MPU.

The "AES T 1/2" and "AES T 3/4" data input to APR-1B board are encoded by AES/EBU transceiver IC (IC1562) (*IC1 and IC3), converted into AES/EBU digital audio signals ("AES O 1/2" and "AES O 3/4") two by two audio channels, then output.

Additionally, "SIF T 1/2 and 3/4" serial audio data are also output from DPR-36H board. However, these data are sent directly to DIF-16B board and encoded to a Serial V/A signal.

Next, the playback process to an analog Betacam tape is described below.

When an analog Betacam tape is played back, the audio signals ("B PB CH-1 and CH-2") that are played back from the longitudinal tracks of the tape, and the audio signals ("B PB CH-3 and CH-4") that are AFM-demodulated from the PB RF signal in track C, are sent from AP-28 board to APR-1BA board, input through the emphasis amplifiers to the A/D converters, and converted into serial data two by two audio channels.

The resultant data are sent to DPR-36H board via the routes named as "AD R 1/2 and 3/4".

These routes are originally input circuits of recording data. However, the unit is in the analog PB mode at that time. Therefore, the data input to DPR-36H board are immediately bypassed to the PB circuit and gain-controlled interlocking with the audio PB level adjustment volume control on the control panel.

The data are then returned to APR-1BA board via the same route as in "DA T 1/2 and 3/4" data, passed through the PB processing circuit on APR-1BA board, and output as the PB audio signals of the Betacam tape.

Lastly, the control system is described below.

The digital audio system is controlled by the MPU (IC51) under the command ("SYIF3 CMD") of the serial communication from the main CPU on SS-52B board.

In addition to the control of its own board circuit, this control system controls CUE-1B board via an I/O port (IC54), the audio level meter (fluorescent indicator tube) by serial communication, and the audio data processor on DPR-36H board by serial communication.

The control system also controls the SIF audio process in DIF-16B board while exchanging 8-bit parallel data.


Moreover, it operates as the center of the diagnosis and automatic adjustment functions of the whole audio system.


* : For Lot No. 307 through 909

Lot No. 910 and higher


DVW-A510P (EK): S/N 14076 and higher
 DVW-A510 (J): S/N 10685 and higher
 DVW-A510 (UC): S/N 11544 and higher
 DVW-510P (EK): S/N 11300 and higher
 DVW-510 (J): S/N 10101 and higher
 DVW-510 (UC): S/N 10758 and higher


DVW-CA510P (EK): S/N 10076 and higher
 DVW-CA510 (J): S/N 10002 and higher
 DVW-CA510 (UC): S/N 10016 and higher





DVW-A510P (EK):	S/N 10001 through 14075	DVW-CA510P (EK):	S/N 10001 through 10075
DVW-A510 (J):	S/N 10001 through 10684	DVW-CA510 (J):	S/N 10001
DVW-A510 (UC):	S/N 10001 through 11543	DVW-CA510 (UC):	S/N 10001 through 10015
DVW-510P (EK):	S/N 10001 through 11299		
DVW-510 (J):	S/N 10001 through 10100		
DVW-510 (UC):	S/N 10001 through 10757		





[CIRCUIT DESCRIPTION OF DIF-16B BOARD]

DIF-16B board is a D-1 serial digital interface board that converts the playback video and audio digital data into a Serial V/A signal.

The Serial V/A signal is a digital signal obtained by means that each data of a digital component video signal and four channel digital audio signals are serialized and channel-coded by the S-NRZI (Scrambled Non-return to Zero Inversion) system.

The playback process is described below.

10-bit parallel D1 video data ("D1/D2 DATA 0 through 9") are sent from VPR-1B board, and serial audio data ("SIF T 1/2 and 3/4") two by two audio channels are sent from DPR-36H board to DIF-16B board.

The video data is sent to D1 encoder (IC123).

The audio data is sent to SIF audio transmitter (IC119), converted into 10-bit parallel audio data whose four channels are multiplexed, and sent to the same D1 encoder as in the video data.

In the D1 encoder, the video data and audio data are multiplexed, converted into 10-bit parallel V/A data, then sent.

The sent 10-bit parallel V/A data branches into two paths. One is input to IC124, converted into serial data, and channel-encoded by the S-NRZI system so as to produce the Serial V/A signal.

The resultant signal is output through a cable driver to the "SERIAL V/A OUTPUT 1, 2, and 3" connectors.


The another is input to D1 superimpose IC (IC700) and superimposed a serial character signal sent from SS-52B board.

The resultant data is input to IC701, converted into serial data, channel-encoded by the S-NRZI system so as to produce the "superimposed Serial V/A signal", then output through a cable driver to the "SERIAL V/A OUTPUT 4" connector.

The SIF audio process is controlled by the MPU on APR-1B board. For that reason, DIF-16B board and the MPU on APR-1B board exchange 8-bit parallel data ("SIF DATA 0 through 7").


Lot No. 907 and higher


DVW-A510P (EK): S/N 14001 and higher
 DVW-A510 (J): S/N 10685 and higher
 DVW-A510 (UC): S/N 11514 and higher
 DVW-510P (EK): S/N 11255 and higher
 DVW-510 (J): S/N 10101 and higher
 DVW-510 (UC): S/N 10758 and higher
 DVW-CA510P (EK): S/N 10076 and higher
 DVW-CA510 (J): S/N 10002 and higher
 DVW-CA510 (UC): S/N 10016 and higher





DVW-A510P (EK): S/N 10001 through 14000
DVW-A510 (J): S/N 10001 through 10684
DVW-A510 (UC): S/N 10001 through 11513
DVW-510P (EK): S/N 10001 through 11254
DVW-510 (J): S/N 10001 through 10100
DVW-510 (UC): S/N 10001 through 10757
DVW-CA510P (EK): S/N 10001 through 10075
DVW-CA510 (J): S/N 10001
DVW-CA510 (UC): S/N 10001 through 10015





DVW-A510/510
DVW-A510P/510P
DVW-CA510/CA510P


[CIRCUIT DESCRIPTION OF CUE-1B BOARD]


CUE-1B board is a CUE/LTC PB processing board that reproduces the CUE and LTC signals recorded on the longitudinal tracks of the tape.


The CUE signal processing circuit is first described below. The CUE signal is also called a CUE AUDIO signal because an audio signal is usually used as the CUE signal. In the case of analog Betacam tape, an AUDIO CH2 signal is recorded on the CUE AUDIO track position, and an AUDIO CH1 track is provided in parallel with the CUE AUDIO track. Therefore, two-channel audio heads are provided, and the AUDIO CH2 head is used in common for digital tape PB operation and Betacam tape PB operation. For tape reproduction, CUE and AUDIO CH2 signals can be reproduced halfway by a same circuit, and an equal circuit is used in AUDIO CH1 during corresponding section. That is, the signal reproduced by the head is made flat in frequency response using a head tuning circuit and PB equalizer circuit, and passed through the audio attenuator and slow equalizer controlled by the MPU on APR-1B board. If the PB signals are CH1 and CH2 Betacam PB audio signals, they are sent to AP-28 board from here. If the PB signal is a CUE signal, it is sent to an exclusive PB processing circuit. In the exclusive PB processing circuit, the CUE signal is compensated in the undulation of a low-frequency response using a contour effect compensator (IC112 and IC113). The compensated signal is then adjusted in level according to the "CUE PB GAIN" instruction (DC voltage) from the control panel, and sent through a noise filter amplifier (IC108) to PB/EE select switch (Q103 and Q104), where a PB or CUE TEST signal is selected according to the command from the MPU on APR-1B board. The selected signal branches into two paths. One is passed through the output circuit on CUE-1B board as a CUE OUT signal, and output from the "CUE" connector of the "AUDIO OUTPUT" connector group on the rear panel. The another is sent to APR-1B board as a CUE MONITOR signal. Moreover, a "PEAK DETECT" detector circuit (IC117) is provided. This detector circuit converts the peak level of the CUE signal into a DC voltage and outputs it. The output voltage is sent to the MPU on APR-1B board and used for the CUE level display of an audio level meter.

An LTC signal processing circuit is described next. The signal reproduced by the TC head is passed through a PB equalizer amplifier (IC404), then a low-pass filter and high-pass filter controlled by the MPU on APR-1B board, and shaped in a waveform using IC407. The PB signal is then sent to the LTC PROCESSOR IC on SS-52B board as a "PB LTC" signal. The signal read by the LTC PROCESSOR IC is sent back to CUE-1B board as an "LTC OUT" signal and shaped in a waveform using IC701. The shaped signal is converted into a balanced signal using IC703 and output to the "TIME CODE OUT" connector.

CUE-1B LEVEL DIAGRAM







[CIRCUIT DESCRIPTION OF DM-89 BOARD]

DM-89 board is a Betacam PB demodulator board that equalizes the RF signal reproduced from an analog Betacam tape according to the type and speed of the tape, demodulates it to a video signal, and detects a dropout.

The outline of Betacam tape reproduction is first described below.

The Y RF and C RF signals reproduced from the Y and C (chroma) tracks of an analog Betacam tape are sent through the VCA circuit on EQ-45B board to DM-89 board. On DM-89 board, PB Y and PB C signals are equalized, demodulated, and dropout detected by their respective circuit. The resultant signals are sent to TBC-24 board.

When the analog Betacam tape is reproduced by a digital Betacam VTR, the relative speed of the rotary head to the tape increases about 9 % depending on the diameter of the head drum. Therefore, the signal recorded on the helical track is reproduced in the form that its time base is compressed about 9 %. The FM carrier frequency and deviation also significantly vary depending on the metal tape and oxide tape. During shuttle PB, the PB frequency decreases in the FF mode and increases in the REW mode. On DM-89 board, a signal is properly processed under these conditions, and the same performance as the conventional one can be obtained.

The outline of each circuit is described next. PB Y and PB C systems are provided. In the PB Y system, a high-speed search compensator is added so that a luminance signal can be reproduced in the high-speed search mode. Therefore, the PB Y system is described.

A normal PB circuit is explained below. The PB Y RF signal sent to DM-89 board is attenuated to 2/5 and sent to the input circuit block in IC101. For a metal tape, the input RF signal is attenuated to 1/2 and output via a VCA circuit. Select switches are incorporated into the input stage of this circuit block, and reference marker signals corresponding to the PB RF frequency whose time base is compressed on the metal tape can be input for a test.

The PB Y RF signal passed through a VCA circuit is sent to a cosine equalizer circuit. This circuit is an amplitude equalizing circuit that can correct the amplitude characteristic without changing the phase characteristic by combining a delay line and differential amplifier. The signal that has been equalized in amplitude is passed through an RF low-pass filter, equalized in phase using two-stage phase equalizer circuits, and sent to a video switch (IC102). The RF low-pass filter and phase equalizer circuits are provided in parallel for a metal tape and oxide tape and selected using the video switch (IC102).

After that, the signal is equalized into Y main and Y sub frequency characteristics by the cosine equalizer circuit in the next stage. The Y main frequency characteristic is a flat characteristic that attaches importance to the frequency characteristic. The Y sub-frequency characteristic is a characteristic that attaches importance to the counter measures for overmodulation.

For the PB Y RF signal whose basic equalization has been completed, Y MAIN RF and Y SUB RF signals are sent to the demodulator circuit system, and a Y MAIN RF signal is sent to the dropout detector circuit system.

The Y MAIN RF and Y SUB RF signals sent to the demodulator circuit system enter into an overmodulation compensator (OMC)(IC501) and are mixed via a limiter circuit. The mixed Y RF signal is sent to a demodulator

(IC501), where the carrier frequency is multiplied, converted from a frequency into a voltage, then de-emphasized. The resultant signal is sent to the low-pass filter in the next stage to eliminate a frequency-multiplied carrier and demodulated into a video signal. The demodulated Y signal is clamped and nonlinear de-emphasized using IC503, then sent to TBC-24 board as a "Y DEMOD" signal.

The Y MAIN RF signal sent to the dropout detector circuit system is input through a dropout equalizer to dropout detector circuit block IC101, where the signal is compared with the reference voltage. If the signal is less than the reference voltage, a dropout is judged to have occurred. A dropout detection pulse ("Y DO PLS") is then sent to TBC-24 board and other blocks.




















The outline of the normal PB circuit is as described above. The normal PB operation indicates the PB range of -1 to +3 times the normal speed in which noiseless PB operation can be performed using a DT function. In this normal PB operation, various corrections for a signal are performed according to the type of a tape. However, the F/V-conversion gain and de-emphasis characteristic of a demodulator vary depending on the tape speed information. The demodulator can be thus used in PB modes other than normal PB.

During shuttle PB, the PB frequency decreases in the FF mode and increases in the REW mode. In the high-speed search mode, especially, in the high-speed FF mode, the FM carrier frequency and deviation decrease. Consequently, the demodulated video signal level decreases, and the waveform is distorted. This makes it difficult to reproduce the video information. Therefore, a high-speed search compensator mentioned below is added in the PB Y system so that a luminance can be reproduced in the high-speed search mode. Each signal is compensated according to the type and speed of a tape.

"SEARCH SW" gate which consists of three blocks of RF switches is provided. The signal whose only amplitude has been equalized passes the gate via a "FLAT" switch in the high-speed REW mode. The signal that has been passed through a "SEARCH LPF" filter passes the gate via a "LOW" switch in the high-speed FF mode. And the signal that has been equalized passes the gate via a "MID" switch in the middle search speed mode. The signal that has passed the gate is emphasized according to the tape speed by a "SEARCH TUNE" circuit and input to the demodulator (IC501) and dropout detector circuit (IC101) instead of a normal PB signal by the selection of RF switches. In the high-speed FF mode, the frequency-multiplied carrier elimination filter in the stage following the demodulator is also changed to "SEARCH LPF".


Lastly, a control system is described below.


Principal controls for each circuit block corresponding to the type and speed of a tape are performed by the MPU (IC906) on DM-89 board under the command ("SYIF2 CMD") of the serial communication from the main CPU on SS-52B board. The main controls are as follows: METAL/OXIDE selection, each selection in the high-speed search compensator, and analog control of VCAs, cosine equalizers, OMCs, and dropout detection reference value via D/A converters (IC904 and IC905). The backup operation by an EEPROM (IC908) is also performed.




Measurement condition
MODE : PB mode
: x-3 SPEED mode
TAPE : CR5-1B

DM-89 Board -A Side-







[CIRCUIT DESCRIPTION OF TBC-24 BOARD]

TBC-24 board is a Betacam PB TBC (A/D conversion) board that generates a clock following the jitter of the demodulation video signal from DM-89 board, converts the demodulation video signal into digital video data using this clock, and sends it to TBC-23 board.

The outline of a process is first described below.

The video signal that is reproduced from a tape and demodulated contains a jitter component. To eliminate the jitter component, a clock that contains the same jitter component is generated using a write clock generator circuit. When a PB video signal is sampled by this write clock, the A/D-converted digital video data becomes data whose jitter component is canceled.

Since Y and C signals are recorded on the different video tracks of a tape, the way in which each jitter is generated also differs. Therefore, two write clock generator circuits and A/D converter circuits for Y and C signal systems are provided on TBC-24 board. These circuits are almost the same respectively in circuit configuration.

The outline of each circuit is described next. Since Y and C signal systems are almost the same in configuration, only the Y signal system is described.

A write clock generator circuit is first explained below. IC301 plays a leading part in a Y write clock generator circuit. IC301 extracts an H sync signal from the input demodulation Y signal and sends it to the sync guard circuit on TBC-23 board. The sync guard circuit eliminates H sync signal with irregular intervals, separates only H sync signal with regular intervals, and sends it back to IC301 as a SELECT H WINDOW (SHW) signal. IC301 doubly differentiates the demodulation Y signal and gates the detected sync edge signal by this SHW signal. After that, IC301 outputs only the sync edge signal, that is judged to be normal, from pin 50 as a SELECT H (SH) signal.

The output SH signal is converted into a sawtooth wave using a sawtooth wave generator in a phase-shift circuit (IC302, IC307, IC308, and IC409). The sawtooth wave inverts a comparator (IC308) by the phase obtained when the "SCH TRACKING" signal from TBC-23 board and the tape speed information are added to the phase set using RV300, and triggers a monostable multivibrator (IC307) to generate a pulse.

The output signal of normal VCO (IC406) (approximately 14.8 MHz during normal PB) is input to pin 67 of IC301 and frequency-divided into the H frequency using a PLL counter that is reset by the output pulse of the phase-shift circuit described above. A COUNT H signal is generated on the basis of this frequency-divided signal. The COUNT H signal is converted into a signal that has a slope for phase comparison in the inversion portion, and output from pins 16 and 17.

The slope of the COUNT H signal output from pin 16 is sampled and held by the output pulse of the phase-shift circuit described above so as to produce a phase error voltage. The phase error voltage is passed through a cutoff switch (IC400) during guard band period and fed back to the normal VCO (IC406) via a normal error amplifier. A PLL loop is formed via this VCO. As a result, the VCO oscillates with

the frequency locked to the input demodulation Y signal and is used for a Y write clock. The slope of the COUNT H signal output from pin 17 is detected its gradient. The result is fed back to pin 14 to maintain the gradient of the slope in the specified value.


IC301 incorporates an impact error detector circuit to cancel an impact jitter occurring when the rotary head touches the tape. The impact error detector circuit takes in the phase error voltage before integration through the A/D converter (IC404), then generates the signal data corresponding to the coming impact jitter by methods of memory, analysis, and forecast, and outputs it. The "IMPACT ERROR" signal obtained when this data is converted from digital into analog is added to a "NORMAL ERROR" voltage to control the normal VCO.

The above description applies to the normal PB mode. For high-speed search mode, a wide-range VCO is incorporated in IC301. The phase error voltage is fed back as a "BID ERROR" voltage via an error amplifier for a wide range. At that time, a "BID ERROR" signal corresponding to the tape speed information is also added to control the wide-range VCO.


The normal VCO and wide-range VCO are selected using an "F BID" signal from TBC-23 board. The selected VCO output signal is sent to the PLL counter in IC301, and simultaneously, it is output to an A/D converter circuit as a Y write clock ("Y WCK") signal. A "Y GATED WCK" signal that eight clock periods (including the reset period of the VCO) are muted is also sent to TBC-23 board.

Moreover, IC301 generates a "WZ" (WRITE ZERO) signal when it receives the output signal of the PLL counter, and sends it to TBC-23 board. IC304 also generates a "W CLP PLS" (WRITE CLAMP pulse) when it receives the SH signal, and sends it to the A/D converter circuit, and to the demodulator circuit on DM-89 board.


In the A/D converter circuit, the input demodulation Y signal is passed through a low-pass filter, clamped in pedestal level using a clamping circuit, and sent to an A/D converter (IC100). The error voltage for clamping is generated when the sample-and-hold voltage using the "Y W CLP" pulse that is generated by a write clock generator circuit and the hold voltage of the "Y PDS CONT" data that is fed back from TBC-23 board are compared with the reference voltage. The demodulation Y signal input to the A/D converter (IC100) is sampled using a write clock that is generated by the write clock generator circuit, and converted into eight-bit digital video data whose jitter is corrected. This data is passed through a digital delay line (IC103) so that it coincides in timing with the "Y DO PLS" pulse from DM-89 board. The data is then sent to TBC-23 board.




TBC-24 Board -A Side-



Measurement Condition
MODE : PB mode
TAPE : CR5-1B





Betacam PB TBC (A/D Conversion)
TBC-24
DVW-A500/A500P
DVW-A510/A510P
DVW-CA510/CA510P

[CIRCUIT DESCRIPTION OF TBC-23 BOARD]

TBC-23 board is a Betacam PB TBC (sequence/reference) board that corrects the time base, dropout, and picture quality and controls the phase by a VISC, with respect to the digital video data from TBC-24 board, and generates various timing signals used in a TBC block.

A sequence processing circuit is first described below.

Since Y and C signal systems are similar in configuration, only the Y signal system is primarily described except the complementary explanation of the block peculiar to the C signal system.

The eight-bit Y data from TBC-24 board is sent to a video data processing circuit in IC104, and the guard band period is replaced by a gray code (01H) and the dropout detection block is replaced by a DO code (00H) as the preparation of dropout compensation. After that, the data is written in field memory (IC107) under the control of a memory control circuit in IC104. Pedestal data is detected in the initial stage of the video data processing circuit, and "PDS CONT" data is fed back to TBC-24 board so that a level of 10H (80H for a chroma signal) is obtained. IC104 also has a sync guard circuit and separates only H sync signal with regular intervals from the H sync signal from the write clock generator circuit on TBC-24 board and sends it back as an SHW (SELECT H WINDOW) signal.

The Y data written in the field memory (IC107) is read by the read clock locked to the reference signal under the control of the memory control circuit in IC104. As a result, the Y data whose time base is corrected is obtained.

The reference V timing signal uses an "SQ V" signal in the normal and DT PB modes and uses an "SV V" signal in the high-speed PB mode.

An analog Betacam chroma signal is recorded on the tape by a system called CTDM (Compressed Time Division Multiplex) in which the R-Y and B-Y signals whose time base is compressed are arranged within an H period. Therefore, when a chroma signal is read from the field memory (IC109), R-Y and B-Y data are alternately read to convert into a signal in which the time-base corrected R-Y and B-Y data are alternately arranged for every clock.

The Y data whose time base has been corrected is input to the three-line dropout compensator (IC110) in the next stage to compensate for a dropout and sent to the next stage as 10-bit data. In the three-line dropout compensator, signals before and after 1H are prepared via delay lines. If a dropout occurs, the signal is replaced by the average data of the signals before and after 1H. If a dropout occurs in the signal after 1H, too, the signal is replaced by the data before 1H.

In the edge noise reducer (ENR) in the next stage, the Y data whose dropout has been compensated is corrected in picture quality by a digital correlation circuit. Chroma data is also corrected in picture quality by a line crawl canceler (LCC)(IC113). The Y data and chroma data are then input to IC206, output as 10-bit digital video data that is multiplexed in the order of "CB, Y, CR, Y, CB, Y, CR, Y, ...", and sent to VPR-1B board as "B-CAM DATA 0 to 9".

In case that a setup is added to the signal in NTSC system, the data is removed the setup and corrected the level by IC228 (NTSC only) in the later stage of IC206, then output.

A reference system is described next. A circuit that generates various timing signals used in the TBC block and a circuit that controls the TBC process are provided in the reference system.

The timing signals used in the TBC block are generated by IC206. IC206 has a "Read Timing Pulse Generator" function as well as a "Y/C Complex" function that multiplexes the Y and C data described above. IC206 generates various timing signals on the basis of the timing reference signals ("REF CK 27", "REF 4FSC", "B-CAM CF", "TBC VD", and "TBC HD") from the timing reference signal generator circuit on VPR-1B board, and sends them to ICs of each sequence process block.

The TBC process is controlled by the MPU (IC202) on TBC-23 board under the command ("SYIF2 CMD") of the serial communication from the main CPU on SS-52B board. The MPU sends the mode information and operation command to each main IC of the TBC process, outputs eight-bit Y/C delay control data, test commands, and other control signals, and saves the adjustment data of the circuit on TBC-23 board in an EEPROM (IC200).


The eight-bit Y/C delay control data output from the MPU is converted into an analog "Y/C DL CONT" signal using a D/A converter (IC203) and sent to TBC-24 board. The data is then added to the phase-shift circuit in a C write clock generator circuit to shift the phase of a chroma signal and synchronize the Y and chroma signals.


The IC (IC205) called a memory sequencer receives the command from IC206, and controls a V timing signal and the phase detection of a VISC signal.

The V timing signal is controlled as described below. IC205 takes in the "PB V", "DT V", "SV V" signals, other timing signals and control information from SS-52B board, VPR-1B board, and a TBC block, generates an "SQ V" signal from the correlation of these signals, and outputs it. This "SQ V" signal is used as the reference of time base correction in the normal PB and DT PB modes.

The phase detection of the VISC signal is controlled as described below. The "VISC Y" signal that is extracted from Betacam PB data on VPR-1B board, converted from digital to analog, and fed back is sent to the VISC phase detector circuit on TBC-23 board, where the phase of a separated VISC signal is compared with the phase of a fine-adjusted REF SC signal (IC216). IC205 outputs a "VISC DET" pulse in proper timing on the basis of various signals and information. The "VISC DET" pulse turns on and off the switch in the phase comparator IC216 to sample and hold the phase compare output signal. The resultant phase error voltage is sent to TBC-24 board as an "SCH TRACKING" signal. The signal is then added to the phase-shift circuit in Y and C write clock generator circuits so as to shift the phase of the Y and C signals and to make the phase of a subcarrier (VISC) during REC coincide with that of an output subcarrier.


DVW-A500P	S/N ; 10001 through 11695 (EK)
DVW-A500P	S/N ; 10001 through 10030 (JC)
DVW-A500	S/N ; 10001 through 10370 (U)
DVW-A500	S/N ; 10001 through 11280 (UC)
DVW-A510P	S/N ; 10001 through 10520 (EK)
DVW-A510	S/N ; 10001 through 10070 (J)
DVW-A510	S/N ; 10001 through 10250 (UC)
DVW-CA510P	S/N ; 10001 through 10020 (EK)
DVW-CA510	S/N ; 10001 through 10004 (UC)






Lot No ; 401 and higher

DVW-A500P S/N ; 11696 and higher (EK)
 DVW-A500P S/N ; 10031 and higher (UC)
 DVW-A500 S/N ; 10371 and higher (J)
 DVW-A500 S/N ; 11281 and higher (UC)
 DVW-A510P S/N ; 10520 and higher (EK)
 DVW-A510 S/N ; 10071 and higher (J)
 DVW-A510 S/N ; 10251 and higher (UC)
 DVW-CA510P S/N ; 10021 and higher (EK)
 DVW-CA510 S/N ; 10001 and higher (J)
 DVW-CA510 S/N ; 10005 and higher (UC)



This block diagram corresponds to the production lots of Lot No. 401 and higher. Circuit sections that any midway change occurred are shown using the abbreviation mentioned below.

Abbrev.	Lot No.	Board No.
Lot (a)	401-604	1-648-543-14
Lot (b)	605-	1-648-543-15



[CIRCUIT DESCRIPTION OF AP-28 BOARD]

AP-28 board is a Betacam PB AFM demodulator board that demodulates the AFM signal reproduced from an analog Betacam tape into an audio signal. This board also mounts a DOLBY decoding circuit for the audio signal (LAU signal) reproduced from the longitudinal tracks of the analog Betacam tape.

The outline of an AFM system is first described below.

In the Betacam SP format, the audio signals in channels 1 and 2 of four-channel audio input signals are recorded on the longitudinal tracks of the tape by an AC bias system, and the audio signals in channels 3 and 4 are recorded on chroma video tracks (track C) by an AFM system. The AFM system frequency-multiplexes FM-modulated audio signals into the FM-modulated chroma signal, then records it. The carrier frequencies of FM audio signals use frequencies lower than the carrier frequency of a chroma signal as described below.

Carrier frequency CH3 : 310 kHz, CH4 : 540 kHz
Maximum frequency deviation 75 kHz

To pay attention on AFM reproduction is that rotary heads C-A and C-B are switched in the course of continued signal because an audio signal contains no blanking period that a video signal contains. Since the switching noise of an RF signal appears as a high noise during FM demodulation, proper measures against the noise are required.

When the analog Betacam tape is reproduced by a digital Betacam VTR, the AFM signal is also reproduced in the form that its time base is compressed about 9% because of the difference of the drum diameter. Therefore, a circuit for time-base correction is added on AP-28 board.

The outline of an AFM signal processing circuit is described next.

The C RF signal that branches in the PB C input circuit on DM-89 board is sent to AP-28 board. This signal is sent to a 800-kHz low-pass filter to eliminate chroma signal components and to produce an AFM RF signal, then adjusted in level using an RF amplifier in the next stage.

The resultant signal is converted into eight-bit data using an A/D converter (IC308) and written in field memory (IC313) via a selector (IC311). The data is written four bits at a time using the selector. The reason is that the field memory consists of four bits per word. Among the data written in the field memory, the CH-A data reproduced by the C-A head is read from pins 5 to 8 four bits at a time and sent to IC312. The CH-B data reproduced by the C-B head is read from pins 35 to 32 four bits at a time and sent to IC312.

Each data mentioned above is restored to eight-bit data using the switch in IC312.

The above process is controlled by IC312. IC312 called a "digital AFM expander" functions as an "AFM TBC" circuit. IC312 controls a PLL circuit and generates a write clock locked to the C SH (C SELECT H) signal generated on TBC-24 board. Using this write clock, the A/D converter (IC308) samples the AFM RF signal and converts it into jitter-canceled data. IC312 also corrects the time base by reading data from the field memory (IC313) using a read clock that is generated from reference signal "REF CK 27".

For the RF signal recorded on the tape, CH-A and CH-B data are not completely switched every time the drum rotates by a half turn, but overlap areas of some hundreds of micro-

second are added before and after each channel. When the analog Betacam tape is reproduced by a digital Betacam VTR, data can be transmitted in one line until it is written in the field memory because the CH-A and CH-B data whose time base is compressed are alternately reproduced at slight intervals. However, when data is read from the field memory, the respective line is required because the time base is corrected.

IC312 alternately links the read CH-A and CH-B data whose time base is corrected and generates time-base corrected AFM RF data. At that time, IC312 uses two select switches for data fetching, and generates the AFM RF data with longer CH-A data and the AFM RF data with longer CH-B data and outputs them by setting high- and low-selection duty cycles and controlling them. These AFM RF data are passed through a D/A converter and 800-kHz low-pass filter, respectively.

As a result, the AFM RF signal with longer CH-A signal ("AFM 1" signal) and the AFM RF signal with longer CH-B signal ("AFM 2" signal) are produced.


The "AFM 1" and "AFM 2" signals are passed through AGC amplifier and branch into two paths, respectively. These signals are then passed through 310-kHz or 540-kHz bandpass filter and demodulator, respectively. As the result, four signals (CH3 audio signal with longer CH-A signal, CH3 audio signal with longer CH-B signal, CH4 audio signal with longer CH-A signal, and CH4 audio signal with longer CH-B signal) are produced.

Using two pairs of select switches (IC503 for CH3 and IC603 for CH4) for signal fetching, therefore, the CH-A and CH-B signal portions (not including a high demodulation noise occurring at the joint of RF signals) are alternately fetched and linked under the control from IC312.


After that, both signals are amplified and passed through 25-kHz low-pass filter, respectively, then sent to a noise reduction circuit (IC701) to produce noise-free AFM demodulation audio signals ("B PB CH3" and "B PB CH4"). The produced signals are sent to APR-1B board.

When a dropout occurs in the AFM RF signal, it is detected in the AGC amplifier (IC403) for the "AFM 2" signal. The dropout portion is temporarily held in each demodulator according to the dropout information, and the relevant portion of a demodulated audio signal is interpolated linearly.

Lastly, an LAU signal processing circuit is described below. The audio signals reproduced from the longitudinal tracks of the analog Betacam tape are equalized in a frequency characteristic on CUE-1B board and sent to AP-28 board. On AP-28 board, the input audio signals are compensated in the undulation of a low-frequency response using contour effect compensator, respectively. After that, the phases in both channels are adjusted using a phase adjustment circuit. The resultant audio signals are sent through 15-kHz low-pass filters to a DOLBY C noise reduction IC (IC105), where the audio signals are DOLBY-decoded and output, then sent to APR-1B board as "B PB CH1" and "B PB CH2" signals.




AP-28 Board -A Side-




Measurement Condition

MODE : PB mode

TAPE : CR5-1B (AFM 400Hz SINE WAVE)





[CIRCUIT DESCRIPTION OF SS-52B BOARD (1/3)]

SS-52B board (1/3) is a system control system block that controls man-machine interface, processor control, and overall system.

SS-52B board consists of the following blocks.

SS-52B (1/3): System control system block

SS-52B (2/3): Servo control system block

SS-52B (3/3): DT control system block

These blocks incorporate CPUs (MPU), respectively, and control their own system while they communicate mutually via dual port RAMs. Especially, the system control system controls the overall system as well as its own system. The system control system is described below.

The outline of the system control system is first described.

The CPU system which constitutes the center of the system control system consists of main and sub CPU systems. The main CPU (IC5) controls the basic functions for peripheral boards and the overall system. The sub CPU (IC50) controls the key panel including the time counter display.

The flow of the controls performed by each CPU are summarized as described below.

Main CPU

- CPU system configuration : Main CPU (V25)(IC5)
Address decoder (IC7(2/2))
ROM (256k bytes)(IC12)
RAM (32k bytes)(IC10)
NOVRAM (8k bytes)(IC13)
Interrupt controller (IC16)
- Communicates with the sub CPU via dual port RAM (IC37 and IC38).
- Communicates with the servo CPU via dual port RAM (IC34 and IC35).
- Controls DPR-36H board while exchanging the system data and control signals ("PAD 0 to 7/CONT") via parallel bus interface (IC28, IC29, and IC30).
- Controls EQ-45B board via RF block interface (IC7(1/2) and IC8).
- Controls APR-1B, FP-58B, SWC-19B, and RM-130 boards via MPU communication controller (IC25 and IC22).
- Controls VPR-1B, DM-89, and TBC-23 boards via MPU communication controller (IC27 and IC26).
- Controls the superimpose IC (IC46) via the circuit mentioned above to send character signals to VPR-1B and DIF-16B boards.
- Controls the LTC processor IC (IC42) to read the LTC signal.
- Communicates with the outside via a serial interface (IC15) by the RS-232C protocol (using the RS-232C connector).

Sub CPU

- CPU system configuration : Sub CPU (Z80)(IC50)
Address decoder (IC53(1/2))
ROM (64/256k bytes)(IC54)
RAM (8k bytes)(IC52)
- Communicates with the main CPU via dual port RAM (IC37 and IC38).
- Controls the key panel (overall lower control panel including the time counter display and search dial assembly) by the serial communication with the MPU on KY-231B board.

- Communicates with the outside via a remote interface (IC53(2/2)) by the RS-422 protocol (using the 9-pin remote connector).
- Sends a watchdog reset pulse to the main CPU when an error is detected during communication with the main CPU.

A few complementary explanation is given for the contents of the above description.

(1) NOVRAM

The NOVRAM (IC13) is used as an error logger that saves the data at that time when each error occurs. This RAM has no backup function.

(2) RF block interface

The RF block interface (IC7(1/2) and IC8) reads the D/A converter control data set in the RAM, converts the data into the serial data ("SYIF1 CMD") in which four-bit D/A channel numbers are added, and sends it to EQ-45B board together with a clock signal and strobe signals, to set the various control data to the three 12-channel D/A converter on EQ-45B board.

The RF block interface also counts the metric pulses from the VITERBI ICs on EQ-45B board, using the head select signals as the gate windows, and sends the count data to the CPU. The CPU controls the gain and phase of each equalizer circuit so that the metric pulses decrease.


(3) MPU communication controller


The MPU communication controllers (IC25 and IC22, and IC27 and IC26) can communicate with eight MPUs (maximum) by serial communication, respectively. IC25 sends a "SYIF3 CMD" command to each board together with a clock signal and chip select signals, and IC27 sends a "SYIF2 CMD" command to each board together with a clock signal and chip select signals. These commands control the basic function of the MPUs on each board.

The MPU communication controller also have 16 parallel ports (eight input ports and eight output ports). These ports are used for the input operations by switches, and the signal exchange between DPR-36H or EQ-45B board and the CPU.

For each CPU, LEDs that display each operation state are mounted on the board.

D301 displays the operation state of the main CPU, and D601 displays the operation state of the sub CPU. Each LED blinks at intervals of approximately 1 Hz if the operation state is normal.





[CIRCUIT DESCRIPTION OF SS-52B BOARD (2/3)]

SS-52B board (2/3) is a servo control system block that gathers the feedback information from sensors and mechanical devices, performs detection processing for the information, and controls the mechanical devices via DR-307/200 board according to the result of the detection.

The configuration of the servo control system block is summarized below.
The servo CPU system (IC750, etc.) constitutes the center of the servo control system, and controls the overall servo system. The servo CPU connects with the servo IC (IC774) and two I/O ports (IC762 and IC782) by data bus, and connects with the drum MPU (IC700), MPU on DR-307/200 board, by serial communication.

The outline of each portion is described below.

(1) Servo CPU system

CPU system configuration : Servo CPU (16-bit)(IC750)
Address decoder (IC756, IC757, etc.)
ROM (4M-16 bits)(IC761)
RAMs (2k bytes x 2)(IC751 and IC758)

The servo CPU constitutes the center of the servo control system. It controls the servo system except a DT function. This servo CPU communicates with the CPU of the system control system via the dual port RAM (IC34 and IC35) (on SS-52B board(1/3)) and communicates with the CPU of the DT control system via dual port RAM (IC2113 and IC2115) (on SS-52B board(3/3)).

The servo CPU has serial ports, so communicates with the drum MPU (IC700) and the MPU on DR-307/200 board in serial, and controls these MPUs.

The servo CPU has analog input terminals, so takes in motor currents, tape tensions, and other analog data, and converts them into digital data. Moreover, it takes in digital data and detection data via the MPU on DR-307/200 board and the servo IC (IC774), and controls the servo according to these data items.

(2) Servo IC

The servo IC (IC774) receives the CTL signal and various FG pulse signals that are fed back from DR-307/200 board, calculates the timing, and outputs PWM signals for each motor control to DR-307/200 board.

However, the PWM signal output from pin 31 provides a speed offset for the PLL circuit in the VITERBI processing system on EQ-45B board. The pulse width of this PWM signal varies depending on the tape speed. This signal is DC-converted using IC765, then time-shared into four PB RF identifying DC signals using analog switches (IC771 and IC775), and sent to EQ-45B board.

In addition to the above description, the servo IC also detects the rotating direction of the capstan motor, generates a 1/2 VD pulse, and outputs them.

(3) Drum MPU

The drum MPU (IC700) sends a PWM signal for drum motor control to DR-307/200 board under the control of the servo CPU, and outputs the select signals for each rotary head to EQ-45B and DPR-36H boards.


(4) CPU operation state display by LED

For each CPU, LEDs that display each operation state are mounted on the board. D711 displays the operation state of the servo CPU, and D800 displays the operation state of the drum MPU. Each LED blinks at intervals of approximately 1 Hz if the operation state is normal.

Moreover, D800 displays the drum operation state by the duty cycle of the blink. The operation of the LED that lights for a longer time indicates "DRUM LOCK". The operation of the LED that goes off for a longer time indicates "DRUM UNLOCK".


CR5-1B PB mode
(In only case of the VTR with a Betacam PB function)

① TP815(H-1) PB mode
TP817(H-1) PB mode
TP819(J-1) PB mode




ZR5-1

① TP815(H-1) PB mode
TP817(H-1) PB mode
TP819(J-1) PB mode





③ TP2803(J-1) STOP(E-E) mode




Measurement Condition
MODE : PB mode
: STOP (E-E) mode
: STILL mode
TAPE : ZR5-1
: CR5-1B

SS-52B Board -A Side-







[CIRCUIT DESCRIPTION OF SS-52B BOARD (3/3)]

SS-52B board (3/3) is a DT control system block that detects a tracking error from the PB signal of the DT head, generates a bimorph drive signal together with the feedback data processing result, and sends it to DT-34B board (bimorph drive board) for dynamic tracking.

DT control system configuration

- DT system control block
 - DT CPU system
 - Servo IC
- Tracking error detection block
 - Wobbling signal generator circuit
 - Digital tracking error detector circuit
 - Analog tracking error detector
- Bimorph control block
 - Bimorph control circuit
 - Bimorph drive circuit (DT-34B board)

The outline of each block is described below.

(1) DT system control block

The DT system control block consists of a DT CPU system (consisting of a DT CPU (IC2104), address decoder (IC2108), ROM (IC2110), and I/O port (IC2109)) and a servo IC (IC2200).

The DT CPU communicates with the servo CPU via the dual port RAM (IC2113 and IC2115), performs detection processing for the feedback data jointly with the servo IC, and controls the DT system according to the result.

The servo IC detects the tape speed from capstan FG signals, calculates the timing of the tracking from a CTL PB signal, and sends the calculated tracking data and others in the form of PWM signal to the bimorph control circuit.

(2) Tracking error detection block

Since a digital Betacam tape has a narrow track width and high trace speed, the degree and direction of a tracking error are detected from the envelope waveform of a PB RF signal by wobbling the DT head (ADVANCE head) in the PB mode. For an analog Betacam tape, the tracking data generated in the DT system control block is corrected from the PB RF level detection and from the PB phase difference detection between channels Y and C by IC2401, as before.

• Wobbling signal generator circuit

Wobbling data is generated by three CTC counters (IC2202, IC2204, and IC2207), converted into a wobbling signal of 1.5 kHz by a D/A converter (IC2210), and added to bimorph drive signals in the mode of "WOBBLING ON".

The timing pulses generated by the above CTC counters are sent through an wobbling control circuit (IC2100, IC2205, and IC2209) to the tracking error detector circuit to control the timing of the error detection.

• Digital tracking error detector circuit

The ADVANCE head is wider in width than the REC head. Two ADVANCE heads are installed on one bimorph plate in pairs so that the portions of the remaining width protrude from the both outsides of the tracks recorded in pairs.

When the bimorph plate wobbles, if the head deflects to the outside of pair tracks, the track width that can be reproduced decreases. Therefore, the amplitude of the PB RF signal decreases.

If the head deflects to the inside of pair tracks, the portion of the head got in the adjacent track cannot reproduce because the azimuth angle differs. However, since the outer edge of the track is covered by the portion of the remaining width of the head, the track width that can be reproduced does not change. For the adjacent head, the same change described above appears in an opposite phase.

If a tracking error occurs, the above change appears more remarkably in the shifted outside head. In the inside head, the change decreases. Therefore, a wobbling component (1.5 kHz) is extracted from the envelope waveform of the PB RF signal in each head, and the difference is obtained using a differential amplifier. As a result, the degree and direction of the tracking error can be detected.

IC2500 to IC2508 are a digital tracking error detector circuit. For the envelope waveform of the PB RF signal from EQ-45B board, only the video RF portion is extracted in the timing of the "PEAK HOLD OFF" signal from a wobbling control circuit, and a wobbling component is taken out using a bandpass filter of 1.5 kHz and half-wave rectified. The resultant half-wave rectification output signals in a pair channel are input to the differential amplifier to taken out the difference and passed through a low-pass filter. As the result, a DC voltage whose polarity and dimensions correspond to the direction and degree of the tracking error is obtained. This voltage is fed back to the bimorph control circuit in the corresponding channel in the mode of "WOBB A/B ON" or "WOBB C/D ON".

(3) Bimorph control block


IC2300 to IC2305 and IC2700 to IC2705 are a bimorph control circuit. In principle, the feedback strain gauge signal and the tracking data calculated by a DT system control block are compared using phase compensators (IC2300 and IC2700), and the difference voltage is output as a bimorph drive signal.

Tracking error detection data is fed back in the course of a tracking data circuit for a digital tape to correct the tracking data. For an analog tape, the tracking error detection data is fed back to the DT system control block to correct the tracking data. Moreover, for a digital tape, a wobbling signal is added to the bimorph drive signal.

An "STG OFFSET" signal contains a same noise component as in the strain gauge signal and is used to cancel the noise. The gain adjustment is performed by changing the ON/OFF duty cycle of a charge/discharge switch by a PWM signal. A "TRACK SIGN" signal inverts the polarity of a "TRACKING" signal. The band eliminators (IC2305 and IC2705) in the later stage are used to eliminate bimorph resonant frequency component of 700 to 800 Hz.


CR5-1B PB mode
(In only case of the VTR
with a Betacam PB function)

- ① TP2703(J-1) STILL mode
- TP2303(J-1) STILL mode
- TP819(J-1)(TRIG)




ZR5-1


- ① TP2703(J-1) STILL mode
- TP2303(J-1) STILL mode
- TP819(J-1)(TRIG)





SS-52B Board -A Side-



Measurement Condition
MODE : STILL mode
TAPE : ZR5-1
: CR5-1B





[CIRCUIT DESCRIPTION OF DR-200 BOARD]

DR-200 board is a servo driver board that drives the mechanical devices of each mechanical block under the control from a servo control block (on SS-52B board (2/3)), receives various sensor and FG signals, and feeds them back to the servo control block. DR-200 board also mounts the REC/PB amplifier of a CTL signal.

The configuration of DR-200 board is summarized as described below.

- Four-bit MPU (IC3) that exchanges data and commands with the servo CPU on SS-52B board (2/3) by serial communication.
- Four switching drivers that drive the motors (drum, capstan, and supply and take-up reel motors) in the tape transport system.
- Three two-way switch drivers that drive the motors (loading, position, and cassette compartment up/down motors) in the loading system.
- Five drive amplifiers that drive the solenoids (pinch, supply and take-up reel brake, and cleaning solenoids) and CC lamp.
- Wave shaping amplifiers of each FG pulse (drum, capstan, supply and take-up reel, and loading FGs).
- Detection amplifiers of tape tensions (supply and take-up tensions).
- Detection amplifier of tape ends (tape top and end).
- CTL signal REC/PB amplifier.

A complementary explanation is given for the contents of the above description.

(1) Servo driver MPU

The serial data from the servo CPU on SS-52B board is converted into parallel data by this MPU (IC3) and sent to each block on DR-200 board. This data is partially used to drive the solenoids via drive amplifiers. The signal that is fed back from each sensor is sent to this MPU as parallel data, converted into serial data, and sent to the servo CPU on SS-52B board.

Two EEPROMs (IC10 and IC25) save the servo- and DT-related adjustment data under the same contents and back up it mutually.

(2) Tape transport system motor drive

The drum motor, capstan motor, supply reel motor, and take-up reel motor that constitute the tape transport system require a high-precision control. Therefore, motor drivers for these motors receive the control signals that are sent from SS-52B board by PWM signals and perform the analog drive control by switching drivers.

That is, the chopper type switching regulator (drive voltage generator circuit) that uses a PWM power controller IC converts the voltage of +18 V supplied from the power supply block into the voltage proportional to the control signal from SS-52B board to control the motor speed.

Take the case of the drum motor driver so as to describe the theory of the switching regulator. The "DRUM PWM" control signal from SS-52B board is sent to a low-pass filter (IC39) to produce a DC signal and compared with the voltage that is fed back from the output side of the regulator in the input stage of a PWM power controller (IC700). As the result, a

PWM pulse whose pulse width varies depending on the difference voltage (error voltage) is output from IC700. This pulse drives the gate of a switching FET (Q106) via IC8. When Q106 is OFF, the current flows continuously through a flywheel diode (D102) into the inductor to charge the capacitor, by the current energy holding effect of inductor. The balanced output voltage value varies with the modulation ratio of a PWM pulse and the capacity of an output current. However, the modulation ratio of the PWM pulse is controlled so that the output voltage becomes a control target value by feeding an output voltage back to IC700.

The basic operation of the switching regulator is as described above. Since the drum motor is a three-phase brushless motor, a three-phase switching circuit that supplies a current to each winding according to the three-phase control signal (output signal of Hall device amplifier) from the drum is provided after the switching regulator.

The capstan motor incorporates a three-phase switching circuit. The rotating direction of the capstan motor is directly switched by the "CAPSTAN MOTOR DIR" signal that is sent from SS-52B board via DR-200 board. Therefore, the capstan motor operates by only sending a drive voltage from DR-200 board.

The switching regulator uses an output current detection voltage for a fed back voltage and functions as a current control type regulator.

The reel motor driver is a dual switching regulator in which switching regulators are connected to both terminals of a DC motor. This reel motor driver feeds back the detection voltage of an output current occurring due to the voltage difference at both terminals to control each output voltage.


The PWM power controller outputs an in-phase PWM pulse from pins 8 and 11, fluctuates the voltages at both terminals in the opposite direction according to the duty cycle ratio of the PWM pulse, and drives the motor differentially. In each switching converter that constitutes this regulator, a switching FET that makes a complementary pair with a drive switching FET is used instead of the flywheel diode.


(3) Loading system motor driver


For the motors in the loading system, there are a loading motor (threading motor), position motor (reel shift motor), and cassette compartment motor (up/down motor). These motor are DC motors and are driven by two-way switch driver ICs. This IC can select four states (forward rotation, reverse rotation, short-brake, and open) by two control lines.


The switching converter controlled by the "LOADING PWM" pulse from SS-52B board is used in the driver power source for the loading motor, so can also control the rotation torque of the loading motor.

DVW-A500P (EK):	S/N 10001 through 21137
DVW-A500P (UC):	S/N 10001 through 10308
DVW-A500 (J):	S/N 10001 through 12788
DVW-A500 (UC):	S/N 10001 through 18302
DVW-500P (EK):	S/N 10001 through 16515
DVW-500P (UC):	S/N 10001 through 10210
DVW-500 (J):	S/N 10001 through 10363
DVW-500 (UC):	S/N 10001 through 13179
DVW-A510P (EK):	S/N 10001 through 14220
DVW-A510 (J):	S/N 10001 through 10684
DVW-A510 (UC):	S/N 10001 through 11583
DVW-510P (EK):	S/N 10001 through 11354
DVW-510 (J):	S/N 10001 through 10100
DVW-510 (UC):	S/N 10001 through 10762
DVW-CA510P (EK):	S/N 10001 through 10075
DVW-CA510 (J):	S/N 10001
DVW-CA510 (UC):	S/N 10001 through 10015











FP-58B : Front Panel Control Board
VR-152B : Phone Level VR Board
VR-153B : Audio PB VR Board
SWC-17B : Upper Control Panel Board
SWC-18B : Sub Control Panel Board
SWC-19B : System Set-up Panel Board
KY-231B : Lower Control Panel Board
DP-176B : Time Counter Display Board
PTC-69 : Search Dial Assembly Board


FUNCTION CONTROL BLOCK

DVW-A510/510
DVW-A510P/510P
DVW-CA510/CA510P









3-3. FRAME




DVW-A510 (J) :#10121 and higher
DVW-A510 (UC) :#10277 and higher
DVW-A510P (EK) :#10751 and higher
DVW-CA510 (J) :#10001 and higher
DVW-CA510 (UC) :#10010 and higher
DVW-CA510P (EK) :#10051 and higher



Drum/Heads (Except CTL Head)
FRAME WIRING (1/3)
DVW-A510/A510P
DVW-CA510/CA510P





Drum/Heads (Except CTL Head)
FRAME WIRING (1/3)
DVW-510/510P





FL1004 and FL1005 are not equipped in the DVW-A510/510/CA510.





SECTION 4

ERROR MESSAGES AND TROUBLESHOOTING


4-1. ERROR MESSAGE

This unit features self-diagnostics.

When trouble is detected, an error code is displayed immediately in the time counter display on the lower control panel, an error code and message are superimposed on the video monitor connected to the VIDEO OUTPUT COMPOSITE 3 connector and the SERIAL V/A OUTPUT 4 connector.

Furthermore, as for the interface error (error code 92, 93, 96 and 98), interface object which error occurred replaced by sub error message on the video monitor.

(To display error code and message on the video monitor, the CHARACTER switch on the system setup panel must be set to ON.)



Code	Error message	Description	Detection
01	REEL TROUBLE-1	The slack of the tape is detected during threading or unthreading, and then tape protection is done.	Detected when the ratio of the FG frequency at a supply reel, take-up reel and threading motor is less than the specified value.
02	REEL TROUBLE-2	The slack or breaking of the tape is detected in search, fast forward, or rewind mode, and then tape protection is done.	Detected when the ratio of the FG frequency at a supply reel and take-up reel is less than the specified value.
03	REEL TROUBLE-3	The slack or breaking of the tape is detected in playback mode, or either of the lock of the supply or take-up reel is detected, and then tape protection is done.	Detected when the FG frequency at a supply or take-up reel is zero (0), or when the tension detected from a tension sensor is less than 15 g.
04	REEL TROUBLE-4	It is detected that the tape does not run at the speed of designation in fast forward or rewind mode, and then tape protection is done.	Depends on the comparison between the tape speed using the FG frequency at supply and take-up reels and the designated speed.
05	REEL TROUBLE-5	It is detected that the supply or take-up reel cannot stop with a cassette is not inserted, or detected that over current has been flowing to supply and take-up reels.	Detected using the FG frequency or current at supply and/or take-up reels.
06	TAPE TENSION ERROR	When excessive tension is detected, tape protection is done.	Detected when the tension detected from a tension sensor is more than 55 g.
07	CAPSTAN TROUBLE	It is detected that the tape does not run at the speed of designation in play or search mode, and tape protection is done.	Detected at the tape speed detected from the FG frequency at a capstan motor.
08	DRUM TROUBLE	It is detected that drum motor rotation is not normal, and then tape protection is done.	Detected when the drum speed obtained from the speed FG of the drum motor is less than the specified value.
09	TH/UNTH MOTOR TIME OUT	It is detected that threading or unthreading is not completed, and then tape protection is done.	Detected when threading or unthreading is not completed within ten seconds after it is started.
0A	THREADING TROUBLE	It is detected that threading cannot be done, and then tape protection is done.	Detected when the tape top sensor is acted during threading after the short FF mode is automatically entered three times.

(Continue)

4-1. ERROR MESSAGE

(Continued)

Code	Error message	Description	Detection
10	HUMID	Condensation is detected.	Detected using a DEW (condensation) sensor.
11	TAPE TOP/END SENSOR TROUBLE	The tape top or end sensor operation is defective.	Detected when the tape top and end are detected at the same time.
12	TAPE TOP SENSOR TROUBLE	The tape top sensor operation is defective.	Detected when the tape top continues for more than seven seconds.
13	TAPE END SENSOR TROUBLE	The tape end sensor operation is defective.	Detected when the tape end continues for more than seven seconds.
14	FAN MOTOR TROUBLE	The operation of the fan motor is defective.	Detected according to the period of a ripple noise at the fan motor terminal.
20	CASSETTE COMPARTMENT MOTOR LOCK	It is detected that cassette up/down operation is not completed, and then tape protection is done.	Detected when cassette up/down operation is not completed within four seconds after it is started.
21	REEL SHIFT MOTOR LOCK	It is detected that driving of the L position to S position or the S position to L position in the reel table is not completed, and then tape protection operation is done.	Detected when reel table driving is not completed within four seconds after it is started.
22	REEL POSITION SENSOR TROUBLE	The operation of the L/S position sensor of the reel table is defective.	Detected when the L and S positions are detected at the same time.
90	KEY BOARD INTERFACE ERROR	The interface between the KY-231B board and SS-52B board is defective.	Detected when no interface signal is sent from the SS-52B board to the KY-231B board.
91	1/2 VD NOT EXIST	No 1/2 VD signal input to SS-52B board is detected.	Detected when no 1/2 VD signal input to the SS-52B board.
92	INTERNAL INTERFACE ERROR sub error message FP APR RM SWC DPR VPR TBC DM	The serial or parallel interface between below board and SS-52B board is defective. (DPR-36H board; parallel interface) FP : IC6 of FP-58B board APR : IC51 of APR-1B board RM : IC2 of RM-130 board (BKDW-509) SWC : IC2 of SWC-19B board DPR : DPR-36H board VPR : IC753 of VPR-1B board TBC : IC202 of TBC-23 board (DVW-A510P/A510 only) DM : IC906 of DM-89 board (DVW-A510P/A510 only)	Detected when no interface signal is sent from the each board to the SS-52B board three times continuously.
93	CPU INITIALIZE ERROR sub error message DT main servo (SV1) drum servo (SV2)	The interface between below CPU on SS-52B board and main CPU (of IC5 on SS-52B board) is defective when the POWER switch is turned ON. DT : IC2104 main servo (SV1) : IC750 drum servo (SV2) : IC700	Detected when no interface signal is sent from the each CPU to the main CPU at the POWER switch is turned ON.
94	CPU INITIALIZE ERROR 2	The operational defect of main CPU (of IC5 on SS-52B board) is defective when the POWER switch is turned ON. (Not display on the video monitor)	Detected when no interface signal is sent from the main CPU to the sub CPU (of IC50 on SS-52B board) at the POWER switch is turned ON.

(Continue)

(Continued)

Code	Error message	Description	Detection
96	NV-RAM TROUBLE	The operational defect of the NV-RAM (setup menu data) on the SWC-19B board or SS-52B board is detected. Then, reset the data in the NV-RAM to the condition at exfactory for menu-1, 2, 3, and id code.	
	sub error message menu-1 menu-2 menu-3	menu-1 : IC13 of SS-52B board ^{*2} menu-2 : IC13 of SS-52B board ^{*2} menu-3 : IC13 of SS-52B board ^{*2}	Detected by the NV-RAM data's checksum.
	id code	id code : IC3, 4, 5 of SWC-19B board	Detected when the ID codes of three NV-RAMs are not equal.
	SWC-1 SWC-2 SWC-3 SWC-4	SWC-1 : IC3 of SWC-19B board SWC-2 : IC4 of SWC-19B board SWC-3 : IC5 of SWC-19B board SWC-4 : IC6 of SWC-19B board	Detected when no interface signal is sent from the each NV-RAM to IC2 on the SWC-19B board.
97	SV NV-RAM TROUBLE	The operational defect of the NV-RAM (servo adjustment data) on the DR-307/200 board is detected.	Detected by the NV-RAM data's checksum.
98 ^{*1}	NV-RAM TROUBLE sub error message RF ADJUST DATA LOST REMOTE-2 DATA RESET	The operational defect of the NV-RAM (IC6) (RF adjustment data or REMOTE-2 setup data) on the SWC-19B board is detected. Then, reset the data in the NV-RAM to the condition at exfactory.	Detected by the NV-RAM data's checksum.

^{*1} ; This error code is applied to the unit in which the version numbers of both SYS1 ROM (IC12) and SYS2 ROM (IC54) on the SS-52B board are 1.10 or higher.

^{*2} ; This description is applied to the unit in which the version numbers of both SYS1 ROM (IC12) and SYS2 ROM (IC54) on the SS-52B board are 3.10 or higher.

For the inapplicable unit, are as follows:

menu-1 : IC3 of SWC-19B board

menu-2 : IC4 of SWC-19B board

menu-3 : IC5 of SWC-19B board

SECTION 5

MAINTENANCE MODE

5-1. OUTLINE

The DVW-A510P/510P/A510/510 has the maintenance mode required for maintenance and troubleshooting. The maintenance mode is as described below.

Each mode consists of some menus and submenus.

(For the menu tree, refer to page 5-4.)

C0: SERVO/DT CHECK
 C1: RF CHECK
 C2: AUDIO/VIDEO CHECK
 C3: BETACAM PB CHECK (DVW-A510P/A510 only)
 C4: OTHERS CHECK
 A0: SERVO/DT ADJUST
 A1: RF ADJUST
 A2: AUDIO/VIDEO ADJUST
 A3: BETACAM PB ADJUST (DVW-A510P/A510 only)

The contents of the maintenance mode are superimposed on the video monitor that is connected to the VIDEO OUTPUT COMPOSITE 3 connector and SERIAL V/A OUTPUT 4 connector.

The figure below shows an example of the screen display.

MAINTENANCE MODE		
*C0 :	SERVO/DT	CHECK
C1 :	RF	CHECK
C2 :	AUDIO/VIDEO	CHECK
C3 :	BETACAM PB	CHECK
C4 :	OTHERS	CHECK
A0 :	SERVO/DT	ADJUST
A1 :	RF	ADJUST
A2 :	AUDIO/VIDEO	ADJUST
A3 :	BETACAM PB	ADJUST

DVW-A510P/A510


MAINTENANCE MODE		
*C0 :	SERVO/DT	CHECK
C1 :	RF	CHECK
C2 :	AUDIO/VIDEO	CHECK
C4 :	OTHERS	CHECK
A0 :	SERVO/DT	ADJUST
A1 :	RF	ADJUST
A2 :	AUDIO/VIDEO	ADJUST

DVW-510P/510


Superimposed Screen (Mode Screen when Maintenance Mode is Activated)

The buttons etc. related to the maintenance mode are as follows:

- ① **Time counter (Lower control panel)**
 The menu number is displayed in the blinking/lighting state during menu assignment.
 For the manual adjustment, data is displayed in the blinking state.
 Be sure to use a video monitor because the information that can be displayed on the time counter is restricted in the maintenance mode.
- ② **MENU button (Lower control panel)**
 In the maintenance mode, the MENU button has the same function as switch ⑨ S301 on the SS board.
- ③ **SET button (Lower control panel)**
 In the maintenance mode, the SET button has the same function as switch ⑧ S300 on the SS board.
 With DIP switch ⑩ S100-7 on the SS board set to ON (upper position), the maintenance mode is entered when this button is pressed while pressing the ④ CTL button in the setup menu mode.
- ④ **CTL button (Lower control panel)**
 With DIP switch ⑩ S100-7 on the SS board set to ON (upper position), the maintenance mode is entered when the ③ SET button is pressed while pressing this button in the setup menu mode.
- ⑤ **SHUTTLE button (Lower control panel)**
 When the ⑦ search dial is turned while pressing this button during manual adjustment, the adjustment data can be changed.
- ⑥ **JOG button (Lower control panel)**
 The JOG lamp lights when this button is pressed once. The ⑦ search dial is then set to the JOG mode.
 When the ⑦ search dial is turned while pressing this button during manual adjustment, the adjustment data can be changed.
- ⑦ **Search dial (Lower control panel)**
 The search dial selects each menu in the JOG mode.
 To change the adjustment data during manual adjustment, turn this search dial while pressing the ⑥ JOG button or ⑤ SHUTTLE button.
 The SHUTTLE and JOG modes are alternately selected every time this dial is pressed. The lamp (SHUTTLE or JOG) indicating the corresponding mode then lights.
- ⑧ **S300 (SS board): DIAG/ADJUST 1 switch (ADJ +)**
 Press this switch to activate the maintenance mode.
 In the maintenance mode, press this switch to execute the menu or submenu selected by the ⑦ search dial.
 In the maintenance mode, the ③ SET button is also the same in function as this switch.
- ⑨ **S301 (SS board): DIAG/ADJUST 2 switch (ADJ -)**
 In the maintenance mode, press this switch to return to the preceding screen.
 To exit the maintenance mode, press this switch when the mode screen is displayed.
 In the maintenance mode, the ② MENU button is also the same in function as this switch.
- ⑩ **S100-7 (SS board): MAINTENANCE MODE ACCESS ENABLE switch**
 To enter the maintenance mode by the button operation on the front panel, set this switch to ON (upper position) in advance.



Lower Control Panel



Switch Position on SS Board

Activating the maintenance mode

- (1) Confirm that the video monitor is connected to the VIDEO OUTPUT COMPOSITE 3 connector or SERIAL V/A OUTPUT 4 connector.
- (2) Press the ⑧ S300 (SS board).
- (3) The mode screen in the maintenance mode is displayed on the monitor screen.

Terminating the maintenance mode

- (1) Press the ② MENU button or ⑨ S301 (SS board) several times to display the mode screen.
- (2) Press the ② MENU button or ⑨ S301 (SS board) again when the mode screen is displayed. The maintenance mode is then exited.

MAINTENANCE MODE		
*C0 :	SERVO/DT	CHECK
C1 :	RF	CHECK
C2 :	AUDIO/VIDEO	CHECK
C3 :	BETACAM PB	CHECK
C4 :	OTHERS	CHECK
A0 :	SERVO/DT	ADJUST
A1 :	RF	ADJUST
A2 :	AUDIO/VIDEO	ADJUST
A3 :	BETACAM PB	ADJUST

DVW-A510P/A510

MAINTENANCE MODE		
*C0 :	SERVO/DT	CHECK
C1 :	RF	CHECK
C2 :	AUDIO/VIDEO	CHECK
C4 :	OTHERS	CHECK
A0 :	SERVO/DT	ADJUST
A1 :	RF	ADJUST
A2 :	AUDIO/VIDEO	ADJUST

DVW-510P/510



Mode Screen

Activating the maintenance mode on lower control panel

When the ⑩ S100-7 (SS board) is set to ON (upper position), the maintenance mode can be activated by the operation mentioned below.

- (1) Press the ② MENU button once.
(The mode then changes from operation mode to setup menu mode.)
- (2) Press the ③ SET button while pressing the ④ CTL button.
(The mode then changes from setup menu mode to maintenance mode.)
- (3) The mode screen in the maintenance mode is displayed on the monitor screen.


MAINTENANCE MODE



Menu Tree


*1: This mode is applied to the unit in which the version numbers of both SYS1 ROM (IC12) and SYS2 ROM (IC54) on the SS board are 1.10 or higher.
*2: These modes are applied to the unit in which the three version numbers of SYS1 ROM (IC12), SV1 ROM (IC761), and DT ROM (IC211) on the SS board are 2.00 or higher.
*3: The A1B and A1C modes are applied on the unit in which the two version numbers of SYS1 ROM (IC12) and SV1 ROM (IC761) are 2.10 or higher.
*4: This mode is applied to the unit in which the version numbers of both SYS1 ROM (IC12) and SYS2 ROM (IC54) on the SS board are 3.10 or higher.

5-2. SERVO/DT SYSTEM CHECK MODE (C0: SERVO/DT CHECK)



5-2-1. Servo System Check 1 (C00: INPUT CHECK)

This section describes the “C00: INPUT CHECK” mode.



a) C000: CASSETTE SW

This mode checks the functions of the cassette tab sensors (switches).

Confirm that lowest digit “0” of the corresponding switch number on the monitor screen changes to “1” when switches/sensors ① through ⑥ in the figure below are pressed manually. Also confirm that the lowest digit returns from “1” to “0” when they are released.

In case of NG;

When “1” is not displayed in the specified position or when the display does not return from “1” to “0” .

Check the corresponding sensors on the PTC-59 board.

Also check the sensor input circuit on the DR-307/200 board.


```

SERVO CHECK
INPUT CHECK

C000:CASSETTE SW
1:REEL HUB      2:METAL/OX
3:THICKNESS    4:SPARE
5:SPARE         6:DGTL/ANLG
7:N.A.         8:N.A.

                                123
SW 87654321                4 5
00000000                    6

```



b) C001: CASSETTE COMP. SW

This mode checks the functions of the sensors (switches) in the compartment block.

Confirm that the corresponding switch number on the monitor screen changes to "■" when switches SW1 through SW3 in the figure below are pressed manually. Also confirm that "■" changes to the corresponding number when they are released.

In case of NG;

When "■" is not displayed in the specified position or when the display does not return from "■" to the corresponding number.

Check the corresponding sensors on the PC-70 board.


Also check the sensor input circuit on the DR-307/200 board.

**SERVO CHECK
INPUT CHECK**


C001: CASSETTE COMP. SW
SW1: CASSETTE IN SW 1
SW2: CASSETTE IN SW 2
SW3: LARGE CASSETTE SW

3 1 2

Push the cassette window up manually.



Switch Position in Compartment Block



Top View of the Cassette Compartment

c) C002: TOP/END SENSOR

This mode checks the function of the tape top and end sensors.

Confirm that the "OFF" display on the monitor screen changes to "ON !" when a screwdriver is brought near sensors ① and ② in the figure below. Also confirm that the display changes from "ON !" to "OFF" when the screwdriver is released from the sensors.

In case of NG;


When "ON !" is not displayed in the specified position or when the display does not return from "ON !" to "OFF" .

Check only the sensors.

Also check the sensor input circuit on the DR-307/200 board.

**SERVO CHECK
INPUT CHECK**
C002: TOP/END SENSOR

END SENSOR	TOP SENSOR
OFF	OFF



d) C003: DEW SENSOR

This mode checks the function of the DEW (dew detection) sensor.

- (1) Confirm that the “DRY” display on the monitor screen changes to “WET !” when the sensor is slightly touched with a cotton swab moistened with water.
- (2) Wipe the sensor with a dry cotton swab to eliminate water. Confirm that the display on the monitor screen returns from “WET !” to “DRY” when a wind is blown against the sensor using a blower to evaporate moisture.

In case of NG;


When the display does not change from “DRY” to “WET !” even if the sensor is moistened.

Check only the sensor.

SERVO CHECK
INPUT CHECK


C003:DEW SENSOR

DEW SENSOR : DRY



5-2-2. Servo System Check 2 (C01: MOTOR CHECK)

This section describes the "C01: MOTOR CHECK" mode.



a) C010: S REEL MOTOR

This mode checks the rotation of the S reel motor.

Turn the S reel motor using a search dial (JOG mode).

Dial	Rotation direction of the S reel motor
FWD	FORWARD (⤵)
REV	REVERSE (⤴)

Confirm that the S reel motor rotates in the direction specified by the dial after the S brake solenoid is turned on and after the S reel brake is released.

In case of NG;

When the ON operation sound of the S brake solenoid is not generated or when the S reel motor does not rotate in the direction specified by the dial.

Check the S reel motor driver circuit (DR-307/200 board).

SERVO CHECK
MOTOR CHECK
C010:S REEL MOTOR

TURN JOG DIAL
IN JOG MODE

S301(SS-52): RETURN

b) C011: T REEL MOTOR

This mode checks the rotation of the T reel motor.

Turn the T reel motor using a search dial (JOG mode).

Dial	Rotation direction of the T reel motor
FWD	FORWARD (⤵)
REV	REVERSE (⤴)

Confirm that the T reel motor rotates in the direction specified by the dial after the T brake solenoid is turned on and after the T reel brake is released.

In case of NG;


When the ON operation sound of the T brake solenoid is not generated or when the T reel motor does not rotate in the direction specified by the dial.

Check the T reel motor driver circuit (DR-307/200 board).

SERVO CHECK
MOTOR CHECK
C011:T REEL MOTOR

TURN JOG DIAL
IN JOG MODE

S301(SS-52): RETURN




c) C012: THREADING MOTOR

This mode checks the rotation of the threading motor, and the functions of the thread end sensor and unthread end sensor.

Turn the threading motor using a search dial (JOG mode). As a result, the thread ring moves as shown in the table below.

Dial	Movement of the threading ring
FWD	Threading
REV	Unthreading

Confirm that the display on the monitor screen changes as shown below.



Threading Motor Check

```
SERVO CHECK
MOTOR CHECK
C012:THREADING MOTOR

*** UNTHREAD END ***

TURN JOG DIAL
IN JOG MODE
FWD:THREAD, REV:UNTH

S301(SS-52): RETURN
```


In case of NG;

When the threading motor does not rotate.

- Check the threading motor and the FG sensor on the PTC-54 board.
- Also check the threading motor driver circuit (DR-307/200 board) and the threading FG amplifier circuit (DR-307/200 board).

When the display remains “.....” with the unit set to the thread end/unthread end state.

- Check the thread end sensor and unthread end sensor on the TR-79 board.



d) C013: CASSETTE COMP.

This mode checks the operation of the cassette compartment motor, and the function of the cassette down sensor.

- (1) Press the SET button (or switch S300 on the SS board).
Confirm that the compartment block goes down. At that time, confirm that the display on the monitor screen changes as shown below.

UP → HORIZ. → VERT. → DOWN

- (2) Press the SET button (or switch S300 on the SS board) again.
Confirm that the compartment block goes up. At that time, confirm that the display on the monitor screen changes as shown below.

DOWN → VERT. → HORIZ. → UP

In case of NG;

When the cassette compartment motor does not rotate.

Check the cassette compartment motor.

Also check the cassette compartment motor driver circuit (DR-307/200 board).

When the compartment block goes up and down normally, but the display does not change.


Check the cassette down sensor.

Also check the sensor input circuit on the DR-307/200 board.

SERVO CHECK
MOTOR CHECK
C013: CASSETTE COMP.

UP

S300 (SS-52): CHECK
S301 (SS-52): RETURN



Top View of the Cassette Compartment

e) C014: CAPSTAN MOTOR

This mode checks the rotation direction of the capstan motor.

- (1) Press the SET button (or switch S300 on the SS board).
Confirm that the capstan motor rotates in the forward direction () and that the "FORWARD OK" display appears on the monitor screen.
- (2) Press the SET button (or switch S300 on the SS board) again.
Confirm that the capstan motor rotates in the reverse direction () and that the "REVERSE OK" display appears on the monitor screen.

In case of NG;

When the capstan motor does not rotate.

Check the capstan motor.

Also check capstan motor driver circuit (DR-307/200 board).

When the capstan motor rotates normally, but the "OK" display does not appear on the monitor screen.

Check the capstan motor.

Also check the capstan FG amplifier input circuit (DR-307/200 board).

```
SERVO CHECK
MOTOR CHECK
C014:CAPSTAN MOTOR
```

```
S300(SS-52): CHECK
S301(SS-52): RETURN
```

f) C015: DRUM MOTOR

This mode checks the rotation of the drum motor.

- (1) Press the SET button (or switch S300 on the SS board) to initiate this check.
The display on the monitor screen at that time is as shown below.
SPEED : NG
PHASE : UNLOCK
PG : NO EXIST

- (2) Confirm that the display on the monitor screen changes as shown at right after a little while.

In case of NG;

When the display on the monitor screen does not change.

Check the drum motor driver circuit (DR-307/200 board), the drum FG amplifier circuit (DR-307/200 board), and the drum PG amplifier circuit (DR-307/200 board).

```
SERVO CHECK
MOTOR CHECK
C015:DRUM MOTOR
```

```
SPEED :
PHASE :
PG :
```

```
S300(SS-52): CHECK
S301(SS-52): RETURN
```

SET or S300

```
SERVO CHECK
MOTOR CHECK
C015:DRUM MOTOR
```

```
SPEED : OK
PHASE : LOCK
PG : EXIST
```


```
S300(SS-52): CHECK
S301(SS-52): RETURN
```

Check completed (OK)

g) C016: REEL SHIFT MOTOR

This mode checks the operation of the reel shift motor, and the function of the reel position sensor.

Confirm that the reel table moves from the S position to the L position (from the L position to the S position) when the SET button (or switch S300 on the SS board) is pressed. Also confirm that the display on the monitor screen changes as shown below.



**SERVO CHECK
MOTOR CHECK
C016: REEL SHIFT MOTOR**

S-POSITION

**S300(SS-52): CHECK
S301(SS-52): RETURN**

In case of NG;


When the reel shift motor does not rotate.

Check the reel shift motor.

Also check the reel shift motor driver circuit (DR-307/200 board).


When the display remains "....." with the reel table moved to the L position or S position.

Check the L position/S position sensor (PTC-71 board).



5-2-3. Servo System Check 3 (C02: PLUNGER SOLENOID CHECK)

This section describes the "C02: PLUNGER SOLENOID CHECK" mode.



a) C020: PINCH ROLLER

This mode checks the operation of the pinch roller solenoid.

- (1) Press the SET button (or switch S300 on the SS board).
Confirm by the generation of a sound that the pinch solenoid is turned on.
- (2) Press the MENU button (or switch S301 on the SS board).
The drive voltage of the pinch solenoid is then turned off.
The monitor screen returns to the submenu.
- (3) Push the pinch lever slightly in the direction of the pinch solenoid with fingers.
The core of the pinch solenoid then returns to the former position.

SERVO CHECK
PLUNGER SOLENOID CHECK
C020:PINCH ROLLER


S300(SS-52): CHECK
S301(SS-52): RETURN

In case of NG;

When the sound indicating that the pinch solenoid is turned on is not generated or when the monitor screen does not change.

Check the pinch solenoid.

Also check the solenoid driver circuit on the DR-307/200 board.



b) C021: S REEL BRAKE

This mode checks the operation of the S reel brake solenoid.

- (1) Press the SET button (or switch S300 on the SS board).
Confirm by the generation of a sound that the S reel brake solenoid is turned on.
- (2) Press the MENU button (or switch S301 on the SS board).
The core of the S reel brake solenoid then returns to the former position.
The monitor screen returns to the submenu.

In case of NG;

When the sound indicating that the S reel brake solenoid is turned on is not generated or when the monitor screen does not change.

Check the S reel brake solenoid.

Also check the solenoid driver circuit on the DR-307/200 board.

SERVO CHECK
PLUNGER SOLENOID CHECK
C021:S REEL BRAKE

S300(SS-52): CHECK
S301(SS-52): RETURN

c) C022: T REEL BRAKE

This mode checks the operation of the T reel brake solenoid.

- (1) Press the SET button (or switch S300 on the SS board).
Confirm by the generation of a sound that the T reel brake solenoid is turned on.
- (2) Press the MENU button (or switch S301 on the SS board).
The core of the T reel brake solenoid then returns to the former position.
The monitor screen returns to the submenu.

In case of NG;


When the sound indicating that the T reel brake solenoid is turned on is not generated or when the monitor screen does not change.

Check the T reel brake solenoid.

Also check the solenoid driver circuit on the DR-307/200 board.

SERVO CHECK
PLUNGER SOLENOID CHECK
C022:T REEL BRAKE

S300(SS-52): CHECK
S301(SS-52): RETURN



d) C023: CLEANING ROLLER

This mode checks the operation of the cleaning roller solenoid.

- (1) Press the SET button (or switch S300 on the SS board).
Confirm that the cleaning roller solenoid is activated, the cleaning roller touches the drum, and it is immediately released from the drum.
- (2) Press the MENU button (or switch S301 on the SS board).
The monitor screen returns to the submenu.

Note: The cleaning roller solenoid is burned when it continuously remains on. If the cleaning roller solenoid is not released from the drum, turn the power of this unit off as soon as possible.

SERVO CHECK
PLUNGER SOLENOID CHECK
C023:CLEANING ROLLER


S300(SS-52): CHECK
S301(SS-52): RETURN

In case of NG;

When the cleaning roller dose not touch the drum or it is not release from the drum.


Check the cleaning roller solenoid.

Also check the solenoid driver circuit on the DR-307/200 board.



5-2-4. Servo System Check 4 (C03: REEL/CAPSTAN MOTOR & FG CHECK)

This section describes the “C03: REEL/CAPSTAN MOTOR & FG CHECK” mode.



a) S REEL FG/MOTOR CHECK

Checks the duty cycle of the S reel FG.

In case of NG;

Check the S reel motor (C010: S REEL MOTOR).

If no abnormality is found, adjust the duty cycle of the S reel FG (A001: S REEL FG DUTY).

b) T REEL FG/MOTOR CHECK

Checks the duty cycle of the T reel FG.

In case of NG;

Check the T reel motor (C011: T REEL MOTOR).

If no abnormality is found, adjust the duty cycle of the T reel FG (A002: T REEL FG DUTY).

c) CAPSTAN FG/MOTOR CHECK

Checks the duty cycle of the capstan FG.

In case of NG;

Check the capstan motor (C014: CAPSTAN MOTOR).

If no abnormality is found, adjust the duty cycle of the capstan FG (A003: CAPSTAN FG DUTY).

d) S REEL OFFSET/FRICTION

Checks the offset and friction levels of the S reel.

In case of NG;

Check the S reel motor (C010: S REEL MOTOR).

If no abnormality is found, adjust the offset and friction of the S reel (A004: S REEL OFFSET/FRIC).

e) T REEL OFFSET/FRICTION

Checks the offset and friction levels of the T reel.

In case of NG;

Check the T reel motor (C011: T REEL MOTOR).

If no abnormality is found, adjust the offset and friction of the T reel (A005: T REEL OFFSET/FRIC).

f) S REEL MOTOR TORQUE

Checks the torque of the S reel.

In case of NG;

Check the S reel motor (C010: S REEL MOTOR).

If no abnormality is found, adjust the torque of the S reel (A006: S REEL TORQUE).

g) T REEL MOTOR TORQUE

Checks the torque of the T reel.


In case of NG;

Check the T reel motor (C011: T REEL MOTOR).

If no abnormality is found, adjust the torque of the T reel (A007: T REEL TORQUE).

5-2-6. Digital DT System Check (C05: DIGITAL DT CHECK)

This section describes the "C05: DIGITAL DT CHECK" mode.



a) C050: DT DRIVER CHECK

This mode checks the bimorph drive control circuit (on the SS board) by the loopback in a bimorph drive amplifier (on the DT-34B board).

(1) Set the "*" mark to "Start auto check" using a search dial (JOG mode).

(2) When the SET button (or switch S300 on the SS board) is pressed after the "Push SET button" message is displayed, this check is initiated.

(3) Confirm that the check is completed and that the "CHECK COMPLETE" message is displayed on the monitor screen.

```

DIGITAL DT CHECK
C050:DT DRIVER CHECK

*No operation
Start auto check
  
```

(1) DIAL
(2) **SET** or **S300**

```

DIGITAL DT CHECK
C050:DT DRIVER CHECK

No operation
*Start auto check

CHECKING.....
  
```

During check

```

DIGITAL DT CHECK
C050:DT DRIVER CHECK

No operation
*Start auto check

CHECK COMPLETE
  
```

Check completed (OK)

In case of NG; (The screen at right is one example.)

When the "CHECK COMPLETE" message is not displayed on the monitor screen.

Check bimorph drive amplifier (DT-34B board) and slip ring.

Also check the bimorph drive control circuit (SS board).

```

DIGITAL DT CHECK
C050:DT DRIVER CHECK

No operation
*Start auto check


# CHECK INCOMPLETE #
A/Bch
  
```

Check completed (NG)

b) C051: SG LOOP CHECK


This mode checks the feedback loop of the strain gauge.

(1) Set the "*" mark to "Start auto check" using a search dial (JOG mode).




(2) When the SET button (or switch S300 on the SS board) is pressed after the "Push SET button" message is displayed, this check is initiated.

(1) DIAL
(2) or



During check

(3) Confirm that the check is completed and that the "CHECK COMPLETE" message is displayed on the monitor screen.




Check completed (OK)

In case of NG; (The screen at right is one example.)

When the "CHECK COMPLETE" message is not displayed on the monitor screen.

Execute the DT driver check (C050: DT DRIVER CHECK).


If no abnormality is found in this case, check the advance head/strain gauge of the inner drum or its signal transmission system (slip ring etc.).



Check completed (NG)

5-2-7. Analog DT System Check (For DVW-A510P/A510) (C06: ANALOG DT CHECK)

This section describes the "C06: ANALOG DT CHECK" mode.



a) C060: SG LOOP CHECK

This mode checks the feedback loop of the strain gauge for Betacam playback.

When a Betacam cassette tape is inserted into this unit, this check is initiated automatically.

(To put the unit into the Betacam PB mode, the Betacam cassette tape is inserted irrespective of its contents.)

Confirm that the check is completed and that the "CHECK COMPLETE" message is displayed on the monitor screen.


Press the MENU button (or switch S301 on the SS board) two times to return to the servo/DT system check mode menu. The cassette tape is ejected automatically.

In case of NG; (The screen at right is one example.)


When the "CHECK COMPLETE" message is not displayed on the monitor screen.

Execute the strain gauge loop check (C051: SG LOOP CHECK) in the digital DT system.


If no abnormality is found, check the Betacam PB bimorph head/strain gauge of the inner drum or its signal transmission system (slip ring etc.).




Insert a Betacam cassette tape



During check



Check completed (OK)




Check completed (NG)

5-3. RF SYSTEM CHECK MODE (C1: RF CHECK)

This mode can check the RF system.

For how to activate and terminate the maintenance mode, refer to page 5-3.




(Above screen is displayed for the DVW-A510P/A510.)

C10: CHANNEL CONDITION

Can display the error condition in all the video and audio channels during PB in units of three stages on the monitor screen.

For more details, refer to next page.



a) C10: CHANNEL CONDITION

This mode can display the error condition in all the video and audio channels during PB in units of three stages on the monitor screen.

The channel condition indicator on the upper control panel indicates the error condition in the worst channel among all the video and audio channels.

- (1) Press the SET button (or switch S300 on the SS board) on the screen at right.
At that time, the unit temporarily exits the maintenance mode. This enables the normal operation.
(Prompt "■" is displayed in the upper right position of the superimposed screen, and the time counter is put into the normal state.)

- (2) Insert the cassette tape recorded by the digital Betacam and play back it in PLAY mode. The ">>>" display then appears on the monitor screen.

Confirm that the ">>>" display appears in the Grn position in all the channels.

- (3) To terminate the operation, stop the tape running and eject the cassette tape.
(The ">>>" display disappears.)
Press the MENU button (or switch S301 on the SS board) to return to the maintenance mode.
(The "■" display disappears on the monitor screen, and the time counter displays menu number C10.)

When the ">>>" display appears in positions other than "Grn", clean the drum (rotary heads).

- (a) Cleaning by the cleaning tape (Refer to Section 1-11-1.)

* Cleaning time is five seconds.

- (b) Cleaning by the cleaning cloth (Refer to Section 1-11-2.)

If the channel condition is not improved after performing the step (a) and (b), there is a possibility to improve the situation by use of cleaning tape repeatedly.

It should be less than 4 times of 5 seconds cleaning in total.

If the channel condition is not improved in the way mentioned above, the possible causes below are considered.

Playback tape fault:

- The tape is damaged.
- The recording state is bad.

Main unit faults:

- Tape running system adjustment defect/part installation defect
- RF system adjustment defect
- DT system adjustment defect
- Worn head
- Harness defect
- Brush/Slip ring defect
- Circuit defect

RF CHECK MODE		
C10:CHANNEL CONDITION		
	Grn	Yel Red
VIDEO Ach		
VIDEO Bch		
VIDEO Cch		
VIDEO Dch		
AUDIO Ach		
AUDIO Bch		
AUDIO Cch		
AUDIO Dch		

- (1) SET or S300
- (2) Playback

RF CHECK MODE ■		
C10:CHANNEL CONDITION		
	Grn	Yel Red
VIDEO Ach	>>>	
VIDEO Bch	>>>	
VIDEO Cch	>>>	
VIDEO Dch	>>>	
AUDIO Ach	>>>	
AUDIO Bch	>>>	
AUDIO Cch	>>>	
AUDIO Dch	>>>	


- (3) EJECT
MENU or S301

RF CHECK MODE		
C10:CHANNEL CONDITION		
	Grn	Yel Red
VIDEO Ach		
VIDEO Bch		
VIDEO Cch		
VIDEO Dch		
AUDIO Ach		
AUDIO Bch		
AUDIO Cch		
AUDIO Dch		

RF CHECK MODE ■		
C10:CHANNEL CONDITION		
	Grn	Yel Red
VIDEO Ach	>>>	
VIDEO Bch	>>>	
VIDEO Cch	>>>	
VIDEO Dch	>>>	
AUDIO Ach	>>>	
AUDIO Bch	>>>	
AUDIO Cch	>>>	
AUDIO Dch	>>>	

5-4. AUDIO/VIDEO SYSTEM CHECK MODE (C2: AUDIO/VIDEO CHECK)

This mode sets the audio/video signal generator operations during maintenance mode execution.
For how to activate and terminate the maintenance mode, refer to page 5-3.



a) C21: VIDEO TEST SG

This mode selects the operation of the internal video test signal generator in the maintenance mode.

OFF: Stops the operation of the video test signal generator.

Except OFF (mentioned below):

Outputs a selected signal from the video test signal generator.

100% color bars

75% color bars

75% reverse color bars

Bowtie

Pulse and bar

Multi burst

H sweep

5-step

Ramp

Shallow ramp

Red signal

50% flat

100% flat

Black burst

Pathological check code

Line 330 (625)-----DVW-A510P/510P only

NTC7 (NTSC)-----DVW-A510/510 only

Selection method

To display the desired setting, turn the search dial while pressing and holding the JOG (or SHUTTLE) button. The test signal specified in this case is continuously output from a video test signal generator until the maintenance mode is terminated or until this setting is changed.

b) C23: AUDIO TEST SG

This mode selects the operation of the internal audio test signal generator in the maintenance mode.

OFF: Stops the operation of the audio test signal generator.

Except OFF (mentioned below):

Outputs the selected signal from the audio test signal generator.

SILENCE

1 kHz sine 0 VU

1 kHz sine burst/1-field

1 kHz sine burst/2-field

1 kHz sine burst/5-field

1 kHz sine burst/8-field

1 kHz sine burst (10)

4 kHz sine burst (40)

SAW(sawtooth) wave

Selection method

To display the desired setting, turn the search dial while pressing and holding the JOG (or SHUTTLE) button. The test signal specified in this case is continuously output from the audio test signal generator until the maintenance mode is terminated or until this setting is changed.

5-5. BETACAM PB SYSTEM CHECK MODE (For DVW-A510P/A510) (C3: BETACAM PB CHECK)

This mode can check the Betacam PB system.

For how to activate and terminate the maintenance mode, refer to page 5-3.

Exclusive mode for
the DVW-A510P/A510

MAINTENANCE MODE

C0 : SERVO/DT CHECK
C1 : RF CHECK
C2 : AUDIO/VIDEO CHECK
*C3 : BETACAM PB CHECK
C4 : OTHERS CHECK
A0 : SERVO/DT ADJUST
A1 : RF ADJUST
A2 : AUDIO/VIDEO ADJUST
A3 : BETACAM PB ADJUST

BETACAM PB CHECK MODE

*C30:CHANNEL CONDITION

C30: CHANNEL CONDITION

Can display the error condition in Betacam PB video channels (Y and C) in units of three stages on the monitor screen.

For more details, refer to next page.

BETACAM PB CHECK MODE
C30:CHANNEL CONDITION

ENV Ych Grn Yel Red
ENV Cch

C3
SET

MENU

C30 SET

MENU

a) C30: CHANNEL CONDITION

This mode can display the error condition in Betacam PB video channels (Y and C) in units of three stages on the monitor screen.

The channel condition indicator on the upper control panel indicates the bad channel state of the error condition.

- (1) Press the SET button (or switch S300 on the SS board) on the screen at right.
At that time, the unit temporarily exits the maintenance mode. This enables the normal operation.
(Prompt "■" is displayed in the upper right position of the superimposed screen, and the time counter is put into the normal state.)

- (2) Insert the recorded Betacam cassette tape.

- (3) Press the PLAY button.
The ">>>" display then appears on the monitor screen.

Confirm that the ">>>" display appears in the "Grn" position in both channels.

- (4) To terminate the operation, stop the tape running and eject the cassette tape.
(The ">>>" display disappears.)
Press the MENU button (or switch S301 on the SS board) to return to the maintenance mode.
(The "■" display disappears on the monitor screen, and the time counter displays menu number C30.)

```

BETACAM PB CHECK MODE
C30:CHANNEL CONDITION

      |Grn|Yel|Red|
ENV Ych
ENV Cch
  
```

- (1) SET or S300
- (2) Insert a Betacam tape
- (3) PLAY

```

BETACAM PB CHECK MODE ■
C30:CHANNEL CONDITION

      |Grn|Yel|Red|
ENV Ych  >>>
ENV Cch  >>>
  
```

- (4) EJECT
MENU or S301

```

BETACAM PB CHECK MODE
C30:CHANNEL CONDITION

      |Grn|Yel|Red|
ENV Ych
ENV Cch
  
```

When the ">>>" display appears in positions other than "Grn", clean the drum (rotary heads).

- (a) Cleaning by the cleaning tape (Refer to Section 1-11-1.)

*Cleaning time is five seconds.

- (b) Cleaning by the cleaning cloth (Refer to Section 1-11-2.)

If the channel condition is not improved after performing the step (a) and (b), there is a possibility to improve the situation by use of cleaning tape repeatedly.

It should be less than 4 times of 5 seconds cleaning in total.

If the channel condition is not improved in the way mentioned above, the possible causes below are considered.

Playback tape fault:

- The tape is damaged.

- The recording state is bad.

Main unit faults:

- Tape running system adjustment defect/part installation defect
- RF system adjustment defect
- DT system adjustment defect
- Worn head
- Harness defect
- Brush/Slip ring defect
- Circuit defect


```


BETACAM PB CHECK MODE ■
C30:CHANNEL CONDITION

      |Grn|Yel|Red|
ENV Ych  >>>
ENV Cch  >>>
  
```

5-6. OTHERS CHECK MODE (C4: OTHERS CHECK)

This section describes the "C4: OTHERS CHECK" mode.
For how to activate and terminate the maintenance mode, refer to page 5-3.





a) **C40: ROM VERSION**


This mode displays the version of the ROM (including the ROM in a microprocessor) that exists in this unit. It also displays the installed option (BKDW-).

The screen at right is displayed when both an audio program play board (BKDW-507) and parallel (50-pin) interface board (BKDW-509) are installed in the DVW-A510P.

The display description is shown below.

OTHERS CHECK MODE			
C40:ROM VERSION			
DVW-A510P			
(with BKDW-507,509)			
SYS1	V1.00	SYS2	V1.00
SV1	V1.00	SV2	V1.00
DT	V1.00	DR	V1.00
APR	V1.00	VPR	V1.00
FP	V1.00	FL	V1.00
KY	V1.00	SWC	V1.00
DM	V1.00	TBC	V1.00
RM	V1.00		

This version value is one example.



b) **C41: SERIAL NUMBER**

ISR use

Displays/sets the serial number. This is setting requisite for the ISR. Setting performs at each digit. (Blinking a digit can change.) Displays "-----" when the serial number is not set.

Setting

- (1) Trun the search dial(JOG mode) to blinking digit.
- (2) Trun the search dial while pressing the JOG button to display the desire number.
- (3) For other digits to be set, repeat steps (1) and (2).
- (4) Press the SET button (or switch S300 on the SS board). Setting is then completed.

OTHERS CHECK MODE	
C41:SERIAL NUMBER	
10001	

Above screen is one example.

c) C42: RS-232C STATUS

ISR use

Displays the RS-232C port status, and sets the baud rate and flow control requisite for the ISR.

Setting (Baud rate or Flow control)

- (1) Align “*” mark with the item to be set using the search dial(JOG mode).
- (2) To display the desire setting, trun the search dial while pressing the JOG button.
- (3) Press the SET button (or switch S300 on the SS board). Setting is then completed.

The display description is shown below.

OTHERS CHECK MODE			
C42:RS-232C STATUS			
*BAUD RATE	19.2K		
FLOW CONTROL	H/W		
ISR [	]		
ID [DigiBeta-1	]		
PE 00	FE 00	OE 00	
TXD(2)0000	RXD(3)0000		
RTS(4) ON	CTS(5) ON		
DSR(6) ON	DCD(8) ON		
DTR(20) ON			

Above screen is one example.

- ① Selects the buad rate from the followings.
1200, 2400, 4800, 9600, 19.2K (bps)
- ② Selects/changes the flow control of transmitting side from the followings.
H/W ; Hardware control
XOFF ; XON/XOFF control
H/W,XOFF ; Both the hardware and XON/XOFF
- ③ Protocol state indication
ISR x[yyyy.....]
 - Displays last correctly recieving command
(Displays former recieving command till ACK transmitting is completed.)
 - Displays the protocol status of the unit.
A ; on ACK transmission
N ; on NAK transmission
T ; on ATN (OPC or QRESP) transmission
W ; waiting for ACK
X ; XOFF received, waiting for XON
- ④ Device ID is desplayed a name that sets by DEVID command of ISR protocol.
Even if the power is turned off, this device ID is kept till it changes by DEVID command.
- ⑤ Displays the number of the parity error (PE), framing error (FE), and overrun error (OE) of receiving data.
- ⑥ The number with () indicates the pin number of RS-232C connector.
The four figures (hexadecimal) at TXD or RXD indicates the number of correctly transmitting or recieving data (byte).
Other items indicates the pin state with ON(> +3 V) or OFF(< -3 V).
When RS-232C port connects with computer &c., normally turns all ON.
When not connected, the state of input pins (CTS, DSR, DCD) are undefined.

OTHERS CHECK MODE			
C42:RS-232C STATUS			
*BAUD RATE	19.2K	①	
FLOW CONTROL	H/W	②	
ISR [	]	③	
ID [DigiBeta-1	]	④	
PE 00	FE 00	OE 00	⑤
TXD(2)0000	RXD(3)0000		
RTS(4) ON	CTS(5) ON		
DSR(6) ON	DCD(8) ON		⑥
DTR(20) ON			

d) C45: MEMORY CHECK

This mode displays the data in the ROM that exists in this unit (in hexadecimal).

Move the “*” mark upward or downward using a search dial (JOG mode).
The address and data display areas are then scrolled.

Factory use

OTHERS CHECK MODE			
C45:MEMORY CHECK			
*0000	:	24 07 00 F0	
0004	:	24 07 00 F0	
0008	:	24 07 00 F0	
000C	:	24 07 00 F0	
0010	:	24 07 00 F0	
0014	:	24 07 00 F0	
0018	:	24 07 00 F0	
001C	:	24 07 00 F0	
0020	:	24 07 00 F0	
0024	:	24 07 00 F0	

This data value is one example.

e) C46: HOUR METER

This mode can display and reset the resetable hours meter and thread counter of this unit.

Display description

DRUM HOURS : Drum rotation time
TAPE HOURS : Tape running time
THREAD COUNTER : Number of threading times

Resetting

- (1) Align the “*” mark with the item to be reset using a search dial (JOG mode).
- (2) Turn the search dial in the reverse direction while pressing the JOG (or SHUTTLE) button. The display value then becomes zero (“0”).
To return the display value to the former value after that, turn the search dial in the forward direction.
- (3) For other items to be reset, repeat steps (1) and (2).
- (4) Press the SET button (or switch S300 on the SS board). Resetting is then completed.

OTHERS CHECK MODE			
C46:HOOR METER			
*DRUM HOURS		234	
TAPE HOURS		123	
THREAD COUNTER		1234	

This value is one example.

f) C47: METER HEAD ROOM

This mode selects the head room of the audio level meter from the following.
20 dB, 18 dB, 16 dB, 15 dB*, 14 dB, 12 dB, 9 dB*-----DVW-A510P/510P only
20 dB, 18 dB, 16 dB, 14 dB, 12 dB-----DVW-A510/510 only

Selection method

- (1) To display the desire setting, turn the search dial while pressing the JOG (or SHUTTLE) button.
- (2) Press the SET button (or switch S300 or the SS board). Setting is then completed.

*1; These head rooms are added to the unit in which the APR microprocessor (IC753 on the APR board) version is 1.04 or higher, and FL microprocessor (in audio level meter) version is 1.01.

OTHERS CHECK MODE			
C47:METER HEAD ROOM			
*		20dB	

g) C48 : BKDW-509 SETUP

This menu changes/resets the BKDW-509 setup data (input/output pins function of the parallel interface). Also displays the logic level of the input/output pins. This menu is not displayed when the BKDW-509 is not installed.

The C480 mode changes the setup data of the input pins function, and displays the logic level of it.

The C481 mode changes the setup data of the output pins function, and displays the logic level of it.

The C482 mode saves the setup data in an NV-RAM, returns it to the previous state without saving, or resets it to the factory data.

The C48 menu is applied on the unit in which the version No. of both SYS1 ROM (IC12) and SYS2 ROM (IC54) on the SS board are 1.10 or higher.

(The BKDW-509 does not operate when the above two ROM's version No. are each less than 1.10. To operate the version-up of the two ROMs is required.)

(The monitor screen is displayed as an example of "C480 : INPUT PIN ASSIGN". The displayed data value and logic level are an example.)

Display Description

The pin numbers are displayed at the column of "No.".

Also the right at the pin number is displayed the logic level state (H;high, L;low).

The monitor screen is scrolled and displayed.

Operation during data changing

(1) Set "*" mark to the left of data to be adjusted using a search dial (JOG mode).


(2) Turn the search dial to change the data while pressing the JOG (or SHUTTLE) button.

FWD (○): Increases the data value.
REV (○): Decreases the data value.

(3) For any other data, repeat steps (1) and (2).

(4) After change is completed, press the MENU button (or switch S301 on the SS board) to return to the BKDW-509 SETUP menu screen.

(5) To save the adjustment data in an NV-RAM, execute the "C482: NV-RAM CONTROL" mode.



DIAL
[SET] or [S300]

BKDW-509 SETUP
C480: INPUT PIN ASSIGN

No.	Command
01:H*20	10 00 00 00 00
18:H 20	30 00 00 00 00
19:H 20	05 00 00 00 00
20:H 20	20 00 00 00 00
21:H 40	10 00 00 00 00
22:H 20	04 00 00 00 00
23:H 20	0F 00 00 00 00

(1) DIAL

BKDW-509 SETUP
C480: INPUT PIN ASSIGN

No.	Command
01:H 20	10 00 00 00 00
18:H 20*	30 00 00 00 00
19:H 20	05 00 00 00 00
20:H 20	20 00 00 00 00
21:H 40	10 00 00 00 00
22:H 20	04 00 00 00 00
23:H 20	0F 00 00 00 00

(2) [JOG] + DIAL

BKDW-509 SETUP
C480: INPUT PIN ASSIGN

No.	Command
01:H 20	10 00 00 00 00
18:H 20*	50 00 00 00 00
19:H 20	05 00 00 00 00
20:H 20	20 00 00 00 00
21:H 40	10 00 00 00 00
22:H 20	04 00 00 00 00
23:H 20	0F 00 00 00 00

(4) [MENU] or [S301]

*C482: NV-RAM CONTROL

Caution

If to change the setup data, and/or the version-up of the ROMs, please contact to Sony's service organization.

Do not change the setup data carelessly. This causes a trouble.

If the adjustment data been changed carelessly, execute the "ALL DATA PREVIOUS" mode in C482 : NV-RAM CONTROL or turn off the power of this unit without executing the C482 : NV-RAM CONTROL.

Never execute the "SAVE ALL DATA" mode.

C482 : NV-RAM CONTROL

Caution : Once the BKDW-509 setup data is saved in an NV-RAM, it cannot return to the previous state.


- (1) Using a search dial (JOG mode), set the "*" mark as follows;
Set it to "SAVE ALL DATA" when the setup data after change is saved.
Set it to "ALL DATA PREVIOUS" when the setup data before change is returned.
Set it into "RESET ALL DATA" when the setup data resets to the factory data.

- (2) Press the SET button (or switch S300 on the SS board) to initiate the data transfer.


The monitor screen at right is displayed when the setup data is saved/reseted. The "Loading ..." message is displayed when the setup data before change is returned.

- (3) After data transfer is completed, the "Complete" message is displayed on the monitor screen.
The monitor screen at right is displayed when the setup data is saved/reseted. The "Load Complete" message is displayed when the setup data before adjustment is returned.


Note : If the power of this unit is turned off without saving the BKDW-509 setup data in an NV-RAM after change is completed, the setup data returns to the previous state.



(1) DIAL
(2) [SET] or [S300]



During data saving



Data saving completed

C49: SETUP BANK4


This mode copies into the setup menu BANK-4 from BANK-1, 2, or 3, or resets it to the factory data.

The C49 mode is applied on the unit in which the version No. of both SYS1 ROM (IC12) and SYS2 ROM (IC54) on the SS board are 3.10 or higher.


- (1) Using a serch dial (JOG mode), set the "*" mark as follows;
Set it to "COPY BANK1 TO BANK4" when the BANK-1 data is copied into the BANK-4.
Set it to "COPY BANK2 TO BANK4" when the BANK-2 data is copied into the BANK-4.
Set it to "COPY BANK3 TO BANK4" when the BANK-3 data is copied into the BANK-4.
Set it into "RESET BANK4" when the BANK-4 data resets to the factory data.

- (2) Press the SET button (or switch S300 on the SS board) to initiate the data transfer.

- (3) After data transfer is completed, the "Save Complete" message is displayed on the monitor screen.





5-7. SERVO/DT SYSTEM ADJUSTMENT MODE (A0: SERVO/DT ADJUST)



5-7-1. Servo System Adjustment Mode (A00-01: SERVO ADJUST)

This section describes the “A00-01: SERVO ADJUST” mode.





a) A000: A001-A008 ADJ.

This mode executes the adjustment menus below automatically and continuously.

A001: S REEL FG DUTY
 A002: T REEL FG DUTY
 A003: CAPSTAN FG DUTY
 A004: S REEL OFFSET/FRICTION
 A005: T REEL OFFSET/FRICTION
 A006: S REEL TORQUE
 A007: T REEL TORQUE
 A008: S/T TENSION OFFSET

- (1) Press the SET button (or switch S300 on the SS board) to initiate the adjustment.

The "A001: S REEL FG DUTY" adjustment is performed first.
 The "ADJUSTING....." message is displayed during adjustment.

As the adjustment progresses, the display in the fifth line (※) changes.


- (2) If no abnormality is found after all the adjustments are completed, the "ADJUST COMPLETE" message is displayed on the monitor screen.

- (3) Press the MENU button (or switch S301 on the SS board) to return to the SERVO ADJUST menu screen.

- (4) To save the adjustment data in an NV-RAM, execute the "A012: NV-RAM CONTROL" mode.

In case of NG; (The screen at right is one example.)

When the "ADJUST INCOMPLETE" message is displayed on the monitor screen.
 Refer to the "In case of NG" in each adjustment menu.



**b) A001: S REEL FG DUTY
A002: T REEL FG DUTY
A003: CAPSTAN FG DUTY**

A001: Adjusts the S reel FG duty cycle.
A002: Adjusts the T reel FG duty cycle.
A003: Adjusts the capstan FG duty cycle.

These operation methods are the same as one another. The monitor screen at right is displayed for "A001: S REEL FG DUTY".

- (1) Press the SET button (or switch S300 on the SS board) to initiate the adjustment.

During adjustment, the "ADJUSTING....." message is displayed on the monitor screen.

- (2) After adjustment is completed, the "ADJUST COMPLETE" message is displayed on the monitor screen.


- (3) Press the MENU button (or switch S301 on the SS board) to return to the SERVO ADJUST menu screen.

- (4) To save the adjustment data in an NV-RAM, execute the "A012: NV-RAM CONTROL" mode.

In case of NG;

When the "ADJUST INCOMPLETE" message is displayed on the monitor screen, perform the following checks.

- For "A001: S REEL FG DUTY", check the S reel FG amplifier circuit and S reel motor driver circuit on the DR-307/200 board.
- For "A002: T REEL FG DUTY", check the T reel FG amplifier circuit and T reel motor driver circuit on the DR-307/200 board.
- For "A003: CAPSTAN FG DUTY", check the capstan FG amplifier circuit and capstan motor driver circuit on the DR-307/200 board.



(1) [SET] or [S300]

SERVO ADJUST
A001:S REEL FG DUTY

ADJUSTING.....

During adjustment

SERVO ADJUST
A001:S REEL FG DUTY

ADJUST COMPLETE

Adjustment completed

(3) [MENU] or [S301]

*A012:NV-RAM CONTROL

SERVO ADJUST
A001:S REEL FG DUTY

ADJUST INCOMPLETE

Adjustment NG

**c) A004: S REEL OFFSET/FRICTION
A005: T REEL OFFSET/FRICTION**

A004: Adjusts the S reel offset and friction.

A005: Adjusts the T reel offset and friction.

These operation methods are the same as each other. The monitor screen at right is displayed for "A004: S REEL OFFSET/FRICTION".

- (1) Press the SET button (or switch S300 on the SS board) to initiate the adjustment.

During adjustment, the "ADJUSTING....." message is displayed on the monitor screen.

- (2) After adjustment is completed, the "ADJUST COMPLETE" message is displayed on the monitor screen.


- (3) Press the MENU button (or switch S301 on the SS board) to return to the SERVO ADJUST menu screen.

- (4) To save the adjustment data in an NV-RAM, execute the "A012: NV-RAM CONTROL" mode.

In case of NG;

When the "ADJUST INCOMPLETE" message is displayed on the monitor screen, perform the following adjustments and checks.

- For "A004: S REEL OFFSET/FRICTION", adjust the S reel FG duty cycle (A001: S REEL FG DUTY) again and check the S reel motor driver circuit on the DR-307/200 board.
- For "A005: T REEL OFFSET/FRICTION", adjust the T reel FG duty cycle (A002: T REEL FG DUTY) again and check the T reel motor driver circuit on the DR-307/200 board.



**d) A006: S REEL TORQUE
A007: T REEL TORQUE**

A006: Adjusts the S reel torque.

A007: Adjusts the T reel torque.

These operation methods are the same as each other. The monitor screen at right is displayed for "A006: S REEL TORQUE".

- (1) Press the SET button (or switch S300 on the SS board) to initiate the adjustment.

During adjustment, the "ADJUSTING....." message is displayed on the monitor screen.

- (2) After adjustment is completed, the "ADJUST COMPLETE" message is displayed on the monitor screen.


- (3) Press the MENU button (or switch S301 on the SS board) to return to the SERVO ADJUST menu screen.

- (4) To save the adjustment data in an NV-RAM, execute the "A012: NV-RAM CONTROL" mode.

In case of NG;

When the "ADJUST INCOMPLETE" message is displayed on the monitor screen, perform the following adjustments and checks.

- For "A006: S REEL TORQUE", adjust the S reel FG duty cycle (A001: S REEL FG DUTY) again and check the S reel motor driver circuit on the DR-307/200 board.
- For "A007: T REEL TORQUE", adjust the T reel FG duty cycle (A002: T REEL FG DUTY) again and check the T reel motor driver circuit on the DR-307/200 board.



e) A008: S/T TENSION OFFSET

This mode adjusts the offset of an S/T tension regulator.

- (1) Press the SET button (or switch S300 on the SS board) to initiate the adjustment.

During adjustment, the “ADJUSTING.....” message is displayed on the monitor screen.


- (2) After adjustment is completed, the “ADJUST COMPLETE” message is displayed on the monitor screen.

- (3) Press the MENU button (or switch S301 on the SS board) to return to the SERVO ADJUST menu screen.

- (4) To save the adjustment data in an NV-RAM, execute the “A012: NV-RAM CONTROL” mode.

In case of NG;

When the “ADJUST INCOMPLETE” message is displayed on the monitor screen.
Check the S tension detector circuit (IC40) or T tension detector circuit (IC32) on the DR-307/200 board.



f) A010: CAPSTAN FREE SPEED

This mode adjusts the free speed of a capstan.

- (1) When alignment tape ZR2-1P/1 is inserted into this unit, this adjustment is initiated automatically.

ZR2-1P; for DVW-A510P/510P
ZR2-1 ; for DVW-A510/510

During adjustment, the "ADJUSTING....." message is displayed on the monitor screen.

Note: Be sure to use alignment tape ZR2-1P/1. If not, the adjustment is not performed correctly even if the "ADJUST COMPLETE" message is displayed after adjustment is completed.

- (2) After adjustment is completed, the "ADJUST COMPLETE" message is displayed on the monitor screen.

The alignment tape is ejected automatically.

- (3) Press the MENU button (or switch S301 on the SS board) to return to the SERVO ADJUST menu screen.


- (4) To save the adjustment data in an NV-RAM, execute the "A012: NV-RAM CONTROL" mode.

In case of NG;


When the "ADJUST INCOMPLETE" message is displayed on the monitor screen.

Confirm that the playback tape is alignment tape ZR2-1P/1.


Then, check the capstan FG amplifier circuit, capstan motor driver circuit, and CTL amplifier circuit on the DR-307/200 board.



(1) Insert alignment tape





During adjustment



Adjustment completed

(3) MENU or S301



Adjustment NG

g) A011: RF SWITCHING POS.

This mode adjusts the RF switching position.

This step describes the automatic adjustment operation. (The PG data displayed in this case is a standard value.)

To perform this adjustment, alignment tape ZR2-1P/1 on which the beginning of the time code is beforehand located in 00:25:00:00 is required.

(1) Set the "*" mark to "AUTO" using a search dial (JOG mode).

(2) Press the SET button (or switch S300 on the SS board).
The monitor screen changes as shown at right.

(3) When alignment tape ZR2-1P/1 is inserted into this unit, this adjustment is initiated automatically.

ZR2-1P; for DVW-A510P/510P
ZR2-1 ; for DVW-A510/510


During adjustment, the "ADJUSTING....." message is displayed on the monitor screen.

Note: Be sure to use alignment tape ZR2-1P/1. If not, the adjustment is not performed correctly even if the "ADJUST COMPLETE" message is displayed after adjustment is completed.

(4) After adjustment is completed, the "ADJUST COMPLETE" message is displayed on the monitor screen.
The alignment tape is then ejected automatically.

(5) Press the MENU button (or switch S301 on the SS board) two times to return to the SERVO ADJUST menu screen.

(6) To save the adjustment data in an NV-RAM, execute the "A012: NV-RAM CONTROL" mode.



In case of NG; (The screen at right is one example.)

- When the "SYNC PULSE TROUBLE" message is displayed on the monitor screen.

- (1) Confirm that the playback tape is alignment tape ZR2-1P/1.
- (2) Confirm that the SYNC pulse exists at the test terminal below on the SS board.

TP802: SYNC PLS

No SYNC pulse exists: Perform the steps (3) and (4).

A SYNC pulse exist: Check the SS board.

- (3) Perform the "C050: DT DRIVER CHECK" and "C051: SG LOOP CHECK" in the digital DT system.
- (4) Confirm that a segment signal exists at pins 41A and 41B of connector CN123 on the SS board.

CN123-41A: DT SEG 0

CN123-41B: DT SEG 1

No segment signal exists: Check the DPR-36H board.

A segment signal exists: Check the SS board.

```

SERVO ADJUST
A011:RF SWITCHING POS.

# ADJUST INCOMPLETE #
# SYNC PULSE TROUBLE#

PG DATA:2500
  
```

Adjustment NG

h) A012: NV-RAM CONTROL


This mode saves the servo system adjustment data in an NV-RAM.

- (1) Set the "*" mark to "SAVE SERVO ADJUST DATA" using a search dial (JOG mode).

- (2) Press the SET button (or switch S300 on the SS board) to initiate the data transfer.

The "SAVING....." message is then displayed on the monitor screen.


- (3) After data transfer is completed, the "DATA SAVED" message is displayed on the monitor screen.



Note: If the power of this unit is turned off without saving the adjustment data in an NV-RAM after adjustment is completed, the adjustment data in the servo system returns to the preadjustment state.

5-7-2. Digital DT System Adjustment Mode (A02: DIGITAL DT ADJUST)

This section describes the "A02: DIGITAL DT ADJUST" mode.



a) A020: CAPSTAN FG LEVEL

This mode adjusts the capstan FG level.

- (1) Insert alignment tape ZR5-1P/1 into this unit.

ZR5-1P; for DVW-A510P/510P
ZR5-1 ; for DVW-A510/510

- (2) Set the "*" mark to "Start auto adjust" using a search dial (JOG mode).

- (3) Press the SET button (or switch S300 on the SS board).
(If the unit has already entered the PLAY mode, the adjustment is initiated.)

- (4) The "Push PLAY button" message is displayed on the monitor screen. Press the PLAY button to initiate the adjustment.

During adjustment, the "ADJUSTING....." message is displayed on the monitor screen.


- (5) After adjustment is completed, the "ADJUST COMPLETE" message is displayed on the monitor screen.

- (6) Press the MENU button (or switch S301 on the SS board) to return to the DIGITAL DT ADJUST menu screen.

- (7) To save the adjustment data in an NV-RAM, execute the "A023: NV-RAM CONTROL" mode.

How to eject the cassette tape

Return to the menu in the servo/DT system adjustment mode. The cassette tape is then ejected automatically.



In case of NG;

When the "ADJUST COMPLETE" message is not displayed on the monitor screen.

Check the capstan motor and capstan FG amplifier (on the DR-307/200 board).

```
DIGITAL DT ADJUST
A020:CAPSTAN FG LEVEL
MODE : PLAY
```

```
No operation
*Start auto adjust
```

```
# ADJUST INCOMPLETE #
```

Adjustment NG

b) A021: DRIVE GAIN

This mode adjusts the drive gain of the bimorph head.

- (1) Insert alignment tape ZR5-1P/1 into this unit.

ZR5-1P; for DVW-A510P/510P
ZR5-1 ; for DVW-A510/510

- (2) Set the "*" mark to "Start auto adjust" using a search dial (JOG mode).

- (3) Press the SET button (or switch S300 on the SS board).
(If the unit has already entered the STILL mode, the adjustment is initiated.)

- (4) The "Push JOG button" message is displayed on the monitor screen.
Press the JOG button. The unit then enters the STILL mode to initiate the adjustment.

During adjustment, the "ADJUSTING....." message is displayed on the monitor screen.


- (5) After adjustment is completed, the "ADJUST COMPLETE" message is displayed on the monitor screen.

- (6) Press the MENU button (or switch S301 on the SS board) to return to the DIGITAL DT ADJUST menu screen.

- (7) To save the adjustment data in an NV-RAM, execute the "A023: NV-RAM CONTROL" mode.

How to eject the cassette tape

Return to the menu in the servo/DT system adjustment mode. The cassette tape is then ejected automatically.



In case of NG; (The screen at right is one example.)

When the "ADJUST COMPLETE" message is not displayed on the monitor screen, perform the following checks and confirmation.

- (1) Perform the "C050: DT DRIVER CHECK" and "C051: SG LOOP CHECK" in the digital DT system.
- (2) Confirm that an RF envelope signal exists at the test terminals below on the SS board.
 - TP2501: ENV B/D
 - TP2502: ENV A/C

No RF envelope signal exists: Check the EQ board.

An RF envelope signal exists: Check the SS board.

```

DIGITAL DT ADJUST
A021:DRIVE GAIN
MODE : STILL

No operation
*Start auto adjust

# ADJUST INCOMPLETE #
A/B ch
  
```

Adjustment NG

c) A022: HEAD OFFSET LEVEL

This mode adjusts the offset level of an advance head.

- (1) Insert alignment tape ZR5-1P/1 into this unit.

ZR5-1P; for DVW-A510P/510P
ZR5-1 ; for DVW-A510/510

- (2) Set the "*" mark to "Start auto adjust" using a search dial (JOG mode).
- (3) Press the SET button (or switch S300 on the SS board).
(If the unit has already entered the PLAY mode, the adjustment is initiated.)
- (4) The "Push PLAY button" message is displayed on the monitor screen.
Press the PLAY button to initiate the adjustment.

During adjustment, the "ADJUSTING....." message is displayed on the monitor screen.


- (5) After adjustment is completed, the "ADJUST COMPLETE" message is displayed on the monitor screen.

- (6) Press the MENU button (or switch S301 on the SS board) to return to the DIGITAL DT ADJUST menu screen.

- (7) To save the adjustment data in an NV-RAM, execute the "A023: NV-RAM CONTROL" mode.

How to eject the cassette tape

Return to the menu in the servo/DT system adjustment mode. The cassette tape is then ejected automatically.



In case of NG; (The screen at right is one example.)

When the "ADJUST COMPLETE" message is not displayed on the monitor screen, perform the following checks and confirmation.

- (1) Perform the "C050: DT DRIVER CHECK" and "C051: SG LOOP CHECK" in the digital DT system.
- (2) Confirm that a segment signal exists at pins 41A and 41B of connector CN123 on the SS board.
 CN123-41A: DT SEG 0
 CN123-41B: DT SEG 1

No segment signal exists: Check the DPR-36H board.

A segment signal exists: Check the SS board.

DIGITAL DT ADJUST
A022:HEAD OFFSET LEVEL
MODE : PLAY

No operation
***Start auto adjust**

ADJUST INCOMPLETE
A/B ch

Adjustment NG

d) A023: NV-RAM CONTROL


This mode saves the digital DT system adjustment data in an NV-RAM.

(1) Set the "*" mark to "SAVE DIGITAL DT DATA" using a search dial (JOG mode).


(2) Press the SET button (or switch S300 on the SS board) to initiate the data transfer.

The "SAVING....." message is then displayed on the monitor screen.


(3) After data transfer is completed, the "DATA SAVED" message is displayed on the monitor screen.



(1) DIAL
(2) SET or S300



During data saving




Data saving completed

Note: If the power of this unit is turned off without saving the adjustment data in an NV-RAM after adjustment is completed, the adjustment data in the digital DT system returns to the preadjustment state.

5-7-3. Analog DT System Adjustment Mode (For DVW-A510P/A510) (A03: ANALOG DT ADJUST)

This section describes the "A03: ANALOG DT ADJUST" mode.



a) A030: HEAD OFFSET LEVEL

This mode adjusts the offset level of a Betacam PB head.

This step describes the automatic adjustment operation.

(The data value displayed in this case is a standard value.)

- (1) Insert alignment tape CR5-1BPS/1B or CR5-2APS/2A whose beginning is beforehand located in the color bars signal portion into this unit.

CR5-1B PS : TC00:14:00:00	} for DVW-A510P/510P
CR5-2A PS : TC00:00:00:00	
CR5-1B : TC00:14:00:00	} for DVW-A510/510
CR5-2A : TC00:00:00:00	

- (2) Set the "*" mark to "Start auto adjust" using a search dial (JOG mode).
- (3) Press the SET button (or switch S300 on the SS board).
(If the unit has already entered the PLAY mode, the adjustment is initiated.)
- (4) The "Push PLAY button" message is displayed on the monitor screen.
Press the PLAY button to initiate the adjustment.

During adjustment, the "ADJUSTING....." message is displayed on the monitor screen.

However, the displayed data value does not change during adjustment.

- (5) After adjustment is completed, the "ADJUST COMPLETE" message is displayed on the monitor screen.


The data value changes to the data value during this adjustment.

- (6) Press the MENU button (or switch S301 on the SS board) to return to the ANALOG DT ADJUST menu screen.

- (7) To save the adjustment data in an NV-RAM, execute the "A032: NV-RAM CONTROL" mode.

How to eject the cassette tape

Return to the menu in the servo/DT system adjustment mode. The cassette tape is then ejected automatically.



In case of NG; (The screen at right is one example.)

When the "ADJUST COMPLETE" message is not displayed on the monitor screen, perform the following check and confirmation.

- (1) Perform the "C060: SG LOOP CHECK" in the analog DT system.
- (2) Confirm that an RF envelope signal exists at the test terminal below on the SS board.

TP2100: Y RF ENVELOPE

No RF envelope signal exists: Check the DM-89 board.

An RF envelope signal exists: Check the SS board.

ANALOG DT ADJUST	
A030:HEAD OFFSET LEVEL	
MODE : PLAY	
*Start auto adjust	
Ach manual adjust	
Bch manual adjust	
# ADJUST INCOMPLETE #	
Ach	
Ach:00	Bch:00

Adjustment NG

b) A031: DRIVE GAIN

This mode adjusts the drive gain of an analog DT system.

This step describes the automatic adjustment operation.

(The data value displayed in this case is a standard value.)

- (1) Insert alignment tape CR5-1BPS/1B or CR5-2APS/2A whose beginning is beforehand located in the color bars signal portion into this unit.

CR5-1B PS :	TC 00:14:00:00	} for DVW-A510P/510P
CR5-2A PS :	TC 00:00:00:00	
CR5-1B :	TC 00:14:00:00	} for DVW-A510/510
CR5-2A :	TC 00:00:00:00	


- (2) Set the "*" mark to "Start auto adjust" using a search dial (JOG mode).
- (3) Press the SET button (or switch S300 on the SS board).
(If the unit has already entered the variable three times (×3) the normal mode, the adjustment is initiated.)
- (4) The "Set VARIABLE ×3" message is displayed on the monitor screen.
Press the VAR button, then turn the search dial in the forward direction and put the unit into the variable three times (×3) the normal mode to initiate the adjustment.

During adjustment, the "ADJUSTING....." message is displayed on the monitor screen. The data value then changes.

- (5) After adjustment is completed, the "ADJUST COMPLETE" message is displayed on the monitor screen.
- (6) Press the JOG button.
(Set the search dial to the JOG mode)
- (7) Press the MENU button (or switch S301 on the SS board) to return to the ANALOG DT ADJUST menu screen.
- (8) To save the adjustment data in an NV-RAM, execute the "A032: NV-RAM CONTROL" mode.

How to eject the cassette tape


Return to the menu in the servo/DT system adjustment mode. The cassette tape is then ejected automatically.



In case of NG; (The screen at right is one example.)
When the "ADJUST COMPLETE" message is not displayed on the monitor screen, perform the following check and confirmation.

- (1) Perform the "C060: SG LOOP CHECK" in the analog DT system.
- (2) Confirm that the signals at pins 9A and 9B of connector CN123 on the SS board are synchronized.
CN123-9A: Y WZ ()
CN123-9B: C WZ ()

When no signals exist and are synchronized, check the DM-89 board, TBC-24/23 boards, then EQ board.
When signals exist and are synchronized, check the SS board.



Adjustment NG

c) A032: NV-RAM CONTROL


This mode saves the analog DT system adjustment data in an NV-RAM.

- (1) Set the "*" mark to "SAVE ANALOG DT DATA" using a search dial (JOG mode).

- (2) Press the SET button (or switch S300 on the SS board) to initiate the data transfer. The "SAVING....." message is then displayed on the monitor screen.


- (3) After data transfer is completed, the "DATA SAVED" message is displayed on the monitor screen.


Note: If the power of this unit is turned off without saving the adjustment data in an NV-RAM after adjustment is completed, the adjustment data in the analog DT system returns to the preadjustment state.



5-8. RF SYSTEM ADJUSTMENT MODE (A1: RF ADJUST)

This section describes the "A1: RF ADJUST" mode.
For how to activate and terminate the maintenance mode, refer to page 5-3.





a) A10: A11-A17 ADJUST/A10: A11-17, 1B, 1C ADJUST

This mode executes the following adjustment menus automatically and continuously.

A11 : PLAY PLL
 A12 : ADV EQUALIZER
 A14 : SHUTTLE FWD PLL
 A15 : SHUTTLE REV PLL
 A16 : VAR FWD PLL
 A17 : VAR REV PLL
 A1B : P.PLAY+ PLL } These adjustments are performed when
 A1C : P.PLAY- PLL } BKDW-507 is installed.

- (1) Insert alignment tape ZR5-1P/1 into this unit (with the tape rewound in advance).

ZR5-1P; for DVW-A510P/510P
 ZR5-1 ; for DVW-A510/510

- (2) Press the SET button (or switch S300 on the SS board) to initiate the adjustment.

The "A11: PLAY PLL" adjustment is performed first.
 The "Adjusting..." message is displayed during adjustment.


As the adjustment progresses, the display in the fourth line (※) changes.

Note: The "Adjust Incomplete" message is displayed when the tape running stops during adjustment.

- (3) If no abnormality is found after all the adjustments are completed, the "Adjust Complete" message is displayed on the monitor screen.

- (4) Press the MENU button (or switch S301 on the SS board) to return to the RF ADJUST MODE menu screen.

- (5) To save the adjustment data in an NV-RAM, execute the "A1F: NV-RAM CONTROL" mode.



- b) **A11 : PLAY PLL**
A14 : SHUTTLE FWD PLL
A15 : SHUTTLE REV PLL
A16 : VAR FWD PLL
A17 : VAR REV PLL
A1B: P.PLAY+ PLL } These adjustments are displayed when
A1C: P.PLAY- PLL } BKDW-507 is installed.

These modes adjust the VCO free-running frequency of a PB PLL circuit in the following PB modes. For these modes, manual or automatic adjustment can be selected. In this case, only the automatic adjustment is described on the next page with "A11: PLAY PLL" as an example.

A11: PLAY mode
A14: SHUTTLE FWD mode [Tape top]
A15: SHUTTLE REV mode [Tape end]
A16: VARIABLE FWD mode
A17: VARIABLE REV mode
A1B: PROGRAM PLAY (FAST) mode
A1C: PROGRAM PLAY (SLOW) mode

Note: The "Adjust Incomplete" message is displayed when the tape running stops during adjustment.

In this case, rewind or fast forward the alignment tape, then readjust.

For the adjustment in the SHUTTLE mode, especially, put the tape into the state in [] mentioned above, then adjust.

Operation during automatic adjustment

(The monitor screen is displayed as an example of "A11: PLAY PLL". The displayed data value and the ">" number are an example.)

- (1) Change "Manual" to "Auto".

Set the "*" mark to "Manual" using a search dial. After that, turn the search dial in the forward ($\odot$) direction while pressing and holding the JOG (or SHUTTLE) button.

The "Auto (Push SET button)" message is then displayed on the monitor screen.

- (2) Insert alignment tape ZR5-1P/1 into this unit and press the SET button (or switch S300 on the SS board). The tape then runs, and the adjustment is initiated.

ZR5-1P; for DVW-A510P/510P

ZR5-1 ; for DVW-A510/510

When the SET button (or switch S300) is pressed without inserting the alignment tape, the "Waiting ..." message is displayed until the alignment tape is inserted.

During adjustment, the "Auto Adjusting ..." message is displayed on the monitor screen.

Note: The "Adjust Incomplete" message is displayed when the tape running stops during adjustment.

- (3) After adjustment is completed, the "Auto Adjust Complete" message is displayed on the monitor screen. The tape running then stops.

- (4) Press the MENU button (or switch S301 on the SS board) to return to the RF ADJUST MODE menu screen.

- (5) To save the adjustment data in an NV-RAM, execute the "A1F: NV-RAM CONTROL" mode.

```

RF ADJUST MODE
A11:PLAY PLL
*Manual

ADV A/Cch PLL      55

ADV B/Dch PLL      55

```

(1) **JOG** + DIAL (FWD)

```

RF ADJUST MODE
A11:PLAY PLL
*Auto (Push SET button)

ADV A/Cch PLL      55

ADV B/Dch PLL      55

```

(2) Insert alignment tape

SET or **S300**

```

RF ADJUST MODE
A11:PLAY PLL
*Auto Adjusting ...

ADV A/Cch PLL      75
>>>>>>

ADV B/Dch PLL      75
>>>>>>

```

During adjustment

```

RF ADJUST MODE
A11:PLAY PLL
*Auto Adjust Complete

ADV A/Cch PLL      55
>>>

ADV B/Dch PLL      55
>>

```

Adjustment completed

(4) **MENU** or **S301**

```

*A1F:NV-RAM CONTROL

```

c) A12: ADV EQUALIZER

This mode adjust the gain and phase of the PB equalizer circuit for the advance head. For this mode, manual or automatic adjustment can be selected. In this case, only the automatic adjustment operation is described on the next page.

Note: The "Adjust Incomplete" message is displayed when the tape running stops during adjustment.

In this case, rewind or fast forward the alignment tape, then readjust.

Operation during automatic adjustment

(The displayed data value and the ">" number are an example.)

- (1) Change "Manual" to "Auto".

Set the "*" mark to "Manual" using a search dial. After that, turn the search dial in the forward ($\odot$) direction while pressing and holding the JOG (or SHUTTLE) button.

The "Auto (Push SET button)" message is then displayed on the monitor screen.

- (2) Insert alignment tape ZR5-1P/1 into this unit and press the SET button (or switch S300 on the SS board). The tape then runs, and the adjustment is initiated.

ZR5-1P; for DVW-A510P/510P

ZR5-1 ; for DVW-A510/510

When the SET button (or switch S300) is pressed without inserting the alignment tape, the "Waiting ..." message is displayed until the alignment tape is inserted.


During adjustment, the "Auto Adjusting ..." message is displayed on the monitor screen.

Note: The "Adjust Incomplete" message is displayed when the tape running stops during adjustment.

- (3) After adjustment is completed, the "Auto Adjust Complete" message is displayed on the monitor screen. The tape running then stops.

- (4) Press the MENU button (or switch S301 on the SS board) to return to the RF ADJUST MODE menu screen.

- (5) To save the adjustment data in an NV-RAM, execute the "A1F: NV-RAM CONTROL" mode.



e) A19: ADV LEVEL

This mode adjust the RF PB level of the advance head. The RF PB level is adjusted manually. Only the manual adjustment operation is described on the next page.

Caution: Do not change the adjustment data carelessly. This causes a trouble. To adjust the data, adjust it according to the adjustment described in the Maintenance Manual Part 2, Volume-1.

If the adjustment data has been changed carelessly, execute the "ALL DATA PREVIOUS" mode in A1F: NV-RAM CONTROL or turn off the power of this unit without executing the A1F: NV-RAM CONTROL. Never execute the "SAVE ALL ADJUST DATA" mode.

Operation during manual adjustment

(The displayed data value is an example.)

- (1) Press the SET button (or switch S300 on the SS board). At that time, the unit temporarily exits the maintenance mode. This enables the normal operation.
(Prompt "■" is displayed in the upper-right position of the superimposed screen, and the time counter is put into the normal state.)

- (2) Insert alignment tape ZR5-1P/1 into this unit and press the PLAY button.

ZR5-1P; for DVW-A510P/510P
ZR5-1 ; for DVW-A510/510

- (3) Press the MENU button (or switch S301 on the SS board) to return to the maintenance mode.
(The "■" prompt display disappears on the screen, and the time counter displays the menu number.)

- (4) Set "*" mark to the channel to be adjusted using a search dial (JOG mode).


- (5) Turn the search dial to change the data while pressing the JOG (or SHUTTLE) button.

FWD ($\odot$): Increases the data value. (FF is followed by 00.)
REV ($\ominus$): Decreases the data value. (00 is followed by FF.)

- (6) For any other channels, repeat steps (4) and (5).

- (7) After adjustment is completed, press the MENU button (or switch S301 on the SS board) to return to the RF ADJUST MODE menu screen.

- (8) To save the adjustment data in an NV-RAM, execute the "A1F: NV-RAM CONTROL" mode.

**f) A1F: NV-RAM CONTROL**

This mode saves the RF system adjustment data in an NV-RAM or returns it to the preadjustment state without saving the RF system adjustment data.

Caution: Once the RF system adjustment data is saved in an NV-RAM, it cannot return to the preadjustment state.

- (1) Using a search dial (JOG mode), set the "*" mark as follows:
Set it to "SAVE ALL ADJUST DATA" when the adjustment data after adjustment is saved.
Set it to "ALL DATA PREVIOUS" when the adjustment data before adjustment is returned.


- (2) Press the SET button (or switch S300 on the SS board) to initiate the data transfer.

The monitor screen at right is displayed when the adjustment data is saved.
The "Loading ..." message is displayed when the adjustment data before adjustment is returned.

- (3) After data transfer is completed, the "Complete" message is displayed on the monitor screen.

The monitor screen at right is displayed when the adjustment data is saved.
The "Load Complete" message is displayed when the adjustment data before adjustment is returned.

Note: If the power of this unit is turned off without saving the adjustment data in an NV-RAM after adjustment is completed, the adjustment data in the RF system returns to the preadjustment state.



5-9. AUDIO/VIDEO SYSTEM ADJUSTMENT MODE (A2: AUDIO/VIDEO ADJUST)

This section describes the "A2: AUDIO/VIDEO ADJUST" mode.

For how to activate and terminate the maintenance mode, refer to page 5-3.

Caution: Do not change the adjustment data carelessly. This causes a trouble. To adjust the data, adjust it according to the operation described in section 6 or 8 of this manual.

For the items not described in section 6 or 8, perform each adjustment according to the adjustment in the Maintenance Manual Part 2, Volume-1.

If the adjustment data has been changed carelessly, execute the "ALL DATA PREVIOUS" mode in A2F: NV-RAM CONTROL or turn off the power of this unit without executing the A2F: NV-RAM CONTROL.
Never execute the "SAVE ALL ADJUST DATA" mode.

a) Operation during manual adjustment

- (1) Set the "*" mark to the item to be adjusted using a search dial (JOG mode).
- (2) Turn the search dial to change the data while pressing and holding the JOG (or SHUTTLE) button.

FWD (): Increases the data value. (FF is followed by 00.)
REV (): Decreases the data value. (00 is followed by FF.)
- (3) For any other items, repeat steps (1) and (2).
- (4) After adjustment is completed, press the MENU button (or switch S301 on the SS board) to return to the AUDIO/VIDEO ADJUST MODE menu screen.
- (5) To save the adjustment data in an NV-RAM, execute the "A2F: NV-RAM CONTROL" mode.

b) A2F: NV-RAM CONTROL

This mode saves the audio/video system adjustment data in an NV-RAM or returns it to the preadjustment state without saving the audio/video system adjustment data.


Caution: Once the audio/video system adjustment data is saved in an NV-RAM, it cannot return to the preadjustment state.

- (1) Using a search dial (JOG mode), set the "*" mark as follows:
Set it to "SAVE ALL ADJUST DATA" when the adjustment data after adjustment is saved.
Set it to "ALL DATA PREVIOUS" when the adjustment data before adjustment is returned.
- (2) Press the SET button (or switch S300 on the SS board) to initiate the data transfer. The monitor screen at right is displayed when the adjustment data is saved. The "Loading ..." message is displayed when the adjustment data before adjustment is returned.


- (3) After data transfer is completed, the "Complete" message is displayed on the monitor screen.

The monitor screen at right is displayed when the adjustment data is saved. The "Load Complete" message is displayed when the adjustment data before adjustment is returned.

Note: If the power of this unit is turned off without saving the adjustment data in an NV-RAM after adjustment is completed, the adjustment data in the audio/video system returns to the preadjustment state.



Note: The data value displayed in this case is one example.




(Above screen is displayed for the DVW-A510P/A510.)


A20: VPR VR 0
Adjusts the reference signal system and video output system on the VPR-1B board.

In addition to the screen display at right, the items below are scrolled and displayed.


B-CAM R-Y OUT LEVEL } for DVW-A510/510
B-CAM B-Y OUT LEVEL } only



A23: DIF VR
Adjusts the frequency of the voltage-controlled oscillator (VCO) on the DIF-16B board.



A2F: NV-RAM CONTROL
Saves the audio/video system adjustment data in an NV-RAM or returns it to the preadjustment data.



5-10. BETACAM PB SYSTEM ADJUSTMENT MODE (For DVW-A510P/A510) (A3: BETACAM PB ADJUST)

This section describes the "A3: BEATCAM PB ADJUST" mode.

For how to activate and terminate the maintenance mode, refer to page 5-3.

Caution: Do not change the adjustment data carelessly. This causes a trouble. To adjust the data, adjust it according to the operation described in section 6 or 8 of this manual.

For the items not described in section 6 or 8, perform each adjustment according to the adjustment in the Maintenance Manual Part 2, Volume-1.

If the adjustment data has been changed carelessly, execute the "ALL DATA PREVIOUS" mode in A3F: NV-RAM CONTROL or turn off the power of this unit without executing the A3F: NV-RAM CONTROL.

Never execute the "SAVE ALL ADJUST DATA" mode.

a) Operation during manual adjustment (data setting)

- (1) If the specified alignment tape has already been inserted and the specified tape portion has been played back, steps (2),(3), and (4) are omitted.
For the item in which the playback of an alignment tape is not required, proceed to step (5).
- (2) Press the SET button (or switch S300 on the SS board). At that time, the unit temporarily exits the maintenance mode. This enables the normal operation.
(Prompt "■" is displayed in the upper-right position of the superimposed screen, and the time counter is put into the normal state.)
- (3) Insert the specified alignment tape into this unit and play back it from the specified tape portion.
(For the guard band width adjustment in A35: DM VR 4, put the unit into the STOP mode.)
- (4) Press the MENU button (or switch S301 on the SS board) to return to the maintenance mode.
(The "■" prompt display disappears on the screen, and the time counter displays the menu number.)
- (5) Set the "*" mark to the item to be adjusted using a serach dial (JOG mode).
- (6) Turn the search dial to change the data while pressing and holding the JOG (or SHUTTLE) button.

FWD (): Increases the data value. (FF is followed by 00.)

REV (): Decreases the data value. (00 is followed by FF.)

- (7) For any other items, repeat steps (1) through (6).
- (8) After adjustment is completed, press the MENU button (or switch S301 on the SS board) to return to the BETACAM PB ADJUST mode menu screen.
- (9) To save the adjustment data in an NV-RAM, execute the "A3F: NV-RAM CONTROL" mode.

b) A3F: NV-RAM CONTROL

This mode saves the Betacam PB system adjustment data in an NV-RAM or returns it to the preadjustment state without saving the Betacam PB system adjustment data.


Caution: Once the Betacam PB system adjustment data is saved in an NV-RAM, it cannot return to the preadjustment state.

- (1) Using a search dial (JOG mode), set the "*" mark as follows:
Set it to "SAVE ALL ADJUST DATA" when the adjustment data after adjustment is saved.
Set it to "ALL DATA PREVIOUS" when the adjustment data before adjustment is returned.
- (2) Press the SET button (or switch S300 on the SS board) to initiate the data transfer. The monitor screen at right is displayed when the adjustment data is saved. The "Loading ..." message is displayed when the adjustment data before adjustment is returned.

- (3) After data transfer is completed, the "Complete" message is displayed on the monitor screen.

The monitor screen at right is displayed when the adjustment data is saved. The "Load Complete" message is displayed when the adjustment data before adjustment is returned.

Note: If the power of this unit is turned off without saving the adjustment data in an NV-RAM after adjustment is completed, the adjustment data in the Betacam PB system returns to the preadjustment state.





SECTION 6

6-1-1. Index for Board Replacement

6-1-1. Index for Board Replacement

REPLACEMENT OF POWER BLOCK AND CIRCUIT BOARDS

6-1. GENERAL INFORMATION FOR POWER/BOARDS REPLACEMENT

6-1-1. Index for Board Replacement

[Contents]

Section	Board	Pages
6-1-2.	Plug-in Board	6-2
6-2.	SOPS-1042B	6-5
6-2.	SOPS-1042A	6-5
6-3-1.	SWC-17	6-8
6-3-2.	FP-58	6-11
6-3-3.	VR-152	6-15
6-3-4.	VR-153	6-20
6-3-5.	KY-231	6-25
6-3-6.	DP-176	6-26
6-3-7.	SWC-18	6-27
6-3-8.	SWC-19	6-28
6-3-9.	CP-218	6-30
6-3-10.	CP-220	6-32
6-3-11.	DR-307/200	6-33
6-3-12.	DT-34	6-35
6-3-13.	HN-181	6-36
6-3-14.	HN-184	6-42
6-3-15.	HN-185	6-45


[Index]

Board	Section	Location
AP-28	6-1-2.	⑦
APR-1	6-1-2.	④
CP-218	6-3-9.	②⑥
CP-220	6-3-10.	②⑦
CUE-1	6-1-2.	⑥
DIF-16	6-1-2.	①
DM-89	6-1-2.	⑧
DP-176	6-3-6.	②⑤
DPR-36	6-1-2.	③
DR-307/200	6-3-11.	①⑥
DT-34	6-3-12.	①⑦
EQ-45	6-1-2.	⑤
FP-58	6-3-2.	①⑧
HN-181	6-3-13.	①②
HN-184	6-3-14.	①④
HN-185	6-3-15.	①③
KY-231	6-3-5.	②④
SOPS-1042A	6-2.	①①
SOPS-1042B	6-2.	①①
SS-52	6-1-2.	①⑤
SWC-17	6-3-1.	②①
SWC-18	6-3-7.	②②
SWC-19	6-3-8.	②③
TBC-23	6-1-2.	①⑩
TBC-24	6-1-2.	①⑨
VPR-1	6-1-2.	②②
VR-152	6-3-3.	①⑨
VR-153	6-3-4.	②⑩


[Location]

<Top View>


<Bottom View>



<Front View>



<Rear View>




6-1-2. Plug-in Board Pulling Out/ Inserting

Always switch off the power before removing or installing the plug-in board.

Pulling out

1. Loosen a screw, and remove the board retainer (L) or (S).




2. Pull up the eject levers on the board in the direction of the arrows when pulling out the board from the connector.

Note


Do not try to pull the board by grasping any of the components on the board.
Pull out the board with equal force for both sides.

3. Disconnect the connected harness.




Inserting

1. Connect the disconnected harness.
2. Insert the board after pushing down the eject levers as shown in the figure.



3. Insert the protrusion of the board retainer (L) or (S) into the square hole, and tighten the screw.



6-1-3. Flexible Card Wire Replacement

Two 36P flexible card wires are used on between DR-307/200 board and HN-181 board. 13P flexible card wires are used on between DR-307/200 board and each reel motor.

When handling the flexible card wire, be very careful not to bend it because this will markedly reduce its life.


Disconnection

1. Pull up the A portions of the connector.

Note


Never pull the flexible card wire first.

2. Pull out the flexible card wire from the connector.



Connection


1. Distinguish the front from back faces of the cable, then insert the cable into the connector.
2. Push down the A portions.



Note

The flexible card wire consists of conductor side and insulator side. The flexible card wire must be inserted with the conductor side facing the correct way. If the flexible card wire is inserted wrongly, the circuit will not operate.

CN214 and CN215 of the HN-181 board do not have a lock mechanism, so these connector's flexible card wire replacement are performed if only pulling out and inserting the cable.




6-2. POWER BLOCK/BOARD REPLACEMENT


After replacing this board, electrical adjustment should be performed.

(Refer to maintenance manual Part 2.)


1. Remove the power panel.
(Refer to section 1-2-4.)
2. Disconnect six connectors (CN101, CN201, CN202, CN203, CN204 and CN206).




3. Remove two screws, and remove the power block.




4. Remove three screws, and disassemble the power block.



5. Remove four screws, disconnect connector (CN102) and remove the SOPS-1042B board.



6. Remove three screws, and remove the SOPS-1042A board.




7. Install the power block/board in the reverse order of steps 1 through 6.


6-3. HOW TO REPLACE BOARDS

6-3-1. SWC-17 Board


1. Turn off the power.
2. Remove the upper lid.
(Refer to section 1-2-1.)
3. Remove the MD plate.
(Refer to section 1-3.)
4. Remove the cassette compartment assembly.
(Refer to section 1-2-2.)
5. Remove the upper control panel.
(Refer to section 1-2-1.)
6. Remove two screws, and remove the SC guide assembly.




7. Disconnect connector (CN500), remove six screws and pull out the front (upper) chassis assembly.




8. Undo the PCB holder, and open the FP-58 board to rear.



9. Disconnect connector (CN501) on the FP-58 board.



10. Remove three screws, and remove the SWC-17 board by lift the board after inclining to rear.




11. Install the SWC-17 board in the reverse order of steps 1 through 10.

6-3-2. FP-58 Board


After replacing this board, preset level adjustment (PROCESS CONTROL switch : REMOTE) should be performed.

(Refer to maintenance manual Part 2.)


1. Turn off the power.
2. Remove the upper lid.
(Refer to section 1-2-1.)
3. Remove the MD plate.
(Refer to section 1-3.)
4. Remove the cassette compartment assembly.
(Refer to section 1-2-2.)
5. Remove the upper control panel.
(Refer to section 1-2-1.)
6. Remove two screws, and remove the SC guide assembly.




7. Disconnect connector (CN500), remove six screws and pull out the front (upper) chassis assembly.




8. Undo the PCB holder, and open the FP-58 board to rear.




9. Disconnect connector (CN501) on the FP-58 board.



10. Remove two screws, and remove the power switch.
11. Disconnect connector (CN512) on the VR-152 board and connector (CN505) on the FP-58 board, and remove the front (upper) chassis assembly.



12. Disconnect connector (CN503), and remove the FP-58 board.




13. Install the FP-58 board in the reverse order of steps 1 through 12.

Note


When connecting connector (CN503), put the protrusions of the connector on the VR-153 board in the hollow of CN503, then stand the FP-58 board.

6-3-3. VR-152 Board


1. Turn off the power.
2. Remove the upper lid.
(Refer to section 1-2-1.)
3. Remove the MD plate.
(Refer to section 1-3)
4. Remove the cassette compartment assembly.
(Refer to section 1-2-2.)
5. Remove the upper control panel.
(Refer to section 1-2-1.)
6. Remove two screws, and remove the SC guide assembly.




7. Disconnect connector (CN500), remove six screws and pull out the front (upper) chassis assembly.




8. Undo the PCB holder, and open the FP-58 board.




9. Disconnect connector (CN501) on the FP-58 board.




10. Remove two screws, and remove the power switch.
11. Disconnect connector (CN512) on the VR-152 board and connector (CN505) on the FP-58 board, and remove the front (upper) chassis assembly.




12. Disconnect connector (CN503), and remove the FP-58 board.




13. Remove the nut of HEADPHONES jack.
14. Remove two screws, and remove the volume bracket.



15. Disconnect two connectors (CN510 and CN511).



16. Remove one nut and washer, and remove the VR-152 board.



17. Install the VR-152 board in the reverse order of steps 1 through 16.

Note


After installing the nuts, apply locking compound.

6-3-4. VR-153 Board


After replacing this board, audio PB should be performed.

(Refer to maintenance manual Part 2.)


1. Turn off the power.
2. Remove the upper lid.
(Refer to section 1-2-1.)
3. Remove the MD plate.
(Refer to section 1-3.)
4. Remove the cassette compartment assembly.
(Refer to section 1-2-2.)
5. Remove the upper control panel.
(Refer to section 1-2-1.)
6. Remove two screws, and remove the SC guide assembly.




7. Disconnect connector (CN500), remove six screws and pull out the front (upper) chassis assembly.




8. Undo the PCB holder, and open the FP-58 board.




9. Disconnect connector (CN501) on the FP-58 board.




10. Remove two screws, and remove the power switch.
11. Disconnect connector (CN512) on the VR-152 board and connector (CN505) on the FP-58 board, and remove the front (upper) chassis assembly.




12. Disconnect connector (CN503), and remove the FP-58 board.




13. Remove the nut of HEADPHONES jack.
14. Remove two screws, and remove the volume bracket.



15. Disconnect two connectors (CN522 and CN523).



16. Remove five nuts and washers, and remove the VR-153 board.




17. Install the VR-153 board in the reverse order of steps 1 through 16.

Note


After installing the nuts, apply locking compound.

6-3-5. KY-231 Board

1. Turn off the power.
2. Remove the lower control panel assembly.
(Refer to section 1-9.)
3. Remove five screws as shown in the figure, and remove the KY protector.




4. Remove six screws as shown in the figure.
5. Disconnect connector (CN592).



6. Install the KY-231 board in the reverse order of steps 1 through 5.

6-3-6. DP-176 Board


1. Turn off the power.
2. Remove the KY-231 board.
(Refer to section 6-3-5.)
3. Unsolder connector (CN591), and remove the DP-176 board.




4. Install the DP-176 board in the reverse order of steps 1 through 3.

6-3-7. SWC-18 Board

1. Turn off the power.
2. Pull out the lower control panel assembly.
(Refer to section 1-8.)
3. Remove two screws, and remove the sub control panel.



4. Remove three screws.
5. Unlock by sliding the SWC-18 board in the direction of the arrow, and remove the board.




6. Install the SWC-18 board in the reverse order of steps 1 through 5.


6-3-8. SWC-19 Board

After replacing this board, RF (digital) system adjustment should be performed.
(Refer to maintenance manual Part 2.)


1. Turn off the power.
2. Remove the lower control panel assembly.
(Refer to section 1-9.)
3. Remove two screws, and remove the system setup panel.



4. Remove four screws, and open the SWC-19 board.



5. Disconnect connector (CN148).




6. Install the SWC-19 board in the reverse order of steps 1 through 5.


6-3-9. CP-218 Board

After replacing this board, analog video output level check should be performed.
(Refer to maintenance manual Part 2.)

1. Turn off the power.
2. Remove 7 screws.



3. Remove the connector panel.
(Refer to section 1-2-3.)
4. Remove the harness cover.




5. Remove a screw, and remove the CP-218 board.

Note

At this time, an ornamental plate and an ornamental plate spacer are come off. Do not lose them.

6. Disconnect three connectors (CN412, CN413 and CN414).




7. Install the CP-218 board in the reverse order of steps 1 through 6.

Note

When installing the duct cover, exercise caution so as not to nip the harness.

6-3-10. CP-220 Board

1. Turn off the power.
2. Remove the CP-218 board,
(Refer to section 6-3-9.)
3. Remove 12 screws.




4. Remove a screw, and remove the CP-220 board.
5. Disconnect four connectors (CN400, CN401, CN402 and CN403).
6. Install the CP-220 board in the reverse order of steps 1 through 5.

6-3-11.DR-307/200 Board


After replacing this board, servo/DT adjustment should be performed.

(Refer to maintenance manual Part 2.)


1. Turn off the power.
2. Remove the bottom plate.
(Refer to section 1-2-1.)
3. Remove three screws, and remove the BT plate.




4. Disconnect seven connectors (CN302, CN303, CN304, CN305, CN306, CN321 and CN322).
(Refer to section 6-1-3.)



5. Undo the PCB holder, and open the DR-307/200 board.



6. Remove the DR-307/200 board from the rod holder.



7. Install the DR-307/200 board in the reverse order of steps 1 through 6.

Note


When closing the DR-307/200 board, harness of the CN302 should be put in.

6-3-12.DT-34 Board

After replacing this board, DT adjustment should be performed.

(Refer to maintenance manual Part 2.)


1. Turn off the power.
2. Remove the DR-307/200 board.
(Refer to section 6-3-11.)
3. Disconnect two connectors (CN390 and CN391).
4. Remove two screws, and remove the DT-34 board.




5. Install the DT-34 board in the reverse order of steps 1 through 4.

6-3-13.HN-181 Board


1. Turn off the power.
2. Remove the upper lid.
(Refer to section 1-2-1.)
3. Remove the MD plate.
(Refer to section 1-3.)
4. Remove the bottom plate.
(Refer to section 1-2-1.)
5. Remove three screws, and remove the BT plate.




6. Disconnect three connectors (CN302, CN321 and CN322).




7. Undo the PCB holder, and open the DR-307/200 board.




8. Disconnect four connectors (CN212, CN213, CN214 and CN215) on the HN-181 board.




9. Remove three screws, then remove the DR bracket B and DR-307/200 board.




10. Remove the harness cover.




11. Remove two screws, and remove the DT-34 board, then disconnect two connectors (CN208 and CN209).




12. Disconnect nine connectors (CN201, CN202, CN204, CN205, CN210, CN211, CN216, CN217 and CN218) on the HN-181 board.




13. Remove two screws which fix HN-184 board and HN-185 board, and remove two HN brackets each.




14. Disconnect connector (CN203) with care while holding A portion.



15. Disconnect connector (CN241) on the HN-185 board (to protect flexible card wire from damage).
16. Disconnect two connectors (CN206 and CN207) with care while holding B portion.




17. Remove four screws, and remove the HN-181 board.




18. Install the HN-181 board in the reverse order of steps 1 through 17.

6-3-14.HN-184 Board


1. Turn off the power.
2. Remove the upper lid.
(Refer to section 1-2-1.)
3. Remove the MD plate.
(Refer to section 1-3.)
4. Disconnect five connectors (CN231, CN232, CN233, CN234, CN235).




5. Remove the bottom plate.
(Refer to section 1-2-1.)
6. Remove three screws, and remove the BT plate.




7. Undo the PCB holder, and open the DR-307/200 board.




8. Remove two screws, and remove two HN brackets.



9. Disconnect connector (CN203) with care while holding A portion.




10. Remove the HN-184 board.




11. Install the HN-184 board in the reverse order of steps 1 through 10.

6-3-15.HN-185 Board


1. Turn off the power.
2. Remove the upper lid.
(Refer to section 1-2-1.)
3. Remove the MD plate.
(Refer to section 1-3.)
4. Disconnect four connectors (CN241, CN242, CN243 and CN244).




5. Remove a screw, and remove the shield plate.




6. Remove the bottom plate.
(Refer to section 1-2-1.)
7. Remove three screws, and remove the BT plate.




8. Undo the PCB holder, and open the DR-307/200 board.




9. Remove two screws, and remove the DT-34 board, then disconnect two connectors (CN208 and CN209).




10. Remove two screws and two HN brackets.



11. Disconnect two connectors (CN206 and CN207) with care while holding B portion.



12. Remove the HN-185 board.



13. Install the HN-185 board in the reverse order of steps 1 through 12.

6-4. ADJUSTMENT AND CHECK AFTER DIGITAL BOARD REPLACEMENT

After each digital board is replaced, perform adjustment and check which are described in following sections.

6-4-1. VPR-1 Board

6-4-2. APR-1 Board

As for DIF-16 and DPR-36 boards, no adjustment is needed after replacing the board. Perform operation check only.

6-4-1. VPR-1 Board

[Item List]


No.	ITEMS	BOARDS	ADJUSTMENTS	NOTES
1	COMPOSITE OUT LEVEL 1/2	VPR-1	A20: VIDEO 1/2	COMPOSITE 1 COMPOSITE 2 COMPOSITE 3
		VPR-1	CHECK	
	3	VPR-1	A20: VIDEO 3	
2	DATA SAVE		A2F: NV-RAM CONTROL	
	COMPONENT OUT LEVEL Y	VPR-1	A20: Y OUTPUT	COMPONENT Y COMPONENT R-Y COMPONENT B-Y
	R-Y	VPR-1	A20: R-Y OUTPUT	
	B-Y	VPR-1	A20: B-Y OUTPUT	
3	DATA SAVE		A2F: NV-RAM CONTROL	
	COMPONENT OUT LEVEL R-Y	VPR-1	A20: B-CAM R-Y OUTPUT	COMPONENT R-Y COMPONENT B-Y
	(BETACAM)	VPR-1	A20: B-CAM B-Y OUTPUT	
	B-Y	VPR-1	A20: B-CAM B-Y OUTPUT	
4	DATA SAVE		A2F: NV-RAM CONTROL	
	COMPONENT OUT PHASE	VPR-1	CHECK	COMPONENT
5	REF CF PULSE	VPR-1	CHECK	TP1001
6	REF SCH DET	VPR-1	CHECK	TP1002
7	INT 4FSC FREQ	VPR-1	A20: INT 4FSC FREQ	TP1003
8	PB CLOCK PHASE	VPR-1	A20: PB CK27 DL	DATA "F0"

[Equipment]


- Oscilloscope (TEKTRONIX 2465B or equivalent)
- Analog composite signal generator (TEKTRONIX 1410 or equivalent)
- Frequency Counter
- NTSC Waveform/Vector Monitor (TEKTRONIX 1750 or equivalent)
- Component Waveform Monitor (TEKTRONIX WFM300A or equivalent)

[Connection]


connection 1



connection 2



connection 3



How to operate the maintenance mode

Push ⑧ S300(DIAG/ADJUST 1) (M-1) on the SS-52 board to enter the maintenance mode.

How to enter the next menu:

Press the ⑥ JOG button once. (Enters JOG mode.)
Turn the ⑦ search dial to move the * mark to a desired item.
Press the ③ SET button.

How to exit the current menu or the maintenance mode:

Press the ② MENU button.

How to operate a tape (e.g. PLAY) in the manual adjustment or other items:




Press the ③ SET button to exit the maintenance mode temporarily. (A tape can be operated in this condition.)
Press the ② MENU button to return to the maintenance mode.

How to change the data (adjust the level) manually:

Turn the ⑦ search dial to move the * mark to the item wishing to be adjusted.
Turn the ⑦ search dial while pressing the ⑥ JOG button.

How to save the data:

Turn the ⑦ search dial to move the * mark to "A2F: NV-RAM CONTROL".
Press the ③ SET button.
Turn the ⑦ search dial to move the * mark to "SAVE ALL ADJUST DATA".
Press the ③ SET button.





[Set-up Menu]




ITEM 713 : VIDEO SETUP REFERENCE LEVEL

- 1 MASTER LEVEL : 0.0%
- 2 INPUT LEVEL : MASTER
- 3 VBLK REMOVE CNT : —
- 4 BETACAM PB LEVEL : MASTER
- 5 OUTPUT LEVEL : MASTER



1. Composite Video Output Level Adjustment

Preparations for adjustment	Specifications	Adjustments
- Enter "C21: VIDEO TEST SG" menu in the "C2: AUDIO/VIDEO CHECK" in the maintenance mode. - Select "75% Color Bars". - Enter "A20: VPR VR 0" menu in the "A2: AUDIO/VIDEO ADJUST" Step 1 - Connect the waveform monitor to COMPOSITE 1 OUT connector. (Refer to connection 1.)	COMPOSITE 1/2 OUT  $A = 100 \pm 1 \text{ IRE } (714 \pm 7 \text{ mVp-p})$	A20: VPR VR 0 VIDEO 1/2 LEVEL ↓ Level Adjustment
Step 2 Connect the waveform monitor to COMPOSITE 2 OUT connector.		Level Check
Step 3 Connect the waveform monitor to COMPOSITE 3 OUT connector.	COMPOSITE 3 OUT  $B = 100 \pm 1 \text{ IRE } (714 \pm 7 \text{ mVp-p})$	VIDEO 3 LEVEL ↓ Level Adjustment ↓ MENU
Step 4 - Enter "A2F:NV-RAM CONTROL" menu. - Save adjustment data. - Exit the maintenance mode.		A2F:NV-RAM CONTROL SAVE ALL ADJUST DATA SET ↓ MENU ⋮ Press several times. MENU


2. Component Video Output Level Adjustment

Preparations for adjustment	Specifications	Adjustments
• Connection 2. • Enter "C21: VIDEO TEST SG" menu in the "C2: AUDIO/VIDEO CHECK" in the maintenance mode. • Select "100% Color Bars". • Enter "A20:VPR VR 0" menu in the "A2:AUDIO/VIDEO ADJUST" Step 1 • Adjust so that levels of Y, R-Y and B-Y meet the specifications.	COMPONENT Y  $A = 700 \pm 7 \text{ mV p-p}$ COMPONENT R-Y  $B = 700 \pm 7 \text{ mV p-p}$ COMPONENT B-Y  $C = 700 \pm 7 \text{ mV p-p}$	A20: VPR VR 0 Y OUTPUT LEVEL ↓ Level Adjustment ↓ R-Y OUTPUT LEVEL ↓ Level Adjustment ↓ B-Y OUTPUT LEVEL ↓ Level Adjustment ↓ MENU
Step 2 • Enter "A2F:NV-RAM CONTROL" menu. • Save adjustment data. • Exit the maintenance mode.		A2F:NV-RAM CONTROL SAVE ALL ADJUST DATA SET ↓ MENU ⋮ Press several times. MENU




3. Component Video Output (Betacam) Level Adjustment

Preparations for adjustment	Specifications	Adjustments
• Connection 2. • Enter "C21: VIDEO TEST SG" menu in the "C2: AUDIO/VIDEO CHECK" in the maintenance mode. • Select "75% Color Bars". • Enter "A20:VPR VR 0" menu in the "A2:AUDIO/VIDEO ADJUST" Step 1 • Adjust so that levels of R-Y and B-Y meet the specifications.	COMPONENT R-Y  $B = 757 \pm 7 \text{ mV p-p}$ COMPONENT B-Y  $C = 757 \pm 7 \text{ mV p-p}$	A20: VPR VR 0 B-CAM R-Y OUTPUT LEVEL ↓ Level Adjustment ↓ B-CAM B-Y OUTPUT LEVEL ↓ Level Adjustment ↓ MENU
Step 2 • Enter "A2F:NV-RAM CONTROL" menu. • Save adjustmet data. • Exit the maintenance mode.		A2F:NV-RAM CONTROL SAVE ALL ADJUST DATA SET ↓ MENU ⋮ Press several times. MENU



4. Component Video Output Phase Check

Preparations for adjustment	Specifications	Adjustments
• Connection 2. • Enter "C21: VIDEO TEST SG" menu in the "C2: AUDIO/VIDEO CHECK" in the maintenance mode. • Select the "BOWTIE".	waveform monitor  Y/R-Y 0 ns Y/B-Y 0 ns -20 ns +20 ns -20 ns +20 ns Tek Measure the BOWTIE DIP points (cross points of the Y/R-Y and Y/B-Y). $0 \pm 10 \text{ ns}$	Check

5. REF.CF Pulse Check

Preparations for adjustment	Specifications	Adjustments
• Connection 3. • 1410 setting : GEN LOCK mode • 1750 setting : SCH mode Step 1 • Adjust the SCH of SG2 (1410).	 SCH = 0°	1410 SC PHASE VR
Step 2 • Observe FRAME REF of the TSG170A and TP1001 on the VPR-1 board with the oscilloscope. • Turn the SC PHASE VR of the 1410 clockwise slowly from the standard point. When the waveform of the oscilloscope changes A to B, the phase of the burst is referred to as Asc. • Turn the SC PHASE VR of the 1410 counterclockwise slowly from the standard point. When the waveform of the oscilloscope changes A to B, the phase of the burst is referred to as Bsc. FRAME REF TP1001/ VPR (B-1) waveform A FRAME REF TP1001/ VPR (B-1) waveform B 	 Asc - Bsc ≤ 10°	Check
Step 3 When the specification is not met: • Enter "A20:VPR VR 0" menu in the "A2:AUDIO VIDEO ADJUST" in the maintenance mode.		A20:VPR VR 0 REF 1st FLD DET ↓ Phase Adjutment ↓ MENU
Step 4 • Enter "A2F:NV-RAM CONTROL" menu. • Save adjustment data. • Exit the maintenance mode.		A2F:NV-RAM CONTROL SAVE ALL ADJUST DATA SET ↓ MENU ⋮ Press several times. MENU

6. REF SCH DET Check

Preparations for adjustment	Specifications	Adjustments
• Connection 3. • 1410 setting : GEN LOCK mode • 1750 setting : SCH mode Step 1 • Adjust the SCH of SG2 (1410).	 SCH = 0°	1410 SC PHASE VR
Step 2 • Observe TP1002 on the VPR-1 board with the oscilloscope. • Turn the SC PHASE VR of the 1410 clockwise slowly from the standard point. When the waveform of the oscilloscope changes A to B, the phase of the burst is referred to as Asc. • Turn the SC PHASE VR of the 1410 counterclockwise slowly from the standard point. When the waveform of the oscilloscope changes A to B, the phase of the burst is referred to as Bsc. TP1002/VPR1 ————— +5V (B, C-2) ————— GND waveform A TP1002/VPR1 - - - - - (B, C-2) ————— GND waveform B	 Asc - Bsc ≤ 10°	Check
Step 3 When the specification is not met: • Enter "A20:VPR VR 0" menu in the "A2:AUDIO VIDEO ADJUST" in the maintenance mode.		A20:VPR VR 0 REF SCH DET ↓ Phase Adjustment ↓ MENU
Step 4 • Enter "A2F:NV-RAM CONTROL" menu. • Save adjustment data. • Exit the maintenance mode.		A2F:NV-RAM CONTROL SAVE ALL ADJUST DATA SET ↓ MENU : MENU Press several times.

7. INT 4Fsc Frequency Adjustment

Preparations for adjustment	Specifications	Adjustments
Step 1 • Disconnect the REF IN of the unit. • Connect the frequency counter to TP1003 on the VPR-1 board. • Enter "A20:VPR VR 0" menu in the "A2:AUDIO/VIDEO ADJUST" in the maintenance mode.	TP1003/VPR-1(B-1) 14, 318, 181 $\pm$ 50 Hz	A20: VPR VR 0 INT 4Fsc FREQ ↓ Frequency Adjustment ↓ MENU
Step 2 • Enter "A2F:NV-RAM CONTROL" menu. • Save adjustment data. • Exit the maintenance mode.		A2F:NV-RAM CONTROL SAVE ALL ADJUST DATA SET ↓ MENU : Press several times. MENU

8. PB Clock Phase Adjustment

Preparations for adjustment	Specifications	Adjustments
Step 1 Enter "A20:VPR VR 0" menu in the "A2:AUDIO/VIDEO ADJUST" in the maintenance mode.	DATA "F0"	A20: VPR VR 0 PB CK27 DL ↓ Data Setting ↓ MENU
Step 2 - Enter "A2F:NV-RAM CONTROL" menu. - Save adjustment data. - Exit the maintenance mode.		A2F:NV-RAM CONTROL SAVE ALL ADJUST DATA SET ↓ MENU ⋮ Press several times. MENU

6-4-2. APR-1 Board

Adjustment is not necessary when APR-1 Board is replaced on DVW-510.

[Equipment]

- Audio Signal Generator (SONY TEKTRONIX SG505-option 02 or equivalent)
- Audio Analyzer (SONY TEKTRONIX AA501A-option 02 or equivalent)
Note: Audio analyzer should be filtered through 80 kHz L.P.F unless otherwise specified.
- Alignment tape CR8-1A (Part No.8-960-097-45)

Contents

TIME min.: sec.	VIDEO TRACK	VIDEO TRACK	VIDEO TRACK
0 : 00	1 kHz, 0 VU * ¹	Black Burst	CTL
3 : 00	15 kHz, 0 VU	Black Burst	CTL
5 : 00	1 kHz, -20 VU	Black Burst	CTL
6 : 00	40 Hz, -20 VU * ²	Black Burst	CTL
6 : 30	7 kHz, -20 VU * ²		
7 : 00	10 kHz, -20 VU * ²		
7 : 30	15 kHz, -20 VU * ²		
8 : 00	1 kHz, 0 VU		
10 : 00		—	1 kHz sine wave

- * 1. When this tape is reproduced in the audio reference level check or adjustment, the output level (0 dB) should be corrected according to the correction value as follows.
Example: Correction Value = -0.5 dB
Output level = 0 dB - 0.5 dB = -0.5 dB
- * 2. When this tape is reproduced in the audio frequency response check or adjustment, the output level should be corrected according to the correction value.

• Alignment tape CR5-1B (Part No.8-960-096-41)


TIME min.: sec.	VIDEO TRACK	AFM	CTL
0 : 00	RF Sweep	No Signal	CTL
2 : 00	60% H Sweep (CTDM)		
5 : 00	Pulse & Bar (CTDM)		
8 : 00	60% Multi Burst		
11 : 00	Pulse & Bar		
14 : 00	75% Color Bars	400 Hz SINE WAVE 25 kHz DEVIATION	
16 : 30		75 kHz DEVIATION	
17 : 00	50% Bowtie & 12.5T	No Signal	
19 : 00	Line 17 Signal		
22 : 00	Quad Phase		
24 : 00	Flat Field		
26 : 00	75% Color Bars with Dropout		
28 : 00	Composite H Sweep with VISC		
30 : 00			

1. LAU PB Level Adjustment (For DVW-A510/CA510)

Preparations for adjustment	Specifications	Adjustments
Play back the 1 kHz, 0 VU signal portion (0:00-2:55) of the alignment tape CR8-1A.	ANALOG AUDIO OUTPUT CH1 and CH2 $+4.0 \pm 0.1 \text{ dBu}$ (terminated by $600 \ \Omega$)	CH1: ⚙RV103/AP-28(A-1) CH2: ⚙RV203/AP-28(A-1)





2. AFM PB Level Adjustment (For DVW-A510/CA510)

Preparations for adjustment	Specifications	Adjustments
- Do not extend the AP-28 board. - Play back the color bars signal portion (14:00-16:30) of the alignment tape CR5-1B.	ANALOG AUDIO OUTPUT CH3 and CH4 $+4.0 \pm 0.1 \text{ dBu}$ (terminated by $600 \ \Omega$)	CH3: ⚙RV502/AP-28(C-1) CH4: ⚙RV602/AP-28(C-1)



3. Offset Level Check (Board Suffix No. 11, 12 or 21)

* More than 20 minutes should elapse after turning the power on, when this check is performed.

Preparations for adjustment	Specifications	Adjustments																																																																																															
- Eject the cassette tape. - Connect CH1 and CH2 of the oscilloscope to TP1300(or TP1301) and TP1302 on the APR-1 board.	TP1300/ TP1301 FS: TP1302 	Check																																																																																															
Step 1 - Check that lower 8 bits situate between Fig.B and Fig.C. Step 2 When specification is not met - Adjust so that waveform of Fig.A appears.	Fig. A MSB LSB  <table><tr><td></td><td>MSB</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>LSB</td></tr><tr><td>Bit</td><td>18</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></tr><tr><td>Fig B</td><td>H</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>H</td><td>L</td><td>H</td><td>H</td><td>x</td><td>x</td><td>x</td></tr><tr><td>Fig A</td><td>H</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>H</td><td>H</td><td>L</td><td>L</td><td>x</td><td>x</td><td>x</td></tr><tr><td>Fig C</td><td>H</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>H</td><td>H</td><td>H</td><td>H</td><td>H</td><td>x</td><td>x</td></tr></table> x:Do not care Fig. B  Fig. C 		MSB																	LSB	Bit	18																		Fig B	H											H	L	H	H	x	x	x	Fig A	H											H	H	L	L	x	x	x	Fig C	H											H	H	H	H	H	x	x	TP1300 CH1: ♂RV103/APR-1(R-3) CH2: ♂RV203/APR-1(M-3) TP1301 CH3: ♂RV303/APR-1(K-3) CH4: ♂RV403/APR-1(G-3)
	MSB																	LSB																																																																															
Bit	18																																																																																																
Fig B	H											H	L	H	H	x	x	x																																																																															
Fig A	H											H	H	L	L	x	x	x																																																																															
Fig C	H											H	H	H	H	H	x	x																																																																															
		TRIG: TP1302/APR-1 (C-4)																																																																																															

3. Offset Level Check (Board Suffix No. 16 and later)

* More than 20 minutes should elapse after turning the power on, when this check is performed.

Preparations for adjustment	Specifications	Adjustments																																																						
- Eject the cassette tape. - Connect CH1 and CH2 of the oscilloscope to TP1300(or TP1301) and TP1302 on the APR-1 board.	TP1300/ TP1301 FS: TP1302 CH1/CH3 CH2/CH4 5V5V2μs MSB LSB 5.890μs Fig. A 5V5V1μs <table><tr><td></td><td>MSB</td><td></td><td></td><td></td><td></td><td></td><td></td><td>LSB</td><td></td></tr><tr><td>Bit</td><td>18</td><td></td><td>8</td><td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td></tr><tr><td>Fig B</td><td>H</td><td></td><td>H</td><td>H</td><td>H</td><td>L</td><td>H</td><td>L</td><td>×</td><td>×</td></tr><tr><td>Fig A</td><td>H</td><td></td><td>H</td><td>H</td><td>H</td><td>H</td><td>L</td><td>L</td><td>×</td><td>×</td></tr><tr><td>Fig C</td><td>H</td><td></td><td>H</td><td>H</td><td>H</td><td>H</td><td>H</td><td>L</td><td>×</td><td>×</td></tr></table> × Do not care Fig. B 5.890μs 5V5V1μs Fig. C 5.890μs 5V5V1μs		MSB							LSB		Bit	18		8	7	6	5	4	3	2	1	Fig B	H		H	H	H	L	H	L	×	×	Fig A	H		H	H	H	H	L	L	×	×	Fig C	H		H	H	H	H	H	L	×	×	Check TP1300 CH1: RV103/APR-1(P-3) CH2: RV203/APR-1(M-3) TP1301 CH3: RV303/APR-1(J-3) CH4: RV403/APR-1(H-3) TRIG: TP1302/APR-1 (C-4)
	MSB							LSB																																																
Bit	18		8	7	6	5	4	3	2	1																																														
Fig B	H		H	H	H	L	H	L	×	×																																														
Fig A	H		H	H	H	H	L	L	×	×																																														
Fig C	H		H	H	H	H	H	L	×	×																																														

3. Offset Level Check (Board Suffix No. 13, 14, 22 or 23)

* More than 20 minutes should elapse after turning the power on, when this check is performed.

Preparations for adjustment	Specifications	Adjustments																																												
- Eject the cassette tape. - Connect CH1 and CH2 of the oscilloscope to TP1300(or TP1301) and TP1302 on the APR-1 board.	A2 20 V 5.890 ns CH1/CH3 CH2/CH4 TP1300/ TP1301 FS: TP1302 5V 5V 2 ns	Check																																												
Step 1 Check that lower 8 bits situate between Fig.B and Fig.C.	MSB 5.890 ns LSB Fig. A 5V 5V 1 ns	TP1300 CH1: RV103/APR-1(R-3) CH2: RV203/APR-1(M-3) TP1301 CH3: RV303/APR-1(K-3) CH4: RV403/APR-1(G-3)																																												
Step 2 When specification is not met Adjust so that waveform of Fig.A appears.	MSB LSB <table><tr><td>Bit</td><td>18</td><td></td><td>8</td><td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td></tr><tr><td>Fig B</td><td>H</td><td></td><td>H</td><td>H</td><td>H</td><td>L</td><td>H</td><td>L</td><td>x</td><td>x</td></tr><tr><td>Fig A</td><td>H</td><td></td><td>H</td><td>H</td><td>H</td><td>H</td><td>L</td><td>L</td><td>x</td><td>x</td></tr><tr><td>Fig C</td><td>H</td><td></td><td>H</td><td>H</td><td>H</td><td>H</td><td>H</td><td>L</td><td>x</td><td>x</td></tr></table> x:Do not care	Bit	18		8	7	6	5	4	3	2	1	Fig B	H		H	H	H	L	H	L	x	x	Fig A	H		H	H	H	H	L	L	x	x	Fig C	H		H	H	H	H	H	L	x	x	
Bit	18		8	7	6	5	4	3	2	1																																				
Fig B	H		H	H	H	L	H	L	x	x																																				
Fig A	H		H	H	H	H	L	L	x	x																																				
Fig C	H		H	H	H	H	H	L	x	x																																				
	5.890 ns Fig. B 5V 5V 1 ns 5.890 ns Fig. C 5V 5V 1 ns																																													
		TRIG: TP1302/APR-1 (C-4)																																												

6-5. ADJUSTMENT AFTER TBC-23 BOARD REPLACEMENT

When the TBC-23 board had been replaced, be sure to perform adjustment in accordance with the board suffix number.

When make a board replacement, ask to Sony service personnel.

SECTION 7


PERIODIC MAINTENANCE AND INSPECTION

7-1. CLEANING

To make the most of the functions, fully realize the performance of this unit, and to lengthen the life of the unit and tape, clean the components often.

7-1-1. General Information for Cleaning

1. Index



2. Cautions

- Turn the power off before cleaning.
- Each block in the mechanical deck consists of a precision part and is adjusted precisely. Be careful not to damage each part and to apply an excessive force during cleaning.
- Do not touch the greased portions during cleaning. If grease attaches to a cleaning cloth, replace the cleaning cloth by new one. If a cleaning cloth smeared with grease is used, grease may attach to the places where it should not.
- Do not insert a cassette tape before a cleaning fluid completely evaporates after cleaning.

3. Preparation

- (1) Turn the power off.
- (2) Remove the upper lid. (Refer to Section 1-2-1.)
- (3) Remove the sound insulation plate (MD). (Refer to Section 1-3.)
- (4) Remove the cassette compartment. (Refer to Section 1-2-2.)

7-1-2. Rotary Heads Cleaning

Caution

The rotary heads are the part that can be damaged easily. Be careful not to damage the rotary heads during cleaning.

Tools

- Cleaning cloth: 3-184-527-01
- Cleaning fluid: 9-919-573-01

Caution

Do not use a cotton swab to clean the rotary heads.

Procedures

1. Loosen the two screws and remove the upper drum cover.

Note: These screws cannot be removed because of stoppers.


2. Hold the cleaning cloth moistened with cleaning fluid keeping it from becoming wrinkled. And press the cleaning cloth slightly against the rotary heads.
3. Rotate the inner drum slowly counterclockwise two or three turns and clean the rotary heads with the cleaning cloth held.

Caution

Be sure to rotate the inner drum counterclockwise and clean the rotary heads along the circumference. Do not rotate the inner drum in the direction opposite to the specified direction (clockwise) or clean it in the vertical direction. This may damage the rotary heads and the brush/slip ring assembly.

4. After cleaning, wipe it with a dry cleaning cloth two or three times.
5. Tighten the two screws while pressing the upper drum cover towards the drum support direction.

Tightening torque: $14.7 \times 10^{-2} \text{ N}\cdot\text{m}$ (1.5 Kgf·cm)



7-1-3. Upper Drum's Tape Running Surface Cleaning

Caution

Be careful not to damage the upper drum during cleaning. Pay careful attention when cleaning the edge portion below the upper drum because it is located near the rotary heads.

Tools

- Cleaning cloth: 3-184-527-01
- Cleaning fluid: 9-919-573-01


Procedures

1. Press the cleaning cloth moistened with a cleaning fluid slightly against the upper drum's tape running surface (shaded portion in the figure).
2. Clean the upper drum's tape running surface along the circumference two or three times.

Caution

Pay careful attention when cleaning the edge portion below the upper drum.

3. After cleaning, wipe it with a dry cleaning cloth two or three times.



7-1-4. Lower Drum's Tape Running Surface and Lead Surface Cleaning

Caution

Be careful not to damage the lower drum (specially lead surface) during cleaning. Pay careful attention when cleaning the edge portion above the lower drum because it is located near the rotary heads.

Tools


- Cleaning cloth: 3-184-527-01
- Cleaning fluid: 9-919-573-01
- Skewer or an equivalent (A metallic skewer cannot be used.)

Procedures

1. As shown in the figure, put a skewer (or an equivalent) along the drum lead surface and remove the magnetic powder.

Caution

1. Do not use a metallic skewer instead of the skewer. This may damage the tape running surface.
2. Tracking may be badly influenced when magnetic powder attaches to the drum lead surface. Remove the magnetic powder completely during cleaning.
2. Clean the drum lead surface and lower drum's tape running surface (shaded portion in the figure) with a cleaning cloth moistened with a cleaning fluid.
3. After cleaning, wipe it with a dry cleaning cloth two or three times.



7-1-5. Stationary Heads Cleaning

Cautions

- Be careful not to damage the head surface when cleaning the stationary heads.
- The full erase head is not installed in a player.

Tools

- Cleaning cloth: 3-184-527-01
- Cleaning fluid: 9-919-573-01


Procedures

1. Clean the tape running surfaces of the audio/TC head, CTL head, and full erase head in the vertical direction with a cleaning cloth moistened with a cleaning fluid.

Caution

An error may occur in the recording or playback when magnetic powder attaches to the head gap portion of the audio/TC head, CTL head, and full erase head. Remove the magnetic powder completely during cleaning.

2. After cleaning, wipe it with a dry cleaning cloth two or three times.



7-1-6. Tape Running System and Tape Cleaner Cleaning

Warning

The tape cleaner has a sharp edge. Do not touch the edge with bare hands. Pay careful attention when cleaning the tape cleaner.

Tools


- Cleaning cloth: 3-184-527-01
- Cleaning fluid: 9-919-573-01

Procedures

1. Pass a piece of paper approximately this manual's paper thick through the clearance of the tape cleaner from top to bottom four or five times.
At this time, do not move the paper from bottom to top.
2. Clean the tape running surfaces (shaded portions in the figure) of each guide with cleaning cloth moistened with a cleaning fluid.
3. After cleaning, clean it with a dry cleaning cloth two or three times.

Warning

Do not touch the edge portion of the tape cleaner with bare hands.



7-1-7. Fan Motor Cleaning

Caution


The temperature in the unit increases when dust attaches to the fan motor and when the air flow is disturbed. This may badly influence the performance and life of the unit. Clean the fan motor on the rear panel periodically because it accumulates dust easily.

Tools

- Cleaning cloth: 3-184-527-01
- Cleaning fluid: 9-919-573-01
- Vacuum cleaner

Procedures

1. Remove the power panel. (Refer to Section 1-2-1.)
2. Remove the connector panel. (Refer to Section 1-2-3.)
3. Remove the dust on the fan motors using a vacuum cleaner.
4. Clean the fin (shaded portion in the figure) with cleaning cloth moistened with cleaning fluid.
5. Install the connector panel. (Refer to Section 1-2-3.)
6. Install the power panel. (Refer to Section 1-2-1.)



7-1-8. Cassette Compartment Cleaning

Cautions

- Be careful not to apply an excessive force to the compartment or the mirror when cleaning the cassette compartment.
- Do not clean the door and the mirror with alcohol. This may cause a crack.

Tools


- Cloth (or Gauze)
- Vacuum cleaner

Procedures

1. Remove the cassette compartment from the unit. (Refer to Section 1-2-2.)
2. Remove the dust on the cassette compartment from the cassette insertion inlet using a vacuum cleaner.
3. Clean the compartment (shaded portion in the figure) with a dry cloth (or gauze).

Caution

Do not apply an excessive force to the compartment block.



7-2. PERIODIC CHECK

To make the most of the functions, fully realize performance of the unit, lengthen the life of the unit and tape, a periodic check is recommended.

7-2-1. Hours Meter

This unit can display an hours meter on the time counter display of the upper control panel or on the monitor connected to this unit. Perform a periodic check with this hours meter as a reference.

1. Display procedure

Refer to Section 1-10-2 in Installation Manual.

2. Contents of display


SET-UP MENU	DESCRIPTION	TIME COUNTER DISPLAY	MONITOR DISPLAY
H01: OPERATION HOURS	Accumulated hours when the power of the unit is on	Display the time by ten hours. (Note)	Display the time by an hour.
H02: DRUM RUNNING HOURS	Accumulated hours when the drum rotates in the threading end state	Display the time by ten hours. (Note)	Display the time by an hour.
H03: TAPE RUNNING HOURS	Accumulated hours when the tape runs in the F. FWD, REW, PLAY, SEARCH, REC and EDIT modes (not including STILL mode)	Display the time by ten hours. (Note)	Display the time by an hour.
H04: THREADING COUNTER	Accumulated number of threading and unthreading times	Display the number by ten times. (Note)	Display the actual number

(Note) While pressing the JOG or SHUTTLE button on the lower control panel, display the time by an hour (or display the actual number).


〈Example〉

In a case of the total hours that the power of the unit has been turned on is 12,345 hours:

• Time Counter Display



• Monitor Display



7-2-2. Periodic Check List

The replacement time shown in the table below is not the guarantee term of parts. Use this table as guidelines for maintenance and inspection. The replacement time of parts varies depending on the operating environment and conditions of the unit.

To maintain the steady performance, it is recommended to clean the tape running system and perform the RF system automatic adjustment every the following hours as a guide.

- every 50 hours (H02): Cleaning by cleaning tape (Refer to Section 1-11-1.)
- every 200 hours (H02): Perform the cleaning as the following procedure.
 1. Cleaning by cleaning tape (Refer to Section 1-11-1.)
 2. Cleaning by cleaning cloth (Refer to Section 7-1-2 through 7-1-6.)
- every 500 hours (H02): Execute the following automatic adjustment. (Refer to Section 5-8.)
A12: ADV EQUALIZER

Note: The part marked with “↓” in the table is replaced simultaneously with when the part in the column below its mark is replaced. ☆ : Replace the part. ◇ : Perform check (adjustment).

No.	Item	Menu No.	Inspection Hours (h)						Replacement Parts			
			1000	2000	3000	4000	5000	6000	Part Name		Part No.	Q'ty
Drum Block												
1	Inner Drum Assembly ^(Note 1)	H02	☆	☆	↓	☆	☆	↓	INNER DRUM ASSY DJR-06A-R: DVW-A510P DJR-08A-R: DVW-510P	A-8260-747- A-8260-749-	1 1	
2	Brush/Slip Ring Assembly	H02	—	—	↓	—	—	↓	SR13 ASSY (RP), BRUSH: DVW-A510P SR9 ASSY (RP), BRUSH: DVW-510P	A-8267-571- A-8267-572-	1 1	
3	Drum Assembly ^(Note 1)	H02	—	—	☆	—	—	☆	DRUM ASSY DJH-06A-R: DVW-A510P DJH-08A-R: DVW-510P	A-8260-743- A-8260-745-	1 1	
Cleaners												
4	Cleaning Roller ^(Note 4)	H02	☆	☆	↓	☆	☆	↓	ROLLER ASSY, V CLEANING	X-3167-281-	1	
5	Rotary Head Cleaner Assembly	H02	—	—	☆	—	—	☆	CLEANER ASSY, VIDEO HEAD	A-8267-398-	1	
6	AT Head Cleaner	H02	☆	☆	☆	☆	☆	☆	ARM ASSY, CL	X-3167-053-	1	
Tape Running System												
7	Pinch Roller	H03	☆	☆	☆	☆	☆	☆	ARM ASSY, PINCH	X-3167-054-	1	
8	Audio/TC Head ^(Note 2)	H03	—	—	◇	—	—	☆	HEAD, AUDIO PS244-2103J	8-825-779-02	1	
9	CTL Head	H03	—	—	☆	—	—	☆	HEAD, CTL PS244-21B	8-825-554-83 8-825-554-84	1 1	
10	Capstan Motor	H03	—	—	—	—	—	☆	MOTOR, DC SP37AA	1-698-179-12	1	
Driving System												
11	Pinch Solenoid ^(Note 3)	H03	—	—	—	—	—	☆	SOLENOID, PLUNGER	1-454-338-00	1	
		H04	Replace when used 200,000 times									
12	Brake Lining	H03	—	—	☆	—	—	☆	LINING ASSY	X-3717-205-	2	
13	Reel Motor Assembly	H03	—	—	☆	—	—	☆	S Side: RM (PC) ASSY: DVW-A510P	A-8267-964-	1	
									RM ASSY: DVW-510P	A-8267-774-	1	
									T Side: RM (TPC) ASSY: DVW-A510P	A-8310-086-	1	
									RM ASSY: DVW-510P	A-6737-207-	1	
Others												
14	Fan Motor	H01	Repace when used 10,000 H						FAN, DC	1-541-431-41	2	
15	Filter of the Upper Drum Cover	H02	☆	☆	☆	☆	☆	☆	FILTER	3-182-649-	1	

(Note 1) In an environmental condition of high humidity and excessive dust to operate the unit, it may cause in shortening the life of the heads.

Therefore, it is recommended to use the unit in an air-conditioned place at middle temperature and humidity of the specifications, and lesser dust circumstances. In addition, the tapes should be kept in the same conditions.


(Note 2) ◇: Adjust the audio frequency response. (Refer to Section 8-7.)

(Note 3) Replace the pinch solenoid when the replacement time or count is reached whichever is earlier.



(Note 4) It is recommended to replace the CR spacer (3-182-765-) at the same time.

< Mechanical Deck Block >

Procedure
Refer to Section 8-2-1.
Refer to Section 8-2-2.
Refer to Section 8-2-3.
Refer to Section 8-2-4.
Refer to Section 8-2-4.
Refer to Section 8-2-5.
Refer to Section 8-2-7.
Refer to Section 8-2-8.
Refer to Section 8-2-9.
Not Replacement
Refer to Section 8-2-10.
Refer to Section 8-2-11.
Refer to Section 8-2-12.
Refer to Section 8-2-13.
Refer to Section 8-2-14.
Refer to Section 8-2-15.



< Unit >




Note: Replace the parts shown in the table below periodically when the threading/unthreading operation is repeated frequently.

No.	Item	Menu No.	Inspection Time	Replacement Parts		
				Part Name	Part No.	Q'ty
16	Brake Solenoid	H04	Replace when used 200,000 times	PLUNGER SOLENOID	1-454-417-31	2
17	S Tension Regulator Assembly			REGULATOR ASSY, TENSION	A-8267-795-	1
18	T Tension Regulator Assembly			T-TEN ASSY	A-8267-423-	1
19	T Drawer Arm Assembly			DRAWER ASSY, T	A-8267-381-	1
20	Gear Box Assembly			BOX ASSY, GEAR	A-8267-424-	1
21	Threading Ring Assembly			RING ASSY, THREADING	A-8267-395-	1
22	Ring Roller			ROLLER, RING	3-180-677-	2
				ROLLER, RING B	3-180-679-	1
23	Pinch Arm Guard			GUARD, PINCH ARM	3-180-853-	1
24	CL Guide Rail			RAIL, CL GUIDE	3-180-874-	1
25	Cassette Compartment Assembly			CASSETTE COMPARTMENT ASSY	A-8267-589-	1


(Note 5) Maintenance Manual Part 2 is distributed separately. If you wish to obtain one, please consult with Sony's service organization.

< Mechanical Deck Block >

Procedure
Refer to Volume 1 of MAINTENANCE MANUAL Part 2 (Note 5)
Refer to Section 9-2-2. (Exploded view)
Refer to Section 9-2-2. (Exploded view)
Refer to Section 1-2-2.



< Cassette Compartment >



CASSETTE COMPARTMENT ASSEMBLY

SECTION 8

REPLACEMENT OF PERIODIC MAINTENANCE PARTS

8-1. GENERAL INFORMATION FOR PARTS REPLACEMENT AND ADJUSTMENT

8-1-1. Basic Knowledge

1. Tape Cleaner

Never touch the edge of the tape cleaner with bare hands.

It is in danger of cutting your finger because the tape cleaner has a sharp edge.

Pay careful attention when replacing or adjusting the peripheral parts.

2. Tools

- Clean the surface of the tool with a cleaning cloth moistened with cleaning fluid before use it.
 - Cleaning cloth: 3-184-527-01
 - Cleaning fluid: 9-919-573-01
- Be careful not to damage the tool. If the flawed tool is used, adjustment cannot be performed correctly.

8-1-2. Threading End Mode and Unthreading End Mode

1. Threading End Mode


Threading end mode means that the threading ring rotates in the counterclockwise direction, then stops.

There are three ways of putting the unit into the threading end mode without installing the cassette compartment.

Method ①: Turn the power on.

Method ②: Press the STOP button in power on state.

Method ③: Turn the M gear of the gear box assembly in the direction of the arrow A.



Threading End Mode


2. Unthreading End Mode

Unthreading end mode means that the threading ring rotates in the clockwise direction, then stops. (It is same state with EJECT completion mode.)

There are two ways of putting the unit into the unthreading end mode without installing the cassette compartment.

Method ①: Press the EJECT button in threading end mode.

Method ②: Turn the M gear of the gear box assembly in the direction of the arrow B.



Unthreading End Mode

8-1-3. L Cassette Position and S Cassette Position


1. L Cassette Position

L cassette position means that the reel tables are in the position of L cassette tape.

There are two ways of putting the reel tables into the L cassette position without installing the cassette compartment.

Method ①: Press the switch S700 (C-1/side A) on the SS-52 board in power on state.

Method ②: Turn the drive gear in the direction of the arrow C.




2. S Cassette Position

S cassette position means that the reel tables are in the position of S cassette tape.

There are two ways of putting the reel tables into the S cassette position without installing the cassette compartment.

Method ①: Press the switch S700 (C-1/side A) on the SS-52 board in power on state.


Method ②: Turn the drive gear in the direction of the arrow D.



8-2. PARTS REPLACEMENT

1. Index


〈Mechanical Deck Block〉




No.	Part Name	Page
1	Inner Drum Assembly	8-10
2	Brush/slip ring Assembly	8-24
3	Drum Assembly	8-26
4	Rotary Head Cleaner Assembly	8-32
5	AT Head Cleaner	8-34
7	Pinch Roller	8-38

No.	Part Name	Page
8	Audio/TC Head	8-40
9	CTL Head	8-44
10	Capstan Motor	8-48
11	Pinch Solenoid	8-52
12	Brake Lining	8-58
13	Reel Motor Assembly	8-60

〈Overall Block〉



No.	Part Name	Page
14	Fan Motor	8-69



No.	Part Name	Page
15	Filter	8-70

2. Note

(1) Grease and Oil

- Please use only the specified grease and oil.
If the different grease or oil is used, major malfunctions may be caused due to differences in viscosity and ingredients.
And if the grease or oil is used that has been mixed with dust, major malfunctions may be caused.
Please use the following grease and oil.

- Grease (SGL-505): 7-662-010-04
- Oil: 7-661-018-18

- Smear just enough grease to create a thin film on the surface of the part.
Any grease that adheres to other surrounding parts must be wipe with gauze or soft cloth.

- A drop of oil is defined as follows:
About the amount that will adhere to the end of a stick 2 mm in diameter, as shown in the figure.

- Do not use the grease and oil except for specified portions.

(2) Stop Washer

It should not be used the stop washer once and again.

- Stop washer (d=2.3 mm): 3-669-596-00

3. Preparation


(1) When replacing parts on the upper surface of the mechanical deck

- except DVW-CA510P/CA510

- ① Turn the power off.
- ② Remove the upper lid. (Refer to Section 1-2-1.)
- ③ Remove the plate MD. (Refer to Section 1-3.)
- ④ Remove the cassette compartment. (Refer to Section 1-2-2.)

- DVW-CA510P/CA510

- ① Turn the power off.
- ② Remove the upper lid. (Refer to Section 1-3-1.)
- ③ Remove the ejector assembly. (Refer to Section 1-4.)
- ④ Remove the cassette compartment. (Refer to Section 1-3-2.)



(2) When replacing parts on the bottom surface of the mechanical deck

- except DVW-CA510P/CA510

- ① Turn the power off.
- ② Remove the upper lid. (Refer to Section 1-2-1.)
- ③ Remove the plate MD. (Refer to Section 1-3.)
- ④ Remove the cassette compartment. (Refer to Section 1-2-2.)
- ⑤ Remove the bottom plate. (Refer to Section 1-2-1.)
- ⑥ Remove the plate BT.

- DVW-CA510P/CA510

- ① Turn the power off.
- ② Remove the upper lid. (Refer to Section 1-3-1.)
- ③ Remove the ejector assembly. (Refer to Section 1-4.)
- ④ Remove the cassette compartment. (Refer to Section 1-3-2.)
- ⑤ Remove the bottom plate. (Refer to Section 1-3-1.)
- ⑥ Remove the plate BT.

8-2-1. Inner Drum Assembly Replacement

Outline

Replacement
1. Remove the Rotary Head Cleaner Assembly
2. Remove the Upper Drum Cover
3. Disconnect the Flexible Board (CN241/HN-185 Board)
4. Remove the Brush/Slip Ring Assembly
5. Remove the Upper Drum Assembly
6. Remove the Inner Drum Assembly
7. Cleaning (Inner Drum Assembly Mounting Surface, Drum Support Mounting Surface, Lower Drum Flange Surface, Tape Running Surface, Lead Surface, and Contacting Points)
8. Install the Inner Drum Assembly
9. Install the Upper Drum Eccentricity Adjustment Tool
10. Adjust the Inner Drum Eccentricity
11. Remove the Upper Drum Eccentricity Adjustment Tool
12. Cleaning (Height Determining Plate's Lower Surface, Drum Support's Upper Surface, and Upper Drum Contacting Surface)
13. Install the Upper Drum Assembly
14. Cleaning (DR-205 Board's Contacting Points and Brush/Slip Ring Assembly Mounting Surface)
15. Install the Brush/Slip Ring Assembly
16. Connect the Flexible Board (CN241/HN-185 Board)
17. Cleaning (Rotary Heads and Upper Drum's Tape Running Surface)
18. Install the Upper Drum Cover
19. Install the Rotary Head Cleaner Assembly
Adjustment after Replacement
20. Confirm the Tape Running (Refer to Section 8-4-2.)
21. Confirm the Video Tracking (Refer to Section 8-4-3.)
22. Confirm the CTL Head Height (Refer to Section 8-4-4.)
23. Adjust the CTL Head Position (Refer to Section 8-4-5.)
24. Confirm the Audio/TC Head Height (Refer to Section 8-4-6.)
25. Adjust the Audio/TC Head Position (Refer to Section 8-4-9.)
26. Perform the Servo/DT and RF Adjustment (Refer to Section 8-5.)
27. Perform the Adjustment after Drum Replacement (Refer to Section 8-6.)

Note

When the rotary head tip was worn or damaged, replace the inner drum assembly. It cannot be replaced only head tip.

Basic Knowledge

For except the periodic replacement time, replace the inner drum assembly in the following case.

- A correct RF signal waveform cannot be obtained even if the tracking adjustment is performed.

Tools

- Hexagonal wrench driver (2.5 mm): 7-700-766-04
- Torque screwdriver (6 kg•cm)(JB-5251): J-6252-510-A
- Torque screwdriver (12 kg•cm)(JB-5252): J-6252-520-A
- Torque screwdriver's bit (+ 2 mm, l=75 mm): J-6323-420-A
- Torque screwdriver's hexagonal bit (d=2.5 mm, l=120 mm): J-6251-090-A

- Cleaning cloth: 3-184-527-01
- Cleaning fluid: 9-919-573-01


- Upper drum eccentricity adjustment tool (1): J-6001-840-A
- or upper drum eccentricity adjustment tool (6): J-6325-530-A
- Upper drum eccentricity adjustment tool (2): J-6001-830-A
- Upper drum eccentricity adjustment tool (3): J-6001-820-A
- Upper drum eccentricity adjustment tool (5): J-6087-000-A

Note1: The eccentricity adjustment tool is named an "upper drum eccentricity adjustment tool" in this case. In this unit, the eccentricity value of the inner drum is measured.

Note2: The upper drum eccentricity adjustment tool is assembled for use as shown in the figure.

Note3: The following tool is able to use instead of using the upper drum eccentricity adjustment tool (3) and (5).

- Upper drum eccentricity adjustment tool (7): J-6324-030-A




Upper drum eccentricity adjustment tool

Removal

1. Remove the Rotary Head Cleaner Assembly

- (1) Disconnect the connector from connector CN232 on the HN-184 board.
- (2) Cut the harness clumper.
- (3) Remove the harness from the sensor holder.
- (4) Remove the screw, shift the rotary head cleaner assembly in the direction indicated by the arrow A, and remove it from the drum support.




Remove the Rotary Head Cleaner Assembly

2. Remove the Upper Drum Cover

Loosen the two screws and remove the upper drum cover.

Note: These screws cannot be removed because of stoppers.



Remove the Upper Drum Cover

3. Disconnect the Flexible Board


Disconnect the flexible board from connector CN241 on the HN-185 board.

4. Remove the Brush/Slip Ring Assembly

Remove the two screws, then remove the brush/slip ring assembly.

Caution

1. Do not apply excessive force to the brush/slip ring assembly at that time.
2. If the screws remain put into the screw holes of the brush/slip ring assembly, remove them once. When the brush/slip ring assembly is turned upside down, these screws may be dropped into the slip ring cover.




Remove the Brush/Slip Ring Assembly

5. Remove the Upper Drum Assembly

- (1) Rotate the knob manually by about seven turns, then loosen.
- (2) Remove the two screws using a hexagonal wrench driver.
- (3) Raise the upper drum assembly just above, then remove.

Caution

1. Be careful not to damage the tape running surface and the contacting surface (shaded portion in the figure) of the upper drum when removing the upper drum assembly. Also, take care not to damage the lower edge portion of the upper drum.
2. Be sure to put the removed upper drum assembly with the upper surface (on which the height determining plate is installed) down. If not, the edge portion may be damaged.
3. Be careful not to damage the drum support mounting surface and lower drum's upper edge portion after the upper drum assembly was removed.



Remove the Upper Drum Assembly

6. Remove the Inner Drum Assembly


- (1) Insert the hexagonal wrench driver from the screw hole and loosen the screw fully.

Note: The inner drum assembly is fixed with the four fixing screws (C3x12) in the screw holes. These screws cannot be removed because of stoppers.

- (2) Remove the inner drum assembly while inclining it as shown in the figure.

Caution

Be careful not to damage the upper drum contacting surface of the drum support.



Remove the Inner Drum Assembly

Installation**Caution**

The inner drum assembly for repair has an inner drum cover. This cover is provided to protect the rotary heads. Do not remove the inner drum cover until the inner drum assembly has been installed.

7. Cleaning

- (1) Clean the portion below with a cleaning cloth moistened with cleaning fluid.
 - New inner drum assembly mounting surface (shaded portion shown in the figure)
 - Drum support's upper drum mounting surface (shaded portion shown in the figure)
 - Lower drum flanges (shaded portion shown in the figure) and edge portion
 - Lower drum's tape running surface and lead portion (Refer to Section 7-1-4.)

Caution


After cleaning, wipe with a dry cleaning cloth.

- (2) Wipe the portion below with a dry cleaning cloth.
 - Lower drum's contacting points


Caution

Do not apply cleaning fluid to the contacting points.

• Inner Drum Assembly



• Lower Drum



Cleaning

8. Install the Inner Drum Assembly

When installing the inner drum assembly in the unit with an analog playback function, be sure to check the following items.

Before installing the inner drum assembly

- Loosen the knob (a) sufficiently. (Fig. 2)

Caution

Be careful not to drop the knob (a).

- Loosen the screw (b) about 1.5 turns. (Fig. 2)

After installing the inner drum assembly

- Tighten the screw (b) about 1.5 turns.

- (1) Place the hole (A) on the positioning pin side on DR-202 board into the center position of the drum support.

Caution

At this time, be careful not to touch the contacting points and flanges.


- (2) Align the hole (A) on the positioning pin side on DR-202 board with positioning hole (B) on the inner drum cover. (Fig. 1)

- (3) Put the inner drum assembly on the lower drum gently in the slanting direction with care not to touch the drum support. (Fig. 2)


Caution

1. Do not hold the claws of the inner drum cover when installing the inner drum assembly.
2. Be careful not to touch the audio/TC head, peripheral tape guides and drum support when installing the inner drum assembly.
3. Do not turn the inner drum while the inner drum cover is installed.
- (4) Tighten the four screws (C3×12) tentatively and equally while pushing the inner drum downward.
- (5) Press the claws of the inner drum cover in the direction indicated by the arrow and raise the inner drum cover up, then remove it. (Fig. 3)

(Fig.1)




(Fig.2)



• Remove the Inner Drum Cover

(Fig.3)



Install the Inner Drum Assembly


9. Install the Upper Drum Eccentricity Adjustment Tool

- (1) Clean the measuring probe and the inner drum portion shown in the figure (the circumference) with a cleaning cloth moistened with cleaning fluid.

Caution

Do not make dirt adhere to the measuring probe during use. This may damage the inner drum.

- (2) Install the eccentricity adjustment tool in the chassis shown in the figure.



Install the Upper Drum Eccentricity Adjustment Tool

10. Adjust the Inner Drum Eccentricity

- (1) Set the measuring probe of the tool to the inner drum portion shown in the figure.

Caution

Take care that the measuring probe does not touch the rotary heads.

- (2) Rotate the inner drum slowly clockwise.

Note: The inner drum is rotated clockwise for measuring the eccentricity value. When the brush/slip ring is installed, do not rotate the inner drum clockwise.

Confirm that the pointer deviation of the gauge satisfies the specification in one complete turn of the inner drum.

If the specification is not satisfied, repeat steps ① to ③ below until it is satisfied.

- ① Rotate the inner drum slowly clockwise and stop the rotation in the position where the pointer deviation is minimum.
- ② Push the board cover in the position opposite to the measuring probe by 180 degrees toward the direction of the arrow so that the pointer deviation is 1/2 of the maximum value.
- ③ Confirm that the specification is satisfied.

Note: When the pointer does not move even if the board cover is pushed by finger, tighten the four screws fixing the inner drum a little loosely. When the pointer moves immediately, tighten the screws a little firmly.

- (3) Tighten the four screws gradually in the order indicated in the board cover.

Tightening torque: $39.2 \times 10^{-2} \text{ N} \cdot \text{m}$
(4 kgf·cm)

- (4) Confirm that the pointer deviation of the gauge satisfies the specification.


If the specification is not satisfied, loosen the four screws once. Then perform steps ① to ③ above.

- (5) Tighten the four screws gradually in the order indicated in the board cover.

Tightening torque: $78.4 \times 10^{-2} \text{ N} \cdot \text{m}$
(8 kgf·cm)

- (6) Confirm again that the pointer deviation of the gauge satisfies the specification.

11. Remove the Upper Drum Eccentricity Adjustment Tool




Adjust the Inner Drum Eccentricity

12. Cleaning

Clean the lower surface (shaded portion in the figure) of the height determining plate, the upper surface of the drum support (shaded portion in the figure), and the upper drum contacting surface with a cleaning cloth moistened with cleaning fluid.

Caution

After cleaning, wipe with a dry cleaning cloth.



13. Install the Upper Drum Assembly

- (1) Install the upper drum assembly slowly so that the leaf spring is put into the hole of the height determining plate.


Caution

Take care that the tape running surface and the contacting surface (shaded portion in the figure) of the upper drum does not strike against the drum support. Also, be careful not to damage the lower edge portion of the upper drum.

- (2) Tighten the two screws each by three turns.
- (3) Tighten the knob. At that time, confirm that the portion B of the upper drum assembly somewhat rises to the surface.
- (4) Tighten the two screws alternately and gradually.

Tightening torque: $78.4 \times 10^{-2} \text{ N}\cdot\text{m}$
(8 kgf·cm)

- (5) Confirm that there is no clearance between the drum support and the upper drum assembly (A portion in the figure, both of left and right sides) as visual.




Install the Upper Drum Assembly

14. Cleaning

Wipe the brush/slip ring assembly mounting surface (shaded portion in the figure) and the DR-205 board contacting points with a dry cleaning cloth.

Caution

1. Do not apply cleaning fluid to the contacting points.
2. If the screws remain put into the screw holes of the brush/slip ring assembly, remove them once. When the brush/slip ring assembly is turned upside down, these screws may be dropped into the slip ring cover.



Cleaning

15. Install the Brush/Slip Ring Assembly

- (1) Install the brush/slip ring assembly in the direction shown in the figure.
- (2) Tighten the two screws alternately and gradually while pushing both sides of the flange equally from above.


Tightening torque: $14.7 \times 10^{-2} \text{ N} \cdot \text{m}$
(1.5 kgf·cm)

Caution

Never apply excessive force to the cover.

16. Connect the Flexible Board

Connect the flexible board into connector CN241 on the HN-185 board.



Install the Brush/Slip Ring Assembly

17. Cleaning

Clean the portion below.

- (1) Rotary heads (Refer to Section 7-1-2.)
- (2) Upper drum's tape running surface (Refer to Section 7-1-3.)

Caution


After cleaning, wipe with a dry cleaning cloth.

18. Install the Upper Drum Cover

- (1) Tighten the two screws while pushing the upper drum cover in the direction of the drum support.

Tightening torque: $14.7 \times 10^{-2} \text{ N}\cdot\text{m}$
(1.5 kgf·cm)


- (2) Confirm that the rubber of the upper drum cover does not turn over.
- (3) Confirm that there is no clearance between the upper drum cover and the upper drum.



Install the Upper Drum Cover

19. Install the Rotary Head Cleaner Assembly

- (1) Insert the cleaning roller from the clearance between the drum support and CTL head as shown in the figure.
- (2) Align the two pins of the rotary head cleaner assembly with the two holes of the drum support.
- (3) Tighten the screw while moving the rotary head cleaner assembly in the direction indicated by the arrow A.
- (4) Fix the harness to the sensor holder position shown in the figure.
- (5) Connect a connector into connector CN232 on the HN-184 board.
- (6) Bind the rotary head cleaner harness with the harness clumper (or the equivalent).



Install the Rotary Head Cleaner Assembly

Adjustment after Replacement

- 20. Confirm the Tape Running
Refer to Section 8-4-2.
- 21. Confirm the Video Tracking
Refer to Section 8-4-3.
- 22. Confirm the CTL Head Height
Refer to Section 8-4-4.
- 23. Adjust the CTL Head Position
Refer to Section 8-4-5.
- 24. Confirm the Audio/TC Head Height
Refer to Section 8-4-6.
- 25. Adjust the Audio/TC Head Position
Refer to Section 8-4-9.
- 26. Perform the Servo/DT and RF Adjustment
Refer to Section 8-5.
- 27. Perform the Adjustment after Drum Replacement
Refer to Section 8-6.

8-2-2. Brush/Slip Ring Assembly Replacement

Outline

Replacement
1. Remove the Upper Drum Cover
2. Disconnect the Flexible Board (CN241/HN-185 Board)
3. Remove the Brush/Slip Ring Assembly
4. Cleaning (DR-205 Board's Contacting Points and Brush/Slip Ring Assembly Mounting Surface)
5. Install the Brush/Slip Ring Assembly
6. Connect the Flexible Board (CN241/HN-185 Board)
7. Install the Upper Drum Cover
Adjustment after Replacement
8. Perform the Servo/DT Check (Refer to Section 5-2.) (C05: DIGITAL DT CHECK, C06: ANALOG DT CHECK)
9. Perform the RF Check (Refer to Section 5-3.) (C1: RF CHECK)

Note

When the brush or slip ring was worn or damaged, replace the brush/slip ring assembly. It cannot be replaced only brush or slip ring.

Tools


- Torque screwdriver (6 kg·cm) (JB-5251): J-6252-510-A
- Torque screwdriver's bit (+2 mm, l=75 mm): J-6323-420-A
- Cleaning cloth: 3-184-527-01
- Cleaning fluid: 9-919-573-01

Removal

1. Remove the Upper Drum Cover

Loosen the two screws and remove the upper drum cover.

Note: These screws cannot be removed because of stoppers.



Remove the Upper Drum Cover

2. Disconnect the Flexible Board

Disconnect the flexible board from connector CN241 on the HN-185 board.

3. Remove the Brush/Slip Ring Assembly

(1) Remove the two screws, then remove the brush/slip ring assembly.


Caution

Do not apply excessive force to the brush/slip ring assembly at that time.

(2) Turn the brush/slip ring assembly upside down, and take out the two screws.

Caution

Be careful not to drop the screw into the cover.



Remove the Brush/Slip Ring Assembly


Installation

4. Cleaning

Wipe the brush/slip ring assembly mounting surface (shaded portion in the figure) and the DR-205 board contacting points with a dry cleaning cloth.

Caution

Do not apply cleaning fluid to the contacting points.



5. Install the Brush/Slip Ring Assembly

- (1) Insert the two screws taken out in (2) of step 3 into the screw holes of the brush/slip ring assembly.
- (2) Install the brush/slip ring assembly in the direction shown in the figure.
- (3) Tighten the two screws alternately and gradually while pushing both sides of the flange equally from above.


Tightening torque: $14.7 \times 10^{-2} \text{ N}\cdot\text{m}$
(1.5 kgf·cm)

Caution

Never apply excessive force to the cover.

6. Connect the Flexible Board

Connect the flexible board into connector CN241 on the HN-185 board.




7. Install the Upper Drum Cover

- (1) Tighten the two screws while pushing the upper drum cover in the direction of the drum support.

Tightening torque: $14.7 \times 10^{-2} \text{ N}\cdot\text{m}$
(1.5 kgf·cm)

- (2) Confirm that the rubber of the upper drum cover does not turn over.
- (3) Confirm that there is no clearance between the upper drum cover and the upper drum.



Adjustment after Replacement

8. Perform the Servo/DT Check

Refer to Section 5-2.
(C05: DIGITAL DT CHECK,
C06: ANALOG DT CHECK)

9. Perform the RF Check

Refer to Section 5-2.
(C1: RF CHECK)

8-2-3. Drum Assembly Replacement

Outline

Replacement
1. Remove the Rotary Head Cleaner Assembly
2. Remove the Upper Drum Cover
3. Disconnect the Flexible Board (CN241/NH-185 Board)
4. Remove the Drum Assembly
5. Cleaning (Drum Assembly Mounting Surfaces and Chassis Mounting Surfaces)
6. Install the Drum Assembly
7. Connect the Flexible Board (CN241/HN-185 Board)
8. Cleaning (Rotary Heads, Upper Drum's Tape Running Surface, and Lower Drum's Tape Running Surface)
9. Install the Upper Drum Cover
10. Install the Rotary Head Cleaner Assembly
Adjustment after Replacement
11. Confirm the Drum Motor Operation (Refer to Section 5-2.) (C015 : DRUM MOTOR)
12. Adjust the Tape Running (Refer to Section 8-4-2.)
13. Adjust the Video Tracking (Refer to Section 8-4-3.)
14. Adjust the CTL Head Height (Refer to Section 8-4-4.)
15. Adjust the CTL Head Position (Refer to Section 8-4-5.)
16. Adjust the Audio/TC Head Height (Refer to Section 8-4-6.)
17. Adjust the Audio/TC Head Azimuth (Refer to Section 8-4-7.)
18. Confirm the Audio/TC Head Head-to-Tape Contact (Refer to Section 8-4-8.)
19. Adjust the Audio/TC Head Position (Refer to Section 8-4-9.)
20. Confirm the Audio Level in REV Mode (Refer to Section 8-4-10.)
21. Confirm the Tape Running (Refer to Section 8-4-2.)
22. Perform the Servo/DT and RF Adjustment (Refer to Section 8-5.)
23. Perform the Adjustment after Drum Replacement (Refer to Section 8-6.)

Note

Be careful not to damage the audio/TC head and peripheral tape guides when removing or installing the drum assembly.

Basic knowledge

For except the periodic replacement time, replace the drum assembly in the following cases.

- The upper or lower drum's tape running surface is damaged and cannot be repaired.
- A correct RF signal waveform cannot be obtained due to the worn upper or lower drum even if the tracking adjustment is performed.
- The VTR performance deteriorates because of the noise or jitter caused by the bearing life.


Tools

- | | |
|--|--------------|
| • Hexagonal wrench driver (2.5 mm): | 7-700-766-04 |
| • Torque screwdriver (6 kg•cm)(JB-5251): | J-6252-510-A |
| • Torque screwdriver (12 kg•cm)(JB-5252): | J-6252-520-A |
| • Torque screwdriver's hexagonal bit (d=2.5 mm, l=120 mm): | J-6251-090-A |
| • Cleaning cloth: | 3-184-527-01 |
| • Cleaning fluid: | 9-919-573-01 |

Removal

1. Remove the Rotary Head Cleaner Assembly

- (1) Disconnect the connector from connector CN232 on the HN-184 board.
- (2) Cut the harness clumper.
- (3) Remove the harness from the sensor holder.
- (4) Remove the screw, shift the rotary head cleaner assembly in the direction indicated by the arrow A, and remove it from the drum support.




Remove the Rotary Head Cleaner Assembly

2. Remove the Upper Drum Cover

Loosen the two screws and remove the upper drum cover.

Note: These screws cannot be removed because of stoppers.



Remove the Upper Drum Cover

3. Disconnect the Flexible Board

Disconnect the flexible board from connector CN241 on the HN-185 board.

4. Remove the Drum Assembly

- (1) Disconnect the connector on the harness rail.

Caution

Only the unit applied to the following serial number:

- DVW-A500P (EK): S/N 12036 and higher
- DVW-A510P (EK): S/N 10721 and higher
- DVW-CA510P (EK): S/N 10051 and higher
- DVW-A500 (UC): S/N 11288 and higher
- DVW-A510 (UC): S/N 10257 and higher
- DVW-CA510 (UC): S/N 10010 and higher

- (2) Rotate the inner drum assembly manually counterclockwise and align mark "⇒" indicated on the board cover with the screw hole of the upper drum assembly.



Note: The drum assembly is fixed to the chassis with the three fixing screws (C3×8) in the screw hole. The screw hole of the upper drum assembly coincides with the fixing screw position by aligning it with mark "⇒" on the board cover.

- (3) Loosen the screw fully using a hexagonal wrench driver.

Note: These screws cannot be removed because of stoppers.

- (4) Loosen other two screws fully in the same way as in steps (2) and (3).

• When removing the connector of the demagnetization head assembly
(Only DVW-A500P/A510P/CA510P/A500/A510/CA510)



- (5) Raise the drum assembly just above and remove the harness from the harness holder at the bottom.

Caution

Be careful not to raise the drum assembly by holding the brush/slip ring assembly.

- (6) Disconnect three connectors CN602, CN610, and CN612 in the state of step (5). The drum assembly can then be removed.

Caution

Be careful not to touch the audio/TC head and peripheral tape guides when removing the drum assembly.


- (7) Loosen the hexagonal screw, then remove the demagnetization head assembly from the drum assembly.

Caution


Only the unit applied to the following serial number:

- DVW-A500P (EK): S/N 12036 and higher
- DVW-A510P (EK): S/N 10721 and higher
- DVW-CA510P (EK): S/N 10051 and higher
- DVW-A500 (UC): S/N 11288 and higher
- DVW-A510 (UC): S/N 10257 and higher
- DVW-CA510 (UC): S/N 10010 and higher

• Disconnect the Connectors



• When removing the demagnetization head assembly
(Only DVW-A500P/A510P/CA510P/A500/A510/CA510)



Remove the Drum Assembly


Installation

5. Cleaning

Clean the new drum assembly mounting surfaces and chassis mounting surfaces with a cleaning cloth moistened with cleaning fluid.

Caution

After cleaning, wipe with a dry cleaning cloth.



Cleaning

6. Install the Drum Assembly

- (1) Confirm that there is no clearance between the spacer and the washer. (If clearance exists, tighten the hexagonal screw and the spacer.)

Then insert the demagnetization head into the hole of the drum support, and tighten the hexagonal screw.

Tightening torque: $39.2 \times 10 \text{ N} \cdot \text{m}$
(4 kgf·cm)

Caution

Only the unit applied to the following serial number:

- DVW-A500P (EK): S/N 12036 and higher
- DVW-A510P (EK): S/N 10721 and higher
- DVW-CA510P (EK): S/N 10051 and higher
- DVW-A500 (UC): S/N 11288 and higher
- DVW-A510 (UC): S/N 10257 and higher
- DVW-CA510 (UC): S/N 10010 and higher


- (2) Hold the drum assembly as shown in the figure and connect the three connectors disconnected in (6) of step 4.

Caution


1. Hold the height determining plate and the drum support at that time. Be careful not to hold the upper drum and the brush/slip ring assembly.
2. Pay attention to the direction of the connectors.

- (3) Fix the harness by a harness holder as shown in the figure.


• When installing the demagnetization head assembly (Only DVW-A500P/A510P/CA510P/A500/A510/CA510)




• When connecting the Connectors



• How to fix the Harness



• How to hold the Drum Assembly



- (4) Align the two positioning holes of the drum assembly with the two positioning pin of the chassis while passing the harness under the chassis.

Caution

1. Be careful not to touch the audio/TC head and tape guide at that time.
2. Be careful not to put the harness between the lower drum and the chassis.

- (5) Confirm that the drum assembly is firmly inserted into the positioning pins.
- (6) Rotate the inner drum assembly manually counterclockwise and align the upper drum assembly holes with the fixing screw positions.
- (7) Tighten the screw tentatively.
- (8) Tighten other two screws tentatively in the same way as in steps (6) and (7).
- (9) Tighten the three screws each by two or three turns in the order of counterclockwise.

Tightening torque: $78.4 \times 10^{-2} \text{ N} \cdot \text{m}$
(8 kgf·cm)

- (10) Connect the connector of the demagnetization head assembly into the connector on the harness rail.

Caution

Only the unit applied to the following serial number:

- DVW-A500P (EK): S/N 12036 and higher
- DVW-A510P (EK): S/N 10721 and higher
- DVW-CA510P (EK): S/N 10051 and higher
- DVW-A500 (UC): S/N 11288 and higher
- DVW-A510 (UC): S/N 10257 and higher
- DVW-CA510 (UC): S/N 10010 and higher

7. Connect the Flexible Board

Connect the flexible board into connector CN241 on the HN-185 board, then lock.

8. Cleaning


Clean the portion below.

- (1) Rotary heads (Refer to Section 7-1-2.)
- (2) Upper drum's tape running surface (Refer to Section 7-1-3.)
- (3) Lower drum's tape running surface (Refer to Section 7-1-4.)


Caution

After cleaning, wipe with a dry cleaning cloth.

• When installing the Drum Assembly on the Chassis



• When installing the connector of the demagnetization head assembly (Only DVW-A500P/A510P/CA510P/A500/A510/CA510)




Install the Drum Assembly

9. Install the Upper Drum Cover

- (1) Tighten the two screws while pushing the upper drum cover in the direction of the drum support.

Tightening torque: $14.7 \times 10^{-2} \text{ N}\cdot\text{m}$
(1.5 kgf·cm)


- (2) Confirm that the rubber of the upper drum cover does not turn over.
- (3) Confirm that there is no clearance between the upper drum cover and the upper drum.



Install the Upper Drum Cover

10. Install the Rotary Head Cleaner Assembly

- (1) Insert the cleaning roller from the clearance between the drum support and CTL head as shown in the figure.
- (2) Align the two pins of the rotary head cleaner assembly with the two holes of the drum support.
- (3) Tighten the screw while moving the rotary head cleaner assembly in the direction indicated by the arrow A.
- (4) Fix the harness to the sensor holder position shown in the figure.
- (5) Connect the connector into connector CN232 on the HN-184 board.
- (6) Bind the rotary head cleaner harness with the harness clumper (or the equivalent).



Install the Rotary Head Cleaner Assembly

Adjustment after Replacement**11. Confirm the Drum Motor Operation**

Refer to Section 5-2. (C015 : DRUM MOTOR)

12. Adjust the Tape Running

Refer to Section 8-4-2.

13. Adjust the Video Tracking

Refer to Section 8-4-3.

14. Adjust the CTL Head Height

Refer to Section 8-4-4.

15. Adjust the CTL Head Position

Refer to Section 8-4-5.

16. Adjust the Audio/TC Head Height

Refer to Section 8-4-6.

17. Adjust the Audio/TC Head Azimuth

Refer to Section 8-4-7.

18. Confirm the Audio/TC Head Head-to-Tape Contact

Refer to Section 8-4-8.

19. Adjust the Audio/TC Head Position

Refer to Section 8-4-9.

20. Confirm the Audio Level in REV Mode

Refer to Section 8-4-10.

21. Confirm the Tape Running

Refer to Section 8-4-2.

22. Perform the Servo/DT and RF Adjustment

Refer to Section 8-5.

23. Perform the Adjustment after Drum Replacement

Refer to Section 8-6.

8-2-4. Cleaning Roller and Rotary Head Cleaner Assembly Replacement

Outline

Replacement
1. Remove the Harness (CN232/HN-184 Board)
2. Remove the Rotary Head Cleaner Assembly
3. Replace the Cleaning Roller
4. Install the Rotary Head Cleaner Assembly
5. Adjust the Cleaning Roller Position
6. Install the Harness (CN232/HN-184 Board)
Adjustment after Replacement
7. Confirm the Cleaning Solenoid Operation (Refer to Section 5-2.) (C023: CLEANING ROLLER)

Note


When the cleaning roller is replaced, it is recommended to replace the CR spacer at the same time.

- CR spacer : 3-182-765-02

Removal

- 1. Remove the Harness**
 - (1) Disconnect the connector from connector CN232 on the HN-184 board.
 - (2) Cut the harness clamber.
 - (3) Remove the harness from the sensor holder.
- 2. Remove the Rotary Head Cleaner Assembly**

Remove the screw, shift the rotary head cleaner assembly in the direction indicated by the arrow A, and remove it from the drum support.




Remove/Install the Rotary Head Cleaner Assembly

- 3. Replace the Cleaning Roller**
 - (1) Remove the CR spacer, and remove the cleaning roller.
 - (2) Pass a new cleaning roller through the shaft as shown in the figure. Then fix the cleaning roller by the CR spacer.
 - (3) Move the cleaning roller in the vertical direction.
At this time, confirm that there is no vertical play.

Installation

- 4. Install the Rotary Head Cleaner Assembly**
 - (1) Insert the cleaning roller from the clearance between the drum support and CTL head.
 - (2) Align the two pins of the rotary head cleaner assembly with the two holes of the drum support.
 - (3) Tighten the screw while moving the rotary head cleaner assembly in the direction indicated by the arrow B.
 - (4) Write the time of replacement of the cleaning roller on the hours label pasted on the rotating head cleaner assembly.



Replace the Cleaning Roller

5. Adjust the Cleaning Roller Position


- (1) Check that the cleaning roller does not come in contact with the inner drum as visual. (Spec.1)

If the cleaning roller comes in contact with the inner drum, bend the portion B of the video head cleaner sub assembly in the direction of the arrow C.

- (2) Press the iron core in the direction of the arrow. At that time, check that clearance exists between the cleaner lever and the video head cleaner sub assembly. (Spec.2)

If clearance does not exist, bend the portion B of the video head cleaner sub assembly in the direction of the arrow D.

- (3) Repeat steps (1) through (2) above until the specifications 1 through 2 are satisfied.



Cleaning Roller Position Adjustment


6. Install the harness

- (1) Fix the harness to the sensor holder position shown in the figure.
- (2) Connect a connector into connector CN232 on the HN-184 board.
- (3) Bind the rotary head cleaner harness with the harness clumper (or the equivalent).

Adjustment after Replacement**7. Confirm the Cleaning Solenoid Operation**

Refer to Section 5-2.

(C023: CLEANING ROLLER)



Install the Harness

8-2-5. AT Head Cleaner Replacement

Outline

Replacement
1. Remove the CL Arm Assembly
2. Install the CL Arm Assembly
3. Confirm the CL Arm Assembly Operation

Note

- When the cleaning roller becomes dirty or was damaged, replace the CL arm assembly.
- Do not use the stop washer fixing the CL arm assembly again after it was removed once.
- Adjustment after the CL arm assembly replacement is not required. However, confirm the CL arm assembly operation.

Removal

1. Remove the CL Arm Assembly

- (1) Turn the M gear of the gear box assembly manually and move the CL arm assembly to the position shown in the figure.

Note: Move the CL arm assembly to the front of the HN-185 board. If not, the CL arm assembly cannot be removed because the stop washer is hidden by other parts.

- (2) Remove the stop washer at the top of the CL arm.
- (3) Remove the CL arm assembly from the threading ring.

Caution

Do not remove the spring at the bottom of the CL arm from the shaft.

Installation


2. Install the CL Arm Assembly

- (1) Pass a new CL arm assembly through the shaft while hooking the spring as shown in the figure.

Caution

Insert the short-end spring into the groove of the threading ring and the long-end spring into the hole of the CL arm assembly.

- (2) Fix the CL arm assembly by the stop washer.




3. Confirm the CL Arm Assembly Operation

(1) Turn the M gear of the gear box assembly manually and confirm the items below while repeating the threading and unthreading.

- The CL arm assembly moves along the CL guide rail.
- The cleaning roller cleans the audio/TC head.
- A clearance exists between the CL arm assembly and AT shield case while the audio/TC head is cleaned.

(2) Turn the power on and confirm that the CL arm assembly smoothly operates while repeating the threading and unthreading.



Confirm the CL Arm Assembly Operation

8-2-7. Pinch Roller Replacement

Outline

Replacement
1. Remove the Pinch Arm Assembly
2. Install the Pinch Arm Assembly
3. Adjust the Pinch Arm Assembly Vertical Play
4. Cleaning (Pinch Roller Surface)
Adjustment after Replacement
5. Confirm the Tape Running (Refer to Section 8-4-2.)
6. Confirm the Audio/TC Head Height (Refer to Section 8-4-6.)
7. Confirm the Audio/TC Head Azimuth (Refer to Section 8-4-7.)

Note

- When the pinch roller was damaged or worn, replace the pinch roller assembly.
- Do not use the stop washer fixing the pinch arm assembly again after it was removed once.

Tools

- Thickness gauge: 9-911-053-00
- Cleaning cloth: 3-184-527-01
- Cleaning fluid: 9-919-573-01

Removal

1. Remove the Pinch Arm Assembly

- (1) Remove the stop washer at the top of the pinch arm.

Caution

If a poly-slider washer is inserted between the pinch arm assembly and the stop washer, remove it. This poly-slider washer is used for vertical play adjustment.

- (2) Remove the pinch arm assembly from the threading ring.

Caution

Do not remove the poly-slider washer and spring at the bottom of the pinch arm assembly from the shaft.

Installation


2. Install the Pinch Arm Assembly

- (1) Pass a new pinch arm assembly through the shaft while hooking the spring as shown in the figure.

Caution

Insert the short-end spring into the groove of the threading ring and hook the long-end spring to the pin of the pinch arm assembly.

- (2) Fix the pinch arm assembly by the stop washer.
- (3) Push the pinch arm assembly manually in the direction of the drum, then release. At that time, confirm that the pinch arm assembly smoothly returns to the former position.




Remove/Install the Pinch Arm Assembly

3. **Adjust the Pinch Arm Assembly Vertical Play**
Move the Pinch Arm Assembly in the vertical direction.
At this time, confirm that the vertical play satisfies the specification.

If the specification is not satisfied, perform the adjustment below.

- ① Remove the stop washer.
- ② Install or remove the poly-slider washer at the upper of the Pinch Arm.
- ③ Fix the pinch arm assembly by the stop washer, confirm again that the specification is met.

4. **Cleaning**
Clean the pinch roller surface with a cleaning cloth moistened with cleaning fluid.



Adjust the Pinch Arm Assembly Vertical Play

Adjustment after Replacement

5. **Confirm the Tape Running**
Refer to Section 8-4-2.
6. **Confirm the Audio/TC Head Height**
Refer to Section 8-4-6.
7. **Confirm the Audio/TC Head Azimuth**
Refer to Section 8-4-7.

8-2-8. Audio/TC Head Replacement

Outline


Replacement	
1. Remove the CL Guide Rail	
2. Disconnect the Connector	
3. Remove the Audio/TC Head Assembly	
4. Remove the Audio/TC Head	
5. Install the Audio/TC Head	
6. Install the Audio/TC Head Assembly	
7. Connect the Connector	
8. Install the CL Guide Rail	
9. Cleaning (Audio/TC Head Surface)	
Adjustment after Replacement	
10. Adjust the Audio/TC Head Zenith (Refer to Section 8-4-1.)	
11. Adjust the Tape Running (Refer to Section 8-4-2.)	
12. Adjust the Audio/TC Head Height (Refer to Section 8-4-6.)	
13. Adjust the Audio/TC Head Azimuth (Refer to Section 8-4-7.)	
14. Adjust the Audio/TC Head Head-to-Tape Contact (Refer to Section 8-4-8.)	
15. Adjust the Audio/TC Head Position (Refer to Section 8-4-9.)	
16. Confirm the Audio Level in REV Mode (Refer to Section 8-4-10.)	
17. Confirm the Video Tracking (Refer to Section 8-4-3.)	
18. Confirm the Tape Running (Refer to Section 8-4-2.)	
19. Perform the Adjustment after Audio/TC Head Replacement (Refer to Section 8-7.)	

Tools

- Cleaning cloth: 3-184-527-01
- Cleaning fluid: 9-919-573-01
- Torque screwdriver (6 kg•cm) (JB-5251): J-6252-510-A
- Torque screwdriver's bit (+2 mm, l=75 mm): J-6323-420-A

Removal

- 1. Remove the CL Guide Rail**
Remove the two screws, then remove the CL guide rail.




Remove the CL Guide Rail

- 2. Disconnect the Connector**
Disconnect a connector on the audio/TC head board.
- 3. Remove the Audio/TC Head Assembly**
Remove the two screws, then remove the audio/TC head assembly from the unit.

Caution

Be careful not to touch the drum (especially rotary heads). Also, take care not to damage the peripheral tape guides.



Remove the Audio/TC Head Assembly

4. Remove the Audio/TC Head


- (1) Remove the two screws, then remove the audio/TC head and adjustment plate from the AT bracket.
- (2) Remove the AT shield case.

Installation

5. Install the Audio/TC Head

- (1) Put a new head into the AT shield case and align the hole position.
- (2) Align the hole position with the adjustment plate put between the audio/TC head and AT bracket, then tighten the two screws tentatively.
- (3) Tighten the screws after confirming that the specification is satisfied.

Tightening torque: $19.6 \times 10^{-2} \text{ N}\cdot\text{m}$
(2 kg $\cdot$ cm)



Remove/Install the Audio/TC Head

6. Install the Audio/TC Head Assembly

- (1) Align the two longitudinal holes of the Audio/TC head assembly with the two bosses of the chassis.


Caution

1. Be careful not to touch the drum (especially rotary heads). Also, take care not to damage the peripheral tape guides.
2. Be careful not to damage the audio/TC head surface.

- (2) Align the bosses of the chassis with center of the longitudinal holes and tighten the two screws.

7. Connect the Connector

Connect a connector into the audio/TC head board.



Install the Audio/TC Head Assembly

8. Install the CL Guide Rail


Install the CL guide rail with two screws.

9. Cleaning

Clean the audio/TC head surface with a cleaning cloth moistened with cleaning fluid.

Caution

After cleaning, wipe with a dry cleaning cloth.



Install the CL Guide Rail

Adjustment after Replacement

- 10. **Adjust the Audio/TC Head Zenith**
Refer to Section 8-4-1.
- 11. **Adjust the Tape Running**
Refer to Section 8-4-2.
- 12. **Adjust the Audio/TC Head Height**
Refer to Section 8-4-6.
- 13. **Adjust the Audio/TC Head Azimuth**
Refer to Section 8-4-7.
- 14. **Adjust the Audio/TC Head Head-to-Tape Contact**
Refer to Section 8-4-8.
- 15. **Adjust the Audio/TC Head Position**
Refer to Section 8-4-9.
- 16. **Confirm the Audio Level in REV Mode**
Refer to Section 8-4-10.
- 17. **Confirm the Video Tracking**
Refer to Section 8-4-3.
- 18. **Confirm the Tape Running**
Refer to Section 8-4-2.
- 19. **Perform the Adjustment after Audio/TC Head Replacement**
Refer to Section 8-7.

8-2-9. CTL Head Replacement

Outline

Replacement
1. Disconnect the Connector
2. Remove the CTL Head Assembly
3. Remove the CTL Head
4. Install the CTL Head
5. Install the CTL Head Assembly
6. Connect the Connector
7. Cleaning (CTL Head Surface)
Adjustment after Replacement
8. Adjust the Tape Running (Refer to Section 8-4-2.)
9. Adjust the CTL Head Height (Refer to Section 8-4-4.)
10. Adjust the CTL Head Position (Refer to Section 8-4-5.)
11. Confirm the Tape Running (Refer to Section 8-4-2.)
12. Confirm the Audio/TC Position (Refer to Section 8-4-9.)
13. Adjust Drum Phase (Refer to Section 8-5-1.)

Tools

- Cleaning cloth: 3-184-527-01
- Cleaning fluid: 9-919-573-01
- Torque screwdriver (6 kg·cm) (JB-5251): J-6252-510-A
- Torque screwdriver's bit (+2 mm, l=75 mm): J-6323-420-A

Note

The replacement procedures for the CTL head depend on the serial number of the unit.

- ① If the unit applies to the following serial number, replace the CTL head referring to "For the New Component" (page 8-44 to 8-45).
- DVW-A510P (EK) : S/N 10721 and higher
 - DVW-510P (EK) : S/N 10251 and higher
 - DVW-CA510P (EK) : S/N 10051 and higher
 - DVW-A510 (UC) : S/N 10257 and higher
 - DVW-510 (UC) : S/N 10098 and higher
 - DVW-CA510 (UC) : S/N 10010 and higher
- ② If the unit applies to the following serial number, replace the CTL head referring to "For the Old Component" (page 8-46 to 8-48).
- DVW-A510P (EK) : S/N 10001 thru. 10720
 - DVW-510P (EK) : S/N 10001 thru. 10250
 - DVW-CA510P (EK) : S/N 10001 thru. 10050
 - DVW-A510 (UC) : S/N 10001 thru. 10256
 - DVW-510 (UC) : S/N 10001 thru. 10097
 - DVW-CA510 (UC) : S/N 10001 thru. 10009


For the New Component

Removal

1. **Disconnect the Connector**
Disconnect the connector on the CTL head board.
2. **Remove the CTL Head Assembly**
Remove the screw, then remove the CTL head assembly.

Caution

Be careful not to touch the drum (especially rotary heads). Also, take care not to damage the peripheral tape guides.




Remove the CTL Head Assembly

3. **Remove the CTL Head**
(1) Remove the two CTL head fixing screws, then remove the CTL head.

Caution

Never loosen or remove the screws except for the CTL head fixing screws. If these screws are loosened or removed, the zenith of the CTL head will be out of specification.

- (2) Unsolder the connector pin.



Remove the CTL Head

Installation


4. Install the CTL Head

- (1) Solder the connector pin to the CTL head board.
- (2) Tighten the two screws while moving the CTL head in the direction indicated by arrows A and B.

Tightening torque: $19.6 \times 10^{-2} \text{ N}\cdot\text{m}$
(2kg $\cdot$ cm)

Caution

Be careful not to damage the CTL head.



5. Install the CTL Head Assembly

- (1) Confirm that the threading ring is in the unthreading end state.
- (2) Align longitudinal holes A and B of the CTL head assembly with the bosses of the chassis.

Caution

Be careful not to touch the drum (especially rotary heads). Also, take care not to damage the peripheral tape guides.


- (3) Align the boss of the chassis with center of the longitudinal hole A and tighten the screw.

6. Connect the Connector

Connect the connector into the CTL head board.

7. Cleaning

Clean the CTL head surface with a cleaning cloth moistened with cleaning fluid.



Adjustment after Replacement

8. Adjust the Tape Running

Refer to Section 8-4-2.

9. Adjust the CTL Head Height

Refer to Section 8-4-4.

10. Adjust the CTL Head Position

Refer to Section 8-4-5.

11. Confirm the Tape Running

Refer to Section 8-4-2.

12. Confirm the Audio/TC Head Position

Refer to Section 8-4-9.

13. Adjust the Drum Phase


Refer to Section 8-5-1.

For the Old Component**Removal**

- 1. Disconnect the Connector**
Disconnect the connector on the CTL head board.
- 2. Remove the CTL Head Assembly**
Remove the screw, then remove the CTL head assembly.

Caution

Be careful not to touch the drum (especially rotary heads). Also, take care not to damage the peripheral tape guides.


**Remove the CTL Head Assembly****3. Remove the CTL Head**

- (1) Remove the two screws, then remove the CTL head.

Caution

Never loosen or remove the two screws fixing the CTL bracket. If these screws are loosened or removed, the zenith of the CTL head will be out of specification.

- (2) Unsolder the connector pin.

**Remove the CTL Head****Installation****4. Install the CTL Head**


- (1) Solder the connector pin to the CTL head board.
- (2) Tighten the two screws tentatively while moving the CTL head in the direction indicated by arrows A and B.

Caution

Be careful not to damage the CTL head.

- (3) Tighten the screws after confirming that the specification is satisfied.

Tightening torque: $19.6 \times 10^{-2} \text{ N}\cdot\text{m}$
(2kg·cm)

**Install the CTL Head**

5. Install the CTL Head Assembly

- (1) Confirm that the threading ring is in the unthreading end state.
- (2) Align longitudinal holes A and B of the CTL head assembly with the bosses of the chassis.

Caution

Be careful not to touch the drum (especially rotary heads). Also, take care not to damage the peripheral tape guides.

- (3) Align the boss of the chassis with center of the longitudinal hole A and tighten the screw.

6. Connect the Connector


Connect the connector into the CTL head board.

7. Cleaning

Clean the CTL head surface with a cleaning cloth moistened with cleaning fluid.

Caution

After cleaning, wipe with a dry cleaning cloth.



Install the CTL Head Assembly

Adjustment after Replacement

8. Adjust the Tape Running

Refer to Section 8-4-2.

9. Adjust the CTL Head Height

Refer to Section 8-4-4.

10. Adjust the CTL Head Position

Refer to Section 8-4-5.

11. Confirm the Tape Running

Refer to Section 8-4-2.

12. Confirm the Audio/TC Head Position

Refer to Section 8-4-9.

13. Adjust the Drum Phase

Refer to Section 8-5-1.

8-2-10. Capstan Motor Replacement

Outline

Replacement
1. Remove the Rotary Head Cleaner Assembly
2. Open the DR-307/200 Board
3. Remove the Capstan Motor
4. Install the Capstan Motor
5. Close the DR-307/200 Board
6. Install the Rotary Head Cleaner Assembly
7. Cleaning (Capstan Motor Shaft)
Adjustment after Replacement
8. Confirm the Pinch Press Clearance (Refer to Section 8-3-1.)
9. Confirm the Tape Running (Refer to Section 8-4-2.)
10. Confirm the Capstan Motor Operation (Refer to Section 5-2.) (C014 : CAPSTAN MOTOR)
11. Adjust the Capstan FG Duty (Refer to Section 5-7.) (A003 : CAPSTAN FG DUTY)
12. Adjust the Capstan Free Speed (Refer to Section 5-7.) (A010 : CAPSTAN FREE SPEED)
13. Store the Adjustment Data (Refer to Section 5-7.) (A012 : NV-RAM CONTROL)
14. Adjust the Capstan FG Level (Refer to Section 5-7.) (A020 : CAPSTAN FG LEVEL)
15. Store the Adjustment Data (Refer to Section 5-7.) (A023 : NV-RAM CONTROL)

Note

Replace the capstan motor with the left side panel of the unit down.


Tools

- Cleaning cloth: 3-184-527-01
- Cleaning fluid: 9-919-573-01

Removal

- 1. Remove the Rotary Head Cleaner Assembly**
 - (1) Disconnect a connector from connector CN232 on the HN-184 board.
 - (2) Cut the harness clamber.
 - (3) Remove the harness from the sensor holder.
 - (4) Remove the screw, shift the rotary head cleaner assembly in the direction indicated by the arrow A, and remove it from the drum support.


Note: To remove the fixing screws of the capstan motor, remove the rotary head cleaner assembly.



Remove the Rotary Head Cleaner Assembly

- 2. Open the DR-307/200 Board**

Open the DR-307/200 board with the left side panel of the unit down.



Open the DR-307/200 Board

3. Remove the Capstan Motor

- (1) Disconnect the connector on the capstan motor board.
- (2) Remove the two screws while holding the capstan motor by hand.

Caution

Be careful not to drop the capstan motor.



Installation**4. Install the Capstan Motor**

- (1) Pass a new capstan motor through the hole of the chassis in the direction shown in the figure and tighten the two screws.

Caution

Be careful not to damage the capstan motor shaft when passing the capstan motor through the hole of the chassis.


- (2) Connect the connector disconnected in (1) of step 3 to the capstan motor board.

• Upper Side**• Back Side**

Remove/Install the Capstan Motor

5. Close the DR-307/200 Board

Put the two holes on the DR-307/200 board into the two portions A of the PCB holder shown in the figure.



Close the DR-307/200 Board

6. Install the Rotary Head Cleaner Assembly


- (1) Insert the cleaning roller from the clearance between the drum support and CTL head as shown in the figure.
- (2) Align the two pins of the rotary head cleaner assembly with the two holes of the drum support.
- (3) Tighten the screw while moving the rotary head cleaner assembly in the direction indicated by the arrow A.
- (4) Fix the harness to the sensor holder position shown in the figure.
- (5) Connect a connector into connector CN232 on the HN-184 board.
- (6) Bind the rotary head cleaner harness with the harness clumper (or the equivalent).

7. Cleaning

Clean the capstan motor shaft with a cleaning cloth moistened with cleaning fluid.

Caution

After cleaning, wipe with a dry cleaning cloth.



Install the Rotary Head Cleaner Assembly

Adjustment after Replacement

- 8. Confirm the Pinch Press Clearance**
Refer to Section 8-3-1.
- 9. Confirm the Tape Running**
Refer to Section 8-4-2.
- 10. Confirm the Capstan Motor Operation**
Refer to Section 5-2.
(C014 : CAPSTAN MOTOR)
- 11. Adjust the Capstan FG Duty**
Refer to Section 5-7.
(A003 : CAPSTAN FG DUTY)
- 12. Adjust the Capstan Free Speed**
Refer to Section 5-7.
(A010 : CAPSTAN FREE SPEED)
- 13. Store the Adjustment Data**
Refer to Section 5-7.
(A012 : NV-RAM CONTROL)
- 14. Adjust the Capstan FG Level**
Refer to Section 5-7.
(A020 : CAPSTAN FG LEVEL)
- 15. Store the Adjustment Data**
Refer to Section 5-7.
(A023 : NV-RAM CONTROL)


8-2-11. Pinch Solenoid Replacement

Outline

Replacement
1. Disconnect the Connector (CN854/PD-35 Board)
2. Remove the Pinch Press Assembly
3. Remove the PD-35 Board
4. Remove the P Stopper
5. Remove the Pinch Solenoid
6. Install the Pinch Solenoid
7. Install the P Stopper
8. Install the PD-35 Board
9. Install the Pinch Press Assembly
10. Connect the Connector (CN854/PD-35 Board)
Adjustment after Replacement
11. Confirm the Pinch Solenoid Operation (Refer to Section 5-2.) (C020 : PINCH ROLLER)
12. Adjust the Pinch Press Clearance (Refer to Section 8-3-1.)

Removal


1. **Disconnect the Connector**
Disconnect connector CN854 on the PD-35 board.
2. **Remove the Pinch Press Assembly**
Remove the two screws, then remove the pinch press assembly from the unit.




Remove the Pinch Press Assembly

3. Remove the PD-35 Board

- (1) Remove the screw, then remove the PD-35 board from the pinch press assembly.
- (2) Unsolder the three harnesses wired on the PD-35 board.


**Remove the PD-35 Board****4. Remove the P Stopper**

Remove the two screws and washers, then remove the P stopper.

**Remove the P Stopper**

5. Remove the Pinch Solenoid

- (1) Extract the P joint shaft.
- (2) Remove the two screws and washers, then remove the pinch solenoid.




Remove the Pinch Solenoid

Installation

6. Install the Pinch Solenoid


- (1) Install a new solenoid to the P base in the direction shown in the figure.
- (2) Bend the spring in the direction indicated by the arrow and bring it into contact with surface A of the solenoid shown in the figure.
- (3) Put the P limiter into the notch of the solenoid's iron core and pass the P joint shaft through the hole of the iron core in the direction shown in the figure.
- (4) Confirm that the other end of the spring is put on the notch of the P press lever.



Install the Pinch Solenoid

7. Install the P Stopper


- (1) Pass the longitudinal hole of the P stopper through the P joint shaft, then pass the round hole through the shaft of the P press lever.
- (2) Put the washers and tighten the screws.



Install the P Stopper

8. Install the PD-35 Board

- (1) Wire the harnesses to the PD-35 board as shown in the figure, then solder.
- (2) Insert the PD-35 board into the P stopper and tighten the screw.




Install the PD-35 Board

9. Install the Pinch Press Assembly

Align the notch of the pinch press assembly with the center of the pin and tighten the two screws.

10. Connect the Connector

Connect the connector into connector CN854 on the PD-35 board.



Install the Pinch Press Assembly

Adjustment after Replacement

11. Confirm the Pinch Solenoid Operation

Refer to Section 5-2.
(C020 : PINCH ROLLER)

12. Adjust the Pinch Press Clearance

Refer to Section 8-3-1.

8-2-12. Brake Lining Replacement

Outline

Replacement
1. Remove the Reel Table Assembly
2. Remove the Brake Assembly
3. Remove the Brake Lining
4. Install the Brake Lining
5. Install the Brake Assembly
6. Install the Reel Table Assembly
Adjustment after Replacement
7. Confirm the Reel Table Height (Refer to Section 8-3-4.)
8. Confirm the Reel Brake Clearance (Refer to Section 8-3-5.)
9. Confirm the Reel Brake Release Amount (Refer to Section 8-3-6.)

Note

How to replace the brake lining assembly is the same on the supply and take-up sides.

Tools


- L-shaped wrench (1.5 mm): 7-700-736-05
- Cleaning cloth: 3-184-527-01
- Cleaning fluid: 9-919-573-01

Removal

1. Remove the Reel Table Assembly
 - (1) Align one of the two notches at the bottom of the reel table assembly with the groove position of the reel shift plate assembly.
 - (2) Insert the L-shaped wrench into the notch at the bottom of the reel table assembly along the groove of the reel shift plate.
 - (3) Loosen the screw.
 - (4) Align another notch at the bottom of the reel table assembly with the groove position of the reel shift plate assembly.
 - (5) Loosen the screw in the same way as in step (2).
 - (6) Remove the reel table assembly.

Caution

When the reel table assembly is removed, a poly-slider washer may adhere to it. In this case, remove the poly-slider washer from the reel table assembly and return it to the reel motor shaft position. This poly-slider washer is used for reel table height adjustment.



Remove the Reel Table Assembly

2. Remove the Brake Assembly

- (1) Unhook the spring put on the reel shift plate assembly.
- (2) Remove the E ring, then remove the brake assembly.

3. Remove the Brake Lining


- Unhook the spring put on the brake arm block, then remove the brake lining.

Installation**4. Install the Brake Lining**

- (1) Combine a new brake lining with the brake arm block as shown in the figure.
- (2) Hook the spring to the brake arm block.

5. Install the Brake Assembly

- (1) Pass the brake assembly through the shaft of the reel shift plate assembly.
- (2) Hook the spring to the reel shift plate assembly.
- (3) Fix the brake assembly by the E ring.




Remove/Install the Brake Lining

6. Install the Reel Table Assembly

- (1) Clean the reel table assembly along the circumference.
- (2) Release the reel brake in the direction indicated by the arrow and pass the reel table assembly through the reel motor shaft.

Caution

Tighten the two screws after the reel table height adjustment is completed.



Install the Reel Table Assembly

Adjustment after Replacement

7. **Confirm the Reel Table Height**
Refer to Section 8-3-4.
8. **Confirm the Reel Brake Clearance**
Refer to Section 8-3-5.
9. **Confirm the Reel Brake Release Amount**
Refer to Section 8-3-6.

8-2-13. Reel Motor Assembly Replacement

Outline

Replacement
1. Disconnect the Flat Cable (S side: CN321/DR-307, DR-200 Board, T side: CN322/DR-307, DR-200 Board)
2. Remove the Reel Table Assembly
3. Remove the Crank Arm and Slide Shaft Holder
4. Remove the Reel Shift Plate Assembly
5. Disconnect the Flat Cable (S side: CN923/RM Board, T side: CN923/RM Board)
6. Disconnect the Connector (S side: CN926 and 927/RM Board, T side: CN926 and 927/RM Board)
7. Remove the Reel Motor Assembly
8. Cleaning
9. Install the Reel Motor Assembly
10. Connect the Flat Cable (S side: CN923/RM Board, T side: CN923/RM Board)
11. Connect the Connector (S side: CN926 and 927/RM Board, T side: CN926 and 927/RM Board)
12. Install the Slide Shaft
13. Install the Reel Shift Plate Assembly
14. Smear Grease to the Slide Shaft
15. Install the Crank Arm
Adjustment after Replacement
16. Confirm the Reel Motor Shaft Slantness (Refer to Section 8-3-2.)
17. Install the Reel Table Assembly
18. Confirm the Cassette Pillar Height (Refer to Section 8-3-3.)
19. Confirm the Reel Table Height (Refer to Section 8-3-4.)
20. Connect the Flat Cable (S side: CN321/DR-307, DR-200 Board, T side: CN322/DR-307, DR-200 Board)
21. Confirm the Reel Brake Clearance (Refer to Section 8-3-5.)
22. Confirm the Reel Brake Release Amount (Refer to Section 8-3-6.)
23. Confirm the Reel Motor Operation (Refer to Section 5-2.) (C010 : S REEL MOTOR/ C011 : T REEL MOTOR)
24. Adjust the Reel FG Duty (Refer to Section 5-7.) (A001 : S REEL FG DUTY / A002 : T REEL FG DUTY)
25. Adjust the Reel Offset/Friction (Refer to Section 5-7.) (A004 : S REEL OFFSET/FRIC / A005: T REEL OFFSET/FRIC)
26. Adjust the Reel Torque (Refer to Section 5-7.) (A006 : S REEL TORQUE/A007 : T REEL TORQUE)
27. Store the Adjustment Data (Refer to Section 5-7.) (A012 : NV-RAM CONTROL)

Note


The parts consisting reel motor is different between S side and T side. However, how to replace the reel motor assembly is the same for both sides.

Tools

- | | |
|---|--------------|
| • L-shaped wrench (1.5 mm): | 7-700-736-05 |
| • Torque screwdriver (12 kg · cm)(JB-5252): | J-6252-520-A |
| • Torque screwdriver's bit (+ 3 mm, l=90 mm): | J-6323-430-A |
| • Grease (SGL-505): | 7-662-010-04 |
| • Oil: | 7-661-018-18 |
| • Cleaning cloth: | 3-184-527-01 |
| • Cleaning fluid: | 9-919-573-01 |

Removal**1. Disconnect the Flat Cable**

- (1) Place the unit with the left side panel down.
- (2) Disconnect the flat cable connected with DR-307/200 board.
S side: CN321
T side: CN322
- (3) Place the unit to the horizontal position.


**Disconnect the Flat Cable**

2. Remove the Reel Table Assembly

- (1) Align one of the two notches at the bottom of the reel table assembly with the groove of the reel shift plate assembly.
- (2) Insert the L-shaped wrench into the notch of the reel table assembly along the groove of the reel shift plate.
- (3) Loosen the screw.
- (4) Align another notch of the reel table assembly with the groove of the reel shift plate assembly.
- (5) Loosen the screw in the same way as in step (2).
- (6) Remove the reel table assembly.

Caution

When the reel table assembly is removed, a poly-slider washer may adhere to it. In this case, remove that from the reel table assembly and return it to the reel motor shaft position. This poly-slider washer is used for reel table height adjustment.




Remove the Reel Table Assembly

3. Remove the Crank Arm and Slide Shaft Holder

- (1) Place the reel shift plate assembly in the intermediate position of S and L cassette.

Note: The reel shift plate assembly cannot be removed in the S cassette position or T cassette position.

- (2) Remove an E ring and remove the crank arm (B).
- (3) Remove the screw and remove the slide shaft holder.




Remove the Crank Arm and Slide Shaft Holder

4. Remove the Reel Shift Plate Assembly

While pulling out the slide shaft and remove the reel shift plate assembly.

Caution

1. Be careful not to adhere grease smeared the slide shaft to another parts.
2. Be careful not to cause damage to the slide shaft during removal.




Remove the Reel Shift Plate Assembly

5. Disconnect the Flat Cable

Disconnect the flat cable connected with RM board.

6. Disconnect the Connectors

Disconnect the two connectors CN926 and CN927 on the RM board.



Disconnect the Flat Cable and Connectors

7. Remove the Reel Motor Assembly

- (1) Remove the three screws and shield cover, then remove the reel motor assembly.

Caution


1. The shield cover is not required for DVW-500P/510P/500/510.
2. The spacer is inserted between the reel motor and the reel shift plate assembly. Be careful not to lose this spacer since it comes off with the reel motor assembly.

- (2) Remove the poly-slider washer from the reel motor shaft.


Caution

Confirm the quantity of the spacer and be careful not to lose it.

<S Side>



<T Side>



Remove the Reel Motor Assembly

Installation

8. Cleaning

- (1) Clean the reel motor assembly mounting surface and reel shift plate assembly mounting surface with a cleaning cloth moistened with cleaning fluid.
- (2) Clean the shield cover mounting surface with a cleaning cloth moistened with cleaning fluid. (This step is required only DVW-A500P/A510P/A500/A510.)

9. Install the Reel Motor Assembly

- (1) Pass the shield cover through the reel motor shaft and align the pin of the shield cover with the hole of the reel motor. (This step is required only DVW-A500P/A510P/A500/A510.)
- (2) Pass the reel motor assembly through the hole of the reel shift plate as in the direction shown in the figure.
- (3) Tighten the three screws gradually while moving the reel motor assembly in the direction indicated by the arrow A.

Tightening torque: $68.6 \times 10^{-2} \text{ N} \cdot \text{m}$
(7 kgf · cm)

- (4) Pass the poly-slider washer removed in (2) of step 7 through the reel motor shaft.

10. Connect the Flat Cable

- (1) Clean the insertion of the flat cable with a cleaning cloth moistened with cleaning fluid.
- (2) Connect the flat cable disconnected in step 5 into the connector on the RM board, then lock.


Caution

1. Connect the flat cable with its printing surface upside.
2. Be careful not to twist the flat cable when connecting it.


11. Connect the Connector

Connect the two connectors CN926 and CN927 on the RM board.

<S Side>



<T Side>




Install the Reel Motor Assembly

12. Install the Slide Shaft

- (1) Wipe grease from the two holes where the slide shaft to be inserted of the reel shift plate assembly, then clean them.
- (2) Wipe grease from the slide shaft removed in step 4, then clean it.
- (3) Insert the slide shaft to the reel shift plate assembly.

13. Install the Reel Shift Plate Assembly

- (1) Put the slide shaft on the shaft holder while inserting the portion A shown in the figure of the reel shift plate into the slide table.
- (2) Install the slide shaft holder.



Install the Reel Shift Plate Assembly

14. Smear Grease to the Slide Shaft

- (1) Smear grease very lightly to the slide shaft.
- (2) Confirm that the reel shift plate assembly moves smoothly when moving it by hand towards S cassette and L cassette positions.


15. Install the Crank Arm

- (1) Clean the shaft of the crank arm (A), then pour a drop of oil on it.
- (2) Confirm that the reel shift plate assembly is in the intermediate position of S and L cassettes.

Caution

When installing the crank arm, place the reel shift plate assembly in the intermediate position of S and L cassettes for phase adjustment of the gears.

- (3) Install the crank arm (B) to the shaft of the crank arm (A) with an E ring.



Smear Grease and Install the Crank Arm

Adjustment after Replacement

16. Confirm the Reel Motor Shaft Slantness

Refer to Section 8-3-2.

17. Install the Reel Table Assembly

- (1) Clean the circumference of the reel table assembly with a cleaning cloth moistened with cleaning fluid.
- (2) Pass the reel table assembly through the reel motor shaft while moving the reel brake in the direction indicated by the arrow.

Caution

Tighten two fixing screws after the adjustment of reel table height.

18. Confirm the Cassette Pillar Height


Refer to Section 8-3-3.

19. Confirm the Reel Table Height


Refer to Section 8-3-4.

20. Connect the Flat Cable

- (1) Place the unit with the left side panel down.
- (2) Connect the flat cable into the connector on the DR-307/200 board.
S side: CN321
T side: CN322
- (3) Place the unit to the horizontal position.



Install the Reel Table Assembly



Connect the Flat Cable

21. Confirm the Reel Brake Clearance

Refer to Section 8-3-5.

22. Confirm the Reel Brake Release Amount

Refer to Section 8-3-6.

23. Confirm the Reel Motor Operation

Refer to Section 5-2. (C010 : S REEL MOTOR/ C011 : T REEL MOTOR)

24. Adjust the Reel FG Duty

Refer to Section 5-7. (A001 : S REEL FG DUTY / A002 : T REEL FG DUTY)

25. Adjust the Reel Offset/Friction

Refer to Section 5-7. (A004 : S REEL OFFSET/FRIC / A005: T REEL OFFSET/FRIC)

26. Adjust the Reel Torque

Refer to Section 5-7. (A006 : S REEL TORQUE/A007 : T REEL TORQUE)

27. Store the Adjustment Data

Refer to Section 5-7. (A012 : NV-RAM CONTROL)

8-2-14. Fan Motor Replacement

Outline

Replacement

1. Disconnect the Connectors (CN150/MB-441 Board, Switching Regulator)
2. Remove the Fan Motor
3. Install the Fan Motor
4. Connect the Connectors (CN150/MB-441 Board, Switching Regulator)

Note

Adjustment after the fan motor replacement is not required.

Removal


1. **Disconnect the Connectors**
Disconnect the connectors of the switching regulator and connector CN150 on the MB-441 board.
2. **Remove the Fan Motor**
Remove the screws, then remove the fan motor.

Installation

3. **Install the Fan Motor**
Install a new fan motor with screws.

Caution

1. Install the fan motor in position send the air out.
2. The fan motors on the switching regulator side and connector panel differ in the type and number of fixing screws.
 - Fan motor on switching regulator side: PSW4x30 (4 pcs)
 - Fan motor on connector panel: BVTT3x30 (2 pcs)
4. **Connect the Connectosrs**
Connect the connectors into connector CN150 on the MB-441 board and the switching regulator.



Remove/Install the Fan Motor

8-2-15. Filter Replacement

Outline

Replacement
1. Remove the Cap
2. Replace the Filter
3. Install the Cap

Note

Adjustment after the filter replacement is not required.

Replacement

1. Remove the Cap

Turn the cap counterclockwise and remove it.

2. Replace the Filter


Replace the dirty filter with a new one.

Caution

Be careful not to lose the washer, if it is inserted under the filter.

3. Install the Cap






Turn the cap clockwise until it is clicked.



Remove/Install the Filter

8-3. MECHANICAL ADJUSTMENT

Index

Adjustment	Specification	Page
Pinch Press Clearance Adjustment	 Spec.: $A = 0.6$ to 0.8 mm	8-73
Reel Motor Shaft Slantness Adjustment	 Spec. 1: (L cassette position) $A \leq 0.03$ mm Spec. 2: (S cassette position) $A \leq 0.1$ mm	8-75
Cassette Pillar Height Adjustment	 Spec.: $A =$ No clearance	8-77
Reel Table Height Adjustment	 Spec.: The * marked portion of the gauge slide over the flange of the reel table. The ** marked portion of the gauge does not slide over.	8-79
Reel Brake Clearance Check	 Spec.: $A =$ Clearance exists. Spec.: $A =$ Clearance exists.	8-83
Reel Brake Release Amount Adjustment	Spec. 1: The brake lining doesn't touch a reel table while reel table rotating.	8-85

8-3-1. Pinch Press Clearance Adjustment

Note

- Be sure to check the clearance during pinch press when the pinch press assembly is removed.

Tool

- Wire clearance check gauge set: J-6152-450-A

Check


1. Put the Pinch Solenoid into the Energized State

- (1) Turn the M gear of the gear box assembly manually, and put the unit into the threading end mode.
- (2) Press the iron core of the pinch solenoid in the direction of the fully energized state.

2. Check the Pinch Press Clearance

Check that the clearance between the pinch limiter and pinch press lever satisfies the specification.

If the specification is not satisfied, perform steps 3 and later.



Pinch Press Clearance Check

Adjustment

3. Loosen Screws

Loosen the two screws fixing the pinch press assembly by 1/2 to one turn.

4. Adjust the Pinch Press Assembly Position


Put the pinch solenoid into the energized state, then insert the tip of a 3 mm flat-blade screwdriver into the notch of the pinch press assembly and adjust the pinch press assembly position so that the specification is satisfied.

5. Tighten Screws

Tighten the two screws loosened in step 3.

6. Recheck the Pinch Press Clearance

Refer to steps 1 and 2.



Pinch Press Clearance Adjustment

8-3-2. Reel Motor Shaft Slantness Adjustment

Notes

- Be sure to check the slantness of the reel motor shaft when the reel motor assembly is replaced or when the reel shift plate assembly is removed.
- Perform the reel motor shaft slantness adjustment correctly.
If this adjustment is not performed correctly, a reel hub touches the case in a cassette tape, a noise occurs, and the tape does not run correctly. This may damage the tape.


Tools

- Cassette reference plate (L)(MW-088): J-6320-880-A
- Reel motor shaft slantness check tool (MW-087): J-6320-870-A
- Thickness gauge: 9-911-053-00
- Torque screwdriver (12 kg•cm) (JB-5252): J-6252-520-A
- Torque screwdriver's bit (+3 mm, l=50 mm): J-6323-430-A

Check

- 1. Install the Cassette Reference Plate (L)**
Place the cassette reference plate (L) in the direction shown in the figure, then place it on two cassette supports.
- 2. Place the Reel Shift Plate Assembly in the L Cassette Position**
Rotate the drive gear counterclockwise as far as it will go.
- 3. Check the Slantness in the L Cassette Position**
 - (1) Press the check tool against the reel motor shaft from the directions indicated by the arrow.
 - (2) Check that the clearance between the reel motor shaft and tool satisfies specification 1.

If the specification is not satisfied, perform steps 6 through 10.



Reel Motor Shaft Slantness Check (L)


4. Place the Reel Shift Plate Assembly in the S Cassette Position

Rotate the drive gear clockwise as far as it will go.

5. Check the Slantness in the S Cassette Position

- (1) Press the check tool against the reel motor shaft from the directions indicated by the arrow.
- (2) Check that the clearance between the reel motor shaft and tool satisfies specification 2.

If the specification is not satisfied, perform steps 6 and later.



Reel Motor Shaft Slantness Check (S)

Adjustment

6. Loosen Screws

Loosen the three screws fixing the reel motor by one to two turns.

7. Bend Spacer

Bend the adjustment spacer as shown in the figure.

8. Insert Spacer

Insert the adjustment spacer into the square hole on the upper surface of the reel shift plate assembly with tweezers.


9. Tighten Screws

Gradually tighten the three screws loosened in step 6.

Tightening torque: $68.6 \times 10^{-2} \text{ N} \cdot \text{m}$ (7 kgf·cm)

10. Recheck the Reel Motor Shaft Slantness

Refer to steps 2 through 5.



Reel Motor Shaft Slantness Adjustment

8-3-3. Cassette Pillar Height Adjustment (L Cassette)**Note**

- Be sure to check the height of the cassette pillars when the reel shift plate assembly is removed.

Tools

- Cassette reference plate (L)(MW-088): J-6320-880-A
- Adjustment mirror (circular): J-6080-029-A
- L-shaped wrench (1.5 mm): 7-700-736-05

Check**1. Install the Cassette Reference Plate (L)**

Place the cassette reference plate (L) in the direction shown in the figure, then place it on two cassette supports.

2. Place the Reel Shift Plate Assembly in the Intermediate Position of S and L Cassette

- (1) Rotate the drive gear and place the reel shift plate assembly in the intermediate position of S and L cassettes.

Note: The reel shift plate assembly should be moved to the position where the cassette pillars do not appear from the hole of the reference plate.


- (2) Check that the S and T cassette pillars are positioned under the reference plate.

3. Check the Cassette Pillar Height

Push the three positions (a), (b), and (c) of the cassette reference plate (L) lightly toward the chassis and make sure that the clearance between the shaft cap and cassette reference plate satisfies the specification.

If the specification is not satisfied, perform steps 4 through 6.

DVW-A500 (UC)	: S/N 15993 and Higher
DVW-A500P (CE)	: S/N 17638 and Higher
DVW-500 (UC)	: S/N 12400 and Higher
DVW-500P (CE)	: S/N 14881 and Higher
DVW-A510 (UC)	: S/N 11154 and Higher
DVW-A510P (CE)	: S/N 13276 and Higher
DVW-510 (UC)	: S/N 10638 and Higher
DVW-510P (CE)	: S/N 11065 and Higher

**Cassette Pillar Height Check**

Adjustment

4. Loosen Fixing Screw

Loosen the fixing screw of the T cassette pillar by one or two turns with L-shaped wrench.

5. Adjust the Cassette Pillar Height

Turn and adjust the shaft cap until the clearance is met the specification, then tighten the fixing screw.


Tightening torque: 0.6 to 0.7 N·m (6 to 7 kgf·cm)

6. Recheck the Cassette Pillar Height

Check that the height of the S and T cassette pillars satisfies the specification.

Caution

Shift the tightening position of the fixing screw when performing readjustment with the specification not satisfied. (Do not tighten the screw in the same position as previous.)



Cassette Pillar Height Adjustment

8-3-3. Cassette Pillar Height Adjustment (S Cassette)

Note

- Be sure to check the height of the cassette pillars when the reel shift plate assembly is removed.

Tools

- Cassette reference plate (L)(MW-088): J-6320-880-A
- Adjustment mirror (circular): J-6080-029-A
- L-shaped wrench (1.5 mm): 7-700-736-05

Check

1. Install the Cassette Reference Plate (L)

Place the cassette reference plate (L) in the direction shown in the figure, then place it on two cassette supports.

2. Place the Reel Shift Plate Assembly in the Intermediate Position of S and L Cassette

- (1) Rotate the drive gear and place the reel shift plate assembly in the intermediate position of S and L cassettes.

Note: The reel shift plate assembly should be moved to the position where the cassette pillars do not appear from the hole of the reference plate.

- (2) Check that the S and T cassette pillars are positioned under the reference plate.


3. Check the Cassette Pillar Height

- (1) Turn the reference plate over and place it on the cassette pillars.

Note: The reference plate should be turned over because it has a concave portion at the back and cannot be adjusted correctly.

- (2) Check with an adjustment mirror that there are no clearances between the S and T cassette pillars and the reference plate.

If the specification is not satisfied, perform steps 4 through 6.



Cassette Pillar Height Check

Adjustment

4. Loosen Fixing Screw

Loosen the fixing screw of the S or T cassette pillar by one to two turns.

5. Adjust the Cassette Pillar Height


Lift the cassette pillars and press them slightly against the lower surface of the reference plate. Tighten the fixing screw under this condition.

6. Recheck the Cassette Pillar Height

Check that the height of the S and T cassette pillars satisfies the specification.

Caution

Shift the tightening position of the fixing screw when performing readjustment with the specification not satisfied. (Do not tighten the screw in the same position as previous.)



Cassette Pillar Height Adjustment

8-3-4. Reel Table Height Adjustment

Notes

- Be sure to check the height of the reel table when a reel table is removed.
- Perform the reel table height adjustment correctly.
The height of the reel table is used as the reference for the tape path.
- After supply reel table height adjustment is performed, be sure to check the video tracking. (Refer to Section 8-4-3.)

Tools


- Cassette reference plate (L)(MW-088): J-6320-880-A
- Reel table height gauge (MW-935): J-6329-350-A
- L-shaped wrench (1.5 mm): 7-700-736-05

Check

- 1. Install the Cassette Reference Plate (L)**
Place the cassette reference plate (L) in the direction shown in the figure, then place it on two cassette supports.
- 2. Place the Reel Shift Plate Assembly in the L Cassette Position**
Rotate the drive gear counterclockwise as far as it will go.
- 3. Check the Take-up Reel Table Height**
 - (1) Press the "T"-stamped side of the gauge against the take-up reel table from the directions indicated by the arrow.
 - (2) Check that the specification is satisfied while rotating the take-up reel table clockwise by one turn.

If the specification is not satisfied, perform steps 7 and 8.
- 4. Check the Supply Reel Table Height**
 - (1) Press the "S"-stamped side of the gauge against the supply reel table from the directions indicated by the arrow.
 - (2) Check that the specification is satisfied while rotating the supply reel table counterclockwise by one turn.

If the specification is not satisfied, perform steps 7 and 8.



Reel Table Height Check (L)

5. Place the Reel Shift Plate Assembly in the S Cassette Position


Rotate the drive gear clockwise as far as it will go.

6. Check the Supply and Take-up Reel Table Height

Perform in the same way as in steps 3 and 4.

If the specification is not satisfied, perform steps 7 and later.

If the specifications are satisfied in both the L and S cassette positions, perform steps 9 and later.



Reel Table Height Check (S)

Adjustment

7. Remove the Reel Table

8. Adjust the Number of Poly-slider Washers

Adjust the number of poly-slider washers installed in the reel motor shaft so that the specifications are satisfied in both the L and S cassette positions.

9. Remove the Cassette Reference Plate (L)


Remove the cassette reference plate (L) and reel table height gauge.

10. Tighten the Screws of the Reel Table Assembly

- (1) Align the notch at the bottom of the reel table assembly with the groove position of the reel shift plate assembly.
- (2) Insert an L-shaped wrench into the notch at the bottom of the reel table assembly along the groove of the reel shift plate and tighten the two screws.

11. Recheck the Reel Table Height

Refer to steps 2 through 6.



Reel Table Height Adjustment

8-3-5. Reel Brake Clearance Check

Note

- Be sure to check clearance of the reel brake when the brake lining assembly is replaced or when the reel table assembly is removed.

Check

1. Check the Take-up Reel Brake Clearance

Rotate the take-up reel table counterclockwise by fingers.




At that time, check that a clearance occurs between the brake arm block and boss.

If no clearance occurs, replace the brake lining. (Refer to Section 8-2-12.)


2. Check the Supply Reel Brake Clearance

Rotate the supply reel table clockwise by fingers. At that time, check that a clearance occurs between the brake arm block and boss.

If no clearance occurs, replace the brake lining. (Refer to Section 8-2-12.)



Spec.: A = Clearance exists.



Spec.: A = Clearance exists.

8-3-6. Reel Brake Release Amount Adjustment

Notes

- Be sure to check the release amount of the reel brake when the brake lining assembly is replaced or when the reel table assembly is removed.
- Be sure to check the following when performing adjustment with the specification not satisfied.
 - (1) Cassette pillar height check (Refer to Section 8-3-3.)
 - (2) Reel table height check (Refer to Section 8-3-4.)

Basic knowledge

The brake lining is pressed against the reel table when the power is off.

When the power is turned on, the brake lining is released.

In the PLAY, STOP, REW, F FWD, SEARCH, and REV modes, the brake lining remains released.

Press the EJECT button to put the unit into the EJECT mode. The brake lining is pressed against the reel table a few seconds after the EJECT mode is completed.

Tool

- Wire clearance check gauge set: J-6152-450-A


Check

1. Turn the Power On

2. Check the Brake Release Amount

Check on the supply and take-up sides that the brake lining does not touch the reel table while a reel table is rotating. (Specification 1)

If specification 1 is not satisfied, perform steps 3 and later.



Reel Brake Release Amount Check

Adjustment

3. Turn the Power Off

4. Remove the Reel Shift Plate Assembly

Refer to steps 1 through 4 in Section 8-2-13.
(It is not necessary to remove a reel table.)

5. Loosen the Screws Fixing the Brake Solenoid

Loosen the two screws fixing the brake solenoid.

6. Adjust the Brake Solenoid Position

Press down the iron core of the brake solenoid to the energized position.

At that time, adjust the brake solenoid position so that the clearance between the brake lining and reel table satisfies specification 2.

Note

Press down only the iron core by a sharp-pointed stick.

Do not touch other portions.

Know-how:

- Shift the brake solenoid upward.
→ Clearance A is narrowed.

- Shift the brake solenoid downward.
→ Clearance A is widened.

7. Tighten the Screws Fixing the Brake Solenoid

Tighten the two screws loosened in step 5.

8. Recheck the Brake Release Amount

Refer to step 6.

9. Install the Reel Shift Plate Assembly




Refer to steps 12 through 22 in Section 8-2-13.
(It is not necessary to smear grease again to the slide shaft or to apply oil again to the crank arm (A).)

10. Check the Cassette Pillar Height

Refer to Section 8-3-3.

11. Check the Reel Table Height

Refer to Section 8-3-4.



Reel Brake Release Amount Adjustment

8-4. TAPE PATH ADJUSTMENT

1. Parts Location of the Tape Running System

The parts location of the tape running system is described on page 8-135.

2. Notes

(1) Cassette Compartment

- The tape path adjustment should be performed with the cassette compartment not installed in the unit. If not, the check and adjustment may be impossible.
- When the tape path adjustment is performed with the cassette compartment removed, the tape protection circuit is activated and the "ERROR" message may be displayed. In this case, turn the power off, then turn it on again.

(2) S701-1 on SS-52 board

This switch selects whether to enable the tracking control volume.

- ON (Upper position): Tracking control disabled.
- OFF (Lower position): Tracking control enabled.

After adjustment is completed, be sure to return this switch to ON (upper position).

(3) Audio/TC Head

The audio erase head is not installed although it is drawn in the figures.

3. Preparation

(1) Remove the rotary head cleaner. (Refer to Section 8-2-4.)

(2) Clean the following portions :

- Rotary heads (Refer to Section 7-1-2.)
- Upper drum's tape running surface (Refer to Section 7-1-3.)
- Lower drum's tape running surface and lead surface (Refer to Section 7-1-4.)
- Stationary heads (Refer to Section 7-1-5.)
- Tape running system and tape cleaner (Refer to Section 7-1-6.)


Note : The tape running condition may be difficult to check with the rotary head cleaner installed. Therefore, remove this component in advance.

4. Locking Compound

When loosening the following screws, apply locking compound to the screws after adjustment is completed.

The locking compound that applied to other surrounding parts must be wiped off with gauze or soft cloth.

- Locking compound: 7-432-114-11



5. Alignment Tape

(1) ZR2-1

- Part No.: 8-960-073-11
- Contents:

TIME min. sec	CTL TRACK	CUE TRACK	VIDEO/AUDIO TRACK	USE
00 : 00 ↑ (7 : 3 PULSE) ↓ 15 : 00	CTL	1 kHz, 0 VU	4 MHz (A CH only)	• Video Tracking Adjustment • CTL Head Position Adjustment • Audio/TC Head Height Adjustment (DVW-510) • Audio/TC Head Position Adjustment • Audio Level Check in REV Mode (DVW-510)
20 : 00	CTL	12 kHz, 0 VU	A, C CH – 4 MHz B, D CH – 8 MHz	• Audio/TC Head Azimuth Adjustment (DVW-510) • Audio/TC Head Head-to-tape Contact Adjustment (DVW-510)
25 : 00	CTL	12 kHz, 0 VU	16 MHz (ALL CH)	
27 : 00	CTL	_____	50 % FLAT FIELD (ALL CH)	

* CTL head height adjustment can be performed at any portion of this alignment tape.

Note

When the 7:3 pulse portion is played back, the displayed TC data is interpolated by CTL signal due to no recording on the time code track.

(2) CR8-1A

- Part No.: 8-960-097-45
- Contents:

TIME min. sec	AUDIO TRACK	VIDEO TRACK	CTL TRACK	USE
00 : 00	1 kHz, 0 VU	_____	CTL	
02 : 55	Blank			
03 : 00	10 kHz, –10 VU	_____	CTL	• Audio/TC Head Azimuth Adjustment (DVW-A510/CA510) • Audio/TC Head Head-to-tape Contact Adjustment (DVW-A510/CA510)
04 : 55	Blank			
05 : 00	1 kHz, –20 VU	_____	CTL	
05 : 55	Blank			
06 : 00	40 Hz, –20 VU 7 kHz, –20 VU 10 kHz, –20 VU 15 kHz, –20 VU	_____	CTL	
07 : 55	Blank			
08 : 00	1 kHz, 0 VU	_____	1 kHz Sine Wave	• Audio/TC Head Height Adjustment (DVW-A510/CA510) • Audio Level Check in REV Mode (DVW-A510/CA510)
10 : 00				

Note

This alignment tape is not required in the DVW-510.

8-4. TAPE PATH ADJUSTMENT

(3) CR5-1B

- Part No.: 8-960-096-41
- Contents:

TIME min.:sec.	VIDEO TRACK	AFM	CTL	USE
0 : 00	RF Sweep	No Signal	CTL	• Y/C Head Head-to-tape Contact Check
2 : 00	60% H Sweep (CTDM)			
5 : 00	Pulse & Bar (CTDM)			
8 : 00	60% Multi Burst			
11 : 00	Pulse & Bar			
14 : 00	75% Color Bars	400 Hz SINE WAVE 25 kHz DEVIATION		
16 : 30		75 kHz DEVIATION		
17 : 00	50% Bowtie & 12.5T	No Signal		
19 : 00	Line 17 Signal			
22 : 00	Quad Phase			
24 : 00	Flat Field			
26 : 00	75% Color Bars with Dropout			
28 : 00	Composite V Sweep with VISC			
30 : 00				

Note

This alignment tape is not required in the DVW-510.

8-4-1. Audio/TC Head Zenith Adjustment

Note

The audio/TC head zenith check and adjustment are not required except when the audio/TC head is replaced.

Tools

- Flatness plate (SL-657): J-6086-570-A
- Cleaning cloth: 3-184-527-01
- Cleaning fluid: 9-919-573-01

Check

1. Unthreading End Mode

Check that the unit is in the unthreading end mode.

2. Check the Audio/TC Head Zenith

- (1) Push the flatness plate lightly against the TG-4 guide and audio head.


Caution

Be careful not to damage the surface of the audio head and TG-4 guide.

- (2) Check that no clearance exists between the audio head and flatness plate as TG-4 guide reference in step (1).

If the specification is not satisfied, perform steps 3 and later.

If it is satisfied, perform step 7.



Audio/TC Head Zenith Check

Adjustment

3. Remove the CL Guide Rail

Remove the two screws, then remove the CL guide rail.

4. In Case Clearance Exists at the Upper Part (Fig. 1)

Turn the zenith adjustment screw counterclockwise to satisfy the specification.

5. In Case Clearance Exists at the Lower Part (Fig. 2)


Turn the zenith adjustment screw clockwise to satisfy the specification.

6. Install the CL Guide Rail

Install the CL guide rail with two screws.

7. Cleaning

Clean the surface of the audio head and TG-4 guide with a cleaning cloth moistened with cleaning fluid.



Audio/TC Head Zenith Adjustment

8-4-2. Tape Running Adjustment

Drum Entrance Side

Tools

- Digital Betacam cassette BCT-D32 (S cassette)
- Adjustment mirror (circular): J-6080-029-A
- Tape guide adjustment driver (MW-261): J-6322-610-A

Check

1. Set the S Cassette Tape

- (1) Place the reel shift plate assembly in the S cassette position.
- (2) Set the BCT-D32 and put a weight on the cassette so that it does not rise up.

2. Turn the Power On

3. PLAY Mode

Check that the tape running condition satisfies specification 1.

If specification 1 is not satisfied, perform steps 9 and 10.

4. REV $\times$ 10 Mode

Check that the tape running condition satisfies specification 1.

If specification 1 is not satisfied, perform steps 9 and 10.

5. F.FWD Mode

Check that the tape running condition satisfies specification 1.

If specification 1 is not satisfied, perform steps 9 and 10.

6. REW Mode

Check that the tape running condition satisfies specification 1.

If specification 1 is not satisfied, perform steps 9 and 10.

7. REV $\times$ 1 Mode


Check that the tape running condition satisfies specification 1.

If specification 1 is not satisfied, perform steps 9 and 10.

8. VAR $\times$ -1/30 Mode

Check that the tape running condition satisfies specification 1.

If specification 1 is not satisfied, perform steps 9 and 10.



Tape Running Check at Drum Entrance Side

Adjustment


9. Adjust the TG-1 and TG-2 (Entrance Guide) Height

- (1) Put the unit into the PLAY mode.
- (2) Turn the height adjustment nut of TG-1 and the upper flange of TG-2 using a tape guide adjustment driver and adjust the height of TG-1 and TG-2 so that the specification 1 is satisfied.

10. Recheck the Tape Running at Drum Entrance Side

Refer to steps 3 through 8.

If the specification 1 is not satisfied, perform the adjustment in step 9 again.



Tape Running Adjustment at Drum Entrance Side

Drum Exit Side**Tools**

- Digital Betacam cassette BCT-D32 (S cassette)
- Digital Betacam cassette BCT-D94L (L cassette)
- Adjustment mirror (circular): J-6080-029-A
- Tape guide adjustment driver (MW-261): J-6322-610-A

Check**1. Set the S Cassette Tape**

- (1) Place the reel shift plate assembly in the S cassette position.
- (2) Set the BCT-D32 and put a weight on the cassette so that it does not rise up.

2. Turn the Power On**3. PLAY Mode**

Check that the tape running condition satisfies specification 2.

If specification 2 is not satisfied, perform steps 12 and 14.

4. REV × 10 Mode

Check that the tape running condition satisfies specification 2.

If specification 2 is not satisfied, perform steps 13 and 14.

5. F.FWD Mode

Check that the tape running condition satisfies specification 2.

If specification 2 is not satisfied, perform steps 12 and 14.

6. REW Mode

Check that the tape running condition satisfies specification 2.

If specification 2 is not satisfied, perform steps 12 and 14.

7. REV × 1 Mode

Check that the tape running condition satisfies specification 2.

If specification 2 is not satisfied, perform steps 12 and 14.

8. VAR × -1/30 Mode

Check that the tape running condition satisfies specification 2.

If specification 2 is not satisfies, perform steps 13 and 14.

9. Set the L Cassette Tape

- (1) Take out the BCT-D32.
- (2) Press S700 (C-1/side A) on the SS-52 board and place the reel shift plate assembly in the L cassette position.
- (3) Set the BCT-D94L and put a weight on the cassette so that it does not rise up.


10. Play Back the Tape

Play back the tape beginning portion of the BCT-D94L.

11. Check the Tape Running at the T Tape Guide of Cassette

Check that the tape running condition satisfies specification 3 at TG-10 and the T tape guide of the BCT-D94L.

If specification 3 is not satisfied, perform step 15.

**Spec. 2: ⑤ LEAD OF DRUM EXIT SIDE**

The tape runs without any curl at the lead.

⑥ TG-3 (EXIT GUIDE)

The tape runs in contact with the upper flange.
The tape curl is less than 1/10 of the tape width.

⑦ TG-4

The tape runs in contact with the lower flange.
The tape curl is less than 1/10 of the tape width.

⑧ TG-5 (THREADING ROLLER)

The tape runs without any curl at the upper and lower flanges.

Spec. 3: PLAY Mode**⑨ TG-10**

The tape runs not in contact with the upper and lower flanges.

⑩ TAKE-UP SIDE TAPE GUIDE

The tape runs without any curl at the upper and lower portions of the tape guide.

Tape Running Check at Drum Exit Side

Adjustment

12. Adjust the TG-3 (Exit Guide) and TG-4 Height

- (1) Set the BCT-D32 and put the unit into the PLAY mode.
- (2) Turn the upper flanges of TG-3 and TG-4 using a tape guide adjustment driver and adjust the height of TG-3 and TG-4 so that the specification 2 is satisfied.

13. Adjust the TG-5 (Threading Roller) Height

(only when the specification is not satisfied in REV $\times$ 10 mode and VAR $\times$ -1/30 mode)

- (1) Put the unit into the EJECT mode.
- (2) Take out the cassette tape.
- (3) Turn the upper flange of TG-5 using a tape guide adjustment driver and adjust the height of TG-5 so that the specification 2 is satisfied.
- (4) Set the S cassette tape and put the unit into the REV $\times$ 10 mode or VAR $\times$ -1/30 mode. At this time, check that the tape running condition satisfies specification 2.

If it is not satisfied, repeat steps (1) through (4) mentioned above.

14. Recheck the Tape Running at Drum Exit Side

Refer to steps 2 through 8.

If the specification 2 is not satisfied, perform the adjustment in step 12 again.


(If the specification 2 is not satisfied in REV $\times$ 10 mode and VAR $\times$ -1/30 mode, perform the adjustment in step 13 again.)

15. Adjust the Slant Guide Slantness

- (1) Loosen the fixing screw of the adjustment plate by 1/4 to 1/2 turn.
- (2) Insert a 3 mm flatbladed screwdriver into the notch of the adjustment plate.
- (3) Adjust the slantness of the slant guide so that specification 3 is satisfied.
- (4) Tighten the screw loosened in step (1).
- (5) Recheck that specification 3 is satisfied referring to steps 9 through 11.


If it is not satisfied, repeat steps (1) through (5) mentioned above.

* TG-3, 4 Height Adjustment/Slant Guide Slantness Adjustment



* TG-5 Height Adjustment (only when the specification is not satisfied in REV $\times$ 10 mode and VAR $\times$ -1/30 mode)

(Unthreading End Mode)



Tape Running Adjustment at Drum Exit Side

8-4-3. Video Tracking Adjustment


Note
The Y/C Head Head-to-tape Contact Check (step 16) should be performed in the DVW-A510/CA510 only. In the DVW-510, it is not required.

Tools

- Alignment tape ZR2-1: 8-960-073-11
- Oscilloscope
- Alignment tape CR5-1B: 8-960-096-41
(Not required in the DVW-510)
- Adjustment mirror (circular): J-6080-029-A
- Tape guide adjustment driver (MW-261): J-6322-610-A

Preparation

1. Turn the Power Off
2. Connect the Oscilloscope
CH-1: TP2502/SS-52 board (ENV A/C signal)
TRIG: TP819/SS-52 board (1/2 VD signal)
3. Set the Alignment Tape
Set the ZR2-1 and put a weight on the cassette so that it does not rise up.
4. Put S2101-7, 8 on the SS-52 Board to ON (upper position).
5. Turn the Power On.
6. Press S2100 on the SS-52 Board.



Preparation

Check

7. PLAY Mode

- Play back the ZR2-1 (00:00 to 15:00).
- Put S701-1 on the SS-52 board to OFF (lower position) so that the tracking control volume can be operated.
- Turn RV700 (tracking control volume) on the SS-52 board and check that the output levels at the entrance and exit sides do not become higher than the output level in the center portion.

If they become higher, perform the adjustment (at the Drum Entrance Side or Drum Exit Side) in steps 17 and later.


- Turn RV700 on the SS-52 board clockwise and adjust the center portion of the RF envelope waveform so that it is 80% of the maximum output level.
At that time, check that the RF envelope waveform satisfies specification 1.

If the level fluctuates, read the average level. Then turn RV700 on the SS-52 board so that the output level in the center portion of the RF envelope waveform is maximum, and check that the fluctuation amounts satisfy specification 2.

If specification 1 and 2 are not satisfied, perform the adjustment (at the Drum Entrance Side or Drum Exit Side) in steps 17 and later.

– To be continued. –


<SS-52 BOARD, Side A>



ON: upper position
(TRACKING VR operation disabled)
OFF: lower position
(TRACKING VR operation enabled)

• Alignment Tape: ZR2-1 (00: 00 to 15: 00)

<Head-to-Tape Contact> S701-1 : OFF




$$A = \text{RF max} \times 0.8$$

$$\text{Spec. 1: } \frac{B}{A} \times 100 \geq 70 \%$$

$$\frac{C}{A} \times 100 \geq 70 \%$$

(Output levels (B and C) at the drum entrance side and exit side are more than 70% of the center level (A).)

<Fluctuation> S701-1 : OFF



$$D = \text{average level}$$

$$\text{Spec. 2: } \frac{a}{D} \times 100 \leq 20 \%$$

$$\frac{b}{D} \times 100 \leq 20 \%$$

$$\frac{c}{D} \times 100 \leq 20 \%$$

(Fluctuation amounts (a, b, c) at the drum center portion, entrance side and exit side are less than 20% of the average level (D).)


If the output waveform is extremely abnormal condition as shown in Fig. 1 after replacing the inner drum assembly, perform the steps 1 to 5 below.

- Remove the upper drum. (Refer to steps 1 through 5 in Section 8-2-1.)
- Clean the drum support's upper drum contacting surface. (Refer to step 7 in Section 8-2-1.)
- Clean the upper drum's drum support contacting surface. (Refer to step 12 in Section 8-2-1.)
- Install the upper drum and other removed parts. (Refer to steps 13 through 19 in Section 8-2-1.)
- Check the video tracking again.


If a bamboo stick is available, it is recommended to observe the waveform while pressing the tape as shown in Fig. 2 before performing the steps 1 to 5 above. If the abnormal waveform returns to the normal waveform when pressing down by bamboo stick, it shows that the tape is running apart from the drum lead without touching. In such case, reinstall the upper drum according to the steps 1 to 5 above.

<Fig. 1>

* abnormal waveform (example)



<Fig. 2>



Video Tracking Check (PLAY)

8. REV×10 Mode



- (1) Put S701-1 on the SS-52 board to ON (upper position) and fix the tracking control volume.
- (2) Play back the ZR2-1
- (3) Put the unit into the REV×10 mode and check that the RF envelope waveform satisfies specification 3.

If specification 3 is not satisfied, perform the adjustment (at the Drum Entrance Side or Drum Exit Side) in steps 17 and later.

9. F.FWD and REW Modes

- (1) Play back the ZR2-1
- (2) Put the unit into the F.FWD and REW modes and check that no waveform lacking exists in RF envelope waveform. (Spec. 4)


If specification 4 is not satisfied, perform the adjustment (at the Drum Entrance Side or Drum Exit Side) in steps 17 and later.

**Video Tracking Check (REV x 10)****Video Tracking Check (F. FWD, REW)****10. REW Mode to PLAY Mode**

- (1) Play back the ZR2-1 (00:00 to 15:00)
- (2) Put the unit into the REW mode once. Two or three seconds later, put the unit into PLAY mode. Check that the RF envelope waveform turns to the maximum level with the even level within 1 second. (Spec. 5-①)

If specification 5-② is not satisfied in waveform A or B shown in the figure, check the tape running at the drum entrance side. (Refer to Section 8-4-2.)

If specification 5-② is not satisfied in waveform C shown in the figure, check the tape running at the drum exit side. (Refer to Section 8-4-2.)

**Video Tracking Check (REW → PLAY)**

11. VAR×-1/30 Mode

- (1) Play back the ZR2-1 (00:00 to 15:00).
- (2) Put the unit into the VAR×-1/30 mode and check that the no waveform lacking exists, the waveform are equal, and no waveform disordered exists. (Spec. 6)

In case of the drum entrance side is no good, perform the tracking adjustment at drum entrance side. (Refer to steps 17 through 19.)

In case of the drum exit side is no good, adjust the height of TG-5 first. In case of the drum exit side is no good though TG-5 height adjustment is performed, perform the tracking adjustment at drum exit side. (Refer to steps 20 through 24.)

Check that the tape curl at the lower flange of TG-4 is less than 1/10 of the tape width (Spec. 7)

If the specification 7 is not satisfied, adjust the height of TG-5 first. In case of the drum exit side is no good though TG-5 height adjustment is performed, perform the tracking adjustment at drum exit side. (Refer to steps 20 through 24.)

12. PLAY Mode to VAR×-1/30 Mode

- (1) Play back the ZR2-1 (00:00 to 15:00).
- (2) Put the unit into the PLAY mode once. Two or three seconds later, put the unit into the VAR×-1/30 mode.

Check that the no waveform lacking exists, the waveform are equal, and no waveform disordered exists when changing the mode. (Spec. 6)

In case of the drum entrance side is no good, perform the tracking adjustment at drum entrance side. (Refer to steps 17 through 19.)


In case of the drum exit side is no good, adjust the height of TG-5 first. In case of the drum exit side is no good though TG-5 height adjustment is performed, perform the tracking adjustment at drum exit side. (Refer to steps 20 through 24.)

Check that the tape curl at the lower flange of TG-4 is less than 1/10 of the tape width. (Spec. 7)

If the specification 7 is not satisfied, adjust the height of TG-5 first. In case of the drum exit side is no good though TG-5 height adjustment is performed, perform the tracking adjustment at drum exit side. (Refer to steps 20 through 24.)

• Alignment Tape: ZR2-1 (00:00~15:00)


(OK)




Spec. 6: No waveform lacking exists.
The waveform are equal, and no waveform disordered exists.

* In case of the drum entrance side is NG (Example):

(NG)




(NG)





* In case of the drum exit side is NG (Example):

(NG)



(NG)



Spec. 7: Lower Flange of TG-4
The tape curl is less than 1/10 of the tape width.

Video Tracking Check (VAR×-1/30, VAR×-1)

13. VAR×-1 Mode

- (1) Play back the ZR2-1 (00:00 to 15:00).
- (2) Put the unit into the VAR×-1 mode, and check that the no waveform lacking exists, the waveform are equal, and no waveform disordered exists. (Spec. 6)

In case of the drum entrance side is no good, perform the tracking adjustment at drum entrance side. (Refer to steps 17 through 19.)

In case of the drum exit side is no good, adjust the height of TG-5 first. In case of the drum exit side is no good though TG-5 height adjustment is performed, perform the tracking adjustment at drum exit side. (Refer to steps 20 through 24.)

Check that the tape curl at the lower flange of TG-4 is less than 1/10 of the tape width. (Spec. 7)

If the specification 7 is not satisfied, adjust the height of TG-5 first. In case of the drum exit side is no good though TG-5 height adjustment is performed, perform the tracking adjustment at drum exit side. (Refer to steps 20 through 24.)

14. PLAY Mode to VAR×-1 Mode

- (1) Play back the ZR2-1 (00:00 to 15:00).
- (2) Put the unit into the PLAY mode once. Two or three seconds later, put the unit into the VAR×-1 mode.

Check that no waveform lacking exists, the waveform are equal, and no waveform disordered exists when changing the mode. (Spec. 6)

In case of the drum entrance side is no good, perform the tracking adjustment at drum entrance side. (Refer to steps 17 through 19.)


In case of the drum exit side is no good, adjust the height of TG-5 first. In case of the drum exit side is no good though TG-5 height adjustment is performed, perform the tracking adjustment at drum exit side. (Refer to steps 20 through 24.)

Check that the tape curl at the lower flange of TG-4 is less than 1/10 of the tape width. (Spec. 7)

If the specification 7 is not satisfied, adjust the height of TG-5 first. In case of the drum exit side is no good though TG-5 height adjustment is performed, perform the tracking adjustment at drum exit side. (Refer to steps 20 through 24.)

• Alignment Tape: ZR2-1 (00:00~15:00)


(OK)




Spec. 6: No waveform lacking exists.
The waveform are equal, and no waveform disordered exists.

* In case of the drum entrance side is NG (Example):

(NG)




(NG)





* In case of the drum exit side is NG (Example):

(NG)



(NG)




Spec. 7: Lower Flange of TG-4
The tape curl is less than 1/10 of the tape width.

Video Tracking Check (VAR×-1/30, VAR×-1)

15. Check the Advance Head Head-to-tape Contact

- (1) Connect the oscilloscope.
CH-1: TP401/EQ-45 board (Y/ADV AC signal)
CH-2: TP501/EQ-45 board (C/ADV BD signal)
TRIG: TP103/EQ-45 board (Y/ADV AC SEL signal)
- (2) Play back the ZR2-1 (20:00 to 25:00).
- (3) Put S701-1 on the SS-52 board to ON (upper position) and fix the tracking control volume.
- (4) Check that the all channels output the RF envelope waveform.




Advance Head Head-to-tape Contact Check

Note

Y/C Head Head-to-tape Contact Check should be performed in the DVW-A510/CA510 only. In the DVW-510, it is not required.

16. Check the Y/C Head Head-to-tape Contact

- (1) Connect the Oscilloscope.
CH-1: TP401/EQ-45 board (Y/ADV AC signal)
CH-2: TP501/EQ-45 board (C/ADV BD signal)
TRIG: TP819/SS-52 board (1/2 VD signal)
- (2) Take out the ZR2-1.
- (3) Set the CR5-1B and put a weight on the cassette so that it does not rise up.
- (4) Play back the CR5-1B (2:00 and later).
- (5) Put S701-1 on the SS-52 board to ON (upper position) and fix the tracking control volume.
- (6) Check that the all channels output the RF envelope waveform.



Y/C Head Head-to-tape Contact Check (only DVW-A510/CA510)

Adjustment


Drum Entrance Side

17. Adjust the Tracking at Drum Entrance Side

- (1) Play back the ZR2-1 (00:00 to 15:00).
- (2) Put S701-1 on the SS-52 board to OFF (lower position) so that the tracking control volume can be operated.
- (3) Turn RV700 on the SS-52 board clockwise and adjust the center portion of the RF envelope waveform so that it is 80% of the maximum output level.
- (4) Loosen the upper flange of TG-2 so that the tape does not come in contact with the upper flange of TG-2.
- (5) Turn the height adjustment nut of TG-1 so that the RF envelope waveform is as shown in Fig. 1.
- (6) Turn the upper flange of TG-2 and adjust the height of TG-2 so that the RF envelope waveform is flat. (Fig. 2)


— To be continued. —

〈SS-52 BOARD, Side A〉




- Alignment Tape: ZR2-1 (00:00~15:00)

〈Fig. 1〉



If the pressure against the tape at TG-1,2 are too much, the waveform become as shown in the right figure. (NG)

〈Fig. 2〉



If the waveform is not flat, perform the check and adjustment below.

- ① Clean the drum lead with a bamboo stick. (Refer to Section 7-1-4.)
 - ② Press down the tape by bamboo stick and check that the tape is running without aparting from the drum lead.
 - ③ Adjust the height of TG-2 so that the RF envelope waveform is nearly flat within the range of the specification shown in the Fig. 3. At this time, do not overpress the tape at TG-2.
- (7) Check the tape running at the drum entrance side in the following modes.
- PLAY mode
 - REV × 10 mode
 - F.FWD mode
 - REW mode
 - REV × 1 mode
 - VAR × -1/30 mode
- If the tape curl does not satisfy the specification at either TG-0, TG-1 or TG-2, perform the following adjustments while observing the waveform.
- ① Change the pressure against the tape at TG-1 and TG-2 within the range of the specification shown in the Fig. 1.
 - If the tape curl at TG-1 exceeds the specification described in Section 8-4-2, increase the pressure by turning the upper flange of TG-2 clockwise.
 - If the tape curl at TG-2 exceeds the specification described in Section 8-4-2, increase the pressure by turning the height adjustment nut of TG-1 clockwise.
 - ② Perform the tracking adjustment again. (Refer to step (1) through (7) mentioned above.)


18. Recheck the Video Tracking

Refer to steps 7 through 14. (page 8-98 to 8-100)

Caution

After adjustment is completed, be sure to put S701-1 on the SS-52 board to ON (upper position), and put S2101-7,8 on the SS-52 board to OFF (lower position).

〈Fig. 3〉




〈Tape Running Check〉

- Spec. 1:**
- ① TG-0
The tape runs without any curl at the upper and lower flanges.
 - ② TG-1 (S TENSION REGULATOR)
The tape runs in contact with the upper flange.
The tape curl is less than 1/10 of the tape width.
 - ③ TG-2 (ENTRANCE GUIDE)
The tape runs in contact with the upper flange.
The tape curl is less than 1/10 of the tape width.
 - ④ LEAD OF DRUM ENTRANCE SIDE
The tape runs without any curl at the lead.

Tracking Adjustment at Drum Entrance Side

Drum Exit Side**19. Remove the CL Guide Rail**

Remove the two screws, then remove the CL guide rail.



Removal/Installation of the CL Guide Rail

20. Adjust the Tracking at Drum Exit Side

- (1) Play back the ZR2-1 (00:00 to 15:00).
- (2) Put S701-1 on the SS-52 board to OFF (lower position) so that the tracking control volume can be operated.
- (3) Turn RV700 on the SS-52 board clockwise and adjust the center portion of the RF envelope waveform so that it is 80% of the maximum output level.
- (4) Turn the upper flange of TG-3 counterclockwise by one to two turns so that the tape does not come in contact with the upper flange of TG-3.
- (5) Turn the upper flange of TG-4 clockwise so that the tape does not come in contact with the lower flange of TG-4.
- (6) Turn the zenith adjustment screw of the audio/TC head and adjust the RF envelope waveform so that it is 0 to 30% of the maximum output level. (Fig. 1)

At this time, check that the tape never touch both the upper flange of TG-3 and the lower flange of TG-4.

If the tape touches either flanges, repeat step (4) or (5).

If the tape follows the flanges in step (4) or (5), perform the following adjustment because the symptom indicates the too much tension either at upper or lower part of the tape caused by audio/TC head zenith.




- If the tape follows the upper flange at TG-3:
Turn the zenith adjustment screw counterclockwise.
- If the tape follows the lower flange at TG-4:
Turn the zenith adjustment screw clockwise.

- (7) Turn the upper flange of TG-3 so that it comes in contact with the tape and so that the RF envelope waveform is flat. (Fig. 2)

At that time, the tape does not contact with the lower flange of TG-4.


— To be continued. —

〈SS-52 BOARD, Side A〉




- Alignment Tape: ZR2-1 (00:00~15:00)

〈Fig. 1〉



If the pressure against the tape at TG-3 is too much, the waveform become as shown in the right figure. (NG)

〈Fig. 2〉



If the waveform is not flat, perform the check and adjustment below.

- ① Clean the drum lead with a bamboo stick.
(Refer to Section 7-1-4.)
 - ② Press down the tape by bamboo stick and check that the tape is running without aparting from the drum lead.
 - ③ Adjust the height of TG-3 so that the RF envelope waveform is nearly flat within the range of the specification shown in the Fig. 3. At this time, do not overpress the tape at TG-3.
- (8) Adjust the height of TG-4 so that the lower flange of TG-4 comes in contact with the tape.
 - (9) Check the tape running at the drum exit side in the following modes.
 - PLAY mode
 - REV $\times 10$ mode
 - F.FWD mode
 - REW mode
 - REV $\times 1$ mode
 - VAR $\times -1/30$ mode
- If the tape curl does not satisfy the specification at TG-3, perform the following adjustments while observing the waveform.
- ① Change the zenith of the audio/TC head within the range of the specification shown in Fig. 1.
 - ② Perform the tracking adjustment again.
(Refer to step (1) through (9) mentioned above.)

21. Recheck the Video Tracking

Refer to steps 7 through 14. (Page 8-98 through 8-100)


22. Install the CL Guide Rail

Install the CL guide rail with two screws.

Caution

After adjustment is completed, be sure to put S701-1 on the SS-52 board to ON (upper position), and put S2101-7,8 on the SS-52 board to OFF (lower position).

(Fig. 3)



(Tape Running Check)

Spec. 2: ⑤ LEAD OF DRUM EXIT SIDE

The tape runs without any curl at the lead.

⑥ TG-3 (EXIT GUIDE)

The tape runs in contact with the upper flange.
The tape curl is less than 1/10 of the tape width.

⑦ TG-4

The tape runs in contact with the lower flange.
The tape curl is less than 1/10 of the tape width.

⑧ TG-5 (THREADING ROLLER)

The tape runs without any curl at the upper and lower flanges.

Tracking Adjustment at Drum Exit Side

8-4-4. CTL Head Height Adjustment

Tools

- Alignment tape ZR2-1: 8-960-073-11
- Oscilloscope
- Tape guide adjustment driver (MW-261): J-6322-610-A


Preparation

1. Turn the Power Off
2. Connect the Oscilloscope
CH-1: TP800/SS-52 board (CTL signal)
TRIG: TP819/SS-52 board (1/2 VD signal)
3. Set the Alignment Tape
Set the ZR2-1 and put a weight on the cassette so that it does not rise up.

* Connection of the Oscilloscope

CH-1: TP800/SS-52 board (CTL signal)
TRIG: TP819/SS-52 board (1/2 VD signal)

〈SS-52 BOARD, Side A〉



Preparation


Check

4. Turn the Power On
5. Play Back the Alignment Tape
Play back the ZR2-1.
6. Check the CTL Head Height
 - (1) Check that the level decreases when portion A of the tape shown in the figure is pressed down.

If the level increases, perform step 7.
 - (2) Check that the level decreases when portion B of the tape is pushed up.

If the level increases, perform step 8.

* Alignment Tape : ZR2-1



Spec.: The level decreases when pressing down and pushing up the alignment tape.

CTL Head Height Check

Adjustment


7. In Case the Level Increases when the Tape is Pressed Down (Fig. 1)

Turn the adjustment nut counterclockwise and adjust so that the output waveform is maximum.


8. In Case the Level Increases when the Tape is Pushed Up (Fig. 2)

Turn the adjustment nut clockwise and adjust so that the output waveform is maximum.

〈Fig. 1〉



〈Fig. 2〉



CTL Head Height Adjustment

8-4-5. CTL Head Position Adjustment

Note

The CTL head position adjustment is closely related to the audio/TC head position adjustment.

Be sure to confirm the audio/TC head position when the CTL head position is adjusted.

Tools

- Alignment tape ZR2-1: 8-960-073-11
- Oscilloscope


Preparation

1. Turn the Power Off
2. Connect the Oscilloscope
CH-1: TP2502/SS-52 board (ENV A/C signal)
CH-2: TP819/SS-52 board (1/2 VD signal)
CH-3: TP103/EQ-45 board (ADV AC SEL signal)
TRIG: TP819/SS-52 board (1/2 VD signal)
3. Put S2101-7, 8 on the SS-52 Board to ON (upper position).
4. Set the Alignment Tape
Set the ZR2-1 and put a weight on the cassette so that it does not rise up.

* Connection of the Oscilloscope

CH-1: TP2502/SS-52 board (ENV A/C signal)
CH-2: TP819/SS-52 board (1/2 VD signal)
CH-3: TP103/EQ-45 board (ADV AC SEL signal)
TRIG: TP819/SS-52 board (1/2 VD signal)

〈SS-52 BOARD, Side A〉




ON : upper position
OFF: lower position

〈EQ-45 BOARD, Side A〉 (Board suffix No. 15 and later)



(Board suffix No. 11, 12, 13, 22, 23, 31, 41)



Preparation

Check

5. Turn the Power On**6. Play Back the Alignment Tape**

Play back the ZR2-1 (00:00 to 15:00).


7. Check the CTL Head Position

- (1) Put S701-1 on the SS-52 board to OFF (lower position) so that the tracking control volume can be operated.
- (2) Turn RV700 (tracking control volume) on the SS-52 board so that the output level in the center portion of the RF envelope waveform is maximum. At that time, check that the marker is located in the rising portion of 1/2 VD signal.
- (3) Put S701-1 on the SS-52 board to ON (upper position) and fix the tracking control volume.
- (4) Check that the output level in the center portion of the RF envelope waveform satisfies the specification.


If the specification is not satisfied, perform steps 8 and later.

If it is satisfied, put S2101-7, 8 on the SS-52 board to OFF (lower position).

* Alignment Tape: ZR2-1 (00:00 to 15:00)



〈SS-52 BOARD, Side A〉



CTL Head Position Check

Adjustment

8. Loosen the Screw

Loosen the fixing screw of the CTL head assembly by 1/4 to 1/2 turn.

9. Adjust the CTL Head Position

- (1) Put the unit into the STILL mode. At this time, the peak level of RF envelope waveform is 100%. (Fig. 1)
 - (2) Insert a 3 mm flatbladed screwdriver into the notch of the CTL head assembly.
 - (3) Put the unit into the PLAY mode. Adjust the CTL head assembly position so that the output level in the center portion is 10% and more, and the marker of RF envelope waveform is located in the rising portion of 1/2 VD signal. (Fig. 2)
- At this time, check that the impedance roller of TG-2 rotates smoothly. If not, perform the step (1) through (3) mentioned above again.

10. Tighten the Screw

Tighten the screw loosened in step 8.

11. Recheck the CTL Head Position

Refer to steps 6 and 7.

12. Adjust the Offset Level of Advance Head

Refer to Section 5-7.

(A022 : HEAD OFFSET LEVEL)

13. Store the Adjustment Data

Refer to Section 5-7.

(A023 : NV-RAM CONTROL)

In case the adjustment is performed



14. Adjust the Audio/TC Head Position

Refer to Section 8-4-9.


Caution

After adjustment is completed, be sure to put S701-1 on the SS-52 board to ON (upper position) and put S2101-7, 8 to OFF (lower position).

<Fig. 1> STILL mode



<Fig. 2> PLAY mode



CTL Head Position Adjustment

8-4-6. Audio/TC Head Height Adjustment

For DVW-A510/CA510

Note

The audio/TC head height adjustment is closely related to the azimuth adjustment, head-to-tape contact adjustment, and head position adjustment. Be sure to perform adjustments (or checks) according to "In case the adjustment is performed" in this section when the audio/TC head height is adjusted.

Tools

- Alignment tape CR8-1A: 8-960-097-45
- Oscilloscope


Preparation

1. Turn the Power Off
2. Connect the Oscilloscope
CH-1: TP103/AP-28 board (CH-1 PB signal)
CH-2: TP203/AP-28 board (CH-2 PB signal)
3. Set the Alignment Tape
Set the CR8-1A and put a weight on the cassette so that it does not rise up.

* Connection of the Oscilloscope

CH-1: TP103/AP-28 board (CH-1 PB signal)
CH-2: TP203/AP-28 board (CH-2 PB signal)

〈AP-28 BOARD, Side A〉



Preparation (DVW-A510/CA510)

Check

4. Turn the Power On

5. Play Back the Alignment Tape

Play back the 1 kHz, 0 VU signal portion (8:00 to 10:00) on the CR8-1A.

6. Check the Audio/TC Head Height


- (1) Check that both levels in CH-1 and CH-2 decrease when portion A of the tape shown in the figure is pressed down.

If both levels increase, perform step 7.


- (2) Check that both levels in CH-1 and CH-2 decrease when portion B of the tape is pushed up.

If both levels increase, perform step 8.

* Alignment Tape: CR8-1A(8:00 to 10:00)



〈Audio Output Waveform〉



Spec. : The portion A widens when pressing down and pushing up the alignment tape.

Audio/TC Head Height Check (DVW-A510/CA510)

Adjustment

7. In Case both Levels Increase when the Tape is Pressed Down (Fig. 1)

Turn the height adjustment screw clockwise and adjust so that both output waveforms in CH-1 and CH-2 are maximum.

8. In Case both Levels Increase when the Tape is Pushed Up (Fig. 2)

Turn the height adjustment screw counterclockwise and adjust so that both output waveforms in CH-1 and CH-2 are maximum.

In case the adjustment is performed

9. Adjust the Audio/TC Head Azimuth

Refer to Section 8-4-7 (For DVW-A510/CA510).

10. Adjust the Audio/TC Head Head-to-tape Contact

Refer to Section 8-4-8 (For DVW-A510/CA510).

11. Check the Audio/TC Head Azimuth

Refer to Section 8-4-7 (For DVW-A510/CA510).

12. Adjust the Audio/TC Head Position

Refer to Section 8-4-9.


13. Check the Audio/TC Head Height

Refer to steps 5 and 6 in this section.


14. Check the Audio/TC Head Azimuth

Refer to Section 8-4-7 (For DVW-A510/CA510).

〈Fig. 1〉



〈Fig. 2〉



For DVW-510

Note

The audio/TC head height adjustment is closely related to the azimuth adjustment, head-to-tape contact adjustment, and head position adjustment.
Be sure to perform adjustments (or checks) according to "In case the adjustment is performed" in this section when the audio/TC head height is adjusted.

Tools

- Alignment tape ZR2-1: 8-960-073-11
- Oscilloscope

Preparation

1. **Turn the Power Off**
2. **Connect the Oscilloscope**
CH-1: AUDIO OUTPUT CUE connector/
connector panel
or
TP701/CUE-1 board (CUE OUT signal)
3. **Play Back the Alignment Tape**
Set the ZR2-1 and put a weight on the cassette so that it does not rise up.


Check

4. **Turn the Power On**
5. **Play Back the Alignment Tape**
Play back the 1 kHz, 0 VU signal portion (00:00 to 15:00) on the ZR2-1.
6. **Check the Audio/TC Head Height**
 - (1) Check that the level decreases when portion A of the tape shown in the figure is pressed down.

If the level increases, perform step 7.
 - (2) Check that the level decreases when portion B of the tape is pushed up.

If the level increases, perform step 8.

* Alignment Tape: ZR2-1 (00:00 to 15:00)



〈Cue Output Waveform〉



Spec. : The level decreases when pressing down and pushing up the alignment tape.

Audio/TC Head Height Check (DVW-510)

Adjustment

7. In Case the Level Increases when the Tape is Pressed Down (Fig. 1)

Turn the height adjustment screw clockwise and adjust so that the output waveform is maximum.

8. In Case the Level Increases when the Tape is Pushed Up (Fig. 2)

Turn the height adjustment screw counterclockwise and adjust so that the output waveform is maximum.

In case the adjustment is performed

9. Adjust the Audio/TC Head Azimuth

Refer to Section 8-4-7 (For DVW-510).

10. Adjust the Audio/TC Head Head-to-tape Contact

Refer to Section 8-4-8 (For DVW-510).

11. Check the Audio/TC Head Azimuth

Refer to Section 8-4-7 (For DVW-510).

12. Adjust the Audio/TC Head Position

Refer to Section 8-4-9.


13. Check the Audio/TC Head Height

Refer to steps 5 and 6 in this section.


14. Check the Audio/TC Head Azimuth

Refer to Section 8-4-7 (For DVW-510).

〈Fig. 1〉




HEIGHT ADJUSTMENT SCREW




maximum

〈Fig. 2〉



HEIGHT ADJUSTMENT SCREW



maximum

Audio/TC Head Height Adjustment (DVW-510)

8-4-7. Audio/TC Head Azimuth Adjustment

For DVW-A510/CA510**Note**

The audio/TC head azimuth adjustment is closely related to the head-to-tape contact adjustment, head position adjustment, and head height adjustment.

Be sure to perform adjustments (or checks) according to "In case the adjustment is performed" in this section when the audio/TC head azimuth is adjusted.

Tools

- Alignment tape CR8-1A: 8-960-097-45
- Oscilloscope


Preparation

1. **Turn the Power Off**
2. **Connect the Oscilloscope**
CH-1: TP103/AP-28 board (CH-1 PB signal)
CH-2: TP203/AP-28 board (CH-2 PB signal)
3. **Set the Alignment Tape**
Set the CR8-1A and put a weight on the cassette so that it does not rise up.

*** Connection of Oscilloscope**

CH-1: TP103/AP-28 board (CH-1 PB signal)
CH-2: TP203/AP-28 board (CH-2 PB signal)

〈AP-28 BOARD, Side A〉



Preparation (DVW-A510/CA510)

Check

4. Turn the Power On

5. Play Back the Alignment Tape

Play back the 10 kHz, -10 VU signal portion (3:00 to 4:55) on the CR8-1A.


6. Check the Audio/TC Head Azimuth

- (1) Output a lissajous waveform so that the amplitudes in the horizontal and vertical directions are 6 cm each.
- (2) Check that the vertical amplitude at the center point in the horizontal direction satisfies the specification.


If the specification is not satisfied, perform steps 7 and later.

- (3) Strike the portions A and B shown in the figure lightly with the tip of a screwdriver. Then check that the specification is satisfied.

* Alignment Tape: CR8-1A (3:00 to 4:55)



〈Lissajous Waveform〉



Spec. : $A \leq 0.52\text{cm}$

Audio/TC Head Azimuth Check (DVW-A510/CA510)

Adjustment

7. Adjust the Audio/TC Head Azimuth

- (1) Turn the azimuth adjustment screw clockwise and adjust so that the specification is satisfied.
- (2) Strike the portions A and B shown in the figure lightly with the tip of a screwdriver. Then check that the specification is satisfied.

In case the adjustment is performed

8. Adjust the Audio/TC Head Head-to-tape Contact

Refer to Section 8-4-8 (For DVW-A510/CA510).

9. Check the Audio/TC Head Azimuth

Refer to steps 5 and 6 in this section.

10. Adjust the Audio/TC Head Position


Refer to Section 8-4-9.

11. Check the Audio/TC Head Height

Refer to Section 8-4-6 (For DVW-A510/CA510).

12. Check the Audio/TC Head Azimuth

Refer to steps 5 and 6 in this section.



Audio/TC Head Azimuth Adjustment (DVW-A510/CA510)

For DVW-510**Note**

The audio/TC head azimuth adjustment is closely related to the head-to-tape contact adjustment, head position adjustment, and head height adjustment.

Be sure to perform adjustments (or checks) according to "In case the adjustment is performed" in this section when the audio/TC head azimuth is adjusted.

Tools

- Alignment tape ZR2-1: 8-960-073-11
- Oscilloscope


Preparation

1. **Turn the Power Off**
2. **Connect the Oscilloscope**
CH-1: AUDIO OUTPUT CUE connector/
connector panel
or
TP701/CUE-1 board (CUE OUT signal)
3. **Set the Alignment Tape**
Set the ZR2-1 and put a weight on the cassette so that it does not rise up.


Adjustment

4. **Turn the Power On**
5. **Play Back the Alignment Tape**
Play back the 12 kHz, 0 VU signal portion (15:00 to 25:00) on the ZR2-1.
6. **Adjust the Audio/TC Head Azimuth**
 - (1) Turn the azimuth adjustment screw and adjust so that the output waveform is maximum.
 - (2) Strike the portions A and B shown in the figure lightly with the tip of a screwdriver. Then the level remains maximum.
7. **Adjust the Audio/TC Head Head-to-tape Contact**
Refer to Section 8-4-8 (For DVW-510).
8. **Adjust the Audio/TC Head Position**
Refer to Section 8-4-9.
9. **Check the Audio/TC Head Height**
Refer to Section 8-4-6 (For DVW-510).

* Alignment Tape : ZR2-1 (15:00 to 25:00)



〈Cue Output Waveform〉



8-4-8. Audio/TC Head Head-to-tape Contact Adjustment**For DVW-A510/CA510****Note**

The audio/TC head head-to-tape contact adjustment is closely related to the head position adjustment, head height adjustment, and head azimuth adjustment. Be sure to perform adjustments (or checks) according to "In case the adjustment is performed" in this section when the audio/TC head head-to-tape contact is adjusted.

Tools

- Alignment tape CR8-1A: 8-960-097-45
- Oscilloscope
- Torque screwdriver (6 kg•cm) (JB-5251): J-6252-510-A
- Torque screwdriver's bit (+2 mm, l= 75 mm): J-6323-420-A


Preparation

1. **Turn the Power Off**
2. **Connect the Oscilloscope**
 CH-1: TP103/AP-28 board (CH-1 PB signal)
 CH-2: TP203/AP-28 board (CH-2 PB signal)
3. **Set the Alignment Tape**
 Set the CR8-1A and put a weight on the cassette so that it does not rise up.

*** Connection of Oscilloscope**

CH-1: TP103/AP-28 board (CH-1 PB signal)
 CH-2: TP203/AP-28 board (CH-2 PB signal)

〈AP-28 BOARD, Side A〉



Preparation (DVW-A510/CA510)

Check

4. Turn the Power On

5. Play Back the Alignment Tape


Play back the 10 kHz, -10 VU signal portion (3:00 to 4:55) on the CR8-1A.

6. Check the Audio/TC Head Head-to-tape Contact


- (1) Push portions A and B of the tape shown in the figure slightly.
- (2) Check that both increase values of the output levels in CH-1 and CH-2 satisfy the specification.

If the specification is not satisfied, perform step 7 and later.

* Alignment Tape : CR8-1A (3:00 to 4:55)



〈Audio Output Waveform〉



Spec. : Both increase values of the output levels in CH-1 and CH-2 are within 5%.

Audio/TC Head Head-to-tape Contact Check (DVW-A510/CA510)

Adjustment

7. Loosen the Screws

Loosen the two head fixing screws by 1/4 to 1/2 turn.

8. Adjust the Audio/TC Head Head-to-tape Contact

- (1) Insert a 2 mm flatbladed screwdriver into the notch of the adjustment plate.
- (2) Adjust the audio/TC head position so that the output waveform is maximum.

9. Tighten the Screws

Tighten the two fixing screws loosened in step 7.

Tightening torque: $19.6 \times 10^{-2} \text{ N}\cdot\text{m}$ (2 kgf·cm)

10. Recheck the Audio/TC Head Head-to-tape Contact

Refer to steps 5 and 6 in this section.

In case the adjustment is performed

11. Check the Audio/TC Head Position


Refer to Section 8-4-9.

12. Check the Audio/TC Head Height

Refer to Section 8-4-6 (For DVW-A510/CA510).

13. Check the Audio/TC Head Azimuth

Refer to Section 8-4-7 (For DVW-A510/CA510).



Audio/TC Head Head-to-tape Contact Adjustment (DVW-A510/CA510)

For DVW-510**Note**

The audio/TC head head-to-tape contact adjustment is closely related to the head position adjustment, head height adjustment, and head azimuth adjustment. Be sure to perform adjustments (or checks) according to "In case the adjustment is performed" in this section when the audio/TC head head-to-tape contact is adjusted.

Tools

- Alignment tape ZR2-1: 8-960-073-11
- Oscilloscope
- Torque screwdriver (6 kg•cm)(JB-5251): J-6252-510-A
- Torque screwdriver's bit (+2 mm, l= 75 mm): J-6323-420-A

Preparation


1. **Turn the Power Off**
2. **Connect the Oscilloscope**
CH-1: AUDIO OUTPUT CUE connector/
connector panel
or
TP701/CUE-1 board (CUE OUT signal)
3. **Set the Alignment Tape**
Set the ZR2-1 and put a weight on the cassette so that it does not rise up.

Check

4. **Turn the Power On**
5. **Play Back the Alignment Tape**
Play back the 12 kHz, 0 VU signal portion (15:00 to 25:00) on the ZR2-1.
6. **Check the Audio/TC Head Head-to-tape Contact**
 - (1) Push portions A and B of the tape shown in the figure slightly.
 - (2) Check that the increase value in the output level satisfies the specification.

If the specification is not satisfied, perform step 7 and later.

* Alignment Tape : ZR2-1 (15:00 to 25:00)



Spec. : The increase value of the output level is within 5%.

Adjustment

7. Loosen the Screws

Loosen the two head fixing screws by 1/4 to 1/2 turn.

8. Adjust the Audio/TC Head Head-to-tape Contact

- (1) Insert a 2 mm flatbladed screwdriver into the notch of the adjustment plate.
- (2) Adjust the audio/TC head position so that the output waveform is maximum.

9. Tighten the Screws

Tighten the two fixing screws loosened in step 7.

Tightening torque: $19.6 \times 10^{-2} \text{ N}\cdot\text{m}$ (2 kgf·cm)

10. Recheck the Audio/TC Head Head-to-tape Contact

Refer to steps 5 and 6 in this section.

In case the adjustment is performed

11. Check the Audio/TC Head Position


Refer to Section 8-4-9.

12. Check the Audio/TC Head Height

Refer to Section 8-4-6 (For DVW-510).

13. Check the Audio/TC Head Azimuth

Refer to Section 8-4-7 (For DVW-510).



Audio/TC Head Head-to-tape Contact Adjustment (DVW-510)

8-4-9. Audio/TC Head Position Adjustment

Notes

- The CTL head position adjustment must have been completed before performing this adjustment. The audio/TC head position is adjusted with the CTL head position as reference.
- The audio/TC head position adjustment is closely related to the head height adjustment, head azimuth adjustment, and head-to-tape contact adjustment. Be sure to perform adjustments (or checks) according to "In case the adjustment is performed" in this section when the audio/TC head position is adjusted.

Tools

- Alignment tape ZR2-1: 8-960-073-11
- Oscilloscope

Preparation

1. **Turn the Power Off**
2. **Connect the Oscilloscope**
CH-1: TP815/SS-52 board (CTL PULSE signal)
CH-2: TP2800/SS-52 board (PB LTC signal)
3. **Set the Alignment Tape**
Set the ZR2-1 and put a weight on the cassette so that it does not rise up.

Check


4. **Turn the Power On**
5. **Play Back the Alignment Tape**
Play back the ZR2-1 (00:00 to 15:00).
6. **Check the Audio/TC Head Position**
Check that the positional relationship between the rising edges of CTL and TC signals satisfies the specification.

If the specification is not satisfied, perform steps 7 and later.

* Connection of the Oscilloscope


CH-1: TP815/SS-52 board (CTL PULSE signal)
CH-2: TP2800/SS-52 board (PB LTC signal)

〈SS-52 BOARD, Side A〉



Preparation

* Alignment Tape: ZR2-1 (00:00 to 15:00)



Audio/TC Head Position Check

Adjustment

7. Remove the CL Guide Rail

Remove the two screws, then remove the CL guide rail.

8. Loosen the Screws

Loosen the two fixing screws of the audio/TC head assembly by 1/4 to 1/2 turn.

9. Adjust the Audio/TC Head Position

- (1) Insert a 3 mm flatbladed screwdriver into the notch of the audio/TC head assembly.
- (2) Adjust the audio/TC head assembly position so that the specification is satisfied.

10. Tighten the Screws

Tighten the two screws loosened in step 8.

11. Recheck the Audio/TC Head Position

Refer to steps 5 and 6 in this section.

12. Install the CL Guide Rail

Install the CL guide rail with two screws.

In case the adjustment is performed

13. Check the Audio/TC Head Height

Refer to Section 8-4-6 (For DVW-A510/CA510 or For DVW-510).

14. Check the Audio/TC Head Azimuth


Refer to Section 8-4-7 (For DVW-A510/CA510 or For DVW-510).

15. Check the Audio/TC Head Head-to-tape Contact

Refer to Section 8-4-8 (For DVW-A510/CA510 or For DVW-510).

16. Check the Audio/TC Head Position

Refer to steps 5 and 6 in this section.



Audio/TC Head Position Adjustment

8-4-10. Audio Level Adjustment in REV Mode

For DVW-A510/CA510

Tools

- Alignment tape CR8-1A: 8-960-097-45
- Oscilloscope
- Digital Betacam cassette BCT-D32 (S cassette)
- Adjustment mirror (circular): J-6080-029-A
- Tape guide adjustment driver (MW-261): J-6322-610-A


Preparation

1. **Turn the Power Off**
2. **Connect the Oscilloscope**
CH-1: TP203/AP-28 board (CH-2 PB signal)
3. **Set the Alignment Tape**
Set the CR8-1A and put a weight on the cassette so that it does not rise up.

* Connection of the Oscilloscope

CH-1: TP203/AP-28 board (CH-2 PB signal)

(AP-28 BOARD, Side A)




Preparation (DVW-A510/CA510)

Check

4. **Turn the Power On**
5. **Play Back the Alignment Tape**
Play back the 1 kHz, 0 VU signal portion (8:00 to 10:00) on the CR8-1A.
6. **Check the Audio Output Level**
Check the audio output level A in CH-1.
7. **Put the Unit into the REV × 1 Mode**
8. **Check the Audio Output Level**
Check that the audio output level B in CH-1 satisfies specification 1.

If specification 1 is not satisfied, perform steps 9 and later.

* Alignment Tape: CR8-1A (8:00 to 10:00)



$$\text{Spec.1: } \frac{B}{A} \times 100 \geq 90\%$$

Audio Level Check in REV Mode (DVW-A510/CA510)

Adjustment

9. Adjust the TG-5 (Threading Roller) Height

- (1) Play back the 1 kHz, 0VU signal portion (8:00 to 10:00) on the CR8-1A.
- (2) Put the unit into the REV x 1 mode.
- (3) In case the level increases when portion A of the tape shown in the figure is pressed down, turn the upper flange of TG-5 clockwise using a tape guide adjustment driver.
In case the level increases when portion B is pushed up, turn the upper flange of TG-5 counterclockwise.
- (4) Check the audio output level satisfies specification 1. (Refer to steps 5 through 8.)

If the specification 1 is not satisfied, repeat steps (1) through (4) mentioned above.


10. Check the Tape Running at Drum Exit Side

In the modes below, check that the tape running condition satisfies specification 2.

- (1) PLAY mode
- (2) REV x 10 mode
- (3) REV x 1 mode

If specification 2 is not satisfied, adjust the tape guides height at the drum exit side. (Refer to steps 12 through 14 (at the Drum Exit Side) in Section 8-4-2.)

If the height of the tape guide is adjusted, perform the video tracking check. (Refer to Section 8-4-3.)



Spec. 2: ⑤ LEAD OF DRUM EXIT SIDE

The tape runs without any curl at the lead.

⑥ TG-3 (EXIT GUIDE)

The tape runs in contact with the upper flange.

The tape curl is less than 1/10 of the tape width.

⑦ TG-4

The tape runs in contact with the lower flange.

The tape curl is less than 1/10 of the tape width.

⑧ TG-5 (THREADING ROLLER)

The tape runs without any curl at the upper and lower flanges.

Audio Level Adjustment in REV Mode (DVW-A510/CA510)

For DVW-510**Tools**

- Alignment tape ZR2-1: 8-960-073-11
- Oscilloscope
- Digital Betacam cassette BCT-D32 (S cassette)
- Adjustment mirror (circular): J-6080-029-A
- Tape guide adjustment driver (MW-261): J-6322-610-A


Preparation

1. **Turn the Power Off**
2. **Connect the Oscilloscope**
CH-1: AUDIO OUTPUT CUE connector/
connector panel
or
TP701/CUE-1 board (CUE OUT signal)
3. **Set the Alignment Tape**
Set the ZR2-1 and put a weight on the cassette so that it does not rise up.

Check

4. **Turn the Power On**
5. **Play Back the Alignment Tape**
Play back the 1 kHz, 0 VU signal portion (00:00 to 15:00) on the ZR2-1.
6. **Check the Cue Output Level**
Check the cue output level A.
7. **Put the Unit into the REV × 1 Mode**
8. **Check the Cue Output Level**
Check that the cue output level B satisfies specification 1.

If specification 1 is not satisfied, perform steps 9 and later.

**Audio Level Check in REV Mode (DVW-510)**

Adjustment

9. Adjust the TG-5 (Threading Roller) Height

- (1) Play back the 1 kHz, 0VU signal portion (00:00 to 15:00) on the ZR2-1.
- (2) Put the unit into the REV x 1 mode.
- (3) In case the level increases when portion A of the tape shown in the figure is pressed down, turn the upper flange of TG-5 clockwise using a tape guide adjustment driver.
In case the level increases when portion B is pushed up, turn the upper flange of TG-5 counterclockwise.
- (4) Check the cue output level satisfies specification 1. (Refer to steps 5 through 8.)

If the specification 1 is not satisfied, repeat steps (1) through (4) mentioned above.


10. Check the Tape Running at Drum Exit Side

In the modes below, check that the tape running condition satisfies specification 2.

- (1) PLAY mode
- (2) REV x 10 mode
- (3) REV x 1 mode

If specification 2 is not satisfied, adjust the tape guides height at the drum exit side. (Refer to steps 12 through 14 (at the Drum Exit Side) in Section 8-4-2.)

If the height of the tape guide is adjusted, perform the video tracking check. (Refer to Section 8-4-3.)



Spec. 2: ⑤ LEAD OF DRUM EXIT SIDE

The tape runs without any curl at the lead.

⑥ TG-3 (EXIT GUIDE)

The tape runs in contact with the upper flange.
The tape curl is less than 1/10 of the tape width.

⑦ TG-4


The tape runs in contact with the lower flange.
The tape curl is less than 1/10 of the tape width.

⑧ TG-5 (THREADING ROLLER)

The tape runs without any curl at the upper and lower flanges.

Audio Level Adjustment in REV Mode (DVW-510)

Parts Location of the Tape Running System



8-5. SERVO/DT AND RF ADJUSTMENT

Adjustment of each item is performed by using maintenance mode. Refer to section 5 for how to operate the maintenance mode.

[Equipment]

- Analog Component Signal Generator (TEKTRONIX TSG-300 or equivalent)
- Analog Composite Signal Generator (TEKTRONIX TSG-170A or equivalent)
- Alignment Tape ZR2-1 (Part No. 8-960-073-11)
- Alignment Tape ZR5-1 (Part No. 8-960-073-01)
- Alignment Tape CR5-1B (Part No. 8-960-096-41)

Alignment Tape ZR2-1 (Part No. 8-960-073-11)

Contents

TIME min.:sec.	CTL TRACK	CUE TRACK	VIDEO/AUDIO TRACK
00 : 00 ↑ (7 : 3 PULSE) ↓ 15 : 00	CTL	1 kHz, 0 VU	4 MHz (A CH only)
20 : 00	CTL	12 kHz, 0 VU	A,C CH - 4 MHz B,D CH - 8 MHz
25 : 00	CTL	12 kHz, 0 VU	16 MHz (All CH)
27 : 00	CTL	—	50% FLAT FIELD (All CH)

Alignment Tape CR5-1B (Part No. 8-960-096-41)

Contents

TIME min.:sec.	VIDEO TRACK	AFM	CTL
0 : 00	RF Sweep	No Signal	CTL
2 : 00	60% H Sweep (CTDM)		
5 : 00	Pulse & Bar (CTDM)		
8 : 00	60% Multi Burst		
11 : 00	Pulse & Bar		
14 : 00	75% Color Bars	400 Hz SINE WAVE 25 kHz DEVIATION	
16 : 30		75 kHz DEVIATION	
17 : 00	50% Bowtie & 12.5T	No Signal	
19 : 00	Line 17 Signal		
22 : 00	Quad Phase		
24 : 00	Flat Field		
26 : 00	75% Color Bars with Dropout		
28 : 00	Composite V Sweep with VISC		
30 : 00			

8-5. SERVO/DT AND RF ADJUSTMENT


Alignment Tape ZR5-1 (Part No. 8-960-073-01)

Contents


TIME min.:sec.	CTL	VIDEO	D-AUDIO	CUE	TIME min.:sec.	
00 : 00		Color Bars (100%)	1 kHz -20 dB FS	1 kHz 0 VU	00 : 00	
				Blank	01 : 25	
02 : 00			1 kHz 0 dB FS	1 kHz -20 VU	01 : 30	
				Blank	02 : 25	
				3 kHz -20 VU	02 : 30	
				Blank	02 : 55	
				7 kHz -20 VU	03 : 00	
				Blank	03 : 25	
				10 kHz -20 VU	03 : 30	
				Blank	03 : 55	
04 : 00			-∞ dB FS	12 kHz -20 VU	04 : 00	
				Blank	04 : 25	
				90 Hz -20 VU	04 : 30	
				Blank	04 : 55	
06 : 00			20 Hz -20 dB FS	Repeat		05 : 00
08 : 00			20 kHz -20 dB FS			
10 : 00				10 : 00		
		Ramp	Repeat	Repeat		
20 : 00					20 : 00	

[Switch Setting]


Upper/Lower Control Panel



Sub Control Panel



System Setup Panel



How to operate the maintenance mode

Push ⑧ S300(DIAG/ADJUST 1) (M-1) on the SS-52 board to enter the maintenance mode.

How to enter the next menu:

Press the ⑥ JOG button once. (Enters JOG mode.)
Turn the ⑦ search dial to move the * mark to a desired item.
Press the ③ SET button.

How to exit the current menu or the maintenance mode:

Press the ② MENU button.

How to operate a tape (e.g. PLAY) in the manual adjustment or other items:


Press the ③ SET button to exit the maintenance mode temporarily. (A tape can be operated in this condition.)
Press the ② MENU button to return to the maintenance mode.

How to change the data (adjust the level) manually:

Turn the ⑦ search dial to move the * mark to the item wishing to be adjusted.
Turn the ⑦ search dial while pressing the ⑥ JOG button.

How to save the data:

Turn the ⑦ search dial to move the * mark to "A??: NV-RAM CONTROL".
Press the ③ SET button.
Turn the ⑦ search dial to move the * mark to "SAVE ALL ADJUST DATA".
Press the ③ SET button.



8-5-1. Drum Phase Adjustment


- (1) Prepare the alignment tape ZR2-1 which is cue upped the 00:25:00:00 portion by the time code.
- (2) Press S300 switch on the SS-52 board to enter the maintenance mode.
- (3) Move the * mark to "A0 : SERVO/DT ADJUST" by the search dial.
- (4) Press the SET button to enter "A0 : SERVO/DT ADJUST" mode.

From this time on, operate the menu in the same way.

- (5) Enter "A00-01 : SERVO ADJUST" menu.
- (6) Enter "A011 : RF SWITCHING POS.".
- (7) Select "AUTO" by turning the search dial while pressing the JOG button.
- (8) Insert the alignment tape ZR2-1 as instructed by monitor display and execute the automatic adjustment.
- (9) After adjustment is completed, "ADJUST COMPLETE" is displayed.
- (10) Press the MENU button to return to the SERVO ADJUST display.
- (11) Enter "A012 : NV-RAM CONTROL" menu.
- (12) Select "SAVE SERVO ADJUST DATA".
- (13) After adjustment data are saved in NV-RAM completely, "DATA SAVED" is displayed.
- (14) Press the MENU button several times to return to the operation mode.

Note

When adjustment is incomplete at "A011 : RF SWITCH POS", error message is displayed. As for error message, refer to section 5-7-1. Servo System Adjustment Mode.



8-5-2. Digital DT Adjustment


- (1) Insert the alignment tape ZR5-1.
- (2) Press S300 switch on the SS-52 board to enter the maintenance mode.
- (3) Move the * mark to "A0 : SERVO/DT ADJUST" by the search dial.
- (4) Press the SET button to enter "A0 : SERVO/DT ADJUST" mode.

From this time on, operate the menu in the same way.

- (5) Enter "A02 : DIGITAL DT ADJUST" menu.
- (6) Enter "A021 : DRIVE GAIN".
- (7) Select "Start auto adjust".
- (8) Put the unit into the STILL mode by pressing the JOG button as instructed by monitor display.
- (9) After adjustment is completed, "ADJUST COMPLETE" is displayed.
- (10) Press the MENU button to return to the DIGITAL ADJUST display.
- (11) Enter "A022:HEAD OFFSET LEVEL".
- (12) Select "Start auto adjust".
- (13) Put the unit into the PLAY mode by pressing the PLAY button as instructed by monitor display.
- (14) After adjustment is completed, "ADJUST COMPLETE" is displayed.
- (15) Press the MENU button to return to DIGITAL ADJUST display.
- (16) Enter "A023 : NV-RAM CONTROL".
- (17) Execute "SAVE DIGITAL DT ADJUST".
- (18) After adjustment data are saved in NV-RAM completely, "DATA SAVED" is displayed.
- (19) Press the MENU button several times to return to the operation mode.

Note

When adjustment is incomplete at "A021 : DRIVE GAIN" or "A022 : HEAD OFFSET LEVEL", "ADJUST INCOMPLETE" is displayed. Refer to section 5-2-6. Digital DT System Check.



8-5-3. Analog DT Adjustment


- (1) Insert the alignment tape CR5-1B, and cue up the color bars signal portion (00:14:00:00).
- (2) Press the S300 switch on the SS-52 board to enter the maintenance mode.
- (3) Move the * mark to "A0 : SERVO/DT ADJUST" by the search dial.
- (4) Press the SET button to enter "A0 : SERVO/DT ADJUST".

From this time on, operate the menu in the same way.



- (5) Enter "A03 : ANALOG DT ADJUST" menu.
- (6) Enter "A030 : HEAD OFFSET LEVEL".
- (7) Select "Start auto adjust".
- (8) Put the unit into the PLAY mode by pressing the PLAY button as instructed by monitor display.
- (9) After adjustment is completed, "ADJUST COMPLETE" is displayed.
- (10) Press the MENU button to return to ANALOG DT ADJUST display.
- (11) Enter "A031 : DRIVE GAIN".
- (12) Select "Start auto adjust".
- (13) Set to VAR+3 times speed mode as instructed by monitor display. (Press VAR button on the control panel and turn the search dial clockwise.)
- (14) After adjustment is completed, "ADJUST COMPLETE" is displayed.
- (15) Press the JOG button on the control panel.
- (16) Press the MENU button to return to ANALOG DT ADJUST display.
- (17) Enter "A032 : NV-RAM CONTROL".
- (18) Select "SAVE ANALOG DT DATA".
- (19) After adjustment data are saved in NV-RAM completely, "DATA SAVED" is displayed.

Note


- Never eject the tape until the data saved. If ejecting, re-adjust.
- When adjustment is incomplete at "A030 : HEAD OFFSET LEVEL" or "A031 : DRIVE GAIN", "ADJUST INCOMPLETE" is displayed. Refer to section 5-2-7. Analog DT System Check.



8-5-4. ADV Envelope Level Adjustment (EQ-45 Board suffix No. 15 and later)


Preparations for adjustment	Specifications	Adjustments
- Enter "A19:ADV LEVEL" menu in the "A1:RF ADJUST" mode in the maintenance mode. Step 1 - Connect CH1 and CH2 of the oscilloscope to TP423 and TP103 on the EQ-45 board. - Play back the alignment tape ZR5-1.	Oscilloscope TP423/EQ-45 (*F-1)  A = 800 ± 100 mV	A19:ADV LEVEL Ach LEVEL ↓ Level Adjustment ↓ Cch LEVEL ↓ Level Adjustment TRIG:TP103/EQ-45(C-1)
Step 2 - Connect CH1 and CH2 of the oscilloscope to TP523 and TP103 on the EQ-45 board. - Play back the alignment tape ZR5-1.	Oscilloscope TP523/EQ-45 (*E-1)  A = 800 ± 100 mV	Bch LEVEL ↓ Level Adjustment ↓ Dch LEVEL ↓ Level Adjustment TRIG:TP103/EQ-45(C-1)
Step 3 - Enter "A1F:NV-RAM CONTROL" menu. - Save adjustment data.		A1F:NV-RAM CONTROL SAVE ALL ADJUST DATA

Board suffix No. 15 and later





*: B SIDE

Board suffix No. 15 and later




A SIDE

8-5-4. ADV Envelope Level Adjustment (EQ-45 Board suffix No. 11, 12, 13, 22, 23, 31, 41)


Preparations for adjustment	Specifications	Adjustments
- Enter "A19:ADV LEVEL" menu in the "A1:RF ADJUST" mode in the maintenance mode. Step 1 - Connect CH1 and CH2 of the oscilloscope to TP423 and TP103 on the EQ-45 board. - Play back the alignment tape ZR5-1.	Oscilloscope TP423/EQ-45 (*F-1)(F-3)  ADV AC LEVEL ADV AC SEL A = 800 ± 100 mV	A19:ADV LEVEL Ach LEVEL Level Adjustment Cch LEVEL Level Adjustment TRIG:TP103/EQ-45(C-1)
Step 2 - Connect CH1 and CH2 of the oscilloscope to TP523 and TP104 on the EQ-45 board. - Play back the alignment tape ZR5-1.	Oscilloscope TP523/EQ-45 (*D-1)(D-3)  ADV BD LEVEL ADV BD SEL A = 800 ± 100 mV	Bch LEVEL Level Adjustment Dch LEVEL Level Adjustment TRIG:TP104/EQ-45(C-1)
Step 3 - Enter "A1F:NV-RAM CONTROL" menu. - Save adjustment data.		A1F:NV-RAM CONTROL SAVE ALL ADJUST DATA

Board suffix No. 13, 23, 31, 41



*: B SIDE

Board suffix No. 11, 12, 22




A SIDE

8-5-5. Playback Equalizer Adjustment

- (1) Insert the alignment tape ZR5-1.
- (2) Press S300 switch on the SS-52 board to enter the maintenance mode.
- (3) Move the * mark to "A1 : RF ADJUST" by the search dial.
- (4) Press the SET button to enter "A1 : RF ADJUST" mode.

From this time on, operate the menu in the same way.

- (5) Enter "A12 : ADV EQUALIZER" menu.
- (6) Select "Auto" by turning the search dial while pressing the JOG button.
- (7) Press the SET button to execute the automatic adjustment.
- (8) After adjustment is completed, "Adjust Complete" is displayed.
- (9) Press the MENU button to return to RF ADJUST MODE display.
- (10) Enter "A1F : NV-RAM CONTROL".
- (11) Select "SAVE ALL ADJUST DATA".
- (12) After adjustment data are saved in NV-RAM completely, "Save Complete" is displayed.
- (13) Press the MENU button several times to return to the operation mode.



8-6. ADJUSTMENT AFTER DRUM REPLACEMENT (For DVW-A500/A510/CA510)**[Item List]**

No.	ITEMS	BOARDS	ADJUSTMENTS	NOTES
1	EQ RF (METAL Y)	DM-89	A30: RF GAIN M-Y-A,B	TP101
	(OXIDE Y)	DM-89	A30: RF GAIN O-Y-A,B	TP101
	(METAL C)	DM-89	A30: RF GAIN M-C-A,B	TP301
	(OXIDE C)	DM-89	A30: RF GAIN O-C-A,B	TP301
	DATA SAVE		A3F: NV-RAM CONTROL	
2	DM OMC LIM BAL (METAL Y)	DM-89	RV105, RV106	TP105
	(OXIDE Y)	DM-89	RV107, RV108	TP105
	(METAL C)	DM-89	RV305, RV306	TP305
	(OXIDE C)	DM-89	RV307, RV308	TP305
3	DEMOD LIM BAL (Y)	DM-89	RV502	TP501
	(C)	DM-89	RV702	TP8
4	PB F RESP (METAL Y)	DM-89	A32: EQ1 METAL-Y-A, B	COMPONENT Y
	(OXIDE Y)	DM-89	A32: EQ1 OXIDE-Y-A, B	COMPONENT Y
	(METAL C)	DM-89	A32: EQ1 METAL-C-A, B	COMPONENT R/B
	(OXIDE C)	DM-89	A32: EQ1 OXIDE-C-A, B	COMPONENT R/B
	DATA SAVE		A3F: NV-RAM CONTROL	
5	DM RF (METAL Y)	DM-89	A31: RF LEVEL M-Y-A, B	TP3
	(OXIDE Y)	DM-89	A31: RF LEVEL O-Y-A, B	TP3
	(METAL C)	DM-89	A31: RF LEVEL M-C-A, B	TP7
	(OXIDE C)	DM-89	A31: RF LEVEL O-C-A, B	TP7
	DATA SAVE		A3F: NV-RAM CONTROL	
6	DM RF ENVELOPE CHECK	DM-89	RV205	TP203
		DM-89	RV405	TP403
7	TBC Y/C DELAY (METAL)	TBC-24	RV500	COMPONENT
	(OXIDE)	TBC-24	RV501	COMPONENT
8	Y and C ERROR OFFSET	TBC-24	RV401	COMPOSITE
		TBC-24	RV601	COMPOSITE
9	AFM RF LEVEL	AP-28	RV301	TP401, TP451

[Equipment]

- Oscilloscope (TEKTRONIX 2465B or equivalent)
- Signal Generator
Analog Composite SG (TEKTRONIX TSG-170A or equivalent)
- Spectrum Analyzer
- Waveform/Vector Monitor (TEKTRONIX 1750 or equivalent)
- Component Waveform Monitor (TEKTRONIX WFM300A or equivalent)

- Alignment Tape CR5-2A (part No. 8-960-097-44)

Contents

TIME min. : sec.	VIDEO TRACK
0 : 00	75% Color Bars
3 : 00	60% Multi Barst Y: 0.5, 1.0, 2.0, 3.0, 4.1, 4.5 MHz C: 0.2, 0.5, 1.0, 1.5, 2.0 MHz
6 : 00	50% Bowtie & 12.5T
9 : 00	Pulse & Bar
11 : 00	Quad Phase
13 : 00	C-Monoscope Switching position is shifted.
15 : 00	


- Alignment Tape CR5-1B (part No. 8-960-096-41)

Contents


TIME min.: sec.	VIDEO TRACK	AFM	CTL
0 : 00	RF Sweep	No Signal	CTL
2 : 00	60% H Sweep (CTDM)		
5 : 00	Pulse & Bar (CTDM)		
8 : 00	60% Multi Burst		
11 : 00	Pulse & Bar		
14 : 00	75% Color Bars	400 Hz SINE WAVE 25 kHz DEVIATION	
16 : 30		75 kHz DEVIATION	
17 : 00	50% Bowtie & 12.5T	No Signal	
19 : 00	Line 17 Signal		
22 : 00	Quad Phase		
24 : 00	Flat Field		
26 : 00	75% Color Bars with Dropout		
28 : 00	Composite V Sweep with VISC		
30 : 00			

[Switch Setting]


Upper/Lower Control Panel



Sub Control Panel




System Set-up Panel




[Switch Setting]


Upper/Lower Control Panel



Sub Control Panel



System Set-up Panel



How to operate the maintenance mode

Push ⑧ S300(DIAG/ADJUST 1) (M-1) on the SS-52 board to enter the maintenance mode.

How to enter the next menu:

Press the ⑥ JOG button once. (Enters JOG mode.)
Turn the ⑦ search dial to move the * mark to a desired item.
Press the ③ SET button.

How to exit the current menu or the maintenance mode:

Press the ② MENU button.

How to operate a tape (e.g. PLAY) in the manual adjustment or other items:


Press the ③ SET button to exit the maintenance mode temporarily. (A tape can be operated in this condition.)
Press the ② MENU button to return to the maintenance mode.



How to change the data (adjust the level) manually:

Turn the ⑦ search dial to move the * mark to the item wishing to be adjusted.
Turn the ⑦ search dial while pressing the ⑥ JOG button.


How to save the data:

Turn the ⑦ search dial to move the * mark to "A?F: NV-RAM CONTROL".
Press the ③ SET button.
Turn the ⑦ search dial to move the * mark to "SAVE ALL ADJUST DATA".
Press the ③ SET button.

Preparations for adjustment	Specifications	Adjustments
⑧ ⑦ ③ ⑦ ③ ③ PLAY ② • Enter "A30: EQ VR" menu in the "A3:BETACAM PB ADJUST" in the maintenance mode. Step 1 • Connect CH-1 and CH-2 of the oscilloscope to TP101 and TP4 on the DM-89 board. • Play back the flat field signal portion (24:00-26:00) of the alignment tape CR5-1B.	Oscilloscope TP101/DM-89(F-7)  Center of V period A = 150 ±10 mV p-p	A30: EQ VR RF GAIN METAL-Y-A Level Adjustment RF GAIN METAL-Y-B Level Adjustment TRIG:TP4/DM-89(E-1)
Step 4		↓ MENU
Step 5		A3F: NV-RAM CONTROL SAVE ALL ADJUST DATA SET MENU MENU Press several times.




DM-89 board (A side)



When adjustment is performed, return the settings of the switch to factory settings as shown below.

SWITCH No.		Name	FACTORY SETTING
S101		Y-RF LPF & EQ TEST (Y-RF low-pass filter & equalizer test)	NORMAL POSITION
S102		_____	NORMAL POSITION
S301		C-RF LPF & EQ TEST (C-RF low-pass filter & equalizer test)	NORMAL POSITION
S302		_____	NORMAL POSITION
*S303 Not on the board Suffix No.13 and higher		_____	NORMAL POSITION
S501		NON LINEAR ON/OFF (Non-linear equalization on/off selection)	ON (DEFAULT POSITION)
S901	1	RF ADJUSTING SWITCH	OFF (OPEN)
	2	_____	OFF (OPEN)
	3	_____	OFF (OPEN)
	4	_____	ON (CLOSE)

TBC-23 board (A side)




When adjustment is performed, return the settings of the switch to factory settings as shown below.


SWITCH No.		Name	FACTORY SETTING
S1	1	Y MUTE	OFF (OPEN)
	2	C MUTE	OFF (OPEN)
	3	_____	OFF (OPEN)
	4		
	5	COMB	OFF (OPEN)
	6	TBC TEST	OFF (OPEN)
	7	_____	OFF (OPEN)
	8	VIDEO PHASE	OFF (OPEN)
*S500 On the board Suffix No.13 and higher	1	_____	OFF (OPEN)
	2	_____	OFF (OPEN)
	3	_____	OFF (OPEN)
	4	_____	OFF (OPEN)

[Connection]

Connect some equipments as follows unless otherwise specified.



8-6-1. EQ RF Output Level Adjustment


Preparations for adjustment	Specifications	Adjustments
- Enter "A30: EQ VR" menu in the "A3:BETACAM PB ADJUST" in the maintenance mode. Step 1 - Connect CH-1 and CH-2 of the oscilloscope to TP4 and TP100 (*TP101) on the DM-89 board. - Play back the flat field signal portion (24:00-26:00) of the alignment tape CR5-1B.	Oscilloscope TP100 (*TP101)/DM-89(F-7)  Center of V period A = 380 ± 20 mV p-p (*A = 150 ± 10 mV p-p)	A30: EQ VR RF GAIN METAL-Y-A ↓ Level Adjustment ↓ RF GAIN METAL-Y-B ↓ Level Adjustment TRIG:TP4/DM-89(E-1)

Continues to next page.


Note


*; For suffix No. 11/12 of the DM-89 board

Board suffix No. 13 and later



Board suffix No. 11, 12




Preparations for adjustment	Specifications	Adjustments
Step 2 - Connect CH-1 and CH-2 of the oscilloscope to TP4 and TP100 (*TP101) on the DM-89 board. - Play back the color bars signal portion (0:00-3:00) of the alignment tape CR5-2A.	Oscilloscope TP100 (*TP101)/DM-89(F-7)  Center of V period $A = 250 \pm 20 \text{ mV p-p}$ (*$A = 100 \pm 10 \text{ mV p-p}$)	RF GAIN OXIDE-Y-A ↓ Level Adjustment ↓ RF GAIN OXIDE-Y-B ↓ Level Adjustment TRIG:TP4/DM-89(E-1)


Note


*, For suffix No. 11/12 of the DM-89 board

Board suffix No. 13 and later



Board suffix No. 11, 12




Preparations for adjustment	Specifications	Adjustments
Step 3 - Connect CH-1 and CH-2 of the oscilloscope to TP4 and TP300 (*TP301) on the DM-89 board. - Play back the flat field signal portion (24:00-26:00) of the alignment tape CR5-1B.	Oscilloscope TP300 (*TP301)/DM-89(F-7)  $A = 380 \pm 20 \text{ mV p-p}$ $(*A = 150 \pm 10 \text{ mV p-p})$	RF GAIN METAL-C-A ↓ Level Adjustment ↓ RF GAIN METAL-C-B ↓ Level Adjustment TRIG:TP4/DM-89(E-1)

Note


*, For suffix No. 11/12 of the DM-89 board


Continues to next page.

Board suffix No. 13 and later



Board suffix No. 11, 12




Preparations for adjustment	Specifications	Adjustments
Step 4 - Connect CH-1 and CH-2 of the oscilloscope to TP4 and TP300 (*TP301) on the DM-89 board. - Play back the color bars signal portion (0:00-3:00) of the alignment tape CR5-2A.	Oscilloscope TP300 (*TP301)/DM-89(F-7)  Center of V period $A = 250 \pm 20 \text{ mV p-p}$ $(*A = 100 \pm 10 \text{ mV p-p})$	RF GAIN OXIDE-C-A ↓ Level Adjustment ↓ RF GAIN OXIDE-C-B ↓ Level Adjustment ↓ MENU TRIG:TP4/DM-89(E-1)
Step 5 - Enter "A3F:NV-RAM CONTROL" menu. - Save adjustment data. - Exit the maintenance mode.		A3F: NV-RAM CONTROL SAVE ALL ADJUST DATA ↓ SET ↓ MENU ↓ MENU Press several times.


Note

*; For suffix No. 11/12 of the DM-89 board

Board suffix No. 13 and later




Board suffix No. 11, 12






8-6-2(1). DM OMC Limiter Balance Adjustment



[Connection]


**Note**

In case spectrum analyzer is not available, refer to 8-6-2 (2).


Preparations for adjustment	Specifications	Adjustments
Connect the spectrum analyzer to OUT terminal of the oscilloscope. - Spectrum analyzer setting CENTER FREQ: 10 MHz SPAN: 20 MHz RBW: 100 kHz VBW: 10 kHz SWP TIME: 100 ms Step 1 - Connect CH-1 and CH-2 of the oscilloscope to TP4 and TP105 on the DM-89 board. - Play back the flat field signal portion (24:00-26:00) of the alignment tape CR5-1B.	Spectrum analyzer TP105/DM-89(G-4)  7.6 MHz 15.3 MHz $A \geq 40 \text{ dB}$	(Y OMC LIM BALANCE) ●RV105/DM-89(F-4) ●RV106/DM-89(F-5) TRIG: TP4/DM-89(E-1)
Step 2 - Connect CH-1 and CH-2 of the oscilloscope to TP4 and TP105 on the DM-89 board. - Play back the pulse & bar signal portion (9:00-11:00) of the alignment tape CR5-2A.	Spectrum analyzer TP105/DM-89(C-4)  5.5 MHz 11.0 MHz $A \geq 35 \text{ dB}$	(Y OMC LIM BALANCE) ●RV107/DM-89(F-5) ●RV108/DM-89(F-5) TRIG: TP4/DM-89(E-1)




Preparations for adjustment	Specifications	Adjustments
Step 3 - Connect CH-1 and CH-2 of the oscilloscope to TP5 and TP305 on the DM-89 board. - Play back the flat field signal portion (24:00-26:00) of the alignment tape CR5-1B.	Spectrum analyzer TP305/DM-89(C-4)  5.8 MHz 11.6 MHz $A \geq 40 \text{ dB}$	(C OMC LIM BALANCE) ●RV305/DM-89(F-4) ●RV306/DM-89(F-5) TRIG: TP5/DM-89(D-1)
Step 4 - Connect CH-1 and CH-2 of the oscilloscope to TP5 and TP305 on the DM-89 board. - Play back the pulse & bar signal portion (9:00-11:00) of the alignment tape CR5-2A.	Spectrum analyzer TP305/DM-89(C-4)  4.9 MHz 9.8 MHz $A \geq 35 \text{ dB}$	(C OMC LIM BALANCE) ●RV307/DM-89(F-5) ●RV308/DM-89(F-5) TRIG: TP5/DM-89(D-1)






8-6-2 (2). DM OMC Limiter Balance Adjustment...When Spectrum analyzer is not used.


Preparations for adjustment	Specifications	Adjustments
Set RVs as shown right figure.		Y; - RV105/DM-89(F-4) - RV106/DM-89(F-5) - RV107/DM-89(F-5) - RV108/DM-89(F-5) C; - RV305/DM-89(F-4) - RV306/DM-89(F-5) - RV307/DM-89(F-5) - RV308/DM-89(F-5)




8-6-3. Demodulator Limiter Balance Adjustment



Preparations for adjustment	Specifications	Adjustments
Step 1 - Connect CH-1 and CH-2 of the oscilloscope to TP4 and TP501 on the DM-89 board. - Play back the flat field signal portion (24:00-26:00) of the alignment tape CR5-1B.	Spectrum analyzer TP501/DM-89(F-4)  Maximize the A. (Minimize the fc.)	(Y DEMOD BALANCE) ●RV502/DM-89(E-3) TRIG: TP4/DM-89 (E-1)
In case spectrum analyzer is not available, set RV502 as shown right figure.		





Preparations for adjustment	Specifications	Adjustments
Step 2 - Connect CH-2 of the oscilloscope to TP8 on the DM-89 board. - Play back the color bars signal portion (14:00-16:30) of the alignment tape CR5-1B.	Oscilloscope TP8/DM-89(C-1)  Minimize the moire 20.65µs	(C DEMOD BALANCE) ●RV702/DM-89(A-4)





8-6-4. PB Frequency Response Adjustment


Preparations for adjustment	Specifications	Adjustments
- Enter "A32:DM VR 1" menu in the "A3:BETACAM PB ADJUST" in the maintenance mode. - Connect the waveform monitor or the oscilloscope to COMPONENT Y OUTPUT connector (terminated by 75 Ω). Step 1 - Play back the multi burst signal portion (8:00-11:00) of the alignment tape CR5-1B.	Waveform monitor or oscilloscope COMPONENT Y OUT  (1) 0.5 MHz reference 100% (or 0 dB) 4.1 MHz = 100% (104 through 91%) ($0^{+0.3}_{-0.8}$ dB) (2) Check the levels for following frequencies. 1.0 MHz = 100% (106 through 71%) ($0^{+0.5}_{-3.0}$ dB) 2.0 MHz = 100% (106 through 71%) ($0^{+0.5}_{-3.0}$ dB) 3.0 MHz = 100% (106 through 71%) ($0^{+0.5}_{-3.0}$ dB) 4.5 MHz = 80% (106 through 71%) ($-2.0^{+2.5}_{-1.0}$ dB) (3) Flicker should not be on the monitor picture.	A32:DM VR 1 EQ 1 METAL-Y-A ↓ Level Adjustment ↓ EQ 1 METAL-Y-B ↓ Level Adjustment TRIG:REF.VIDEO
Step 2 Play back the multi burst signal portion (3:00-6:00) of the alignment tape CR5-2A.	Waveform monitor or oscilloscope COMPONENT Y OUT  (1) 0.5 MHz reference 100% (or 0 dB) 2.0 MHz = 100% (104 through 95%) ($0^{+0.3}_{-0.4}$ dB) (2) Check the levels for following frequencies. 1.0 MHz = 100% (106 through 50%) ($0^{+0.5}_{-6.0}$ dB) 3.0 MHz = 90% (106 through 50%) ($-1.0^{+1.5}_{-5.0}$ dB) 4.1 MHz = 70% (106 through 50%) ($-3.0^{+3.5}_{-3.0}$ dB) (3) Flicker should not be on the monitor picture.	EQ 1 OXIDE-Y-A ↓ Level Adjustment ↓ EQ 1 OXIDE-Y-B ↓ Level Adjustment TRIG:REF.VIDEO


Continue to next page.

Preparations for adjustment	Specifications	Adjustments
Step 3 - Connect the waveform monitor or the oscilloscope to COMPONENT R-Y/B-Y OUTPUT connector (terminated by 75 Ω). - Play back the multi burst signal portion (8:00-11:00) of the alignment tape CR5-1B.	Waveform monitor or oscilloscope COMPONENT R-Y/B-Y OUT  (1) R-Y 7T BAR reference 100% (or 0 dB) 1.0 MHz = 95% (100 through 89%) (-0.5 ± 0.5 dB) (2) Check the levels for following frequencies. 0.2 MHz = 100% (106 through 71%) ($0_{-3.0}^{+0.5}$ dB) 0.5 MHz = 100% (106 through 71%) ($0_{-3.0}^{+0.5}$ dB) 1.5 MHz = 80% (106 through 71%) ($-2.0_{-1.0}^{+2.5}$ dB) (3) Check the waveform of B-Y meets the specifications above. If it does not, perform fine adjustments so that both waveforms of R-Y and B-Y meet the specifications.	EQ 1 METAL-C-A ↓ Level Adjustment EQ 1 METAL-C-B ↓ Level Adjustment TRIG:REF.VIDEO
Step 4 Play back the multi burst signal portion (3:00-6:00) of the alignment tape CR5-2A.	Waveform monitor or oscilloscope COMPONENT R-Y/B-Y OUT  (1) R-Y 7T BAR reference 100% (or 0 dB) 1.0 MHz = 95% (100 through 89%) (-0.5 ± 0.5 dB) (2) Check the levels for following frequencies. 0.2 MHz = 100% (106 through 71%) ($0_{-3.0}^{+0.5}$ dB) 0.5 MHz = 95% (106 through 71%) ($-0.4_{-2.6}^{+0.9}$ dB) 1.5 MHz = 80% (106 through 71%) ($-2.0_{-1.0}^{+2.5}$ dB) (3) Check the waveform of B-Y meets the specifications above. If it does not, perform fine adjustments so that both waveforms of R-Y and B-Y meet the specifications.	EQ 1 OXIDE-C-A ↓ Level Adjustment EQ 1 OXIDE-C-B ↓ Level Adjustment ↓ MENU TRIG:REF.VIDEO
Step 5 - Enter "A3F:NV-RAM CONTROL" menu. - Save adjustment data. - Exit the maintenance mode.		A3F:NV-RAM CONTROL SAVE ALL ADJUST DATA SET ↓ MENU ↓ MENU Press several times.


8-6-5. DM RF Output Level Adjustment (For board suffix No. 11, 12)**Note** The adjustment for board suffix No. 13 not necessary.


Preparations for adjustment	Specifications	Adjustments
- Enter "A31:DM VR 0" menu in the "A3:BETACAM PB ADJUST" in the maintenance mode. Step 1 - Connect CH-1 and CH-2 of the oscilloscope to TP3 and TP4 on the DM-89 board. - Play back the flat field signal portion (24:00-26:00) of the alignment tape CR5-1B.	Oscilloscope TP3/DM-89(E-1)  Center of V period $A = 400 \pm 40 \text{ mV p-p}$	A31:DM VR 0 RF LEVEL METAL-Y-A ↓ Level Adjustment ↓ RF LEVEL METAL-Y-B ↓ Level Adjustment TRIG:TP4/DM-89(E-1)
Step 2 - Connect CH-1 and CH-2 of the oscilloscope to TP3 and TP4 on the DM-89 board. - Play back the 75% color bars signal portion (0:00-3:00) of the alignment tape CR5-2A.	Oscilloscope TP3/DM-89(B-7)  Center of V period $A = 400 \pm 40 \text{ mV p-p}$	RF LEVEL OXIDE-Y-A ↓ Level Adjustment ↓ RF LEVEL OXIDE-Y-B ↓ Level Adjustment TRIG:TP4/DM-89(E-21)




Preparations for adjustment	Specifications	Adjustments
Step 3 - Connect CH-1 and CH-2 of the oscilloscope to TP7 and TP4 on the DM-89 board. - Play back the flat field signal portion (24:00-26:00) of the alignment tape CR5-1B.	Oscilloscope TP7/DM-89(D-1)  $A = 400 \pm 40 \text{ mV p-p}$	RF LEVEL METAL-C-A ↓ Level Adjustment ↓ RF LEVEL METAL-C-B ↓ Level Adjustment TRIG:TP4/DM-89(E-1)

Continues to next page.




Preparations for adjustment	Specifications	Adjustments
Step 4 - Connect CH-1 and CH-2 of the oscilloscope to TP7 and TP4 on the DM-89 board. - Play back the 75% color bars signal portion (0:00-3:00) of the alignment tape CR5-2A.	Oscilloscope TP7/DM-89(D-1)  Center of V period $A = 400 \pm 40 \text{ mV p-p}$	RF LEVEL OXIDE-C-A ↓ Level Adjustment ↓ RF LEVEL OXIDE-C-B ↓ Level Adjustment ↓ MENU TRIG:TP4/DM-89(E-1)
Step 5 - Enter "A3F:NV-RAM CONTROL" menu. - Save adjustment data. - Exit the maintenance mode.		A3F:NV-RAM CONTROL SAVE ALL ADJUST DATA SET ↓ MENU ↓ MENU Press several times.




8-6-6. DM RF Envelope Check

Preparations for adjustment	Specifications	Adjustments
Step 1 - Connect CH-1 and CH-2 of the oscilloscope to TP203 and TP4 on the DM-89 board. - Play back the flat field signal portion (24:00-26:00) of the alignment tape CR5-1B.	Oscilloscope TP203/DM-89(G-6)  $A = 2.0 \pm 0.2 \text{ V dc}$	When the specification is not met: RV205/DM-89(G-6) TRIG:TP4/DM-89(E-1)
Step 2 - Connect CH-1 and CH-2 of the oscilloscope to TP403 and TP4 on the DM-89 board. - Play back the flat field signal portion (24:00-26:00) of the alignment tape CR5-1B.	Oscilloscope TP403/DM-89(D-6)  $A = 2.0 \pm 0.2 \text{ V dc}$	When the specification is not met: RV405/DM-89(C-6) TRIG:TP4/DM-89(E-1)


Board suffix No. 13 and later




Board suffix No. 11, 12





8-6-7. TBC Y/C Delay Check

Preparations for adjustment	Specifications	Adjustments
- CAPSTAN LOCK switch/sub control panel: 2FD - Connect the waveform monitor to COMPONENT OUTPUT - CH-1: Y OUTPUT - CH-2: B-Y OUTPUT - CH-3: R-Y OUTPUT Step 1 - Play back the bowtie signal portion (17:00-19:00) of the alignment tape CR5-1B.	COMPONENT WAVEFORM MONITOR: BOWTIE mode COMPONENT OUTPUT  Set the BOWTIE DIP points of (A) and (B) on the center marker. $0 \pm 10 \text{ ns}$	(METAL Y/C DELAY) RV500/TBC-24(B-1) TRIG:EXT/WFM


Continues to next page.




Preparations for adjustment	Specifications	Adjustments
Step 2 Play back the bowtie signal portion (6:00-9:00) of the alignment tape CR5-2A.	COMPONENT WAVEFORM MONITOR: BOWTIE mode COMPONENT OUTPUT  Set the BOWTIE DIP points of (A) and (B) on the center marker. $0 \pm 10 \text{ ns}$	(OXIDE Y/C DELAY) ●RV501/TBC-24(C-1) TRIG:EXT/WFM



8-6-8. Y and C Error Offset Check

Preparations for adjustment	Specifications	Adjustments
• Playback the color bars with drop out signal portion (26:00-28:00) of the alignment tape CR5-1B. • CHARACTER switch/sub control panel:OFF • Connect a picture monitor to VIDEO OUTPUT COMPOSITE 3 connector.	PICTURE MONITOR VIDEO OUTPUT COMPOSITE 3  C DO PORTION → Y DO PORTION → (A) The Y DO portions should disappear on the monitor display by RV401. (B) The C DO portions should disappear on the monitor display by RV601.	(Y ERR CLIP) ●RV401/TBC-24(F-6) (C ERR CLIP) ●RV601/TBC-24(C-6)



SONY MADE IN JAPAN DOLBY

1-848-544-

PB AMP

NR

RV301

RF AMP

FREQ COM

AP-28

DEMOD

TP402

TP451

TP40

TP306

AFM EXPANDER

8-7. ADJUSTMENT AFTER AUDIO/TC HEAD REPLACEMENT**[Item List]**

No.	ITEMS	BOARDS	ADJUSTMENTS	NOTES
1	AUDIO PB FREQ RESPONSE OXIDE	CUE-1 CUE-1	RV106, RV108 RV107, RV110	CH1 CH2
2	AP DOLBY LEVEL	AP-28 AP-28	RV102 RV202	TP102 TP202
3	LAU PB LEVEL	AP-28 AP-28	RV103 RV203	CH1 CH2
4	LAU PB PHASE	AP-28	RV201	CH1, CH2
5	CUE PB FREQ RESPONSE	CUE-1	RV901	CUE
6	CUE PB LEVEL	CUE-1	RV114, RV120	CUE
7	LTC PB LEVEL CHECK	CUE-1	CHECK	TP402

[Equipment]

- Oscilloscope (TEKTRONIX 2465B or equivalent)
- Audio analyzer (TEKTRONIX AA501A-option 02 or equivalent)
Note: Audio analyzer should be filtered through 80 kHz L.P.F unless otherwise specified.
- Audio level meter

- Alignment tape ZR5-1 (part No. 8-960-073-01)

Contents

TIME min.:sec.	CTL	VIDEO	D-AUDIO	CUE	TIME min.:sec.
00 : 00		Color Bars (100%)	1 kHz -20 dB FS	1 kHz 0 VU	00 : 00
02 : 00				Blank	01 : 25
			1 kHz -20 VU	01 : 30	
			Blank	02 : 25	
			3 kHz -20 VU	02 : 30	
			Blank	02 : 55	
			1 kHz 0 dB FS	03 : 00	
			7 kHz -20 VU	03 : 25	
			Blank	03 : 30	
			10 kHz -20 VU	03 : 55	
Blank			04 : 00		
04 : 00			-∞ dB FS	12 kHz -20 VU	04 : 25
				Blank	04 : 30
				90 Hz -20 VU	04 : 55
				Blank	05 : 00
06 : 00			20 Hz -20 dB FS	Repeat	
08 : 00					
10 : 00			20 kHz -20 dB FS	Repeat	
		Ramp	Repeat	Repeat	
20 : 00					

- Alignment tape CR8-1A (part No. 8-960-097-45)

Contents

TIME min.: sec.	AUDIO TRACK	VIDEO TRACK	CTL TRACK
0 : 00	1 kHz, 0 VU *1	—	CTL
2 : 55	Blank		
3 : 00	10 kHz, -10 VU		
4 : 55	Blank	—	CTL
5 : 00	1 kHz, -20 VU		
5 : 55	Blank		
6 : 00	40 Hz, -20 VU*2	—	CTL
6 : 25	Blank		
6 : 30	7 kHz, -20 VU*2		
6 : 55	Blank	—	CTL
7 : 00	10 kHz, -20 VU*2		
7 : 25	Blank		
7 : 30	15 kHz, -20 VU*2	—	CTL
7 : 55	Blank		
8 : 00	1 kHz, 0 VU		
10 : 00	1 kHz, 0 VU	—	1 kHz, 0 VU

- *1. When this tape is reproduced in the audio reference level check or adjustment, the output level (0 dB) should be corrected according to the correction value as follows.

Example: Correction value = -0.5 dB
 Output level = 0 dB - 0.5 dB = -0.5 dB

- *2. When this tape is reproduced in the audio frequency response check or adjustment, the output level should be corrected according to the correction value.


- Alignment tape CR5-1B (part No. 8-960-096-41)

Contents


TIME min.: sec.	VIDEO TRACK	AFM	CTL
0 : 00	RF Sweep	No Signal	CTL
2 : 00	60% H Sweep (CTDM)		
5 : 00	Pulse & Bar (CTDM)		
8 : 00	60% Multi Burst		
11 : 00	Pulse & Bar		
14 : 00	75% Color Bars		
16 : 30		400 Hz SINE WAVE 25 kHz DEVIATION	
17 : 00		75 kHz DEVIATION	
	50% Bowtie & 12.5T	No Signal	
19 : 00	Line 17 Signal		
22 : 00	Quad Phase		
24 : 00	Flat Field		
26 : 00	75% Color Bars with Dropout		
28 : 00	Composite V Sweep with VISC		
30 : 00			


[Switch Setting]

Upper/Lower Control Panel




System Set-up Panel




APR-1 board (Board Suffix No. 16 and higher)**Selecting output level**

Audio Channel	Ref. No.	Output Level (dBm/600 Ω)				Fine Adjustment (Address No.)
		+4	0	-3	-20	
CH1	S1531-1	ON	OFF	OFF	OFF	RV500 (P-5)
	S1531-2	OFF	ON	OFF	OFF	
	S1531-3	OFF	OFF	ON	OFF	
	S1531-4	OFF	OFF	OFF	ON	
CH2	S1533-1	ON	OFF	OFF	OFF	RV501 (M-5)
	S1533-2	OFF	ON	OFF	OFF	
	S1533-3	OFF	OFF	ON	OFF	
	S1533-4	OFF	OFF	OFF	ON	
CH3	S1541-1	ON	OFF	OFF	OFF	RV700 (K-5)
	S1541-2	OFF	ON	OFF	OFF	
	S1541-3	OFF	OFF	ON	OFF	
	S1541-4	OFF	OFF	OFF	ON	
CH4	S1543-1	ON	OFF	OFF	OFF	RV701 (H-5)
	S1543-2	OFF	ON	OFF	OFF	
	S1543-3	OFF	OFF	ON	OFF	
	S1543-4	OFF	OFF	OFF	ON	
MONITOR L-CH	S1552-1	ON	OFF	OFF	OFF	RV901 (F-5)
	S1552-2	OFF	ON	OFF	OFF	
	S1552-3	OFF	OFF	ON	OFF	
	S1552-4	OFF	OFF	OFF	ON	
MONITOR R-CH	S1555-1	ON	OFF	OFF	OFF	RV902 (D-5)
	S1555-2	OFF	ON	OFF	OFF	
	S1555-3	OFF	OFF	ON	OFF	
	S1555-4	OFF	OFF	OFF	ON	
FACTORY SETTING		○				


APR-1 board (Board suffix No. 11, 12, 13, 14, 21, 22, 23, 31, 32, 33)**Selecting output level**

Audio Channel	Ref. No.	Output Level (dBm/600 Ω)				Fine Adjustment (Address No.)
		+4	0	-3	-20	
CH1	SL500 SL501 SL502 R531	OPEN OPEN OPEN MOUNT	SHORT OPEN OPEN NO MOUNT	OPEN SHORT OPEN NO MOUNT	OPEN OPEN SHORT NO MOUNT	RV500 (P-5)
CH2	SL503 SL504 SL505 R532	OPEN OPEN OPEN MOUNT	SHORT OPEN OPEN NO MOUNT	OPEN SHORT OPEN NO MOUNT	OPEN OPEN SHORT NO MOUNT	RV501 (M-5)
CH3	SL700 SL701 SL702 R731	OPEN OPEN OPEN MOUNT	SHORT OPEN OPEN NO MOUNT	OPEN SHORT OPEN NO MOUNT	OPEN OPEN SHORT NO MOUNT	RV700 (K-5)
CH4	SL703 SL704 SL705 R732	OPEN OPEN OPEN MOUNT	SHORT OPEN OPEN NO MOUNT	OPEN SHORT OPEN NO MOUNT	OPEN OPEN SHORT NO MOUNT	RV701 (H-5)
MONITOR L-CH	SL902 SL903 SL904 R1038	OPEN OPEN OPEN MOUNT	SHORT OPEN OPEN NO MOUNT	OPEN SHORT OPEN NO MOUNT	OPEN OPEN SHORT NO MOUNT	RV901 (F-5)
MONITOR R-CH	SL905 SL906 SL907 R1039	OPEN OPEN OPEN MOUNT	SHORT OPEN OPEN NO MOUNT	OPEN SHORT OPEN NO MOUNT	OPEN OPEN SHORT NO MOUNT	RV902 (E-5)
FACTORY SETTING		○				

CUE-1 board



CUE-1 Board (A Side)



CUE-1 Board (B Side)

CUE-1 board, the on-board switch

Switch S101 is not equipped in DVW-500

Switch No.		Name	Description	FACTORY SETTING
S101	1	CH-1 AUDIO HEAD TUNE ADJ. SWITCH	By coupling with RV106 on the CUE-1 board, adjust the CH-1 head amp high frequency response (head vibration). This switch is used in audio head dumping adjustment. If the switch setting is changed when this adjustment is not performed, audio frequency response may be failed.	When the unit is shipped, this switch is set to the position based on the adjustment condition.
	2			
S102	1	CH-2 AUDIO HEAD TUNE ADJ. SWITCH	By coupling with RV107 on the CUE-1 board, adjust the CH-2 head amp high frequency response (head vibration). This switch is used in audio head dumping adjustment. If the switch setting is changed when this adjustment is not performed, audio frequency response may be failed.	When the unit is shipped, this switch is set to the position based on the adjustment condition.
	2			

CUE-1 board, the on-board shorting lands and resistor selection


(* : Component attached on B side)

Selecting output level

Ref. No.	Output Level (dBm/600 Ω)			
	+4	0	-3	-20
SL701 SL702 SL703 R762*	OPEN OPEN OPEN 0 Ω MOUNT	SHORT OPEN OPEN NO MOUNT	OPEN SHORT OPEN NO MOUNT	OPEN OPEN SHORT NO MOUNT
FACTORY SETTING	○			

8-7-1. Audio PB Frequency Response Adjustment (Oxide) (For DVW-A510/CA510)

Preparations for adjustment	Specifications	Adjustments												
Play back the 1 kHz, 40 Hz, 7 kHz, 10 kHz and 15 kHz (−20 VU) signal portions (5:00-8:00) of the alignment tape CR8-1A.	ANALOG AUDIO OUTPUT CH1 and CH2 <table><tr><th>FREQUENCY [Hz]</th><th>OUTPUT LEVEL [dB]</th></tr><tr><td>1 k</td><td>0 (REF)</td></tr><tr><td>40</td><td>0^{+0.7}_{−1.7}</td></tr><tr><td>7 k</td><td>0 ±0.3</td></tr><tr><td>10 k</td><td>0 ±0.3</td></tr><tr><td>15 k</td><td>0 ±0.5</td></tr></table> Note: Correct the output levels by using correction value of the alignment tape.	FREQUENCY [Hz]	OUTPUT LEVEL [dB]	1 k	0 (REF)	40	0 ^{+0.7} _{−1.7}	7 k	0 ±0.3	10 k	0 ±0.3	15 k	0 ±0.5	CH1 15 kHz: ⌚RV106/CUE-1(B-1) 7 kHz: ⌚RV108/CUE-1(A-1) If the specifications are not met, switch S101 and adjust again. CH2 15 kHz: ⌚RV107/CUE-1(C-1) 7 kHz: ⌚RV110/CUE-1(C-2) If the specifications are not met, switch S102 and adjust again.
FREQUENCY [Hz]	OUTPUT LEVEL [dB]													
1 k	0 (REF)													
40	0 ^{+0.7} _{−1.7}													
7 k	0 ±0.3													
10 k	0 ±0.3													
15 k	0 ±0.5													




8-7-2. AP Board Dolby Level Adjustment (For DVW-A510/CA510)

Preparations for adjustment	Specifications	Adjustments
- Extend the AP-28 board by extension board EX-377. - Connect the audio level meter to TP102 or TP202 on the AP-28 board. - Turn on the power, and insert the alignment tape CR8-1A. - Play back the 1 kHz, 0 VU signal portion (0:00-2:55).	TP102/AP-28(A-3) -10.0 ± 0.1 dBu	TP102: ●RV102/AP-28(A-4)
	TP202/AP-28(B-3) -10.0 ± 0.1 dBu	TP202: ●RV202/AP-28(B-4)


8-7-3. LAU PB Level Adjustment (For DVW-A510/CA510)


Preparations for adjustment	Specifications	Adjustments
Play back the 1 kHz, 0 VU signal portion (0:00-2:55) of the alignment tape CR8-1A.	ANALOG AUDIO OUTPUT CH1 and CH2 +4.0 ± 0.1 dBu (terminated by 600 Ω)	CH1: ●RV103/AP-28(A-1) CH2: ●RV203/AP-28(A-1)



8-7-4. LAU PB Phase Adjustment (For DVW-A510/CA510)


NOTE: Before performing this adjustment, section 8-4-7. Audio/TC Head Azimuth Adjustment should be completed.

Preparations for adjustment	Specifications	Adjustments
• Play back the 10 kHz, 0 VU signal portion (3:00-5:00) of the alignment tape CR8-1A. • Observe the lissajous with the oscilloscope.	ANALOG AUDIO OUTPUT CH1 and CH2 (terminated by 600 Ω)  $A \leq 0.52 \text{ cm (5° or less)}$	RV201/AP-28(A-6)




8-7-5. Cue PB Frequency Response Adjustment

Preparations for adjustment	Specifications	Adjustments														
• Play back the 1 kHz, 3 kHz, 7 kHz, 10 kHz, 12 kHz and 90 Hz (−20 VU) signal portions (1:30-4:55) of the alignment tape ZR5-1.	ANALOG AUDIO OUTPUT CUE <table><tr><th>FREQUENCY [Hz]</th><th>OUTPUT LEVEL [dB]</th></tr><tr><td>1 k</td><td>0 (REF)</td></tr><tr><td>3 k</td><td>0 ±0.5</td></tr><tr><td>7 k</td><td>0 ±0.5</td></tr><tr><td>10 k</td><td>0 ±0.5</td></tr><tr><td>12 k</td><td>−0.2 ±0.5</td></tr><tr><td>90</td><td>0 ^{+0.7}_{−1.7}</td></tr></table> Note: Correct output levels by correction value of the alignment tape	FREQUENCY [Hz]	OUTPUT LEVEL [dB]	1 k	0 (REF)	3 k	0 ±0.5	7 k	0 ±0.5	10 k	0 ±0.5	12 k	−0.2 ±0.5	90	0 ^{+0.7} _{−1.7}	●RV901/CUE-1(A-4) As for DVW-510, when the specifications are not met, switch S102 and then perform this adjustment again.
FREQUENCY [Hz]	OUTPUT LEVEL [dB]															
1 k	0 (REF)															
3 k	0 ±0.5															
7 k	0 ±0.5															
10 k	0 ±0.5															
12 k	−0.2 ±0.5															
90	0 ^{+0.7} _{−1.7}															





8-7-6. Cue PB Level Adjustment

Preparations for adjustment	Specifications	Adjustments
Step 1 - Shorten TP101 and E108 on the CUE-1 board with a shorting clip. - Play back the 1 kHz, 0 VU signal portion(0:00-1:25) of the alignment tape ZR5-1.	ANALOG AUDIO OUTPUT CUE 4.0 ± 0.1 dBu (terminated by 600 Ω)	PB LEVEL ADJ ●RV114/CUE-1(C-2)
Step 2 - Disconnect the shorting clip. - Play back the 1 kHz, 0 VU signal portion(0:00-1:25) of the alignment tape ZR5-1.	ANALOG AUDIO OUTPUT CUE 4.0 ± 0.1 dBu (terminated by 600 Ω)	PB REF ADJ ●RV120/CUE-1(A-3)



8-7-7. LTC PB Level Check

Preparations for adjustment	Specifications	Adjustments
Step 1 - Connect the oscilloscope to TP402(X) and E400(G) on the CUE-1 board. - Play back the alignment tape ZR5-1 (any portion is acceptable).	TP402/CUE-1 (F-6)  $A \geq 80 \text{ mV p-p}$	check
Step 2 - REW - REV shuttle $\times 5$ - REV shuttle $\times 1/5$ Play back at upper speed.	TP402/CUE-1 (F-6)  $A \geq 80 \text{ mV p-p}$	check If the specification is not met, clean the head. Nevertheless the specification is not met, perform section 8-4-10. Audio Level Adjustment again. Then, check from section 8-7-1. Audio PB Frequency Response Adjustment again.



SECTION 9

SPARE PARTS

9-1. NOTES ON SPARE PARTS

1. Safety Related Components Warning

Components marked $\triangle$ are critical to safe operation.

Therefore, specified parts should be used in the case of replacement.

2. Standardization of Parts

Some repair parts supplied by Sony differ from those used for the unit. These are because of parts commonality and improvement.

Parts list has the present standardized repair parts.

3. Stock of Parts

Parts marked with "o" at SP(Supply Code) column of the spare parts list may be not stocked. Therefore, the delivery date will be delayed.

4. Tension Spring

(xxT) after a tension spring is shown on the parts list in order to indicate the number of spring turns required for the use.

(Example) TENSION, SPRING (20T):

This spring must be cut at its 20th turn for actual use.




9-2. SPARE PARTS LIST – VTR –


9-2. 補修部品リスト – 本体 –

9-2-1. Index

9-2-1. インデックス

Mark	Item	Title	Page
①	S Reel Table	REEL CHASSIS (S SIDE) BLOCK	9-4
②	RS Table (S)		
③	Reel Shift		
④	T Reel Table	REEL CHASSIS (T SIDE) BLOCK	9-6
⑤	RS Table (T)		
⑥	Head Drum	DRUM AND ROTARY HEAD CLEANER BLOCK	9-8
⑦	Rotary Head Cleaner		
⑧	Tension Regulator	S TENSION REGULATOR BLOCK	9-10
⑨	CTL Head	CTL AND FE HEAD BLOCK	9-12
⑭	Threading Ring	THREADING RING AND PINCH ROLLER BLOCK	9-14
⑮	Pinch Roller		
⑯	AT Head Cleaner		
⑰	AT Head	AT HEAD AND CAPSTAN MOTOR BLOCK	9-16
⑱	Capstan Motor		
⑲	Tape Cleaner		
⑳	Pinch Press	PINCH PRESS AND GEAR BOX BLOCK	9-18
㉑	Gear Box Motor		
㉒	T Tension Regulator	T TENSION REGULATOR BLOCK	9-20
㉓	Cassette Compartment	CASSETTE COMPARTMENT BLOCK	9-22
㉔	Printed Circuit Board	PRINTED CIRCUIT BOARD (BOTTOM SIDE) BLOCK	9-24
㉕	Upper Lid	ORNAMENTAL PANEL BLOCK	9-26
	Bottom Panel		
	Cabinet (right)		
	Cabinet (left)		
㉖	Upper Control Panel	UPPER CONTROL PANEL BLOCK	9-28
㉗	Lower Control Panel	LOWER CONTROL PANEL BLOCK	9-30
㉘	Sub Control Panel	SUB CONTROL PANEL BLOCK	9-32
㉙	Connector Panel	CONNECTOR PANEL BLOCK	9-34
㉚	Power Block		
㉛	Cassette Compartment Stay	CHASSIS BLOCK	9-36
㉜	Mounted Circuit Board	MOUNTED CIRCUIT BOARD BLOCK	9-38







9-2-2. Exploded Views and Mechanical Parts List


9-2-2. 分解図および機構部品リスト

No.	Part No.	SP Description	No.	Part No.	SP Description
1	A-8267-774-E s RM ASSY		29	3-535-532-01 s SPRING, TENSION	
2	A-6741-066-B o BRAKE ASSY		30	3-648-217-00 o SPRING, TENSION	
*A 3	A-8267-701-C s FG ASSY, REEL		31	3-659-324-00 s SPRING, COMPRESSION	
*B	A-8278-310-A s FG ASSY, REEL		32	3-669-596-01 s WASHER (2.3), STOPPER	
4	A-8267-703-J s TABLE (S) BLOCK ASSY, RS		33	3-701-441-01 s WASHER, POLY 4mm DIA., 0.13T	
5	A-8276-619-A o MOUNTED CIRCUIT BOARD, PTC-71		34	3-701-441-11 s WASHER, POLY 4mm DIA., 0.25T	
6	X-3166-024-1 o ARM (A) ASSY, CRANK		35	3-701-441-21 s WASHER, POLY 4mm DIA., 0.50T	
7	X-3166-025-3 s TABLE ASSY, REEL		36	3-701-506-01 s SET SCREW, DOUBLE POINT 3x4	
8	X-3166-060-1 o ARM (B) ASSY, CRANK		37	3-701-507-00 s SET SCREW, DOUBLE POINT M3x5	
*A 9	X-3167-047-1 o BASE ASSY, REEL SHIFT		*A 38	3-717-210-01 s WORM	
10	X-3717-205-1 s LINING ASSY		*A 39	3-717-212-01 o WASHER (B), WORM	
11	1-454-417-31 s SOLENOID, PLUNGER		*A 40	3-717-213-01 o WASHER (A), WORM	
12	1-648-570-11 o PRINTED CIRCUIT BOARD, COM-15		41	3-717-224-01 s WASHER (B), WORM	
13	1-698-152-11 s MOTOR (SVD-1449), DC		42	3-717-230-01 o BRACKET, LIMITER	
14	1-807-683-11 s RESISTOR ELEMENT		43	3-717-231-01 o HOLDER, LIMITER	
*A 15	2-279-715-01 s RIVET, NYLON		44	3-717-266-01 o CAP (S), CG SHAFT	
16	2-280-622-51 o SUPPORT (M3), HEXAGON		45	3-717-398-01 o TABLE, SLIDE	
17	3-171-430-01 o GEAR, CRANK		46	3-717-399-01 s WHEEL, W	
18	3-171-316-01 s GEAR, M		47	3-717-450-02 o ARM, BRAKE RELEASE	
*A 19	3-171-318-01 o BEARING, WORM		48	3-717-625-01 s SPACER	
*A 20	3-171-319-01 o SHAFT, WORM		*A 49	3-729-013-01 s SCREW (P1.4x1.6), WASHER-HEAD	
*A 21	3-171-320-01 o GEAR, DRIVE		50	8-719-939-05 s PHOTO INTERRUPTER GP1S54	
*B	3-603-393-01 o GEAR, SHIFT		52	3-188-108-01 s WASHER, POLY 4mm DIA., 0.05T	
22	3-171-397-02 o HOLDER (S), SHAFT		*A	for S/N 10001 thru. 10745: DWV-A510(UC)	
23	3-171-429-01 o GEAR, LS			for S/N 10001 thru. 10345: DWV-A510(J)	
24	3-171-431-01 s SHAFT, SLIDE			for S/N 10001 thru. 10469: DWV-510(UC)	
25	3-180-687-01 o HOLDER (A), SHAFT			for S/N 10001 thru. 10035: DWV-510(J)	
26	3-180-866-01 o BASE, LS SENSOR		*B	for S/N 10746 and higher: DWV-A510(UC)	
27	3-307-381-00 s SPRING, TENSION			for S/N 10346 and higher: DWV-A510(J)	
28	3-491-247-00 s SPRING, COMPRESSION			for S/N 10470 and higher: DWV-510(UC)	
				for S/N 10036 and higher: DWV-510(J)	







No.	Part No.	SP Description	No.	Part No.	SP Description
101	A-8627-774-E	s RM ASSY	125	3-648-217-00	o SPRING, TENSION
102	A-6741-066-B	o BRAKE ASSY	126	3-669-596-01	s WASHER (2.3), STOPPER
103	A-8267-549-B	o SENSOR ASSY, MC	127	3-701-441-01	s WASHER, POLY 4mm DIA., 0.13T
*A 104	A-8267-701-C	s FG ASSY, REEL	128	3-701-506-01	s SET SCREW, DOUBLE POINT 3x4
*B	A-8278-310-A	s FG ASSY, REEL	129	3-701-507-00	s SET SCREW, DOUBLE POINT M3x5
105	A-8267-702-H	s TABLE (T) BLOCK ASSY, RS	130	3-717-230-01	o BRACKET, LIMITER
106	X-3166-024-1	o ARM (A) ASSY, CRANK	131	3-717-231-01	o HOLDER, LIMITER
107	X-3166-025-3	s TABLE ASSY, REEL	132	3-717-266-01	o CAP (S), CG SHAFT
108	X-3166-060-1	o ARM (B) ASSY, CRANK	133	3-717-398-01	o TABLE, SLIDE
109	X-3717-205-1	s LINING ASSY	134	3-717-450-02	o ARM, BRAKE RELEASE
110	1-454-417-31	s SOLENOID, PLUNGER	135	3-717-625-01	s SPACER
*A 111	1-807-683-11	s RESISTOR ELEMENT	*A 136	3-729-013-01	s SCREW (P1.4x1.6), WASHER-HEAD
*B	1-801-300-11	s RESISTOR ELEMENT, MAGNETIC	138	3-701-441-21	s WASHER, POLY 4mm DIA., 0.50T
*A 112	2-279-715-01	s RIVET, NYLON	139	3-188-108-01	s WASHER, POLY 4mm DIA., 0.05T
114	3-171-428-02	o HOLDER (T), SHAFT	*C 140	3-717-222-01	s CAP (L), CS SHAFT
115	3-171-430-01	o GEAR, CRANK	*A for S/N 10001 thru. 10745: DWV-A510(UC) for S/N 10001 thru. 10345: DWV-A510(J) for S/N 10001 thru. 10469: DWV-510(UC) for S/N 10001 thru. 10035: DWV-510(J)		
116	3-171-431-01	s SHAFT, SLIDE	*B for S/N 10746 and higher: DWV-A510(UC) for S/N 10346 and higher: DWV-A510(J) for S/N 10470 and higher: DWV-510(UC) for S/N 10036 and higher: DWV-510(J)		
117	3-180-756-01	o CAP, MC	*C for S/N 11154 and higher: DWV-A510(UC) for S/N 10565 and higher: DWV-A510(J) for S/N 10638 and higher: DWV-510(UC) for S/N 10100 and higher: DWV-510(J) for S/N 10016 and higher: DWV-CA510(UC) for S/N 10002 and higher: DWV-CA510(J)		
118	3-180-757-01	o PIN (1), MC			
119	3-180-758-01	o PIN (2), MC			
120	3-180-759-01	o HOLDER, MC			
121	3-307-381-00	s SPRING, TENSION			
122	3-491-247-00	s SPRING, COMPRESSION			
123	3-554-202-00	o SPRING, COMPRESSION			
124	3-535-532-01	s SPRING, TENSION			
125	3-648-217-00	o SPRING, TENSION			
126	3-669-596-01	s WASHER (2.3), STOPPER			
127	3-701-441-01	s WASHER, POLY 4mm DIA., 0.13T			
128	3-701-506-01	s SET SCREW, DOUBLE POINT 3x4			
129	3-701-507-00	s SET SCREW, DOUBLE POINT M3x5			



No.	Part No.	SP Description	No.	Part No.	SP Description
201	A-8260-746-D s INNER DRUM ASSY, DJR-05A-R (for DWM-A510/CA510)		214	3-180-730-01 o PLATE, STOPPER (for S/N 10001 thru. 10250: DWM-A510(UC)) (for S/N 10001 thru. 10070: DWM-A510(J)) (for S/N 10001 thru. 10074: DWM-510(UC)) (for S/N 10001 thru. 10020: DWM-510(J))	
202	A-8260-748-D s INNER DRUM ASSY, DJR-07A-R (for DWM-510)				
203	A-8260-742-D s DRUM ASSY, DJH-05A-R (for DWM-A510/CA510)				
	A-8260-744-D s DRUM ASSY, DJH-07A-R (for DWM-510)				
	A-8267-391-D s COVER ASSY, DRUM, UPPER				
*A 204	A-8267-398-H s CLEANER ASSY, VIDEO HEAD		215	3-307-378-00 s SPRING, TENSION	
*B 205	A-8320-545-A s CLEANER (B) ASSY, VIDEO HEAD		216	3-642-490-00 s SPRING, TENSION	
	A-8267-571-A s SR13 ASSY (RP), BRUSH (for DWM-A510/CA510)		217	3-703-074-01 s CAP 3, SHAFT	
	A-8267-572-A s SR9 ASSY (RP), BRUSH (for DWM-510)		218	3-899-249-11 s BOLT, HEXAGON SOCKET	
	X-3167-280-3 s CLEANER SUB ASSY, VIDEO (for S/N 10251 and higher: DWM-A510(UC)) (for S/N 10071 and higher: DWM-A510(J)) (for S/N 10075 and higher: DWM-510(UC)) (for S/N 10021 and higher: DWM-510(J)) (for S/N 10001 and higher: DWM-CAS10(UC)) (for S/N 10001 and higher: DWM-CA510(J))		219	3-182-488-02 s SCREW, FITTING, UD	
206	X-3167-280-2 s CLEANER SUB ASSY, VIDEO (for S/N 10251 and higher: DWM-A510(UC)) (for S/N 10001 thru. 10250: DWM-A510(UC)) (for S/N 10001 thru. 10070: DWM-A510(J)) (for S/N 10001 thru. 10074: DWM-510(UC)) (for S/N 10001 thru. 10020: DWM-510(J))		221	3-182-648-02 s CAP	
	X-3167-045-3 o BASE ASSY, V CLEANER		222	3-182-649-01 s FILTER	
207	1-454-607-11 s SOLENOID, PLUNGER		223	3-183-901-01 s WASHER, CL	
208	3-180-112-02 o BRACKET, TAPE		224	3-183-902-01 o STOPPER, CL (for S/N 10001 thru. 10250: DWM-A510(UC)) (for S/N 10001 thru. 10070: DWM-A510(J)) (for S/N 10001 thru. 10074: DWM-510(UC)) (for S/N 10001 thru. 10020: DWM-510(J))	
209	3-180-163-01 s SCREW (2x16)				
210	3-180-164-01 s SPRING, FITTING, UD		225	3-183-903-01 o CASE, VH SHIELD	
211	3-180-729-02 o LEVER, V CLEANER (for S/N 10251 and higher: DWM-A510(UC)) (for S/N 10071 and higher: DWM-A510(J)) (for S/N 10075 and higher: DWM-510(UC)) (for S/N 10021 and higher: DWM-510(J)) (for S/N 10001 and higher: DWM-CA510(UC)) (for S/N 10001 and higher: DWM-CA510(J))		226	A-8314-518-A s HEAD ASSY, DEMAGNETIZATION	
	3-180-729-01 o LEVER, V CLEANER (for S/N 10001 thru. 10250: DWM-A510(UC)) (for S/N 10001 thru. 10070: DWM-A510(J)) (for S/N 10001 thru. 10074: DWM-510(UC)) (for S/N 10001 thru. 10020: DWM-510(J))		227	3-671-150-01 o CLAMP	
213			228	X-3167-281-3 s ROLLER ASSY, V CLEANING	
			229	3-182-765-02 s SPACER, CR	
			230	3-190-056-01 s LABEL, HOURS	
			*B 231	A-8320-546-A s ROLLER (B) ASSY (RP), V CLEANING	
			*B 232	3-615-958-01 s LABEL 5, SELF	
			*A	for S/N 10001 thru. 11253: DWM-A510(UC) for S/N 10001 thru. 10624: DWM-A510(J) for S/N 10001 thru. 10642: DWM-510(UC) for S/N 10001 thru. 10100: DWM-510(J)	
			*B	for S/N 11254 and higher: DWM-A510(UC) for S/N 10625 and higher: DWM-A510(J) for S/N 10643 and higher: DWM-510(UC) for S/N 10101 and higher: DWM-510(J)	







No.	Part No.	SP Description
301	A-8267-795-E	s TENSION REGULATOR ASSY (RP)

SテンションレギュレータASSYの構成部品の交換は、厳密な調整を必要とするため、組立品で交換してください。


If the component parts of the S tension regulator assembly are needed to replace, replace as a whole assembled parts instead of as a component part because of the strict adjustment is required.

302	X-3168-229-1	o PLATE (S) ASSY
303	3-701-506-01	s SET SCREW, DOUBLE POINT 3x4







No.	Part No.	SP Description
403	A-8267-554-B s	TG-2 ASSY
404	X-3167-044-2 o	BASE ASSY, CTL/FE (for S/N 10721 and higher: DVM-A510P(EK)) (for S/N 10257 and higher: DVM-A510(UC)) (for S/N 10101 and higher: DVM-A510(J)) (for S/N 10251 and higher: DVM-510P(EK)) (for S/N 10098 and higher: DVM-510(UC)) (for S/N 10021 and higher: DVM-510(J)) (for S/N 10051 and higher: DVM-CA510P(EK)) (for S/N 10010 and higher: DVM-CA510(UC)) (for S/N 10001 and higher: DVM-CA510(J))
	X-3167-044-1 o	BASE ASSY, CTL/FE (for S/N 10001 thru. 10720: DVM-A510P(EK)) (for S/N 10001 thru. 10256: DVM-A510(UC)) (for S/N 10001 thru. 10100: DVM-A510(J)) (for S/N 10001 thru. 10250: DVM-510P(EK)) (for S/N 10001 thru. 10097: DVM-510(UC)) (for S/N 10001 thru. 10020: DVM-510(J)) (for S/N 10001 thru. 10050: DVM-CA510P(EK)) (for S/N 10001 thru. 10009: DVM-CA510(UC))
405	X-3167-056-1 s	ROLLER ASSY, GUIDE
408	2-203-519-21 s	NUT (A), LOCK, PIVOT
410	3-180-665-02 o	FLANGE (L), UPPER
411	3-180-725-01 s	SPRING, CTL/FE
412	3-180-726-02 o	BRACKET, CTL/FE (for S/N 10721 and higher: DVM-A510P(EK)) (for S/N 10257 and higher: DVM-A510(UC)) (for S/N 10101 and higher: DVM-A510(J)) (for S/N 10251 and higher: DVM-510P(EK)) (for S/N 10098 and higher: DVM-510(UC)) (for S/N 10021 and higher: DVM-510(J)) (for S/N 10051 and higher: DVM-CA510P(EK)) (for S/N 10010 and higher: DVM-CA510(UC)) (for S/N 10001 and higher: DVM-CA510(J))
	3-180-726-01 o	BRACKET, CTL/FE (for S/N 10001 thru. 10720: DVM-A510P(EK)) (for S/N 10001 thru. 10256: DVM-A510(UC)) (for S/N 10001 thru. 10100: DVM-A510(J)) (for S/N 10001 thru. 10250: DVM-510P(EK)) (for S/N 10001 thru. 10097: DVM-510(UC)) (for S/N 10001 thru. 10020: DVM-510(J)) (for S/N 10001 thru. 10050: DVM-CA510P(EK)) (for S/N 10001 thru. 10009: DVM-CA510(UC))
417	3-181-489-01 s	FLANGE, DIA. 8
418	3-181-834-01 o	PULLEY, ME
419	3-181-839-01 o	WIRE, STAINLESS
420	3-563-104-00 s	SPRING, TENSION
421	3-657-842-11 o	SPACER (3x7)
422	3-661-588-01 s	SPACER (3x5)
423	3-701-788-XX s	SPRING, TENSION (27T)
426	3-738-730-01 s	SPRING, COMPRESSION
428	4-869-230-00 s	SPRING, COMPRESSION
431	8-825-554-84 s	HEAD, CTL, FS244-21B
433	X-3167-257-1 o	IDLER ASSY, ME
434	1-506-481-11 o	PIN, CONNECTOR 2P
437	A-8267-860-B o	HEAD ASSY, CTL
438	3-740-546-31 s	SCREW (M2x12)




THREADING RING AND PINCH ROLLER BLOCK





No.	Part No.	SP Description
501	A-8267-395-F	s RING ASSY, THREADING
502	X-3167-052-2	s ROLLER ASSY, ONEBARE
503	X-3167-053-2	s ARM ASSY, CL
504	X-3167-054-4	s ARM ASSY, PINCH
505	3-180-676-01	s SHAFT, (B) RING ROLLER
506	3-180-677-01	s ROLLER, RING
507	3-180-678-01	s SHAFT, RING ROLLER
508	3-180-679-01	s ROLLER, (B) RING
509	3-180-681-01	s ROLLER (C) RING
510	3-180-772-01	s SPRING (RG), PLATE
511	3-180-773-02	s FLANGE, ONEBARE USE
512	3-180-774-03	s FLANGE, TG5 (UPPER)
513	3-180-849-01	s SPRING (C), TORSION
514	3-180-850-01	s ARM, LOCK
515	3-180-853-01	s GUARD, PINCH ARM
516	3-180-874-02	s RAIL, CL GUIDE
517	3-669-596-01	s WASHER (2.3), STOPPER
518	3-676-327-01	s SPRING, COMPRESSION
519	3-701-439-11	s WASHER, POLY 3mm DIA., 0.25T
	3-701-439-01	s WASHER, POLY 3mm DIA., 0.13T
520	3-714-587-01	o SPRING, LEAF
521	3-739-736-02	o BASE, SPRING
522	4-879-563-00	s SPRING, COMPRESSION
523	3-701-439-21	s WASHER, POLY 3mm DIA., 0.50T







No.	Part No.	SP Description
601	A-8267-394-C	s TG-3 ASSY
602	A-8267-422-B	o HEAD ASSY, AT
603	X-3167-049-3	s GUIDE ASSY, TG-0
604	X-3167-057-1	o PLATE, ADJUSTMENT ASSY, AT
605	X-3167-061-2	o BRACKET ASSY, AT
606	X-3167-142-2	o PLATE, SHIELD ASSY, AT
607	X-3167-203-4	o CLEANER ASSY, TWIN TAPE
608	1-698-179-12	s MOTOR, DC (CAPSTAN)
609	2-279-715-01	s RIVET, NYLON
610	3-180-403-01	o HOLDER, SENSOR
611	3-180-669-02	s FLANGE, FIXED GUIDE USE
612	3-180-670-01	o NUT, FIXED GUIDE ADJUSTMENT
613	3-180-826-01	o GOOSENECK PLATE
614	3-183-829-04	o CASE, SHIELD AT
615	3-181-489-01	s FLANGE, DIA. 8
616	3-181-491-01	o SLEEVE, DIA. 6
617	3-181-979-01	o SPRING, COMPRESSION
618	3-181-980-01	o SPACER, AT
619	3-738-730-01	s SPRING, COMPRESSION
620	8-825-778-23	s HEAD, AUDIO EPS244-2103G
621	1-543-316-31	s HEAD, SENSING (SMALL TYPE)
622	3-180-869-04	s PLATE, (S)
623	3-183-823-01	o BRACKET, GUIDE RETAINER
624	3-669-316-01	s SPRING, COMPRESSION






No.	Part No.	SP Description
701	A-6749-117-C	o PRESS ASSY, PINCH
702	A-8267-424-A	s BOX ASSY, GEAR
703	1-454-338-11	s SOLENOID, PLUNGER
704	1-622-596-11	o PRINTED CIRCUIT BOARD, PD-35
705	1-648-570-11	o PRINTED CIRCUIT BOARD, CCM-15
706	1-698-152-11	s MOTOR (SVD-1449), DC
707	3-180-717-01	s GEAR, RING
708	3-180-718-01	s GEAR, DRIVE
709	3-180-719-01	s GEAR, WORM
710	3-180-720-01	o GUARD, WORM
711	3-180-843-02	o SHAFT, WORM
712	3-180-844-01	s GEAR, (M)
713	3-180-845-01	s GEAR, (B)
714	3-653-382-01	o SPACER (4x25)
715	3-659-324-00	s SPRING, COMPRESSION
716	3-669-596-01	s WASHER (2.3), STOPPER
718	3-701-441-21	s WASHER, POLY 4mm DIA., 0.50T
719	3-701-788-XX	s SPRING, TENSION (12T)
720	3-703-074-01	s CAP 3, SHAFT
721	3-717-246-01	o LEVER, PRESS, P
722	3-717-247-01	o LIMITER, P
723	3-717-248-01	o SPRING
724	3-717-249-01	o STOPPER, P
725	3-717-250-02	o SHAFT, JOINT, P
726	1-640-163-12	o PRINTED CIRCUIT BOARD, PTC-54







No.	Part No.	SP Description	No.	Part No.	SP Description
801	A-8274-876-C	s DRAWER ASSY, T	821	3-645-028-00	s BEARING, BALL
802	A-8267-423-C	s T-TEN ASSY	822	3-669-596-01	s WASHER (2.3), STOPPER
803	A-8267-555-D	s TG-4 ASSY	823	3-701-439-01	s WASHER, POLY 3mm DIA., 0.13T
804	A-8276-628-A	o MOUNTED CIRCUIT BOARD, TR-79		3-701-439-11	s WASHER, POLY 3mm DIA., 0.25T
805	X-3678-288-2	s GUIDE ASSY, SLANT		3-701-439-21	s WASHER, POLY 3mm DIA., 0.50T
806	X-3167-063-4	s ARM ASSY, DRAWING, T	824	3-701-439-21	s WASHER, POLY 3mm DIA., 0.50T
807	X-3167-064-5	s ARM ASSY, T TEN	825	3-717-253-01	s ROLLER
808	2-279-715-01	s RIVET, NYLON	826	3-738-730-01	s SPRING, COMPRESSION
809	3-180-262-01	s SPRING, TENSION	827	1-543-316-31	s HEAD, SENSING (SMALL TYPE)
810	3-180-404-02	o BASE, DRAWING, T	828	X-3167-347-2	s ROLLER ASSY, GUIDE
811	3-180-669-02	s FLANGE, FIXED GUIDE USE	829	3-183-460-02	s FLANGE (B), UPPER
812	3-180-670-01	o NUT, FIXED GUIDE ADJUSTMENT	830	3-183-462-02	s FLANGE, LOWER
813	3-180-708-01	s PLATE, SLANT GUIDE ADJUSTMENT	831	4-879-563-00	s SPRING, COMPRESSION
814	3-180-710-03	s GUARD, DRAWER	832	X-3167-052-2	s ROLLER ASSY, ONEBARE
815	3-180-715-01	s SPRING, (A) TORSION COIL			
816	3-180-716-02	s SPRING, (B) TORSION COIL			
817	3-180-861-01	o HOLDER, DME			
818	3-180-863-03	s BASE, SLANT GUIDE			
819	3-190-819-01	s FLANGE, DIA. 8			
820	3-181-490-01	o SLEEVE, DIA. 7			




9-22





No.	Part No.	SP Description	No.	Part No.	SP Description
901	A-8267-589-F	s CASSETTE COMPARTMENT ASSY	957	3-701-443-21	s WASHER, POLY 5mm DIA., 0.50T
902	A-8276-625-A	o MOUNTED CIRCUIT BOARD, PC-70			(for S/N 10001 thru. 12891: DWV-A500P(EK))
903	A-8276-626-B	o MOUNTED CIRCUIT BOARD, CL-29			(for S/N 10001 thru. 10054: DWV-A500P(UC))
904	A-8276-627-A	o MOUNTED CIRCUIT BOARD, LP-81			(for S/N 10001 thru. 11700: DWV-500P(EK))
905	A-8276-957-B	s STAGE ASSY			(for S/N 10001 thru. 10030: DWV-500P(UC))
					(for S/N 10001 thru. 11950: DWV-A500(UC))
907	X-3167-849-1	o DECK (L) ASSY, PULLEY			(for S/N 10001 thru. 11019: DWV-500(UC))
908	X-3167-848-1	o DECK (R) ASSY, PULLEY			(for S/N 10001 thru. 10620: DWV-A500(J))
909	X-3167-447-3	o SLIDER (R) ASSY			(for S/N 10001 thru. 10100: DWV-500(J))
910	X-3167-446-3	o SLIDER (L) ASSY			(for S/N 10001 thru. 11109: DWV-A510P(EK))
911	X-3166-217-1	s MIRROR ASSY			(for S/N 10001 thru. 10340: DWV-510P(EK))
					(for S/N 10001 thru. 10474: DWV-A510(UC))
912	1-655-836-11	s PC BOARD, CI-41 FLEXIBLE			(for S/N 10001 thru. 10139: DWV-510(UC))
913	3-188-745-01	s BEARING, BALL, (NO FLANGE)			(for S/N 10001 thru. 10185: DWV-A510(J))
914	3-171-367-06	o SWITCH (R), IN			(for S/N 10001 thru. 10030: DWV-510(J))
915	3-171-398-05	o SWITCH (L), IN			
916	3-171-399-02	o GUIDE (R), CASSETTE	958	3-712-786-01	s DAMPER, OIL
			959	3-717-369-04	o STOPPER, DOOR
917	3-171-400-04	o GUIDE (L), CASSETTE	960	4-858-799-00	s SPRING, TENSION
919	3-171-418-03	s WORM	961	1-698-152-11	s MOTOR, DC (SVD-1449)
920	3-171-419-11	s WHEEL	962	3-182-706-01	s SPACER
921	3-171-420-04	o SHUTTER			
922	3-171-421-01	o SLIDER, DOOR SWITCHING	963	3-171-459-01	s ROLLER, GUIDE
					(for S/N 10001 thru. 12891: DWV-A500P(EK))
923	3-171-422-01	o LEVER, DOOR SWITCHING			(for S/N 10001 thru. 10054: DWV-A500P(UC))
924	3-171-423-02	o JOINT, MOTOR			(for S/N 10001 thru. 11700: DWV-500P(EK))
925	3-171-424-02	o HOLDER, SENSOR			(for S/N 10001 thru. 10030: DWV-500P(UC))
926	3-171-457-03	o SHAFT, JOINT			(for S/N 10001 thru. 11950: DWV-A500(UC))
927	3-171-458-01	s BELT, TIMING			(for S/N 10001 thru. 11019: DWV-500(UC))
					(for S/N 10001 thru. 10620: DWV-A500(J))
928	3-171-459-01	s ROLLER, GUIDE			(for S/N 10001 thru. 10100: DWV-500(J))
929	3-171-460-01	s ROLLER, SLIDER			(for S/N 10001 thru. 11109: DWV-A510P(EK))
930	3-171-461-04	o SHAFT, RETAINER, L CASSETTE			(for S/N 10001 thru. 10340: DWV-510P(EK))
934	3-171-465-01	o GEAR, DRIVING			(for S/N 10001 thru. 10474: DWV-A510(UC))
935	3-171-466-02	o GEAR, LIMITER			(for S/N 10001 thru. 10139: DWV-510(UC))
					(for S/N 10001 thru. 10185: DWV-A510(J))
936	3-171-479-01	o GEAR, MIDWAY			(for S/N 10001 thru. 10030: DWV-510(J))
937	3-171-480-01	o SHAFT, WORM WHEEL	3-188-273-01	s ROLLER (B), GUIDE	
938	3-171-508-04	o HOLDER, LAMP			(for S/N 12892 and higher: DWV-A500P(EK))
939	3-171-510-02	s DOOR, CASSETTE			(for S/N 10055 and higher: DWV-A500P(UC))
					(for S/N 11701 and higher: DWV-500P(EK))
					(for S/N 10031 and higher: DWV-500P(UC))
941	3-176-139-01	s SPRING, C GUIDE			(for S/N 11951 and higher: DWV-500(UC))
942	3-194-680-01	s SPRING, TENSION			(for S/N 11020 and higher: DWV-500(UC))
944	3-176-583-01	o PULLEY (A)			(for S/N 10621 and higher: DWV-A500(J))
					(for S/N 10101 and higher: DWV-500(J))
					(for S/N 11110 and higher: DWV-A510P(EK))
946	3-176-584-01	o PULLEY (B)			(for S/N 10341 and higher: DWV-510P(EK))
					(for S/N 10475 and higher: DWV-A510(UC))
947	3-181-430-01	o WHEEL, WORM			(for S/N 10140 and higher: DWV-510(UC))
948	3-181-431-01	o RUBBER, LIMITER			(for S/N 10186 and higher: DWV-A510(J))
949	3-548-757-00	s SPRING, TENSION			(for S/N 10031 and higher: DWV-510(J))
950	3-579-759-00	s SPRING, COMPRESSION			
951	3-646-214-00	s SPRING			
			964	X-3167-848-1	o DECK (R) ASSY, PULLEY
952	3-671-150-01	o CLAMP	965	X-3167-849-1	o DECK (L) ASSY, PULLEY
953	3-672-461-00	s SPRING, TENSION	966	3-190-575-01	s SPRING, TENSION
954	3-677-193-00	o PIN, STOPPER	967	X-3168-049-1	s LEAF SPRING (R) ASSY
955	3-698-217-11	s BEARING (NO FLANGE), BALL	968	X-3168-050-1	s LEAF SPRING (L) ASSY
956	3-701-441-21	s WASHER, POLY 4mm DIA., 0.50T	969	3-531-576-11	s RIVET







No.	Part No.	SP Description
1001	A-8275-166-A	o MOUNTED CIRCUIT BOARD, DT-34
1002	A-8313-031-A	o MOUNTED CIRCUIT BOARD, DR-307 (for S/N 11584 and higher: DW-AS10(UC)) (for S/N 10763 and higher: DW-510(UC)) (for S/N 10685 and higher: DW-AS10(J)) (for S/N 10101 and higher: DW-510(J)) (for S/N 10016 and higher: DW-CA510(UC)) (for S/N 10002 and higher: DW-CA510(J))
	A-8275-167-B	o MOUNTED CIRCUIT BOARD, DR-200N (for S/N 10001 thru. 11583: DW-AS10(UC)) (for S/N 10001 thru. 10762: DW-510(UC)) (for S/N 10001 thru. 10684: DW-AS10(J)) (for S/N 10001 thru. 10100: DW-510(J)) (for S/N 10001 thru. 10015: DW-CA510(UC)) (for S/N 10001: DW-CA510(J))
1003	A-8276-781-B	o MOUNTED CIRCUIT BOARD, HN-181B
1004	A-8276-621-A	o MOUNTED CIRCUIT BOARD, HN-184
1005	A-8276-623-B	o MOUNTED CIRCUIT BOARD, HN-185
1006	3-180-680-01	o BRACKET, HANDLE (B), HN
1007	3-180-760-01	o SUPPORT, DR
1008	3-180-762-02	o COVER (A), DT SHIELD
1009	3-180-763-02	o COVER (B), DT SHIELD
1010	3-180-819-02	o BRACKET, DEW SENSOR
1011	3-180-852-01	o BRACKET, TRANSISTOR
1013	3-180-873-06	o SHEET, INSULATING (DR)
1014	3-180-886-02	o HEAT SINK (DR)
1015	3-181-651-01	o COVER (RS), HARNESS
1016	3-531-576-11	s RIVET
1017	3-531-576-21	s RIVET
1018	3-646-084-00	o CAP, REINFORCEMENT
1019	3-646-086-00	o HOLDER, ROD
1020	3-703-141-00	o HOLDER, PRINTED CIRCUIT BOARD
1021	3-703-249-01	s SCREW, PTTWH 3x6







No.	Part No.	SP Description
1101	A-8267-397-A	o LID ASSY, ASSY
1102	X-3642-018-3	o HANDLE ASSY
1103	3-171-369-01	o LID (A), UPPER, AIR GUARD
1104	3-171-410-01	o RETAINER (S), PC BOARD
1105	3-171-489-01	o BRACKET, PLATE, BOTTOM
1106	3-171-533-04	o CABINET (RIGHT)
1107	3-171-534-04	o CABINET (LEFT)
1108	X-3167-285-1	o PLATE ASSY, BOTTOM
1109	3-180-641-01	o PLATE (L), PC BOARD RETAINER
1110	3-180-642-01	o PLATE (S), PC BOARD RETAINER
1111	3-180-643-01	o CUSHION, PC BOARD RETAINER
1112	3-688-102-01	o SPACER, M4
1113	3-703-848-01	o LABEL (N), SUB CAUTION
1114	3-717-392-01	o SCREW, LID
1115	3-733-690-01	s +B 4X6 (CU,NI)







No.	Part No.	SP Description	No.	Part No.	SP Description
1201	A-8267-321-C	o GUIDE ASSY, SC	1223	3-688-814-01	s CAP, SWITCH
1202	A-8275-075-A	o MOUNTED CIRCUIT BOARD, VR-153	1224	3-701-441-21	s WASHER, POLY 4mm DIA., 0.50T
1203	A-8275-210-A	o MOUNTED CIRCUIT BOARD, SMC-17B	1225	3-703-141-00	o HOLDER, PRINTED CIRCUIT BOARD
1204	A-8275-077-B	o MOUNTED CIRCUIT BOARD, FP-58	1226	3-717-614-01	o LABEL, C-LOCK OUT
1205	A-8275-213-A	o MOUNTED CIRCUIT BOARD, VR-152B	1227	3-717-615-01	o SPRING
1206	X-3167-825-1	o KNOB ASSY (P), VOL	1228	3-717-616-01	o SPRING
1208	X-3167-167-5	o SUB ASSY, FRONT PANEL	1229	3-717-617-01	o SHAFT, SC GUIDE
1209	1-517-185-32	s INDICATOR MODULE, FLUORESCENT	1230	3-717-618-01	o GUIDE (LEFT), SC
1210	Δ 1-762-953-11	s SWITCH, POWER	1231	3-717-619-02	o GUIDE (RIGHT), SC
1211	3-611-769-01	s SPRING, COMPRESSION	1232	3-717-620-01	o PLATE, OUT, C-LOCK
1212	2-269-962-00	o COVER, SWITCH	1233	4-314-320-00	o HOLDER, WIRE
1213	3-180-747-01	o GUARD (S), AIR	1234	4-874-187-01	o CLIP, CABLE
1215	3-180-749-02	o SUPPORT (A), SC GUIDE	1235	4-937-336-11	s HOLDER, LED
1216	3-180-750-02	o SUPPORT (B), SC GUIDE	1236	4-937-336-51	o HOLDER, LED
1217	3-183-119-01	o LABEL (for DWV-A510)	1237	3-704-198-01	o SUPPORT, PC
	3-183-480-01	o LABEL (for DWV-510)			
1218	3-180-813-01	o LABEL, A/D (only DWV-A510)			
1219	3-180-822-05	s KEY TOP 6X6			
1220	3-181-398-12	s KEY TOP 6X6			
1221	3-682-057-21	s SPACER (SMALL)			
1222	3-677-193-00	o PIN, STOPPER			







No.	Part No.	SP Description	No.	Part No.	SP Description
1301	A-8267-410-F	s DIAL ASSY, SEARCH	1326	3-180-859-02	o HOLDER, SENSOR
1302	A-8267-577-B	o PANEL ASSY, KEY	1327	3-181-398-02	s KEY TOP 6x6 (WHITE)
1303	A-8274-058-A	o MOUNTED CIRCUIT BOARD, DP-176	1328	3-181-398-12	s KEY TOP 6x6 (GRAY)
1304	A-8275-209-A	o MOUNTED CIRCUIT BOARD, KY-231B	1329	3-181-765-01	s KEY TOP 3x5
1305	A-8276-585-B	o MOUNTED CIRCUIT BOARD, PTC-69	1330	3-181-766-01	s PIN, KEY TOP
1306	1-454-606-11	s SOLENOID, PLUNGER	1331	3-181-833-02	o SPACER
1307	2-124-691-01	s ROLLER	1332	3-181-956-01	o SPRING, COMPRESSION
1308	2-124-693-02	s PLATE	1333	3-618-225-03	s NUT, PLATE
1309	2-124-695-01	o PLATE, CUSHION	1334	3-645-189-11	s SPRING, TENSION
1310	2-143-603-01	o ARM, RETURN	1335	3-668-124-00	o HOLDER, LED
1311	2-143-613-01	s SPRING, TORSION	1336	3-701-441-21	s WASHER, POLY 4mm DIA., 0.50T
1312	2-217-533-00	s SPRING, COMPRESSION	1337	3-704-198-11	o SUPPORT, PC
1313	3-180-632-01	o KNOB, DIAL	1338	3-686-086-01	s CUSHION, BUTTON
1314	3-180-633-03	s RUBBER, DIAL KNOB	1339	3-701-443-21	s WASHER, POLY 5mm DIA., 0.50T
1315	3-180-638-01	o ARM, JOINT GEAR	1341	4-937-336-51	o HOLDER, LED
1316	3-180-639-01	o PLATE, MODE SELECTION	1342	3-703-249-01	s SCREW, PTTWH 3x6
1317	3-180-640-02	o GEAR, JOINT	1343	3-180-904-03	o CHASSIS, KEY PANEL
1318	3-180-644-02	o PROTECTOR, KY			
1319	3-180-648-01	o PROTECTOR, PTC			
1320	3-180-649-02	o LINK, SOLENOID			
1321	3-180-650-03	s FG-RING			
1322	3-180-651-04	o CAM, SD			
1323	3-180-816-03	s KEY TOP, 5x9			
1324	3-180-817-03	s KEY TOP, 9x16			
1325	3-180-858-01	o HANDLE			







No.	Part No.	SP Description
1401	A-8275-341-A	o MOUNTED CIRCUIT BOARD, SMC-18BA (for DVW-A510/CA510)
	A-8275-211-A	o MOUNTED CIRCUIT BOARD, SMC-18B (for DVW-510)
1402	A-8275-352-A	o MOUNTED CIRCUIT BOARD, SMC-19BA (for DVW-A510/CA510)
	A-8275-212-A	o MOUNTED CIRCUIT BOARD, SMC-19B (for DVW-510)
1403	X-3167-022-4	o CHASSIS ASSY, SUB
1404	X-3167-065-3	o SLIDER (R) ASSY
1405	X-3167-066-3	o SLIDER (L) ASSY
1406	X-3167-301-3	o PANEL ASSY (NTSC), SUB (for DVW-A510/CA510)
	X-3167-168-3	o PANEL ASSY (NTSC), SUB (for DVW-510)
1407	X-3717-253-1	o RAIL ASSY, SLIDE
1408	3-183-126-01	o PLATE, ORNAMENTAL APN SMC-19 (for DVW-A510/CA510)
	3-181-699-01	o PLATE, ORNAMENTAL DPN SMC-19 (for DVW-510)
1409	3-180-814-01	o PLATE, ORNAMENTAL (SMALL), SLIDE SW
1410	3-717-393-03	o PLATE (LARGE), ORNAMENTAL, SW
1411	3-185-303-01	o SEAL, EJECT
1412	3-188-703-02	s CONNECTOR, PLATE, FIXED
1413	3-191-626-01	s PLATE(A), CONNECTOR FIXED






No.	Part No.	SP Description
1501	A-8275-207-A	o MOUNTED CIRCUIT BOARD, CP-220B (for DVM-A510/510/CA510(UC))
	A-8275-362-A	o MOUNTED CIRCUIT BOARD, CP-220BJ (for DVM-A510/510/CA510(J))
1502	A-8275-214-A	o MOUNTED CIRCUIT BOARD, CP-218B
1503	A-8276-659-A	o MOUNTED CIRCUIT BOARD, AC-155
1504	Δ 1-413-831-24	s SWITCHING REGULATOR
1505	Δ 1-576-036-11	s BREAKER, CIRCUIT
1506	1-750-881-11	s CONVERTER, COAXIAL CONNECTOR
1507	2-990-241-02	s HOLDER (A), PLUG
1509	3-173-384-01	o SPACER, ORNAMENTAL PLATE
1510	3-180-477-03	o COVER, HARNESS
1511	3-180-661-03	o SHEET, INSULATED
1512	3-180-662-01	o PANEL, POWER
1513	3-180-675-01	o PANEL, OP
1514	3-181-084-02	o PANEL, (P) CONNECTOR
1515	3-181-886-01	o PLATE, SHIELD, POWER
1516	3-531-576-01	s RIVET
1518	3-717-394-03	o PLATE (SMALL), ORNAMENTAL, SW
1519	3-727-029-01	o BRACKET, BREAKER
1520	1-541-431-41	s FAN, DC
1521	3-703-845-01	o LABEL(N) (U/C), MAIN CAUTION
1522	3-184-425-02	o INSULATOR, CONNECTOR PANEL





No.	Part No.	SP Description
1601	A-8267-384-D	s BRACKET ASSY, CASSETTE COMPARTMENT
1602	A-8267-385-B	o PLATE (MD) ASSY
1603	A-8276-622-A	o MOUNTED CIRCUIT BOARD, MB-441A (for DVW-A500/A510)
	A-8276-657-A	o MOUNTED CIRCUIT BOARD, MB-441 (for DVW-500/510)
1604	X-2068-004-1	s TERMINAL ASSY
1605	1-541-431-41	s FAN, DC
1606	2-068-008-00	s WASHER
1607	2-132-434-01	s CLIP, WIRE
1608	3-180-479-03	o PLATE, MR
1609	3-180-634-01	o GUARD (MB1), AIR
1610	3-180-635-04	o PLATE, BT
1611	3-180-636-02	o PLATE, FT
1612	3-180-654-02	o PANEL, D-SUB
1613	3-180-655-01	o HARNESS (A), COVER
1614	3-180-656-01	o GUARD (MB3), AIR
1615	3-180-657-01	o GUARD (MB2), AIR
1616	3-180-751-01	o MD, SLIDER
1617	3-180-752-01	o BRACKET, SLIDER
1618	3-180-753-02	o MD, PLATE SPRING
1619	3-181-652-03	o HOLDER, HARNESS
1620	3-642-656-01	s FOOT
1621	3-697-707-01	o CLAMP (A), HARNESS
1622	3-717-306-01	o SPRING
1623	3-182-786-01	o SPRING, CASSETTE COMPARTMENT
1624	3-650-537-00	o WASHER




9-2-3. Mounted Circuit Board List 9-2-3. マウント基板リスト

For DVW-A510/CA510

No.	Part No.	SP Description
1701	A-8275-339-C	o MOUNTED CIRCUIT BOARD, VPR-1BA
1702	A-8275-333-B	o MOUNTED CIRCUIT BOARD, APR-1BA (for S/N 11544 and higher: DVW-A510(UC)) (for S/N 10685 and higher: DVW-A510(J)) (for S/N 10016 and higher: DVW-CA510(UC)) (for S/N 10002 and higher: DVW-CA510(J))
	A-8275-393-A	o MOUNTED CIRCUIT BOARD, APR-1BA (for S/N 10001 thru. 11543: DVW-A510(UC)) (for S/N 10001 thru. 10684: DVW-A510(J)) (for S/N 10001 thru. 10015: DVW-CA510(UC)) (for S/N 10001: DVW-CA510(J))
1703	A-8275-346-A	o MOUNTED CIRCUIT BOARD, SS-52BA
1704	A-8275-349-B	o MOUNTED CIRCUIT BOARD, DIF-16B
1705	A-8275-155-B	o MOUNTED CIRCUIT BOARD, TBC-23
1706	A-8275-355-A	o MOUNTED CIRCUIT BOARD, CUE-1BA
1707	A-8275-359-B	o MOUNTED CIRCUIT BOARD, EQ-45BA (for S/N 11644 and higher: DVW-A510(UC)) (for S/N 10685 and higher: DVW-A510(J)) (for S/N 10016 and higher: DVW-CA510(UC)) (for S/N 10002 and higher: DVW-CA510(J))
	A-8275-359-A	o MOUNTED CIRCUIT BOARD, EQ-45BA (for S/N 10001 thru. 11643: DVW-A510(UC)) (for S/N 10001 thru. 10684: DVW-A510(J)) (for S/N 10001 thru. 10015: DVW-CA510(UC)) (for S/N 10001: DVW-CA510(J))
1708	A-8275-208-B	o MOUNTED CIRCUIT BOARD, DPR-36H
1709	A-8275-231-A	o MOUNTED CIRCUIT BOARD, AP-28
1710	A-8275-156-A	o MOUNTED CIRCUIT BOARD, TBC-24
1711	A-8275-154-B	o MOUNTED CIRCUIT BOARD, DM-89
1712	3-171-453-03	o PLATE (L), SHIELD, CARD
1713	3-171-454-02	o SHEET (L), CARD
1714	3-171-455-01	o PLATE (S), SHIELD, CARD
1715	3-171-456-02	o SHEET (S), CARD
1716	3-179-084-01	s LEVER (R), PC BOARD
1717	3-179-085-01	s LEVER (L), PC BOARD
1718	3-180-646-02	o GUIDE (L), PRINTED CIRCUIT BOARD
1719	3-180-674-01	o GUIDE (S), PRINTED CIRCUIT BOARD
1720	3-696-787-03	o SHEET (S), CARD
1721	3-696-891-03	o PLATE, CARD-S

For DVW-510

No.	Part No.	SP Description
1701	A-8275-339-C	o MOUNTED CIRCUIT BOARD, VPR-1BA
1702	A-8275-343-B	o MOUNTED CIRCUIT BOARD, APR-1B (for S/N 10758 and higher: DVW-510(UC)) (for S/N 10101 and higher: DVW-510(J))
	A-8275-343-A	o MOUNTED CIRCUIT BOARD, APR-1B (for S/N 10001 thru. 10757: DVW-510(UC)) (for S/N 10001 thru. 10100: DVW-510(J))
1703	A-8275-347-A	o MOUNTED CIRCUIT BOARD, SS-52B
1704	A-8275-349-B	o MOUNTED CIRCUIT BOARD, DIF-16B
1706	A-8275-356-A	o MOUNTED CIRCUIT BOARD, CUE-1B
1707	A-8275-359-B	o MOUNTED CIRCUIT BOARD, EQ-45BA (for S/N 10763 and higher: DVW-510(UC)) (for S/N 10101 and higher: DVW-510(J))
	A-8275-360-A	o MOUNTED CIRCUIT BOARD, EQ-45B (for S/N 10001 thru. 10762: DVW-510(UC)) (for S/N 10001 thru. 10100: DVW-510(J))
1708	A-8275-208-B	o MOUNTED CIRCUIT BOARD, DPR-36H
1712	3-171-453-03	o PLATE (L), SHIELD, CARD
1713	3-171-454-02	o SHEET (L), CARD
1714	3-171-455-01	o PLATE (S), SHIELD, CARD
1715	3-171-456-02	o SHEET (S), CARD
1716	3-179-084-01	s LEVER (R), PC BOARD
1717	3-179-085-01	s LEVER (L), PC BOARD
1718	3-180-646-02	o GUIDE (L), PRINTED CIRCUIT BOARD
1719	3-180-674-01	o GUIDE (S), PRINTED CIRCUIT BOARD



9-2-4. Packing Materials and Supplied Accessories List

9-2-4. 梱包部品および標準付属品リスト

For DVW-A510

Ref. No. or Q'ty	Part No.	SP Description
1pc	* -----	CABLE, REMOTE CONTROL 9P (for J)
1pc	△ 1-551-812-11	s CORD, POWER 3P (for UC)
	△ 1-575-181-11	s CORD, POWER 3P (for J)
1pc	△ 1-793-461-11	o PLUG, CONVERSION (3P-2P)(for J)
1pc	2-990-242-01	o HOLDER (B), PLUG (for UC)
1pc	3-613-640-01	o HOLDER (C), PLUG (for J)
1pc	3-181-533-02	o CUSHION (LOWER)
1pc	3-181-534-02	o CUSHION (UPPER)
1pc	3-181-535-01	o SPACER (A)
1pc	3-181-536-01	o SPACER (B)
1pc	3-183-128-03	o INDIVIDUAL CARTON
1pc	3-701-616-01	o BAG, POLYETHYLENE
1pc	3-701-634-00	o BAG, POLYETHYLENE
4pcs	7-682-965-01	s SCREW +PSW 4X16

For DVW-510

Ref. No. or Q'ty	Part No.	SP Description
1pc	* -----	CABLE, REMOTE CONTROL 9P (for J)
1pc	△ 1-551-812-11	s CORD, POWER 3P (for UC)
	△ 1-575-181-11	s CORD, POWER 3P (for J)
1pc	△ 1-793-461-11	o PLUG, CONVERSION (3P-2P)(for J)
1pc	2-990-242-01	o HOLDER (B), PLUG (for UC)
1pc	3-613-640-01	o HOLDER (C), PLUG (for J)
1pc	3-181-533-02	o CUSHION (LOWER)
1pc	3-181-534-02	o CUSHION (UPPER)
1pc	3-181-535-01	o SPACER (A)
1pc	3-181-536-01	o SPACER (B)
1pc	3-183-481-02	o INDIVIDUAL CARTON
1pc	3-701-616-01	o BAG, POLYETHYLENE
1pc	3-701-634-00	o BAG, POLYETHYLENE
4pcs	7-682-965-01	s SCREW +PSW 4X16

For DVW-CA510

Ref. No. or Q'ty	Part No.	SP Description
1pc	* -----	CABLE, REMOTE CONTROL 9P (for J)
1pc	△ 1-551-812-11	s CORD, POWER 3P (for UC)
	△ 1-575-181-11	s CORD, POWER 3P (for J)
1pc	△ 1-793-461-11	o PLUG, CONVERSION (3P-2P)(for J)
1pc	2-990-242-01	o HOLDER (B), PLUG (for UC)
1pc	3-613-640-01	o HOLDER (C), PLUG (for J)
1pc	3-183-868-01	o PLATE, TOP
1pc	3-183-869-01	o INDIVIDUAL CARTON
1pc	3-183-871-01	o CUSHION (UPPER)
1pc	3-183-872-01	o CUSHION (LOWER)
1pc	3-701-634-00	o BAG, POLYETHYLENE
1pc	3-704-318-01	o BAG, PROTECTION

※: RCC-5G相当品。製品で購入してください。

9-3. SPARE PARTS LIST – OPTIONAL ACCESSORIES –
9-3. 補修部品リスト – オプション –


9-3-1. Index
9-3-1. インデックス

Model Name		Page
BKDW-507 ^(*)	Audio Program Play Board	—
BKDW-509	Parallel (50P) Interface Kit	9-43
BKDW-510	Control Panel Extension Kit	9-44
BKDW-511	Control Panel Case	9-45

(*)1) Please order the standard products.
製品をお求めください。

9-3-2. BKDW-509


Exploded View



No.	Part No.	SP Description
1	1-563-893-21	s SOCKET, D-SUB CONNECTOR 50P
2	3-180-788-01	o PANEL (RM), ORNAMENTAL
3	3-673-910-31	s SCREW, CONNECTOR
4	3-184-609-01	o GUIDE, CONNECTOR

9-3-3. BKDW-510


Exploded View



No.	Part No.	SP Description
1	A-6768-668-B	o PANEL ASSY, BLANK
2	3-717-425-01	o HANDLE
1pc	1-751-316-11	o CABLE ASSY, ENCAPSULATED

9-3-4. BKDW-511

Exploded View



No.	Part No.	SP Description
1	2-246-108-00	s CUSHION
2	2-260-992-00	o CUSHION, PANEL CASE
3	2-260-993-21	o CASE (UPPER), CONTROL PANEL
4	2-260-994-02	o CASE (LOWER), CONTROL PANEL
5	2-270-617-00	s SCREW, KNOB
6	3-661-588-00	o SPACER, 3X5

9-4. Spare Parts List

Part No. SP Description

7-621-255-15 s SCREW +P 2X3
 7-621-259-25 s CSREW +PWH 2.6X4
 7-621-260-55 s SCREW +P 2.6X25
 7-621-283-10 s SCREW +P 2X10
 7-621-559-20 s SCREW +K 2.6X4

 7-621-721-06 s SET-SCREW, SLOT 2X2.5 (FLAT)
 7-621-733-08 s SET-SCREW, HEX 2X4 (FLAT)
 7-621-734-09 s SET-SCREW, HEX 2.6X3 (WP)
 7-621-740-08 s SET-SCREW, HEX 2.6X6 (FLAT)
 7-621-772-00 s SCREW +B 2X3

 7-621-772-10 s SCREW +B 2X4
 7-621-772-20 s SCREW +B 2X5
 7-621-772-50 s SCREW +B 2X10
 7-621-773-95 s SCREW +B 2.6X6
 7-621-775-20 s SCREW +B 2.6X5

 7-621-775-80 s SCREW +B 2.6X16
 7-622-207-05 s N 2.6, TYPE 2
 7-623-205-22 s SW 2, TYPE 2
 7-623-207-22 s SW 2.6, TYPE 2
 7-623-422-07 s LW3, TYPE B

 7-623-510-01 s LUG, 4
 7-623-923-11 s WASHER 2.6, NYLON
 7-623-924-11 s WASHER 3.0, NYLON
 7-624-105-04 s STOP RING 2.3 (E TYPE)
 7-624-106-04 s STOP RING 3.0 (E TYPE)

 7-624-108-04 s STOP RING 4.0 (E TYPE)
 7-628-253-00 s SCREW +PS 2X4
 7-628-253-15 s SCREW +PS 2X5
 7-628-253-20 s SCREW +PS 2X6
 7-628-253-35 s SCREW +PS 2X8

 7-628-254-30 s SCREW +PS 2.6X10
 7-671-155-01 s BALL 3, STEEL
 7-682-544-04 s SCREW +B 3X3
 7-682-545-09 s SCREW +B 3X4
 7-682-546-09 s SCREW +B 3X5

 7-682-547-09 s SCREW +B 3X6
 7-682-548-09 s SCREW +B 3X8
 7-682-550-09 s SCREW +B 3X12
 7-682-551-09 s SCREW +B 3X14
 7-682-552-09 s SCREW +B 3X16

Part No. SP Description

7-682-646-09 s SCREW +PS 3X5
 7-682-648-09 s SCREW +PS 3X8
 7-682-661-01 s SCREW +PS 4X8
 7-682-661-09 s SCREW +PSW 4X8
 7-682-666-09 s SCREW +PS 4X20

 7-682-668-09 s SCREW +PSW 4X30
 7-682-902-11 s SCREW +PWH 2.6X5
 7-682-903-21 s SCREW +PWH 3X8
 7-682-947-01 s SCREW +PSW 3X6
 7-682-948-01 s SCREW +PSW 3X8

 7-682-949-01 s SCREW +PSW 3X10
 7-682-962-01 s SCREW +PSW 4X10
 7-682-965-01 s SCREW +PSW 4X16
 7-683-174-01 s SET-SCREW, SLOT 3X4 (FLAT)
 7-683-176-01 s SET-SCREW, SLOT 3X6 (FLAT)

 7-683-176-21 s SET-SCREW, SLOT 3X6 (CONE)
 7-684-023-04 s N 3, TYPE 2
 7-685-103-19 s SCREW +P 2X5 TYPE2 NON-SLIT
 7-685-105-19 s SCREW +PTP 2X8 TYPE2 NON-SLIT
 7-685-134-19 s SCREW +P 2.6X8 TYPE2 NON-SLIT

 7-685-247-19 s SCREW +KTP 3X10 TYPE2 NON-SLIT
 7-685-646-79 s SCREW +BVTP 3X8 TYPE2 IT-3
 7-685-865-09 s SCREW +BVTT 2.6X12 (S)
 7-685-866-01 s SCREW +BVTT 2.6X14 (S)
 7-685-871-01 s SCREW +BVTT 3X6 (S)

 7-685-871-09 s SCREW +BVTT 3X6 (S, BLACK)
 7-685-872-09 s SCREW +BVTT 3X8 (S)
 7-685-873-09 s SCREW +BVTT 3X10 (S)
 7-685-875-09 s SCREW +BVTT 3X14 (S)
 7-685-879-01 s SCREW +BVTT 3X30 (S)

 7-685-881-01 s SCREW +BVTT 4X8 (S)
 7-685-902-01 s SCREW +PTPWH 2.6X5 (TYPE2)
 7-685-903-11 s SCREW +PTPWH 3X6 (TYPE2)
 7-685-903-21 s SCREW +PTPWH 3X8 (TYPE2)
 7-688-001-01 s W 2, SMALL

 7-688-001-11 s W 2, MIDDLE
 7-688-002-11 s W 2.6, MIDDLE
 7-688-003-01 s W 3, SMALL
 7-688-003-11 s W 3, MIDDLE
 7-688-004-11 o SW 4, MIDDLE

DVW-CA510

This section contains the exclusive information of DVW-CA510.
Please replace or add the corresponding pages from Section 1 to 9 with them.

TABLE OF CONTENTS

1. SERVICE OVERVIEW

1-1. NOTES ON POWER SUPPLY BLOCK	1-1
1-1-1. Warning on Primary Circuit and Electric Shock	1-1
1-1-2. Notes on Resetting the Circuit Breaker	1-1
1-2. REMOVAL OF THE UNIT FROM THE RACK	1-1
1-3. REMOVAL/INSTALLATION OF CABINET	1-2
1-3-1. Cabinet Removal/Installation	1-2
1-3-2. Cassette Compartment Removal/Installation ..	1-4
1-3-3. Connector Panel Removal/Installation	1-6
1-3-4. Power Supply Panel Removal/Installation	1-7
1-4. REMOVAL OF EJECTOR ASSEMBLY	1-8
1-5. FUNCTIONS OF PRINTED CIRCUIT BOARD	1-9
1-6. LOCATIONS OF MAIN PART	1-10
1-6-1. Printed Circuit Board Locations	1-10
1-6-2. Main Mechanical Part Locations	1-12
1-6-3. Function and Location of Sensors	1-12
1-7. LED INDICATOR INFORMATION ON BOARDS	1-14
1-8. MECHANISM OF CASSETTE	1-16
1-9. HOW TO PULL OUT/PUSH IN THE LOWER CONTROL PANEL	1-18
1-10. REMOVAL/INSTALLATION OF LOWER CONTROL PANEL ASSEMBLY	1-18
1-11. HOW TO TAKE OUT THE CASSETTE WHEN THE TAPE IS SLACKING	1-20
1-12. CLEANING WHEN THE HEADS ARE CLOGGED	1-21
1-12-1. Cleaning by Cleaning Tape	1-21
1-12-2. Cleaning by Cleaning Cloth	1-21
1-13. FIXTURE AND MEASURING EQUIPMENT FOR ADJUSTMENT	1-22
1-13-1. Fixture	1-22
1-13-2. Measuring Equipment	1-24
1-14. ERROR LOGGER FUNCTION	1-24
1-15. SAFETY CHECK-OUT	1-25

2. RECORDING FORMAT, HEAD CONFIGURATION, AND SIGNAL PROCESSING

2-1. OUTLINE	2-1
2-2. RECORDING FORMAT	2-2
2-2-1. Tape Pattern	2-2
2-2-2. Data Arrangement on Program Tracks	2-3
2-2-3. Longitudinal Tracks	2-4
2-3. HEAD CONFIGURATION	2-5
2-4. SIGNAL PROCESSING	2-6
2-4-1. Outline of the Digital Interface Format	2-6
2-4-2. Outline of the Digital Signal Processing	2-8
2-4-3. Error Correction Coding	2-9

3. BLOCK DIAGRAMS AND CIRCUIT DESCRIPTIONS

3-1. OVERALL	3-2
OVERALL (1/2)	3-2
OVERALL (2/2)	3-4
3-2. CIRCUIT BLOCK	3-7
EQ-45B	3-7
DPR-36H	3-11
VPR-1B	3-15
APR-1B	3-19
DIF-16B	3-23
CUE-1B	3-27
DM-89	3-30
TBC-24	3-35
TBC-23	3-39
AP-28	3-45
SS-52B (1/3)	3-49
SS-52B (2/3)	3-53
SS-52B (3/3)	3-57
DR-307/200	3-61
FUNCTION CONTROL	3-64
POWER SUPPLY	3-66
3-3. FRAME	3-68
FRAME WIRING (1/3)	3-68
FRAME WIRING (2/3)	3-70
FRAME WIRING (3/3)	3-72

4. ERROR MESSAGES AND TROUBLESHOOTING

4-1. ERROR MESSAGE	4-1
--------------------------	-----

5. MAINTENANCE MODE

5-1. OUTLINE	5-1
5-2. SERVO/DT SYSTEM CHECK MODE	5-5
5-2-1. Servo System Check 1	5-6
5-2-2. Servo System Check 2	5-10
5-2-3. Servo System Check 3	5-16
5-2-4. Servo System Check 4	5-20
5-2-6. Digital DT System Check	5-23
5-2-7. Analog DT System Check (For DVW-A510P/A510)	5-26
5-3. RF SYSTEM CHECK MODE	5-28
5-4. AUDIO/VIDEO SYSTEM CHECK MODE	5-30
5-5. BETACAM PB SYSTEM CHECK MODE (For DVW-A510P/A510)	5-32
5-6. OTHERS CHECK MODE	5-34
5-7. SERVO/DT SYSTEM ADJUSTMENT MODE	5-39
5-7-1. Servo System Adjustment Mode	5-40
5-7-2. Digital DT System Adjustment Mode	5-51
5-7-3. Analog DT System Adjustment Mode (For DVW-A510P/A510)	5-59
5-8. RF SYSTEM ADJUSTMENT MODE	5-64
5-9. AUDIO/VIDEO SYSTEM ADJUSTMENT MODE	5-74
5-10. BETACAM PB SYSTEM ADJUSTMENT MODE (For DVW-A510P/A510)	5-76

6. REPLACEMENT OF POWER BLOCK AND CIRCUIT BOARDS

6-1. GENERAL INFORMATION FOR POWER/BOARDS REPLACEMENT	6-1
6-1-1. Index for Board Replacement	6-1
6-1-2. Plug-in Board Pulling Out/Inserting	6-2
6-1-3. Flexible Card Wire Replacement	6-4
6-2. POWER BLOCK/BOARD REPLACEMENT	6-5
6-3. HOW TO REPLACE BOARDS	6-8
6-3-1. SWC-17 Board	6-8
6-3-2. FP-58 Board	6-11
6-3-3. VR-152 Board	6-15
6-3-4. VR-153 Board	6-20
6-3-5. KY-231 Board	6-25
6-3-6. DP-176 Board	6-26
6-3-7. SWC-18 Board	6-27
6-3-8. SWC-19 Board	6-28
6-3-9. CP-218 Board	6-30
6-3-10. CP-220 Board	6-32
6-3-11. DR-307/200 Board	6-33
6-3-12. DT-34 Board	6-35
6-3-13. HN-181 Board	6-36
6-3-14. HN-184 Board	6-42
6-3-15. HN-185 Board	6-45
6-3-16. LED-200 Board	6-48-1
6-4. ADJUSTMENT AND CHECK AFTER DIGITAL BOARD REPLACEMENT	6-49
6-4-1. VPR-1 Board	6-49
6-4-2. APR-1 Board	6-59
6-5. ADJUSTMENT AFTER TBC-23 BOARD REPLACEMENT	6-64

7. PERIODIC MAINTENANCE AND INSPECTION

7-1. CLEANING	7-1
7-1-1. General Information for Cleaning	7-1
7-1-2. Rotary Heads Cleaning	7-3
7-1-3. Upper Drum's Tape Running Surface Cleaning	7-4
7-1-4. Lower Drum's Tape Running Surface and Lead Surface Cleaning	7-5
7-1-5. Stationary Heads Cleaning	7-6
7-1-6. Tape Running System and Tape Cleaner Cleaning	7-7
7-1-7. Fan Motor Cleaning	7-8
7-1-8. Cassette Compartment Cleaning	7-9
7-2. PERIODIC CHECK	7-10
7-2-1. Hours Meter	7-10
7-2-2. Periodic Check List	7-11

8. REPLACEMENT OF PERIODIC MAINTENANCE PARTS

8-1. GENERAL INFORMATION FOR PARTS REPLACEMENT AND ADJUSTMENT	8-1
8-1-1. Basic Knowledge	8-1
8-1-2. Threading End Mode and Unthreading End Mode	8-2
8-1-3. L Cassette Position and S Cassette Position	8-4

8-2. PARTS REPLACEMENT	8-7
8-2-1. Inner Drum Assembly Replacement	8-10
8-2-2. Brush/Slip Ring Assembly Replacement	8-24
8-2-3. Drum Assembly Replacement	8-26
8-2-4. Rotary Head Cleaner Assembly Replacement	8-32
8-2-5. AT Head Cleaner Replacement	8-34
8-2-7. Pinch Roller Replacement	8-38
8-2-8. Audio/TC Head Replacement	8-40
8-2-9. CTL Head Replacement	8-44
8-2-10. Capstan Motor Replacement	8-48
8-2-11. Pinch Solenoid Replacement	8-52
8-2-12. Brake Lining Replacement	8-58
8-2-13. Reel Motor Assembly Replacement	8-60
8-2-14. Fan Motor Replacement	8-69
8-2-15. Filter Replacement	8-70
8-3. MECHANICAL ADJUSTMENT	8-71
8-3-1. Pinch Press Clearance Adjustment	8-73
8-3-2. Reel Motor Shaft Slantness Adjustment	8-75
8-3-3. Cassette Pillar Height Adjustment (L Cassette)	8-77(1)
8-3-3. Cassette Pillar Height Adjustment (S Cassette)	8-77(2)
8-3-4. Reel Table Height Adjustment	8-79
8-3-5. Reel Brake Clearance Check	8-83
8-3-6. Reel Brake Release Amount Adjustment	8-85
8-4. TAPE PATH ADJUSTMENT	8-87
8-4-1. Audio/TC Head Zenith Adjustment	8-91
8-4-2. Tape Running Adjustment	8-93
8-4-3. Video Tracking Adjustment	8-97
8-4-4. CTL Head Height Adjustment	8-107
8-4-5. CTL Head Position Adjustment	8-109
8-4-6. Audio/TC Head Height Adjustment	8-113
8-4-7. Audio/TC Head Azimuth Adjustment	8-119
8-4-8. Audio/TC Head Head-to-tape Contact Adjustment	8-123
8-4-9. Audio/TC Head Position Adjustment	8-129
8-4-10. Audio Level Adjustment in REV Mode	8-131
8-5. SERVO/DT AND RF ADJUSTMENT	8-137
8-5-1. Drum Phase Adjustment	8-141
8-5-2. Digital DT Adjustment	8-142
8-5-3. Analog DT Adjustment	8-143
8-5-4. ADV Envelope Level Adjustment	8-144
8-5-5. Playback Equalizer Adjustment	8-145
8-6. ADJUSTMENT AFTER DRUM REPLACEMENT (For DVW-A500/A510/CA510)	8-151
8-6-1. EQ RF Output Level Adjustment	8-157
8-6-2. DM OMC Limiter Balance Adjustment	8-161
8-6-2(1). DM OMC Limiter Balance Adjustment (without Spectrum analyzer)	8-164
8-6-3. Demodulator Limiter Balance Adjustment	8-165
8-6-4. PB Frequency Response Adjustment	8-167
8-6-5. DM RF Output Level Adjustment (For board's No. suffix 11,12)	8-169
8-6-6. DM RF Envelope Check	8-172
8-6-7. TBC Y/C Delay Check	8-173
8-6-8. Y and C Error Offset Check	8-175
8-6-9. AFM RF Level Adjustment	8-176

8-7. ADJUSTMENT AFTER AUDIO/ TC HEAD REPLACEMENT	8-177
8-7-1. Audio PB Frequency Response Adjustment (Oxide) (For DVW-A510/CA510)	8-184
8-7-2. AP Board Dolby Level Adjustment (For DVW-A510/CA510)	8-185
8-7-3. LAU PB Level Adjustment (For DVW-A510/CA510)	8-185
8-7-4. LAU PB Phase Adjustment (For DVW-A510/CA510)	8-186
8-7-5. Cue PB Frequency Response Adjustment ...	8-187
8-7-6. Cue PB Level Adjustment	8-188
8-7-7. LTC PB Level Check	8-189

9. SPARE PARTS

9-1. NOTES ON SPARE PARTS	9-1
9-2. SPARE PARTS LIST – VTR –	9-2
9-2-1. Index	9-2
9-2-2. Exploded Views and Mechanical Parts List ...	9-4
Reel Chassis (S Side) Block	9-4
Reel Chassis (T Side) Block	9-6
Drum and Rotary Head Cleaner Block	9-8
S Tension Regulator Block	9-10
CTL Head Block	9-12
Threading Ring and Pinch Roller Block	9-14
AT Head and Capstan Motor Block	9-16
Pinch Press and Gear Box Block	9-18
T Tension Regulator Block	9-20
Cassette Compartment Block	9-22
Printed Circuit Board (Bottom Side) Block	9-24
Ornamental Panel Block	9-26
Upper Control Panel Block	9-28
Lower Control Panel Block	9-30
Sub Control Panel Block	9-32
Connector Panel Block	9-34
Chassis Block	9-36
Ejector Block	9-38
9-2-3. Mounted Circuit Board List	9-40
9-2-4. Packing Materials and Supplied Accessories List	9-42
9-3. SPARE PARTS LIST	
– OPTIONAL ACCESSORIES –	9-43
9-3-1. Index	9-43
9-3-2. BKDW-509	9-44
9-3-3. BKDW-510	9-45
9-3-4. BKDW-511	9-46
9-4. SPARE PARTS LIST	9-47

SECTION 1 SERVICE OVERVIEW

1-1. NOTES ON POWER SUPPLY BLOCK

1-1-1. Warning on Primary Circuit and Electric Shock

The power supply block consists of the AC-155 board and primary peripheral components. The whole AC-155 board is on the primary side circuit, so pay careful attention to the electric shock. Since the inside of a switching regulator is also on the primary side circuit, treat it with care.


1-1-2. Notes on Resetting the Circuit Breaker

When the breaker on the power supply panel is activated and the button is ejected, remove the cause of the trouble, then push the button.


1-2. REMOVAL OF THE UNIT FROM THE RACK

This unit can be removed from the rack. This work should be performed by two persons.


1. Pull out the unit while pushing down the lock levers on both sides.



2. Pull out the unit while pushing the VTR stopper in the direction of the arrow.




3. Cancel the both side lock plate of the slide rail and remove the unit from the rack.



1-3-1. Cabinet Removal/Installation

Always switch off the POWER before removing and installing cabinet.



Upper Control Panel/Front Sub Panel

1. Remove the right and left screws fixing the front sub panel.
2. Remove one screw at the top of the front sub panel, then remove the front sub panel.
3. Remove six control knobs on the upper control panel.
4. Remove the right and left screws fixing the upper control panel.
5. As shown in Fig. A, put fingers between the panel and chassis and remove the panel while spreading the panel edge.




Fig. A

6. To install the panel, align the convex portion of the panel with the hole of the chassis and fix the panel with the screw. (Fig. B)





FIG. B

Upper Lid (S)

Loosen one fixing screw fully, move the upper lid (S) in the direction indicated by the arrow, and remove it. To install the upper lid (S), align the upper lid (S) with the notches on the front sub panel, push it into the notches, and fix with the screw.

Upper Lid (L)


Loosen two fixing screws fully, move the upper lid (L) in the direction indicated by the arrow, and remove it.



1-3-2. Cassette Compartment Removal/Installation


Removal

1. Turn off the POWER switch.
2. Remove the upper lid (S).
(Refer to 1-3-1. Cabinet Removal/Installation)
3. Loosen two fixing screws fully and remove the bracket assembly.




Removal of the Bracket Assembly

4. Disconnect the three connectors (CN280, CN286, and CN281) on the CL-28 board.



Disconnecting the Connectors

5. Raise the cassette compartment in the direction indicated by the arrow and remove it from the unit.



Removal of the Cassette Compartment

Installation

6. Put the harnesses of the three connectors (CN280, CN286, and CN281) disconnected in step 4 in the position where they do not become obstructive.
7. Install the cassette compartment in the unit.

NOTE


Confirm that the four legs for fixing the cassette compartment position are inserted into the four holes for fixing the mechanical chassis position.

8. Install the bracket assembly after confirming that the legs for fixing position are inserted into the holes for fixing position.

NOTE

Bracket assembly are inserted into the holes of the cassette compartment. (Refer to the figure for cassette compartment bracket assembly removal.)


9. Connect the three connectors (CN280, CN286, and CN281) on the CL-28 board.
10. Install the upper lid (S).



Installation of the Cassette Compartment


1-3-3. Connector Panel Removal/Installation

1. Turn off the POWER.
2. Remove six screws indicated → at the top and bottom on the connector panel.



Removal of Screws


3. Remove the connector panel so as not to stretch the harness as shown in the figure.
4. Install the connector panel in the reverse order of steps 1 through 3.




Removal of the Connector Panel

1-3-4. Power Supply Panel Removal/Installation

1. Turn off the POWER.
2. Remove two screws, and open the power supply panel.


**Removal of the Power Supply Panel**

3. Remove a screw and a spring washer which secure the ground terminal, then disconnect connector (CN002) on the AC-155 board, then remove the power supply panel.
4. Install the power supply panel in the reverse order of steps 1 through 3.

**Disconnecting the Connector**


1-4. REMOVAL OF EJECTOR ASSEMBLY

1. Remove the upper lid (S). (Refer to 1-3. Removal/Installation of Cabinet.)
2. Remove the harness of the ejector assembly from the purse lock.



1-4. REMOVAL OF EJECTOR ASSEMBLY

3. Loosen the two fixing screws of the ejector assembly fully.
4. Move the ejector assembly in the direction of the arrow shown in the figure and shift it to the connector panel side.



1-5. FUNCTIONS OF PRINTED CIRCUIT BOARD

The numbers in left columns of the board name are in common with the numbers of Section 1-6-1. Printed Circuit Board Locations.

No.	Board Name	Circuit Function	System Configuration
1	DIF-16	4:2:2 Component Serial Digital Interface with Embedded Audio	Digital Process
2	VPR-1	Video Signal Processor, D/A, HUE, GAIN Ref CK Generator, Composite Encoder	
3	DPR-36	Digital Data Processor (Decode, Error Correction)	
4	APR-1	Audio Signal Processor (D/A, AES/EBU I/F)	RF/Analog Process
5	EQ-45	PB RF Equalizer, Analog Betacam PB Buff	
6	CUE-1	CUE, TC PB & LAU PB Circuit	
7	AP-28	AFM Demodulator & LAU Noise Reduction for Analog Betacam (PB)	Analog Betacam Playback
8	DM-89	RF Demodulator for Analog Betacam (PB)	
9	TBC-24	TBC (A/D Conversion & Write Clock Gen. Blocks)	
10	TBC-23	TBC (Sequence & Reference Block)	Power
12	AC-155	AC Connector Board with Breaker	
13	SW REG	Switching Regulator	
14	HN-181	Connection Board (Drum, etc)	Connection
15	HN-185	Connection Board with Dew Sensor	
16	HN-184	Connection Board (Threading Motor,etc)	
17	SS-52	System, Servo, DT Control	System/Servo Control
18	DR-307/200	Motors (Drum, Reel, Capstan, etc) Driver, Solenoids Driver	
19	DT-34	DT Driver	

No.	Board Name	Circuit Function	System Configuration
20	FP-58	Panel Function (SWs, LEDs) Control, CAV Control Level Conversion	Front Panel Function
21	VR-152	Phone level RV, Phone connector	
22	VR-153	Audio PB Level VRs	
23	SWC-17	Upper Panel Function (Switches, LEDs)	
24	SWC-18	Sub Control Panel Function	
25	SWC-19	System Set-up Panel Function Control	
26	KY-231	Lower Panel Function Control	
27	DP-176	Time Counter Display	Rear Panel Function
28	PTC-69	Search Dial Sensor	
29	CP-218	Rear Panel Connector Board (Analog Video Signal Buffer)	
30	CP-220	Rear Panel Connector Board (Analog/Digital Audio,TC)	Option
31	RM-130	Parallel (50P) Interface (optional accessory BKDW-509)	
32	MB-441	Mother Board	Other
33	PTC-54	Threading FG	
34	CCM-15	Threading Motor/Reel Shift Motor	
35	TR-79	T Tension Sensor,Thread/Unthread End Sensor	
36	PTC-59	Cassette's Holes Sensor	
37	RM-141	T Reel Motor	
38	RM-82	S Reel Motor	
39	SE-228	Reel FG	
40	PTC-71	Reel Position Sensor	
41	TR-78	S Tension Sensor	
42	PD-35	Pinch Solenoid Connection	Cassette Compartment & Betacart Use
43	DU-91	Cassette Out Sense, Cassette Sense, Arm Position Sense	
44	SE-225	Cassette In Sense, Cassette Up Sense	
45	SE-226	Cassette Down Sense	
46	CL-28	Cassette Compartment	
47	IF-36	Betacart Interface	
48	LED-200	ON AIR Lamp	


1-6. LOCATIONS OF MAIN PART

1-6-1. Printed Circuit Board Locations


The numbers in the figures are in common with the numbers in Section 1-5. Functions of Printed Circuit Board.

INDEX


AC-155	12
AP-28	7
APR-1	4
CCM-15	34
CL-29	43
CP-218	29
CP-220	30
CUE-1B/BA	6
DIF-16	1
DM-89	8
DP-176	27
DPR-36	3
DR-307/200	18
DT-34	19
DU-91	43
EQ-45	5
FP-58	20
HN-181	14
HN-184	16
HN-185	15
IF-36	47
KY-231	26
LED-200	48
MB-441	32
PC-70	45
PD-35	42
PTC-54	33
PTC-59	36
PTC-69	28
PTC-71	40
RM-130	31
RM-141	37
RM-82	38
SE-225	44
SE-226	45
SE-228	39
SS-52	17
SW REG	13
SWC-18	24
SWC-19	25
TBC-23	10
TBC-24	9
TR-78	41
TR-79	35
VPR-1	2
VR-152	21
VR-153	22




<Top view>






<Bottom view>




<Front view>



<Rear view>



1-6-2. Main Mechanical Part Locations




<Top view>

INDEX

- | | |
|---------------------------|---------------------------|
| ① Audio/TC head | ⑭ T worm wheel |
| ② TG-3 tape guide | ⑮ Worm gear |
| ③ Head drum | ⑯ Drive gear |
| ④ Threading ring | ⑰ S worm wheel |
| ⑤ T tension regulator arm | ⑱ S brake assembly |
| ⑥ CTL head | ⑲ S reel table |
| ⑦ TG-2 tape guide | ⑳ S tension regulator arm |
| ⑧ Audio/TC head cleaner | ㉑ TG-0 tape guide |
| ⑨ T drawer arm | ㉒ Capstan shaft |
| ⑩ TG-10 tape guide | ㉓ Cleaning roller block |
| ⑪ Pinch roller | ㉔ Pinch press block |
| ⑫ T reel table | ㉕ TG-4 tape guide |
| ⑬ T brake assembly | ㉖ Threading gear block |

1-6-3. Function and Location of Sensors



<Top view>

- | | |
|---|---|
| <p>① Threading motor rotation sensor
The threading motor rotation sensor detects the rotation speed of the threading motor.
The FG output signal of this detection sensor is input to the servo circuit to control the threading speed so that the tape is not damaged during threading and unthreading.</p> | <p>④ Condensation sensor
This sensor detects whether the dew condensation occurs in the unit.</p> |
| <p>② Threading-end/unthreading-end sensor
This sensor detects whether the threading ring reaches the threading-end or unthreading-end position.</p> | <p>⑤ Tape top sensor
This sensor detects the top of the tape, and in addition detects the tape end of the tape that runs in the reverse direction.</p> |
| <p>③ T tension regulator arm sensor
During recording and playback, this sensor detects the tension arm position and controls the reel torque to keep a constant T tape tension.</p> | <p>⑥ Reel hub diameter sensor
The reel hub diameter of a cassette tape varies depending on the length of the tape wound on the cassette tape. The reel hub diameter sensor detects the reel hub diameter using a tub on the back side of the cassette tape. The output signal of this sensor is input to the servo circuit to control the rotation speed and torque of the reel motor.</p> |

⑦ **Metal tape sensor**

Using a tub on the back side of the cassette tape, this sensor detects whether an oxide tape or metal tape is being inserted into the unit. (Only during analog tape playback)

⑧ **Tape thickness sensor**

Using a tub on the back side of the cassette tape, this sensor detects the thickness of the tape wound on a cassette tape that is being inserted into the unit.

⑨ **Analog/digital tape sensor**

Using a tub on the back side of the cassette tape, this sensor detects whether an analog tape or digital tape is being inserted into the unit.

⑩ **T reel table rotation sensor**

This sensor detects the rotation of the take-up reel table. The FG output signal of this sensor is input to the servo circuit to control the rotation speed of the reel motor.

⑪ **S reel table rotation sensor**

This sensor detects the rotation of the supply reel table. The FG output signal of this sensor is input to the servo circuit to control the rotation speed of the reel motor.

⑫ **Reel L/S position sensor**

This sensor detects whether the reel table moves to the correct position according to the size of the inserted cassette tape.

⑬ **S tension regulator arm sensor**

During recording and playback, this sensor detects the tension arm position and controls the reel torque to keep a constant S tape tension.

⑭ **Tape end sensor**

This sensor detects the end of the tape that runs in the forward direction.

⑮ **Cassette-out sensor**

This sensor detects whether a cassette is being pushed out of the unit.

⑯ **Cassette-in sensor (L)**

This sensor detects whether a cassette is being inserted.

⑰ **Cassette-down (2) sensor**⑱ **Cassette-down (1) sensor**


The cassette-down (1) sensor detects the movement of the cassette compartment through combined ON/OFF operation of the cassette-down (2) sensor, the cassette-down (1) sensor, and a cassette-in sensor.

⑲ **Cassette sensor**


This sensor detects the existence of a cassette in a cassette compartment.

⑳ **Ejector arm sensor**

This sensor detects whether an ejector arm is returned to the starting position.



<Cassette compartment>





<Ejector>

1-7. LED INDICATOR INFORMATION ON BOARDS

Lot No. 907 and higher

DVW-A510 (UC): S/N 11514 and higher
DVW-510 (UC): S/N 10758 and higher
DVW-A510 (J): S/N 10685 and higher
DVW-510 (J): S/N 10101 and higher
DVW-CA510 (UC): S/N 10016 and higher
DVW-CA510 (J): S/N 10002 and higher

DVW-A510 (UC): S/N 10001 through 11513
DVW-510 (UC): S/N 10001 through 10757
DVW-A510 (J): S/N 10001 through 10684
DVW-510 (J): S/N 10001 through 10100
DVW-CA510 (UC): S/N 10001 through 10015
DVW-CA510 (J): S/N 10001



DIF-16 Board

LED No.	Name	Color	Description	Normal State
D100	DIF TEST YP	Red	Lights when the Y PARITY test mode is executed in the maintenance mode.	Goes off
D101	PARA IN P ERROR	Red	Lights when an error occurs in the video signal that is sent from VPR board to DIF board.	Goes off
D102	TX625/525	Green	Indicates the state of 4: 2: 2 component serial digital interface output. This state is set 625/50 by C.P.U BUS CONTROL.	Goes off
*D507	ENC1 ADJUST	Green	Lights when the VCO frequency is almost 27 MHz adjusting the D1 ENC1 VCO in the maintenance mode A23 : DIF VR.	Unsettled
*D508	ENC2 ADJUST	Green	Lights when the VCO frequency is almost 27 MHz adjusting the D1 ENC2 VCO in the maintenance mode A23 : DIF VR.	Unsettled

SS-52 Board

LED No.	Name	Color	Description	Normal State
D300	—	—	Unused	—
D301	SYS 1	Amber	Blinks during SYS 1 V25 CPU normal operation.	Blinks
D601	SYS 2	Amber	Blinks during SYS 2 Z80 CPU normal operation.	Blinks
D711	SV	Amber	Checks the ROM and RAM for communication when the power switch is set to ON. Lights for scores ms at intervals 1 to 2 seconds. (For the blinking pattern when abnormality occurred, refer to the figure shown right.)	Blinks
D800	DRUM	Amber	Blinks during drum microcomputer normal operation. Usually lights for 30 msecond at intervals of about one second. The blinking interval is inverted when the drum is locked.	Blinks
D2109	DT	Amber	Blinks during DT microcomputer FMC-16 CPU normal operation.	Blinks

APR-1 Board

LED No.	Name	Color	Description	Normal State
D51	APR 1	Amber **Red	Blinks during APR 1 microcomputer normal operation (when a 1/2VD signal is received from the SS-52 board).	Blinks

DM-89 Board (for DVW-A510)

LED No.	Name	Color	Description	Normal State
D902	ADJUST	Amber	Usually lights for about 10 msecond at intervals of about one second. The blinking interval is inverted when the unit is in the adjustment mode (when switch S901-1 is set to ON).	Blinks


TBC-23 Board (for DVW-A510)

LED No.	Name	Color	Description	Normal State
D200	TBC	Amber	Lights once a second during TBC microcomputer normal operation.	Blinks

* : Lot No. 907 and higher

** : Lot No. 910 and higher

<Blinking Pattern of D711 on SS-51 Board>




TBC-23 BOARD

D200

DM-89 BOARD

D902





< Top view >

1-8. MECHANISM OF CASSETTE



As shown in the figure below, plugs and tabs are provided at the back side of the cassette tape.

Analog cassette tape



- ① S cassette REC inhibit tab (for oxide tape)
- ② Video tape thickness detection tab
- ③ Metal tape detection tab
- ④ Reel hub diameter detection tab
- ⑤ S cassette REC inhibit plug (for metal particle tape)
- ⑥ L cassette REC inhibit plug

Digital cassette tape



- ⑦ S cassette analog REC inhibit plug (originally open)
- ⑧ Video tape thickness detection tab
- ⑨ SPARE ID
- ⑩ Digital tape detection hole
- ⑪ SPARE ID
- ⑫ Reel hub diameter detection tab
- ⑬ S cassette digital REC inhibit plug
- ⑭ L cassette digital REC inhibit plug
- ⑮ L cassette analog REC inhibit plug (originally open)




Fig 1.




Fig 2.

The presence or absence of these plugs and tabs determines the cassette status as shown in the table below.

Analog cassette tape

No.	Plug and tab	Cassette status with or without plugs and tabs	
		With plugs and tabs	Without plugs and tabs
①	S cassette REC inhibit tab (for oxide tape)	Can be recorded (refer to Fig. 1).	Cannot be recorded (refer to Fig. 2).
②	Video tape thickness detection tab	A 20 μm thick tape is wound on the cassette.	A 15 μm thick tape is wound on the cassette.
③	Metal tape detection tab	An oxide tape is wound on the cassette.	A metal tape is wound on the cassette.
④	Reel hub diameter detection tab	For small hub	For large hub
⑤	S cassette REC inhibit plug (for metal particle tape)	Can be recorded (refer to Fig. 1).	Cannot be recorded (refer to Fig. 2).
⑥	L cassette REC inhibit plug		

Digital cassette tape

No.	PLUG AND TAB	CASSETTE STATUS WITH OR WITHOUT PLUGS AND TABS	
		WITH PLUGS AND TABS	WITHOUT PLUGS AND TABS
⑦	S cassette analog REC inhibit plug (originally open)	_____	Analog signals cannot be recorded.
⑧	Video tape thickness detection tab	_____	A 14 μm thick tape is wound on the cassette.
⑨	SPARE ID	_____	_____
⑩	Digital tape detection hole	An analog tape is wound on the cassette.	A digital tape is wound on the cassette.
⑪	SPARE ID	_____	_____
⑫	Reel hub diameter detection tab	For small hub	For large hub
⑬	S cassette digital REC inhibit plug	Can be recorded (refer to Fig. 1).	Cannot be recorded (refer to Fig. 2).
⑭	L cassette digital REC inhibit plug	Can be recorded (refer to Fig. 1).	Cannot be recorded (refer to Fig. 2).
⑮	L cassette analog REC inhibit plug (originally open)	_____	Analog signals cannot be recorded.

1-9. HOW TO PULL OUT/PUSH IN THE LOWER CONTROL PANEL

1. Take both side handles of a lower control panel and pull them slightly forward. Pull them more strongly, then the lower control panel is fixed.
2. Lift the lower control panel. The panel can be moves maximum 90 degrees.


NOTE

The lower control panel can be tilted up to 90 degrees by approximately 15 degree step. When using the lower control panel on the tilt, turn the knobs clockwise to hold the panel firmly.

3. When put back the panel assembly in the unit, replace it horizontally to the front side of the unit and then push it in the unit.

NOTE

Put back the panel assembly in the unit surely after using the unit.




Pulling out/Pushing in the Lower Control Panel

1-10. REMOVAL/INSTALLATION OF LOWER CONTROL PANEL ASSEMBLY


Removal

1. Fix a lower control panel at 90 degrees.
(Refer to Sec. 1-8. How to Pull out/Push in Lower Control Panel.)
2. Disconnect the connector (CN580) on the system set-up panel.
3. Loosen the two black screws on the lower control panel assembly. (Loosen the screws until screw's top are exposed from the lack of the lower control panel assembly.)



Disconnecting the Connector


4. While pushing the loosen black screws in the direction of the arrow, remove the lower control panel assembly from the arms.



Removal of the Panel Assembly

Installation

5. Connect the harness of the panel assembly to the connector (CN580) on the system set-up panel.
6. Fix the arms at 45 degrees.
7. Set the notches of the panel assembly to the claws of the arms and insert the panel assembly until making a click sound. Then fix the assembly with the two screws.
8. When putting back the panel assembly in the unit, replace it horizontally to the front side of the unit and then push it in the unit.



Installation of the Panel Assembly

1-11. HOW TO TAKE OUT THE CASSETTE WHEN THE TAPE IS SLACKING

When the tape is slacked in the VTR, take out the cassette tape in the procedure below while taking care not to damage the tape.

1. Turn off the POWER.
2. Remove the upper lid(s).
(Refer to Section 1-3. Removal/Installation of Cabinet.)
3. Remove the ejector assembly.
(Refer to Section 1-4. Removal/Installation of Ejector Assembly.)
4. Rotate the rotation detection pulley of the threading motor block in the direction of the arrow with fingers by about a half turn and slacken the tape.
5. Shift the ME lever toward the front panel and wind the tape inside the cassette.


NOTE

Do not shift the ME lever during normal operation (during reel table operation).


Repeat steps 4 and 5 until the unit is put into the unthreading-end state and until the tape is wound completely.

6. Fix the lower control panel assembly at the position of 90 degrees.
(Refer to Section 1-8. How to Pull out/Push in Lower Control Panel.)

7. Turn the yellow pulley of the cassette compartment motor shown in the figure clockwise until the cassette tape is ejected completely.



Winding of a Tape



Ejection of a Cassette Tape

1-12. CLEANING WHEN THE HEADS ARE CLOGGED

If the video heads are clogged, clean the heads as the following procedure.
If the video heads are clogged after cleaning by cleaning tape, clean them by cleaning piece.

1-12-1. Cleaning by Cleaning Tape

NOTE

Make sure to use the cleaning tape BCT-5CLN. If the cleaning is performed by other cleaning tape, not the BCT-5CLN, unusual friction or damage of the video head may occur.

1. Insert the cleaning tape BCT-5CLN in the unit.
2. Press the EJECT button simultaneously with PLAY button.
Head cleaning starts.
3. After 5 seconds, the cleaning tape will be ejected automatically.

NOTE

Be sure to eject the cleaning tape after cleaning to avoid damages to the heads.

4. Confirm that the head clog is clear.

1-12-2. Cleaning by Cleaning Cloth

Caution

- Turn the power off before cleaning.
- Each block in the mechanical deck consists of a precision part and is adjusted precisely. Be careful not to damage each part and to apply an excessive force during cleaning.
- Do not touch the greased portions during cleaning. If grease attaches to a cleaning cloth, replace the cleaning cloth by new one. If a cleaning cloth smeared with grease is used, grease may attach to the places where it should not.
- Do not insert a cassette tape before a cleaning fluid completely evaporates after cleaning.

Tools

- Cleaning cloth: 3-184-527-01
- Cleaning fluid: 9-919-573-01

CAUTION


Do not use a cotton swab to clean the rotary heads.

Procedures

1. Turn the power off.
2. Remove the upper lid(s).
(Refer to Section 1-3.)
3. Remove the ejector assembly.
(Refer to Section 1-4.)
4. Remove the cassette compartment.
(Refer to Section 1-3-2.)
5. Loosen the two screws and remove the upper drum cover.

NOTE

These screws cannot be removed because of stoppers.



Removal/Installation of Upper Drum Cover


6. Press the cleaning cloth moistened with cleaning fluid slightly against the rotary heads.
7. Rotate the inner drum slowly counterclockwise two or three turns and clean the rotary heads.

CAUTION

Be sure to rotate the inner drum counterclockwise and clean the rotary heads along the circumference. Do not rotate the inner drum in the direction opposite to the specified direction (clockwise) or clean it in the vertical direction. This may damage the rotary heads.

8. After cleaning, wipe it with a dry cleaning cloth two or three times.
9. Tighten the two screws while pressing the upper drum cover towards the drum support direction.

Tightening torque: $14.7 \times 10^{-2} \text{ N} \cdot \text{m}$ (1.5 Kg $\cdot$ cm)





Cleaning by Cleaning Cloth

1-13. FIXTURE AND MEASURING EQUIPMENT FOR ADJUSTMENT

1-13-1. Fixture

Fig. No.	Part No.	Description	Inscription No.	For use
1	J-6001-820-A	Drum Eccentricity Gauge (3)	_____	Inner drum eccentricity adjustment
2	J-6001-830-A	Drum Eccentricity Gauge (2)	_____	
3	J-6001-840-A or J-6325-530-A	Drum Eccentricity Gauge (1) or Drum Eccentricity Gauge (6)	_____	
4	J-6087-000-A	Drum Eccentricity Gauge (5)	_____	
5	J-6324-030-A	Drum Eccentricity Gauge (7)	MW-403	
6	J-6035-070-A	Extraction Tool (for PLCC socket)	_____	Extraction of IC (PLCC type)
7	J-6080-029-A	Small Dental Mirror (Round type ϕ 12)	_____	Cassette pillar height adjustment
8	J-6086-570-A	Reference Flat Plate	SL-657	Audio/TC head zenith adjustment
9	J-6152-450-A	Wire Clearance Check Gauge Set	_____	Clearance check
10	J-6251-090-A	Torque screwdriver's hexagonal bit (d=2.5 mm, l=120 mm)	_____	Tightening screws to fix a drum assembly and inner drum assembly
	J-6323-440-A	Torque screwdriver's hexagonal bit (d=0.89 mm, l=50 mm)	_____	Tightening screws to fix a tension regulator roller
	J-6323-500-A	Torque screwdriver's hexagonal bit (d=2 mm, l=75 mm)	_____	Tightening screws to fix a reel FG sensor
11	J-6323-420-A	Torque screwdriver's bit (+ 2 mm, l=75 mm)	_____	Tightening screws to fix a brush/slip ring assembly
	J-6323-430-A	Torque screwdriver's bit (+ 3 mm, l=90 mm)	_____	Tightening screws to fix a reel motor assembly or a ring roller
12	J-6252-510-A	Torque screwdriver (6 kg•cm)	JB-5251	Tightening screws
	J-6252-520-A	Torque screwdriver (12 kg•cm)	JB-5252	Tightening screws
13	J-6420-350-A	Extension Board (L), EX-366	_____	Large-sized printed circuit board for check and adjustment
14	J-6420-360-A	Extension Board (S), EX-378	_____	Small-sized printed circuit board for check and adjustment
15	J-6320-870-A	Reel Motor Shaft Slantness Check Fixture	MW-087	Reel motor shaft slantness adjustment
16	J-6320-880-A	Cassette Reference Plate (L)	MW-088	Reel table height adjustment, Reel motor shaft slantness adjustment
17	J-6322-610-A	Tape Guide Adjustment Driver	MW-261	Tape path alignment
18	J-6329-350-A	Reel Table Height Gauge	MW-935	Reel table height adjustment
19	J-6420-320-A	Extension Cable Set	_____	Extension of the Switching regulator
20	1-952-684-11	Extension Cable (14 P)	_____	Repair of the TBC-23/24 boards

Fig. No.	Part No.	Description	Inscription No.	For use
21	3-184-527-01	Cleaning Cloth (15 cm x 15 cm)	_____	Cleaning
22	7-432-114-11	Locking Compound 200 g	_____	Inhibits loosening of screws
23	7-661-018-18	Diamond Oil NT-68 50 ml	_____	
24	7-651-000-10	Sony Grease (SGL-601) 50 g	_____	
25	7-700-736-01	L-shaped Hexagonal Wrench (d=1.27 mm)	_____	
	7-700-736-05	L-shaped Hexagonal Wrench (d=1.5 mm)	_____	
	7-700-736-06	L-shaped Hexagonal Wrench (d=0.9 mm)	_____	
26	7-700-766-04	Hexagonal Wrench Driver (d=2.5 mm)	_____	
27	8-960-073-01	Alignment Tape, ZR5-1	_____	Digital Video and Audio alignments
	8-960-073-11	Alignment Tape, ZR2-1	_____	Tracking adjustments (for digital)
28	8-960-096-41	Alignment Tape, CR5-1B (metal particle tape)	_____	Analog Video alignments
	8-960-097-44	Alignment Tape, CR5-2A (oxide tape)	_____	Analog Video alignments
	8-960-097-45	Alignment Tape, CR8-1A (oxide tape)	_____	Analog Audio alignments
29	9-911-053-00	Thickness Gauge	_____	Clearance check
30	9-919-573-01	Cleaning Liquid	_____	Cleaning
31	J-6530-760-A	TG-0 Adjustment Fixture	DF-076	TG-0 Adjustment



1-13-2. MEASURING EQUIPMENT

It is recommended to use the measuring equipments listed below or the equivalents.
Each equipment is available as a standard product.

Equipment	Model Name	Remarks
Analog Composite Signal Generator	SONY TEKTRONIX 1410	for VPR-1 board alignment
	SONY TEKTRONIX TSG-170A	
Analog Component Signal Generator	SONY TEKTRONIX TSG-300 or TSG-370	for generating SMPTE/EBU format analog signals
Digital Component Signal Generator	SONY TEKTRONIX TSG-422(OP.1S)	for generating 4:2:2 format digital signals
Spectrum Analyzer	ADVANTEST R3261A	with external trigger function bandwidth: more than 100 MHz
Oscilloscope	SONY TEKTRONIX 2465B	
Component/Composite Wave Form Monitor	SONY TEKTRONIX WFM 300A	for measuring video levels
Wave Form/Vector Monitor	SONY TEKTRONIX 1750 or 1780R	for measuring analog composite SCH
Audio Level Meter	HEWLETT PACKARD HP3400A	
Audio Analyzer	SONY TEKTRONIX AA501A(OP.02)	for measuring distortion and levels
Audio Generator	SONY TEKTRONIX SG505(OP.02)	
Frequency Counter	ADVANTEST TR5821AK	
Digital Voltmeter	ADVANTEST TR6845	
Monitor with Serial Digital Input	SONY BVM-1410 (with optional accessory BKM-2085-14)	
Network Analyzer	ANRITSU MS-420B	
DA Converter Board (D-1)	SONY BKPF-102CA	for VPR-1 board alignment
Digital Video Interface Unit	SONY PFV-D50/D100/D200	for VPR-1 board alignment


1-14. ERROR LOGGER FUNCTION

- CH COND RED (Channel Condition Red)
When the red CHANNEL CONDITION Lamp on the upper control panel lights;
- REF ALARM (Reference Alarm)
When a reference signal is missing (no signal is input to the INPUT REF VIDEO connector)
- TAPE EJECT
When the cassette tape is ejected;
(If no error is occurred from when the cassette tape was ejected last time until it is ejected this time, the preceding time code is overwritten by this time code.)
- ERROR-xx
When a trouble is detected;
(The corresponding error code is recorded.)

When any one of the conditions mentioned above occurs, the corresponding message and time code are stored. After the power switch is turned on, the error logger function always monitors the unit to detect the errors. The contents of these data items can be read and checked in the form of a list.

Error Logger Screen

To enter the error logger screen, press the MENU button while pressing and holding the ENTRY button on the lower control panel.
The error logger data is superimposed on the monitor screen (output to the VIDEO OUTPUT COMPOSITE 3 connector or SERIAL V/A OUTPUT 4 connector). Moreover, the time counter on the lower control panel displays the error logger data by only the number of storage error times.
A maximum of 99 error data items can be stored. To display the error data items that are not displayed on the screen, turn the search dial to scroll up them. When 99 data items are exceeded, the old data is erased and the data sequence is advanced.
To exit the error logger screen, press the MENU button on the lower control panel.





Tape Operation during Error Logger Screen Display

With the error logger screen displayed, press the SET button on the lower control panel to display a block sign on the monitor screen. This enables the tape operation.
To return to the error logger screen, press the MENU button on the lower control panel.

Error Logger Data Erasure

To erase the error logger data, press the RESET button on the lower control panel in the error logger screen display.



1-15. SAFETY CHECK-OUT


After correcting the original service problem, perform the following safety checks before releasing the unit to the customer:



Check the metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.

LEAKAGE TEST


AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis must not exceed 3.5 mA. Leakage current can be measured by any one of three methods.


- (1) A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
- (2) A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
- (3) Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 5.25V; therefore, analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 20V AC range are suitable. (Refer to Fig. A)






Drum/Heads (Except CTL Head)
FRAME WIRING (1/3)
DVW-510/510P





FL1004 and FL1005 are not equipped in the DVW-A510/510/CA510.



b) C001: CASSETTE COMP. SW

This mode checks the functions of the cassette-in sensor and cassette sensor in the compartment block.

Note:

Since the maintenance mode and the sensors of compartment block on this unit do not match. Therefore, this mode cannot check the function of a sensor. As a result, the AND of the above two sensors' state is reflected on the display of the monitor screen. Switch numbers "1" and "2" change to/from "■".

LARGE CASSETTE SW does not exist in this unit. Therefore, switch number "3" on the monitor screen does not change. If switch number "3" changes to "■", check the sensor input circuit on the DR-307/200 board.

**SERVO CHECK
INPUT CHECK**

C001: CASSETTE COMP. SW
SW1: CASSETTE IN SW 1
SW2: CASSETTE IN SW 2
SW3: LARGE CASSETTE SW

3 1 2

- (1) Slide the lever guide to the left until the cassette retainer (R) is lowered.
The display on the monitor screen does not change yet.
- (2) Confirm that the two switch numbers ("1" and "2") on the monitor screen change to "■" when the cassette sensor arm is pushed manually.
- (3) Confirm that "■" returns to the switch numbers when the cassette sensor arm is released.
- (4) Raise the cassette retainer (R) so that the lever guide to the former position.
- (5) Confirm that the display on the monitor screen does not change even if the cassette sensor arm is pushed manually.

In case of NG;

When the monitor screen display changes in step (1).

Check the cassette sensor on the DU-91 or SE-237 board.

Also check IC2 on the CL-28 board.

When the monitor screen display changes in step (5).


Check the cassette-in sensor on the SE-225 board.

Also check IC2 on the CL-28 board.

When the monitor screen display does not change in step (2) or (3).

Check IC2 on the CL-28 board.

Also check the sensor input circuit on the DR-307/200 board.



Top View of the Cassette Compartment

c) C002: TOP/END SENSOR

This mode checks the function of the tape top and end sensors.

Confirm that the "OFF" display on the monitor screen changes to "ON !" when a screwdriver is brought near sensors ① and ② in the figure below. Also confirm that the display changes from "ON !" to "OFF" when the screwdriver is released from the sensors.

In case of NG;


When "ON !" is not displayed in the specified position or when the display does not return from "ON !" to "OFF" .

Check only the sensors.

Also check the sensor input circuit on the DR-307/200 board.

**SERVO CHECK
INPUT CHECK**
C002: TOP/END SENSOR

END SENSOR	TOP SENSOR
OFF	OFF



d) C013: CASSETTE COMP.

This mode checks the operation of the cassette compartment motor, and the function of the cassette down sensor.

- (1) Press the SET button (or switch S300 on the SS board).
Confirm that the compartment block goes down. At that time, confirm that the display on the monitor screen changes as shown below.

UP → HORIZ. → DOWN

- (2) Press the SET button (or switch S300 on the SS board) again.
Confirm that the compartment block goes up. At that time, confirm that the display on the monitor screen changes as shown below.

DOWN → HORIZ. → UP

**SERVO CHECK
MOTOR CHECK
C013: CASSETTE COMP.**

UP

**S300(SS-52): CHECK
S301(SS-52): RETURN**

In case of NG;

When the cassette compartment motor does not rotate.


Check the cassette compartment motor.

Also check the cassette compartment motor driver circuit (DR-307/200 board).

When the compartment block goes up and down normally, but the display does not change.

Check the cassette down sensor (SE-225 or SE-226 board).

Also check the sensor input circuit on the DR-307/200 board.



Top View of the Cassette Compartment

e) C014: CAPSTAN MOTOR

This mode checks the rotation direction of the capstan motor.

- (1) Press the SET button (or switch S300 on the SS board).
Confirm that the capstan motor rotates in the forward direction () and that the "FORWARD OK" display appears on the monitor screen.
- (2) Press the SET button (or switch S300 on the SS board) again.
Confirm that the capstan motor rotates in the reverse direction () and that the "REVERSE OK" display appears on the monitor screen.

In case of NG;

When the capstan motor does not rotate.

Check the capstan motor.

Also check capstan motor driver circuit (DR-307/200 board).

When the capstan motor rotates normally, but the "OK" display does not appear on the monitor screen.

Check the capstan motor.

Also check the capstan FG amplifier input circuit (DR-307/200 board).

```
SERVO CHECK
MOTOR CHECK
C014:CAPSTAN MOTOR
```

```
S300(SS-52): CHECK
S301(SS-52): RETURN
```

f) C015: DRUM MOTOR

This mode checks the rotation of the drum motor.

- (1) Press the SET button (or switch S300 on the SS board) to initiate this check.
The display on the monitor screen at that time is as shown below.
SPEED : NG
PHASE : UNLOCK
PG : NO EXIST

- (2) Confirm that the display on the monitor screen changes as shown at right after a little while.

In case of NG;

When the display on the monitor screen does not change.

Check the drum motor driver circuit (DR-307/200 board), the drum FG amplifier circuit (DR-307/200 board), and the drum PG amplifier circuit (DR-307/200 board).

```
SERVO CHECK
MOTOR CHECK
C015:DRUM MOTOR

SPEED :
PHASE :
PG :

S300(SS-52): CHECK
S301(SS-52): RETURN
```

SET or S300

```
SERVO CHECK
MOTOR CHECK
C015:DRUM MOTOR


SPEED : OK
PHASE : LOCK
PG : EXIST

S300(SS-52): CHECK
S301(SS-52): RETURN
```

Check completed (OK)

6-3-16.LED-200 Board

1. Turn off the power.
2. Remove the upper control panel and front sub panel.
(Refer to section 1-3-1.)
3. Remove the cassette compartment assembly.
(Refer to section 1-3-2.)
4. Disconnect the connector (CN1).
5. Remove two screws, and remove the LED-200 board.



6. Install the LED-200 board in the reverse order of steps 1 through 5.

SECTION 7

PERIODIC MAINTENANCE AND INSPECTION


7-1. CLEANING

To make the most of the functions, fully realize the performance of this unit, and to lengthen the life of the unit and tape, clean the components often.


7-1-1. General Information for Cleaning

1. Index


〈Mechanical Deck Block〉



〈Cassette Compartment〉



〈Unit〉



2. Cautions

- Turn the power off before cleaning.
- Each block in the mechanical deck consists of a precision part and is adjusted precisely. Be careful not to damage each part and to apply an excessive force during cleaning.
- Do not touch the greased portions during cleaning. If grease attaches to a cleaning cloth, replace the cleaning cloth by new one. If a cleaning cloth smeared with grease is used, grease may attach to the places where it should not.
- Do not insert a cassette tape before a cleaning fluid completely evaporates after cleaning.

3. Preparation

- (1) Turn the power off.
- (2) Remove the upper lid. (Refer to Section 1-3-1.)
- (3) Remove the ejector assembly. (Refer to Section 1-4.)
- (4) Remove the cassette compartment. (Refer to Section 1-3-2.)

7-1-8. Cassette Compartment Cleaning

Cautions

- Be careful not to apply an excessive force to the compartment when cleaning the cassette compartment.

Tools


- Cloth (or Gauze)
- Vacuum cleaner

Procedures

1. Remove the cassette compartment from the unit. (Refer to Section 1-3-2.)
2. Remove the dust on the cassette compartment from the cassette insertion inlet using a vacuum cleaner.
3. Clean the compartment (shaded portion in the figure) with a dry cloth (or gauze).

Caution

Do not apply an excessive force to the compartment block.



7-2. PERIODIC CHECK

To make the most of the functions, fully realize performance of the unit, lengthen the life of the unit and tape, a periodic check is recommended.

7-2-1. Hours Meter

This unit can display an hours meter on the time counter display of the upper control panel or on the monitor connected to this unit. Perform a periodic check with this hours meter as a reference.

1. Display procedure

Refer to Section 1-10-2 in Installation Manual.

2. Contents of display


SET-UP MENU	DESCRIPTION	TIME COUNTER DISPLAY	MONITOR DISPLAY
H01: OPERATION HOURS	Accumulated hours when the power of the unit is on	Display the time by ten hours. (Note)	Display the time by an hour.
H02: DRUM RUNNING HOURS	Accumulated hours when the drum rotates in the threading end state	Display the time by ten hours. (Note)	Display the time by an hour.
H03: TAPE RUNNING HOURS	Accumulated hours when the tape runs in the F. FWD, REW, PLAY, SEARCH, REC and EDIT modes (not including STILL mode)	Display the time by ten hours. (Note)	Display the time by an hour.
H04: THREADING COUNTER	Accumulated number of threading and unthreading times	Display the number by ten times. (Note)	Display the actual number

(Note) While pressing the JOG or SHUTTLE button on the lower control panel, display the time by an hour (or display the actual number).


〈Example〉

In a case of the total hours that the power of the unit has been turned on is 12,345 hours:

• Time Counter Display



• Monitor Display



7-2-2. Periodic Check List

The replacement time shown in the table below is not the guarantee term of parts. Use this table as guidelines for maintenance and inspection. The replacement time of parts varies depending on the operating environment and conditions of the unit.

To maintain the steady performance, it is recommended to clean the tape running system and perform the RF system automatic adjustment every the following hours as a guide.

- every 50 hours (H02) : Cleaning by cleaning tape (Refer to Section 1-12-1.)
- every 200 hours (H02) : Perform the cleaning as the following procedure.
 1. Cleaning by cleaning tape (Refer to Section 1-12-1.)
 2. Cleaning by cleaning cloth (Refer to Section 7-1-2 through 7-1-6.)
- every 500 hours (H02) : Execute the "A12: ADV EQUALIZER" (Refer to Section 5-8.)

Note: The part marked with “↓” in the table is replaced simultaneously with when the part in the column below its mark is replaced.

☆ : Replace the part. ◇ : Perform check (adjustment).

No.	Item	Menu No.	Inspection Hours (h)						Replacement Parts		
			1000	2000	3000	4000	5000	6000	Part Name	Part No.	Q'ty
Drum Block											
1	Inner Drum Assembly (Note 1)	H02	☆	☆	↓	☆	☆	↓	INNER DRUM ASSY DJR-05A-R: DVW-CA510	A-8260-746-	1
2	Brush/Slip Ring Assembly	H02	—	—	↓	—	—	↓	SR13 ASSY (RP), BRUSH: DVW-CA510	A-8267-571-	1
3	Drum Assembly (Note 1)	H02	—	—	☆	—	—	☆	DRUM ASSY DJH-05A-R: DVW-CA510	A-8260-742-	1
Cleaners											
4	Cleaning Roller (Note 4)	H02	☆	☆	↓	☆	☆	↓	ROLLER ASSY, V CLEANING	X-3167-281-	1
5	Rotary Head Cleaner Assembly	H02	—	—	☆	—	—	☆	CLEANER ASSY, VIDEO HEAD	A-8267-398-	1
6	AT Head Cleaner	H02	☆	☆	☆	☆	☆	☆	ARM ASSY, CL	X-3167-053-	1
Tape Running System											
7	Pinch Roller	H03	☆	☆	☆	☆	☆	☆	ARM ASSY, PINCH	X-3167-054-	1
8	Audio/TC Head (Note 2)	H03	—	—	◇	—	—	☆	HEAD, AUDIO PS244-2103J	8-825-779-02	1
9	CTL Head	H03	—	—	☆	—	—	☆	HEAD, CTL PS244-21B	8-825-554-83 8-825-554-84	1 1
10	Capstan Motor	H03	—	—	—	—	—	☆	MOTOR, DC SP37AA	1-698-179-12	1
Driving System											
11	Pinch Solenoid (Note 3)	H03	—	—	—	—	—	☆	SOLENOID, PLUNGER	1-454-338-00	1
		H04	Replace when used 200,000 times								
12	Brake Lining	H03	—	—	☆	—	—	☆	LINING ASSY	X-3717-205-	2
13	Reel Motor Assembly	H03	—	—	☆	—	—	☆	S Side: RM(PC) ASSY T Side: RM (TPC)ASSY	A-8267-964- A-8310-086-	1 1
Others											
14	Fan Motor	H01	Replace when used 10,000 H						FAN, DC	1-541-431-41	2
15	Filter of the Upper Drum Cover	H02	☆	☆	☆	☆	☆	☆	FILTER	3-182-649-	1

(Note 1) In an environmental condition of high humidity and excessive dust to operate the unit, it may cause in shortening the life of the heads.

Therefore, it is recommended to use the unit in an air-conditioned place at middle temperature and humidity of the specifications, and lesser dust circumstances. In addition, the tapes should be kept in the same conditions.


(Note 2) ◇: Adjust the audio frequency response. (Refer to Section 8-7.)

(Note 3) Replace the pinch solenoid when the replacement time or count is reached whichever is earlier.



(Note 4) It is recommended to replace the CR spacer (3-182-765-) at the same time.

< Mechanical Deck Block >

Procedure
Refer to Section 8-2-1.
Refer to Section 8-2-2.
Refer to Section 8-2-3.
Refer to Section 8-2-4.
Refer to Section 8-2-4.
Refer to Section 8-2-5.
Refer to Section 8-2-7.
Refer to Section 8-2-8.
Refer to Section 8-2-9.
Not Replacement
Refer to Section 8-2-10.
Refer to Section 8-2-11.
Refer to Section 8-2-12.
Refer to Section 8-2-13.
Refer to Section 8-2-14.
Refer to Section 8-2-15.



< Unit >




Note: Replace the parts shown in the table below periodically when the threading/unthreading operation is repeated frequently.

No.	Item	Menu No.	Inspection Time	Replacement Parts		
				Part Name	Part No.	Q'ty
16	Brake Solenoid	H04	Replace when used 200,000 times	PLUNGER SOLENOID	1-454-417-31	2
17	S Tension Regulator Assembly			REGULATOR ASSY, TENSION	A-8267-795-	1
18	T Tension Regulator Assembly			T-TEN ASSY	A-8267-423-	1
19	T Drawer Arm Assembly			DRAWER ASSY, T	A-8267-381-	1
20	Gear Box Assembly			BOX ASSY, GEAR	A-8267-424-	1
21	Threading Ring Assembly			RING ASSY, THREADING	A-8267-395-	1
22	Ring Roller			ROLLER, RING ROLLER, RING B	3-180-677- 3-180-679-	2 1
23	Pinch Arm Guard			GUARD, PINCH ARM	3-180-853-	1
24	CL Guide Rail			RAIL, CL GUIDE	3-180-874-	1
25	Cassette Compartment Assembly			CASSETTE COMPARTMENT ASSY	A-8310-045-	1


(Note 5) Maintenance Manual Part 2 is distributed separately. If you wish to obtain one, please consult with Sony's service organization.

< Mechanical Deck Block >

Procedure
Refer to Volume 1 of MAINTENANCE MANUAL Part 2 (Note 5)
Refer to Section 9-2-2. (Exploded view)
Refer to Section 9-2-2. (Exploded view)
Refer to Section 1-2-2.



< Cassette Compartment >



CASSETTE COMPARTMENT ASSEMBLY

SECTION 9

SPARE PARTS

9-1. NOTES ON SPARE PARTS

1. Safety Related Components Warning

Components marked $\triangle$ are critical to safe operation.

Therefore, specified parts should be used in the case of replacement.

2. Standardization of Parts

Some repair parts supplied by Sony differ from those used for the unit. These are because of parts commonality and improvement.

Parts list has the present standardized repair parts.

3. Stock of Parts

Parts marked with "o" at SP(Supply Code) column of the spare parts list may be not stocked. Therefore, the delivery date will be delayed.

4. Tension Spring

(xxT) after a tension spring is shown on the parts list in order to indicate the number of spring turns required for the use.

(Example) TENSION, SPRING (20T):

This spring must be cut at its 20th turn for actual use.

9-2. SPARE PARTS LIST – VTR –


9-2. 補修部品リスト – 本体 –

9-2-1. Index


9-2-1. インデックス

Mark	Item	Title	Page
①	S Reel Table	REEL CHASSIS (S SIDE) BLOCK	9-4
②	RS Table (S)		
③	Reel Shift		
④	T Reel Table	REEL CHASSIS (T SIDE) BLOCK	9-6
⑤	RS Table (T)		
⑥	Head Drum	DRUM AND ROTARY HEAD CLEANER BLOCK	9-8
⑦	Rotary Head Cleaner		
⑧	Tension Regulator	S TENSION REGULATOR BLOCK	9-10
⑨	CTL Head	CTL AND FE HEAD BLOCK	9-12
⑭	Threading Ring	THREADING RING AND PINCH ROLLER BLOCK	9-14
⑮	Pinch Roller		
⑯	AT Head Cleaner		
⑰	AT Head	AT HEAD AND CAPSTAN MOTOR BLOCK	9-16
⑱	Capstan Motor		
⑲	Tape Cleaner		
⑳	Pinch Press	PINCH PRESS AND GEAR BOX BLOCK	9-18
㉑	Gear Box Motor		
㉒	T Tension Regulator	T TENSION REGULATOR BLOCK	9-20
㉓	Cassette Compartment	CASSETTE COMPARTMENT BLOCK	9-22
㉔	Printed Circuit Board	PRINTED CIRCUIT BOARD (BOTTOM SIDE) BLOCK	9-24
㉕	Upper Lid	ORNAMENTAL PANEL BLOCK	9-26
	Bottom Panel		
	Cabinet (right)		
	Cabinet (left)		
㉖	Upper Control Panel	UPPER CONTROL PANEL BLOCK	9-28
㉗	Lower Control Panel	LOWER CONTROL PANEL BLOCK	9-30
㉘	Sub Control Panel	SUB CONTROL PANEL BLOCK	9-32
㉙	Connector Panel	CONNECTOR PANEL BLOCK	9-34
㉚	Power Block		
㉛	Mother Board	CHASSIS BLOCK	9-36
㉜	Ejector	EJECTOR BLOCK	9-38
㉝	Mounted Circuit Board	MOUNTED CIRCUIT BOARD BLOCK	9-40


OVERALL BLOCK




MECHANICAL DECK
(TOP VIEW)



MECHANICAL DECK
(BOTTOM VIEW)







9-2-2. Exploded Views and Mechanical Parts List


9-2-2. 分解図および機構部品リスト


No.	Part No.	SP Description	No.	Part No.	SP Description
1	A-8267-774-E	s RM ASSY	29	3-535-532-01	s SPRING, TENSION
2	A-6741-066-B	o BRAKE ASSY	30	3-648-217-00	o SPRING, TENSION
*A 3	A-8267-701-C	s FG ASSY, REEL	31	3-659-324-00	s SPRING, COMPRESSION
*B	A-8278-310-A	s FG ASSY, REEL	32	3-669-596-01	s WASHER (2.3), STOPPER
4	A-8267-703-J	s TABLE (S) BLOCK ASSY, RS	33	3-701-441-01	s WASHER, POLY 4mm DIA., 0.13T
5	A-8276-619-A	o MOUNTED CIRCUIT BOARD, PTC-71	34	3-701-441-11	s WASHER, POLY 4mm DIA., 0.25T
6	X-3166-024-1	o ARM (A) ASSY, CRANK	35	3-701-441-21	s WASHER, POLY 4mm DIA., 0.50T
7	X-3166-025-3	s TABLE ASSY, REEL	36	3-701-506-01	s SET SCREW, DOUBLE POINT 3x4
8	X-3166-060-1	o ARM (B) ASSY, CRANK	37	3-701-507-00	s SET SCREW, DOUBLE POINT M3x5
*A 9	X-3167-047-1	o BASE ASSY, REEL SHIFT	*A 38	3-717-210-01	s WORM
10	X-3717-205-1	s LINING ASSY	*A 39	3-717-212-01	o WASHER (B), WORM
11	1-454-417-31	s SOLENOID, PLUNGER	*A 40	3-717-213-01	o WASHER (A), WORM
12	1-648-570-11	o PRINTED CIRCUIT BOARD, CCM-15	41	3-717-224-01	s WASHER (B), WORM
13	1-698-152-11	s MOTOR (SVD-1449), DC	42	3-717-230-01	o BRACKET, LIMITER
14	1-807-683-11	s RESISTOR ELEMENT	43	3-717-231-01	o HOLDER, LIMITER
*A15	2-279-715-01	s RIVET, NYLON	44	3-717-266-01	o CAP (S), CG SHAFT
16	2-280-622-51	o SUPPORT (M3), HEXAGON	45	3-717-398-01	o TABLE, SLIDE
17	3-171-430-01	o GEAR, CRANK	46	3-717-399-01	s WHEEL, W
18	3-171-316-01	s GEAR, M	47	3-717-450-02	o ARM, BRAKE RELEASE
*A19	3-171-318-01	o BEARING, WORM	48	3-717-625-01	s SPACER
*A20	3-171-319-01	o SHAFT, WORM	*A 49	3-729-013-01	s SCREW (P1.4x1.6), WASHER-HEAD
*A21	3-171-320-01	o GEAR, DRIVE	50	8-719-939-05	s PHOTO INTERRUPTER GP1S54
*B	3-603-393-01	o GEAR, SHIFT	52	3-188-108-01	s WASHER, POLY 4mm DIA., 0.05T
22	3-171-397-02	o HOLDER (S), SHAFT	*A	for S/N 10001 thru. 10745:	DVM-A510(UC)
23	3-171-429-01	o GEAR, LS		for S/N 10001 thru. 10345:	DVM-A510(J)
24	3-171-431-01	s SHAFT, SLIDE		for S/N 10001 thru. 10469:	DVM-510(UC)
25	3-180-687-01	o HOLDER (A), SHAFT		for S/N 10001 thru. 10035:	DVM-510(J)
26	3-180-866-01	o BASE, LS SENSOR	*B	for S/N 10746 and higher:	DVM-A510(UC)
27	3-307-381-00	s SPRING, TENSION		for S/N 10346 and higher:	DVM-A510(J)
28	3-491-247-00	s SPRING, COMPRESSION		for S/N 10470 and higher:	DVM-510(UC)
				for S/N 10036 and higher:	DVM-510(J)







No.	Part No.	SP Description	No.	Part No.	SP Description
801	A-8274-876-C	s DRAWER ASSY, T	821	3-645-028-00	s BEARING, BALL
802	A-8267-423-C	s T-TEN ASSY	822	3-669-596-01	s WASHER (2.3), STOPPER
803	A-8267-555-D	s TG-4 ASSY	823	3-701-439-01	s WASHER, POLY 3mm DIA., 0.13T
804	A-8276-628-A	o MOUNTED CIRCUIT BOARD, TR-79		3-701-439-11	s WASHER, POLY 3mm DIA., 0.25T
805	X-3678-288-2	s GUIDE ASSY, SLANT		3-701-439-21	s WASHER, POLY 3mm DIA., 0.50T
806	X-3167-063-4	s ARM ASSY, DRAWING, T	824	3-701-439-21	s WASHER, POLY 3mm DIA., 0.50T
807	X-3167-064-5	s ARM ASSY, T TEN	825	3-717-253-01	s ROLLER
808	2-279-715-01	s RIVET, NYLON	826	3-738-730-01	s SPRING, COMPRESSION
809	3-180-262-01	s SPRING, TENSION	827	1-543-316-31	s HEAD, SENSING (SMALL TYPE)
810	3-180-404-02	o BASE, DRAWING, T	828	X-3167-347-2	s ROLLER ASSY, GUIDE
811	3-180-669-02	s FLANGE, FIXED GUIDE USE	829	3-183-460-02	s FLANGE (B), UPPER
812	3-180-670-01	o NUT, FIXED GUIDE ADJUSTMENT	830	3-183-462-02	s FLANGE, LOWER
813	3-180-708-01	s PLATE, SLANT GUIDE ADJUSTMENT	831	4-879-563-00	s SPRING, COMPRESSION
814	3-180-710-03	s GUARD, DRAWER	832	X-3167-052-2	s ROLLER ASSY, ONEBEARE
815	3-180-715-01	s SPRING, (A) TORSION COIL			
816	3-180-716-02	s SPRING, (B) TORSION COIL			
817	3-180-861-01	o HOLDER, DME			
818	3-180-863-03	s BASE, SLANT GUIDE			
819	3-190-819-01	s FLANGE, DIA. 8			
820	3-181-490-01	o SLEEVE, DIA. 7			







No.	Part No.	SP Description	No.	Part No.	SP Description
901	A-6751-278-A	o RETAINER (LEFT) ASSY, C	926	3-530-248-XX	o SPRING, TENSION (58T)
902	A-8267-900-A	s MOTOR ASSY	927	3-530-249-XX	s SPRING, TENSION (97T)
903	A-8276-813-A	o MOUNTED CIRCUIT BOARD, CL-28	928	3-677-153-00	o HOLDER
904	A-8310-045-A	s CASSETTE COMPARTMENT ASSY	929	3-677-165-03	s GEAR, MIDWAY
905	X-3167-319-1	s HOLDER ASSY, LB	930	3-677-187-00	s ROLLER, GUIDE
906	X-3687-608-1	s ROLLER (A) ASSY	933	3-688-007-01	o BRACKET, IN SWITCH
907	X-3688-001-1	o SUPPORT ASSY, C RETAINER	934	3-688-011-02	s ARM, DOWN (2)
908	X-3688-002-3	s RETAINER (R) ASSY, CASSETTE	935	3-688-024-01	o RETAINER, SPRING
909	X-3688-003-1	o SUPPORT (1) ASSY, C SENSOR	936	3-688-036-01	s RETAINER (M), CASSETTE
910	X-3688-004-1	o ARM ASSY, C SENSOR	937	3-688-043-01	o SUPPORT (H), SHAFT
911	X-3688-008-1	o SUPPORT (2) ASSY, C SENSOR	938	3-688-044-01	o GUIDE, LEVER
912	X-3688-011-2	o HOLDER ASSY, PIN	939	3-688-045-01	s SPRING (RIGHT), TORSION
913	X-3688-040-1	o SUPPORT (LEFT) ASSY, RETAINER	940	3-688-047-01	o RETAINER (H), SHAFT
914	X-3688-041-1	o RETAINER (LEFT) ASSY, C	941	3-688-054-01	s LEVER, DISCHARGE
915	1-654-100-11	o PRINTED CIRCUIT BOARD, SE-237	942	3-688-058-01	o GUIDE, CASSETTE
916	1-650-567-11	o PRINTED CIRCUIT BOARD, SE-225	943	3-688-136-01	o PLATE, GUIDE
917	1-650-568-11	o PRINTED CIRCUIT BOARD, SE-226	944	3-688-183-01	s SPRING (LEFT), TORSION
918	1-698-152-11	s MOTOR, DC SVD-1449	945	3-701-437-11	s WASHER, POLY 2mm DIA., 0.25T
919	3-183-295-01	o SHAFT, LINEAR	946	3-701-437-21	s WASHER, POLY 2mm DIA., 0.50T
920	3-183-297-01	s SPRING LC LIMITER	947	3-701-439-21	s WASHER, POLY 3mm DIA., 0.50T
921	3-183-310-01	o SLIDER, LINEAR	948	3-701-441-11	s WASHER, POLY 4mm DIA., 0.25T
922	3-183-312-01	o GUIDE, HARNESS	949	3-701-441-21	s WASHER, POLY 4mm DIA., 0.50T
923	3-183-315-03	o LC, DRIVING GEAR	950	3-723-431-01	o GEAR, MIDWAY
924	3-183-322-03	s DRIVING ARM C	951	4-890-173-00	s WASHER
925	3-480-044-00	o SPRING, COMPRESSION			







No.	Part No.	SP Description
1001	A-8275-166-A	o MOUNTED CIRCUIT BOARD, DT-34
1002	A-8313-031-A	o MOUNTED CIRCUIT BOARD, DR-307 (for S/N 11584 and higher: DVM-A510(UC)) (for S/N 10763 and higher: DVM-510(UC)) (for S/N 10685 and higher: DVM-A510(J)) (for S/N 10101 and higher: DVM-510(J)) (for S/N 10016 and higher: DVM-CA510(UC)) (for S/N 10002 and higher: DVM-CA510(J))
	A-8275-167-B	o MOUNTED CIRCUIT BOARD, DR-200N (for S/N 10001 thru. 11583: DVM-A510(UC)) (for S/N 10001 thru. 10762: DVM-510(UC)) (for S/N 10001 thru. 10684: DVM-A510(J)) (for S/N 10001 thru. 10100: DVM-510(J)) (for S/N 10001 thru. 10015: DVM-CA510(UC)) (for S/N 10001: DVM-CA510(J))
1003	A-8276-781-B	o MOUNTED CIRCUIT BOARD, HN-181B
1004	A-8276-621-A	o MOUNTED CIRCUIT BOARD, HN-184
1005	A-8276-623-B	o MOUNTED CIRCUIT BOARD, HN-185
1006	3-180-680-01	o BRACKET, HANDLE (B), HN
1007	3-180-760-01	o SUPPORT, DR
1008	3-180-762-02	o COVER (A), DT SHIELD
1009	3-180-763-02	o COVER (B), DT SHIELD
1010	3-180-819-02	o BRACKET, DEW SENSOR
1011	3-180-852-01	o BRACKET, TRANSISTOR
1013	3-180-873-06	o SHEET, INSULATING (DR)
1014	3-180-886-02	o HEAT SINK (DR)
1015	3-181-651-01	o COVER (RS), HARNESS
1016	3-531-576-11	s RIVET
1017	3-531-576-21	s RIVET
1018	3-646-084-00	o CAP, REINFORCEMENT
1019	3-646-086-00	o HOLDER, ROD
1020	3-703-141-00	o HOLDER, PRINTED CIRCUIT BOARD
1021	3-703-249-01	s SCREW, PTTWH 3x6







No.	Part No.	SP Description	No.	Part No.	SP Description
11101	A-8267-904-A	o LID, UPPER (SMALL) ASSY	1121	3-183-294-01	o LEVER, LOCK
11102	A-8267-905-A	o LID, UPPER ASSY	1122	3-183-303-01	o STOPPER, VTR
11103	X-3167-285-1	o PLATE, BOTTOM ASSY	1123	3-183-316-02	s COVER, G
11104	X-3167-324-1	o RETAINER (L) ASSY, GUIDE	1124	3-183-324-01	o PANEL, FRONT SUB
11105	X-3167-325-1	o RETAINER (R) ASSY, GUIDE	1125	3-183-325-01	o CABINET (RIGHT)
11106	X-3167-326-1	o LEVER ASSY, SW	1126	3-558-378-00	s SPRING, TENSION
11107	X-3167-327-1	o FLANGE (L) ASSY	1127	3-668-413-00	o WASHER (M3), STOP
11108	X-3167-328-1	o FLANGE (R) ASSY	1128	3-688-102-01	o SPACER, M4
11109	X-3167-331-1	s BRACKET ASSY	1129	3-688-104-01	o MEMBER, INNER
11110	X-3642-018-3	o HANDLE ASSY	1130	3-688-122-01	o BLIND
11111	X-3688-023-1	o CHASSIS (RIGHT) ASSY, LEVER	1131	3-688-140-01	o CUSHION
11112	X-3688-025-1	o CHASSIS (LEFT) ASSY, LEVER	1132	3-703-079-21	o LABEL (BACK), SUB CAUTION (for DVW-CA510P)
11113	1-553-661-00	s SWITCH, MICRO	3-703-848-01	o LABEL (N), SUB CAUTION (for DVW-CA510)	
11114	2-284-009-00	o HANDLE, (2)	3-717-392-01	o SCREW, LID	
11115	3-171-410-01	o RETAINER (S), PC BOARD	1133	3-717-392-01	o SCREW, LID
11116	3-171-489-01	o BRACKET, PLATE, BOTTOM	1134	3-733-690-01	s +B 4X6 (CU, NI)
11117	3-171-534-04	o CABINET (LEFT)	1135	4-858-760-00	s SPRING, TENSION
11118	3-180-642-01	o PLATE (S), PC BOARD RETAINER	1136	1-560-132-21	s HOUSING, 20P
11119	3-180-643-01	o CUSHION, PC BOARD RETAINER	1-508-958-21	o CONTACT, MALE	
11120	3-183-293-02	o RETAINER (L), PC BOARD			







No.	Part No.	SP Description
1201	A-8276-814-A	o MOUNTED CIRCUIT BOARD, LED-200
1202	A-8275-075-A	o MOUNTED CIRCUIT BOARD, VR-153
1203	A-8275-210-A	o MOUNTED CIRCUIT BOARD, SWC-17B
1204	A-8275-077-B	o MOUNTED CIRCUIT BOARD, FP-58
1205	A-8275-213-A	o MOUNTED CIRCUIT BOARD, VR-152B
1206	X-3165-983-3	o KNOB ASSY (WHITE), VOL
1207	X-3167-330-1	o PANEL ASSY, ON AIR
1208	X-3167-167-5	o SUB ASSY, FRONT PANEL
1209	1-517-185-21	s INDICATOR MODULE, FLUORESCENT
1210	Δ 1-762-953-11	s SWITCH, POWER
1211	3-611-769-01	s SPRING, COMPRESSION
1212	2-269-962-00	o COVER, SWITCH
1213	2-280-622-51	o SUPPORT (M3), HEXAGON
1217	3-183-301-01	o LABEL (for DVW-CA510P)
	3-183-302-01	o LABEL (for DVW-CA510)
1219	3-180-822-05	s KEY TOP 6X6
1220	3-181-398-12	s KEY TOP 6X6
1221	3-682-057-21	s SPACER (SMALL)
1223	3-688-814-01	s CAP, SWITCH
1225	3-703-141-00	o HOLDER, PRINTED CIRCUIT BOARD
1233	4-314-320-00	o HOLDER, WIRE
1234	4-874-187-01	o CLIP, CABLE
1235	4-937-336-11	s HOLDER, LED
1236	4-937-336-51	o HOLDER, LED
1237	3-704-198-01	o SUPPORT, PC







No.	Part No.	SP Description	No.	Part No.	SP Description
1301	A-8267-410-F	s DIAL ASSY, SEARCH	1326	3-180-859-02	o HOLDER, SENSOR
1302	A-8267-577-B	o PANEL ASSY, KEY	1327	3-181-398-02	s KEY TOP 6x6 (WHITE)
1303	A-8274-058-A	o MOUNTED CIRCUIT BOARD, DP-176	1328	3-181-398-12	s KEY TOP 6x6 (GRAY)
1304	A-8275-209-A	o MOUNTED CIRCUIT BOARD, KY-231B	1329	3-181-765-01	s KEY TOP 3x5
1305	A-8276-585-B	o MOUNTED CIRCUIT BOARD, PTC-69	1330	3-181-766-01	s PIN, KEY TOP
1306	1-454-606-11	s SOLENOID, PLUNGER	1331	3-181-833-02	o SPACER
1307	2-124-691-01	s ROLLER	1332	3-181-956-01	o SPRING, COMPRESSION
1308	2-124-693-02	s PLATE	1333	3-618-225-03	s NUT, PLATE
1309	2-124-695-01	o PLATE, CUSHION	1334	3-645-189-11	s SPRING, TENSION
1310	2-143-603-01	o ARM, RETURN	1335	3-668-124-00	o HOLDER, LED
1311	2-143-613-01	s SPRING, TORSION	1336	3-701-441-21	s WASHER, POLY 4mm DIA., 0.50T
1312	2-217-533-00	s SPRING, COMPRESSION	1337	3-704-198-11	o SUPPORT, PC
1313	3-180-632-01	o KNOB, DIAL	1338	3-686-086-01	s CUSHION, BUTTON
1314	3-180-633-03	s RUBBER, DIAL KNOB	1339	3-701-443-21	s WASHER, POLY 5mm DIA., 0.50T
1315	3-180-638-01	o ARM, JOINT GEAR	1341	4-937-336-51	o HOLDER, LED
1316	3-180-639-01	o PLATE, MODE SELECTION	1342	3-703-249-01	s SCREW, PTTWH 3x6
1317	3-180-640-02	o GEAR, JOINT	1343	3-180-904-03	o CHASSIS, KEY PANEL
1318	3-180-644-02	o PROTECTOR, KY			
1319	3-180-648-01	o PROTECTOR, PTC			
1320	3-180-649-02	o LINK, SOLENOID			
1321	3-180-650-03	s FG-RING			
1322	3-180-651-04	o CAM, SD			
1323	3-180-816-03	s KEY TOP, 5x9			
1324	3-180-817-03	s KEY TOP, 9x16			
1325	3-180-858-01	o HANDLE			







No.	Part No.	SP Description
1603	A-8276-622-A	o MOUNTED CIRCUIT BOARD, MB-441A
1604	X-2068-004-1	s TERMINAL ASSY
1605	1-541-431-41	s FAN, DC
1606	2-068-008-00	s WASHER
1607	2-132-434-01	s CLIP, WIRE
1608	3-180-479-03	o PLATE, MR
1609	3-180-634-01	o GUARD (MB1), AIR
1610	3-180-635-04	o PLATE, BT
1611	3-180-636-02	o PLATE, FT
1612	3-180-654-02	o PANEL, D-SUB
1613	3-180-655-01	o HARNESS (A), COVER
1614	3-180-656-01	o GUARD (MB3), AIR
1615	3-180-657-01	o GUARD (MB2), AIR
1619	3-181-652-03	o HOLDER, HARNESS
1620	3-642-656-01	s FOOT
1621	3-697-707-01	o CLAMP (A), HARNESS
1622	3-650-537-00	o WASHER





No.	Part No.	SP Description
1901	A-6729-088-A	o MOUNTED CIRCUIT BOARD, IF-36
1902	A-8267-901-A	s EJECTOR ASSY
1903	X-3721-001-2	s ROLLER (AU) ASSY
1904	X-3688-013-1	o ARM ASSY, EJ
1905	1-654-100-11	o PRINTED CIRCUIT BOARD, SE-237
1906	3-668-413-00	o WASHER (M3), STOP
1909	3-687-644-01	s GEAR, MOTOR
1910	3-688-018-01	o SHAFT, ARM
1911	3-688-019-02	o SPACER, SHAFT, ARM
1912	3-688-025-01	o GEAR, ARM
1913	3-688-108-01	s BEARING (FLANGE), BALL
1914	3-701-439-21	s WASHER, POLY 3mm DIA., 0.50T
1915	3-701-510-00	s SET SCREW, DOUBLE POINT 4X4
1916	4-314-320-00	o HOLDER, WIRE
1917	8-719-918-74	s PHOTO INTERRUPTER GP-1S04
1918	8-838-087-01	s MOTOR, DC KNS-1600A





9-2-3. Mounted Circuit Board List
9-2-3. マウント基板リスト
For DVW-A510/CA510

No.	Part No.	SP Description	No.	Part No.	SP Description
1701	A-8275-339-C	o MOUNTED CIRCUIT BOARD, VPR-1BA	1701	A-8275-399-C	o MOUNTED CIRCUIT BOARD, VPR-1BA
1702	A-8275-393-B	o MOUNTED CIRCUIT BOARD, APR-1BA (for S/N 11544 and higher: DVW-A510(UC)) (for S/N 10685 and higher: DVW-A510(J)) (for S/N 10016 and higher: DVW-CA510(UC)) (for S/N 10002 and higher: DVW-CA510(J))	1702	A-8275-343-B	o MOUNTED CIRCUIT BOARD, APR-1B (for S/N 10758 and higher: DVW-510(UC)) (for S/N 10101 and higher: DVW-510(J))
	A-8275-393-A	o MOUNTED CIRCUIT BOARD, APR-1BA (for S/N 10001 thru. 11543: DVW-A510(UC)) (for S/N 10001 thru. 10684: DVW-A510(J)) (for S/N 10001 thru. 10015: DVW-CA510(UC)) (for S/N 10001: DVW-CA510(J))		A-8275-343-A	o MOUNTED CIRCUIT BOARD, APR-1B (for S/N 10001 thru. 10757: DVW-510(UC)) (for S/N 10001 thru. 10100: DVW-510(J))
1703	A-8275-346-A	o MOUNTED CIRCUIT BOARD, SS-52BA	1703	A-8275-347-A	o MOUNTED CIRCUIT BOARD, SS-52B
1704	A-8275-349-B	o MOUNTED CIRCUIT BOARD, DIF-16B	1704	A-8275-349-B	o MOUNTED CIRCUIT BOARD, DIF-16B
1705	A-8275-155-B	o MOUNTED CIRCUIT BOARD, FEC-23	1706	A-8275-356-A	o MOUNTED CIRCUIT BOARD, CUE-1B
1706	A-8275-355-A	o MOUNTED CIRCUIT BOARD, CUE-1BA			
1707	A-8275-359-B	o MOUNTED CIRCUIT BOARD, EQ-45BA (for S/N 11644 and higher: DVW-A510(UC)) (for S/N 10685 and higher: DVW-A510(J)) (for S/N 10016 and higher: DVW-CA510(UC)) (for S/N 10002 and higher: DVW-CA510(J))	1707	A-8275-359-B	o MOUNTED CIRCUIT BOARD, EQ-45BA (for S/N 10763 and higher: DVW-510(UC)) (for S/N 10101 and higher: DVW-510(J))
	A-8275-359-A	o MOUNTED CIRCUIT BOARD, EQ-45BA (for S/N 10001 thru. 11643: DVW-A510(UC)) (for S/N 10001 thru. 10684: DVW-A510(J)) (for S/N 10001 thru. 10015: DVW-CA510(UC)) (for S/N 10001: DVW-CA510(J))		A-8275-360-A	o MOUNTED CIRCUIT BOARD, EQ-45B (for S/N 10001 thru. 10762: DVW-510(UC)) (for S/N 10001 thru. 10100: DVW-510(J))
1708	A-8275-208-B	o MOUNTED CIRCUIT BOARD, DPR-36H	1708	A-8275-208-B	o MOUNTED CIRCUIT BOARD, DPR-36H
1709	A-8275-231-A	o MOUNTED CIRCUIT BOARD, AP-28	1712	3-171-453-03	o PLATE (L), SHIELD, CARD
1710	A-8275-156-A	o MOUNTED CIRCUIT BOARD, FEC-24	1713	3-171-454-02	o SHEET (L), CARD
1711	A-8275-154-B	o MOUNTED CIRCUIT BOARD, DW-89	1714	3-171-455-01	o PLATE (S), SHIELD, CARD
1712	3-171-453-03	o PLATE (L), SHIELD, CARD			
1713	3-171-454-02	o SHEET (L), CARD	1715	3-171-456-02	o SHEET (S), CARD
1714	3-171-455-01	o PLATE (S), SHIELD, CARD	1716	3-179-084-01	s LEVER (R), PC BOARD
1715	3-171-456-02	o SHEET (S), CARD	1717	3-179-085-01	s LEVER (L), PC BOARD
1716	3-179-084-01	s LEVER (R), PC BOARD	1718	3-180-646-02	o GUIDE (L), PRINTED CIRCUIT BOARD
1717	3-179-085-01	s LEVER (L), PC BOARD	1719	3-180-674-01	o GUIDE (S), PRINTED CIRCUIT BOARD
1718	3-180-646-02	o GUIDE (L), PRINTED CIRCUIT BOARD	1720	3-696-787-03	o SHEET (S), CARD
1719	3-180-674-01	o GUIDE (S), PRINTED CIRCUIT BOARD	1721	3-696-891-03	o PLATE, CARD-S

9-2-4. Packing Materials and Supplied Accessories List

For DVW-A510

Ref. No. or Q'ty	Part No.	SP Description
1pc	* -----	CABLE, REMOTE CONTROL 9P (for J)
1pc	△ 1-551-812-11	s CORD, POWER 3P (for UC)
	△ 1-575-181-11	s CORD, POWER 3P (for J)
1pc	△ 1-793-461-11	o PLUG, CONVERSION (3P-2P)(for J)
1pc	2-990-242-01	o HOLDER (B), PLUG (for UC)
1pc	3-613-640-01	o HOLDER (C), PLUG (for J)
1pc	3-181-533-02	o CUSHION (LOWER)
1pc	3-181-534-02	o CUSHION (UPPER)
1pc	3-181-535-01	o SPACER (A)
1pc	3-181-536-01	o SPACER (B)
1pc	3-183-128-03	o INDIVIDUAL CARTON
1pc	3-701-616-01	o BAG, POLYETHYLENE
1pc	3-701-634-00	o BAG, POLYETHYLENE
4pcs	7-682-965-01	s SCREW +PSW 4X16

For DVW-510

Ref. No. or Q'ty	Part No.	SP Description
1pc	* -----	CABLE, REMOTE CONTROL 9P (for J)
1pc	△ 1-551-812-11	s CORD, POWER 3P (for UC)
	△ 1-575-181-11	s CORD, POWER 3P (for J)
1pc	△ 1-793-461-11	o PLUG, CONVERSION (3P-2P)(for J)
1pc	2-990-242-01	o HOLDER (B), PLUG (for UC)
1pc	3-613-640-01	o HOLDER (C), PLUG (for J)
1pc	3-181-533-02	o CUSHION (LOWER)
1pc	3-181-534-02	o CUSHION (UPPER)
1pc	3-181-535-01	o SPACER (A)
1pc	3-181-536-01	o SPACER (B)
1pc	3-183-481-02	o INDIVIDUAL CARTON
1pc	3-701-616-01	o BAG, POLYETHYLENE
1pc	3-701-634-00	o BAG, POLYETHYLENE
4pcs	7-682-965-01	s SCREW +PSW 4X16

For DVW-CA510

Ref. No. or Q'ty	Part No.	SP Description
1pc	* -----	CABLE, REMOTE CONTROL 9P (for J)
1pc	△ 1-551-812-11	s CORD, POWER 3P (for UC)
	△ 1-575-181-11	s CORD, POWER 3P (for J)
1pc	△ 1-793-461-11	o PLUG, CONVERSION (3P-2P)(for J)
1pc	2-990-242-01	o HOLDER (B), PLUG (for UC)
1pc	3-613-640-01	o HOLDER (C), PLUG (for J)
1pc	3-183-868-01	o PLATE, TOP
1pc	3-183-869-01	o INDIVIDUAL CARTON
1pc	3-183-871-01	o CUSHION (UPPER)
1pc	3-183-872-01	o CUSHION (LOWER)
1pc	3-701-634-00	o BAG, POLYETHYLENE
1pc	3-704-318-01	o BAG, PROTECTION


※: RCC-5G相当品。製品で購入してください。

9-3. SPARE PARTS LIST – OPTIONAL ACCESSORIES –**9-3. 補修部品リスト – オプション –****9-3-1. Index****9-3-1. インデックス**

Model Name		Page
BKDW-507 ^(*)	Audio Program Play Board	—
BKDW-509	Parallel (50P) Interface Kit	9-44
BKDW-510	Control Panel Extension Kit	9-45
BKDW-511	Control Panel Case	9-46

(*)1) Please order the standard products.


製品をお求めください。

9-3-2. BKDW-509**Exploded View**

No.	Part No.	SP Description
1	1-563-893-21	s SOCKET, D-SUB CONNECTOR 50P
2	3-180-788-01	o PANEL (RM), ORNAMENTAL
3	3-673-910-31	s SCREW, CONNECTOR
4	3-184-609-01	o GUIDE, CONNECTOR


9-3-3. BKDW-510

Exploded View



No.	Part No.	SP Description
1	A-6768-668-B	o PANEL ASSY, BLANK
2	3-717-425-01	o HANDLE
1pc	1-751-316-11	o CABLE ASSY, ENCAPSULATED

9-3-4. BKDW-511
Exploded View



No.	Part No.	SP Description
1	2-246-108-00	s CUSHION
2	2-260-992-00	o CUSHION, PANEL CASE
3	2-260-993-21	o CASE (UPPER), CONTROL PANEL
4	2-260-994-02	o CASE (LOWER), CONTROL PANEL
5	2-270-617-00	s SCREW, KNOB
6	3-661-588-00	o SPACER, 3X5

9-4. Spare Parts List

Part No.	SP Description	Part No.	SP Description
7-621-255-15	s SCREW +P 2X3	7-682-646-09	s SCREW +PS 3X5
7-621-259-25	s CSREW +PWH 2.6X4	7-682-648-09	s SCREW +PS 3X8
7-621-260-55	s SCREW +P 2.6X25	7-682-661-01	s SCREW +PS 4X8
7-621-283-10	s SCREW +P 2X10	7-682-661-09	s SCREW +PSW 4X8
7-621-559-20	s SCREW +K 2.6X4	7-682-666-09	s SCREW +PS 4X20
7-621-721-06	s SET-SCREW, SLOT 2X2.5 (FLAT)	7-682-668-09	s SCREW +PSW 4X30
7-621-733-08	s SET-SCREW, HEX 2X4 (FLAT)	7-682-902-11	s SCREW +PWH 2.6X5
7-621-734-09	s SET-SCREW, HEX 2.6X3 (WP)	7-682-903-21	s SCREW +PWH 3X8
7-621-740-08	s SET-SCREW, HEX 2.6X6 (FLAT)	7-682-947-01	s SCREW +PSW 3X6
7-621-772-00	s SCREW +B 2X3	7-682-948-01	s SCREW +PSW 3X8
7-621-772-10	s SCREW +B 2X4	7-682-949-01	s SCREW +PSW 3X10
7-621-772-20	s SCREW +B 2X5	7-682-962-01	s SCREW +PSW 4X10
7-621-772-50	s SCREW +B 2X10	7-682-965-01	s SCREW +PSW 4X16
7-621-773-95	s SCREW +B 2.6X6	7-683-174-01	s SET-SCREW, SLOT 3X4 (FLAT)
7-621-775-20	s SCREW +B 2.6X5	7-683-176-01	s SET-SCREW, SLOT 3X6 (FLAT)
7-621-775-80	s SCREW +B 2.6X16	7-683-176-21	s SET-SCREW, SLOT 3X6 (CONE)
7-622-207-05	s N 2.6, TYPE 2	7-684-023-04	s N 3, TYPE 2
7-623-205-22	s SW 2, TYPE 2	7-685-103-19	s SCREW +P 2X5 TYPE2 NON-SLIT
7-623-207-22	s SW 2.6, TYPE 2	7-685-105-19	s SCREW +PTP 2X8 TYPE2 NON-SLIT
7-623-422-07	s LW3, TYPE B	7-685-134-19	s SCREW +P 2.6X8 TYPE2 NON-SLIT
7-623-510-01	s LUG, 4	7-685-247-19	s SCREW +KTP 3X10 TYPE2 NON-SLIT
7-623-923-11	s WASHER 2.6, NYLON	7-685-646-79	s SCREW +BVTP 3X8 TYPE2 IT-3
7-623-924-11	s WASHER 3.0, NYLON	7-685-865-09	s SCREW +BVTT 2.6X12 (S)
7-624-105-04	s STOP RING 2.3 (E TYPE)	7-685-866-01	s SCREW +BVTT 2.6X14 (S)
7-624-106-04	s STOP RING 3.0 (E TYPE)	7-685-871-01	s SCREW +BVTT 3X6 (S)
7-624-108-04	s STOP RING 4.0 (E TYPE)	7-685-871-09	s SCREW +BVTT 3X6 (S, BLACK)
7-628-253-00	s SCREW +PS 2X4	7-685-872-09	s SCREW +BVTT 3X8 (S)
7-628-253-15	s SCREW +PS 2X5	7-685-873-09	s SCREW +BVTT 3X10 (S)
7-628-253-20	s SCREW +PS 2X6	7-685-875-09	s SCREW +BVTT 3X14 (S)
7-628-253-35	s SCREW +PS 2X8	7-685-879-01	s SCREW +BVTT 3X30 (S)
7-628-254-30	s SCREW +PS 2.6X10	7-685-881-01	s SCREW +BVTT 4X8 (S)
7-671-155-01	s BALL 3, STEEL	7-685-902-01	s SCREW +PTPWH 2.6X5 (TYPE2)
7-682-544-04	s SCREW +B 3X3	7-685-903-11	s SCREW +PTPWH 3X6 (TYPE2)
7-682-545-09	s SCREW +B 3X4	7-685-903-21	s SCREW +PTPWH 3X8 (TYPE2)
7-682-546-09	s SCREW +B 3X5	7-688-001-01	s W 2, SMALL
7-682-547-09	s SCREW +B 3X6	7-688-001-11	s W 2, MIDDLE
7-682-548-09	s SCREW +B 3X8	7-688-002-11	s W 2.6, MIDDLE
7-682-550-09	s SCREW +B 3X12	7-688-003-01	s W 3, SMALL
7-682-551-09	s SCREW +B 3X14	7-688-003-11	s W 3, MIDDLE
7-682-552-09	s SCREW +B 3X16	7-688-004-11	s W 4, MIDDLE

このマニュアルに記載されている事柄の著作権は当社にあり、説明内容は機器購入者の使用を目的としています。

従って、当社の許可なしに無断で複写したり、説明内容(操作、保守等)と異なる目的で本マニュアルを使用することを禁止します。

The material contained in this manual consists of information that is the property of Sony Corporation and is intended solely for use by the purchasers of the equipment described in this manual.

Sony Corporation expressly prohibits the duplication of any portion of this manual or the use thereof for any purpose other than the operation or maintenance of the equipment described in this manual without the express written permission of Sony Corporation.

Le matériel contenu dans ce manuel consiste en informations qui sont la propriété de Sony Corporation et sont destinées exclusivement à l'usage des acquéreurs de l'équipement décrit dans ce manuel.

Sony Corporation interdit formellement la copie de quelque partie que ce soit de ce manuel ou son emploi pour tout autre but que des opérations ou entretiens de l'équipement à moins d'une permission écrite de Sony Corporation.

Das in dieser Anleitung enthaltene Material besteht aus Informationen, die Eigentum der Sony Corporation sind, und ausschließlich zum Gebrauch durch den Käufer der in dieser Anleitung beschriebenen Ausrüstung bestimmt sind.

Die Sony Corporation untersagt ausdrücklich die Vervielfältigung jeglicher Teile dieser Anleitung oder den Gebrauch derselben für irgendeinen anderen Zweck als die Bedienung oder Wartung der in dieser Anleitung beschriebenen Ausrüstung ohne ausdrückliche schriftliche Erlaubnis der Sony Corporation.

DVW-A510 (UC)
DVW-510 (UC)
DVW-CA510 (UC) E
3-183-122-07 (1)

Sony Corporation
Communication System Solutions Network Company

Printed in Japan
2000. 10 08
©1993