




# Maintenance Manual

## Vision 30



# Pan and Tilt Head

---

# **Vision 30**

## **PAN AND TILT HEAD**

### **3259**

## **MAINTENANCE MANUAL**

### **AND**

## **ILLUSTRATED PARTS LIST**

### **PUBLICATION PART No. 3259-9**

### **ISSUE 3**

Copyright © Vinten Broadcast Limited 1999

All rights reserved throughout the world. No part of this document may be stored in a retrieval system, transmitted, copied or reproduced in any way including, but not limited to, photocopy, photograph, magnetic or other record without the prior agreement and permission in writing of Vinten Broadcast Limited.

Vinten, Vision and Quickfit are registered trademarks of Vinten Broadcast Limited.

---

## Foreword

This manual provides full and detailed maintenance and spare parts information for the Vinten® Vision® 30 pan and tilt head.



**WARNING!:** Read the Safety Section on [page 8](#) before using this pan and tilt head or attempting any adjustment or repair.

---

It is recommended that this manual is read carefully and the illustrations studied prior to operating or servicing the pan and tilt head. Attention to the details contained herein will ensure that the pan and tilt head will operate efficiently with the minimum of attention over a long service life. Particular attention must be paid to cleaning, especially after use in adverse conditions.

To order spare parts or to obtain further information, application should be made to Vinten Broadcast Limited or to your local distributor.

---

**NOTE:** Information contained in this document is subject to change. Vinten Broadcast Ltd reserves the right, without notice, to make changes in equipment design or performance as progress in engineering, manufacturing or technology may warrant.

---

## Notes to readers

This is the on-line version of 'Vision 30 Pan and Tilt Head Maintenance Manual' (3259-9). Readers should be aware that the pagination differs between on-line and printed versions.

### Navigation

Clicking the mouse on any [blue text](#) will move you around the document. For example, if you click on one of the blue call-outs on an exploded drawing, you will be taken to the appropriate line in the relevant parts list.

[Contents](#) Clicking here will take you to the Contents Page.

-  Clicking here will take you to the first page.
-  Clicking here will take you to the previous page.
-  Clicking here will take you to the next page.
-  Click here to go back to the previous view.

Alternatively, you may use the Acrobat Reader navigation buttons

# Contents

	<b>Page</b>
<b>Foreword</b> .....	3
<b>Notes to readers</b> .....	4
<b>Safety - Read This First!</b> .....	8
<b>Abbreviations</b> .....	9
<b>Technical Specification</b> .....	10
<b>Design Improvements</b> .....	11
<b>Section 1 - Introduction and Description</b>	
Introduction .....	12
Description .....	12
<b>Section 2 - Operation</b>	
General .....	15
Installation	
Fitting the head to its support mounting .....	16
Pan bar attachment .....	16
Fitting a camera to the head .....	16
Balancing the camera .....	18
Setting the tilt drag .....	18
Setting the pan drag .....	18
Setting the pan and tilt brakes .....	19
Operation .....	19
<b>Section 3 - Tools and Materials</b>	
Special tools .....	20
Consumable materials .....	20
<b>Section 4 - Servicing</b>	
General .....	21
Cleaning .....	21
Lubrication .....	21
Brake adjustment .....	21

<b>Contents (Cont)</b>	<b>Page</b>
<b>Section 5 - Repair</b>	
General .....	25
Repair .....	26
Platform assembly .....	26
Top cover .....	27
Front cover .....	28
End plate/adjustment thread assembly .....	28
Cross members .....	29
Mechanism block and secondary spring assemblies .....	31
Base assembly .....	33
Pan drag unit assembly .....	34
Loading bars .....	37
Side plate assembly .....	39
Tilt drag unit assembly .....	40
Other components .....	43
<b>Section 6 - Illustrated Parts List</b>	
Introduction .....	47
Ordering spare parts .....	48
Main assembly part numbers .....	48
<b>Illustrations</b>	
Fig 1.1 Vision 30 Pan and Tilt Head .....	13
Fig 2.1 Balance Graph .....	17
Fig 6.1 Vision 30 Pan and Tilt Head .....	49
Fig 6.2 Secondary Mechanism Assembly .....	52
Fig 6.3 Primary Mechanism Assembly .....	56
Fig 6.4 Side Plate Assembly .....	61
Fig 6.5 Tilt Drag Unit Assembly .....	63
Fig 6.6 Mechanism Block and Secondary Spring Assemblies .....	66
Fig 6.7 End Plate/Adjustment Thread Assembly .....	68
Fig 6.8 Platform Assembly .....	70
Fig 6.9 Pan Drag Unit Assembly .....	72
Fig 6.10 Quadrant Assembly .....	74

<b>Contents (Cont)</b>	<b>Page</b>
<a href="#">Fig 6.11 Pan Bar Assembly</a> .....	76
<a href="#">Fig 6.12 Spherical Base</a> .....	78
<a href="#">Fig 6.13 Flat Base Assembly</a> .....	80
<a href="#">Fig 6.14 Automatic Wedge Adaptor and Wedge Assemblies</a> .....	82

# Safety - Read This First!

## Warning symbols in this maintenance manual



Where there is a risk of personal injury, injury to others, or damage to the pan and tilt head or associated equipment, comments appear, highlighted by the word **WARNING!** and supported by the warning triangle symbol.

### Critical data

#### Mass

Mass 10 kg (22 lb)

#### Load

Maximum payload 35 kg (77 lb)

## Abbreviations

The following abbreviations are used in this publication:

ac	alternating current	lb	pound (weight)
A	Amps	LF	Lubricated Friction
AF	across flats	LH	left hand
A/R	as required	MISO	metric thread
ASME	American Society of Mech Engineers	m	metre
assy	assembly	mm	millimetre
BS	British Standard	N	Newton
BA	British Association thread	NPT	National Pipe thread
BSF	British Standard Fine thread	NI	not illustrated
BSP	British Standard Parallel Pipe thread	No.	number
BSW	British Standard Whitworth thread	OD	outside diameter
btn	button	PCB	printed circuit board
chs	cheese	PCD	pitch circle diameter
C of G	centre of gravity	pozi	Pozidriv
comp	compression	psi	pounds per square inch
csk	countersunk	pt	point
cu	cubic	PTFE	Polytetrafluoroethylene
c/w	complete with	PVC	Polyvinyl chloride
dc	direct current	RH	right hand
dia	diameter	sect	section
ft	foot	skt	socket
hd	head	SWG	standard wire gauge
hex	hexagon	thk	thick
Hz	Hertz (frequency)	UNC	Unified Coarse thread
IC	integrated circuit	UNF	Unified Fine thread
ID	inside diameter	V	Volts
in.	inch	W	Watts
kg	kilogram		

---

## Technical Specification

Weight	10 kg (22 lb)
Height	230 mm (9 in.)
Length	175 mm (7 in.)
Width	245 mm (9.7 in.)
Load capacity	See balance graph
Tilt range	±90°
Pan range	360°
Pedestal/tripod fixing	150 mm ball or flat base

## Design Improvements

<b>DETAILS</b>	<b>SERIAL No. INFORMATION</b>

Section 1

Introduction and Description

Contents Para
Introduction 1
Description 3
Pan and tilt drag 7
Pan and tilt brakes 8
Balance 9
Centre lock 10
Pan bar and viewfinder bracket attachment 11
Head and camera attachment 12


Introduction

1 The Vinten® Vision® 30 pan and tilt head, Part No. 3259-3 (Fig 1.1), features a unique system for the counterbalancing of different camera/lens combinations. Compensation for any camera/lens combination within the load capacity range of the head is easily accomplished via a control mounted on the rear face of the head, which enables the head to be maintained in perfect balance, with no change of feel, at any tilt angle up to 90° each side of horizontal. Centre of gravity heights from 75 mm (3 in.) to 250 mm (10 in.) above a camera mounting platform can be accommodated for a camera mass in the range of 6 kg to 45 kg. The load capacity can be increased beyond this but the range of tilt within which balance is maintained is then limited. The balance graph (Fig 2.1) shows the relationship between centre of gravity height, camera mass, and tilt range and may be used to ascertain the suitability of the head for any given combination of camera, lens and accessories. The shaded area of the graph corresponds to those loads/C of G heights that can be balanced over the full tilt range. The areas to the right indicate the progressively reducing tilt range over which the head can balance higher loads.

2 The Vision 30 head incorporates an improved version of the Vinten lubricated friction (L.F) system. The LF system allows the amount of drag for both the tilt and pan movements to be varied over a wide range to suit the operators preference and permits "whip-pan" movements to be executed, even at high drag settings. Both pan and tilt movements are provided with a friction lock and a manually operated positive lock is provided at the platform horizontal position.

Description

3 The camera mounting platform of the pan and tilt head is pivoted on a body which is itself rotatable about a fixed base.



**Fig 1.1 Vision 30 Pan and Tilt Head**

4 The fixed base houses a bearing, part of the L.F. drag system and brake mechanism for the pan function. Two types of fixed base are available, namely flat (Types 3259-3D or 3F) or spherical (Types 3259-3E or 3S). Tapped holes are provided in the flat base for attachment of the head, either directly to a support or via intermediate adaptors, while a peripheral groove in the flat base allows the head to be mounted via a Vinten Quickfix<sup>®</sup> adaptor. Heads with spherical bases are for mounting in 150 mm bowl type tripod heads. The bases, secured to the superstructure of the head by four screws, are easily interchangeable.

5 The body rotates on the base and houses the bearings, the L.F. drag and brake mechanisms for the tilt function and the operator controlled parts of the pan drag and brake mechanism. The body also houses the counterbalancing mechanism. A "Betelight" illuminated 'T' type spirit level is fitted to facilitate head levelling and there is provision for an optional viewfinder mounting bracket.

6 The tiltable mounting, with adjustable platform slide plate, pivots relative to the body. Attachment points are provided on both the left and right hand sides for pan bars and a knob is provided for the positive lock in the horizontal position. Stowage for two camera mounting screws is provided on the right hand side of the platform face. Type 3259-3D and 3E heads accommodate the camera directly on the adjustable platform slide plate, while an automatic wedge adaptor Type 3761 is provided with Type 3259-3F and 3S heads for camera attachment.

## Pan and tilt drag

7 Both the pan and tilt mechanisms incorporate lubricated friction drag systems to provide smooth movement and jerk-free break-away in the pan and tilt axes. The amount of drag applied is controlled by rotation of large ribbed control knobs, annotated PAN DRAG and TILT DRAG, mounted conveniently on the right and left hand sides of the body respectively.

## Pan and tilt brakes

8 Two friction brakes are provided one for the pan and one for tilt movements. The rotary levers, annotated PAN BRAKE and TILT BRAKE, which control these brakes are mounted below the tilt drag control on the left-hand side of the body.

## Balance

9 A large cruciform control on the rear of the body is used for adjusting the mechanism which provides the counterbalancing force for a fitted camera. Fine positioning of the camera on the platform, in a fore and aft direction, is accomplished using a lead-screw-driven platform slide. The lead screw is operated via knurled knobs at the front and rear ends of the platform. The amount of adjustment is approximately 50 mm (2 in.). The platform slide is locked in position by two knurled-headed screws on the right hand side of the platform. Scales are provided on the underside of the platform slide for reference and to facilitate re-setting.

## Centre lock

10 The position centre lock is controlled by a knob near the top LH side of the head, above the tilt drag control. This lock, retained in the OFF position by a detent, is biased by spring pressure to the engaged position when released. A locking spigot engages an aperture in the side of the head main casting when the platform is at the mid-point of the tilt range. A detent is provided at the disengaged position of the lock to prevent inadvertent engagement. The lock is released by pulling the knob out against the spring pressure and rotating the knob.

## Pan bar and viewfinder bracket attachment

11 Quadrant assemblies, each incorporating a tubular clamp, are mountable on each side of the tilting unit to enable pan bars to be attached to the head. The quadrant assemblies provide adjustment for the angle of the pan bars. A third mounting point is provided on the body, facing forward, at the lower left-hand front, for attachment of a viewfinder bracket.

## Head and camera attachment

12 The head is mounted on the tripod or pedestal support on which it is to be used via a 150 mm spherical base (Type 3259-3E or 3S heads) or a flat base (Type 3259-3D or 3F heads), which will also accept Quickfix or other mounting adaptors. Spherical bases are secured to the support using a single, central, clamp screw and flat bases are secured using four 3/8 in. hexagon-headed screws.

13 The camera may be attached directly to the platform slide plate via two screws passed through slots in the plate and screwed into the camera base. Alternatively the camera may be attached via a Vinten wedge assembly (Type 3761-13) and automatic wedge adaptor (Type 3761-3).

## Section 2

# Operation

Contents	Para
<b>General</b> .....	1
<b>Installation</b>	
Fitting the head to its support mounting .....	3
Pan bar attachment .....	6
Fitting a camera to the head .....	8
Centre screw fixing .....	9
Wedge adaptor fixing .....	10
Balancing the camera .....	12
Setting the tilt drag .....	15
Setting the pan drag .....	16
Setting the pan and tilt brakes .....	17
<b>Operation</b> .....	18

## General

1 The Vision 30 Head is part of a range including the Vision 5, 10 and 20 heads. It may be supplied already fitted in a carrying case within a packing case.

2 After removal of the head from its packing ensure that the TILT BRAKE and PAN BRAKE levers are set to the 'ON' position (levers fully clockwise) with the camera mounting platform parallel with the base and the CENTRE LOCK engaged (control knob almost touching side wall of platform). The CENTRE LOCK is provided to retain the platform in a rigid position for fitting and/or removing camera and/or lenses and for safety when a mounted camera is left unattended. The pin of the lock is biased to engage under spring pressure.



**WARNING!: Do not rely on the tilt brake mechanism alone during camera mounting/dis-mounting - use the centre lock.**

## Installation

### Fitting the head to its support mounting

- 3 The head may now be mounted to a support (pedestal, tripod, etc.). A flat based head attaches via either
- 3.1 The four 3/8 in. BSW hex. headed bolts supplied, passed upwards through the support and screwed into the head base. or
  - 3.2 A Vinten Quickfix adaptor, in which case the four 3/8 in. BSW bolts are removed and the head is secured to the adaptor by tightening the three knurled headed screws of the adaptor.
- 4 A spherical based head attaches to a 150 mm bowl tripod head. The spherical base must be very securely clamped to the support tripod.
- 5 After attachment to its support the head should be accurately levelled. This is facilitated by using the 'T' type spirit level fitted to the forward end of the tilt drag mechanism cover. The level is illuminated by integral "Betalights" for low light conditions.

### Pan bar attachment

- 6 A quadrant assembly is first loosely attached to the head by its central wingheaded stud.



**WARNING!: Do not tighten wingheaded stud if a pan bar is not fitted.**

- 7 A pan bar is inserted into the clamp ring of the quadrant assembly and the latter is rotated to achieve the required pan bar position. The wingheaded stud is then tightened to retain the pan bar and quadrant assembly in position.

### Fitting a camera to the head

- 8 It is important to ensure that the camera is complete with all its ancillary equipment (lenses, zoom and focus controls, etc) otherwise the later balancing #!of the system will be upset.



**WARNING!: The centre lock and the pan and tilt brakes must be applied before any attempt is made to fit or remove any equipment mounted on the pan and tilt head.**

### Centre screw fixing

- 9 Ensure a camera mounting screw is located in the required slot in the platform slide plate. It may be repositioned by withdrawing it from the underside of the platform slide plate and inserting in the other slot. Access to the slots is gained by repositioning the platform slide plate. It is possible that a second screw may be required if the camera/lens combination is mounted via a sub-plate. The screws are housed, when not in use, in tapped holes in the rear right hand side of the platform casting. Recheck that the CENTRE LOCK is

engaged and then, mount and secure the camera/lens combination, with their combined centre of gravity approximately over the head tilt axis.

### Wedge adaptor fixing

10 The adaptor (if not already fitted) is attached to the platform slide plate by either two 3/8 in. BSW screws passed through the slide plate slots into threaded inserts in the adaptor body, or by a minimum of four M4 screws passed through the adaptor body into the appropriate threaded holes in the slide plate. The wedge assembly is secured to the camera underside by one or two captive screws in the wedge assembly.

11 Recheck that the head CENTRE LOCK is engaged on the platform and pull out the wedge adaptor lock bar until it is held by the action of the lock pin. Offer the wedge assembly into the forward end of the adaptor body pushing the lock slide assembly against the spring tension. Lower the rear end of the wedge assembly into the adaptor body and the wedge slide will secure the rear of the wedge assembly. An audible click indicates correct engagement.




Fig 2.1 Balance Graph

## Balancing the camera

12 Balancing the Vision 30 head achieves two objectives. Firstly, when a head is correctly balanced the operator will need a minimum amount of even effort to move the head. Secondly, once balanced, the head and its payload can be set to any tilt position and the head will maintain this position with “hands off”.

13 The graph (Fig 2.1) illustrates the relationship between load and centre-of-gravity (C of G) height and may be used to ascertain the suitability of the head for any given combination of camera, lens and accessories. The shaded area of the graph corresponds to those loads/C of G heights that can be balanced over the full tilt range. The areas to the right indicate the progressively reducing tilt range over which the head can balance higher loads.

14 Ensure the pan bar or bars with zoom and focus controls are fitted to the platform, that the platform is horizontal and proceed as follows:

14.1 Turn the balance adjustment knob approximately 15 to 20 revolutions in the positive (+) (clockwise) direction.

14.2 Position the centre of gravity of the camera/lens combination over the head tilt axis by adjusting the platform slide. Slacken two slide lock screws protruding from the right hand side plate and by operation of either slide adjuster knob, positioned one at each end of the platform slide, position the slide and camera/lens combination to give equal 'fall-away' or 'centring' tendency in both directions. Relock slide in position using the two slide lock screws.

14.3 Hold the pan bar to restrain possible movement about the tilt axis and release the CENTRE LOCK (pull out and turn) and the TILT BRAKE (lever fully counter-clockwise).

14.4 By feel on the pan bar determine whether the platform 'centres' or tends to 'fall away' forwards or backwards.

14.4.1 If the platform 'centres' decrease balance by turning the adjustment knob counter-clockwise until an approximate balance is achieved.

14.4.2 If the platform tends to 'fall-away' in either direction increase balance by turning the adjustment knob clockwise until an approximate balance is achieved.

14.5 Finely trim the balance and fore and aft adjustments to achieve accurate balance throughout the full tilt range.

14.6 Re-engage CENTRE LOCK and apply TILT BRAKE.

## Setting the tilt drag

15 Hold the pan bar and release the CENTRE LOCK and TILT BRAKE. Turn the TILT DRAG control knob, on the left hand side, to the required amount of drag; clockwise to increase, counter-clockwise to decrease.

## Setting the pan drag

16 The pan drag is set in a similar manner to the tilt drag by operation of the PAN DRAG control knob on the right hand side of the head.

---

## Setting the pan and tilt brakes

17 Both the PAN BRAKE and TILT BRAKE are fully applied when the respective lever on the left hand side of the head is rotated fully clockwise.

## Operation



**WARNING!** The tilt centre lock must be engaged and the pan and tilt brakes must be applied before any attempt is made to fit or remove any equipment mounted on the pan and tilt head.

---

18 With the PAN BRAKE, TILT BRAKE applied and the CENTRE LOCK engaged, adjust the position of the pan bar to suit the operators requirements by slackening the wing headed stud and moving the pan bar and quadrant to the desired position. Retighten the wing headed stud.

---

**NOTE:** Repositioning of the pan bars may necessitate fine adjustment in the fore and aft position of the camera and of the balance.

---

19 While firmly holding the pan bar withdraw the tilt CENTRE LOCK control knob and set the PAN BRAKE and TILT BRAKE to the off position.

20 Check the freedom of movement in both pan and tilt axes and adjust the drag on each by means of the PAN DRAG and TILT DRAG control knobs to suit, the operator.

21 The PAN BRAKE and TILT BRAKE must be applied if the camera is to be left on a static shot for any period of time with the operator in control to prevent inadvertent movement.

22 If the camera is to be left unattended the PAN BRAKE and TILT BRAKE must be applied and the tilt CENTRE LOCK engaged.

## Section 3

# Tools and Materials

### Special tools

1 No special tools are required

### Consumable materials

2 The following consumable materials are required for certain procedures in Section 5.

**NOTE:** :Adhesives and lubricants are not supplied by Vinten Broadcast Ltd and should be obtained under local arrangements.

ITEM	PART No.	USE
Vinten Fluid No. 3	3051-25	Lubricated friction systems
Grease, molybdenum disulphide, GP50	Z150-081	Adjustment thread
Grease, white bearing	Z150-085	Moving contact surfaces and bearings
Grease, Shell Tonner TX-32 Slide Way	Z150-116	Platform dovetail faces
Loctite 221	Z002-026	Screw and nut locking
Loctite 270	Z002-034	Stud locking
Loctite 290	Z002-012	Push-on cover brush rivet sealing
Loctite 601	Z002-020	Sleeve attachment
Loctite 638	Z002-038	Tilt brake bore liner attachment
Loctite adhesive IS495	Z002-059	Buffer pad adhesive
Scotch Y909 adhesive tape	Z001-046	Knob label attachment

Section 4

Servicing

Contents Para
General 1
Cleaning 2
Lubrication 4
Brake adjustment 6

General

1 The Vision 30 pan and tilt head is robustly made to high engineering standards and little attention is required to maintain serviceability save regular cleaning.

Cleaning

2 During indoor use, the only cleaning required should be a regular wipe over with a lint-free cloth. Dirt accumulated during storage may be removed using a semi-stiff brush.

3 All Vision heads are weatherproof. However, use out-of-doors under adverse conditions will require special attention. Salt spray should be washed off with fresh water at the earliest opportunity.

NOTE: Use only detergent-based cleaners. DO NOT use solvent- or oil-based cleaners, abrasives or wire brushes to remove accumulations of dirt, as these damage the protective surfaces.

Lubrication

4 The roller and thrust bearings contained in the pan and tilt head are packed with grease prior to final assembly and should not require re-greasing, in normal working use, for several years.

5 With both the pan and tilt drag controls rotated fully counter-clockwise, both brake controls rotated fully counter-clockwise and the CENTRE LOCK disengaged both pan and tilt rotation should have complete freedom of movement.

Brake adjustment

6 The pan and tilt brake knobs are set during manufacture so that the brakes are fully applied when the knobs are in the vertical position. As the brakes bed in during use it may be necessary to reset the knobs.

---

7    The procedure for resetting the pan and tilt brake knobs is as follows:

7.1    Apply the brakes.

7.2    Referring to [Fig 6.2](#), remove the grubscrew (54) and pull the knob (53) off the shaft. Ensure knob retainer (53A) remains on shaft.

7.3    Turn the shaft so that the brake is fully applied and refit knob (53) in the vertical position. Secure with grubscrew (54), ensure grubscrew seats correctly in knob retainer (53A).

Section 5

Repair

<b>Contents</b>	<b>Para</b>
Repair .....	25
<b>Section 5 - Repair</b>	
Repair .....	26
Repair	
Platform assembly .....	26
Platform assembly .....	26
Platform assembly .....	27
Platform assembly .....	27
Platform assembly .....	27
Repair	
Top cover .....	27
Top cover .....	28
Repair	
Front cover .....	28
Front cover .....	28
Repair	
End plate/adjustment thread assembly .....	28
End plate/adjustment thread assembly .....	29
Repair	
Cross members .....	29
Cross members .....	29
Cross members .....	30
Cross members .....	30
Repair	
Mechanism block and secondary spring assemblies .....	31

---

Mechanism block and secondary spring assemblies .....	31
Mechanism block and secondary spring assemblies .....	32
Mechanism block and secondary spring assemblies .....	32
Mechanism block and secondary spring assemblies .....	32
<b>Repair</b>	
Pan drag unit assembly .....	34
Pan drag unit assembly .....	34
Pan drag unit assembly .....	35
Pan drag unit assembly .....	36
<b>Repair</b>	
Loading bars .....	37
Loading bars .....	38
Loading bars .....	38
Loading bars .....	39
<b>Repair</b>	
Side plate assembly .....	39
Side plate assembly .....	39
Side plate assembly .....	39
<b>Repair</b> .....	40
Tilt drag unit assembly .....	40
Tilt drag unit assembly .....	41
Tilt drag unit assembly .....	41
Tilt drag unit assembly .....	42
<b>Repair</b>	
Other components .....	43
Lower carriage roller	
Remove .....	63
Refit .....	64

---

Guide roller track blocks

Remove ..... 65

Refit ..... 66

Pan drag actuator shaft and lever

Remove ..... 67

Refit ..... 69

Pan brake actuator shaft

Remove ..... 70

Refit ..... 71

## General

1 Repair and renewal of damaged items involves disassembling various assemblies and must be carried out in accordance with the following instructions. Any load must be removed from the pedestal before carrying out the following procedures.

2 Disassembly and assembly of the various components is carried out in conjunction with figures in the Illustrated Parts List (Section 6).

**NOTE: Certain special consumable materials are required for procedures detailed in this Section. Please refer to Section 3 - Tools and Materials. For further details, please contact Vinten Broadcast Ltd or your local distributor.**

3 The Vision 30 pan and tilt head may be divided into a number of separate assemblies to facilitate repair. In use the head will have various accessories, zoom and focus controls viewfinders etc., which must be removed before dismantling the basic head. The pan bar and quadrant assemblies may be removed, for convenience, prior to performing repairs to the head. The base assembly affords protection to the pan drag unit and is removed prior to repair to this assembly or to the pan brake assembly. The automatic wedge adaptor assembly, if fitted, (Type 3259-3F and 3S heads) may remain attached to the platform assembly unless repairs to the platform are required.

4 The basic unit comprises the secondary mechanism which has the following main components/assemblies.

- 4.1 The mechanism block assembly and associated secondary spring assembly.
- 4.2 The adjustment thread assembly.
- 4.3 The two cross members.
- 4.4 The pan drag lubricated friction mechanism.
- 4.5 The pan brake mechanism.
- 4.6 The platform on which the camera equipment is mounted.

- 4.7 The primary mechanism assembly.
- 5 The primary mechanism assembly consists of the following main components/assemblies.
  - 5.1 The main casting with associated parts.
  - 5.2 The loading bars which operate in conjunction with the mechanism block assembly.
  - 5.3 The tilt drag lubricated friction mechanism.
  - 5.4 The tilt brake mechanism.
  - 5.5 The side plate which supports the right hand side of the platform.
  - 5.6 The bearing bracket and associated parts.
- 6 To remove any part of the primary mechanism assembly it is first necessary to remove the items of the secondary mechanism assembly as detailed in [Para 9](#), [Para 14](#), [Para 16](#), [Para 18](#), [Para 20](#) and [Para 24](#). The items of the secondary mechanism assembly are refitted as detailed in [Para 30](#), [Para 23](#), [Para 19](#), [Para 17](#), [Para 15](#) and [Para 13](#).

## Repair

### Pan bar and quadrant assembly

- 7 The pan bar assembly ([Fig 6.11](#) item 248) is secured in the quadrant assembly ([Fig 6.10](#) item 241) by a screw and washer ([Fig 6.1](#)). To remove the pan bar, unscrew the quadrant wing nut (243).
- 8 The quadrant assembly (241) is refitted by positioning it on a serrated plate (109) and securing with the wing nut (243).

### Platform assembly

#### Remove

- 9 The platform assembly (38) is removed as follows ([Fig 6.2](#) and [Fig 6.8](#)):
  - 9.1 Unscrew and remove two slide clamps screws (58).
  - 9.2 Unscrew and remove three M6 socket cap head screws (39) recessed in left hand upper face.
  - 9.3 Unscrew and remove four M6 button head screws (31) from right hand side plate (82).
  - 9.4 Remove platform assembly (38).

### Automatic wedge adaptor assembly

- 10 The automatic wedge adaptor assembly (281) is removed as follows ([Fig 6.14](#)):
  - 10.1 Unscrew and remove six M4 pan head screws ([Fig 6.1](#) item H) or unscrew two 3/8 BSW screws (219) (shown stowed on [Fig 6.8](#)) whichever is applicable
  - 10.2 Remove the assembly.

10.3 The adaptor assembly is refitted by a reversal of this procedure.

## Dismantle

11 To dismantle the platform assembly ([Fig 6.8](#)), proceed as follows

- 11.1 Unscrew and remove two M3 pan head screws (129) and slide out gib strip (218).
- 11.2 Tap out spirol pin (212) from one slide adjuster knob (211) and remove knob with its shim (159).
- 11.3 By turning remaining knob withdraw the slide adjuster stud (209) from threaded block (207).
- 11.4 Further dismantling of the platform will be obvious on inspection.

## Assemble

12 Reassembly of the platform assembly is performed by a reversal of the procedure detailed at [Para 11](#) noting the following points.

- 12.1 Dovetail faces should be lightly lubricated with Shell Tonner TX-32 grease.
- 12.2 The remaining moving contact surfaces should be lightly lubricated with white bearing grease.
- 12.3 The 'T' on threaded block (207) must be on visible face.
- 12.4 The gib strip (218) is lightly retained by the M3 screws.
- 12.5 Screws securing threaded block (207), platform slide block (210) and gib strip (218) are locked using Loctite 221 on the threads.
- 12.6 Dovetail insert (215) should be adjusted to ensure an easy sliding action with minimum clearance.

## Refit

13 The platform assembly is refitted by a reversal of the procedure detailed at [Para 9](#).

## Top cover

### Remove

14 The top cover (37) is removed as follows ([Fig 6.2](#)):

- 14.1 Remove platform as detailed in [Para 9](#).
- 14.2 Unscrew and remove four M4 socket cap head screws (33).
- 14.3 Remove top cover (37)

## Refit

15 The top cover is refitted by a reversal of the procedure detailed at [Para 14](#), ensuring the left-hand end is flush with the main casting (61) ([Fig 6.3](#)).

## Front cover

### Remove

16 The front cover (32) is removed as follows ([Fig 6.2](#)):

- 16.1 Remove top cover as detailed in [Para 14](#).
- 16.2 Unscrew and remove four M4 socket cap head screws (33).
- 16.3 Remove front cover (32).

### Refit

17 The front cover is refitted by a reversal of the procedure detailed at [Para 16](#), ensuring the left-hand end is flush with the main casting (61) ([Fig 6.3](#)).

## End plate/adjustment thread assembly



**WARNING!** There is risk of serious injury if any attempt is made to remove the end plate/adjustment thread assembly while the main spring is compressed, i.e. when the platform is tilted or when adjustment knob is not turned fully counter-clockwise.

### Remove

18 The end plate/adjustment thread assembly (29) is removed as follows ([Fig 6.7](#) and [Fig 6.2](#)):

- 18.1 Position tilt assembly horizontally and engage CENTRE LOCK.
- 18.2 Rotate BALANCE adjustment knob (186) fully counter-clockwise.
- 18.3 Unscrew and remove single M6 button head screw (31) below adjustment knob (186).
- 18.4 Unscrew and remove six M6 button head screws (30), three from each side of adjustment knob (186).
- 18.5 Withdraw end plate/adjustment thread assembly (29) from main casting (61) ([Fig 6.3](#)).
- 18.6 Withdraw main spring (28) from within mechanism block assembly (12).

**NOTE:** Complete dismantling of the assembly is not recommended. Should the needle thrust bearing (193) require regreasing this can be accomplished with the bearing in situ after screwing the main spring adjustment shaft (191) out of the adjustment nut (201). If it becomes necessary to remove bearing (193) a procedure for its removal is detailed at [Para 61](#).

## Refit

- 19 The end plate/adjustment thread assembly is refitted as follows ([Fig 6.7](#) and [Fig 6.2](#)):
- 19.1 Insert main spring (28) into mechanism block (12).
  - 19.2 Grease thread of main spring adjustment shaft (191) with molybdenum disulphide grease GP50.
  - 19.3 Ensure adjustment nut (201) assembled to collar (197) is screwed up to thrust race (192) on end bracket (195) by turning adjustment knob (186) fully counter-clockwise.
  - 19.4 Insert main spring adjustment shaft (191) into mechanism block (12) ensuring plain end of shaft (191) is inserted in the mechanism blocks adjustment shaft bearing (169) ([Fig 6.6](#)) and that the guide roller bearing (199) engages in the lower trackway in the primary mechanism assembly.
  - 19.5 Secure end bracket (195) to main casting (61) with six M6 button head screws (30) removed at [Para 18.4](#) and one M6 button head screw (31) removed at [Para 18.3](#).
  - 19.6 Turn adjustment knob (186) clockwise two or three turns to apply light pressure to main spring (28).
  - 19.7 If mechanism block assembly (12) has not been disturbed slacken four M5 button head screws (14) securing load beam (174) ([Fig 6.6](#)).
  - 19.8 Checking that loading bar assemblies (119) and (130) are positioned vertically and that secondary spring (176) ([Fig 6.6](#)) is centrally located in its bore in balance mechanism block (166), tighten load beam securing screws (14).

## Cross members

### Remove

- 20 The procedure for both front and rear cross members (15 and 21 respectively) is similar except that the rear cross member is fitted with two additional rollers. The procedure is as follows ([Fig 6.2](#)):
- 20.1 Remove platform assembly as detailed at [Para 9](#).
  - 20.2 Remove top cover as detailed at [Para 14](#).
  - 20.3 Remove front cover as detailed at [Para 16](#).
  - 20.4 Remove end plate/adjustment thread assembly and main spring as detailed at [Para 18](#).
  - 20.5 Unscrew and remove M4 button head screw (16) from each end of cross member (15) or (21) - front or rear respectively.
  - 20.6 Lift cross member (15) or (21) from its locating pins (93) ([Fig 6.3](#)).

### Dismantle

- 21 To dismantle the cross member continue as follows ([Fig 6.2](#)):
- 21.1 For each yoke type track roller (17):

- 21.1.1 Slacken M3 socket head grub screw (20) securing axle-cross member roller (19).
- 21.1.2 Press out axle (19) and remove track roller (17) and its associated shims (18).
- 21.2 For each lateral guide roller (22) on rear cross member (21):
  - 21.2.1 Unscrew and remove M4 button head screw (24).
  - 21.2.2 Remove bush (23) complete with its lateral guide roller (22).

## Assemble

- 22 The cross members are assembled as follows ([Fig 6.2](#)):
  - 22.1 For each lateral guide roller (22) on rear cross member (21):
    - 22.1.1 Assemble lateral guide roller (22) to its bush (23).
    - 22.1.2 Assemble bush (23) and roller (22) to cross member (21) using M4 button head screw (24) removed at [Para 21.2.1](#). Do not fully tighten screw at this stage.
  - 22.2 For each yoke type track roller (17):
    - 22.2.1 Apply white bearing grease to track roller (17) and faces of shims.
    - 22.2.2 Assemble track roller (17) with one shim (18) on each side face into cross member and retain with an axle (19) removed at [Para 21.1.2](#). Ensure M3 socket head grub screw (20) is seated on flat of axle and that axle is flush with inner face of cross member.
    - 22.2.3 Tighten M3 socket head grub screw (20) to retain axle (19).

## Refit

- 23 To refit the cross members continue as follows ([Fig 6.2](#)):
  - 23.1 Apply white bearing grease to cross member locating pins (93).
  - 23.2 Very sparingly apply Loctite 221 into tapped hole of locating pins (93).
  - 23.3 Position each cross member on its respective locating pins (93).

---

**NOTE: The lateral guide rollers (22) on the rear cross member (21) locate between the two vertical tracks machined into the rear of the mechanism block assembly (12).**

---

- 23.4 Insert M4 button head screws (16) and evenly adjust both ends of each cross member so that yoke type track rollers (17) just contact mechanism block tracks (168) ([Fig 6.6](#)) with no pre-load. Check no clearance exists between any horizontal track and associated roller (8 positions).
- 23.5 Adjust lateral position of mechanism block assembly (12) to equalize clearance between block (166) should be central with guide roller tracks (90) ([Fig 6.3](#)) on inner surface of main casting (61).
- 23.6 Tighten lateral guide roller screws (24) on rear cross member (21) so that there is no clearance between rollers and their tracks on mechanism block (166). Do not pre-load.

---

## Mechanism block and secondary spring assemblies

### Remove

- 24 The mechanism block assembly (12) is removed as follows (Fig 6.6):
- 24.1 Remove platform assembly as detailed at [Para 9](#).
  - 24.2 Remove top cover as detailed at [Para 14](#).
  - 24.3 Remove front cover as detailed at [Para 16](#).
  - 24.4 Remove end plate/adjustment thread assembly and main spring as detailed at [Para 18](#).
  - 24.5 Remove cross members as detailed at [Para 20.5](#) and [Para 20.6](#).
  - 24.6 Unscrew and remove two M5 button head screws (14) from each end of load beam (174).
  - 24.7 Remove two spring plugs (27), springs (26) and plunger-carriage assembly (25) from mechanism block (Fig 6.2)
  - 24.8 Lift out mechanism block assembly (12).
  - 24.9 Retain shims (13) from tops of loading bars (119) and (130) noting their orientation for replacement.

### Dismantle

- 25 To dismantle the mechanism block assembly (12) continue as follows (Fig 6.6):
- 25.1 Unscrew and remove secondary spring adjustment plug (181) and inspect buffer pad-lower end (182) for deterioration.
  - 25.2 Unscrew and remove two M4 socket countersunk head screws (179) securing first stop plate-secondary spring (178). Remove stop plate and inspect buffer pad-stop plate (180) for deterioration.
  - 25.3 Repeat [Para 25.2](#) for second stop plate-secondary spring.
  - 25.4 Lift out secondary spring assembly (171).
  - 25.5 Inspect rubber buffer-spring carriage (170) for deterioration.
  - 25.6 Inspect vertical and horizontal track faces for scoring.
- 26 To dismantle the secondary spring assembly (171) continue as follows:
- 26.1 Remove spring guide-lower (177) and remove spring (176).
  - 26.2 Withdraw screw (172) and separate guide-top (175) and load beam (174).
  - 26.3 Degrease screw shank and spring guide-top.
  - 26.4 Inspect buffer pads (173), on underside of screw (172) head and underside of load beam (174), for deterioration.

## Buffer pad renewal

27 In the event that any of the buffer pads on the mechanism block assembly or the secondary spring assembly have deteriorated they should be replaced. Remove all traces of the defective pad and adhesive, ensure both pad and component are free from greasy deposits (use IS Quick Clean) and secure new pads with Loctite adhesive IS495. Ensure the following conditions are achieved:

- 27.1 Stop plate-secondary spring (178) pad must be flush with inner edge of stop plate.
- 27.2 Buffer pad-lower end (182) on adjustment plug (181), rubber buffer-spring carriage (170), buffer pad on load beam (174) and buffer pad on screw (172) must be positioned concentrically.
- 27.3 Ensure sound joint is made.

## Assemble

28 The secondary spring assembly is assembled as follows ([Fig 6.6](#)):

- 28.1 Lightly apply white bearing grease to shank of screw (172). Avoid applying grease to thread.
- 28.2 Pass screw (172) shank through load beam (174) and spring guide top (175).
- 28.3 Fit spring (176) over screw (172) shank and tubular part of spring guide-top (175).
- 28.4 Screw on spring guide-lower (177) a few turns and then sparingly apply Loctite 221 to screw thread in free end of spring guide-lower (177). Continue to tighten and adjust until all axial movement of components is removed without causing any pre-load to spring. This adjustment is critical.

29 The mechanism block assembly is assembled as follows:

- 29.1 Ensure adjustment shaft bearing (169) is flush with balance mechanism block (166) end face.
- 29.2 Assemble secondary spring assembly (171) into balance mechanism block (166).
- 29.3 Retain secondary spring assembly (171) with stop plates-secondary spring (178) and M4 screws (179) removed at [Para 26](#), ensuring rubber buffers orientated correctly. Lock screws with Loctite 221. Ensure buffer pads-stop plate (180) are not pinched between stop plate (178) and balance mechanism block (166).
- 29.4 Fit adjustment plug (181) and adjust until all axial clearance of components has been removed without causing any pre-load to spring (176). This adjustment is critical. Secure adjustment plug (181) with Titanine.

## Refit

30 The mechanism block assembly is refitted as follows ([Fig 6.6](#)):

- 30.1 Position mechanism block assembly (12) on lower guide rollers (17) ([Fig 6.3](#)) in primary mechanism (2) ensuring that loading bars (119) and (130) are correctly orientated and engaged with load beam (174).
- 30.2 Apply downward pressure to mechanism block assembly (12) and ensure block sits squarely on all four rollers (17) with no perceptible rock. If block does not sit squarely proceed as follows:
  - 30.2.1 Slacken locking screw (5) ([Fig 6.3](#)) at right rear axle position.

- 30.2.2 Adjust adjustable axle (87) ([Fig 6.3](#)) until block ceases to rock.
- 30.2.3 Tighten locking screw (5) and recheck block for stability.
- 30.2.4 Repeat [Para 30.2.1](#) to [Para 30.2.3](#) if necessary.
- 30.3 Refit two plunger (carriage assemblies) (25), springs (26) and spring plugs (27) removed at [Para 24.7](#). Ensure ends of spring plugs (27) are flush with front face of balance mechanism block (166).
- 30.4 Continue refitting procedure at [Para 31](#) or [Para 32](#) as appropriate.
- 31 If it has been necessary to change any of the buffer pads proceed as follows:
  - 31.1 Temporarily attach platform assembly (38) by a reversal of procedure at [Para 9.2](#) to [Para 9.4](#).
  - 31.2 Using two sets of feeler gauges measure clearance between loading bars (119) and (130) and load beam (174) and note dimensions, which should be approximately equal. Care must be exercised to ensure no bias is put onto loading bars during this operation.
  - 31.3 Remove platform assembly as detailed at [Para 9.2](#) to [Para 9.4](#).
  - 31.4 Peel laminations from new load beam shims (13) ([Fig 6.2](#)) to achieve dimensions noted at [Para 31.2](#).
  - 31.5 Assemble shims into position and retain each with two M5 button head screws (14) passed through load beam into respective loading bar. Do not tighten screws at this stage. Final tightening is performed during refitting of end plate/adjustment shaft assembly.
  - 31.6 Continue refitting at [Para 33](#).
- 32 If no buffer pads have been changed proceed as follows:
  - 32.1 Refit shims removed at [Para 24.9](#), ensuring same orientation as removed.
  - 32.2 Retain shims with two M5 button head screws (14) passed through load beam into each loading bar. Do not tighten screws at this stage. Final tightening is performed during refitting of end plate/adjustment thread assembly.
- 33 Continue the mechanism block assembly refitting as follows:
  - 33.1 Refit cross members as detailed at [Para 23](#).
  - 33.2 Refit main spring and end plate/adjustment thread assembly as detailed at [Para 19](#).
  - 33.3 Refit front cover as detailed at [Para 17](#).
  - 33.4 Refit top cover as detailed at [Para 15](#).
  - 33.5 Refit platform assembly as detailed at [Para 13](#).

## Base assembly

- 34 The base assembly (either spherical (266, [Fig 6.12](#)) or flat (276, [Fig 6.13](#)) is removed by unscrewing and removing the four M5 socket cap head screws ([Fig 6.1](#) item D) and lifting the head from the base. The base is refitted by a reversal of this procedure.

## Pan drag unit assembly

### Remove

- 35 The pan drag unit assembly (3) is removed as follows ([Fig 6.2](#)):
- 35.1 Align two notches in periphery of pan drag unit assembly (3) with securing screws (10) of brake flange assembly (9).
  - 35.2 Unscrew and remove two M4 button head screws (10) and remove brake flange assembly (9). Do not operate the PAN BRAKE knob (53) if movement of brake housing body (68) is restricted, i.e. in contact with work bench.
  - 35.3 Unscrew and remove six M5 socket cap head screws (4) and (5) from periphery of pan unit top plate (224), noting position of two shorter screws for refitting.
  - 35.4 Lift pan drag unit assembly away from head withdrawing square drive of drag actuator shaft (230) from pan drag lever (76). Remove brake segment assembly (6) from pan brake actuator shaft (69).
- 36 To remove the pan drag unit from the assembly proceed as follows ([Fig 6.9](#)):
- 36.1 Support assembly over a shallow tray to catch lubricating fluid as drag unit elements are separated.
  - 36.2 Remove bleed screw (236) from push-on cover assembly (233).
  - 36.3 Remove push-on cover assembly (233).
  - 36.4 Drain off lubricating fluid.
  - 36.5 Unscrew and remove four M4 socket cap head screws (41) securing friction shoe carrier-top (228) to pan unit top plate (224).
  - 36.6 Unscrew and remove two M4 socket button head screws (227) retaining pan drag housing (226) to bearing housing (221).
  - 36.7 Separate pan drag unit sub-assembly from pan unit bearing sub-assembly. Two M4 jacking holes are provided in top plate (224) to enable the pan drag unit sub-assembly to be pushed out.

### Dismantle

- 37 To dismantle the pan drag unit sub-assembly proceed as follows ([Fig 6.9](#)):
- 37.1 Unscrew and remove four M5 countersunk socket head screws (110) securing friction shoe carrier-lower (231) to friction shoe carrier-top (pan) (228). Remove friction shoe carrier-lower (231).
  - 37.2 Remove shim (229).
  - 37.3 Withdraw drag actuator shaft (230) from friction shoe carrier-top (228). The four actuator rods (151) will pivot outwards with the shaft and may be removed.
  - 37.4 Remove second shim (229).
  - 37.5 Remove four friction shoe assemblies (144) and two friction shoe pivots (143).

- 37.6 Separate friction shoe carrier-top (228) from pan drag housing (226).
- 37.7 Inspect 'O' rings (232) and (148) and omniseal (153) for deterioration or damage.
- 38 To dismantle the pan unit bearing sub-assembly proceed as follows ([Fig 6.9](#)):
- 38.1 Unscrew and remove two M3 Posidriv countersunk head screws (106) locking bearing nut (225) to pan unit top plate (224).
- 38.2 Unscrew and remove bearing nut (225).
- 38.3 Separate bearing housing (221) from pan unit top plate (224) and remove needle thrust bearing (222) and two thrust washers (223).
- 38.4 Inspect needle thrust bearing (222) and deep groove bearing (62) in bearing housing (221) for wear.

## Assemble

- 39 To assemble the pan unit bearing sub-assembly proceed as follows ([Fig 6.9](#)):
- 39.1 Lubricate both bearings (62) and (222) with white bearing grease.
- 39.2 Fit deep groove bearing (62), if necessary. Refer to [Para 60](#).
- 39.3 Assemble thrust washer (223), needle thrust bearing (222) and second thrust washer (223) into groove of bearing housing (221).
- 39.4 Mate bearing housing (221) with pan unit top plate (224) and secure with bearing nut (225). Tighten bearing nut (225) to a torque of 3.6 Nm (32 lbf in.).
- 39.5 Lock bearing nut (225) with two M3 Posidriv screws (106) removed at [Para 38.1](#).
- 40 To assemble the pan drag unit sub-assembly proceed as follows ([Fig 6.9](#)):
- 40.1 Lightly apply white bearing grease to all moving contact surfaces particularly 'O' ring (148), friction shoe assembly (144) pivot blades, friction shoe pivots (143), 'O' ring (232), and omniseal (153).
- 40.2 Fit 'O' ring (148) into internal groove of friction shoe carrier-top (228).
- 40.3 Pass a shim (229) over drag actuator shaft (230) and assemble shaft into friction shoe carrier-top (228).
- 40.4 Fit a friction shoe pivot (143) into its location on friction shoe carrier-top (228).
- 40.5 Fit a pair of friction shoe assemblies (144) to pivot (143), interleaving pivot blades.
- 40.6 Repeat 40.4 and 40.5 at the other position on friction shoe carrier-top (228).
- 40.7 Position second shim (229) centrally over end of drag actuator shaft (230).
- 40.8 Locate friction shoe carrier-lower (231) over friction shoe pivots (143) and spirol pins (111).
- 40.9 Secure friction shoe carrier-lower (231) to drag actuator shaft (230) with four M5 socket countersunk head screws (110) removed at [Para 37.1](#). Lock screws with Titanine.

40.10 Swing a friction shoe assembly (144) outwards, fit an actuator rod (with each end lubricated with Vinten Fluid No. 3 into its location in drag actuator shaft (230) and swing friction shoe assembly (144) inwards locating outer end of drag actuator rod (151) in the cup in friction shoe assembly (144).

40.11 Repeat [Para 40.10](#) for each actuator rod (151) in turn.

40.12 Assemble friction shoe carrier sub-assembly (228/231) into pan drag housing (226).

40.13 Fit omniseal (153) into pan drag housing (226) recess adjacent friction shoe carrier-top (228) ensuring that the seal is not distorted or damaged.

---

**NOTE: The open side of the seal must be towards the fluid chamber.**

---

41 Further assembly of the pan drag unit sub-assembly should be performed over a shallow tray to catch any spilt fluid. Continue as follows ([Fig 6.9](#)):

41.1 Supporting the pan drag unit sub-assembly with drag actuator shaft (230) square end downwards, introduce Vinten Fluid No. 3 into drag housing (226) ensuring the fluid fills the spaces within friction shoe carriers (228/231). This is a slow process and sufficient time for fluid settlement must be allowed. The chamber must be 3/4 filled.

41.2 Fit 'O' ring (232) in the peripheral groove of pan drag housing (226).

41.3 Check fluid level in pan drag housing (226).

41.4 Press push-on cover (233) over pan drag housing (226).

41.5 When lubricant has ceased to flow from central bleed hole in push-on cover (233) ensure cover is fully seated and screw M3 Posidriv pan head screw (236), secured with Blue Hylomar sealant, into the bleed hole.

42 To assemble the pan drag unit assembly proceed as follows ([Fig 6.9](#)):

42.1 Locate spirol pins (300) in friction shoe carrier-top (228) into their locations in pan unit top plate (224).

42.2 Secure friction shoe carriers (228/231) to pan unit top plate (224) using four M4 socket cap head screws (41) removed at [Para 36.5](#). Retain screws with Loctite 221, used sparingly, ensuring this only contacts the threads.

42.3 Secure pan drag housing (226) to bearing housing (221) with two M4 pan head screws (227), removed at [Para 36.6](#), in diametrically opposite holes.

## Refit

43 To refit the pan drag unit assembly proceed as follows ([Fig 6.2](#)):

43.1 Fit brake segment assembly (6) removed at [Para 35.4](#) onto spigot of pan brake actuator shaft (69).

43.2 Align pan unit top plate cut-out with brake flange assembly mounting position, and offer pan drag unit assembly (3) to the underside of primary mechanism assembly (2).

43.3 Ensure square end of drag actuator shaft (230) engages correctly with aperture of pan drag lever (76) within primary mechanism assembly (2). If difficulty is experienced reposition drag lever by adjustment of pan drag knob (49).

43.4 Secure pan drag unit assembly (3) with six M5 screws (4) and (5) removed at [Para 35.3](#) ensuring two shorter screws (5) are refitted in their correct positions.

43.5 Position brake flange assembly (9) and secure with two M4 button head screws (10) removed at [Para 35.2](#).

## Loading bars

### Remove

44 The LH or RH loading bar assembly is removed as follows ([Fig 6.3](#)):

44.1 Comply with [Para 6](#).

44.2 Remove external circlip (121).

44.3 Remove washer-actuator bearing (120).

44.4 Remove loading bar assembly (119) or (130) and second washer-actuator bearing (120).

## Dismantle

45 To dismantle a loading bar assembly continue as follows (Fig 6.3):

45.1 For each yoke type track roller-follower (125):

45.1.1 Press out spirol pin (127) from interference fit side of loading bar (one side is clearance). Ensure side wall of loading bar (122/131) is not distorted during this operation.

45.1.2 Slide axle retainer (124) towards exposed roller face to release roller axle (126). Both retainers (124) must be correctly positioned before axle (126) may be removed.

45.1.3 Push out roller axle (126) and remove roller (125) and two axle retainers (124).

45.2 Repeat 45.1 for second roller (125).

45.3 If necessary, drawn cup needle bearing (123) may be pressed out. Ensure adequate support to prevent distortion of loading bar (122/131).

## Assemble

46 To assemble a loading bar assembly proceed as follows (Fig 6.3):

46.1 Apply white bearing grease to all bearings and the faces of axle retainers (124).

46.2 If drawn cup needle bearing (123) requires fitting this must be pressed into the loading bar flush with the base of the counterbored hole.

46.3 For each yoke type track roller-follower (125):

46.3.1 Hold roller (125) and two axle retainers (124) in position and pass roller axle (126) through the hole in loading bar, retainers and roller.

46.3.2 Slide axle retainer (124) inward to retain roller axle (126) (retainers engage grooves around axle) and ensure the smaller holes in axle retainers (124) align with the small holes in the loading bar.

---

**NOTE: If the holes do not align it is possible axle retainers (124) are incorrectly seated in axle (126) grooves.**

---

46.3.3 Secure axle retainers (124) with spirol pin (127) passed through the loading bar via the clearance hole in the counterbored face.

46.4 Repeat 46.3 for second roller (125).

46.5 Apply white bearing grease to the ends of each roller axle (126) for protection.

## Refit

47 The LH or RH loading bar assembly is refitted as follows ([Fig 6.3](#)):

47.1 Apply white bearing grease to both washers-actuator bearing (120) and drawn cup needle bearing (123).

47.2 Fit washer-actuator bearing (120) to side plate assembly (82) or tilt drag unit assembly (100) stub shaft (134) with the chamfer of washer (120) towards stub shaft (134) shoulder.

47.3 Fit loading bar assembly (119) or (130) to the stub shaft with the rollers towards the rear and the chamfered end downwards.

47.4 Fit second washer-actuator bearing (120) to stub shaft (134).

47.5 Retain the loading bar assembly on stud shaft (134) with external circlip (121).

47.6 Comply with [Para 6](#).

## Side plate assembly

### Remove

48 The side plate assembly (82) is removed as follows ([Fig 6.4](#)):

48.1 Comply with [Para 6](#).

48.2 Remove RH loading bar assembly (119) as detailed at [Para 44](#).

48.3 Exercising care to prevent damage to the thin label, gently prise off PAN DRAG label (52) ([Fig 6.2](#)) and remove the adhesive tape from drag knob (49).

48.4 Unscrew and remove three M4 countersunk head screw (50) and remove drag knob (49).

48.5 Unscrew and remove two M2.5 countersunk head screws (48) ([Fig 6.3](#)) securing drag knob retainer (47) and remove retainer (47).

48.6 Remove drag knob centre (46)

48.7 Remove snap ring (83).

48.8 Withdraw side plate assembly (82) and remove bearing shield (66).

### Dismantle and assemble

49 The dismantle and assembly procedures for the side plate assembly are self-explanatory using standard techniques. Refer to [Fig 6.4](#).

### Refit

50 The side plate assembly is refitted as follows:

50.1 Reverse the procedure at [Para 48](#).

- 50.2 Re-attach PAN DRAG label (52) with Scotch Y909 adhesive tape.
- 50.3 Refit RH loading bar assembly (119) as detailed at [Para 47](#).
- 50.4 Comply with [Para 6](#).

## Tilt drag unit assembly

51 To repair components of the tilt drag unit in isolation and in situ, it is only necessary to follow the procedure detailed in [Para 52.3](#) to [Para 52.5](#) to gain access for dismantling the unit and then proceed with dismantling as per [Para 54](#). Reassembly for this procedure is detailed at [Para 58.5](#). If repair to the complete tilt drag unit assembly is required proceed as per [Para 52](#).

### Remove

- 52 The tilt drag unit assembly (100) is removed as follows:
  - 52.1 Comply with [Para 6](#).
  - 52.2 Remove LH loading bar assembly (130) as detailed at [Para 44](#).
  - 52.3 Remove side cover (40) as follows ([Fig 6.2](#)):
    - 52.3.1 Fully apply the pan and tilt brakes, then slacken M3 socket head grub screws (54) securing TILT BRAKE and PAN BRAKE knobs (53). Remove knobs and retainers (53A).
    - 52.3.2 Exercising care to prevent damage to the thin label, carefully prise label (51) from TILT DRAG control knob (49). Remove adhesive tape.
    - 52.3.3 Unscrew and remove three M4 countersunk head screws (50) securing knob (49). Remove knob.
    - 52.3.4 Unscrew and remove two M2.5 countersunk head screws (48) securing knob retainer (47). Remove retainer.
    - 52.3.5 Unscrew drag knob centre (46) from tilt drag adjustment stud (150). Remove thick thrust washer (43), needle thrust bearing (44), and thin thrust washer (45) from drag knob centre (46). (f
    - 52.3.6 Unscrew and remove four M4 button head screws (42) exposed by the removal of drag knob centre (46).
    - 52.3.7 Unscrew and remove four M4 socket cap head screws (41) securing side cover (40).
    - 52.3.8 Remove side cover (40). Two jacking holes are provided at 90 degrees to the spirol pins (111).
  - 52.4 Unscrew and remove four M5 socket cap head screws (96) and (97) ([Fig 6.3](#)) noting the position of the short screw (96) for refitting.
  - 52.5 Slide bearing bracket (95) off tilt drag unit assembly (100). Do not slacken or remove bearing nut (105) or associated locking screws (106).
  - 52.6 Unscrew and remove two M4 socket button head screws (24) securing brake flange assembly-tilt (101).

52.7 Remove brake housing body-tilt (99) with tilt brake shaft (103), shim (104), and brake segment assembly (6). Remove brake flange assembly (101) via the access hole.

52.8 Remove snap ring (83).

52.9 Withdraw tilt drag unit assembly (100) and remove bearing shield (66).

53 If it is required to service the tilt drag unit assembly in situ refer to [Para 51](#). Precautions must be taken to prevent fluid contamination of other components.

## Dismantle

54 To dismantle the tilt drag unit assembly continue as follows ([Fig 6.5](#)):

54.1 Support the assembly over a shallow tray to catch the lubricating fluid.

54.2 Unscrew and remove M2.5 Posidriv countersunk head bleed screw (156).

54.3 Unscrew and remove eight M3 socket countersunk head screws (155) from the periphery of top plate (154). Remove top plate (154) anticipating possible fluid loss as this is done.

54.4 Remove omniseal (153) and inspect for deterioration.

54.5 Remove the drag unit from tilt drag housing (141).

54.6 Unscrew and remove four M5 socket button head screws (14) and remove friction shoe carrier-lower (152).

54.7 Remove friction shoe carrier-top (142) from drag actuator shaft (149).

54.8 Remove 'O' rings (148) and inspect for deterioration.

54.9 Further dismantling of the tilt drag unit, if necessary, is self-evident.

## Assemble

55 The tilt drag unit assembly is assembled as follows:

55.1 Lightly apply white bearing grease to all moving contact surfaces particularly 'O' rings (148), friction shoe assembly (144) pivot blades, friction shoe pivots (143), and omniseal (153). Lubricate each end of actuator rods (151) with Vinten Fluid No. 3.

55.2 Reassemble any parts of the tilt drag unit dismantled at [Para 54.9](#).

55.3 Fit 'O' rings (148) into the internal grooves of friction shoe carrier-top (142).

55.4 Ensure spirol pins (111) in the outer face of friction shoe carrier-top (142) project 3.5mm.

55.5 Fit friction shoe carrier-top (142) over drag actuator shaft (149) locating dowel (147), and friction shoe pivots (143) correctly into the carrier (142).

55.6 Locate friction shoe carrier-lower (152) over spirol pins (111) and friction shoe pivots (143), secure friction shoe carrier-lower (152) with four M5 socket button head screws (14) removed at [Para 54.6](#). Secure screws with Titanine.

55.7 Replace the drag unit into tilt drag housing (141).

56 Further assembly of the tilt drag unit should be performed over a shallow tray to catch any spilt fluid. Continue as follows:

56.1 Supporting the tilt drag unit with drag adjustment stud (150) upwards, introduce Vinten Fluid No. 3 into tilt drag housing (141) ensuring the fluid fills the space below friction shoe carrier-top (142). This is a slow process and sufficient time for fluid settlement must be allowed. The chamber must be 3/4 filled.

56.2 Fit omniseal (153) to top plate (154) with the open side towards the fluid.

56.3 Following the manufacturers instructions, apply Blue Hylomar to the top plate mating face of tilt drag housing (141).

56.4 Exercising great care not to damage omniseal (153) slide top plate (154) over friction shoe carrier-top (142) and secure with eight M3 screws (155) removed at [Para 54.3](#). Lock screws with Titanine.

56.5 After ten minutes re-tighten top plate (154) securing screws (75).

56.6 Remove surplus sealant when it has cured.

56.7 When lubricant has ceased to flow from top plate (154) bleed hole fit and secure M2.5 Posidriv screw (156) with Blue Hylomar sealant.

## Refit

57 If repair to the tilt drag unit assembly in isolation has been performed only the procedure at [Para 58.5](#) applies.

58 The tilt drag unit assembly is refitted to the head as follows ([Fig 6.5](#)):

58.1 Lightly apply white bearing grease to all moving contact surfaces particularly bearings (62), pan and tilt brake and tilt drag mechanisms. Ensure braking surfaces are completely free from grease.

58.2 Fit bearing shield (66).

58.3 Insert tilt drag unit assembly (100) into the main casting and retain with snap ring (83).

58.4 Fit brake housing body-tilt (99), with tilt brake shaft (103), shim (104), and brake segment assembly (6) in position, insert brake flange assembly (101) via the access hole in underside of main casting, bias brake flange assembly (101) upwards and secure with two M4 screws (24) removed at [Para 52.6](#).

58.5 Reverse the procedure detailed at [Para 52.3](#) to [Para 52.5](#) using new Scotch Y909 adhesive tape where required. After [Para 52.3.1](#), check that tilt brake operates correctly and that lower face of brake flange (102) does not foul main casting (61).

58.6 Refit LH loading bar assembly (130) as detailed at [Para 47](#).

58.7 Comply with [Para 6](#).

## Other components

### Bearings

59 Regreasing of the four bearings (62, [Fig 6.3](#) and [Fig 6.9](#)) and the bearing (65, [Fig 6.3](#)) can be accomplished with the bearings in situ after gaining access by removing the appropriate assemblies.

60 Should a bearing require replacement the casting in which it is mounted must be heated to 120°C to free the bearing. To fit a replacement bearing the appropriate casting must be heated to 120°C immediately prior to fitting the bearing. Care must be exercised to ensure the bearing is correctly seated. In the case of the needle bearing (65) correct seating is with the bearing flush with the bottom of the counterbore of the pan drag lever (76) bore.

61 The needle thrust bearing (193, [Fig 6.7](#)) on the end plate/adjustment thread assembly is removed as follows:

61.1 Unscrew and remove adjustment nut (201) from adjustment shaft (191).

61.2 Fit a tube (dimensions: 14 mm ID, 35 mm long) over the adjustment shaft (191) shoulder.

61.3 Refit adjustment nut (201) to the shaft (191) and rotate BALANCE adjustment knob (186) counter-clockwise until shaft (191) is driven out of knob centre (189) and away from bearing (193).

62 The end plate/adjustment thread assembly needle thrust bearing (193, [Fig 6.7](#)) is refitted as follows:

62.1 Strip adjustment knob, fit new starlock washer (188) into the knob (186) and reassembly.

62.2 Fit thrust washer (192), bearing (193) and thrust washer (194) onto shaft (191).

62.3 Pass splined end of shaft (191) through central hole of end bracket (195).

62.4 Fit shim washer (190) over splines.

62.5 Press adjustment knob centre (189) onto splines until 'O' ring (187) is slightly compressed, i.e. starlock washer (188) grips shaft (191).

### Lower carriage roller

#### Remove

63 A lower carriage roller (17) is removed as follows ([Fig 6.3](#)):

63.1 Remove the mechanism block assembly as detailed at [Para 24](#).

63.2 For each fixed roller:

63.2.1 Unscrew M4 socket grubscrew (86)

63.2.2 Slide axle-carriage roller lower (85) inwards and remove roller (17) and two shims (18).

63.3 For the adjustable roller:

63.3.1 Remove side plate assembly (82) as detailed at [Para 48](#).

63.3.2 Unscrew and remove M5 socket cap head screw (5) and washer (88).

63.3.3 Remove adjustable axle (87) and remove roller (17) and two shims (18)

## Refit

64 A lower carriage roller (17) is refitted as follows ([Fig 6.3](#)):

64.1 Apply white bearing grease to bearing and shims.

64.2 For each fixed roller:

64.2.1 Assemble roller (17) and shims (18) into their location in main casting (61) and slide axle-carriage roller lower (85) into position (the end flush with the main casting outer face) ensuring the flat on the axle is toward retaining grub screw (86).

64.2.2 Secure the axle with M4 socket grub screw (86).

64.3 For the adjustable roller:

64.3.1 Assemble roller (17) and shims (18) into their location in main casting (61) and fit adjustable axle (87) into position.

64.3.2 Fit adjustable axle retaining screw (5) and washer (88). Do not tighten screw (5) at this stage.

64.3.3 Refit side plate assembly (82) as detailed at [Para 50](#).

64.4 Refit mechanism block assembly (12) as detailed at [Para 30](#) to [Para 33](#).

## Guide roller track blocks

### Remove

65 The guide roller track blocks (92) and (89) are removed as follows ([Fig 6.3](#)):

65.1 Remove the mechanism block assembly as detailed at [Para 24](#).

65.2 Unscrew and remove two M4 socket button head screws (10) securing right hand guide roller track block (92).

65.3 Remove track block (92).

65.4 Repeat 65.2 and 65.3 for left hand guide roller track block (89).

### Refit

66 The guide roller track blocks (92) and (89) are refitted as follows:

66.1 Position left hand guide roller track block (89) against the register face of main casting (61) and secure with two M4 screws (10) removed at [Para 65.2](#).

66.2 Position right hand guide roller track block (92) 10.000 mm to 10.050 mm from left hand track block (89) and secure with two M4 screws (10) removed at [Para 65.2](#).

66.3 Check gap measurement and parallelism of track blocks.

66.4 Try guide roller (needle roller bearing (199)) on end plate/adjustment thread assembly (29) for free movement in gap over entire length of tracks.

66.5 Refit the mechanism block assembly as detailed at [Para 30](#) to [Para 34](#).

## Pan drag actuator shaft and lever

### Remove

67 The pan drag actuator shaft (79) is removed as follows ([Fig 6.3](#)):

67.1 Remove mechanism block assembly as detailed at [Para 24](#).

67.2 Remove pan drag control as detailed at [Para 48](#).

67.3 Unscrew and remove two M3 socket cap head screws (64) securing each retainer (81). Remove retainers.

67.4 Withdraw pan drag actuator shaft (79)

68 If it is required to remove pan drag lever (76) and shims (77) the right hand guide roller track block (92) must be removed as detailed at [Para 65](#).

### Refit

69 The pan drag actuator shaft (79) is refitted as follows ([Fig 6.3](#)):

69.1 Refit pan drag lever (76) and shims (77), if removed.

69.2 Refit right hand guide roller track block (92), if removed, as detailed in [Para 66](#).

69.3 Assemble pan drag actuator shaft (79) into position, with spirol pin (80) projecting downwards and pan drag actuator pin (78) located in pan drag lever (76).

69.4 Retain pan drag actuator shaft (79) with retainers (81). Secure retainer screws (64) with Loctite 221.

69.5 Refit pan drag control by a reversal of the procedure detailed at [Para 48.3](#) to [Para 48.6](#).

69.6 Refit mechanism block assembly as detailed at [Para 30](#) to [Para 33](#).

## Pan brake actuator shaft

### Remove

70 The pan brake actuator shaft (69) is removed as follows ([Fig 6.3](#)):

70.1 Remove brake flange assembly-pan (9) as detailed at [Para 35.1](#) and [Para 35.2](#).

70.2 Slacken six M5 screws (4) and (5) detailed at [Para 35.2](#).

- 
- 70.3 Remove mechanism block assembly as detailed at [Para 24](#).
  - 70.4 Remove side cover as detailed at [Para 52.3](#).
  - 70.5 Remove bearing bracket as detailed at [Para 52.4](#) and [Para 52.5](#).
  - 70.6 Unscrew and remove two M4 button head screws (75) and remove brake housing top-pan (74).
  - 70.7 Lift out two cylindrical rollers (73).
  - 70.8 Exercising care not to dislodge remaining two cylindrical rollers (73) on actuator shaft (69) remove six M5 screw (4) and (5) slackened at [Para 70.2](#) and lift the head away from pan drag unit assembly (3).
  - 70.9 Withdraw extension shaft-pan brake (115) complete with brake cams (117) and (118).
  - 70.10 The actuator shaft (69) and brake housing body (68) with their associated springs (72), spiral pins (71), and cylindrical rollers (73) can now be removed from below.

## Refit

- 71 The pan brake actuator shaft (69) is refitted by a reversal of the procedure detailed at [Para 70](#).

## Section 6

# Illustrated Parts List

<b>Contents</b>	<b>Para</b>
<b>Illustrated Parts List</b> .....	47
Illustrated Parts List .....	48
Illustrated Parts List .....	48
 <b>Illustrations</b>	 <b>Page</b>
Fig 6.1 Vision 30 Pan and Tilt Head .....	49
Fig 6.2 Secondary Mechanism Assembly .....	52
Fig 6.3 Primary Mechanism Assembly .....	56
Fig 6.4 Side Plate Assembly .....	61
Fig 6.5 Tilt Drag Unit Assembly .....	63
Fig 6.6 Mechanism Block and Secondary Spring Assemblies .....	66
Fig 6.7 End Plate/Adjustment Thread Assembly .....	68
Fig 6.8 Platform Assembly .....	70
Fig 6.9 Pan Drag Unit Assembly .....	72
Fig 6.10 Quadrant Assembly .....	74
Fig 6.11 Pan Bar Assembly .....	76
Fig 6.12 Spherical Base .....	78
Fig 6.13 Flat Base Assembly .....	80
Fig 6.14 Automatic Wedge Adaptor and Wedge Assemblies .....	82
Fig 6.15 Composite Spare Parts .....	84

## Introduction

1 This parts list is issued for the Vision 30 pan and tilt heads manufactured by VINTEN BROADCAST LIMITED, Western Way, Bury St Edmunds, Suffolk, IP33 3TB, England.


## Ordering spare parts

- 2 Always quote the head serial number when ordering a spare part.
- 3 When ordering a spare part, please quote the part number, NOT the item number. Certain part numbers have a -900SP series suffix, which denotes a composite spare part. These items are detailed in [Fig 6.15](#)
- 4 Due to restrictions placed on the transport of adhesives and other materials, please obtain supplies of consumable materials, listed in Section 3, from your local distributor.

## Main assembly part numbers

- 5 Please ensure that the correct part number is quoted when ordering main assemblies.

ASSEMBLY	PART No.
Vision 30 Pan & Tilt Head - with four-hole flat base	3259-3D
Vision 30 Pan & Tilt Head - with spherical base	3259-3E
Vision 30 Pan & Tilt Head - with four-hole flat base and automatic wedge adaptor	3259-3F
Vision 30 Pan & Tilt Head - with spherical base and automatic wedge adaptor	3259-3S
Automatic Wedge Adaptor	3761-3
Camera Wedge for Wedge Adaptor	3761-13
Telescopic Pan Bar	3219-42
Bowl Clamp Knob Assembly - for spherical base	3390-18
Fixing Bolt - for four-hole flat base	L054-714
Spanner (for fixing bolt)	J551-001



V30\_6\_01

Fig 6.1 Vision 30 Pan and Tilt Head

**Fig 6.1 Vision 30 Pan and Tilt Head**

Item No.	Part No.	Nomenclature	Qty
	3259-3D	Vision 30 pan and tilt head (flat base)	
A	3259-11	Secondary mechanism assembly	1 <a href="#">Fig 6.2</a>
B	3219-42	Telescopic pan bar, consisting of:	1
	3219-43	Pan bar assembly	1 <a href="#">Fig 6.11</a>
	3259-30	Quadrant assembly	1 <a href="#">Fig 6.10</a>
	3308-159	Washer	1
	M007-520	Screw, skt butt hd, M6 x 16 mm lg	1
C	3329-29	Flat base assembly	1 <a href="#">Fig 6.13</a>
D	M006-704	Screw, skt cap hd M5 x 16 mm lg	4
	L054-714	Bolt, Hex hd, 3/8 in. BSW x 1 in. lg	4
	J551-001	Spanner, 1/4 in. x 5/16 in.	1
	3259-3E	Vision 30 pan and tilt head (spherical base)	
A	3259-11	Secondary mechanism assembly	1 <a href="#">Fig 6.2</a>
B	3219-42	Telescopic pan bar, consisting of:	1
	3219-43	Pan bar assembly	1 <a href="#">Fig 6.11</a>
	3259-30	Quadrant assembly	1 <a href="#">Fig 6.10</a>
	3308-159	Washer	1
	M007-520	Screw, skt butt hd, M6 x 16 mm lg	1
F	3329-25	Spherical base assembly	1 <a href="#">Fig 6.12</a>
D	M006-704	Screw, skt cap hd M5 x 16 mm lg	4
	3259-3F	Vision 30 pan and tilt head (flat base and automatic wedge adaptor)	1
ABCD	3259-3D	Vision 30 pan and tilt head (flat base)	
G	3761-3	Automatic wedge adaptor assembly, secured by and including:	1 <a href="#">Fig 6.14</a>
H	M005-005	Screw, pan hd, M4 x 12 mm lg	6
J	3761-13	Wedge assembly	1
	L054-714	Bolt, Hex hd, 3/8 in. BSW x 1 in. lg	4
	J551-001	Spanner, 1/4 in. x 5/16 in.	1

**Fig 6.1 Vision 30 Pan and Tilt Head (Cont)**

Item No.	Part No.	Nomenclature	Qty
	3259-3S	Vision 30 pan and tilt head (spherical base and automatic wedge adaptor)	1
ABCF	3259-3E	Vision 30 pan and tilt head (spherical base)	
G	3761-3	Automatic wedge adaptor assembly, secured by and including:	1 <a href="#">Fig 6.14</a>
H	M005-005	Screw, pan hd. M4 x 12 mm lg	6
J	3761-13	Wedge assembly	1




Fig 6.2 Secondary Mechanism Assembly

V30\_6\_02

**Fig 6.2 Secondary Mechanism Assembly**

Item No.	Part No.	Nomenclature	Qty
1 Ref	3259-11	Assembly, Secondary Mechanism, comprising:	1
2	3259-14	Assembly, primary mechanism	1 <a href="#">Fig 6.3</a>
3	3259-19	Assembly, pan drag unit, secured by:	1 <a href="#">Fig 6.9</a>
NI	M006-704	Screw, skt cap hd M5 x 16 mm lg	4
5	M006-703	Screw, skt cap hd M5 x 12 mm lg	2
6	3259-24	Assembly, brake segment, comprising:	1
7	3259-302	Segment, brake	1
8	3259-301	Pad, brake	1
9	3259-22	Assembly, brake flange - pan, secured by and comprising:	1
10	M005-506	Screw, butt hd M4 x 16mm lg	2
11	3259-329	Flange, brake - pan	1
8	3259-301	Pad, brake	1
12	3259-15	Assembly, mechanism block	1 <a href="#">Fig 6.6</a>
13	3259-242	Shim, load beam, secured by:	2
14	M006-505	Screw, skt butt hd M5 x 12 mm lg	2
15	3259-247	Cross member - front, secured by:	1
16	M005-505	Screw, butt hd M4 x 12 mm lg	2
17	P603-003	Roller, yoke type, track INA RST05TNX	2
18	3259-210	Shim, carriage roller	4
19	3259-246	Axle, cross member roller, secured by:	2
20	M004-801	Screw, skt grub M3 x 5 mm lg	2
21	3259-248	Cross member - rear	1
16	M005-505	Screw, butt hd M4 x 12 mm lg	2
17	P603-003	Roller, yoke type, track INA RST05TNX	2
18	3259-210	Shim, carriage roller	4
19	3259-246	Axle, cross member roller, secured by:	2
20	M004-801	Screw, skt grub M3 x 5 mm lg	2
22	3259-245	Roller, lateral guide, secured by:	2
23	3259-244	Bush, lateral guide roller	2
24	M005-508	Screw, butt hd M4 x 20 mm lg	2
25	3259-232	Plunger, carriage assembly	2

**Fig 6.2 Secondary Mechanism Assembly (Cont)**

Item No.	Part No.	Nomenclature	Qty
26	J532-037	Spring, compression Flexo 102908	2
27	3259-231	Plug, spring	2
28	J532-084	Spring, compression Terry Barnes 53700	1
29	3259-12	Assembly, end plate/adjustment thread, secured by:	1 <a href="#">Fig 6.7</a>
30	M007-524	Screw, skt butt hd M6 x 25 mm lg	6
31	M007-520	Screw, skt butt hd M6 x 16 mm lg	1
32	3259-250	Cover, front - crosstie, secured by:	1
33	M005-706	Screw, skt cap hd M4 x 16 mm l	4
34	1423-2	Nameplate (medium), secured by:	1
35 (NI)	Z001-046	Tape, adhesive Scotch Y909	A/R
36	L102-001	Screw, hammerdrive, 00 x 1/8 in.	2
37	3259-251	Cover, top - crosstie, secured by:	1
33	M005-706	Screw, skt cap hd M4 x 16 mm l	4
38	3259-13	Assembly, platform, secured by:	1 <a href="#">Fig 6.8</a>
31	M007-520	Screw, skt butt hd M6 x 16 mm lg	4
39	M007-705	Screw, skt cap hd M6 x 20 mm lg	3
40	3259-314	Cover, side, secured by:	1
41	M005-718	Screw, skt cap hd M4 x 12 mm lg	4
42	M005-704	Screw, skt cap hd M4 x 10 mm lg	4
43	P602-028	Washer, thrust INA LS1730	1
44	P602-026	Bearing, needle thrust INA AXK1730	1
45	P602-027	Washer, thrust INA AS1730	1
46	3259-274	Centre, drag knob	1
47	3259-275	Retainer, drag knob, secured by:	1
48	M003-102	Screw, csk hd M2.5 x 6 mm lg	2
49	3199-244	Knob, drag, secured by:	1
50	M005-101	Screw, csk hd M4 x 6 mm lg	3
51	3199-299	Label, tilt drag	
49	3199-244	Knob, drag, secured by:	1
50	M005-101	Screw, csk hd M4 x 6 mm lg	3

**Fig 6.2 Secondary Mechanism Assembly (Cont)**

Item No.	Part No.	Nomenclature	Qty
52	3259-337	Label, pan drag	1
53	3199-285	Knob, brake, secured by:	2
53A	3199-321	Knob retainer	2
54	M004-804	Screw, skt grub M3 x 10 mm lg	2
55	3199-301	Label, tilt brake	1
56	3199-302	Label, pan brake	1
57	3259-333	Label, Vision 30, secured by:	1
36	L102-001	Screw, hammerdrive, 00 x 1/8 in.	2
58	3259-289	Screw, slide clamp	2
59	3259-316	Label, warning, secured by:	1
36	L102-001	Screw, hammerdrive, 00 x 1/8 in.	2
60	1423-33	Label, modification, Vinten	1




Fig 6.3 Primary Mechanism Assembly

V30\_6\_03

**Fig 6.3 Primary Mechanism Assembly**

Item No.	Part No.	Nomenclature	Qty
2 Ref	3259-14	Assembly, primary mechanism, comprising:	
61	3259-206	Casting, main	1
62	P200-229	Bearing, FAG 61809, secured by:	2
64	M004-901	Screw, skt csk hd M3 x 8 mm lg	3
63	3259-271	Retainer, bearing	6
66	3259-272	Shield, bearing	2
65	N500-009	Bearing, needle, Torrington B-95	1
67	M806-028	Pin, spirol 2 mm dia x 10 mm lg	1
68	3259-299	Body, housing - pan brake	1
69	3259-303	Shaft, actuator - pan brake	1
70	3259-304	Insert, actuator	1
71	M806-033	Pin, spirol, 1.5 mm dia. x 12mm lg	2
72	K532-001	Spring, compression, Terry Barnes D10940	2
73	P600-007	Roller, cylindrical, INA ZR04x8	4
74	3259-308	Housing, brake, top - pan, secured by:	1
75	M004-504	Screw, skt butt hd, M3 x 10 mm lg	2
76	3259-253	Lever, pan drag	1
77	3259-252	Shim, pan drag shaft top	2
78	3259-285	Pin, pan drag actuator	1
79	3259-284	Shaft, pan drag actuator	1
80	M806-027	Pin, spirol, 3 mm dia x 14 mm lg	1
81	3259-286	Retainer, secured by:	2
64	M004-901	Screw, skt csk hd, M3 x 8 mm lg	3
82	3259-17	Assembly, side plate, secured by:	1 <a href="#">Fig 6.4</a>
83	P605-001	Snap ring, FAG WR45	1
84	3259-283	Boss, pan drag knob, secured by:	1
4	M006-704	Screw, skt cap hd, M5 x 16 mm lg	4
43	P602-028	Washer, thrust INA LS1730	1
44	P602-026	Bearing, needle thrust INA AXK1730	1
45	P602-027	Washer, thrust INA AS1730	1
46	3259-274	Centre, drag knob	1

**Fig 6.3 Primary Mechanism Assembly (Cont)**

Item No.	Part No.	Nomenclature	Qty
47	3259-275	Retainer, drag knob, secured by:	1
48	M003-102	Screw, csk hd, M2.5 x 6 mm lg	2
17	P603-003	Roller, yoke type, track INA RST05TNX	2
18	3259-210	Shim, carriage roller	4
85	3259-209	Axle, carriage roller lower	3
86	M005-801	Screw, skt grub, dog pt, M4 x 5 mm lg	3
87	3259-211	Axle, adjustable, secured by:	1
5	M006-703	Screw, skt cap hd, M5 x 12 mm lg	1
88	M600-006	Washer, M5	1
89	3259-213	Block, guide roller track LH	1
10 (NI)	M005-506	Screw, skt butt hd, M4 x 16 mm lg	2
90 (NI)	3259-214	Track, guide roller, secured by:	1
91 (NI)	L800-007	Pin, spirol, headed, 5/64 in. dia. x 1/4 in. lg	2
92	3259-212	Block, guide roller track RH, secured by:	1
10	M005-506	Screw, skt button hd. M4 x 16mm lg	2
90	3259-214	Track, guide roller, secured by:	1
91	L800-007	Pin, spirol, headed, 5/64 in. dia. x 1/4 in. lg	2
93	3259-249	Pin, locating	4
94	1423-3	Nameplate, secured by:	1
35 (NI)	Z001-046	Tape, adhesive Scotch Y909	A/R
36	L102-001	Screw, hammerdrive, 00 x 1/8 in.	2
95A	3259-900SP	Bracket assembly, bearing, comprising:	
112	M850-006	Insert, helicoil, M8 x 1 1/2D lg	1
95	3259-207	Bracket, bearing, secured by:	1
96	M006-705	Screw, skt cap hd, M5 x 20 mm lg	1
97	M006-708	Screw, skt cap hd, M5 x 35 mm lg	3
62	P200-229	Bearing, FAG 61809	2
66	3259-272	Shield, bearing	2
98	3259-311	Liner, Bore - tilt brake	1
99	3259-312	Body, brake housing - tilt	1
100	3259-18	Assembly, tilt drag unit, secured by:	1 <a href="#">Fig 6.5</a>

**Fig 6.3 Primary Mechanism Assembly (Cont)**

Item No.	Part No.	Nomenclature	Qty
83	P605-001	Snap ring, FAG WR45	1
6	3259-24	Assembly, brake segment, comprising:	1
7	3259-302	Segment, brake	1
8	3259-301	Pad, brake	1
101	3259-23	Assembly, brake flange - tilt, secured by and comprising:	1
24	M005-508	Screw, butt hd, M4 x 20 mm lg	2
102	3259-330	Flange, Brake	1
8	3259-301	Pad, brake	1
103	3259-313	Shaft, tilt brake	1
104	3199-310	Shim, - tilt brake	1
105	3259-273	Nut, bearing - tilt, secured by:	1
106	M004-101	Screw, csk hd, M3 x 5 mm lg	2
107	3199-35	Level, 'T' type (Betelight illuminated), secured by:	1
108	M003-004	Screw, pan hd, M2.5 x 10 mm lg	2
109	3259-334	Plate, serrated, secured by:	1
110	M006-903	Screw, skt csk hd, M5 x 12 mm lg	3
111	M806-004	Pin, spirol, 4 mm dia x 10 mm lg	1
113	M800-210	Pin, spring, 16 mm dia x 10 mm lg	1
114	3259-310	Block, pan brake bearing, secured by:	1
5	M006-703	Screw, skt cap hd, M5 x 12 mm lg	2
115	3259-309	Shaft, extension - pan brake	1
116	3259-331	Washer, pan brake shaft	1
117	3259-307	Cam, brake	1
118	3259-306	Cam, brake	1
119 Ref	3259-27	Assembly, loading bar (RH), secured by and comprising:	1
120	3259-216	Washer, actuator bearing	2
121	M701-008	Circlip, external, Anderton 1400-11	1
122	3259-220	Bar, loading (RH)	1
123	N500-008	Bearing, drawn cup needle, Torrington B-76	1
124	3259-218	Retainer, axle vertical actuator	4
125	P603-004	Roller, yoke type track INA RST06TNX	2

**Fig 6.3 Primary Mechanism Assembly (Cont)**

Item No.	Part No.	Nomenclature	Qty
126	3259-217	Axle, roller vertical actuator	2
127	M806-032	Pin, spirol 1.5 mm dia x 16 mm lg	2
128	3259-219	Strip, pressure, secured by:	1
91	L800-007	Pin, spirol, headed, 5/64 in. dia. x 1/4 in. lg	2
129	M004-002	Screw, pan hd. M3 x 6 mm lg	1
130 (NI)	3259-28	Assembly, loading bar (LH), secured by and comprising:	1
120 (NI)	3259-216	Washer, actuator bearing	2
121 (NI)	M701-008	Circlip, external, Anderton 1400-11	1
131 (NI)	3259-324	Bar, loading (LH.)	1
123 (NI)	N500-008	Bearing, drawn cup needle, Torrington B-76	1
124 (NI)	3259-218	Retainer, axle vertical actuator	4
125 (NI)	P603-004	Roller, yoke type track INA RST06TNX	2
126 (NI)	3259-217	Axle, roller vertical actuator	2
127 (NI)	M806-032	Pin, spirol 1.5 mm dia x 16 mm lg	2
128 (NI)	3259-219	Strip, pressure, secured by:	1
91 (NI)	L800-007	Pin, spirol, headed, 5/64 in. dia. x 1/4 in. lg	2
129 (NI)	M004-002	Screw, pan hd. M3 x 6 mm lg	1
132	Q001-012	'O' Ring, GACO R2031	1





Fig 6.4 Side Plate Assembly

V30\_6\_04

**Fig 6.4 Side Plate Assembly**

Item No.	Part No.	Nomenclature	Qty
82 Ref	3259-17	Assembly, side plate, comprising and secured by:	1
133A	3259-901SP	Plate, side LH, comprising:	1
133	3259-281	Plate, side LH	1
138	M850-007	Insert, Helicoil M8 x 1D lg	1
134	3259-270	Shaft, stub	1
135	M006-905	Screw, skt. csk.hd. M5 x 20 mm lg	1
136	M006-904	Screw, skt. csk.hd. M5 x 16 mm lg	2
109	3259-334	Plate, serrated, secured by:	1
137	M006-902	Screw, skt csk hd, M5 x 10 mm lg	1
110	M006-903	Screw, skt csk hd, M5 x 12 mm lg	2
111	M806-004	Pin, spirol, 4 mm dia x 10 mm lg	2



V30\_6\_05

Fig 6.5 Tilt Drag Unit Assembly

**Fig 6.5 Tilt Drag Unit Assembly**

Item No.	Part No.	Nomenclature	Qty
100 Ref	3259-18	Assembly, tilt drag unit, comprising and secured by:	1
141A	3259-902SP	Tilt drag housing assy (helicoil) comprising:	1
141	3259-264	Housing, tilt drag	1
138	M850-007	Insert, Helicoil M8 x 1D lg	1
134	3259-270	Shaft, stub	1
110	M006-903	Screw, skt csk hd, M5 x 12 mm lg	1
136	M006-904	Screw, skt csk hd, M5 x 16 mm lg	2
142	3259-265	Carrier, friction shoe - top (tilt)	1
300	M806-005	Pin, spirol, 4 mm dia x 12 mm lg	2
143	3259-256	Pivot, friction shoe	2
144	3259-20	Assembly, friction shoe, comprising:	4
145	3259-258	Shoe, friction	1
146	3259-259	Lining, friction	1
111	M806-004	Pin, spirol, 4 mm dia x 10 mm lg	2
147	M801-005	Dowel, 4 mm dia x 16 mm lg	1
148	R900H068	'O' ring, Dowty 206-314-4470	2
149	3259-266	Shaft, drag actuator	1
150	3259-267	Stud, drag adjustment	1
151	3259-257	Rod, actuator	4
152	3259-268	Carrier, friction shoe - lower, secured by:	1
14	M006-505	Screw, skt butt hd, M5 x 12 mm lg	4
153	Q500-040	Omniseal, AR10400-126GC Flourocarbon Mechanical Seals Div.	1
154	3259-269	Plate, top, secured by:	1
155	M004-902	Screw, skt csk hd, M3 x 10 mm lg	8
156	M003-101	Screw, Posi csk hd, M2.5 x 5 mm ld	1
157	P600-008	Roller, (pin) INA NRR4x21.8SG5	1
158	3259-279	Housing, spring	1
159	3259-278	Shim washer	1
160	J532-066	Spring, compression Flexo M164904	1
161	3259-277	Shaft, centre lock	1

**Fig 6.5 Tilt Drag Unit Assembly (Cont)**

Item No.	Part No.	Nomenclature	Qty
162	3259-280	Knob, secured by:	1
163	M600-006	Washer, plain M5	2
164	M500-080	Nut, M5	1
165	3259-338	Label, centre lock	1
109	3259-334	Plate, serrated, secured by:	1
110	M006-903	Screw, skt. csk. hd. M5 x 12 mm lg	3
111	M806-004	Pin, spirol, 4 mm dia x 10 mm lg	2




Fig 6.6 Mechanism Block and Secondary Spring Assemblies

V30\_6\_06

**Fig 6.6 Mechanism Block and Secondary Spring Assemblies**

Item No.	Part No.	Nomenclature	Qty
12	3259-15	Assembly, mechanism block, comprising:	1
166	3259-208	Block, balance mechanism	1
167	3259-233	Track, vertical face, secured by:	2
91	L800-007	Pin, spirol, headed, 5/64 in. dia. x 1/4 in. lg	4
168	3259-234	Track, horizontal face, secured by:	8
91	L800-007	Pin, spirol, headed, 5/64 in. dia. x 1/4 in. lg	16
169	3259-230	Bearing, adjustment shaft	1
170	3259-229	Buffer, rubber, spring carriage	1
180	3259-227	Pad, buffer, stop plate	1
181	3259-221	Plug, adjustment	1
182	3259-222	Pad, buffer, lower end	1
178	3259-228	Plate, stop secondary spring, secured by:	2
179	M005-903	Screw, skt. csk. hd. M4 x 12 mm lg	4
171	3259-16	Assembly, secondary spring, comprising:	1
172	3259-226	Screw	1
173	3259-225	Pad, buffer	1
174	3259-243	Beam, load	1
175	3259-224	Guide, spring - top	1
176	J532-085	Spring, compression 9-1208-26 British Springs and Pressings	1
177	3259-223	Guide, spring - lower	1




Fig 6.7 End Plate/Adjustment Thread Assembly

V30\_6\_07

**Fig 6.7 End Plate/Adjustment Thread Assembly**

Item No.	Part No.	Nomenclature	Qty
29 Ref	3259-12	Assembly, end plate/adjustment thread, comprising:	1
186	3259-241	Knob, adjustment	1
187	Q001-018	'O' ring. R2043 GACO	1
188	M701-030	Washer, starlock BV6704 Baker and Finnemore	1
189	3259-240	Knob, adjustment centre, secured by:	1
64	M004-901	Screw, skt csk hd, M3 x 8 mm lg	3
301	M806-031	Pin, spirol, 4 mm dia x 8 mm lg	2
190	3259-322	Washer, shim, adjustment knob	1
191	3259-238	Shaft, main spring adjustment	1
192	3259-323	Washer, thrust, adjustment shaft	1
193	P602-017	Bearing, needle thrust, INA AXK 1024	1
194	P602-029	Washer, thrust, INA LS1024	1
195	3259-239	Bracket, end/cross member	1
196	3259-319	Label, balance, secured by:	
36	L102-001	Screw, hammerdrive, 00 x 1/8 in.	2
197	3259-235	Collar, spring adjustment	1
198	3259-236	Shaft, guide roller, secured by:	1
50	M005-101	Screw, csk. hd. M4 x 6 mm lg	3
199	P203-005	Bearing, needle roller, INA NK5/10TN, secured by:	1
200	M701-029	Retainer, 7105.005	1
201	3259-237	Nut, adjustment	1





Fig 6.8 Platform Assembly

V30\_6\_08

**Fig 6.8 Platform Assembly**

Item No.	Part No.	Nomenclature	Qty
38 Ref	3259-13	Assembly, platform, comprising:	
206	3259-282	Platform	1
207	3259-292	Block, threaded, secured by:	1
208	M005-902	Screw, skt. csk. hd. M4 x 10 mm lg	4
209	3259-291	Stud, slide adjuster	1
210	3259-293	Block, platform slide, secured by:	2
208	M005-902	Screw, skt. csk. hd. M4 x 10 mm lg	2
159	3259-278	Shim washer	2
211	3259-294	Knob, slide adjuster, secured by:	2
212	M806-036	Pin, spiroI, 2 mm dia x 14 mm lg	2
213	3259-296	Plate, platform slide	1
214	3259-317	Label, scale, platform, secured by:	2
35 (NI)	Z001-046	Tape, adhesive Scotch Y909	A/R
215	3259-290	Insert, dovetail, secured by:	1
216	M005-704	Screw, cap. hd. M4 x 10 mm lg	3
217	M005-802	Screw, skt. grub, M4 x 6 mm lg	2
218	3259-295	Strip, gib, secured by:	1
129	M004-002	Screw, pan hd. M3 x 6 mm lg	2
219	3170-202	Screw, large	2



**Fig 6.9 Pan Drag Unit Assembly**

V30\_6\_09

**Fig 6.9 Pan Drag Unit Assembly**

Item No.	Part No.	Nomenclature	Qty
3 Ref	3259-19	Assembly, pan drag unit, comprising:	1
221	3259-204	Housing, bearing	1
62	P200-229	Bearing, FAG 61809	1
222	N552-014	Bearing, needle thrust, NTA4458 Torrington	1
223	N552-015	Washer, needle thrust, TRA 4458 Torrington	2
224	3259-205	Plate, pan unit - top, secured by:	1
225	3259-254	Nut, bearing	1
106	M004-101	Screw, Pozi csk hd, M3 x 5 mm lg	2
226	3259-203	Housing, pan drag, secured by:	1
227	M005-001	Screw, pan hd, M4 x 5 mm lg	2
153	Q500-040	Omniseal, AR10400-126GC Flourocarbon Mechanical Seals Div.	1
228	3259-255	Carrier, friction shoe - top (pan), secured by:	1
41	M005-718	Screw, skt cap hd, M4 x 12 mm lg	4
300	M806-005	Pin, spirol, 4 mm dia x 12 mm lg	2
143	3259-256	Pivot, friction shoe	2
144	3259-20	Assembly, friction shoe, comprising:	4
145	3259-258	Shoe, friction	1
146	3259-259	Lining, friction	1
148	R900H068	'O' ring, Dowty 206-314-4470	2
229	3259-260	Shim, drag actuator	1
230	3259-261	Shaft, drag actuator	1
151	3259-257	Rod, actuator	4
229	3259-260	Shim, drag actuator	1
231	3259-262	Carrier, friction shoe, lower, secured by:	
110	M006-903	Screw, skt. csk. hd. M5 x 12 mm lg	4
111	M806-004	Pin, spirol, 4 mm dia x 10 mm lg	2
232	Q900H032	'O' ring, Dowty 200-043-4470	1
233	3259-26	Assembly, push-on cover, comprising:	1
234 (NI)	3259-263	Cover, push-on	1
235 (NI)	M504-004	Bush, minarb M3 1.6A P.S.M. Fasteners Ltd.	1
236	M004-001	Screw, Posi, pan hd. M3 x 5 mm lg	1




Fig 6.10 Quadrant Assembly

**Fig 6.10 Quadrant Assembly**

<b>Item No.</b>	<b>Part No.</b>	<b>Nomenclature</b>	<b>Qty</b>
241 Ref	3259-30	Assembly, quadrant, comprising:	1
242	3259-321	Stud, quadrant	1
243	3259-332	Nut, quadrant wing, secured by:	1
212	M806-036	Pin, spirol, 2 mm dia x 14 mm lg	1
245	3089-335	Clamp, pan bar	1
244	M600-009	Washer, palin, M8	2
246	M701-005	Circlip, external, Anderton 1400-8	1
109	3259-334	Plate, serrated, secured by:	1
247	M006-103	Screw, csk. hd. M5 x 10mm lg	3
111	M806-004	Pin, spirol, 4 mm dia x 10 mm lg	3




Fig 6.11 Pan Bar Assembly

V30\_6\_11

**Fig 6.11 Pan Bar Assembly**

Item No.	Part No.	Nomenclature	Qty
248 Ref	3219-43	Assembly, telescopic pan bar, comprising:	1
249	3219-44	Pan bar, fixed, consisting of:	1
250	3219-600	Spigot	1
251	3219-255	Tube	1
252	3219-227	Sleeve	1
253	J550-074	Hole plug	1
254	3219-38	Pan bar, sliding, consisting of:	1
255	3219-253	Pan bar grip	1
256	K403-004	Knob	1
257	3219-209	Shaft, tube clamp	1
258	M600-016	Washer	1
259	3219-267	Clamp lining	1
260	M500-082	Nut, full, M6	1
261	M600-304	Washer, M4	1
262	M701-061	'E' clip	1
263	3219-217	Shrink-wrap sleeve	1
264	3219-49	Outer tube/clamp assembly	1
265	J550-093	Hole plug	1




Fig 6.12 Spherical Base

V30\_6\_22

**Fig 6.12 Spherical Base**

<b>Item No.</b>	<b>Part No.</b>	<b>Nomenclature</b>	<b>Qty</b>
266 Ref	3259-25	Assembly, spherical base, comprising:	1
267	3259-201	Base, spherical	1
268	3259-327	Stud, clamp	1
	3390-18	Bowl clamp knob assembly, comprising:	1
269	3390-228	Bowl clamp knob, secured by:	1
270	M701-031	Circlip, external 1400-14	1
271	3390-228	Washer	1
274	3390-229	Cup, clamp	1
275	J550-068	Hole plug	1




Fig 6.13 Flat Base Assembly

**Fig 6.13 Flat Base Assembly**

<b>Item No.</b>	<b>Part No.</b>	<b>Nomenclature</b>	<b>Qty</b>
276 Ref	3259-25	Assembly, flat base, comprising:	1
277	3259-202	Base, Flat	1
278	L850-052	Insert, Helicoil 3/8 in. BSW x 1D	4




Fig 6.14 Automatic Wedge Adaptor and Wedge Assemblies

V30\_6\_14

**Fig 6.14 Automatic Wedge Adaptor and Wedge Assemblies**

Item No.	Part No.	Nomenclature	Qty
281 Ref	3761-3	Assembly, automatic wedge adaptor, comprising:	1
282A	3761-900SP	Wedge adaptor (spares), comprising:	1
282	3761-201	Body	1
278	L850-052	Helicoil 3/8 BSW x 1D	3
80	M806-027	Pin, spirol, 3 mm dia x 14 mm lg	1
283	3761-202	Slide, wedge	1
284	3761-11	Assembly, lock bar	1
285	3761-208	Pin, lock	1
286	3761-207	Plate, cover, secured by:	1
287	M003-002	Screw, pan hd, M2.5 x 6 mm lg	2
288	J530-022	Spring, tension Flexo AH2912	1
289	L801-048	Pin, dowel 3/32 in. dia x 3/4 in lg	1
290	J530-021	Spring, tension Flexo D2508	1
291	3761-12	Assembly, lock slide	1
292	K532-002	Spring, compression, Terry D10880	1
293	33761-205	Baseplate, secured by:	1
48	M003-102	Screw, csk hd, M2.5 x 6 mm lg	8
294	M003-104	Screw, csk hd, M2.5 x 10 mm lg	2
295	1423-43	Label (Serial No.), secured by:	1
NI	L102-001	Screw, hammerdrive 00 x 1/8 in. lg	2
296	3761-14	Assembly, plate safety lock, with:	1
NI	3761-213	Screw, shoulder	2
NI	J532-081	Spring, compression (Terry D10730)	1
NI	N600-010	Ball 1/8 in. dia	1
296	3761-13	Assembly, wedge, comprising:	1
297	3761-211	Plate, wedge	1
219	3170-202	Screw	2



**Fig 6.15 Composite Spare Parts**

<b>Part No.</b>	<b>Nomenclature</b>	<b>Qty</b>
3259-900SP	Bearing bracket assembly (Heli-coil), consisting off:	
3259-207	Bearing bracket	1
M850-006	Insert, Heli-coil, M8 x 1.5 D lg	1
3259-901SP	Side plate assembly (Heli-coil), consisting off:	
3259-281	Side plate	1
M850-007	Insert, Heli-coil, M8 x 1 D lg	1
3259-902SP	Tilt drag housing assembly (Heli-coil), consisting off:	
3259-264	Tilt drag housing	1
M850-007	Insert, Heli-coil, M8 x 1 D lg	1