



Draco tera compact

Series 480

KVM Matrix-Switch

User Manual

Edition: 2017-03-31

Firmware version 03.01



Copyright

© 2017. All rights reserved. This information may not be reproduced in any manner without the prior written consent of the manufacturer.

Information in this document is subject to change without notice.

Trademarks

All trademark and trade names mentioned in this document are acknowledged to be the property of their respective owners.

Disclaimer

While every precaution has been taken during preparation of this manual, the manufacturer assumes no liability for errors or omissions. The manufacturer assumes no liability for damages resulting from the use of the information contained herein.

The manufacturer reserves the right to change specifications, functions, or circuitry of the product without notice.

The manufacturer cannot accept liability for damage due to misuse of the product or due to any other circumstances outside the manufacturer's control (whether environmental or installation related). The manufacturer shall not be liable for any loss, damage, or injury arising directly, indirectly, incidentally, or consequently from the use of this product.

Contents

1	About This Manual	8
1.1	Scope.....	8
1.2	Validity	8
1.3	Cautions and Notes.....	8
1.4	Spellings	8
2	Safety Instructions	9
3	Description	10
3.1	Application	10
3.2	Access Options	10
3.3	System Overview	11
3.4	Product Range	12
3.5	Options.....	13
3.6	Device Views	14
3.6.1	Draco tera 80 Port.....	14
3.6.2	Draco tera 64 Port.....	16
3.6.3	Draco tera 48 Port.....	18
3.6.4	Draco tera 32 Port.....	20
3.6.5	Draco tera 16 Port.....	21
3.6.6	Draco tera 8 Port.....	22
3.6.7	Draco tera 8 Port Vario Module.....	22
3.7	Diagnostics and Status	23
3.7.1	Status LEDs	23
3.7.2	Port Status	27
3.7.3	Port Status Matrix Grid.....	31
3.7.4	Extender OSD	32
3.7.5	Network Status.....	33
3.7.6	Firmware Status Matrix	36
3.7.7	Firmware Status Extender.....	38
3.8	Trace Function	39
3.9	Syslog Monitoring.....	40

3.10	SNMP.....	42
3.11	System Check.....	46
3.12	Device Finder.....	47
4	Installation	49
4.1	Package Contents.....	49
4.2	System Setup.....	49
4.3	Example Applications.....	51
4.3.1	KVM Matrix	52
4.3.2	Parallel Operation (Stacking)	53
4.3.3	Matrix Grid	55
5	Configuration.....	57
5.1	Command Mode.....	57
5.2	Control Options	59
5.2.1	Control via OSD	59
5.2.2	Control via Java Tool	64
5.2.3	Control via Serial Interface.....	73
5.3	Assignment	73
5.3.1	Virtual CPU	73
5.3.2	Virtual Console.....	76
5.4	System Settings	79
5.4.1	System Data	79
5.4.2	Automatic ID	83
5.4.3	Access	86
5.4.4	Switch	90
5.4.5	Network.....	93
5.4.6	Date and Time	98
5.5	User Settings	101
5.5.1	User	101
5.5.2	Favorite List Users	104
5.5.3	User Macros.....	107
5.6	Extender Settings.....	111
5.6.1	Flex-Port Extender Units.....	113

5.7	USB-2.0-Extender	114
5.8	Extenders for UNI I/O Boards (USB 2.0 / USB 3.0).....	117
5.9	Configuration of SDI.....	121
5.10	CPU Settings	124
5.11	Console Settings.....	128
5.11.1	CON Devices	128
5.11.2	Mouse and Keyboard.....	133
5.11.3	Extender OSD.....	136
5.11.4	Favorite List Consoles.....	139
5.11.5	Console Macros	141
5.11.6	Shared Operation.....	145
5.11.7	Multi-Screen Control	148
5.12	Saving and Loading of Configurations	152
5.12.1	Active Configuration.....	152
5.12.2	Saving of Configurations (internal)	152
5.12.3	Loading of Configurations (internal)	155
5.12.4	Saving of Configurations (external).....	157
5.12.5	Loading of Configurations (external)	158
5.13	Export and Import Options	159
5.13.1	Export Options	159
5.13.2	Import Options	160
5.14	Matrix Cascading	161
5.15	Matrix Grid	166
5.16	Firmware Update.....	171
5.16.1	Matrix Update.....	171
5.16.2	Extender Update	173
5.17	License Management.....	178
6	Operation	179
6.1	Operation via 'Hot Keys'.....	180
6.1.1	Direct Switching	180
6.1.2	Scan Mode.....	182
6.1.3	Function Keys <F1>—<F16>.....	182

6.1.4	Addressing of Main and Sub Matrices.....	183
6.2	KVM-Switching.....	184
6.3	Extended Switching.....	187
6.4	Switching of single Extenders within Devices	193
6.5	CON Switch	195
6.6	Multi-Screen Control	197
6.7	USB 2.0 Switching	198
6.8	Presets.....	199
6.9	Serial Interface.....	200
6.10	Power On and Power Down Functions	201
6.10.1	Restart	201
6.10.2	Factory Reset.....	202
6.10.3	Power Down.....	202
6.11	Summary of Keyboard Commands	203
7	Specifications	206
7.1	Interfaces	206
7.1.1	RJ45 (Network)	206
7.1.2	RJ45 (Serial)	206
7.1.3	RJ45 (Interconnect)	206
7.2	Interconnect Cable.....	207
7.2.1	Cat X	207
7.3	Connector Pinouts.....	208
7.3.1	I/O Port Cat X.....	208
7.4	Power Supply.....	209
7.5	Environmental Conditions	209
7.6	Size	210
7.7	Shipping Weight.....	211
7.8	MTBF	212
8	Maintenance.....	213
9	Troubleshooting.....	214
9.1	External Failure	214
9.2	Video Interference.....	214

9.3	Malfunction of Fans.....	214
9.4	Malfunction of Power Supply Units.....	215
9.5	Network Error.....	215
9.6	Failure at the Matrix	215
9.7	Blank Screen.....	216
10	Technical Support.....	217
10.1	Support Checklist.....	217
10.2	Shipping Checklist.....	217
11	Certificates.....	218
11.1	CE Declaration Of Conformity	218
11.2	North American Regulatory Compliance	219
11.3	Product Safety	220
11.4	WEEE	220
11.5	RoHS/RoHS 2	220
12	Glossary.....	221
12.1	Matrix specific Glossary	224

1 About This Manual

1.1 Scope

This manual describes how to install your Draco tera, how to operate it and how to perform trouble shooting.

1.2 Validity

This manual is valid for all devices listed on the front page. The product code is printed on the base of the devices.

1.3 Cautions and Notes

The following symbols are used in this manual:



This symbol indicates an important operating instruction that should be followed to avoid any potential damage to hardware or property, loss of data, or personal injury.



This symbol indicates important information to help you make the best use of this product.



This symbol indicates best practice information to show recommended and optimal ways to use this product in an efficient way.

1.4 Spellings

The following spellings are used in the manual:

Spelling	Description
<key>	Description of a key on the keyboard
<key> + <key>	Press keys simultaneously
<key>, <key>	Press keys successively
2x <key>	Press key 2x in quick succession (cf. mouse double click)
Menu item	Description of a menu item in the software
Menu item > Menu item	Select menu items successively
Bold print	Description of terms that are used in the device software

2 Safety Instructions

To ensure reliable and safe long-term operation of your Draco tera please note the following guidelines:

Installation

- ➔ Only use the device according to this User Manual. Failure to follow these procedures could result in damage to the equipment or injury to the user or installer.
- ➔ Only use in dry, indoor environments.
- ➔ The Draco tera and the power supply units can get warm. Do not install components in an enclosed space without any airflow.
- ➔ Do not obscure ventilation holes.
- ➔ Only use power supplies originally supplied with the product or manufacturer-approved replacements. Do not use a power supply if it appears to be defective or has a damaged chassis.
- ➔ Connect all power supplies to grounded outlets. In each case, ensure that the ground connection is maintained from the outlet socket through to the power supply's AC power input.
- ➔ In case the device is equipped with one or more grounding screws, it is obligatory to use these for normal operation in order to ensure the grounding of the chassis.
- ➔ Do not connect the link interface to any other equipment, particularly network or telecommunications equipment.
- ➔ Only connect devices to the serial interface that are protected against short circuit currents and incorrect voltages at the serial interface.
- ➔ To disconnect the Draco tera from the power supply, remove the power cord cables of all power supply units or switch supplies off.
- ➔ Take any required ESD precautions.



In order to disconnect the device completely from the electric circuit, all power cables have to be removed.

Repair

- ➔ Do not attempt to open or repair a power supply unit.
- ➔ Do not attempt to open or repair the Draco tera. There are no user serviceable parts inside.
- ➔ Please contact your dealer or manufacturer if there is a fault.

3 Description

3.1 Application

The Draco tera matrix is used to establish connections from consoles (monitor, keyboard, mouse, and other peripheral devices) to various sources (computer, CPU).

In its maximum configuration, up to 48 independent ports can be defined and switched either as a console or a CPU.




The Draco tera matrix is designed to operate with extenders that are able to transmit video, KVM and USB 2.0 signals. But it can also be used as a video matrix.

The connection between the matrix and the peripheral devices, such as KVM extenders or video sources, can be made by Cat X cables.

The matrix serves as a repeater and can be run at a maximum distance of 140 m from the consoles and 140 m from the sources.

3.2 Access Options

The following options are available to configure and operate the Draco tera:

Access Option	Symbol
OSD	
Java tool	
Serial interface	


3.3 System Overview

A Draco tera matrix system consists of a Draco tera matrix and, for KVM applications, one or more CPU Units / CON Units. The Draco tera matrix is connected to the CPU Units / CON Units by interconnect cables or directly to the video devices where used as a video matrix.

CPU Units are connected directly to the sources (computer, CPU) by the provided cables.

Monitor(s), keyboard and mouse are connected to the CON Units.

Communication between the Draco tera matrix and the CPU Units / CON Units occurs over the respective interconnect cables.



System Overview (exemplary)

- 1 Source (computer, CPU)
- 2 CPU Units
- 3 Interconnect cable
- 4 Draco tera matrix
- 5 CON Units
- 6 Console (monitor, keyboard, mouse)



See Chapter 4.3, Page 51 for installation examples.

3.4 Product Range

Part No.	Description
K480-80C	Draco tera matrix with 80 ports, Cat X, redundant power supply unit
K480-80F	Draco tera matrix with 80 ports, fiber, redundant power supply unit
K480-80XV	Draco tera matrix with 80 ports, 2.5 Gbit/s transmission bandwidth, redundant power supply unit
K480-48C32F	Draco tera matrix with 48 ports Cat X and 32 ports fiber, redundant power supply unit
K480-48C32U	Draco tera matrix with 48 ports Cat X and 32 universal ports fiber, redundant power supply unit
K480-64C	Draco tera matrix with 64 ports, Cat X, redundant power supply unit
K480-64F	Draco tera matrix with 64 ports, fiber, redundant power supply unit
K480-64XV	Draco tera matrix with 64 ports, 2.5 Gbit/s transmission bandwidth, redundant power supply unit
K480-48C16F	Draco tera matrix with 48 ports Cat X and 16 ports fiber, redundant power supply unit
K480-48C	Draco tera matrix with 48 ports, Cat X, redundant power supply unit
K480-48F	Draco tera matrix with 48 ports, fiber, redundant power supply unit
K480-48XV	Draco tera matrix with 48 ports, 2.5 Gbit/s transmission bandwidth, redundant power supply unit
K480-32C	Draco tera matrix with 32 ports, Cat X, redundant power supply unit
K480-32F	Draco tera matrix with 32 ports, fiber, redundant power supply unit
K480-32XV	Draco tera matrix with 32 ports, 2.5 Gbit/s transmission bandwidth, redundant power supply unit
K480-16C	Draco tera matrix with 16 ports, Cat X, redundant power supply unit
K480-16F	Draco tera matrix with 16 ports, fiber, redundant power supply unit
K480-16XV	Draco tera matrix with 16 ports, 2.5 Gbit/s transmission bandwidth, redundant power supply unit

Part No.	Description
B480-8C	Draco tera matrix with 8 ports, Cat X, vario module
K480-8C	Draco tera matrix with 8 ports, Cat X, redundancy option
B480-8F	Draco tera matrix with 8 ports, fiber, vario module
K480-8F	Draco tera matrix with 8 ports, fiber, redundancy option
B480-8XV	Draco tera matrix with 8 ports, 2.5 Gbit/s transmission bandwidth, vario module
K480-8XV	Draco tera matrix with 8 ports, 2.5 Gbit/s transmission bandwidth, redundant power supply unit
B480-8U	Draco teramatrix with 8 universal ports, fiber, vario module
K480-8U	Draco teramatrix with 8 universal ports, fiber, redundancy option


3.5 Options

Part No.	Description
459-ADAP	RJ45/RS232 adapter
436-IECLOCK-EU	IEC connection cable for power supply, lockable, EU power connector
436-IECLOCK-US	IEC connection cable for power supply, lockable, US power connector
459-6M	Multi-mode GBIC, LC duplex, bidirectional, USB 3.0 (6.25 Gbit/s), for use with Draco tera
459-3BX	Coaxial GBIC, bidirectional, for the use with Draco tera (3G-SDI)
459-3DX	DIN 1.0/2.3 GBIC, bidirectional, for the use with Draco tera (3G-SDI)
459-3FX	Single-mode GBIC, LC duplex, bidirectional, for the use with Draco tera (3G-SDI)

3.6 Device Views


The following views of the Draco tera matrix illustrate the various available chassis types.

3.6.1 Draco tera 80 Port



Front View


- 1 I/O ports #1-16
- 2 I/O ports #49-64
- 3 I/O ports #17-32
- 4 I/O ports #65-80
- 5 I/O ports #33-48
- 6 Serial connection (RJ45)
- 7 Network connection (RJ45)



Rear View


- 1 Connect to power supply (standard)
- 2 Connect to power supply (redundancy)
- 3 Grounding

3.6.2 Draco tera 64 Port



Front View


- 1 I/O ports #1-16
- 2 I/O ports #49-64
- 3 I/O ports #17-32
- 4 I/O ports #33-48
- 5 Serial connection (RJ45)
- 6 Network connection (RJ45)



Rear View


- 1 Connect to power supply (standard)
- 2 Connect to power supply (redundancy)
- 3 Grounding

3.6.3 Draco tera 48 Port



Front View

- 1 I/O ports #1-16
- 2 I/O ports #17-32
- 3 I/O ports #33-48
- 4 Serial connection (RJ45)
- 5 Network connection (RJ45)




Rear View

- 1 Connect to power supply (standard)
- 2 Connect to power supply (redundancy)
- 3 Grounding




When mounting a Draco tera matrix with 16, 32 and 48 ports into a 19" rack, additional mounting support is recommended. It should be used in addition to the provided mounting brackets.

3.6.4 Draco tera 32 Port



Front View

- 1 I/O ports #1-16
- 2 I/O ports #17-32
- 3 Serial connection (RJ45)
- 4 Network connection (RJ45)



Rear View


- 1 Connect to power supply (standard)
- 2 Connect to power supply (redundancy)
- 3 Grounding

3.6.5 Draco tera 16 Port



Front View


- 1 I/O ports #1-16
- 2 Serial connection (RJ45)
- 3 Network connection (RJ45)



Front View

- 1 Connect to power supply (standard)
- 2 Connect to power supply (redundancy)
- 3 Grounding

3.6.6 Draco tera 8 Port



Front View

- 1 I/O ports #1-8
- 2 Serial connection (RJ45)
- 3 Network connection (RJ45)
- 4 Connect to power supply
- 5 Connect to 5 V DC power supply (redundancy, optional)

3.6.7 Draco tera 8 Port Vario Module



Rear View


- 1 I/O ports #1-8
- 2 Serial connection (RJ45)
- 3 Network connection (RJ45)

3.7 Diagnostics and Status

3.7.1 Status LEDs


Draco tera components are fitted with the following LEDs for overall status indication:

CPU



Front View

- 1 Status LED 2
- 2 Status LED 1



Front View Draco tera 8 port

- 1 Status LED 2
- 2 Status LED 1


Status LEDs for CPU:

Pos.	LED	Status	Description
1	Status 2	White	CPU board is in registration process
		Red flashing	Registration of the matrix has started
		Off	Operating condition
2	Status 1	White	CPU board is in registration process
		Blue flashing	Registration of the matrix has started
		Red flashing	Registration in progress
		Green flashing	Operating condition
		Green	CPU board de-registered



Due to variations in LED type "white" might also appear as light purple or light blue.

LAN Port




Rear View

- 1 Status LED 1
- 2 Status LED 2

Status LEDs of the LAN port:

Pos.	LED	Status	Description
1	Status 1 (orange)	On	Connection to network available
		Off	No connection to network
2	Status 2 (green)	Flashing	Data traffic active
		Off	Data traffic not active

I/O Ports




Front View

- 1 Link Status Port 1
- 2 Link Status Port 2

Status LEDs at the ports of the I/O boards:

Pos.	LED	Status	Description
1 & 2	Link status	Off	Initialization
		Green	Connection via interconnect cable ok, data traffic active
		Orange	Extender not recognized

Power Supply Unit




Front View

- 1 Power supply unit 1 status LED
- 2 Power supply unit 2 status LED

Status LEDs of the power supply units:

Pos.	LED	Status	Description
1	Status PSU 1 (green)	On	Operating condition
		Off	Power supply unit off
3	Status PSU 2 (blue)	On	Operating condition
		Off	Power supply unit off

Fans



Front View

- 1 Left fan status LED 1
- 2 Left fan status LED 2
- 3 Right fan status LED 2
- 4 Right fan status LED 1

Status LEDs of the fan trays:

Pos.	LED	Status	Description
1	Left fan status 1 (red)	On	Error indication
		Off	Operating condition
2	Left fan status 2 (green)	On	Operating condition
		Off	Fan off
3	Right fan status 2 (green)	On	Operating condition
		Off	Fan off
4	Right fan status 1 (red)	On	Error indication
		Off	Operating condition

3.7.2 Port Status

The connections and the switching status between the various consoles and CPUs are shown in this menu.

You have the following option to access the menu:




Java Tool

The current port configuration of the Draco tera is illustrated in this menu.

- ➔ Select **Status > Matrix View** in the task area when connected to the matrix.



Menu **Status – Matrix View** (example #1)















Menu **Status – Matrix View** (example #2)

The colors indicate the connection status:

Color	Description
Grey	Port not connected
Yellow	Video connection
Green	KVM connection
Red	Faulty Port
Blue	Port connected to another matrix via Grid Line

The symbol indicates the extender that is recognized and defined at a certain port:

Symbol	Description
	Port connected to a CPU Unit
	Port is connected to a CPU Unit that is switched to a CON Unit in Private Mode (see Chapter 3.7.4, Page 32).
	Port connected to a CON Unit
	Port connected to a CON Unit with Shared Access to a CPU
	Port is connected to a CON Unit that is connected to a CPU Unit in Private Mode (see Chapter 3.7.4, Page 32).
	Port connected to a USB 2.0 CPU Unit
	Port connected to a USB 2.0 CON Unit
	Port is configured as Cascade-CON port for cascading of matrices.
	Port is configured as Cascade-CPU port for cascading of matrices.
	Port is a UNI port of an I/O board that can be used for USB 3.0 or SDI switching.
	UNI port is configured as CON port in order to connect USB 3.0 CON extenders, for example.
	UNI port is configured as CPU port in order to connect USB 3.0 CPU extenders, for example.



- Red framed ports are defined as "fixed" (e. g. for USB 2.0 connections).
- The port with four static blue squares is currently selected.
- If a port is selected, all other ports are transparent, except those connected to the currently selected port. A selection can be cleared by pressing the button **Clear Selection**.
- In Matrix View, a red cross on a port indicates that the console to be connected does not have access rights to the respecting CPU at this port.

- ➔ Press the left mouse button to show the extender information of the currently selected port on the right hand side of the working area.

The following information is available:

Field	Description
Extender Name	Name of selected extender
Extender Type	Type of selected extender
Port ID	Number of selected port
Device Name	Name of connected console or CPU
Connections	Listing of assigned connections to marked port (Full Access or Video Access)

- ➔ Press the right mouse button to open the context menu with additional functions for the currently selected port.

The following context functions are available:

Function	Description
Open Extender	The menu for definition of the currently selected extender will be opened
Open Device	The menu for definition of the currently selected console or CPU will be opened
Switch	The menu for execution of switching operations will be opened

In order to reload the **Matrix View** you have the following options:

- Press <F5> on a connected keyboard
- Execute **Edit > Reload** in the menu bar
- Press the Button **Reload** in the tool bar

3.7.3 Port Status Matrix Grid

In this menu the connections and the switching status between the various CON and CPU Devices are shown within the Matrix Grid.

The port view is divided into the different Grid matrices. As a result each matrix is displayed in an optimized view of 24 ports per line in order to be able to show also a larger number of ports.


You have the following option to access the menu:



Java Tool

The current port configuration of the Matrix Grid is illustrated in this menu.

➔ Select **Status > Grid Port View** in the task area when connected to the matrix.




Menu **Status – Grid Port View**



Functions, colors and symbols used in the Grid Port View are identical to those in the port status of the Matrix View see Chapter 3.7.2, Page 27.

3.7.4 Extender OSD

All extenders used with the Draco tera are provided with their own OSD to display the connection status of the console.



Example View **Extender OSD**

The following information is shown in the OSD menu:

Field	Description
CON	Name of console
CPU	<p>Name of currently connected CPU</p> <p>Color Coding:</p> <ul style="list-style-type: none">Green: The connection to the selected CPU is completely established.Yellow: The connection to the selected CPU is partially established.Red: The connection to the selected CPU cannot be established. <p>Note: Possible reasons for any incomplete or non-established connection can be switched off extenders or insufficiently available Grid lines in Matrix Grid operation.</p>

Field	Description
ACCESS	<ul style="list-style-type: none"> • Full Access: Console has a KVM connection to the displayed CPU. • Video Access: Console has a video only connection to the displayed CPU. • Private Mode: Console has a Private Mode connection to the displayed CPU. • not connected: Console is not connected to a CPU.
SHARED	<p>x device(s) shows the exact number of devices that are connected to the current CPU of the console (e.g. 3 devices).</p> <p>If the field remains empty, no other devices are connected to the current CPU.</p>



If the options **Mouse Connect** or **Keyboard Connect** (see Chapter 5.4.4, Page 90) are used, the name of the console with keyboard / mouse control will be displayed on those consoles that do not have current K/M control. The console is displayed in yellow color under **Access**.

3.7.5 Network Status

The current network configuration is shown in this menu.

You have the following options to access the menu:




The following information is shown in this menu:

Field	Description
DHCP	Information whether the network settings are applied dynamically. Display Y (Yes) or N (No)
IP Address	Information about the IP address as provided manually or via DHCP
Subnet Mask	Information about the subnet mask as provided manually or via DHCP
Gateway	Information about the gateway address as provided manually or via DHCP
MAC ID	Information about the MAC address of the matrix

OSD


➔ Select **Status > Network** in the main menu.



Menu **Status – Network**

Java Tool

1. Select **Status > Matrix View** in the task area.



Menu **Status – Matrix View**

2. Use the left mouse button to click on the network port of the CPU board.

The corresponding network status will be shown on the right hand side of the working area.

The available information can be faded in or hidden by pressing the left mouse button on the "plus" or "minus" icon.

3.7.6 Firmware Status Matrix

The current firmware status of the installed boards is shown in this menu. You have the following options to access the menu:




The following information is shown in this menu:

Field	Description
Name	Description of modules
Type	Type number
Ports	Number of ports
Version	Complete description of firmware version
Date	Date of firmware version
Status	Module status

OSD


➔ Select **Status > Firmware** in the main menu.



Menu **Status – Firmware**

Java Tool

1. Select **Status > Matrix Firmware** in the task area.



Menu **Status** – Matrix Firmware

2. To read out the overall status of the matrix and store it locally (file extension **.zip**), select **Matrix > Save Status** or press the respective button in the symbol bar.

The various modules can expanded and retracted in the **Name** column by clicking with the left mouse button on the plus or minus symbols.

By clicking on the plus resp. minus symbol in the upper right corner of the working area you can expand and retract all module information with one click of the left mouse button.

3.7.7 Firmware Status Extender


The current firmware status of connected extenders is shown in this menu. You have the following option to access the menu:



The following information is shown in this menu:

Field	Description
Name	Description of firmware
Type	Description of extender module
Ports	Number of ports
Cur. Version	Description of current firmware version
Cur. Date	Date of current firmware version

➔ Select **Status > EXT Firmware** in the task area.



Menu **Status** – EXT Firmware

3.8 Trace Function

All events, e.g. activities and switching operations of the Draco tera matrix, are logged and displayed in this menu.

This function is used for diagnostic purposes.

You have the option to request various trace views in the menu:



The following information is shown in this menu:

Field	Description
Date	Date stamp
Time	Time stamp
Message	Detailed description of the event

Trace possibilities

- ➔ Select **Status > Trace IO Board** in the main menu to check the events on your current I/O board.
- ➔ Select **Status > Trace Matrix** to check the matrix events.

3.9 Syslog Monitoring


The complete logging of the Draco tera matrix activities, switching operations and surveillance of the function of critical components like fans or power supply units takes place in this menu.

You have the following option to access the menu:



In order to start Syslog Monitoring proceed as follows:

- ➔ Select the symbol **Monitoring** in the symbol bar.



Menu **Monitoring** – Syslog

Logging of system activities starts when the **Monitoring** menu is opened and remains active until the tab is closed.



Syslog messages are transmitted via UDP. Therefore, port 514 within the used network should not be blocked, e.g. by a firewall.

During logging the activities are written continuously into logging files and stored locally. This process can be set with various options.

Options

➔ Select **Extras > Options** in the menu bar and open the tab **Syslog**.

The following options are available:

Option	Description
Log File Directory	Default directory to store the log files
Log File Name	Default name of the log file
Log File Extension	Default extension for the log file
Daily Logfiles	Log files are stored every 24 hours (daily)
Maximum Log File Size (KB)	Allowed maximum size of log file
Maximum Number of Log Files	Allowed maximum number of log files
Autostart	When starting the Java Tool, the Syslog function will be started in the background
Open Monitoring Tab	When starting the Java Tool, the Monitoring tab will be opened



When reaching the maximum log file size, a new log file will be created. When reaching the maximum number of log files, the oldest one will be overwritten with the new information.

Filter Function

In order to filter relevant messages out of a number of logged activities of the Draco terra, the Syslog Monitoring offers various filter options.

In order to set and activate a filter, proceed as follows:

1. Set the desired filter option(s) by activating the respective checkbox(es).
2. Activate the filter settings by pressing the **Filter** button.
3. In order to deactivate an activated filter setting press the **Clear** button.

The following filter options are available:

Option	Description
Date	Messages for a defined date range will be filtered
Facility	Messages for a defined facility will be filtered
Severity	Messages for a defined severity will be filtered
Host	Messages for a defined host will be filtered
Message	Messages with defined text parts will be filtered



Filter options are not valid within the locally stored log files.

Recording Function

All messages shown in the Syslog are equipped with various recording functions.

- ➔ In order to store messages shown in the Syslog (filtered or unfiltered), press the **Save trace** button. The messages will be stored in a .txt file.
- ➔ In order to remove messages shown in the Syslog, press the **Clear trace** button.
- ➔ In order to stop recording messages, press the **Pause** button. In order to continue press the button again.

3.10 SNMP

The SNMP function allows all function-critical and safety-critical elements of the matrix to be monitored and queried. This function complies with the RFC 1157 conformance standard.



When using SNMP monitoring, it is recommended that a dedicated network is used to maintain continuous access.


You have the following options to configure the SNMP monitoring:



OSD

In order to activate the SNMP agent, proceed as follows:

1. Select **Configuration > SNMP** in the main menu.



Menu **Configuration – SNMP**

2. Set the **Enable** option to **Y** (Yes) under **SNMP Agent**. By activating this option, the permission for an active query of the SNMP agent is granted.

In order to configure a SNMP server, proceed as follows:

1. Select **Configuration > SNMP** in the main menu.
2. Set the **Enable Traps** option to **Y** (Yes) within **SNMP Server**. This function allows an active transmission of trap messages from the SNMP agent to the SNMP server.
3. Set the IP address of the SNMP server within **Server Address**.
4. Activate the requested traps by enabling them to **Y** (Yes).

You can select the following traps:

Trap	Description
Status	Notification about matrix status
Temperature	Notification about temperature within the matrix
Insert Board	Notification about insertion of a new I/O board into a slot
Remove Board	Notification about removal of an I/O board out of a slot
Invalid Board	Notification about a faulty I/O board
Insert Extender	Notification about a newly connected extender to the matrix, notification about a switched on extender, notification about a newly established link between extender and matrix
Remove Extender	Notification about a removed extender from the matrix, notification about a switched off extender, notification about an interrupted link between extender and matrix
Switch Command	Notification about a performed switching operation at the matrix
Fan Tray #1	Notification about the status of fan tray #1
Fan Tray #2	Notification about the status of fan tray #2
Power Supply #1	Notification about the status of power supply unit #1
Power Supply #2	Notification about the status of power supply unit #2
Power Supply #3	Notification about the status of power supply unit #3

In order to query the SNMP status, proceed as follows:

1. Select **Status > SNMP** in the main menu.




For an activation of the SNMP agent function or the SNMP server function, a restart of the matrix is necessary.

Two SNMP servers can be used at the same time.

Java Tool

In order to activate the SNMP agent, proceed as follows:

1. Select **System > Network** in the task area.



Menu **System – Network**

2. Activate the **SNMP Agent** option in the **SNMP** tab. By activating this option, the permission for an active query of the SNMP agent is granted.

In order to configure a SNMP-Server, proceed as follows:

1. Select **Configuration > Network** in the task area.
2. Activate the **Enable Traps** option within **SNMP Server**. This function allows an active transmission of trap messages from the SNMP agent to the SNMP server.
3. Set the IP address of the SNMP within **SNMP Server**.
4. Activate the requested traps.



To activate the SNMP agent function or the SNMP server function, a restart of the matrix is required.

3.11 System Check

System Check offers a diagnostic function for checking the matrix configuration. The feature indicates suboptimal and faulty settings.

System Check is exclusively used for a confidence check and does not make any active changes in the configuration.

You have the following option to access the menu:



The following configuration parts are checked:

- Matrix Firmware
- Extender Firmware
- Multi-Screen Control
- Ext Units
- CPU Devices
- CON Devices
- User
- System Configuration
- Matrix Grid

The following notification levels can be shown:


Level	Description
OK (green)	System Check completed without any abnormalities
WARNING (yellow)	System Check revealed abnormalities in the configuration that point to incomplete parts of the configuration, firmware differences, duplications or unconnected extenders but without being system critical
ERROR (red)	System Check revealed errors in the configuration that can have both functional and system critical influences on the system.



If the messages "WARNING" and "ERROR" are generated by the System Check function, the respective problem will be described and a basic guideline will be provided.

In order to start System Check, proceed as follows:

- ➔ Select the **System Check** symbol in the symbol bar.



Menu – **System Check**

3.12 Device Finder

The Device Finder offers the possibility to find all matrices or SNMP boards that are located in the same subnetwork. This is useful, for example, if the IP address of a specific matrix is unknown and should be accessed via IP.

You have the following possibility to access the function:



The following device information is shown in the Device Finder:


Information	Description
Device	Name of device
Name	Name of the active configuration
IP address	Current IP address of the device
MAC Address	MAC address of the device
Type	Type of device



The last column of the Device Finders can be used to access the respective matrix directly using the button **Connect**.

In order to start the Device Finder, proceed as follows:

- ➔ Select the symbol **Device Finder** in the symbol bar.



Menu – **Device Finder**

4 Installation

4.1 Package Contents

Your package contains the following items:

- Draco tera matrix
- 1x power cord per built-in power supply unit
- 1x RJ45/RS232 adapter
- Mounting accessories
- Quick Setup



If anything is missing, contact your dealer.

4.2 System Setup



First time users are recommended to setup the system in the same room as a test setup. This will allow you to identify and solve any cabling problems, and experiment with your system more conveniently.



Due to the construction of the matrix chassis it is recommended to use an additional subfloor below the matrix for the use in a 19" rack.

Setup of the matrix

1. Connect a CON Unit to an I/O port of the matrix for its configuration.
2. Connect keyboard, mouse and monitor to the CON Unit.
3. Connect the matrix and the CON Unit to the power supply.
4. Open OSD via keyboard command <'Hot Key'>, <o> and login with administrator rights in the main menu under **configuration** (see Chapter 5.2.1, Page 59).
5. Configure initially as requested.



After the configuration of the system it is recommended to save the configuration by selecting **Configuration > Save** and restart the matrix by selecting **Restart Matrix**.

6. Optional: Establish a network connection between the matrix and the Java Tool in order to set an extended configuration (see Chapter 5.2.2, Page 64).

The default IP address is 192.168.100.99 and DHCP is deactivated. When installing several matrices at the same time, it is strongly recommended to install them in sequence and to assign unique IP addresses in order to avoid IP address conflicts.

Setup of Extender

1. Connect the CON Units to the matrix by using the interconnect cables (Cat X).
2. Connect the CON Units to the input devices that has to be used (for example keyboard and mouse).
3. Connect the 5VDC power supply units to the CON Units.
4. Check the basic function of the CON Unit by opening the OSD via keyboard command <'Hot Key'>, <o>.
5. Connect the source (computer, CPU) to the CPU Unit of the extender using the provided connection cables.
6. Connect the CPU Unit to the matrix using the interconnect cables (Cat X).
7. Connect the 5VDC power supply units to the CPU Units.
8. Start the system.

4.3 Example Applications

The Draco tera supports a wide and flexible range of system configurations:

A part of the Draco tera can be configured as a Single-Head work station, a part as Dual-Head, as Quad-Head or even as a video matrix for example. In addition to that there are configurations with KVM and USB 2.0 available.

In addition to OSD access by a keyboard connected to the CPU board or and extender CON Unit, other methods of control are available, including:


- Java Tool
- Serial interface

A connection to common media controls is also possible.

The following section shows typical exemplary installations of the Draco tera:

4.3.1 KVM Matrix

In Single-Head mode, up to 48 ports can be used either as an input or as an output port depending on components and equipment. Non-blocking access is available for all users, i.e. user access is not limited by the activities of another user.



Single-Head KVM Matrix

- 1 Source (computer, CPU)
- 2 CPU Unit
- 3 Interconnect cable
- 4 Draco tera matrix
- 5 CON Unit
- 6 Console (monitor, keyboard, mouse)

If you have a Single-Head console, you can also get access to a Dual-Head or Quad-Head console for example. However control is only possible at monitor 1.

Any signal source can be switched to any number of monitors that will show the video signal at the same time. Audio may also be switched if required.

4.3.2 Parallel Operation (Stacking)


If you have special configurations, especially at installations with several monitors per work station or additional support of USB 2.0 transmission paths, the number of connectable CPUs and consoles can be increased by a parallel operation (stacking) of several Draco tera devices.

One Draco tera matrix is defined as the **Master Matrix** and its IP address entered into the **Master IP Address** field (see Chapter 5.4.1, Page 79). All other matrices are defined as **Sub Matrices**. Sub matrices must be connected to the master matrix via network connector (RJ45) on the CPU board. The **Enable LAN Echo** option has to be activated at the master matrix (see Chapter 5.4.1, Page 79).

If a switching command is performed using the OSD, the synchronized matrices will also switch automatically.



Switching of stacked devices might be delayed by several seconds.



Parallel Operation (Stacking)

- 1 Dual-Head source (computer, CPU)
- 2 CPU Unit
- 3 Interconnect cable
- 4 Master matrix
- 5 Synchronized matrix
- 6 Network connection master matrix / synchronized matrix
- 7 CON Unit
- 8 Console (2x monitor, keyboard, mouse)

4.3.3 Matrix Grid

You can use a matrix grid for applications where the required number of ports is not sufficient or important connections need to be made to several matrices to provide redundancy.

A matrix grid consists of one master matrix and at least one slave matrix. In its maximum configuration, it can consist of up to 16 matrices.


In order to build a matrix grid, the grid matrices are interconnected by "Grid Lines". In this case, the slave matrices can be connected directly to the master matrix or between themselves.

When arranging the grid lines, various grid setups can be realized, for example: a ring setup, a hub & spoke setup or a fully connected setup of matrices.

Grid lines can process signals bidirectional (**Smart Connect**). Per grid line, one KVM connection can be transmitted.

All switching operation will be exclusively performed through the Grid Master.

To configure the matrix grid, see see Chapter 5.15, Page 166.



Matrix Grid

5 Configuration

5.1 Command Mode

The Draco tera includes a Command Mode that allows several functions to be controlled by keyboard commands during normal use.

To enter Command Mode use a 'Hot Key' sequence and to exit Command Mode, press <Esc>. While in Command Mode, the LEDs **Shift** and **Scroll** on the console keyboard will flash.



In Command Mode, normal keyboard and mouse operation will cease. Only selected keyboard commands are available.

If there is no keyboard command executed within 10 s after activating Command Mode, it will be deactivated automatically.

The following table lists the keyboard commands to enter and to exit Command Mode and to change the 'Hot Key' sequence:

Function	Keyboard Command
Enter Command Mode (default)	2x <Left Shift> (or 'Hot Key')
Exit Command Mode	<Esc>
Change 'Hot Key' sequence	<current 'Hot Key'>, <c>, <new 'Hot Key' code>, <Enter> Until 2011-30-09: <Left Ctrl> + <Left Shift> + <c>, <'Hot Key' Code>, <Enter>



<Key> + <Key>	Press keys simultaneously
<Key>, <Key>	Press keys successively
2x <Key>	Press key quickly, twice in a row (similar to a mouse double-click)

The 'Hot Key' sequence to enter Command Mode can be changed. The following table lists the 'Hot Key' Codes for the available key sequences:

'Hot Key' Code	'Hot Key'
0	Freely selectable (from 2012-01-12 on)
2	2x <Scroll>
3	2x <Left Shift>
4	2x <Left Ctrl>
5	2x <Left Alt>
6	2x <Right Shift>
7	2x <Right Ctrl>
8	2x <Right Alt>



In a combined KVM matrix / U-Switch configuration, choose different 'Hot Keys' for the KVM matrix and the U-Switch.

Set freely selectable 'Hot Key' (exemplary)

In order to set a freely selectable 'Hot Key' (e.g. 2x <Space>), use the following keyboard sequence:

<current 'Hot Key'>, <c>, <0>, <Space>, <Enter>

Set 'Hot Key' for direct OSD Access

Next to the 'Hot Key' for standard functions, this 'Hot Key' can be exclusively used for opening the OSD directly.

In order to select a 'Hot Key' from the 'Hot Key' table for a direct opening of the OSD, use the following keyboard sequence:

<current 'Hot Key'>, <f>, <'Hot Key' code>, <Enter>

In order to select a freely selectable 'Hot Key' (e.g. 2x <Space>) for opening OSD directly, use the following keyboard sequence:

<current 'Hot Key'>, <f>, <0>, <Space>, <Enter>

Reset 'Hot Key'

In order to set a 'Hot Key' back to default settings of the extender, press the key combination <Right Shift> + within 5 s after switching on the CON Unit or plugging in a keyboard.

In order to delete the 'Hot Key' for direct OSD access, use the following keyboard sequence:

<current 'Hot Key'>, <f>, <0>, , <Enter>

5.2 Control Options

The Draco tera contains an internal CPU that allows you to control all functions from any console without the need for an external CPU or media control.

You have the following options to access the Draco tera for configuration and operation:

- via OSD
- via Java Tool
- via serial interface

5.2.1 Control via OSD



Via OSD (On-Screen-Display) you set the configuration of the Draco tera operating system. The settings of the **Configuration** menu are described below. All other menus are described in later chapters.

You have the following options to enter the OSD of the Draco tera:

- via keyboard connected to the CPU board
- via keyboard connected to a CON Unit of an extender

Entering OSD

1. Start Command Mode with the 'Hot Key' (see Chapter 5.1, Page 57).
2. Press <O> to open OSD.
You will see a list of all available CPUs as a start menu.
3. Press <Esc> to enter the main menu.




If the **Enable CPU Selection** option is enabled in the **Configuration** menu, the selection list for switching CPU devices will be opened initially. This list can be skipped by pressing the <F7> key.

Leaving OSD

- ➔ Press <Esc> in the main menu or simultaneously <Left Shift> + <Esc> anywhere within the OSD.

The OSD will be closed without any further changes and the currently active CPU connection will be displayed.

Menu Structure



Example View

The general layout of the OSD is structured into three areas:

- Upper status area (topmost two text lines)
- Working area
- Lower status area (lowest two text lines)

Keyboard control

You can select the following keyboard commands:

Function	Keyboard Command
Left cursor - only within an input field or a switching screen	<Cursor Left>
Right Cursor - only within an input field or a switching screen	<Cursor Right>
<ul style="list-style-type: none"> In input fields: Line up (with wrap around) In menus: Line up (without wrap around) 	<Cursor Up>
<ul style="list-style-type: none"> In input fields: Line down (with wrap around) In menus: Line down (without wrap around) 	<Cursor Down>
Previous page in menus with more than one page	<Page Up>
Next page in menus with more than one page	<Page Down>
Next input field	<Tab>
Previous input field	<Left Shift> + <Tab>
Next option in selection fields	<+>
Previous option in selection fields	<->
Switching in selection fields between two conditions, e. g. between ON / OFF or Y (Yes) / N (No)	<Space>
<ul style="list-style-type: none"> In menus with input fields: Save data In menus: Select menu item 	<Enter>
<ul style="list-style-type: none"> In menus with input fields: Cancel data input without saving In menus with selection fields: Go back to the superior menu 	<Esc>

Sorting Function


Lists and tables in the Java Tool offer a sorting function for fast and smooth search.

The following sorting functions are available:

Function	Keyboard Command
Sort ID numbers in descending order by pressing the keyboard command once. Sort ID numbers in ascending order by pressing the keyboard command twice (ID).	<F1>
Sort ID names in descending order by pressing the keyboard command once. Sort ID names in ascending order by pressing the keyboard command twice (Name).	<F2>
Go to the next result in the list of results of the search field (Next).	<F3>
Go to the previous result in the list of results of the search field (Previous).	<F4>
Refresh the currently shown list (Refresh).	<F5>
Jump between the search field and the list of results (Find).	<F6>

Password request

You have to login with administrator rights to be able to set configurations.



Menu **Login**

Access to the configuration menu requires administrator rights. User login is mandatory.

Field	Input
User	admin
Password	admin

By pressing <F10> in the main menu of the OSD, the login mask will be opened. In order to log out a user, press <F10> again.



For security reasons, please change the administrator password as soon as possible (see Chapter 5.4.1, Page 79).

5.2.2 Control via Java Tool



Requirements

If you want to use the Java Tool, the following requirements have to be fulfilled:

- Computer with an executable Java Tool and an installed Java Runtime Environment (JRE, version 1.7 or higher)
- Java Tool software
- Available network connection between the Java Tool and the matrix



Contact your system administrator concerning JRE and network connection.

Installation of the Java Tool

The Java Tool is available as a single executable program file that does not require a separate installation.

➔ Copy the tool after receiving the file to a directory on your computer.



If you do not have a copy of the Java Tool, contact your dealer.

Computer Connection to the Matrix



For a direct connection between computer and matrix, a cross-wired network cable is required.

For a connection between computer and matrix via switch or hub, a parallel assembled network cable is required.

Do not use a network connection between Java Tool and the matrix that is primarily used for transmitting audio data.

➔ Connect the network cable to the RJ45 ports of computer and CPU board of the matrix.

Start of the Java Tool


➔ Open the Java Tool by a double click on the program icon or use the <Enter> key of the keyboard.

Connection to the Matrix



At least FTP rights are required.

1. Open the Java Tool.
2. Select **Matrix > Connect** in the menu bar.
3. Enter the IP address in the popup input field according to the network configuration of the Draco tera (see Chapter 5.2.3, Page 73).
4. Enter the user name and password for the Draco tera (see Chapter 5.4.1, Page 79).
5. Confirm your inputs with the button **OK** or reject with **Cancel**.




Menu **Connect**



Up to twelve connections between the matrix and the Java Tool can be established at the same time due to a limitation of available sockets.

Menu structure



Example View (System – System Data)

The menu structure of the Java Tools is subdivided into various sections:

- Menu bar (top line)
- Toolbar (second line)
- Tab bar (third line)
- Task area (left menu section)
- Working area (right menu section)
- Status bar (bottom line section)

Operating Instructions

The operation of the Java Tool is intuitive and corresponds to the user interface of common operating systems.

The Java Tool contains its own support function.

The integrated help texts in the working area of the Java Tool can be activated or deactivated by the checkbox in the upper right corner.

Mouse Control

You can select the following mouse commands:

Function	Mouse Command
Menu selection, marking	Left mouse button
Open function specific selection menus	Double click left mouse button
Open context specific selection menus	Right mouse button

Keyboard Control

You can select the following keyboard commands:

Function	Keyboard Command
Cursor to the left	<Cursor Left>
Cursor to the right	<Cursor Right>
Line up	<Cursor Up>
Line down	<Cursor Down>
Previous page in input or status menus with more than one page	<Page Up>
Next page in input or status menus with more than one page	<Page Down>
Next field in input menus	<Tab>
Previous field in input menus	<Left Shift> + <Tab>
<ul style="list-style-type: none"> Switching in selection fields between two conditions (checkmark or not). Open already marked fields with editing or selecting possibility. 	<Space>
<ul style="list-style-type: none"> In menus: Data saving Menu item selection 	<Enter>
<ul style="list-style-type: none"> Leave tables Jump from tables into the next field 	<Ctrl> + <Tab>
<ul style="list-style-type: none"> Leave tables Jump from tables into the previous field 	<Ctrl> + <Left Shift> + <Tab>



Various functions within the menus in the menu bar can be executed with the provided keyboard commands (e. g. press <Ctrl> + <S> to execute **Save**) that are listed to the right of the respective menu item.

Reload Options

The information shown in the Java Tool can be reloaded in different ways.

- Via <F5> on the used keyboard
- Via **Edit > Reload** in the menu bar
- Via "Reload"-Symbol in the symbol bar

Context Function

The Java Tool offers several context functions that support user-friendly and effective operation. The context functions are described in the respective chapters.

- ➔ To execute a context function, use the right mouse button on the corresponding field and select the desired function.

Sorting Function

Lists and tables in the Java Tool offer a sorting function for fast and smooth search.

1. Ascending: Click left mouse button once on the header of the column to be sorted.

The sort status is indicated by an arrow that points upwards.

2. Descending: Click left mouse button once on the header of the column to be sorted.

The sort is displayed by an arrow that points downwards.

3. Cancel sort: Click left mouse button once or twice on the head of the sorted column.

The arrow displayed disappears.

Filter Function

Lists and tables in the Java Tool offer a filter function that allows a fast and smooth search.

1. To activate a filter, use the right mouse button to click on the header of the column to be filtered and select **Set Filter**.
2. Write the word or part of a word that has to be filtered into the header.

The filter results are shown immediately.

3. In order to delete a filter, use the right mouse button to click on the header of the column that has to be filtered and select **Clear Filter**.



An active filter is indicated by an asterix in the header.
The filter function is based on the functional principle of common web search engines.

Offline Configuration

Configuration and system settings via Java Tool can be changed in offline mode without a direct connection between matrix and Java Tool.

In order to activate a matrix configuration, proceed as follows:

1. Select **File > Upload** in the menu bar.
2. Enter the IP address of the matrix (see Chapter 5.2.3, Page 73) and the name and password of the user authorization and select the storage location of the new configuration (**default** or **config01-08**) in the **Select Configuration** menu.
3. Select **Matrix > Connect** in the menu bar and enter the IP address of the matrix and the name and password for user authorization.
4. Select **Administration > Activate Configuration** in the task area and select the storage location that has been selected above.
5. Use the **Activate** button to open the selected configuration within the matrix.


The connection and the open tab will be closed and the matrix will be restarted.



During the activation of a configuration, the matrix is temporarily unavailable.

Online Configuration

Configurations and system settings can be also edited via Java Tool in online mode with an active connection between matrix and Java Tool.



Menu System – System Data

In order to edit a configuration in online mode, proceed as follows:

1. Select the menu item **Matrix > Activate Online Configuration Mode**. This setting will also be shown in the lower part of the working area.
2. Make any edits at the configuration and system settings and confirm them by pressing the **Apply** button. The changes will be applied immediately.
3. In order to deactivate the online mode, select the menu item **Matrix > Deactivate Online Configuration Mode** in the menu bar.

Options menu

The Java Tool can be adapted and customised by editing various default settings.

In order to activate or change the default settings, proceed as follows:

- ➔ Select **Extras > Options** in the menu bar. The tab **Default Settings** will open.

The following default settings parameters can be changed:

Option	Description
IP / Hostname	Default IP address of the matrix required for connection
User	Default user name required for connection
Configuration Directory	Default directory for configuration files
Firmware Directory	Default directory for update files
Status Directory	Default directory for the firmware status
Import / Export Directory	Default directory for import and export files
Presets Directory	Default directory for macro files

In order to set various font sizes for the Java Tool, proceed as follows:

1. Select **Extras > Options** in the menu bar.
2. Open the **Font** tab.
3. Select the desired font size (**normal** or **large**).


Report

The Java Tool is equipped with a report function that shows the current switching status and all relevant parts of the matrix configuration in a PDF file.

In order to create a report, proceed as follows:

1. Select **File > Report...** in the menu bar. A selection assistant will be opened.
2. Select contents that should be included in the report (**Matrix View**, **EXT Units**, **CPU Devices**, **CON Devices** and **Users**) and confirm with the button **Next >**.
3. Select the preferred location for storage of the report and confirm with the **Finish** button.

The report will be created as a PDF file.



Menu **File > Report**



The report function can be used in both online or offline mode of the Java Tool.

5.2.3 Control via Serial Interface



The Draco tera operating system offers various functions for an operation via serial interface. There are telegrams for Switching single or all connections available, both unidirectional and bidirectional. In addition, there are telegrams for an overall definition of the total switching status and for saving and loading such switching states.

The Draco tera optionally provides an echo of all affected switching operations via serial interface or network interface. This aids continuous tracking of a matrix configuration and enables your own applications to be updated.

As an additional application you can parallelly switch matrix clones as synchronized matrices (**Stacking**) via serial network interface.

5.3 Assignment

The Draco tera offers the option of a console specific or a CPU specific assignment.

- Assign virtual CPUs to real CPUs.
- Assign real consoles to virtual consoles.

5.3.1 Virtual CPU

You can assign virtual to real CPUs in this menu.


With this function the effort of switching several consoles to the same CPU can be reduced. If several consoles are connected to a virtual CPU that is assigned to a real CPU, you only have to change the real CPU once and all consoles will receive the video signal of the new CPU.

You have the following options to access the menu:



OSD

➔ Select **Assignments > Virtual CPU Devices** in the main menu.



Menu Assignments – Virtual CPU Devices

For an assignment, proceed as follows:


1. Select the virtual CPU in the **Virtual Devices** list that has to be assigned to a real CPU.
2. Press the **Edit** button.
3. Select the CPU in the **Real Devices** list that has to be assigned to the selected virtual CPU.
4. Press the **Okay** button to confirm the assignment.
The assignment will be made.



Only one virtual CPU can be assigned to a real CPU.

Java Tool

➔ Select **Assignment > Virtual CPU Devices** in the task area.



Menu **Assignment – Virtual CPU Devices**

For an assignment, proceed as follows:

1. Select a virtual CPU in the **Virtual CPU** list.
2. Double click in the **Real CPU** column to display a list of all available real CPUs.
3. Select a real CPU.

You can select the following buttons:

Button	Function
Send	Send assignments to the matrix
Reload	Reload changes



When the **Auto Send** function in the left lower corner of the work area is ticked, switching operations will be completed immediately without user confirmation by means of the **Send** button.

The selection boxes in the **Real CPU** column contain a filter function for an easy selection of a single CPU from a larger pool of CPUs (see Chapter 5.2.2, Page 64).

The Java tool offers the option to switch directly from the **Assignment** menu to the **Definition** menu to check specific settings for the respective console or CPU.

- ➔ Use the right mouse button to select the respective console or CPU and select **Open CON Device** or **Open CPU Device**.

5.3.2 Virtual Console

You can assign real consoles to virtual consoles in this menu.

This function reflects changes in permission made to virtual consoles onto real consoles.


Virtual consoles can be switched in the same way as real consoles. Real consoles that are assigned to a virtual console that is connected to a CPU will receive the video signal. The last-assigned console will also have control of the keyboard and mouse.

You have the following options to access the menu:



OSD

➔ Select **Assignments > Virtual CON Devices** in the main menu.



Menu **Assignments – Virtual CON Devices**

For an assignment, proceed as follows:

1. Select the real console in the **Real Devices** list that has to be assigned to a virtual CPU.
2. Press the **Edit** button.
3. Select the virtual console in the **Virtual Devices** list that has to be assigned to the selected real console.
4. Press the **Okay** button to confirm the assignment.


The assignment will be made.



A virtual console can be assigned to more than one real consoles.

Java Tool

➔ Select **Assignment > Virtual CON Devices** in the task area.



Menu **Assignment – Virtual CON Devices**

In order to place an assignment, proceed as follows:

1. Select the required real console in the **Real Console** table.
2. Double click in the **Virtual Console** column to display a list of all available virtual consoles.
3. Select the required virtual console.

You can select the following buttons:

Button	Function
Send	Send assignments to the matrix
Cancel	Reject changes



When the **Auto Send** function in the left lower corner of the work area is ticked, switching operations will be completed immediately without user confirmation by means of the **Send** button.

The selection boxes in the **Virtual Console** column contain a filter function for an easy selection of a single CON from a larger pool of CON (see Chapter 5.2.2, Page 64).

5.4 System Settings

You have the option to configure the following system settings at the Draco tera.



The configuration of the system settings can only be done by users with administrator rights.

5.4.1 System Data

The system configuration is set in this menu.

You have the following options to access the menu:



You can select the following settings:

Field	Selection	Description
Device	Text	Enter the device name of the matrix (default: SWITCH_01)
Name	Text	Enter the name of the configuration that is used to save the current settings (default: Standard)
Info	Text	Additional text field to describe the configuration (default: Factory settings)
Sub Matrix	activated	If the matrix is defined as a sub matrix in the OSD, the user will lose control. Control can be recovered by using the keyboard command <Shift>, <Shift>, <s>, <o>. The OSD for the matrix that has been defined as sub matrix will be reopened.
	deactivated	Function not active (default)
Load Default	activated	Starting the matrix after a restart or a switch-on with the default configuration.
	deactivated	Starting the matrix after a restart or a switch-on with the last saved configuration (default).

Field	Selection	Description
Auto Save	activated	Save the current configuration of the matrix in the flash memory periodically. Note: During the save operation, the matrix will not be operational. Saving takes place every 600 seconds, as long as changes of the configuration or switching operations have been executed in the meantime.
	deactivated	Function not active (default)
Enable COM Echo	activated	Send all switching commands performed in the matrix as an echo via serial interface. Note: This function should be enabled when using a media control via serial interface.
	deactivated	Function not active (default)
Enable LAN Echo	activated	Send all switching commands performed in the matrix as an echo via LAN connection. Note: This function should be enabled when using a media control via LAN connection or when using stacking with two or more matrices.
	deactivated	Function not active (default)
Enable Redundancy	activated	Automatically switch to the second link of a connected redundant CON Unit when losing the primary link of a CPU Unit (default) Note: This function will have to be activated for both matrices in a fully redundant setup
	deactivated	Function not active
Synchronize	activated	Synchronize the slave matrix to the switch status of the master matrix.
	deactivated	Function not active (default)
Echo Only	activated	Synchronize the matrix according to the echo of a second matrix. Note: This is a bidirectional synchronization where both matrices have to be configured as Synchronize with the Master IP of the respective other matrix.
	deactivated	Function not active (default)
Master IP Address	Numerical value	Set the network address of the master matrix (default value: 000.000.000.000)

Field	Selection	Description
Invalid IO-Boards	activated	Keep I/O boards with incorrect or invalid firmware online in the matrix. Note: In order to keep an I/O board with wrong or damaged firmware online in the matrix, the maintenance mode of the matrix will be activated. During maintenance mode, you can only work.
	deactivated	Shut down I/O boards with incorrect or invalid firmware automatically (default).
Hor. Mouse Speed 1/x	1-9	Adjustment of the horizontal mouse speed, 1 = slow, 9 = fast (default value: 4)
Ver. Mouse Speed 1/x	1-9	Adjustment of the vertical mouse speed, 1 = slow, 9 = fast (default value: 5)
Double Click Time	100-800	Adjustment of the time slot for a double click (default value: 200 ms)
Keyboard layout	Region	Set the OSD keyboard layout according to the keyboard used (default: German (DE))

OSD

➔ Select **Configuration > System** in the main menu.

The screenshot shows the OSD Configuration menu with the following settings:

```


admin@CON_010167832
Configuration
System
Device : SWITCH 01
Name : Standard
Info : Factory settings
Sub Matrix : N
Load Default : N
Auto Save : N
Enable COM Echo : N
Enable LAN Echo : N
Enable Redundancy : Y
Synchronize : N
Echo Only : N
Master IP Address : 000 000 000 000
Enable Auto Config : Y
ID Real CPU Device : 1001
ID Virt. CPU Device : 2001
ID Real CON Device : 3001
ID Virt. CON Device : 4001
Invalid IO-Boards : N
Enable old Echos : N
OSD Data CPU
Horizontal mouse speed 11/x1: 4
Vertical mouse speed 11/x1: 5
Double click time ms1: 200
Keyboard layout : German DE,129
Cancel
Okay
SWITCH_01
  
```

Menu Configuration – System

You can select the following buttons:

Button	Function
Cancel	Reject changes
Save	Save changes

Java Tool



Menu System – System Data

5.4.2 Automatic ID

Settings for automatic creation of CPU and CON Devices when a new extender unit is connected are made in this menu.

You have the following options to access the menu:




You can select the following settings:

Field	Selection	Description
Enable Auto Config	activated	Automatic creation of a new CPU or CON Device if new extender units are connected (default)
	deactivated	Function not active
ID Real CPU Device	Numerical value	Initial value of the automatic ID for real CPUs (default value: 1000)
ID Virtual CPU Device	Numerical value	Initial value of the automatic ID for virtual CPUs (default value: 2000)
ID Real CON Device	Numerical value	Initial value of the automatic ID for real CONs (default value: 3000)
ID Virtual CON Device	Numerical value	Initial value of the automatic ID for virtual CONs (default value: 4000)

OSD

➔ Select **Configuration > System** in the main menu.




Menu **Configuration – System**

You can select the following buttons:

Button	Function
Cancel	Reject changes
Save	Save changes

Java Tool

➔ Select the tab **Automatic ID** in **System > System Data**.



Menu System – Automatic ID

5.4.3 Access

The access configuration is set in this menu.

You have the following options to access the menu:




You can select the following settings:

Field	Selection	Description
Force User Login	activated	The user has to login with a user name and a password once to enter OSD. Thereafter the user remains logged in until he explicitly logs out or an auto logout is effected. Note: When using the Force User Login function, console favorites and console macros still remain active.
	deactivated	Function not active (default)
Enable User ACL	activated	CPU access is restricted according to the permissions in the ACL (Access Control List). <ul style="list-style-type: none"> User login is required. Switching by keyboard 'Hot Keys' requires a prior login.
	deactivated	Function not active (default)
Enable Console ACL	activated	CPU access is restricted according to the permissions in the respective Console ACL (Access Control List). No login required
	deactivated	Function not active (default)
Enable new User	activated	Newly created users automatically receive access to all CPUs
	deactivated	Function not active (default)
Enable new CON	activated	Newly created CON Devices automatically receive access to all CPUs
	deactivated	Function not active (default)
Auto Disconnect	activated	Upon opening the OSD, the console will be automatically disconnected from the current CPU.

Field	Selection	Description
	deactivated	Function not active (default)
OSD Timeout	0-999 seconds	<p>Period of inactivity after which OSD will be closed automatically.</p> <ul style="list-style-type: none"> Select 0 seconds for no timeout (default: 0 seconds)
Auto Logout	0-999 minutes	<p>Period of inactivity of a logged-in user at a console after which he will be automatically logged out.</p> <p>There may be a disconnect because of the logout, depending on the defined rights in each CON and user ACL.</p> <ul style="list-style-type: none"> Select 0 minutes for an automatic user logout when leaving OSD. <ul style="list-style-type: none"> Using the setting -1 allows the user to be logged in permanently, until a manual logout is executed. The timer is not active as long as the OSD is open. <p>(default: 0 minutes)</p>

OSD

➔ Select **Configuration > Access** in the main menu.




*Menu **Configuration – Access***

You can select the following buttons:

Button	Function
Cancel	Reject changes
Save	Save changes

Java Tool

➔ Select **System > Access** in the task area.



Menu System – Access

5.4.4 Switch

The configuration of the switching parameters is set in this menu.

You have the following options to access the menu:



You can select the following settings:

Field	Selection	Description
Video Sharing	activated	The user can switch to any CPU as an observer, including ones that are already assigned to another user (observer without keyboard/mouse access). <ul style="list-style-type: none"> Note: Switching with the key <Space>, not <Enter>. The operator will not be informed if further users connect as an observer to the CPU that is connected to his console.
	deactivated	Function not active (default)
Force Connect	activated	The user can connect to every single CPU as an operator, including ones that are related to another user. <ul style="list-style-type: none"> Note: The previous user is set to video only status. To share K/M control, Force Connect has to be activated.
	deactivated	Function not active (default)
Force Disconnect	activated	Extension of Force Connect : If the user connects as an operator to a CPU already related to another user, the previous user will be disconnected. Note: To share K/M control Force Disconnect has to be deactivated.
	deactivated	Function not active (default)


Field	Selection	Description
CPU Auto Connect	activated	If a console is not connected to a CPU, you can establish an automatic connection to the next available CPU by hitting any key or mouse button.
	deactivated	Function not active (default)
CPU Timeout	0 – 999 minutes	Period of inactivity after which a console will be automatically disconnected from its current CPU (default value: 0 minutes)
Keyboard Connect	activated	Activate request of K/M control by keyboard event (key will be lost)
	deactivated	Function not active (default)
Mouse Connect	activated	Activate request of K/M control by mouse event
	deactivated	Function not active (default)
Release Time	0-999 seconds	<p>Period of inactivity of a connected console after which K/M control can be requested by other consoles connected to the CPU.</p> <ul style="list-style-type: none"> • Note: Set "0" for an immediate transfer in real-time. • Only one console can have keyboard and mouse control at the same time. The other consoles that are connected to the same CPU have a video only status (default value: 10 seconds)



If the **Keyboard Connect** and/or **Mouse Connect** options are activated, the **Release Time** condition will have to be met until a new user will gain control.

OSD

➔ Select **Configuration > Switch** in the main menu.




Menu **Configuration – Switch**

You can select the following buttons:

Button	Function
Cancel	Reject changes
Save	Save changes

Java Tool

➔ Select **System > Switch** in the task area.



Menu **System – Switch**

5.4.5 Network

The network configuration is set in this menu.

You have the following options to access the menu:



You can select the following settings:

Field	Selection	Description
DHCP	activated	The network settings are automatically supplied by a DNS server Note: If DHCP is activated and there is no physical network connection available, the boot times might increase.
	deactivated	Function not active (default)

Field	Selection	Description
IP address	Byte	Input of the IP address, if DHCP is not active (default: 192.168.100.99)
Subnet Mask	Byte	Input of the subnet mask in the form "255.255.255.0", if DHCP is not active (default: 255.255.255.0)
Gateway	Byte	Input of the subnet mask in the form "192.168.1.1", if DHCP is not active
API Service	activated	LAN interface at the Draco tera activated for access via Java tool (API service port 5555)
	deactivated	Function not active
FTP Server	activated	FTP server for transmission of configuration files activated.
	deactivated	Function not active
Syslog #1/#2	activated	Syslog server for status request is active
	deactivated	Function not active (default)
Syslog Server #1/#2	Byte	Input of the IP address of the Syslog servers in the form "192.168.1.1" and of the Syslog port (default: 514)
LDAP	activated	LDAP for the request of information from a user administration is active
	deactivated	Function not active (default)
LDAP Server	Byte	Input of the IP address for the LDAP-Servers in the form "192.168.1.1" and the LDAP port (Default: 389)
LDAP Base DN	Text	Input of the LDAP Base DN according to the existing stucture of the user directory

Trace	DEB	Activate debug messages in Trace (default: NO) Note: The debug messages are exclusively for matrix diagnostics. They only should be activated after consultation with the manufacturer. Otherwise an increased traffic of data might limit the performance of the CPU board.
	INF	Activate information messages in Trace (default: NO)
	NOT	Activate notification messages in Trace (default: YES)
	WAR	Activate warning messages in Trace (default: YES)
	ERR	Activate error messages in Trace (default: YES)
Syslog #1/#2	DEB	Activate debug messages in Syslog (default: NO) Note: The debug messages are exclusively for matrix diagnostics. They only should be activated after consultation with the manufacturer. Otherwise an increased traffic of data might limit the performance of the CPU board.
	INF	Activate information messages in Syslog (default: NO)
	NOT	Activate notification messages in Syslog (default: YES)
	WAR	Activate warning messages in Syslog (default: YES)
	ERR	Activate error messages in Syslog (default: YES)




Activate the modified network parameters by restarting the matrix.



Consult your system administrator before modifying the network parameters. Otherwise unexpected results and failures can occur in combination with the network.

OSD

➔ Select **Configuration > Network** in the main menu.



Menu **Configuration – Network**

You can select the following buttons:

Button	Function
Cancel	Reject changes
Save	Save changes


Release of Network Ports

The following ports are used by the matrix depending on the configuration and have to be released at the security gateway, if necessary. The ports only will have to be released, if you want to use the respective function.

Function	Port
FTP	21
DNS	53
SNTP	123
SNMP	161/162
LDAP	389
Syslog	514
API	5555
Broadcast	5556
Matrix-Grid	5557

Java Tool

➔ Select **System > Network** in the task area.



*Menu **System – Network***

5.4.6 Date and Time

Date and Time are set in this menu, based on Simple Network Time Protocol (SNTP).

You have the following options to access the menu:



You can select the following settings:

Field	Selection	Description
SNTP Client	activated	Enable network time server synchronization
	deactivated	Function not active (default)
SNTP Server	Byte	Input of the SNTP server IP address (default: 000.000.000.000)
Time Zone	Region	Set your specific time zone
Month	1–12	Enter month
Date	1–31	Enter date
Year	1–99	Enter year
Day	1–7	Enter day of the week
Hours	0–23	Enter hour
Minutes	0–59	Enter minute
Seconds	0–59	Enter second



Date format according to the English notation.

OSD

➔ Select **Configuration > Date+Time** in the main menu.

The screenshot shows a terminal window titled 'admin@CON 010148887' with a 'Configuration' menu. The 'Time Server' section has three fields: 'SNTP Client' set to 'Y' (with a note 'Enable the synchronisation with a network time server'), 'SNTP Server' set to '000.000.000.000', and 'Time Zone' set to 'GMT+01' (with a note 'Select your time zone'). Below this is the 'Real Time Clock' section with three fields: 'Date' set to '12/21/12' (with a note 'Enter the date with format MM/DD/YY'), 'Day' set to '05' (with a note 'Enter the day of the week'), and 'Time' set to '07:53:57' (with a note 'Enter the time with format hh:mm:ss'). At the bottom right of the configuration area are three buttons: 'Set RTC', 'Cancel', and 'Okay'. The bottom of the terminal window shows 'test-device'.

Menu **Configuration – Date + Time**

In order to configure a time server, proceed as follows:


1. Set the **SNTP Client** option to **Y** (Yes).
2. Enter the IP address of your SNTP server in the **SNTP Server** field.
3. Select your time zone in the **Time Zone** field.
4. Press the **Okay** button to confirm your settings.
5. Restart the matrix. The system time will be now provided by the SNTP server.

In order to set the real time clock without using SNTP, proceed as follows:

1. Set the current date in the **Date** field.
2. Set the current Day in the **Day** field.
3. Set the current time in the **Time** field.
4. Press the **RTC** button to confirm your settings.

Java Tool

➔ Select **System > Date and Time** in the main menu.



Menu Configuration – Date and Time

In order to configure a time server, proceed as follows:

1. Enable **SNTP** option.
2. Enter the IP address of your SNTP server in the **SNTP Server** field.
3. Select your time zone in the **Time Zone** field.
4. Press the **Apply** button to confirm your settings.
5. Restart the matrix. The system time will be now provided by the SNTP server.

In order to set the real time clock without using SNTP, proceed as follows:

1. Set the current date in the **Date and Time** field.
2. Set the current time in the **Day and Time** field.
3. Press the **Apply** button to set the system time.
4. Option: If you want to receive the time from your currently used computer, press the **Get Local Time** button.

5.5 User Settings

You have the option to configure the following user settings:

5.5.1 User

New users and their user settings and permissions are set in this menu.

You have the following options to access the menu:



You can select the following settings:

Field	Selection	Description
Name	Text	User name (case sensitive)
Password	Text	User password (case sensitive)
Repeat Password	Text	Repeat user password (case sensitive)
FTP	activated	Access permission via FTP. This setting is necessary for file access from the Java tool or any web browser.
	deactivated	Function not active (default).
Power User	activated	<ul style="list-style-type: none"> User has user rights Permission to switch consoles to CPUs in Extended Switching according to the CON or User ACL
	deactivated	Function not active.
Super User	activated	Permission to switch any console to any CPU in Extended Switching .
	deactivated	Function not active.
Administrator	activated	<ul style="list-style-type: none"> Permission for system configuration and all switching operations User has administrator rights This setting is required for an online connection with the Java tool
	deactivated	Function not active.
LDAP User	activated	Permission to login via domain user
	deactivated	Function not active.

OSD

➔ Select **Configuration > User** in the main menu.

admin@CON 010167832
Configuration

F1:ID F2:Name F3:Next F4:Previous F5:Refresh F6:Find ESC

User List

ID	Name	Next
00001	admin	

User Data

ID : 1
Login Name : admin
Full Name :
Password :
Repeat Password :
Administrator : ☒ HTTP Access : ☒
Super User : ☒ FTP Access : ☒
Power User : ☒ Telnet Access : ☒
LDAP User : ☐

CPU Access Control List

Full access	Video access	No access
01002 CPU_010135668		
01003 CPU_010207794		
01001 CPU_0160980185		
01004 CPU_040011492		

Enter a name to find an item
SWITCH_01

New
Edit
Delete
Cancel
Okay


Menu **Configuration – User**

You can select the following buttons:

Button	Function
New	Create a new user
Edit	Edit an existing user
Delete	Delete an existing user
Cancel	Reject changes
Save	Save changes

Java Tool

➔ Select **Definition > User** in the task area.



Menu **Definition – User**

You can select the following buttons:

Button	Function
New	Open a new user configuration
Delete	Delete an existing user
Apply	Create a new user account
Cancel	Reject changes

In order to configure a user access rights for CPUs, proceed as follows:

1. Select a user in the **User** list.
2. By clicking the right mouse button once on a CPU in one of the respective access lists (**Full Access**, **Video Access** and **No Access**) two lists for selection will appear in which the respective CPU can be moved and the access rights can be changed.
3. Confirm the configuration with the **Apply** button.

In order to create a new user, proceed as follows:

1. Press the **New** button.
2. Select a template of an existing user if applicable (**Choose template**).
3. Press the **OK** button.
4. Set a user name.
5. Set a password.
6. Set general access permissions.
7. Set user permissions for CPU access (paste function).
8. Set user favorites for OSD access.
9. Press the **Apply** button to save the new user settings.

You can select the following keyboard commands:

Function	Keyboard Command
Add CPU to list Full Access	<F>
Add CPU to list Video Access	<V>
Add CPU to list No Access	<N>

5.5.2 Favorite List Users

Individual favorite lists of CPUs that will be switched frequently can be created for different users in this menu. A favorite list can contain up to 16 different CPUs.


The switching of the favorites is done via 'Hot Key' using the keyboard (see Chapter 6.1.1, Page 180).

You have the following options to access the menu:



OSD

➔ Select **Assignments > User Favorites** in the main menu.




Menu **Assignments** – **User Favorites**

To create a favorite list for you own user, proceed as follows:

1. Select a CPU to be moved to the favourite list on the **CPU Devices** list. Press <a> to move a CPU Device to the favourite list. Remove a CPU by pressing <r>.
2. The order of the CPU Devices within the favorite list can be changed by pressing th <+> and <->.
3. Press the **Save** button to save the settings.

Java-Tool

- ➔ Select the respective user in the working area of the **User** menu for the favorite list and open the **Favorites** tab.



Menu **Definition – User**

To create a favorite list for any user, proceed as follows:

1. Select the CPUs in the **CPU available** list that should be added to the favorite list (**CPU assigned**). By pressing the <Ctrl> at the same time, more than one CPU Device can be marked.
2. Press the > button to move the marked CPU Devices to the favorite list. If you press the >> button, the first eight CPU Devices from the **CPU available** list will be moved to the favorite list (**CPU assigned**).
3. The order of marked CPU Devices within the favorite list can be changed by pressing <+> and <->.
4. In order to remove marked CPU Devices from the favorite list, press the < button. If you press the << button, all CPU Devices will be removed from the favorite list.

5.5.3 User Macros

In this menu macro commands for switching, disconnection or user administration can be created. Macro commands are created for each user separately.

A macro can execute up to 16 switching commands successively.

The execution of the macros is done via 'Hot Key' and the <F1>-<F16> function keys (see Chapter 6.1.3, Page 182).



In order to execute user macros the user has to be logged in to the matrix.

You can select the following settings:

Field	Selection	Description
Function (01–16)	Connect (P1=CON, P2=CPU)	Set bidirectional connection from console P1 to CPU P2
	Connect Video (P1=CON, P2=CPU)	Set video connection from console P1 to CPU P2
	Disconnect (P1=CON)	Disconnect console P1
	Logout User	Logout current user
	Set Real CPU (P1=VCPU, P2=RCPU)	Assign a virtual CPU to a real CPU
	Set Virtual CON (P1=RCON, P2=VCON)	Assign a real console to a virtual console
	Push (P1=CON)	The user's KVM connection is forwarded to console P1 and is changed to a video only connection.
	Push Video (P1=CON)	The video signal of the current connection (KVM or video only) is forwarded to console P1. The user's connection remains unchanged (KVM or video only).

Field	Selection	Description
	Get (P1=CON)	The user's console gets a KVM connection to the CPU that is currently connected to console P1. The connection of console P1 is changed into a video only connection.
	Get Video (P1=CON)	The user's console gets a video only connection to the CPU that is currently connected to console P1. The connection of console P1 remains unchanged (KVM or video only).
	Login User console P2	Login a certain user P1 at console P2
P1	CON or CPU Device	Name of CON or CPU Device
P2	CPU or CPU Device	Name of CON or CPU Device

You have the following options to access the menu:



OSD

- ➔ Select via **Configuration > User Macros** in the main menu the user for which a user macro has to be created.

03000 CON 010125349 - admin

Configuration F1:ID F2:Name F3:Next F4:Previous F5:Refresh F6:Find ESC

F1:ID	F2:Name	F3:Next	F4:Previous	F5:Refresh	F6:Find	ESC
00001	admin					

User Macros

Key : F01

Key	Parameter #1	Parameter #2
Connect	03000 CON 010125349	01000 CPU 010129250
Connect Video	Actual CON device	Disconnect CON

Macro Data

Function	CON Devices	CPU Devices
empty		
Parameter #1		
Actual CON device		
Parameter #2		
Disconnect CON		

SWITCH 01

Edit
Delete
Cancel
Okay


Menu **Configuration – User Macros**

In order to create a macro for the selected user, proceed as follows:

1. Select in the **Key** field the function key (F1-F16) for which a macro has to be created.
2. Select the position in the **Key** list where a macro command is to be inserted.
3. Select a macro command in the **Macro Data** field.
4. Set the necessary parameters **P1** and **P2** (e.g. CON Devices or CPU Devices) for the selected macro command.
5. Confirm your selection by pressing <Enter> and repeat the process for further macro commands, if necessary.

Java-Tool

- ➔ Select in the working area of the **Definition > User** menu the user for which macros are to be created and open the **Macros** tab.



Menu **Definition – User**

In order to create a macro for the selected user, proceed as follows:

1. Select in the **Key** field the function key (F1-F16) for which a macro has to be created.
2. Select in the **Function** column the commands that should be part of the macro. The selection list is opened by a double click on the empty fields.
3. Select in the **P1** and **P2** columns the respective parameters for the macro functions (e.g. corresponding consoles and CPUs).
4. Confirm your selections by pressing the **Apply** button.

For an efficient macro configuration the following context functions are available:

- ➔ Via right click on the **Macros** tab, macros can be assigned to other users by using the **Assign Macros to ...** function and can be copied from other users by using the **Copy Macros from ...** function.

- ➔ Via right click on the macro list, macros of the selected key can be copied into the cache by using the **Copy Key Macros** function. You can paste the macros from the cache into a key by using the **Paste Key Macros** function and you can reset all macros of the selected key by using the **Reset Key Macros** function.

5.6 Extender Settings

All extender units are managed in this menu. This includes the creation of new extender units and the deletion of existing extender units.

The extender unit describes the connection of an physical extender to the matrix. Every extender board with a direct cable connection to the matrix is recognized as an extender unit. Dual-Head KVM extenders will be recognized as two independent extender units.



KVM Extenders automatically create extender units inside the matrix.

You have the following options to access the menu:



You can select the following settings:

Field	Selection	Description
ID	Text	Numerical value of the extender ID (KVM extenders: ID is provided by extender unit (Serial No.) and cannot be changed)
Name	Text	Name of the extender unit
Fixed	activated	Create an extender unit with a fixed port assignment (default)
	deactivated	Function not active.
Port	1–288 (depending on the matrix)	Port number of the extender unit

OSD

➔ Select **Configuration > EXT Units** in the main menu.

Configuration F1:ID F2:Name F3:Next F4:Previous F5:Refresh F6:Find ESC

EXT Units

- 010135668 EXT_010135668
- 010167832 EXT_010167832
- 010203247 EXT_010203247
- 010207794 EXT_010207794
- 016090105 EXT_016090105
- 040011492 EXT_040011492

EXT Data

ID : 10135668 CPU/CON.assigned
 Name : EXT_010135668 01003 CPU_010207794

Fixed : ☐ Port 1/2 : ☐ Universal : ☐

General OSD Data

Horizontal mouse speed [1/x]: 4
 Vertical mouse speed [1/x]: 5
 Double click time [ms]: 200
 Keyboard layout [ms]: German DE.129
 Video mode : variable

Extender OSD Data

Enable CPU selection : ☐
 Enable connection info : ☐
 Update connection info : ☐
 Display time [sec]: 0
 Horizontal position : 0
 Vertical position : 0

EXT Type

Input Signals	CW1	CW2	Output Signals	CW1	CW2
DVI/VGA-CPU (video ..)	<input checked="" type="checkbox"/>	<input type="checkbox"/>	DVI/VGA-CON (video ..)	<input type="checkbox"/>	<input type="checkbox"/>
HID-CON (keyb., mouse..)	<input type="checkbox"/>	<input type="checkbox"/>	HID-CPU (keyb., mouse..)	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Audio (analog, digital)	<input type="checkbox"/>	<input type="checkbox"/>	Audio (analog, digital)	<input type="checkbox"/>	<input type="checkbox"/>
RS232 (serial ..)	<input type="checkbox"/>	<input type="checkbox"/>	RS232 (serial ..)	<input type="checkbox"/>	<input type="checkbox"/>
USB-CON (embedded)	<input type="checkbox"/>	<input type="checkbox"/>	USB-CPU (embedded)	<input type="checkbox"/>	<input type="checkbox"/>
USB-CON (standalone)	<input type="checkbox"/>	<input type="checkbox"/>	USB-CPU (standalone)	<input type="checkbox"/>	<input type="checkbox"/>
Universal-CON	<input type="checkbox"/>	<input type="checkbox"/>	Universal-CPU	<input type="checkbox"/>	<input type="checkbox"/>
Cascade-CON	<input type="checkbox"/>	<input type="checkbox"/>	Cascade-CPU	<input type="checkbox"/>	<input type="checkbox"/>

Buttons: New, Edit, Delete, Cancel, Okay

SWITCH_01

Menu **Configuration – EXT Units**


You can select the following buttons:

Button	Function
New	Create a new extender unit
Edit	Edit an existing extender unit
Delete	Delete an existing extender unit
Cancel	Reject changes
Save	Save changes

The settings for the tab OSD Data are described in Chapter 5.11.2, Page 133.

Java Tool

➔ Select **Definition > EXT Units** in the task area.



Menu **Definition – EXT Units**

You can select the following buttons:

Button	Function
New	Create a new extender unit
Delete	Delete an existing unit
Apply	Confirm changes of an extender unit
Cancel	Reject changes

5.6.1 Flex-Port Extender Units

Extenders with auto-ID functionality are automatically recognized and cannot be created manually. This is the Flex Port function of the matrix.



The connection of a fixed port extender unit (e. g. USB 2.0) to a Flex-Port can cause unintended results.

5.7 USB-2.0-Extender


This chapter helps you to configure and use your USB 2.0 extenders. These extenders will have to be connected to standard I/O boards in this case. USB 2.0 extenders can be configured for independent switching or can be assigned to already existing KVM extenders.

You have the following options to configure the extenders:



OSD

➔ Select **Configuration > EXT Units** in the main menu.




Menu Configuration – EXT Units

1. In order to configure a USB 2.0 extender unit, press the **New** button. An extender with an eight-digit ID will be created, starting with digit **9**.
2. Assign an appropriate name to the extender in the **Name** field.

3. Enter the port number of the matrix physically connected to the USB 2.0 extender unit into the **Port** field.
4. In order to configure the created extender as a CON Unit, set the **USB-CON (standalone)** option to **Y (C#1** in the **Input Signals** column) and confirm by pressing the **Okay** button.
5. In order to configure the created extender as a CON Unit, set the **USB-CPU (standalone)** option to **Y (C#1** in the **Output Signals** column) and confirm by pressing the **Okay** button.
6. In order to create an individually switchable Device for the USB 2.0 CON extender, select **Configuration > CON Devices** and press the **New R** button.
Alternatively, you can assign the USB 2.0 CON extender to an already existing CON Device. For this purpose, select the Device and move the USB 2.0 CON extender from the **EXT available** field into the **EXT assigned** field.
7. Give an appropriate name to the new Device in the **Name** field.
8. Repeat the steps 6. and 7. for all USB 2.0 CPU extenders in the **Configuration > CPU Devices** menu.
9. If you use parallel operation within the matrix, set the **Release Time** in the **Configuration > Switch** menu to **10 s** or more (see Chapter 5.11.6, Page 145).
10. Restart all I/O boards on which USB 2.0 extenders have been configured or alternatively restart the matrix.
The USB 2.0 extender are now configured and can be used.

Java Tool

➔ Select **Definition > EXT Units** in the task area.



Menu **Definition – EXT Units**

1. Press the **New** button.
A popup window opens.
2. Select (**Templates**) in the selection box, if you want to use a template for a USB 2.0 CON Unit (**USB CON Unit**) or a USB 2.0 CPU Unit (**USB CPU Unit**).
An extender with an eight-digit ID will be created, starting with digit **9**.
3. Give an appropriate name to the extender in the **Name** field.
4. Enter the port number of the matrix physically connected to the USB 2.0 extender unit into the **Port** field.
5. Confirm your settings by pressing the **Apply** button.
6. The USB 2.0 CON extenders now has to be either assigned to an existing CON Device in the menu **Definition > CON Devices** or a new CON Device has to be created for the assignment by pressing the **New** button.

7. The USB 2.0 CPU extenders now has to be either assigned to an existing CON Device in the **Definition > CPU Devices** menu or a new CON Device has to be created for the assignment by pressing the **New** button.
8. If you use parallel operation within the matrix, set the **Release Time** in the **Configuration > Switch** menu to **10 s** or more (see Chapter 5.11.6, Page 145).
9. Restart all I/O boards on which USB 2.0 extenders have been configured or alternatively restart the matrix.

The USB 2.0 extenders are now configured and can be used.



Created extender units are always set as fixed port extenders. This configuration is necessary if you want to switch e.g. USB 2.0 connections via the matrix.

In order to make a fixed port available again for Flex-Port extender units after deleting a fixed port extender unit, a restart of the I/O board is necessary.

5.8 Extenders for UNI I/O Boards (USB 2.0 / USB 3.0)

This chapter will help you to configure and use your USB 2.0/3.0 extenders. For the use of USB 3.0 extenders you need at least one UNI I/O board and SFP modules based on 6.25 Gbit/s for the matrix.

You have the following options to configure the system:



OSD

➔ Select **Configuration > EXT Units** in the main menu.

admin@CON 010167832
Configuration

F1:ID F2:Name F3:Next F4:Previous F5:Refresh F6:Find ESC

EXT Units

- 010135668 EXT_010135668
- 010167832 EXT_010167832
- 010203247 EXT_010203247
- 010207794 EXT_010207794
- 016090105 EXT_016090105
- 040011492 EXT_040011492

EXT Data

ID : 010135668 CPU/CON_assigned
Name : EXT_010135668 01003 CPU_010207794

Fixed : ☐ Port 1/2 : 11 / 0 Universal : ☐

General OSD Data

Horizontal mouse speed [1/x]: 4
Vertical mouse speed [1/x]: 5
Double click time [ms]: 200
Keyboard layout : German DE_129
Video mode : variable

Extender OSD Data

Enable CPU selection : ☐
Enable connection info : ☐
Update connection info : ☐
Display time [sec]: 0
Horizontal position : 0
Vertical position : 0

EXT Type

Input Signals	C#1	C#2	Output Signals	C#1	C#2
DVI/VGA-CPU (video ..)	<input checked="" type="checkbox"/>	<input type="checkbox"/>	DVI/VGA-CON (video ..)	<input type="checkbox"/>	<input type="checkbox"/>
HID-CON (keyb., mouse..)	<input type="checkbox"/>	<input type="checkbox"/>	HID-CPU (keyb., mouse..)	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Audio (analog, digital)	<input type="checkbox"/>	<input type="checkbox"/>	Audio (analog, digital)	<input type="checkbox"/>	<input type="checkbox"/>
RS232 (serial ..)	<input type="checkbox"/>	<input type="checkbox"/>	RS232 (serial ..)	<input type="checkbox"/>	<input type="checkbox"/>
USB-CON (embedded)	<input type="checkbox"/>	<input type="checkbox"/>	USB-CPU (embedded)	<input type="checkbox"/>	<input type="checkbox"/>
USB-CON (standalone)	<input type="checkbox"/>	<input type="checkbox"/>	USB-CPU (standalone)	<input type="checkbox"/>	<input type="checkbox"/>
Universal-CON	<input type="checkbox"/>	<input type="checkbox"/>	Universal-CPU	<input type="checkbox"/>	<input type="checkbox"/>
Cascade-CON	<input type="checkbox"/>	<input type="checkbox"/>	Cascade-CPU	<input type="checkbox"/>	<input type="checkbox"/>

SWITCH_01

New Edit Delete Cancel Okay

Menu **Configuration – EXT Units**


1. Insert the SFP modules into the matrix and connect the extenders according to the required application.
One extender will be created for each SFP module in the **EXT Units** list. The appropriate names always start with "UNI".
2. In order to configure a CON Unit, select one of the extenders in the **EXT Units** list that are physically connected to a USB CON Unit.
3. Edit the extender by setting the **USB-CON (standalone)** option in the **Input Signals** field to **Y** for **C#1**. Set additionally the **Universal-CPU** option in the **Output Signals** field to **N** for **C#1**.
4. In order to configure a CPU Unit, select one of the extenders in the **Ext Units** list that are physically connected to a USB CPU Unit.
5. Edit the extender by setting the **USB-CPU (standalone)** option in the **Output Signals** field to **Y** for **C#1**. Set additionally the **Universal-CPU** option in the **Input Signals** field to **N** for **C#1**.

- The edited EXT Units for the respecting USB CON Units now have to be either assigned to an existing CON Device or you have to create a new CON Device by using the **New R.** button for an assignment in the **Configuration > CON Devices** menu.
- The edited EXT Units for the respecting USB CPU Units now have to be either assigned to an existing CPU Device or you have to create a new CPU Device by using the **New R.** button for an assignment in the **Configuration > CPU Devices** menu.
- If you use parallel operation within the matrix, set the **Release Time** in the **Configuration > Switch** menu to **10 s** or more ().
- Restart the matrix.

The USB extenders are completely configured now and can be used.

Java-Tool

➔ Select **Definition > EXT Units** in the task area.



Menu Definition – EXT Units

1. Insert the SFP modules into the matrix and connect the extender according to the required application.
One extender will be created for each SFP module in the **Ext Units** list. The appropriate names always start with "UNI".
2. In order to configure a CON Unit, select one of the extenders in the **Ext Units** list that are physically connected to a USB CON Unit.
3. Select the item **UNI CON USB** in the **Type** selection box of the **Extender Type** tab and confirm your settings by pressing the **Apply** button.
4. Restart the I/O board upon request in the popup window by pressing the **Yes** button.
5. In order to configure a CPU Unit, select one of the extenders in the **Ext Units** list that are physically connected to a USB CPU Unit.
6. Select the item **UNI CPU USB** in the **Type** selection box of the **Extender Type** tab and confirm your settings by pressing the **Apply** button.
7. Restart the I/O board upon request in the popup window by pressing the **Yes** button.
8. The edited EXT Units for the respecting USB CON Units now have to be either assigned to an existing CON Device or you have to create a new CON Device by using the **New** button for an assignment in the **Definition > CON Devices** menu.
9. The edited EXT Units for the respecting USB CPU Units now have to be either assigned to an existing CPU Device or you have to create a new CPU Device by using the **New** button for an assignment in the **Definition > CPU Devices** menu.
10. If you use parallel operation within the matrix, set the **Release Time** in the **System > Switch** menu to **10 s** or more ().

The USB extenders are completely configured now and can be used.

5.9 Configuration of SDI

This chapter will help you to configure the matrix for the use of SDI. Using SDI requires at least one I/O board and appropriate SFP modules according to the SDI video signal to be used.

You have the following options to configure the system:



OSD

➔ Select **Configuration > EXT Units** in the main menu.

Configuration F1:ID F2:Name F3:Next F4:Previous F5:Refresh F6:Find ESC

EXT Units

- 010135668 EXT_010135668
- 010167832 EXT_010167832
- 010203247 EXT_010203247
- 010207794 EXT_010207794
- 016090105 EXT_016090105
- 040011492 EXT_040011492

EXT Data

ID : 010135668 CPU/CON assigned
 Name : EXT_010135668 01003 CPU_010207794

Fixed : ☐ N Port 1/2 : 11 / 0 Universal : ☐ N

General OSD Data

Horizontal mouse speed [1/x]: 4
 Vertical mouse speed [1/x]: 5
 Double click time [ms]: 200
 Keyboard layout : German DE_129
 Video mode : variable

Extender OSD Data

Enable CPU selection : ☐ N
 Enable connection info : ☐ N
 Update connection info : ☐ N
 Display time [sec]: 0
 Horizontal position : 0
 Vertical position : 0

EXT Type

Input Signals	CW1	CW2	Output Signals	CW1	CW2
DVI/VGA-CPU (video ..)	<input checked="" type="checkbox"/> Y	<input type="checkbox"/> N	DVI/VGA-CON (video ..)	<input type="checkbox"/> N	<input type="checkbox"/> N
HID-CON (keyb., mouse..)	<input type="checkbox"/> N	<input type="checkbox"/> N	HID-CPU (keyb., mouse..)	<input checked="" type="checkbox"/> Y	<input type="checkbox"/> N
Audio (analog, digital)	<input type="checkbox"/> N	<input type="checkbox"/> N	Audio (analog, digital)	<input type="checkbox"/> N	<input type="checkbox"/> N
RS232 (serial ..)	<input type="checkbox"/> N	<input type="checkbox"/> N	RS232 (serial ..)	<input type="checkbox"/> N	<input type="checkbox"/> N
USB-CON (embedded)	<input type="checkbox"/> N	<input type="checkbox"/> N	USB-CPU (embedded)	<input type="checkbox"/> N	<input type="checkbox"/> N
USB-CON (standalone)	<input type="checkbox"/> N	<input type="checkbox"/> N	USB-CPU (standalone)	<input type="checkbox"/> N	<input type="checkbox"/> N
Universal-CON	<input type="checkbox"/> N	<input type="checkbox"/> N	Universal-CPU	<input type="checkbox"/> N	<input type="checkbox"/> N
Cascade-CON	<input type="checkbox"/> N	<input type="checkbox"/> N	Cascade-CPU	<input type="checkbox"/> N	<input type="checkbox"/> N

Buttons: New, Edit, Delete, Cancel, Okay

SWITCH 01

Menu **Configuration - EXT Units**


1. Insert the SFP modules into the matrix.

One extender will be created for each SFP module in the **EXT Units** list. The appropriate names always start with "UNI".

2. In order to configure a SDI input select one of the extenders in the **EXT Units** list that corresponds to the respective SFP and is intended to be used as input.
3. Edit the extender by setting the **Universal-CPU** option in the Output Signals field to **Y** for **C#1**. Set additionally the **Universal-CON** option in the Input Signals field to **N** for **C#1**.
4. In order to configure a SDI output select one of the extenders in the **EXT Units** list that corresponds to the respective SFP and is intended to be used as output.
5. Edit the extender by setting the **Universal-CON** option in the Input Signals field to **Y** for **C#1**. Set additionally the **Universal-CPU** option in the Output Signals field to **N** for **C#1**.
6. The edited EXT Units for the SDI inputs now have to be either assigned to an existing CPU Device or you have to create anew CPU Device by using the **New R.** button for an assignment in the **Configuration > CPU Devices** menu.
7. The edited EXT Units for the SDI outputs now have to be either assigned to an existing CON Device or you have to create a new CON Device by using the **New R.** button for an assignment in the **Configuration > CON Devices** menu.
8. Restart the Matrix.
The SDI inputs and outputs are completely configured now and can be used.

Java-Tool

➔ Select **Definition > EXT Units** in the task area.



Menu Definition - EXT Units

1. Insert the SFP modules into the matrix.
One extender will be created for each SFP module in the **EXT Units** list. The appropriate names always start with "UNI".
2. In order to configure a SDI input select one of the extenders in the **EXT Units** list that corresponds to the respective SFP and is intended to be used as input.
3. Select the item **UNI CPU** in the Type selection box of the **Extender Type** tab and confirm your settings by pressing the **Apply** button.
4. Restart the I/O board upon request in the popup window by pressing the **Yes** button.
5. In order to configure a SDI output select one of the extenders in the **EXT Units** list that corresponds to the respective SFP and is intended to be used as output.
6. Select the item **UNI CON** in the **Type** selection box of the **Extender Type** tab and confirm your settings by pressing the **Apply** button.
7. Restart the I/O board upon request in the popup window by pressing the **Yes** button.

8. The edited EXT Units for the SDI inputs now have to be either assigned to an existing CPU Device or you have to create a new CPU Device by using the **New R.** button for an assignment in the **Configuration > CPU Devices** menu.
9. The edited EXT Units for the SDI outputs now have to be either assigned to an existing CON Device or you have to create a new CON Device by using the **New R.** button for an assignment in the **Configuration > CON Devices** menu.

The SDI inputs and outputs are completely configured now and can be used.

5.10 CPU Settings

New CPU Devices are configured in this menu including their assignment to extenders.

The assignment helps to describe and switch more complex computer configurations (e.g. Quad-Head with USB 2.0) in the matrix.

You have the following options to access the menu:




You can select the following settings:

Field	Selection	Description
ID	Text	ID of the CPU Unit (see Chapter 5.4.2, Page 83).
Name	Text	Name of the CPU Device.
Virtual Device	activated	Create new CPU Device as a virtual one.
	deactivated	Function not active (default).
Allow Private	activated	Allow switching to the respective CPU Device in Private Mode
	deactivated	Function not active (default).
Force Private	activated	Force switching to the respective CPU only in Private Mode.
	deactivated	Function not active (default).
Fix Frame	activated	Force showing a red frame when switching to the respective CPU.
	deactivated	Function not active (default).

OSD

➔ Select **Configuration > CPU Units** in the main menu.




Menu **Configuration – CPU Devices**

You can select the following buttons:

Button	Function
New R.	Create a new real CPU Device
New V.	Create a new virtual CPU Device
Edit	Edit an existing CPU Device
Delete	Delete an existing CPU Device
Cancel	Reject changes
Save	Save changes

Java Tool

➔ Select **Definition > CPU Devices** in the task area.



Menu Definition – CPU Devices

You can select the following buttons:

Button	Function
New	Open a new CPU Device
Delete	Delete a new CPU Device
Apply	Confirm a created CPU Device
Cancel	Reject changes
>	Assign selected extender units
>>	Assign all available extender units
<	Remove selected extender units
<<	Remove all extender units

You can select the following keyboard commands:

Function	Keyboard Command
Change assignment number of EXT unit upwards	<+>
Change assignment number of EXT unit downwards	<->

In order to create a new CPU Device, proceed as follows:

1. Press the **New** button.
2. Select a real CPU (**Create a real CPU**) or a virtual CPU (**Create a virtual CPU**) or a template of an existing CPU (**Choose template**).



A template can only be used if there is at least one existing CPU Device.

3. Press the **OK** button.
4. Determine all parameters that are relevant for the CPU.
5. To confirm the new CPU, press the **Apply** button.

In order to access a new CPU via matrix, an assignment of one or more CPU type extender units is required. Proceed as follows:

1. Select the new CPU in the **CPU Devices** list.
2. Select one or more extenders in the **Extender available** list.
3. Perform the assignment by pressing the **>** button. To assign all available extenders to the CPU, press the **>>** button.

The assignments are displayed in the **Extender assigned** list.

4. Confirm the assignment by pressing the **Apply** button.

In order to remove an extender assignment, proceed as follows:

1. Select a CPU in the **CPU Devices** list.
2. Select one or more extenders in the **Extender assigned** list.
3. Remove the assignment with the **<** button. To remove all existing assignments, press the **<<** button.
4. Confirm the removal with the **Apply** button.

5.11 Console Settings

You have the option to perform the following console settings:

5.11.1 CON Devices

New CON Devices are created in this menu including access rights and assignment to extenders.

You have the following options to access the menu:




You can select the following settings:

Field	Selection	Description
ID	Text	ID of the CON Unit (see Chapter 5.4.2, Page 83).
Name	Text	Name of the CON Device.
Virtual Device	activated	Create new CON Device as a virtual one.
	deactivated	Function not active (default).
Allow User ACL	activated	Allow activation of the User ACL at the local console.
	deactivated	Function not active (default).
Force Login	activated	Force user login at this CON Device.
	deactivated	Function not active (default).
LOS Frame	activated	<ul style="list-style-type: none"> When the video signal between source (computer, CPU) and the CPU Unit or the connection between matrix and the CON Unit is lost, an orange frame will be displayed. When switching to a CPU without video signal, a blank screen will appear surrounded by an orange frame.
	deactivated	Function not active (default).

Field	Selection	Description
Allow CPU Scan	activated	Allow a scan mode with an automatic change of the video signal for the favorite list (CPU Devices) of the respective console or a logged in user.
	deactivated	Function not active (default).
Force CPU Scan	activated	Force a scan mode with an automatic change of the video signal for the favorite list (CPU Devices) of the respective console or a logged in user.
	deactivated	Function not active (default).
Scan Time	0-99 seconds	Retention period until switching to the next CPU Device.
Port Mode	activated	The favorite list will be replaced by a port list where the ports from 1-99 can be directly selected at each matrix. Note: The selection only works for CPU Devices and has to be made according to the switching of favorites. When using the Port Mode, CON and User favorites will be deactivated.
	deactivated	Function not active (default).
Redundancy Off	activated	Function not active
	deactivated	Automatically switch to the second link of a connected redundant CON Unit when losing the primary link of a CPU Unit (default).

OSD

➔ Select **Configuration > CON Devices** in the main menu.




Menu **Configuration – CON Devices**

You can select the following buttons:

Button	Function
New R.	Create a real console
New V.	Create a virtual console
Edit	Edit an existing console
Delete	Delete an existing console
Cancel	Reject changes
Save	Save changes

Java Tool

➔ Select **Definition > CON Devices** in the task area.



Menu **Definition – CON Devices**

You can select the following buttons:

Button	Function
New	Open a new CON Device
Delete	Delete a new CON Device
Apply	Confirm a created CON Device
Cancel	Reject changes
>	Assign selected extender units
>>	Assign all available extender units
<	Remove the selected extender units
<<	Remove all extender units

You can select the following keyboard commands:

Function	Keyboard Command
Decrease assignment number of the extender unit	<+>
Increase assignment number of the extender unit	<->

In order to create a new console, proceed as follows:

1. Press the **New** button.
2. Select a real console (**Create a real Console**) or a virtual console (**Create a virtual Console**) or a template of an existing console (**Choose template**).



A template can only be used, if there is at least one existing CON Device.

3. Press the **OK** button.
4. Determine all parameters that are relevant for the console.
5. To confirm a created console, press the **Apply** button.

To run a CPU via a matrix, one or more CON Units (extender) must be assigned. To place an assignment, proceed as follows:

1. Select the console in the **CON Devices** list that has to be assigned to an extender.
2. Select the extender in the **Extender available** list that should be assigned to the CON.
3. Perform the assignment by pressing the **>** button. To assign all available extenders to the console, press the **>>** button. The assignments are displayed in the **Extender assigned** list.
4. Confirm the assignment by pressing the **Apply** button.

In order to remove an extender assignment, proceed as follows:

1. Select the console in the **CON Devices** list to be modified.
2. Select the extender(s) in the **Extender assigned** list to be removed.
3. Remove the assignment with the **<** button. To remove all existing assignments, press the **<<** button.
4. Confirm the changes by pressing the **Apply** button.

In order to configure CPU access rights of consoles, proceed as follows:

1. Select a console in the **CON Devices** list.
2. Open the **CPU Access Control** tab.
3. Assign new access rights by using the right mouse button or the respective keyboard commands (cf. below).
4. Confirm the configuration by pressing the **Apply** button.

You can select the following keyboard commands:

Function	Keyboard Command
Add CPU to list Full Access	<F>
Add CPU to list Video Access	<V>
Add CPU to list No Access	<N>

5.11.2 Mouse and Keyboard

The OSD configuration for mouse and keyboard is made in this menu.

You have the following options to access the menu:



You can select the following settings:

Field	Selection	Description
Hor. Speed 1/x	1–9	Adjustment of the horizontal mouse speed, 1 = slow, 9 = fast (default value: 4)
Ver. Speed 1/x	1–9	Adjustment of the vertical mouse speed, 1 = slow, 9 = fast (default value: 5)
Double Click	100–800	Adjustment of the time slot for a double click (default value: 200 ms)
Keyboard layout	Region	Set the OSD keyboard layout according to the used keyboard (default: German (DE))
Video Mode	Variable or specific resolution	Resolution that is used when opening OSD



The mouse and keyboard settings are console specific and can be set separately for each console.

OSD

➔ Select **Configuration > EXT Units** in the main menu.

The screenshot shows the 'Configuration' menu with 'EXT Units' selected. The 'EXT Units' list on the left includes several entries, with '010135668 EXT_010135668' highlighted. The 'EXT Data' section on the right displays various settings for the selected unit, including ID, Name, Fixed status, Port 1/2, Universal status, General OSD Data (Horizontal mouse speed, Vertical mouse speed, Double click time, Keyboard layout, Video mode), and Extender OSD Data (Enable CPU selection, Enable connection info, Update connection info, Display time, Horizontal position, Vertical position). The 'EXT Type' section at the bottom shows a table of input and output signals for the selected unit.

EXT Units	
010135668 EXT_010135668	
010167832 EXT_010167832	
010203247 EXT_010203247	
010207794 EXT_010207794	
016090105 EXT_016090105	
040011492 EXT_040011492	

EXT Data

ID : 010135668 CPU/CON. assigned
 Name : EXT_010135668 01003 CPU_010207794
 Fixed : ☐ Port 1/2 : 11 / 0 Universal : ☐
 General OSD Data
 Horizontal mouse speed [1/x]: 4
 Vertical mouse speed [1/x]: 5
 Double click time [ms]: 200
 Keyboard layout [ms]: German DE.129
 Video mode : variable
 Extender OSD Data
 Enable CPU selection : ☐
 Enable connection info : ☐
 Update connection info : ☐
 Display time [sec]: 0
 Horizontal position : 0
 Vertical position : 0

EXT Type

Input Signals	C#1	C#2	Output Signals	C#1	C#2
DVI/VGA-CPU (video ..)	<input checked="" type="checkbox"/>	<input type="checkbox"/>	DVI/VGA-CON (video ..)	<input type="checkbox"/>	<input type="checkbox"/>
HID-CON (keyb., mouse..)	<input type="checkbox"/>	<input type="checkbox"/>	HID-CPU (keyb., mouse..)	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Audio (analog, digital)	<input type="checkbox"/>	<input type="checkbox"/>	Audio (analog, digital)	<input type="checkbox"/>	<input type="checkbox"/>
RS232 (serial ..)	<input type="checkbox"/>	<input type="checkbox"/>	RS232 (serial ..)	<input type="checkbox"/>	<input type="checkbox"/>
USB-CON (embedded)	<input type="checkbox"/>	<input type="checkbox"/>	USB-CPU (embedded)	<input type="checkbox"/>	<input type="checkbox"/>
USB-CON (standalone)	<input type="checkbox"/>	<input type="checkbox"/>	USB-CPU (standalone)	<input type="checkbox"/>	<input type="checkbox"/>
Universal-CON	<input type="checkbox"/>	<input type="checkbox"/>	Universal-CPU	<input type="checkbox"/>	<input type="checkbox"/>
Cascade-CON	<input type="checkbox"/>	<input type="checkbox"/>	Cascade-CPU	<input type="checkbox"/>	<input type="checkbox"/>

Buttons: New, Edit, Delete, Cancel, Okay

Menu **Configuration – EXT Units**

You can select the following buttons:

Button	Function
Cancel	Reject changes
Save	Save changes

Java Tool

➔ Select **Definition > EXT Units** in the task area.



Mouse and keyboard settings are made in the **OSD Data** tab.

#	ID	Name	Port	Type
28	010229547	75-144 (F1242)	44	CPU
29	010229556	75-126 (F1231)	28	CPU
30	010229548	75-145 (F1231)	45	CPU
31	010229549	75-146 (F1231)	45	CPU
32	010229554	75-130 (F1262)	16	CPU
33	010229553	75-120 (F1262)	20	CPU
34	010229557	75-118 (F1262)	19	CPU
35	010229567	75-117 (F1262)	17	CPU
36	010229558	75-119 (F1262)	19	CPU
37	010229564	75-106 (F1241)	6	CPU
38	010229711	75-173 (R11)	73	CON
39	010229704	75-176 (R11)	76	CON
40	010229714	75-170 (R11)	70	CON
41	010229713	75-174 (R11)	74	CON
42	010229699	75-175 (R11)	75	CON
43	010229705	75-171 (R11)	71	CON
44	010229702	75-179 (R11)	79	CON
45	010229698	75-172 (R11)	72	CON
46	010229701	75-177 (R11)	77	CON
47	010229712	75-178 (R11)	78	CON
48	010229708	75-167 (R11)	6	CON
49	010229709	75-168 (R11)	8	CON
50	010229710	75-169 (R11)	8	CON
51	040002033	75-166	8	CON
52	010225009	75-133 (F1262)	33	CPU

Menu **Definition – EXT Units**

5.11.3 Extender OSD

In this menu the settings for the Extender OSD can be adjusted. These are local settings that can be made individually for each console.

You can select the following Extender OSD settings:

Field	Selection	Description
Enable CPU Selection List	activated	When executing the key sequence for opening the OSD, a selection list for switching CPU Devices will be displayed in the center of the monitor. Pressing the <F7> button within the selection list opens the standard OSD.
	deactivated	Function not active (default)
Enable Connection Info	activated	Enable Extender OSD (default: YES)
	deactivated	Function not active
Update Connection Info	activated	Update connection changes during fade-in of Extender OSD (default: YES)
	deactivated	Function not active
Display Time	0-999 seconds	Duration of OSD fade-in (default: 10)
Horizontal Position	10 pixels	Horizontal OSD position (default: -2)
Vertical Position	10 pixels	Vertical OSD position (default: 2)



When setting the horizontal OSD position, a prefixed minus describes the orientation to the right edge of the monitor, e.g. -2 means $2 \times 10 = 20$ pixels to this edge. When setting a vertical position, a prefixed minus describes the orientation to the bottom edge of the monitor.

If the **Update Connections** function is deactivated, the Extender OSD only appears when switching via OSD.

You have the following options to access the menu:



OSD

➔ Select **Configuration > EXT Units** in the main menu.

The screenshot shows the OSD Configuration menu with the following sections:

EXT Units

010135668	EXT_010135668
010167832	EXT_010167832
010203247	EXT_010203247
010207794	EXT_010207794
016090105	EXT_016090105
040011492	EXT_040011492

EXT Data

ID : 10135668 CPU/CON.assigned
 Name : EXT_010135668 01003 CPU_010207794

Fixed : ☐ N Port 1/2 : ☐ 11 / ☐ 0 Universal : ☐ N

General OSD Data

Horizontal mouse speed [1/x]: 4
 Vertical mouse speed [1/x]: 5
 Double click time [ms]: 200
 Keyboard layout : German DE.129
 Video mode : variable

Extender OSD Data

Enable CPU selection : ☐ N
 Enable connection info : ☐ N
 Update connection info : ☐ N
 Display time [sec]: 0
 Horizontal position : 0
 Vertical position : 0

EXT Type

Input Signals	CW1	CW2	Output Signals	CW1	CW2
DVI/VGA-CPU (video ..)	<input checked="" type="checkbox"/> Y	<input type="checkbox"/> N	DVI/VGA-CON (video ..)	<input type="checkbox"/> N	<input type="checkbox"/> N
HID-CON (keyb., mouse..)	<input type="checkbox"/> N	<input type="checkbox"/> N	HID-CPU (keyb., mouse..)	<input checked="" type="checkbox"/> Y	<input type="checkbox"/> N
Audio (analog, digital)	<input type="checkbox"/> N	<input type="checkbox"/> N	Audio (analog, digital)	<input type="checkbox"/> N	<input type="checkbox"/> N
RS232 (serial ..)	<input type="checkbox"/> N	<input type="checkbox"/> N	RS232 (serial ..)	<input type="checkbox"/> N	<input type="checkbox"/> N
USB-CON (embedded)	<input type="checkbox"/> N	<input type="checkbox"/> N	USB-CPU (embedded)	<input type="checkbox"/> N	<input type="checkbox"/> N
USB-CON (standalone)	<input type="checkbox"/> N	<input type="checkbox"/> N	USB-CPU (standalone)	<input type="checkbox"/> N	<input type="checkbox"/> N
Universal-CON	<input type="checkbox"/> N	<input type="checkbox"/> N	Universal-CPU	<input type="checkbox"/> N	<input type="checkbox"/> N
Cascade-CON	<input type="checkbox"/> N	<input type="checkbox"/> N	Cascade-CPU	<input type="checkbox"/> N	<input type="checkbox"/> N

Buttons: New, Edit, Delete, Cancel, Okay

SWITCH_01


Menu **Configuration – EXT Units**

In order to change the Extender OSD settings, proceed as follows:

1. Select the console extender in the **EXT Units** list whose Extender OSD settings has to be adjusted.
2. When confirming the selection by pressing <Enter>, the respective console extender will be enabled for editing.

Java-Tool

➔ Select **Definition > EXT Units** in the task area.



Menu **Definition – EXT Units**

In order to change the Extender OSD settings, proceed as follows:

1. Select the console extender in the **EXT Units** list for which the Extender OSD settings are to be adjusted.
2. Open the **Extender OSD Data** tab.
3. Adjust the desired settings and confirm your changes by pressing the **Apply** button.

5.11.4 Favorite List Consoles

Individual favorite lists of CPUs to be switched frequently can be created for all consoles in this menu. A favorite list can contain up to 16 different CPUs.


The switching of the favorites is done via 'Hot Key' using the keyboard (see Chapter 6.1.1, Page 180).

You have the following options to access the menu:



OSD

➔ Select **Assignments > CON Favorites** in the main menu.



Menu **Assignments** – **CON Favorites**


To create a favorite list for your own console, proceed as follows:

1. Select a CPU to be moved to the favorite list on the **CPU Devices** list. Press <a> to move a CPU Device to the favorite list. Press <r> to remove a CPU from the favorite list.

2. The order of the CPU devices within the favorite list can be changed by pressing <+> and <->.
3. Press the **Save** button to save the settings.

Java Tool

- ➔ Select the user in the working area of the **CON Devices** menu for the favorite list and open the **Favorites** tab.



Menu Definition – CON Devices

To create a favorite list for any console, proceed as follows:

1. Select the CPUs in the **CPU available** list that should be added to the favorite list (**CPU assigned**). At the same time, multiple CPU Devices can be marked by pressing and holding <Ctrl>.
2. Press the > button to move the marked CPU Devices to the favorite list. If you press the >> button, the first eight CPU Devices from the list will be moved to the favorite list (**CPU assigned**).
3. The order of marked CPU Devices within the favorite list can be changed by pressing <+> and <->.
4. To remove marked CPU Devices from the favorite list, press the < button. If you press the << button, all CPU Devices will be removed from the favorite list.

5.11.5 Console Macros

In this menu macro commands for switching, disconnection or user administration can be created. The macro commands are created for each console separately.

A macro can execute up to 16 switching commands successively.

The execution of the macros is done via 'Hot Key' and the function keys <F1>-<F16> (see Chapter 6.1.3, Page 182).

You can select the following settings:

Field	Selection	Description
Function (01–16)	Connect (P1=CON, P2=CPU)	Set bidirectional connection from console P1 to CPU P2
	Connect Video (P1=CON, P2= CPU)	Set video connection from console P1 to CPU P2
	Disconnect (P1=CON)	Disconnect console P1
	Logout User	Logout current user
	Set Real CPU (P1=VCPU, P2=RCPU)	Assign a virtual CPU to a real CPU
	Set Virtual CON (P1=RCON, P2=VCON)	Assign a real console to a virtual console
	Push (P1=CON)	The KVM connection is forwarded to console P1 and is changed to a video only connection.
	Push Video (P1=CON)	The video signal of the current connection (KVM or video only) is forwarded to console P1. The connection remains unchanged (KVM or video only).
	Get (P1=CON)	The console gets a KVM connection to the CPU that is currently connected to console P1. The connection of console P1 is changed into a video only connection.

Field	Selection	Description
	Get Video (P1=CON)	The console gets a video only connection to the CPU that is currently connected to console P1. The connection of console P1 remains unchanged (KVM or video only).
	Login User	Login a certain user P1 at console P2
P1	CON or CPU Device	Name of CON or CPU Device
P2	CPU or CPU Device	Name of CON or CPU Device

You have the following options to access the menu:



OSD

- ➔ Select via **Configuration > CON Macros** in the main menu the console for which a console macro is to be created.

03000 CON_010125349 - admin

Configuration F1:ID F2:Name F3:Next F4:Previous F5:Refresh F6:Find ESC

CON devices		CON Macros	
03000 CON_010125349		Key : F01	
		Connect	03000 CON_010125349 01001 CPU_010135060
		Disconnect	03000 CON_010125349

Macro Data		
Function	CON Devices	not used
Disconnect	Actual CON device	
Parameter #1	03000 CON_010125349	
Parameter #2		

Edit
Delete
Cancel
Okay

SWITCH 01


Menu **Configuration – CON Macros**

In order to create a macro for the selected console, proceed as follows:

1. Select in the **Key** field the function key (F1-F16) for which a macro should be created.
2. Select the respective place on the list (1-16) the key that should be set with a macro key.
3. Select for the highlighted position on the list a macro command in the **Macro Data** field.
4. Set the necessary parameters **P1** and **P2** (e.g. CON Devices or CPU Devices) for the selected macro command.
5. Confirm your inputs by pressing <Enter> and repeat the process for further macro commands, if necessary.

Java-Tool

- ➔ Select the console in the working area of the **Definition > CON Devices** menu for which a macro has to be created and open the **Macros** tab.



Menu Definition – CON Devices

In order to create a macro for the selected console, proceed as follows:

1. Select in the **Key** field the function key (F1-F16) for which a macro has to be created.
2. Select in the **Function** column the commands that should be part of the macro. The selection list will be opened by a double click on the empty fields.
3. Select the respective parameters for the macro functions (e.g. corresponding consoles and CPUs) in the **P1** and **P2** columns.
4. Confirm your inputs by pressing the **Apply** button.

For an efficient macro configuration the following context functions are available:

- ➔ When clicking on the **Macros** tab, macros can be assigned to other consoles by using the **Assign Macros to ...** function and can be copied from other consoles by using the **Copy Macros from ...** function.
- ➔ When clicking on the macro list, macros of the selected key can be copied into the cache by using the **Copy Key Macros** function. You can paste the macros from the cache into a key by using the **Paste Key Macros** function and you can reset all macros of the selected key by using the **Reset Key Macros** function.

5.11.6 Shared Operation

This menu enables shared operation of a CPU Device by two or more CON Devices. A CPU Device can be controlled by only one CON Device at a time but can be taken over successively by other CON Devices. Control of a CPU Unit by a CON Unit is relinquished after the expiration of an inactivity timer associated with the controlling CON Device. The mouse or keyboard may also be used to take control.



In order to allow a smooth and accurate function of the shared operation, you should use identical mice and keyboards. They should be connected to the same USB-HID ports of each CON Unit.

The alternative is using the USB-HID Ghosting (see Chapter 6.11, Page 203).


When taking over control within 10 s, any assigned USB 2.0 / 3.0 extenders, if available, will not be switched due to security and stability aspects.

You have the following options to configure shared operation:



OSD

➔ Select **Configuration > Switch** in the main menu.




Menu **Configuration – Switch**

In order to configure shared operation, proceed as follows:

1. Activate the **Enable Video Sharing** function.
2. Activate the **Force Connect** function.
3. Activate the **Keyboard Connect** function, if taking over control by a keyboard event should be possible.
4. Activate the **Mouse Connect** function, if taking over control by a keyboard movement should be possible.
5. Define a **Release Time** of inactivity (0 - 999 sec.) after which control can be taken over.

Java-Tool

➔ Select **System > Switch** in the task area.



Menu **System – Switch**

In order to configure shared operation, proceed as follows:

1. Activate the **Enable Video Sharing** function.
2. Activate the **Force Connect** function.
3. Activate the **Keyboard Connect** function, if taking over control by a keyboard event is to be permitted.
4. Activate the **Mouse Connect** function, if taking over control by a keyboard movement should be possible.
5. Define a **Release Time** of inactivity (0 - 999 sec.) after which control can be taken over.

5.11.7 Multi-Screen Control

This menu configures the USB-HID switching operation, allowing a CON Device with several monitors to control several connected sources (computers, CPUs). Smooth switching can be performed for up to four connected sources by dragging the mouse pointer beyond the respective monitor to an adjacent one.

Monitors can be arranged side-by-side or in a grid layout.



When using sources (computers, CPUs) in multi-head operation (e.g. dual-head), switching only works manually via keyboard commands. Non-compliance may have a negative influence on the stability of the system.

When using CON Units with the possibility to connect a local source (computer, CPU) in a Multi-Screen Control environment, the local switching will be disabled.



In order to enable Multi-Screen Control, all Extender Units assigned to the related CON Device, must be physically connected to the same block of 4 ports on the I/O board of the matrix.




CON Units that have been already configured for Multi-Screen Control can be connected together to other blocks of 4 ports. In this case any further configuration is not necessary, their functionality will remain as set previously.

You have the following options to access the menu:



OSD

➔ Select **Assignments > Multi-Screen Control** in the main menu.



Menu **Assignments – Multi-Screen Control**


In order to configure the Multi-Screen Control, proceed as follows:

1. In the **Arrangement** field, select the layout for the CON Device you want to configure (**1 x 4** or **2 x 2**).
The fields for the configuration of the individual displays will be arranged accordingly.
2. Activate **Manual** option, if USB-HID switching is to be restricted to keyboard commands (see Chapter 6.6, Page 197).
Manual switching allows the use of multi-head consoles.
3. Ensure that the **Enabled** option is set to **Y** on all displays in order to activate the respective display for Multi-Screen Control.
4. Select one or more control displays within the CON Device by setting the **Control** function to **Y** in the display field.
Control displays are referred to the extender units within the Multi-Screen Control that are connected to keyboard and mouse.

5. When using the **Owner** function, you can determine which control display is permitted for USB-HID switching to the different displays. Select that display from the list.
In order to make a display accessible to all neighboring control displays, set the **Owner** function to **shared**.
6. Use the **Frame** function to configure a red frame that shows the current display with mouse control after the expiration of a selectable timer.
The frame to fade in can be individually activated by using a timer >0 seconds.

Java-Tool

➔ Select **Assignment > Multi-Screen Control** in the main menu.



Menu Assignment – Multi-Screen Control

In order to configure the Multi-Screen Control, proceed as follows:

1. Select the block of 4 ports in the list of the working area that should be configured for Multi-Screen Control.
Only blocks of 4 ports that contain at least one CON Unit are shown.

2. Activate **Manual** option, if the USB-HID switching is to be restricted to keyboard commands (see Chapter 6.6, Page 197).
Manual switching allows the use of multi-head consoles.
3. In the **Arrangement** field, select the layout for the CON Devices you want to configure (**1 x 4** or **2 x 2**).
The fields for the configuration of the individual displays will be arranged accordingly.
4. Select one or more control displays within the CON Device by setting the **Control** function to **Y** in the respective display field.
Control displays are referred to the extender units within the Multi-Screen Control that are connected to keyboard and mouse.
5. When using the **Owner** function, you can determine which control display is permitted for USB-HID switching to the different displays. Select that display from the list.
In order to make a display accessible for all neighboring control displays, set the **Owner** function to **shared**.
6. Use the **Frame** function to configure a red frame that shows the current display with mouse control after the expiration of a selectable timer.
The frame to fade in can be individually activated by using a timer >0 seconds.

5.12 Saving and Loading of Configurations

You have the option to set the following administration of configurations:

5.12.1 Active Configuration

You have the following option to access the menu:



→ Select **Configuration > Save** in the main menu.

By selecting this menu item, the active configuration of the matrix is saved to the permanent matrix memory. By default, the last configuration that has been saved in this way will be restored after a restart of the matrix.



Changing or saving configurations blocks the matrix memory and leads to a freeze of all OSD menus for a few seconds. The switching connections are not affected by this freeze.

If you select **Auto Save** within the system settings an additional automatic saving of the configuration will be periodically performed (see Chapter 5.3.2, Page 76).

5.12.2 Saving of Configurations (internal)

In this menu the current matrix configuration is saved to predefined storage locations. However, it does not replace the buffering of configuration (see Chapter 5.12.1, Page 152).

You have the following options to access the menu:



In **Active**, the name and detailed information of the current configuration are shown. This configuration can be saved.

In **Default** and **File #1** to **File #8**, the name and detailed information of the respective saved configuration are shown. These storage locations can be overwritten.


The storage location to be overwritten by the current configuration must be selected explicitly.

The current configuration will be saved to this storage location and will be shown immediately in the menu. The previously saved configuration saved to this storage location is deleted.

OSD

You have the possibility to save the created configuration within eight storage locations in the matrix (**File #1 – File #8**). Additionally a configuration can also be saved as default configuration.

1. Select **Configuration > Save As...** in the main menu.
2. Select the required storage location (**File #1 – File #8**) or **Default**.




Menu **Configuration – Save as**

Java Tool

In order to save the configuration into the internal matrix memory, proceed as follows:

1. Select **File > Upload** in the menu bar.
2. Enter the IP address of the matrix, your user name and your password and confirm your inputs with the **Next** button.
3. Select the storage location in that the configuration has to be saved (**default** or **config01 – config08**) and confirm with the **OK** button.



Menu File – Upload

5.12.3 Loading of Configurations (internal)

Previously saved configurations are loaded in this menu.

You have the following options to load configurations from files:



In **Active**, the currently loaded configuration is displayed.


In addition to the default configuration, up to eight further configurations can be loaded.

The selection of the configuration to be loaded can be made between eight personalizable configurations and the default settings.

The selected configuration is immediately loaded and displayed in the menu as **Active**. The previously active configuration is deleted.

OSD


1. Select **Configuration > Open** in the main menu.
2. Select the desired configuration.
3. Load the configuration by pressing <Enter>.



Menu **Configuration – Open...**

Java Tool

1. Select **Administration > Activate Configuration** during online-mode in the task area
2. Select the desired configuration.
3. Load the configuration by pressing the **Activate** button.



Menu Administration – Activate Configuration

5.12.4 Saving of Configurations (external)

Configurations can be saved as a files that can be stored independent of the matrix.


You have the following option to access the menu:



1. Select **File > Save As** in the menu bar.
2. Enter a name for the configuration.
3. Select the directory of the configuration on your storage medium where it is to be saved.



Configurations are always saved in a file with the ending **etc**.



*Menu **File** – **Save As***

5.12.5 Loading of Configurations (external)


Externally saved configurations are opened and activated in this menu.

You have the following option to load configurations from files:



1. Select **File > Open...** during offline-mode and select the storage location of the configuration file that has to be opened.
2. Open the configuration by pressing the **Open** button.
3. Select **File > Upload** in the menu bar to transfer the opened configuration to the matrix. Enter the necessary parameters.
4. Select **Matrix > Connect** in the menu bar to make a connection between the matrix and the Java tool. Enter the necessary parameters.
5. Select **Administration > Activate Configuration** and select the configuration to be activated.
6. Confirm the process with the **Activate** button.

The opened configuration is activated.



Menu File – Open...

5.13 Export and Import Options

The Draco tera offers the ability to read out available configuration lists (extender, CPUs, consoles and users) for export and import again via Java tool. You have the following option to handle configuration lists.

Exported configuration lists are always saved in .csv format that allows offline editing with common spreadsheet applications.


You have the following option to export or import configuration lists:



5.13.1 Export Options

Configuration lists are exported in this menu. In order to export, proceed as follows:

1. Select **File > Export** in the menu bar.
2. After opening the menu, select the list to export (**Extender, CPU, Console or User**).
3. Select the storage location for the export file.
4. Confirm the export with the **Finish** button.



Menu File – Export


5.13.2 Import Options

Configuration lists are imported in this menu. In order to import, proceed as follows:

1. Select **File > Import** in the menu bar of an offline configuration.
2. After opening the menu, select the list to import (**Extender, CPU, Console or User**).
3. Select the directory of the list to import.
4. Confirm the import with the **Finish** button.



Importing configuration lists is only possible in offline configurations.



Menu **File** – **Import...**

5.14 Matrix Cascading

This simple method of cascading allows a switchable connection between two matrices via so called **Tie Lines**.

The Matrix Cascading does not require **Bundle 4**.

This kind of configuration may become necessary, if the number of ports in the entire system has to be increased or if certain important connections should be distributed to several matrices due to reasons of redundancy.

The Tie Lines are unidirectional and can only be used in one direction according to their configuration. For a bidirectional use of the cascading you have to configure opposite Tie Lines.

In order to connect Tie Lines to the matrices, you have to create intended Master/Slave CON and Master/Slave CPU Devices that have to be switched within the cascaded environment.

You have the following options to configure Matrix Cascading:



General Preparation

1. Define a **Master Matrix**. All further matrices will be configured as **Sub Matrices** in the configuration process.
2. Ensure that the Tie Lines will only connected after finishing the configuration.

OSD

- ➔ Select **Configuration > EXT Units** in the main menu of the master matrix.

The screenshot shows the 'Configuration' menu with 'EXT Units' selected. The 'EXT Units' list contains several entries, with 'EXT_010135668' highlighted. The 'EXT Data' section shows fields for ID (010135668), Name (EXT_010135668), Fixed (N), Port 1/2 (11/0), and Universal (N). It also includes 'General OSD Data' and 'Extender OSD Data' sections. The 'EXT Type' section contains a table for Input and Output Signals. The bottom bar shows 'SWITCH_01' and buttons for New, Edit, Delete, Cancel, and Okay.

Input Signals	CW1	CW2	Output Signals	CW1	CW2
DVI/VGA-CPU (video ..)	Y	N	DVI/VGA-CON (video ..)	N	N
HID-CON (keyb., mouse..)	N	N	HID-CPU (keyb., mouse..)	Y	N
Audio (analog, digital)	N	N	Audio (analog, digital)	N	N
RS232 (serial ..)	N	N	RS232 (serial ..)	N	N
USB-CON (embedded)	N	N	USB-CPU (embedded)	N	N
USB-CON (standalone)	N	N	USB-CPU (standalone)	N	N
Universal-CON	N	N	Universal-CPU	N	N
Cascade-CON	N	N	Cascade-CPU	N	N

Menu **Configuration - EXT Units**

1. Press the **New** button.
A new Extender Unit will be created that is needed for the connection of Tie Lines.
2. Enter an appropriate extender name into the **Name** field.
3. Enter a port number into the **Port** field according to the required connection of the Tie Line.
4. If the Tie Line should be directed from the Sub to the Master, set the **Cascade-CON** option to **Y (C#1)** in the **Input Signals** column.
If the Tie Line should be directed from the Master to the Sub, set the **Cascade-CPU** option to **Y (C#1)** in the **Output Signals** column.
5. Save your settings by pressing the **Okay** button.
6. If you have created a Master/Slave CON Unit, select **Configuration > CON Devices** in the main menu of the master matrix and press the **New R** button.
A switchable CON Device will be created.

7. If you have created a Master/Slave CPU Unit, select **Configuration > CPU Devices** in the main menu of the master matrix and press the **New R** button.
A switchable CPU Device will be created.
8. Enter an appropriate Device name into the **Name** field.
9. Assign the previously configured Extender Unit to the just created Device by moving the Extender Unit from the **Ext available** field into the **Ext assigned** field and save your settings.
10. Repeat steps 1 to 9 for the Sub Matrix.
11. Select **Configuration > System** in the main menu of the Sub Matrix and set the **Sub Matrix** option to **Y**.
The OSD of the Sub Matrix will immediately freeze and will be only accessible by using the keyboard command <'Hot Key'>, <s>, <o>.
12. Restart all I/O boards on which any Master/Slave CON or CPU Units have been configured or alternatively restart the matrix.
13. Connect the Tie Lines to the matrices. Ensure that each **Master/Slave CON** on one matrix is connected to **Master/Slave CPU** on the other matrix in order to achieve switchability between two matrices.

The Matrix Cascading is now configured and can be used. Additional Tie Lines are configured accordingly. The use of cascading is described in Chapter 6.1.4, Page 183.

2017-03-31

- [illegible]

3. If the Tie Line should be directed from the Sub to the Master, select **Master/Slave CON Unit** in the **Choose Extender Type** selection box.
If the Tie Line should be directed from the Sub to the Master, select **Master/Slave CPU Unit** in the **Choose Extender Type** selection box.
4. Enter an appropriate extender name into the **Name** field.
5. Enter a port number into the **Port** field according to the required connection of the Tie Line.
6. Confirm your settings by pressing the **Apply** button.

7. If you have created a Master/Slave CON Unit, select **Definition > CON Devices** in the task area of the master matrix and press the **New** button.
A switchable CON Device will be created.
8. If you have created a Master/Slave CPU Unit, select **Definition > CPU Devices** in the task area of the Master Matrix and press the **New** button.
A switchable CPU Device will be created.
9. Enter an appropriate extender name into the **Name** field.
10. Assign the previously configured Extender Unit to the just created Device by moving the Extender Unit from the **Extender available** field into the **Extender assigned** field and save your settings by pressing the **Apply** button.
11. Connect to the Sub Matrix and repeat steps 1 to 10.
12. Select **System > System Data** in the task area of the Sub Matrix and activate the **Sub Matrix** option.
The OSD of the Sub Matrix will immediately freeze and will be only accessible by using the keyboard command <'Hot Key'>, <s>, <o>.
13. Restart all I/O boards on which any Master/Slave CON or CPU Units have been configured or alternatively restart the matrix.
14. Connect the Tie Lines to the matrices. Ensure that each **Master/Slave CON** on one matrix is connected to **Master/Slave CPU** on the other matrix in order to achieve switchability between two matrices.

The Matrix Cascading is now configured and can be used. Additional Tie Lines are configured accordingly. The use of cascading is described in Chapter 6.1.4, Page 183.

5.15 Matrix Grid

In this menu you can configure a Matrix Grid in order to connect two or more matrices. This kind of configuration may become necessary if the number of ports in the entire system has to be increased or if certain important connections should be distributed to several matrices due to reasons of redundancy.

The connections between two matrices have to be established by so called Grid Lines that are connected between particular I/O ports as connecting links. The Grid Lines can be used bidirectionally and can respectively handle a full access connection of a CON Device to a CPU Device.

The number of Grid Lines in the system specifies, if a CON Device can be switched to a CPU Device in Non-Blocking Access or in Blocking Access and has to be separately determined for each Grid environment.

In this case Non-Blocking Access means that a Grid Line for a cross-matrix switching operation of a CON Device to a CPU Device is available at any time.

Whereas Blocking Access means that for a certain switching operation no Grid Line may be available according to the switching status within the Grid. The result will be that no cross-matrix switching will be possible.

You have the following options to configure a Matrix Grid:



Administration of Settings

Within a Matrix Grid you have to differ between settings that have to be made locally for each matrix and settings that can be made globally so that they are valid for the whole Matrix Grid.

The settings in the following menus have to be made separately for each matrix or within the master matrix in order to affect all matrices in the Grid:

System, Access, Switch, Network, Date + Time, SNMP, Matrix Grid, Multi-Screen Control

The settings in the following menus have to be made globally and only once within the Matrix Grid:

EXT Units, CPU Devices, CON Devices, User, CON Macros, User Macros, CON Favorites, User Favorites, Virtual CPU Devices, Virtual CON Devices



If global settings are made in the respective menus, they will be immediately available on each matrix within the Matrix Grid.

General Preparation

The following requirements have to be fulfilled before starting the Matrix Grid configuration:

1. The Matrix Grid function (Bundle 4) must be activated on all matrices to be connected to the Grid by a license key (see Chapter 5.17, Page 178).
2. Firmware V03.10 must be installed on all matrices to be connected to the Grid.
3. All matrices to be connected to the Grid must be within the same TCP/IP network (see Chapter 5.4.5, Page 93).
4. The port 5556 needed for network communication must not be blocked by a firewall.

OSD

In order to configure a Matrix Grid, proceed as follows. The following configuration steps have to be repeated for each matrix separately:

➔ Select **Configuration > System** in the main menu.

admin@CON_010195237
Configuration

System

Device : Switch 01 Host name for network environment
Name : Test_Grid Name of current matrix configuration
Info : Factory settings

Sub Matrix : N Allow hotkey control in cascaded environment
Load Default : N Load always default configuration
Auto Save : N Save matrix status automatically
Enable COM Echo : N Echo all switch commands via COM ports
Enable LAN Echo : N Echo all switch commands via LAN ports

Synchronize : N Synchronize matrix with master matrix
Echo Only : N Synchronize matrix with echo only
Master IP Address : 000.000.000.000

Enable Auto Config : Y Assign new extender to a new CPU or CON unit
ID Real CPU Device : 1000 Start ID for automatic assignment of real CPU devices
ID Virt. CPU Device : 2000 Start ID for automatic assignment of virtual CPU devices
ID Real CON Device : 3000 Start ID for automatic assignment of real CON devices
ID Virt. CON Device : 4000 Start ID for automatic assignment of virtual CPU devices

Invalid IO-Boards : N Keep IO-Boards with invalid firmware online for update
Enable old Echos : N Echo internal switch commands with old format


OSD Data CPU

Horizontal mouse speed 11/xl: 4
Vertical mouse speed 11/xl: 5
Double click time msl: 200
Keyboard layout : German DE_129

Cancel
Okay

Menu Configuration – System

1. Enter a unique name for each matrix into the **Device** field. Each name only may exist once within the Matrix Grid.
2. Enter a unique Grid name into the **Name** field. The Grid name has to be same within all Grid matrices.
3. Select **Configuration > Matrix Grid** in the main menu.




Menu **Configuration – Matrix Grid**

4. Activate the **Enable Matrix Grid** function.
5. Write all device names of the Grid matrices into the Matrix Grid list, starting in the left column. Based on the listings, a Grid master will be automatically determined for the Matrix-Grid. The more on the top a matrix is listed in the matrix Grid list, the more likely the matrix is considered in the automatic master selection, provided that certain criteria like system availability are fulfilled.
6. Activate the single matrices in the Matrix Grid list by enabling the **Y (YES)** function.
7. Enter the number of chassis ports for each matrix (**8, 16, 32, 48, 64, 80, 160 or 288**).
8. Restart all matrices, beginning with the master matrix.

The Matrix Grid can be used now and offers the possibility for a cross-matrix switching of CON Devices to CPU Devices.

Java Tool

- ➔ In order to use the Matrix Grid execute the configuration wizard in the menu **System > Matrix Grid**. It guides you through the configuration of Matrix-Grids.



Menu System – Matrix Grid

5.16 Firmware Update

5.16.1 Matrix Update

The firmware of the matrix can be updated in this menu.

You have the following option to access the menu:



Java Tool



Only use computers to update the matrix that are not integrated into the KVM extender / matrix setup.

Ensure that the computer used for the update is not set into stand by mode or sleep mode during the update.

Ensure that your configuration has been saved externally before you start the update.

For reasons of network stability, an update via WLAN is not recommended.

Preparation

Take the following steps in order to be prepared for the matrix update:

1. Save the matrix configuration externally (see Chapter 5.12.4, Page 157).
2. Open **Extras > Options** in the menu bar and insert in the setting **Firmware Directory** the directory from which the update files should be standardly sourced.
3. Put all hot spare boards into the matrix.
4. Activate the Syslog function (see Chapter 5.12.4, Page 157) for the monitoring of the update, if unlocked via license key.




Ensure that all USB 2.0 extenders are only connected to the provided ports (fixed ports) before you start the matrix update. Non-compliance may affect the stability of the update.

Performing the Update

Take the following steps in order to be prepared for the matrix update:

1. Select **Administration > Update Matrix Firmware** in the task area.
All updateable components of the matrix will be automatically selected and highlighted in green.



Menu Administration – Update Matrix Firmware

2. Start the update by pressing the **Update** button in the appearing pop up window.
3. Restart the Matrix after the update by pressing the **Restart matrix** button in the lower part of the working area.



For a safe initialisation of the matrix, a cold start (power cycle) is recommended.

5.16.2 Extender Update

The firmware of the extenders connected to the matrix can be updated in this menu.

You have the following option to access the menu:



Preparation

Take the following steps in order to be prepared for the extender update:


1. Save the matrix configuration externally (see Chapter 3.9, Page 40).
Open **Extras > Options** in the menu bar and insert the name of the directory from which the update files should be sourced in **Firmware Directory**.
2. Connect all hot spare extenders to the matrix.



For reasons of network stability, an update via WLAN is not recommended.

Performing the Update in Standard Mode (parallel Update)

1. Select **Administration > Update EXT Firmware** in the task area. The standard mode for the parallel update will be selected by default and the **Upload Firmware** tab will be opened.



Menu **Administration – Update EXT Firmware**

2. Before the actual update process, all firmware files have to be uploaded to the respective I/O boards on that extenders will have to be updated. If a newer firmware is available, appropriate I/O boards will be automatically selected for the upload in the **Selected** column and highlighted in green.
3. Start the upload and distribution of the update files by pressing the **Upload** button.




By performing the upload process, no update files will be installed. the update process can be performed at a later time.

If there are not selected all I/O cards, the upload of the update files will be performed in sequence.

- After finishing the upload process successful completion will be confirmed by a popup message. If you want to directly start the actual update process, you will have to confirm this by pressing the **Yes** button. You will be immediately forwarded to the **Update Firmware** tab.



When updating an identical or an older firmware version than the version currently installed, the **Force Update** option in the lower part of the working area must be enabled.



Menu **Administration – Update EXT Firmware**

- Start the actual update process by pressing the **Update** button.




Just before the update process, all affected I/O boards will be set into **Service Mode** and retrieved gradually after finishing the respective updates.

Performing the Update in Expert Mode (sequential Update)

Take the following steps in order to be prepared for the extender update:


1. Select **Administration > Update EXT Firmware** and select **Expert Mode** in the upper part of the working area. All updateable extenders will be automatically selected and highlighted in green.



Menu Administration – Update EXT Firmware

2. Set the matrix into Service Mode upon request in the popup window or via **Matrix > Activate Service Mode** in the menu bar.

During activation, all matrix functions are disabled on the I/O boards on which an update is currently performed. An OSD picture indicates the activation of the Service Mode and is displayed on all monitors that are connected to the matrix via a CON device. In addition, the Service Mode is indicated by a red tool icon in the lower part of the working area.



OSD View **Service Mode**

3. Start the update by pressing the **Update** button in the lower part of the working area.
4. Quit Service Mode after updating after responding to the confirmation request in the popup window or via **Matrix > Deactivate Service Mode** in the task area.
5. Verify after the update in the Java tool via **Administration > Update EXT Firmware** in the **Protocol** tab of the **Expert Mode**, if the updates for all extenders have been installed correctly.

5.17 License Management

In this menu the matrix can be upgraded with new function bundles by installation of license keys.



To obtain license keys to upgrade matrix functions, contact your distributor.


You have the following option to access the menu:



Java Tool

In order to activate a function bundle, proceed as follows:

1. Select **Administration > Miscellaneous > License Management** in the task area.



Menu **Administration – Miscellaneous – License Management**

2. Enter your license key in the working area under **Activate Bundles** in the **License Key** field.
3. In order to activate the license key press the **Activate** button. The new functions will be immediately enabled, a restart of the matrix will not be necessary.

6 Operation

The Draco tera can be operated in three different ways:

1. Direct Switching

- via a keyboard connected to a CON port and the favorites
- by a macro keyboard connected to a console port

2. OSD

- via keyboard/mouse directly connected to the CPU board of the matrix
- via keyboard/mouse connected to a CON Unit and the OSD

3. External Switching Commands:

- via an external computer via Java tool (network connection required)
- via a media control (network or serial connection required)

6.1 Operation via 'Hot Keys'

6.1.1 Direct Switching

The direct switching by favorites on a keyboard is the fastest possibility for a user to switch at his console between different CPUs. This offers the option to switch video, keyboard and mouse or video only.

Direct Switching of Video, Keyboard and Mouse

1. Start Command Mode with the 'Hot Key'.
Shift and **Scroll** LEDs on the keyboard will flash, if Command Mode is activated.

2. Enter the index number of the new CPU from the list of favorites and confirm with <Enter>.

At the same time the Command Mode is closed and the console is connected to the new CPU which takes over complete control.

Example: Switching to favorite CPU 7 with video, keyboard and mouse

<left Shift>, <left Shift>, <7>, <Enter>



Fastest switching time can be achieved by using identical mice, keyboards and monitors. This contributes to a smooth and seamless direct switching of the matrix.

Switching in Private Mode

1. Start Command Mode with the 'Hot Key'.
Shift and **Scroll** LEDs on the keyboard will flash, if command mode is activated.

2. Enter the index number of the new CPU from the list of favorites and confirm with <left Shift>, <Enter> pressed at the same time.

At the same time the Command Mode is closed and the console is connected to the new CPU with complete control in **Private Mode**.

Example: Switching to favorite CPU 3 in **Private Mode**

<left Shift>, <left Shift>, <3>, <left Shift>, <Enter>

Direct Switching of Video

1. Start Command Mode with the 'Hot Key'.
Shift and **Scroll** LEDs on the keyboard will flash, if command mode is activated.
2. Enter the index number of the new CPU from the list of favorites and confirm with <Space>.
At the same time Command Mode is closed and the console is connected to the new CPU with video only.
Example: Switching to favorite CPU 1 with video only
<left Shift>, <left Shift>, <1>, <Space>

Switch to previous CPU

1. Start Command Mode with the 'Hot Key'.
Shift and **Scroll** LEDs on the keyboard will flash, if Command Mode is activated.
2. Press the key <p> of your keyboard.
At the same time Command Mode is closed and the console is connected to the previous CPU with complete control.



If you switch to a CPU that was previously connected with Video Access only, you will be connected to this CPU with full KVM access.



You can only switch to valid, unused CPUs using 'Hot Keys'. The options **Force Connect** and **Force Disconnect** as well as the restrictions of the User ACL and CON ACL are taken into account.
'Hot Keys' are only supported, if neither **Enable User Login** nor the **Enable User ACL** is selected and the user is logged in the OSD.

Disconnect current connection

1. Start Command Mode with the 'Hot Key'.
Shift and **Scroll** LEDs on the keyboard will flash, if Command Mode is activated.
2. Press the key <Backspace> of your keyboard.
The Command Mode is closed and the console is disconnected from the previous connected CPU.

6.1.2 Scan Mode

Scan Mode enables fast switching between video signals from different CPUs registered as favorites without continuously using the 'Hot Key'. Switching between two video signals can even take place within one frame.

1. Start command mode with the 'Hot Key'. **Shift** and **Scroll** LEDs on the keyboard will flash, if command mode is activated.
2. Press the key <Left Shift> and hold it down. You can now enter the index numbers of the various CPUs from the list of favorites with the keyboard and immediately switch to the video signal of the respective CPU after entering the index number.
3. Leave Scan Mode by pressing <Left Shift> + <Esc>.



Optimal results can be achieved by the use of as identical resolutions as possible. This contributes to a smooth and seamless function of the scan mode.

6.1.3 Function Keys <F1>—<F16>

In Command Mode you can retrieve the macros 1–16 with the function keys <F1>—<F16> on the connected standard keyboard instead of the special macro keyboard.

The stored command sequence for the appropriate function key is executed and Command Mode is left immediately.



It is not necessary to use <Enter> to confirm selection of macros.

6.1.4 Addressing of Main and Sub Matrices

The Draco tera can be cascaded over two levels. You can either send the commands (including opening the OSD) to the main or the sub matrix.

When in command mode, you can select whether commands should be handled in the main or the sub matrix.

OSD Access

- OSD access to the main matrix:
`<Left Shift>, <Left Shift>, <m> (optional), <o>`
- OSD access to the sub matrix:
`<Left Shift>, <Left Shift>, <s>, <o>`

In order to do a cross-matrix switching, proceed as follows:

1. Open the OSD of the master matrix with the following keyboard sequence:
`<'Hot Key'>, <o>`
2. Select the CPU device configured as Tie Line in the CPU selection list and press `<Enter>` to switch onto.
3. Open the OSD of the sub matrix with the following keyboard command:
`<'Hot Key'>, <s>, <o>`
4. Select your target CPU in the CPU selection list of the sub matrix.



The selected master matrix / sub matrix mode is permanently activated until the other mode will be manually activated. This means that if you select `<s>`, all prospective commands will be sent to the sub matrix, but not if the Command Mode is left in the meantime.

6.2 KVM-Switching

You have the following option to perform switching operations with the Draco tera:




OSD

➔ Select **Switch** in the main menu.



By pressing <F8>, inactive CPU devices can be shown in order to expand the current view.



Menu **Switch**

To switch the console to any available CPU, proceed as follows:

1. Select in the **CPU Devices** list on the left hand side that one that should be connected to the CON Device.
2. Confirm desired connection type with the appropriate keyboard command.

Switching operations from the own CON Device can only be performed on CPU Devices that are available in the **CPU Devices** list.



Listed CPU Devices highlighted in red color are currently connected in Private Mode and are blocked by the connected CON Device.

Switching via Selection List for CPU Devices

The matrix offers the ability to execute KVM switching operations by means of a selection list for CPU Devices next to the OSD in full screen.

In order to use the selection list for CPU Devices, proceed as follows:

1. Activate the **Enable CPU Selection List** option in the **Configuration** menu for those consoles where the selection list for CPU Devices should be available.
2. Execute the key sequence for opening the OSD. The selection list immediately appears in the preset position of the extender OSD.




Pressing <F8> hides inactive CPU Devices to provide a clearer overview.

3. Execute the desired switching operation by pressing the respective key (see Chapter 6.3, Page 187).

In order to prevent a switching operation and access OSD, press <F7>.

In order to close the selection list, press <Esc>.



Example view **Selection list CPU Devices**

Activating the automatical Scan Mode for CPU Devices

The matrix offers the ability to use a scan mode based on the favorite list of each console or user. Scan mode allows the matrix to switch in sequence between the CPU Devices in the favorite list within a predefined time. All scans are performed in video only mode.

To configure scan mode, refer to Chapter 5.11.1, Page 128.

You have the following option to activate the scan mode:



In order to activate scan mode, proceed as follows:

1. Define a favorite list for the respective CON Device or user (see Chapter 5.11.4, Page 139 for CON Devices or see Chapter 5.5.2, Page 104 for users)
2. Start Command Mode with the 'Hot Key' and press <o> to open OSD.
3. Select one of the CPU Devices in the CPU selection list that are defined in your favorite list.

4. Confirm your selection by pressing the **CPU Scanner** button. The scan will automatically start.
5. If you have enabled the **Force CPU Scan** option, the scan will automatically start after switching the respective CON Device to any CPU Device from the favorite list without the need to press the **CPU Scanner** button.

6.3 Extended Switching

You have the following options to perform switching operation with the Draco tera:




OSD

To switch any console to any available CPU, proceed as follows:

- ➔ Select **Extended Switch** in the main menu.



Pressing <F8> hides inactive CPU Devices to provide a clearer overview.



Menu **Extended Switch**

1. Select in the **CON Devices** list on the left hand side that one that should be switched to a CPU Device and open it by pressing <Enter>.
2. Select in the **CPU Devices** list on the left hand side that one that should be connected to the open CON Device.
3. Confirm the desired connection type with the respective keyboard command.

Switching operations from the user's CON Device can only be performed on CPU Devices that are available in the **CPU Devices** list.

The following information is shown in this menu:

Field	Description
CON device	Assigned physical extender unit (CON Unit)
CON assigned	Virtual CON Device that is assigned to the real CON Device
CPU connected	Currently connected CPU Device
CON status	Current connection status (CON Device)
EXT list	List of all available physical extender units (CON Units)

Field	Description
CPU device	Assigned physical extender unit (CPU Unit)
CPU assigned	Real CPU Device that is assigned to a virtual CPU Device
CON connected	Currently connected CON Device
CPU status	Current connection status (CPU Device)
EXT list	List of all available physical extender units (CPU Units)

You can select the following switching functions:


Function	Keyboard Command
Set a video only connection.	<Space>
Set a KVM connection.	<Enter>
Set a KVM connection in private mode (video sharing disabled).	<Shift> + <Enter>
Disconnect own CON Device from CPU Device.	<Backspace>

Java Tool

You have two options to perform switching operations for the Draco tera via Java Tool:

Possibility 1:

➔ Select **Control > Extended Switch** in the task area.



Menu **Control – Extended Switch**

All connected consoles and the associated CPU connections are shown in columns in the working area in this menu.





Switching operations can only be performed in online mode. That means an active network connection is required between the matrix and the Java Tool.

- ➔ In order to set a **KVM connection** between a console and a CPU, double-click on the corresponding selection box within the **Full Access** column and select the requested CPU.
- ➔ In order to set a **video connection** between a console and a CPU, double-click on the corresponding selection box within the **Video Only** column and select the requested CPU.
- ➔ In order to set a **Private Mode** connection between a console and a CPU, double-click on the corresponding selection box within the **Private Mode** column and select the requested CPU.



If a CPU console does not have access rights, it will not appear in the list.

The following symbols are shown in the connection overview:

Symbol	Description
	CON Device is connected via Shared Access with at least one further console to the same CPU. The CON Device has Full Access at the moment.
	CON Device is connected via Shared Access with at least one further console to the same CPU. The CON Device has a Video Access connection at the moment.

You can use the following buttons to perform a switching operation:

Button	Function
Send	Send effected switching operations to the matrix
Reset	Disconnect all existing connections within the matrix
Reload	Reload switching status




When the **Auto Send** function in the left lower corner of the work area is ticked, switching operations will be completed immediately without user confirmation by means of the **Send** button.

When the **Hide Devices w/o Extender Assignment** function in the left lower corner of the work area is ticked, only CON and CPU Devices that are assigned to extenders are shown.

Possibility 2:

- ➔ Select **Status > Matrix View** in the task area or select **Status > Grid Port View** when using a Matrix Grid.



Menu **Status – Matrix View**

In order to perform switching operations between CON and CPU Devices proceed as follows:

1. Move the mouse cursor to the port that has to be switched.
2. Hold down the left mouse button and move the cursor to the port that has to be connected to the initial port. The current cursor movement will be displayed by a black auxiliary line.
3. Release the left mouse button. A popup to select the available switching type (**Full Access**, **Video Access** or **Private Mode**) will be opened.
4. Select the desired switching type. The switching operation will be immediately executed. At the same time all extender units that are assigned to the involved devices will be switched.



If a port is shown with a red cross on **Matrix View**, the console does not have access rights to the CPU connected to that port.

In order to disconnect existing connection between CON and CPU Devices proceed as follows:

1. Click on the port that is to be disconnected by using the right mouse button.
2. Select the **Disconnect** function in the popup that appears. The connected ports will be immediately disconnected. At the same time all further connections of the extenders assigned to the involved devices will be disconnected.

6.4 Switching of single Extenders within Devices

You can independently switch single extenders within configurations consisting of CON and CPU devices with multiple extenders.


You have the following option to switch single extenders:



OSD

In order to switch a single extender a device with multiple extender, proceed as follows:

➔ Select **Switch** in the main menu.



Menu – Switch

1. Select the respective CPU Device in the CPU selection list containing the extender you want to have access to.
2. Press the function key **<F7>** on the keyboard. The standard will change into the switching mode for single extenders.
3. Select the extender you want to switch within your CON Device.
4. Access the extender list of the selected CPU Device by pressing the key **<Tab>**.
5. Select the CPU extender you want to switch to and press the key **<Space>** in order to execute the switching operation.



Switching of single extenders from a Device is only possible in video only mode. Single extenders of a Device that are already switched will be highlighted with "!".

6.5 CON Switch

KVM extender CON Units connected to a local source (computer, CPU) can be locally switched via the matrix. Switching is performed between the local source and the KVM connection and can be executed via 'Hot Keys' or via OSD.

If you switch to the local source, the KVM connection will be automatically disconnected.




When using CON Units with the possibility to connect a local source (computer, CPU) in a Multi-Screen Control environment, the local switching will be disabled.

You have the following option to switch to the local source:



OSD

➔ Select **Switch** in the main menu.



Menu – **CON Switch**

In order to switch to a local source, proceed as follows:

1. If you are not in the **Switch** menu of the OSD, start Command Mode with the 'Hot Key' (see Chapter 5.1, Page 57).
2. Press <o> to open OSD.
You will see a list of all available CPUs as a start menu.
3. Switch to the CPU in the **Local CPU** list.
The switching operation to the local source will be performed immediately.



The local source (computer, CPU) will be only shown in the OSD, if the connected CON Unit includes the option for a local connection.

As an alternative, the following keyboard commands are available to switch to the local source:

Function	Keyboard Command
Switching to extender connection	<'Hot Key'>, <k>, <1>, <Enter>
Switching to extender connection 2 (only with redundant CON Units)	<'Hot Key'>, <k>, <2>, <Enter>
Switching to the local source (computer, CPU)	<'Hot Key'>, <l>, <Enter>

6.6 Multi-Screen Control

The Multi-Screen function contains a switching of the USB-HID signal between different statically connected sources (computer, CPU) within a CON Device and can be performed in two different ways:

Switching via Mouse

The switching of the USB-HID signal can be made by a movement of the mouse pointer beyond the edge of the current display to a neighboring display (see Chapter 5.11.7, Page 148).

In order to perform a switching operation by movement of the mouse pointer, proceed as follows:

1. Move the mouse pointer to that edge of the display which borders vertically or horizontally to the neighboring display.
2. Move the mouse pointer beyond the edge of the display. The mouse pointer will appear on the adjacent display.
The switching operation has been performed and the USB-HID signal will be now available at the target display.

Switching via Keyboard

Switching of the USB-HID signal can also be achieved using the keyboard (configuration see Chapter 5.11.7, Page 148).

In order to perform a switching operation via keyboard command, proceed as follows:

1. Start Command Mode with the 'Hot Key' (see Chapter 5.1, Page 57).
2. Select the target display by pressing the respective key on the numeric pad of the keyboard.
The switching operation will be performed and the USB-HID signal will be available at the target display.

You can select the following switching operations:

Keyboard Command	Function
<current 'Hot Key'>, <Num 0>	Switching of the USB-HID signal to the own display (CON Unit with keyboard and mouse)
<current 'Hot Key'>, <Num 1>	Switching of the USB-HID signals to display #1
<current 'Hot Key'>, <Num 2>	Switching of the USB-HID signals to display #2
<current 'Hot Key'>, <Num 3>	Switching of the USB-HID signals to display #3
<current 'Hot Key'>, <Num 4>	Switching of the USB-HID signals to display #4

6.7 USB 2.0 Switching

Switching of USB 2.0 extender basically works like switching of KVM extenders. The following scenarios to switch USB 2.0 extenders are possible.

1. An extender unit with USB 2.0 will be created and assigned to an already existing device with existing KVM extender units (see Chapter 5.10, Page 124 or Chapter 5.11.1, Page 128).
2. A separate device for the extender unit with USB 2.0 will be created without assigning a KVM extender unit to that device. This possibility offers a separate switching of the USB 2.0 signal (see Chapter 5.10, Page 124 or Chapter 5.11.1, Page 128).



Switching of USB 2.0 signals uses Extended Switching functionality (see Chapter 6.3, Page 187).

When using parallel operation within the matrix, set the Release Time in the **Configuration > Switch** menu to 10 s or more (see Chapter 5.11.6, Page 145). Otherwise the connection of the USB 2.0 extender will not be established due to security and stability reasons.


6.8 Presets

Predefined macros to switch the matrix without loading a new configuration can be created and activated in this menu.

You have the following option to access the menu:



➔ Select **Control > Presets** in the task area.



Menu **Control – Presets**

To create a new switch macro proceed as follows:

1. Open a new switch macro by pressing on the **New** symbol in the right column of the working area.

You are asked if the existing connections should be taken over for the new switch macro.

2. Set the desired switching operations in the corresponding columns (**Full Access**, **Video Only** or **Private Mode**) by using a double click on the appropriate selection box or use the function for a disconnect (**Disconnect CPU**).

3. Save the created switch macro by clicking the **Save** symbol in the right column of the working area.
A save dialog will be opened.
4. Enter a name for the new switch macro and confirm by pressing the **Ok** button in the save dialog.
5. By clicking on a selected switch macro with the right mouse button, you can create a copy of the current switch macro when using the **Save as...** option.
6. Previously saved macros can be deleted by pressing the **Delete** symbol.

To load a predefined switching, proceed as follows:

1. Select the switch macro in the right column of the working area that has to be loaded.
2. Activate the selected switch macro by pressing the **Send** button on the bottom right of the working area.



A predefined switch macro can only be activated in online mode. When loading presets, only those switching operations that are compliant with the hardware and the configuration of the currently used matrix are taken into account.

6.9 Serial Interface



The Draco tera offers the option to switch via a serial interface (RS232).

Detailed information for the serial interface and the corresponding switching commands are available in form of an API (application programming interface) upon request.

6.10 Power On and Power Down Functions

6.10.1 Restart

You have the following options to perform a restart:



OSD

1. Select **Configuration > Restart Matrix** or **Restart IO Board** in the main menu to restart either the matrix or the I/O boards.
2. Confirm the selection with **Okay** button.

The matrix and the I/O boards will be restarted with the current settings.

Java Tool

- ➔ Select **Matrix > Restart Matrix** in the menu bar.

The matrix will be restarted with the current settings.



The boot process of the matrix might take longer, if there is no physical network connection available.

6.10.2 Factory Reset

You have the following option to perform a reset of the system:



If you perform a (factory) reset, all current settings and all configurations stored in the matrix will be lost. This also applies to the network parameters (reset to DHCP) and the admin password.



If a firmware update has been installed since the delivery, the matrix will be set to the state defined there.

OSD

1. Select **Configuration > Factory Reset** in the main menu.
2. Confirm the selection with the **Okay** button.

The matrix will be reset to factory settings.

6.10.3 Power Down

You have the following option to perform a shut down of the system or single components:



OSD

In order to shut down the system, proceed as follows:

1. Select **Configuration > Shut down Matrix** in the main menu.
2. Confirm the selection with the **Okay** button.

The matrix will be shut down.

In order to shut down an I/O board, proceed as follows:

1. Select **Configuration > Shut Down IO Board** in the main menu.
2. Confirm the selection with the **Okay** button.

The I/O board will be shut down.

6.11 Summary of Keyboard Commands

In the following you find a summary of keyboard commands that can activate extender and matrix functions after executing the 'Hot Key'.

Extender

Keyboard Command	Description
<'Hot Key'>, <a>	Download of DDC information for the monitor connected to the CON Unit into the CPU Unit
<'Hot Key'>, <k>, <1>, <Enter>	Switch to the KVM connection 1 (only with HDMI CON Units with available connection for a local source)
<'Hot Key'>, <k>, <2>, <Enter>	Switch to the KVM connection 2 (only with HDMI CON Units with available connection for a local source and a redundant interconnection)
<'Hot Key'>, <l>, <Enter>	Switch to local source (computer, CPU) (only with HDMI CON Units with available connection for a local source)
<'Hot Key'>, <h>, <w>, <Enter>	USB-HID Ghosting: Write device descriptions of the input devices connected to the CON Unit into the CPU Unit. Activate the emulation in the CPU Unit.
<'Hot Key'>, <h>, <e>, <Enter>	Activate the emulation of already stored device descriptions in the CPU Unit
<'Hot Key'>, <h>, <d>, <Enter>	Deactivate the emulation of active device descriptions in the CPU Unit. The input devices connected to the CON Unit will be passed transparently to the source (computer, CPU).
<'Hot Key'>, <h>, <r>, <Enter>	Deactivate the emulation of active device descriptions in the CPU Unit. Delete the descriptions out of the CPU Unit. The input devices connected to the CON Unit will be passed transparently to the source (computer, CPU).
<'Hot Key'>, <d>, <1>, <Enter>	Switch to video channel 1 of the Dual-Head CPU Unit (482 series only)
<'Hot Key'>, <d>, <2>, <Enter>	Switch to video channel 2 of the Dual-Head CPU Unit (482 series only)

Matrix

Keyboard Command	Description
<'Hot Key'>, <0>	Open OSD
<'Hot Key'>, <m>, <0>	Open OSD of the master matrix in a cascaded environment
<'Hot Key'>, <s>, <0>	Open OSD of the sub matrix in a cascaded environment
<'Hot Key'>, <Enter>	Set a KVM connection (keyboard, mouse and video) to the selected source (computer, CPU)
<'Hot Key'>, <Space>	Set a video only connection to the selected source (computer, CPU)
<'Hot Key'>, <Left Shift> + <Enter>	Set a Private Mode connection to the selected source (computer, CPU)
<'Hot Key'>, <Backspace>	Close the current connection of the own console
<'Hot Key'>, <p>	Switch back to the previous connected source (computer, CPU) with a KVM connection
<'Hot Key'>, <1> ... <16>, <Enter> (<Space> or <Left Shift> + <Enter>)	Switch to a source (computer, CPU) stored in the Favorite List with a KVM connection (video only or Private-Mode connection)
<'Hot Key'>, <F1> ... <F16>	Execute a predefined macro
<'Hot Key'>, <c>, <new 'Hot Key'-Code>, <Enter>	Change the 'Hot Key' according to the predefined 'Hot Key' table
<'Hot Key'>, <c>, <0>, <new 'Hot Key' key>, <Enter>	Define freely selectable 'Hot Key'
<'Hot Key'>, <f>, <new 'Hot Key'-Code>, <Enter>	Change the 'Hot Key' for direct OSD access according to the predefined 'Hot Key' table
<'Hot Key'>, <f>, <0>, <new 'Hot Key' key>, <Enter>	Define freely selectable 'Hot Key' for direct OSD access
<'Hot Key'>, <Num 0>	Switch the USB-HID signal to the user's display (CON Unit with keyboard and mouse)
<'Hot Key'>, <Num 1>	Switching of the USB-HID signals to display #1
<'Hot Key'>, <Num 2>	Switching of the USB-HID signals to display #2

Keyboard Command	Description
<'Hot Key'>, <Num 3>	Switching of the USB-HID signals to display #3
<'Hot Key'>, <Num 4>	Switching of the USB-HID signals to display #4

7 Specifications

7.1 Interfaces

7.1.1 RJ45 (Network)

The communication of the Cat X devices requires a 1000BASE-T connection.

The cabling has to be done according to EIA/TIA-568-B (1000BASE-T) with RJ45 connectors at both ends. All four wire pairs are used in both directions. The cabling is suitable for a full duplex operation. For the cable connection to a source (computer, CPU), a crossed network cable (cross cable) has to be used.

7.1.2 RJ45 (Serial)

Communication takes place with a transmission speed of 115.2 KBaud, regardless of the file format. The transmission takes place with eight data bits and a stop bit, but without a parity bit. Limited hardware handshake (DSR) is possible.

7.1.3 RJ45 (Interconnect)

Communication between Cat X devices requires a 1000BASE-T connection.

Connector wiring must comply with EIA/TIA-568-B (1000BASE-T), with RJ45 connectors at both ends. All four cable wire pairs are used.

7.2 Interconnect Cable

7.2.1 Cat X



A point-to-point connection is required. Operation with several patch fields is possible. Routing over an active network component, such as an Ethernet Hub, Router or Matrix, is not allowed.

➔ Avoid routing Cat X cables along power cables.



To maintain regulatory EMC compliance, correctly installed shielded Cat X cable must be used throughout the interconnection link.



To maintain regulatory EMC compliance, all Cat X cables need to carry ferrites on both cable ends close to the device.

Type of Interconnect Cable

The Draco tera requires interconnect cabling specified for Gigabit Ethernet (1000BASE-T). The use of solid-core (AWG24), shielded, Cat 5e (or better) is recommended.

Cat X Solid-Core Cable AWG24	S/UTP (Cat 5e) cable according to EIA/TIA-568-B. Four pairs of wires AWG24. Connection according to EIA/TIA-568-B (1000BASE-T).
Cat X Patch Cable AWG26/8	S/UTP (Cat 5e) cable according to EIA/TIA-568-B. Four pairs of wires AWG26/8. Connection according to EIA/TIA-568-B (1000BASE-T).




The use of flexible cables (patch cables) type AWG26/8 is possible, however the maximum possible extension distance is halved.

Maximum Acceptable Cable Length


Cat X Installation Cable AWG24	140 m (400 ft)
Cat X Patch Cable AWG26/8	70 m (200 ft)

7.3 Connector Pinouts

RJ45 (Serial)


Picture	Pin	Signal	Pin	Signal
	1	DCD	5	RxD
	2	DSR	6	TxD
	3	RTS	7	CTS
	4	GND	8	DTR

RJ45

Picture	Pin	Signal	Pin	Signal
	1	D1+	5	n.c
	2	D1-	6	D2-
	3	D2+	7	n.c
	4	n.c	8	n.c

7.3.1 I/O Port Cat X

RJ45

Picture	Pin	Signal	Pin	Signal
	1	D1+	5	D3-
	2	D1-	6	D2-
	3	D2+	7	D4+
	4	D3+	8	D4-

7.4 Power Supply

Maximum Current / Voltage

Draco tera 8C, 8F, 8U	0,7 A, 100-240 Vac, 50/60 Hz
Draco tera 48C, 48F, 32C, 32F, 16C, 16F	1.4 A, 100-240 Vac, 50/60 Hz
Draco tera 80C, 80F, 48C32F, 48C32U, 64C, 64F, 48C16F	2.3 A, 100-240 Vac, 50/60 Hz

Power Requirement

Draco tera 80C / 80F	max. 125 W
Draco tera 48C32F	max. 125 W
Draco tera 48C32U	max. 125 W
Draco tera 64C / 64F	max. 105 W
Draco tera 48C16F	max. 105 W
Draco tera 48C / 48F	max. 90 W
Draco tera 32C / 32F	max. 65 W
Draco tera 16C / 16F	max. 40 W
Draco tera 8C / 8F	max. 13 W

7.5 Environmental Conditions

Operating Temperature	41 to 113°F (5 to 45°C)
Storage Temperature	-13 to 140°F (-25 to 60°C)
Relative Humidity	Max. 80% non-condensing

Noise Emission

Sound Pressure Level (SPL)	64/80-port chassis: max. 52 dBA per fan
	16/32/48-port chassis: max. 42 dBA per fan

Heat Dissipation

Thermal output	Corresponds to power consumption in Watt (W)
-----------------------	--

7.6 Size

Draco tera 80C / 80F

Matrix	443 x 435 x 90 mm (17.4" x 17.1" x 3.5")
Shipping Box	602 x 526 x 200 mm (23.7" x 20.7" x 7.9")

Draco tera 48C32F

Matrix	443 x 435 x 90 mm (17.4" x 17.1" x 3.5")
Shipping Box	602 x 526 x 200 mm (23.7" x 20.7" x 7.9")

Draco tera 48C32U

Matrix	443 x 435 x 90 mm (17.4" x 17.1" x 3.5")
Shipping Box	602 x 526 x 200 mm (23.7" x 20.7" x 7.9")

Draco tera 64C / 64F

Matrix	443 x 435 x 90 mm (17.4" x 17.1" x 3.5")
Shipping Box	602 x 526 x 200 mm (23.7" x 20.7" x 7.9")

Draco tera 48C16F

Matrix	443 x 435 x 90 mm (17.4" x 17.1" x 3.5")
Shipping Box	602 x 526 x 200 mm (23.7" x 20.7" x 7.9")

Draco tera 48C / 48F

Matrix	443 x 435 x 45 mm (17.4" x 17.1" x 1.8")
Shipping Box	602 x 526 x 154 mm (23.7" x 20.7" x 6.1")

Draco tera 32C / 32F

Matrix	443 x 435 x 45 mm (17.4" x 17.1" x 1.8")
Shipping Box	602 x 526 x 154 mm (23.7" x 20.7" x 6.1")

Draco tera 16C / 16F

Matrix	443 x 435 x 45 mm (17.4" x 17.1" x 1.8")
Shipping Box	602 x 526 x 154 mm (23.7" x 20.7" x 6.1")

Draco tera 8C / 8F / 8U

Matrix	220 x 146 x 45 mm (8.7" x 5.7" x 1.8")
Shipping Box	550 x 365 x 115 mm (21.7" x 14.4" x 4.5")

7.7 Shipping Weight

Draco tera 80C / 80F

Matrix	7.2 kg (15.9 lb)
Shipping Box	9.6 kg (21.1 lb)

Draco tera 48C32F

Matrix	7.2 kg (15.9 lb)
Shipping Box	9.6 kg (21.1 lb)

Draco tera 48C32U

Matrix	7.2 kg (15.9 lb)
Shipping Box	9.6 kg (21.1 lb)

Draco tera 64C / 64F

Matrix	7.0 kg (15.4 lb)
Shipping Box	9.4 kg (20.7 lb)

Draco tera 48C16F

Matrix	7.0 kg (15.4 lb)
Shipping Box	9.4 kg (20.7 lb)

Draco tera 48C / 48F

Matrix	4.1 kg (9.0 lb)
Shipping Box	6.0 kg (13.2 lb)

Draco tera 32C / 32F

Matrix	4.0 kg (8.8 lb)
Shipping Box	5.9 kg (13.0 lb)

Draco tera 16C / 16F

Matrix	3.9 kg (8.6 lb)
Shipping Box	5.8 kg (12.8 lb)

Draco tera 8C / 8F / 8U

Matrix	0.9 kg (1.9 lb)
Shipping Box	3.4 kg (7.5 lb)

7.8 MTBF

The following table contains the mean time between failure (MTBF) in power-on hours (POH). The estimate is based on the FIT rates of the parts included. FIT rates are based on normalized environmental conditions of $T = 60^{\circ}\text{C}$ and activation energy (E_a) of 0.7 eV. Calculations are based on 90% confidence limit.

We estimate that inside the housing, temperature will be 15°C higher than the ambient temperature. Therefore, the MTBF calculation refers to an ambient temperature of 45°C . The humidity is limited to 60%.

Matrix	Chassis	Per Fan	Per PSU
Draco tera 80C	90,690	280,000	238,800
Draco tera 80F	83,350	280,000	238,800
Draco tera 48C32F	87,250	280,000	238,800
Draco tera 48C32U	87,250	280,000	238,800
Draco tera 64C	97,300	280,000	238,800
Draco tera 64F	92,900	280,000	238,800
Draco tera 48C16F	95,600	280,000	238,800
Draco tera 48C	140,000	280,000	295,700
Draco tera 48F	133,400	280,000	295,700
Draco tera 32C	165,300	280,000	295,700
Draco tera 32F	161,200	280,000	295,700
Draco tera 16C	208,322	280,000	295,700
Draco tera 16F	206,100	280,000	295,700
Draco tera 8C / 8F / 8U	684,700	280,000	309,700

8 Maintenance

The Draco tera contains no user serviceable parts inside. Please contact your dialer or manufacturer, if there is a fault or a problem (see Chapter 10, Page 217).



For the use in a 24/7 operation it is recommended to keep a hot spare matrix available.

9 Troubleshooting

In the following chapters, support for problems with the Draco tera matrix is provided. It is assumed that fully operational CPU and CON Devices are available, which can be tested over a peer-to-peer connection using Cat X or fibre cables. Please refer to the relevant manuals for assistance with this if necessary.

9.1 External Failure

Diagnosis	Possible Reason	Measure
Matrix cannot be started anymore.	Fuse at the standard appliance outlet.	➔ Check fuse.

9.2 Video Interference

Diagnosis	Possible Reason	Measure
Opening the OSD not possible	No OSD jumper set	➔ Set jumper 11 on the CON unit.
Incorrect video display	Cable connection disturbed	➔ Check the connection, length and quality of the interconnect cable to the units.

9.3 Malfunction of Fans

Diagnosis	Possible Reason	Measure
Fans do not run, LED OK on	Fans defective	➔ Contact your dealer.
Fans do not run, LED OK off	Power supply	➔ Check power supply and power connection.

9.4 Malfunction of Power Supply Units

Diagnosis	Possible Reason	Measure
Matrix cannot be started	No power supply available	➔ Check if power supply cables are connected correctly.
	Power supply units are not switched on	➔ Check switch on the power supply units.


9.5 Network Error

Diagnosis	Possible Reason	Measure
Network settings are not assumed after editing.	Restart of the matrix not yet completed.	➔ Restart the matrix.

9.6 Failure at the Matrix

Diagnosis	Possible Reason	Measure
Serial control impossible or only restrictedly possible.	CPU and matrix operating at different Baud rates.	➔ Change Baud rate in the matrix and CPU (see Chapter 5.3.2, Page 76).
Serial control via RJ45 port not possible.	Wrong network cable.	➔ Use a crossed network cable.
Port definitions as USB 2.0 invalid.	Restart of the matrix not yet completed.	➔ Restart the matrix.

9.7 Blank Screen



Rear View



Front View

Diagnosis	Possible Reason	Measure
Monitors remains dark after switching operation	Switching to a CPU Port without active Source (computer, CPU).	➔ Switching to a CPU Port with an active source (computer, CPU).
LED 1 on or LED 2 off	Connections CON Unit, matrix and CPU Unit.	➔ Check connecting cables and connectors. (No cable, cable break, CPU/CON Unit offline, CPU/CON Unit connected to the wrong port).
LED 3 off	Power supply	➔ Check power supply units and the connection to the power network.

10 Technical Support

Prior to contacting support please ensure you have read this manual, and then installed and set-up your Draco tera as recommended.

10.1 Support Checklist

To efficiently handle your request it is necessary that you complete a support request checklist ([Download](#)). Please ensure that you have the following information available before you call:

- Company, name, phone number and email
- Type and serial number of the device (see bottom of device)
- Date and number of sales receipt, name of dealer if necessary
- Issue date of the existing manual
- Nature, circumstances and duration of the problem
- Components included in the system (such as graphic source/CPU, OS, graphic card, monitor, USB-HID/USB 2.0 devices, interconnect cable) including manufacturer and model number
- Results from any testing you have done

10.2 Shipping Checklist

1. To return your device, contact your dealer to obtain a RMA number (Return-Material-Authorization).
2. Package your devices carefully, preferably using the original box. Add all pieces which you received originally.
3. Note your RMA number visibly on your shipment.



Devices that are sent in without a RMA number cannot be accepted. The shipment will be sent back without being opened, postage unpaid.

11 Certificates

11.1 CE Declaration Of Conformity

The products listed below in the form as delivered comply with the provisions of the following European Directives:

2014/30/EU	Council Directive on the approximation of the laws of the Member States relating to electromagnetic compatibility
2014/35/EU	Council Directive on the harmonization of the laws of the Member States relating to the making available on the market of electrical equipment designed for use within certain voltage limits.



CE Marking

Product list:

Series 480

The products comply with the following harmonized standards for Information Technology Equipment:

- EN 55022: 2010/AC:2011 (Class A)
- EN 55024:2010 + A1:2015
- EN 61000-3-2:2014
- EN 61000-3-3:2013
- EN 61000-6-2:2005
- EN 60950-1:2006/A2:2013

Manufacturer:

IHSE GmbH

Maybachstrasse 11

88094 Oberteuringen

Deutschland

Oberteuringen, October 1st, 2016

The Management

A handwritten signature in blue ink, appearing to read 'Emo L. Hauer', is written over the printed name 'The Management'.

**Use in a Domestic Environment**

This is a Class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures.

This declaration certifies the conformity to the specified directives but contains no assurance of properties. The safety instructions and installation guidelines noted in this manual shall be considered in detail. Compliance with the specifications for cable lengths and types is mandatory.

11.2 North American Regulatory Compliance

This equipment has been found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Shielded cables must be used with this equipment to maintain compliance with radio frequency energy emission regulations and ensure a suitably high level of immunity to electromagnetic disturbances.

All power supplies are certified to the relevant major international safety standards.

11.3 Product Safety

The product safety of the devices is proven by the compliance to the following standards:

- IEC 60950-1A1:2010
- EN 60950-1/A12:2011/A1:2010/A11:2009
- UL 60950-1-2007
- CAN/CSA-C22.2 60950-1-07

The compliance is verified and confirmed by TÜV Süd, Germany.



11.4 WEEE

The manufacturer complies with the EU Directive 2012/19/EU on the prevention of waste electrical and electronic equipment (WEEE).

The device labels carry a respective marking.

11.5 RoHS/RoHS 2

This device complies with the Directive 2011/65/EU of the European Parliament and of the council of 8 June 2011 on the restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS 2, RoHS II).

The device labels carry a respective marking.

12 Glossary

The following terms are commonly used in this guide or in video and KVM technology:

Term	Explanation
AES/EBU	Digital audio standard that is officially known as AES3 and that is used for carrying digital audio signals between devices.
Cat X	Any Cat 5e (Cat 6, Cat 7) cable
CGA	Color Graphics Adapter (CGA) is an old analog graphic standard with up to 16 displayable colors and a maximum resolution of 640x400 pixels.
Component Video	Component Video (YPbPr) is a high-quality video standard that consists of three independently and separately transmittable video signals, the luminance signal and two color difference signals.
Composite Video	Composite Video is also called CVBS and it is part of the PAL TV standard.
CON Unit	Component of a KVM Extender or Media Extender to connect to the console (monitor(s), keyboard and mouse; optionally also with USB 2.0 devices)
Console	Keyboard, mouse and monitor
CPU Unit	Component of a KVM Extender or Media Extender to connect to a source (computer, CPU)
CVBS	The analog color video baseband signal (CVBS) is also called Composite Video and it is part of the PAL TV standard.
DDC	Display Data Channel (DDC) is a serial communication interface between monitor and source (computer, CPU). It allows a data exchange via monitor cable and an automatic installation and configuration of a monitor driver by the operating system.
DisplayPort	A VESA standardised interface for an all-digital transmission of audio and video data. It is differentiated between the DisplayPort standards 1.1 and 1.2. The signals have LVDS level.
Dual Access	A system to operate a source (computer, CPU) from two consoles

Term	Explanation
Dual Link	A DVI-D interface for resolutions up to 2560x2048 by signal transmission of up to 330 MPixel/s (24-bit)
Dual-Head	A system with two video connections
DVI	Digital video standard, introduced by the Digital Display Working Group (http://www.ddwg.org). Single Link and Dual Link standard are distinguished. The signals have TMDS level.
DVI-I	A combined signal (digital and analog) that allows running a VGA monitor at a DVI-I port – in contrast to DVI-D (see DVI).
EGA	The Enhanced Graphics Adapter (EGA) is an old analog graphic standard, introduced by IBM in 1984. A D-Sub 9 connector is used for connection.
Fiber	Single-mode or multi-mode fiber cables
HDMI	An interface for an all-digital transmission of audio and video data. It is differentiated between the HDMI standards 1.0 to 1.4a. The signals have TMDS level.
KVM	Keyboard, video and mouse
Mini-XLR	Industrial standard for electrical plug connections (3 pole) for the transmission of digital audio and control signals
Multi-mode	62.5µ multi-mode fiber cable or 50µ multi-mode fiber cable
OSD	The On-Screen-Display is used to display information or to operate a device.
Quad-Head	A system with four video connections
RCA (Cinch)	A non-standard plug connection for transmission of electrical audio and video signals, especially with coaxial cables
S/PDIF	A digital audio interconnect that is used in consumer audio equipment over relatively short distances.
SFP	SFPs (Small Form Factor Pluggable) are pluggable interface modules for Gigabit connections. SFP modules are available for Cat X and fiber interconnect cables.

Term	Explanation
Single Link	A DVI-D interface for resolutions up to 1920x1200 by signal transmission of up to 165 MPixel/s (24-bit). Alternative frequencies are Full HD (1080p), 2K HD (2048x1080) and 2048x1152.
Single-Head	A system with one video connection
Single-mode	9μ single-mode fiber cable
S-Video (Y/C)	S-Video (Y/C) is a video format transmitting luminance and chrominance signals separately. Thereby it has a higher quality standard than CVBS.
TOSLINK	Standardized fiber connection system for digital transmission of audio signals (F05 plug connection)
Triple-Head	A system with three video connections
USB-HID	USB-HID devices (Human Interface Device) allow for data input. There is no need for a special driver during installation; "New USB-HID device found" is reported. Typical HID devices include keyboards, mice, graphics tablets and touch screens. Storage, video and audio devices are not HID.
VGA	Video Graphics Array (VGA) is a computer graphics standard with a typical resolution of 640x480 pixels and up to 262,144 colors. It can be seen as a follower of the graphics standards MDA, CGA and EGA.

12.1 Matrix specific Glossary

Term	Explanation
Auto Disconnect	Matrix function that allows an automatic disconnect between a console and a CPU, if OSD is opened via this console.
Auto Logout	Matrix function that describes the duration of inactivity after the user has been logged out from the OSD at this console.
CON Device	Logical term that summarizes several physical extenders to switch more complex console systems via matrix.
CON Timeout	Matrix function that allows an automatic disconnect of the own console from the connected CPU after a predefined time.
Console ACL	Console Access Control List is a list that shows the respective switching rights for the various consoles.
CPU Auto Connect	Matrix function that allows an automatic connection establishment between the own console and a random CPU that is available.
CPU Device	Logical term that summarizes several physical extenders to switch more complex CPU systems via matrix.
CPU Timeout	Matrix function that allows the user to disconnect after a predefined period of time of inactivity from the respective CPU.
EXT Unit	Part or extender board of a CON or CPU unit with a connection to the matrix. A CON or CPU unit can consist of several EXT devices.
Force Connect	Matrix function that allows to switch with the own console to a CPU that is already used and in doing so to take keyboard and mouse control. The connected console so far loses K/M control, but keeps video.
Force Disconnect	Matrix function that allows to switch with the own console to a CPU that is already used and in doing so to take KVM control. The connected console so far loses complete KVM control.
Java Tool	Java based control and configuration tool for the Draco tera matrix.

Term	Explanation
Keyboard Connect	Matrix function that allows taking over the keyboard control of an inactive console.
Macro Keys	Programmable keys that can execute a stringing together of commands to the matrix.
Mouse Connect	Matrix function that allows taking the mouse control of an inactive console.
Non-Blocking-Access	Matrix configuration where no user can be disturbed by an activity of another user.
OSD Timeout	Matrix function that closes the OSD automatically after a predefined period of time of inactivity.
Release Time	Matrix function that allows a console that is connected with the same CPU to release the K/M control after a predefined time.
Service Mode	Defined maintenance condition that allows updating of extenders that are connected to the matrix.
Tie Line	Communication connection to and between extension modules in a network environment.
User ACL	User Access Control List is a list that shows the respective switching rights for the various users.
Video Sharing	Matrix function that allows switching from the user's console to any CPU with video.