WIN3300/3500 Interface to Cougar Matrix

DB-9 Female to:

Cougar Internal CPU
Serial 1 (J13) port
Serial 2 (J14) port

DB-9 Female to:

Personal Computer
(Com port)

Cougar Internal CPU	Pin		Pin	Personal Computer
CD (Carrier Detect)	1		1	CD (Carrier Detect)
RX (Receive Data)	2		3	TX (Transmit Data)
TX (Transmit Data)	3		2	RX (Receive Data)
DTR (Data Terminal Ready)	4		6	DSR (Data Set Ready)
SG (Signal Ground)	5		5	SG (Signal Ground)
DSR (Data Set Ready)	6		4	DTR (Data Terminal Ready)
RTS (Ready To Send)	7		8	CTS (Clear To Send)
CTS (Clear To Send)	8		7	RTS (Ready To Send)
RI (Ring Indicator)	9		9	RI (Ring Indicator)