Lawo AG Am Oberwald 8 D-76437 Rastatt Telefon+49 (0) 7222 1002-0Telefax+49 (0) 7222 1002-7101Internetwww.lawo.com



Technical Documentation

Exchange of OLED /

Fader Panel 962/21

Product series: mc² 66 MKII

Version: 1.2

Revision: 16.05.2017

Copyright

All rights reserved. Permission to reprint or electronically reproduce any document or graphic in whole or in part for any reason is expressly prohibited, unless prior written consent is obtained from the Lawo AG.

All trademarks and registered trademarks belong to their respective owners. It cannot be guaranteed that all product names, products, trademarks, requisitions, regulations, guidelines, specifications and norms are free from trade mark rights of third parties.

All entries in this document have been thoroughly checked, however no guarantee for correctness can be given. Lawo AG cannot be held responsible for any misleading or incorrect information provided throughout this manual.

Lawo AG reserves the right to change specifications at any time without notice

© Lawo AG, May 2017



1.	Introduction	3
	1.1. What to to?	3
	1.2. What do you need?	4
	How to disassemble the panel:	
	How to remove the OLED bar:	
	How to mount the new OLED Bar:	
	Assembling the panel:	



1. Introduction:

1.1. What to to?

- Exchange of OLEDs into new ones







1.2. What do you need?


- Loctite
- Screw-wrench 5,5 (3mm)
- Phillips screw-driver
- Torx T10
- Knife blade
- Tweezes
- Screwdrivers for round nuts i.e Lawo No:434-9000-000
- Standard screwdriver



- OLED-Set 296-2219-000 contains









- Remove the fader caps and the caps of the rotarys knobs



- Open screws of the rotary knobs and remove them:





- Open the screws for the back plate
- Remove the plate







- Remove the powercable
- Unplug all fader cables






- Disconnect the USB-controller flatfoil
- Open the screws for USB-Controller and fader control board
- Remove the boards








- Remove the PCB from the front plate
- Open the TX10 screws of all fader at the front and remove the faders






3. How to remove the OLED bar:

- Open the 6 screws of the 2 OLED bars




- open the flatfoil locks and remove the OLED bars:





3. How to remove the OLED bar:

- do the same on the second PCB and remove the OLED bars



- open the flatfoil locks and remove the OLED bars:






4. How to mount the new OLED Bar:

- Hold the bar in upright position and insert the flat foils into their sockets and close the locks carefully:




- Lay down the bar to its final position, while the flat foils were bent very slowly.





- Fix the bar with its screws.
- Remove the security plastic film from every single OLED
- The windows on of the front plate have to be clean and free of dust before assembling the front plate.





5. Assembling the panel:

- For assembling please refer to page 6 13 in reversed order.
- Please do not forget to save all PCB screws with Loctite.

