

<b>&lt;Hot Key&gt;, &lt;o&gt; or &lt;OSD Fast Key&gt;</b>	Open OSD.
<b>(CPU selection), &lt;Enter&gt;</b>	Set a KVM connection (keyboard, mouse and video) to the selected source (computer, CPU).
<b>(CPU selection), &lt;Space&gt;</b>	Set a Video Only connection to the selected source (computer, CPU).
<b>(CPU selection), &lt;Left Shift&gt; + &lt;Enter&gt;</b>	Set a Private Access connection to the selected source (computer, CPU).
<b>&lt;Hot Key&gt;, &lt;Backspace&gt;</b>	Close the current connection of the own console.
<b>&lt;Hot Key&gt;, &lt;p&gt;</b>	Switch back to the previous connected source (computer, CPU) with Full Access.

<Hot Key>, <1> ... <16>, <Enter> (<Space> or <Left Shift> + <Enter>)	Switch to a source (computer, CPU) stored in the favorite list with a KVM connection (Video Only or Private Access connection).	Multi-Screen Control
<Hot Key>, <F1> ... <F16>	Execute a predefined macro.	
<Hot Key>, <Num 0>	Switch USB-HID signal to own screen (CON Unit with keyboard and mouse).	
<Hot Key>, <Num 1> ... <Num 4>	Switch USB-HID signal to screen #1 ... #4.	