


# DIGICART/E GPI/O DB-25 PINOUT



\* IF USING THE SUPPLIED VOLTAGE FROM THE DIGICART  
YOU MUST LOOP PIN #4 TO PIN #8 OR 9.

\*USE A MALE DB-25 WHILE CONNECTING THE DIGICART