

ATTN: Jeff Joslin - NEP
FROM: Rich. Canon USA

on Type 6II
sw2 - Sony
off thumb
cap Sony

XJ86x LDK ⇒ BVP

1. Change Rotary Switch Position

SW11; #7 (for LDK) ⇒ #0 (for Sony)

2. Disconnect Wire #22 on 36 pin Camera Connector on Lens Mount

Blue

