

Hi George,

As discussed here is the procedure to re-set lens:

1. Make sure camera power is off
2. Set Iris in Auto Position
3. Switch zoom operation to Servo
4. Press and hold "MEMO" switch on drive unit, while powering up the camera
5. Release "MEMO" switch
6. Press "IRIS" memory switch
7. Press "AUX2" switch
8. Press "RET" switch
9. Press "VTR" switch
10. Press "AUX1" switch

The sequence 1-10 has to be followed exactly as mentioned above.

The lens will start it's automatic re-set cycle.

Don't touch anything, wait until lens finishes the re-set cycle (iris and zoom will stop moving by itself)

If you have any further questions please feel free to contact us.

ALPINE OPTICS, INC.

Horst Stahl

T (828) 884-5822