

FUJINON

TV LENS ACCESSORY

PARTS LIST

OPTICAL STABILIZER CONTROL UNIT

EA-12A-05BA

FUJIFILM Group

FUJINON Corporation

1.

General Assembly
EA-12A-05BA (Fig. 1)

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Q'ty</u>	<u>Remarks</u>
A 1	110A10116200	P.C. board assembly	1	
A 2	111A10955970	Cable assembly	1	
B 1	11B9622660	Cover	2	
B 2	12B10054910	Case	1	
B 3	16B8450110	Knob	1	
B 4	16B10054930	Knob	1	
B 5	41B4133060	Retaining plate	1	
B 6	41B10116180	Mounting frame	1	
B 7	46B10068710	Mounting frame	1	
B 8	46B10126140	Retaining plate	1	
B 9	46B10966380	Mounting plate	1	
B 10	51B7693490	Rubber sheet	1	
B 11	51B10054940	Rubber sheet	1	
B 12	53B10126150	Screw	1	
B 13	57B3965300	Rubber cap	1	
B 14	58B7687740	Number label	1	
B 15	58B9622730	Label (V+H)	1	
B 16	58B10462210	Label (HIGH)	1	
B 17	58B10462220	Label (STD.)	1	
B 18	58B10930300	Label (V)	1	
B 19	58B10966390	Nameplate	1	
B 20	60B10930280	Packing	1	
B 21	60B10930290	Packing	1	
B 22	81B3965290	Cable holder	1	
B 23	109B10075050	Conductive piece	1	
B 24	111B10093800	Cable holder	1	
K 1	53K443490	Tapping screw	2	Nitto Seiko BTP2.0
K 2	106K1042020	LED	1	Stanley EMPG3378S
K 3	112K1150710	Jack	1	Marushin No.MJ-075; see P.C.I. No. 1
K 4	113K310830	Connector	1	Tajimi R01-01P9-8M
K 5	113K1150720	Plug	1	Marushin No.MP-013MS; see P.C.I. No. 1
M 1	110M200303Z	Screw	3	
M 2	110M200403Z	Screw	4	
M 3	110M261203G	Screw	4	
M 4	120M260401Z	Setscrew	2	

2.

P.C. Board Assembly
110A10116200 (Fig. 3a, b)

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Q'ty</u>	<u>Remarks</u>
A 1	110B10072350		1	
Q 1	106K792580	Transistor	1	NEC FA1L4M-A
R 1	117R7590750	Resistor 0.1W 1.2k Ω D	1	
S 1	121K1145660	Tact switch	1	Alps SKHHPJA010
S 2	121K1145680	Toggle switch	1	Nikkai B-12JB
S 3	121K1152020	Toggle switch	1	Omron A9T11-0014; see P.C.I. No. 3

