

3922 496 30931 Service Manual HD WIRELESS

I - LDK 4470 / x1 - HD WIRELESS CONTROL UNIT

Tab	Part number	Drawing number	Description
1	8926 447 01001	-	HD WIRELESS CONTR.UNIT FISHER
	8926 447 02001	-	HD WIRELESS CONTR.UNIT TRI-LOCK
	8926 447 03001	-	HD WIRELESS CONTR.UNIT ARD
	8926 447 04001	-	HD WIRELESS CONTR.UNIT LEMO 4
	8926 447 05001	-	HD WIRELESS CONTR.UNIT LEMO-BBC
	8926 447 06001	-	HD WIRELESS CONTR.UNIT LEMO 3
	3922 407 30531	3922 407 30530	TRIAx CONN. ASSY FISCHER
	3922 407 30551	3922 407 30550	TRIAx CONN. ASSY TRILOCK
	3922 407 30571	3922 407 30570	TRIAx CONN. ASSY ARD
	3922 407 30591	3922 407 30590	TRIAx CONN. ASSY LEMO 4
	3922 407 30611	3922 407 30610	TRIAx CONN. ASSY LEMO
	3922 407 30631	3922 407 30630	TRIAx CONN. ASSY LEMO 3
	46153241AA	46153241AA	KIT. CCU DITAX 220V
	46153242AA	46153242AA	KIT. CCU DITAX 110V
2	3922 407 48001	3922 407 48001	HD WCU BASIC
	3922 407 48011	3922 407 48011	3U SUBRACK WCU HD
3	3922 406 52151	3922 406 52151	WIRELESS DIGITAL TRIAX UNIT HD
	3922 406 52171	3922 406 52171	WIRELESS DIGITAL TRIAX BOARD
4	3922 406 52111	3922 406 52111	GENLOCK-VIDEO WIRELESS HD
5	3922 406 52161	3922 406 52161	WCU AUDIO INTERCOM HD
	16832184AB	16832184AB	WCU AUDIO INTERCOM
6	3922 406 51661	3922 406 51661	ETHERNET DATA BOARD WIRELESS
	3922 406 50011	3922 406 50011	ETHERNET DATA BOARD BS
	3922 406 87841	3922 406 87841	DISPLAY DATABOARD
7	46152735AE	46152735AE	POWER SUPPLY UNIT