

3922 496 30931 Service Manual WIRELESS HD

II - LDK 4460 / 0X001 - HD ANTENNA MANAGEMENT UNIT

Tab	Part number	Drawing number	Description
1	8926 446 01001	47268620AA	HD AMU FISHER
	8926 446 02001	47268620AA	HD AMU TRILOCK
	8926 446 03001	47268620AA	HD AMU ARD
	8926 446 04001	47268620AA	HD AMU LEMO 4
	8926 446 05001	47268620AA	HD AMU BBC LEMO
	8926 446 06001	47268620AA	HD AMU LEMO 3
	47233204CA	47233204CA	TRIAx ADAPTER FISHER MALE
	47233204DA	47233204DA	TRIAx ADAPTER TRILOCK MALE
	47233992AA	47233992AA	TRIAx ADAPTER ARD
	47233203HA	47233203HA	TRIAx ADAPTER LEMO 4E
	47233204BA	47233204BA	TRIAx ADAPTER BBC FEMALE
	47233203AA	47233203AA	TRIAx ADAPTER LEMO 3
2	3922 407 48021	3922 407 48021	HD AMU BASIC
	3922 407 48031	3923 407 48031	HD AMU BOX ASSY
3	3922 406 53361	3922 406 53361	ELEMENTARY CELL HD BOARD
	16831923AE	16831923AF	FRONT END BOARD
4	16831891AA	16831891AA	LED INDICATOR BOARD
	16832042AA	16832042AA	SUBD DAUGHTER BOARD
5	3922 406 52851	3922 406 52851	HD AMU POWER SUPPLY
6	46072187AB	46072187AB	AERIAL SUPPORT ASSEMBLY
	16832179AA	16832179AA	CABLE ASSY AMU AERIAL 3 COAX
	16832218AB	16832218AB	CABLE ASSY AMU AERIAL
	46072231AA	46072231AA	RF AMPLIFIER ASSY
	16832312AA	16832312AA	CABLE RF DATA EMITTER/BOOSTER
7	3922 496 31091	-	SURVEY OF SD/HD WIRELESS ANNTENNAS, BOOSTERS, RF RECEIVERS and DATA EMITTORS