





# Replacing the NV9000 Power Supply

Follow these steps to replace an NV9000 power supply.

- 1 Loosen the thumbscrew:



- 2 Slide the tab lock to the left:



- 3 Pull the power supply out of the frame:



- 4 Slide in a new power supply:



Push the power supply in until the connectors firmly lock in place.

- 5 Slide the tab (to the right) to engage the power supply:



- 6 Tighten the thumbscrew:



//