

Monitoring Style	Description from Tally Console	Tally	Note 1	Note 2
Source	Source <P1.Name>: shown in Style A with program or preset tally	Yes	Fixed source with tally	Depends on Source Definition > "Style A" column (see also right-click > Show / hide columns)
Source Long	Source <P1.Name>: long name shown with program or preset tally	Yes		Long name is from Source Definition > Long Name column
Source Short	Source <P1.Name>: short name shown with program or preset tally	Yes		Short name is from Source Definition > Long Name column
Destination	Dest <P1.Name>: Selected source shown in Style A with program or preset tally	Yes	Source traced via destination	Style "A"
Destination Long	Dest <P1.Name>: Selected source long name shown with program or preset tally	Yes		Long Name
Destination Short	Dest <P1.Name>: Selected source short name shown with program or preset tally	Yes		Short Name
Dest:Source	Dest <P1.Name>: Destination name and selected source in Style A with program or preset tally	Yes	Like Destination style but with destination label	Style "A"
Dest:Source Long	Dest <P1.Name>: Destination name and selected source long name with program or preset tally	Yes		Long Name
Dest:Source Short	Dest <P1.Name>: Destination name and selected source short name with program or preset tally	Yes		Short Name
Multiple Routed Inputs	Routed input <P1.Name>: Source selected by the destination feeding these inputs, shown in style A, with program or preset tally from this input	Yes	Not used	
Routed Input	Routed input <P1.Name>: Source selected by the destination feeding this input, shown in style A, with program or preset tally from this input	Yes	Used for routed switcher inputs where tally should follow selected switcher button not routed source	Style "A"
Routed Input Long	Routed input <P1.Name>: Long name of source selected by the destination feeding this input, with program or preset tally from this input	Yes		Long Name
Routed Input Short	Routed input <P1.Name>: Short name of source selected by the destination feeding this input, with program or preset tally from this input	Yes		Short Name
Dest:Routed Input	Routed input <P1.Name>: Destination name and source selected by the destination feeding this input, shown in style A, with program or preset tally from this input	Yes	Same as routed input but with destination label	Style "A"
Dest:Routed Input Long	Routed input <P1.Name>: Destination name and long name of source selected by the destination feeding this input, with program or preset tally from this input	Yes		Long Name
Dest:Routed Input Short	Routed input <P1.Name>: Destination name and short name of source selected by the destination feeding this input, with program or preset tally from this input	Yes		Short Name
Routed Multiviewer	Multiviewer destination <P1.Name>	Yes		
Show Name	Show name of UMD	No	Usually for test or UMD location	
Show ID	Show ID (usually serial number)	No	Usually for test or UMD location	
Show Text	Show text override - needed only if no other display style is chosen for a UMD. Other Monitoring styles inherently support text override.	No	UMD shows text from UMDs > Text Override column	