Switch on the system:

1. switch on all the DALLIS units connected to your system
2. switch on the HD Core
3. switch on the PSU of the desk

Switch off the system:

1. Press the three " shutdown" buttons at the Control Room Monitoring section
2. Wait until the system is shut down
3. Switch off the PSU of the desk
4. Switch off the HD Core and the DALLIS components.