

SECTION 7

Panasonic Broadcast Mechanical Parts List

Model No.: **AJ-HPX2700G/MC**

Note:


1. *Be sure to make your orders of replacement parts according to this list.
2. Unless otherwise specified, all resistors are in OHMS, K=1,000 OHMS, all capacitors are in MICROFARADS (μ F), P= μ F.
3. The P.C.Board unit marked with "■" shown below the main assembled parts.
4. The parts marked with Ⓔ on the exploded view show the electric parts.
4. IMPORTANT SAFETY NOTICE
Components identified with the mark $\triangle$ have the special characteristics for safety, When replacing any of these components, use only the sametype.
6. The marking (RTL) indicates the retention time is limited for this item.
After the discontinuation of this assembly in production, it will no longer be available.
6. "M" in Remark column indicates needed in the periodical maintenance.

CONTENTS

CASING & FRAME PARTS ASSEMBLY OVERALL SECTION (1).....	MPL-1
OVERALL SECTION (2)	MPL-3
CAMERA PARTS ASSEMBLY(1)	MPL-5
CAMERA PARTS ASSEMBLY(2)	MPL-7
CAMERA PARTS ASSEMBLY(3)	MPL-9
TOP CASE & HANDLE PARTS ASSEMBLY	MPL-11
SIDE CASE (R) PARTS ASSEMBLY	MPL-13
CARD GUIDE PARTS ASSEMBLY	MPL-15
REAR JACK PARTS ASSEMBLY	MPL-17
BACK CASE PARTS ASSEMBLY	MPL-19
LCD PARTS ASSEMBLY	MPL-21
PACKING PARTS ASSEMBLY	MPL-23

CASING & FRAME PARTS ASSEMBLY OVERALL SECTION (1)

Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.



NOTE:

This connector is the connector ASS'y.
Refer to CABLE PARTS ASSEMBLY with part number.

OVERALL SECTION (1)


Components identified with the mark have the special characteristics for safety. When replacing any of these components, use only the same type.

[illegible]

OVERALL SECTION (2)

Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.

* The part number of card holder is written in Electric Parts List of each P.C.Board.




OVERALL SECTION (2)

Components identified with the mark have the special characteristics for safety. When replacing any of these components, use only the same type.

[illegible][illegible]

CAMERA PARTS ASSEMBLY(1)

Components identified with the mark  have the special characteristics for safety.
When replacing any of these components, use only the same type.




CAMERA PARTS ASSEMBLY (1)

Components identified with the mark have the special characteristics for safety. When replacing any of these components, use only the same type.

[illegible][illegible]


CAMERA PARTS ASSEMBLY(2)



CAMERA PARTS ASSEMBLY (2)

[illegible]

CAMERA PARTS ASSEMBLY(3)




CAMERA PARTS ASSEMBLY (3)

[illegible]

TOP CASE & HANDLE PARTS ASSEMBLY



Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.





TOP CASE & HANDLE PARTS ASSEMBLY

Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.

[illegible]

SIDE CASE (R) PARTS ASSEMBLY

Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.




SIDE CASE (R) PARTS ASSEMBLY

Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
1	VYP9265	SIDE CASE R 2U	1		E32	VEP80D09A	TOGGLE P. C. BOARD	1	
2	VGU8130	SLIDE SW COVER	4		E33	VEP80D03A	V MEM SW P. C. BOARD	1	
3	VGH5067	FILTER NAME PLATE	1		E34	VEP80C64A	HEADPHONE P. C. BOARD	2	
4	VGL1039	LED PANEL LIGHT	1		E35	VEP80D04A	SHOT M SW P. C. BOARD	1	
5	VGK3031	TOGGLE SW PLATE	1						
6	VMP5578	SLIDE SW ANGLE	1						
7	VMG1096	VR RAIN COVER PACKING	3						
8	VMG1195	SLIDE SW RUBBER	4						
9	VZT0624	TAPE A	1						
10	VZT0625	TAPE B	1						
11	VMS7187	LCD LOCK SHAFT	1						
12	VMB3938	MONITOR LOCK SPRING	1						
13	VYF2895	OPERATION PANEL (B)U	1						
14	VGU9675	MONITOR LOCK KNOB	1						
15	VMC1837	SLIDE PLATE SPRING	1						
16	VMP8366	GUIDE PLATE	1						
17	VMG1286	CUSHION RUBBER	2						
18	VMG1506	DOOR CUSHION	1						
19	VGQ8202	MONITOR POP UP	1						
20	VMP8171	POP UP PLATE	1						
21	VMB3996	POP UP SPRING	1						
22	VMP8059	SPEAKER SET ANGLE	1						
23	VGU9301	VR KNOB FRONT	1						
24	VGU9303	VR KNOB	2						
25	VGU9304	OPERATION RUBBER BUTTON	1						
26	VGU8993	OPERATION BUTTON	1						
27	VMG0646	WATERPROOF SW INSULATION SH	4						
28	VGH4680	VR NAME PLATE	2						
29	VGH4948	VF LABEL	1						
30	VMT1494	WATERPROOF CUSHION	4						
 31	VEE1E76	JUMPER CABLE	1						
32	VEE1E77	JUMPER CABLE	1						
33	VWJ30H2070LO	LCD IF FFC	1						
34	VEE1E78	JUMPER CABLE	1						
35	VEE1E79	JUMPER CABLE	2						
36	VEKOM98	SPEAKER U	1						
37	VMT1622	SPEAKER CUSHION	1						
38	VMX0531	CLATCH SPACER	2						
39	VMX3355	SPACER	1						
40	VJF1535	CLAMPER	2						
 41	VEE1E82	JUMPER CABLE	1						
42	VYF3135	OPERATION DOOR U	1						
43	VGU0A79	OPERATION BUTTON	1						
44	VLP0123	FERRITE CORE	2						
45	VGQ1712	ANP BASE	1						
46	VJF1559	CLAMPER	1						
47	VGL1228	LED PANEL LIGHT	3						
48	VMZ3692	LCD FFC SHEET	1						
49	VMT1801	FACE PAD	1						
50	VGQ9385	CONDUCTIVE TAPE	1						
51	VMZ3806	LCD BARRIER A	1						
52	VGU9695	RUBBER BUTTON	1						
101	XTN3+6GFJ	SCREW	2						
102	XYN2+J6FJ	SCREW	2						
103	XYN2+F5FJ	SCREW	3						
104	XQN2+BJ4FJK	SCREW	1						
105	XYN2+C4FJ	SCREW	2						
106	VMX1312	POLY WASHER	4						
107	XYN2+C5FJ	SCREW	2						
108	XYN2+J6FJ	SCREW	16						
109	XQN2+A3FJ	SCREW	2						
110	VHN0382	NYLON NUT	2						
111	XQN2+A2FJK	SCREW	1						
112	XQN2+BJ4FJK	SCREW	2						
113	XTB26+6GFJK	SCREW	8						
114	XYN2+J6FJ	SCREW	5						
E28	VEP80E01C	SPD LCD P. C. BOARD	1						
E29	VEP80E32A	SPD SSW P. C. BOARD	1						
E30	VEP80D11A	POWER SW P. C. BOARD	1						
E31	VEP80E38A	LCD OPEN SW P. C. BOARD	1						

CARD GUIDE PARTS ASSEMBLY

* The part number of card holder is written in Electric Parts List of each P.C.Board.




CARD GUIDE PARTS ASSEMBLY

[illegible]

REAR JACK PARTS ASSEMBLY

Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.




REAR JACK PARTS ASSEMBLY

Components identified with the mark have the special characteristics for safety. When replacing any of these components, use only the same type.

[illegible][illegible]

BACK CASE PARTS ASSEMBLY

Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.




BACK CASE PARTS ASSEMBLY

Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.

[illegible][illegible]

LCD PARTS ASSEMBLY




LCD PARTS ASSEMBLY

[illegible]

PACKING PARTS ASSEMBLY

Components identified with the mark  have the special characteristics for safety. When replacing any of these components, use only the same type.



PACKING PARTS ASSEMBLY

Components identified with the mark have the special characteristics for safety. When replacing any of these components, use only the same type.

[illegible][illegible]