


## External 3500 Connection Methods



In this configuration, the 2 each Virtual Panels and the WIN3500/Virtual Panel can control the Cougar, Jaguar, Tiger frames and or the Bobcat, LNS-8, Ocleot frames simultaneously.

Note: If using the 3500 Internal Controller, only three (3) COM ports are available. 1for WIN3500/VP, 1 for additional VP or automation, and 1 for PRC connection.

Note: The Ocelot Remote/Local control panels will not operate with the PRC controller.