

RC5000 HyperTerminal Setup

1. Cable Type: Null modem 9 pin to 9 pin (see diagram below)
2. Cable Connection: typically Com 1 on the PC to Host Serial A (J50) on the RC5000
3. HyperTerminal settings (Com 1 port settings)
 - a. 19200 baud
 - b. 8 data bits
 - c. No parity
 - d. 2 stop bits
 - e. Flow control Xon/Xoff
4. Function, arrow and control keys act as terminal keys
5. Emulation is VT100
6. Backscroll buffer lines 500

