

DIP Switch	Decription	Settings				
1	Talk Key Row Select	Open:	Use bottom row			Closed:
			Use top row			
2	Expansion Panel In-use Indication	Open:	Flash			Closed:
			LCP Connect			
3	LCP Select	Open:	No LCP Connect			Closed:
			LCP Connect			
4		Adress	Sw 4	Sw 5	Sw 6	Sw 7
		1	Close	Open	Open	Open
		2	Open	Close	Open	Open
		3	Close	Close	Open	Open
5	Logical Keypanel Address Select	4	Open	Open	Close	Open
		5	Close	Open	Close	Open
6		6	Open	Close	Close	Open
		7	Close	Close	Close	Open
7		8	Open	Open	Open	Close
8	Baud Rate Select	Open:	9600 baud			Closed:
			76.8 kbaud (Do Not Use!)			