









	RTS Intercoms <b>Quick Reference Card</b>		Page 1/2
From ST-CO/MKA3	Our Reference		Date Oct, 2017

### Shortcuts

- [Up] and [Down] held for 3 seconds will lock or unlock the menus. Top panel keys and arrows to select pages can still be used.
- If [Scroll List loaded] and pressed [Select], the Scroll List is set as shortcut on the select key.
- [Menu] and [Select] and [Up] and [Down] held for 3 seconds returns the beltpack to factory default settings.
- [Menu] or [Select] or [Up] or [Down] pressed after screen timeout turns on the screen and shows 'home' screen. In dark mode these keys do not turn on the screen.
- Double tap the [Top panel encoder] while holding [Menu] enables or disables dark mode.

	Menu
	Select
	Up
	Down
	Scroll list loaded
	Top panel encoder

## 1 Dark mode

Dark mode ensures that all lights are turned off while the beltpack stays functional. Top panel stays on and can be read with ambient light. If the top panel light is still too bright, this can be adjusted in the menu. The audio alert on power-up and power-down are adjustable on the alert screen, till then it stays as configured per default.



	RTS Intercoms <b>Quick Reference Card</b>		Page 2/2
From ST-CO/MKA3	Our Reference		Date Oct, 2017

**Revision History**

Issue	Date	Editor	Description of amendment
2.4	Oct, 2017	Sven Bindels	Equal version as update guide and training
2.5	Oct, 2017	Sven Bindels	Text improvements