

TM2000 CPU MAC Address

TM2000 CPU MAC Address.doc
7-1-04
G. Behrend

Connect monitor to TM2000.

Press “return” to get log on prompt.

Log on as “root”, use password if required.

Type in “ifconfig eth0” (zero)

space ↗

Top line will be MAC address. It should be 6 hex pairs separated by colons.

OR

Ping address of TM2000 computer and enter “arp -a” and look for physical address.

space ↗ ↘ *minus*