


Top Panel Block

1-2. Exploded Views



No.	Part No.	SP Description
1	A-8278-776-A	o SLIDE ASSY, VF
2	A-8278-779-A	o HANDLE SUB ASSY
3	A-8317-858-A	o MOUNTED CIRCUIT BOARD, SW-937
4	X-3604-506-2	o COVER ASSY, HANDLE
5	1-570-612-11	s SWITCH, TOGGLE "TALLY"
6	1-667-992-11	o PRINTED CIRCUIT BOARD, SW-936
7	3-612-338-01	s SHEET, HANDLE
8	3-612-342-01	o ARM, SLIDE
9	3-612-346-01	o LABEL (INCOM)
10	3-612-378-01	o LABEL (RET1/2)
11	3-612-379-01	o COVER, TALLY
12	3-641-622-00	s SPRING, COMPRESSION
13	3-673-018-11	s SCREW, BLIND
14	3-673-046-00	s LEVER, LOCK
15	3-676-244-00	s COVER, SWITCH
16	3-679-684-01	o REST, ARM
17	3-679-685-11	o TABEL, FIXED, VF SLIDE
18	3-679-686-01	o TABEL, FIXED, VF SHOE
19	3-679-698-01	o RING (C), LOCK
20	3-679-702-01	o CUSION, STOPPER
21	3-682-760-01	o SCREW (M7-0.75), ADJUSTMENT
22	3-701-506-01	s SET SCREW, DOUBLE POINT 3X4
23	3-701-508-00	s SET SCREW, DOUBLE POINT 3X6
24	3-710-039-03	s SHOE, SLIDE
25	3-711-765-01	s BOLT (M3), HEXAGON SOCKET
26	3-711-794-11	o PIN, STOPPER
27	3-720-919-01	o RUBBER, LOCK RING
28	3-895-622-01	s RING (DIA. 5), O