




No.	Part No.	SP Description
-----	----------	----------------

401	X-3166-280-2	o CHASSIS ASSY, MAIN
402	X-3605-877-1	o FRAME (R) ASSY
403	1-589-539-11	o MOUNTED CIRCUIT BOARD, PD-810
404	1-589-542-12	o MOUNTED CIRCUIT BOARD, PD-807
405	1-761-336-11	o MOUNTED CIRCUIT BOARD, PG-41

No.	Part No.	SP Description
-----	----------	----------------

406	1-589-880-12	o MOUNTED CIRCUIT BOARD, PG-207
407	1-589-881-12	o MOUNTED CIRCUIT BOARD, PG-209
408	3-172-767-01	o FRAME (FRONT)
409	3-172-768-01	o SPRING, CRT GROUND
410	3-172-778-01	s PAD, THERMAL
411	3-172-779-01	o PLATE, SHIELD
412	3-627-844-01	o FRAME (L)
413	3-172-823-01	o FRAME (REAR)
414	3-182-456-01	o FRAME TOP
415	3-182-457-11	o PLATE, BOTTOM
416	3-693-297-01	s FOOT, RUBBER, RADIATION
417	3-703-044-26	o LABEL, CAUTION
418	3-697-782-01	o BRACKET, PC
419	3-703-072-00	o HOLDER, PWB
420	1-761-337-11	o MOUNTED CIRCUIT BOARD, PG-42
421	1-761-338-11	o MOUNTED CIRCUIT BOARD, PG-43