


Tilt Table Block-1



No.	Part No.	SP Description
101	X-3166-337-1	o PLATE (L) ASSY, SIDE
102	3-172-784-02	s SPRING, TENSION
103	3-172-785-02	o PLATE, BLIND, TILT
104	3-172-786-01	o SHAFT, LIFT ROTARY
105	3-172-787-01	o PLATE, ORNAMENTAL, TILT
106	3-172-788-01	o PLATE, BLIND, ARM
107	3-172-789-01	o ARM (B), TILT
108	3-172-791-11	o PLATE, FRICTION
109	3-172-796-01	o WASHER (22), DU THRUST
110	3-172-801-01	s SPRING (PIA.20)
111	3-172-802-02	o SHAFT, FRICTION
112	3-172-803-02	s KNOB, FRICTION
113	3-172-805-01	s KNOB, MUSHROOM
114	3-172-806-01	o ARM (A) (L), TILT
115	3-172-808-01	o SHAFT (B), TILT

No.	Part No.	SP Description
116	3-172-809-01	o SHEET (A), THRUST
117	3-172-810-01	o SHEET (B), THRUST
118	3-172-813-01	o CAP, PIPE
119	3-172-814-01	o PIPE, RUBBER
120	3-172-834-01	o PIPE
121	3-172-835-01	o BOOM
122	3-172-841-01	o TILT (L)
123	3-173-371-02	s SCREW, PUNCHING STOPPER
124	3-661-588-00	o SPACER (3X5)
125	3-701-446-21	s WASHER, 8
126	3-701-448-21	s WASHER, POLYETHYLENE
127	4-555-003-00	s SPRING