

**SONY®**

CAMERA OPERATING SOFTWARE

**HZC-PSF3**

USER'S GUIDE English  
1st Edition

# Overview

The HZC-PSF3 Camera Operating Software is optional software that enables the Sony HD Color Camera HSC300R, HSC100R, HSC300RF, HSC100RF to support additional output formats.

These formats can also be output from a compatible CCU.

The HZC-PSF3 Camera Operating Software supports 1080/29.97PsF and 1080/25PsF formats.

# Installation

## 1 Create a key file.

Create a text file that includes the software installation key and change the filename to “hsc300r.key.”

Note that the extension is “.key.”

### Key file format

- You can describe multiple installation keys in a single key file (hsc300r.key). Invalid keys are ignored in the installation process.
- Describe only one installation key on a single line.
- Any description between “#” or “;” and the line break is read as a comment.

### Example of hsc300r.key

```
# A Studio
# CAM1
c51caee92a3d1d77

# CAM2
2897f1db294d70ae

; Studio B
bd9dc931db917f25 ; CAM1
6fe3ebd3f4ba3635 ; CAM2
```

## 2 Copy the key file.

Create a \MSSONY\PRO\CAMERA\HSC300R folder on a USB drive and copy “hsc300r.key” to that folder.

*For information on usable types of USB drives, refer to the OPERATION MANUAL of the camera.*

## 3 Install the key file.

Connect the USB drive to the USB connector, and install the key file on the camera using the <OPTION KEY> page of the MAINTENANCE menu.

*For details on menu operations, refer to the OPERATION MANUAL of the camera.*

```

<OPTION KEY>      M19 TOP
  →READ (USB →CAM)
INSTALLED OPTION

```

When the key file is installed on the camera, the name of the installed key file appears in the <OPTION KEY> page's INSTALLED OPTION column. The illustrations below give an example of the indication when HZC-PSF3 is installed.

Model	Indication
HZC-PSF3	PsF ADDITION

```

<OPTION KEY>      M19 TOP
  →READ (USB →CAM)
INSTALLED OPTION
  PsF ADDITION

```

#### 4 Confirm the result of installation.

Restart the camera and check the OPTION display on the <SERIAL NO.> page of the DIAGNOSIS menu. When the installation is successfully completed, the name of the installed key file appears in the <OPTION> column.

```

<SERIAL NO.>      D03 TOP
MODEL: HSC300R
NO   : 100001
OPTION:
  PsF ADDITION

```

## HZC-PSF3


By installing HZC-PSF3, in addition to 1080/59.94i, 1080/50i, 720/59.94P, and 720/50P formats, you can use 1080/29.97PsF and 1080/25PsF formats.

To select a format, use the menu of the MSU (Master Setup Unit) when the camera is connected to the system, or use the menu of the camera when the camera is used on a stand-alone basis.

As an example, the following describes how to select 1080/29.97PsF format.

### When the camera is connected to the system

Select "Camera Transmit" on the Multi Format Menu page of the MSU, then select "1080/29.97PsF."



For details on menu operations, refer to the OPERATION MANUAL of the MSU.

### When the camera is used on a stand-alone basis

Select "29.97PsF" on the <OUTPUT FORMAT> page of the MAINTENANCE menu.

```

<OUTPUT FORMAT>  M09→TOP
CURRENT
1080-59.94i

[1080]
  59.94i      50i
  →29.97PsF   25PsF

[720]
  59.94P      50P

```

For details on menu operations, refer to the OPERATION MANUAL of the camera.

Sony Corporation