

SONY

Default Output Assignment

XVS Switcher Series



January, 2018

Professional Products Group
Sony Imaging Products and Solutions Inc.

Default Output Assignment – XVS-8000

As of Ver.2.5

Signal Format: 3840x2160P, 3840x2160PsF

Out#	Output
1	P/P PGM 1
2 ~ 4	—
5	P/P PVW
6 ~ 8	—
9	M/E-1 PGM 1
10 ~ 12	—
13	M/E-1 PVW
14 ~ 16	—
17	M/E-2 PGM 1
18 ~ 20	—
21	M/E-2 PVW
22 ~ 24	—
25	M/E-3 PGM 1
26 ~ 28	—
29	M/E-3 PVW
30 ~ 32	—
33	Edit Preview
34 ~ 36	—
37	Aux1
38 ~ 40	—
41	Aux2
42 ~ 44	—
45	Aux3
46 ~ 48	—

Except for 3840x2160P, 3840x2160PsF

Out#	Output
1	P/P PGM 1
2	P/P PVW
3	P/P CLEAN
4	P/P K-PVW 1
5	M/E-1 PGM 1
6	M/E-1 PVW
7	M/E-1 CLEAN
8	M/E-1 K-PVW 1
9	M/E-2 PGM 1
10	M/E-2 PVW
11	M/E-2 CLEAN
12	M/E-2 K-PVW 1
13	M/E-3 PGM 1
14	M/E-3 PVW
15	M/E-3 CLEAN
16	M/E-3 K-PVW 1
17	Edit Preview
18	Preset
19	DME Monitor Video
20	DME Monitor Key
21	Aux1
22	Aux2
23	Aux3
24	Aux4
25 ~ 48	Aux5 ~ Aux28

Default Output Assignment – XVS-7000

As of Ver.2.5

Signal Format: 3840x2160P, 3840x2160PsF

Out#	Output
1	P/P PGM 1
2 ~ 4	—
5	P/P PVW
6 ~ 8	—
9	M/E-1 PGM 1
10 ~ 12	—
13	M/E-1 PVW
14 ~ 16	—
17	M/E-2 PGM 1
18 ~ 20	—
21	M/E-2 PVW
22 ~ 24	—
25	Edit Preview
26 ~ 28	—
29	Aux1
30 ~ 32	—
33	Aux2
34 ~ 36	—
37	Aux3
38 ~ 40	—
41	Aux4
42 ~ 44	—
45	Aux5
46 ~ 48	—

Except for 3840x2160P, 3840x2160PsF

Out#	Output
1	P/P PGM 1
2	P/P PVW
3	P/P CLEAN
4	P/P K-PVW 1
5	M/E-1 PGM 1
6	M/E-1 PVW
7	M/E-1 CLEAN
8	M/E-1 K-PVW 1
9	M/E-2 PGM 1
10	M/E-2 PVW
11	M/E-2 CLEAN
12	M/E-2 K-PVW 1
13	M/E-3 PGM 1
14	M/E-3 PVW
15	M/E-3 CLEAN
16	M/E-3 K-PVW 1
17	Edit Preview
18	Preset
19	DME Monitor Video
20	DME Monitor Key
21	Aux1
22	Aux2
23	Aux3
24	Aux4
25 ~ 48	Aux5 ~ Aux28

Signal Format: 3840x2160P, 3840x2160PsF

Out#	Output
1	P/P PGM 1
2 ~ 4	—
5	P/P PVW
6 ~ 8	—
9	M/E-1 PGM 1
10 ~ 12	—
13	M/E-1 PVW
14 ~ 16	—
17	Edit Preview
18 ~ 20	—
21	Aux1
22 ~ 24	—

Except for 3840x2160P, 3840x2160PsF

Out#	Output
1	P/P PGM 1
2	P/P PVW
3	P/P CLEAN
4	P/P K-PVW 1
5	M/E-1 PGM 1
6	M/E-1 PVW
7	M/E-1 CLEAN
8	M/E-1 K-PVW 1
9	Edit Preview
10	Preset
11	DME Monitor Video
12	DME Monitor Key
13	Aux1
14	Aux2
15	Aux3
16	Aux4
17 ~ 24	Aux5 ~ Aux12

SONY

SONY is a registered trademark of Sony Corporation.

Names of Sony products and services are the registered trademarks and/or trademarks of Sony Corporation or its Group companies.

Other company names and product names are registered trademarks and/or trademarks of the respective companies.