



Model 370 Intercom Beltpack

Configuration Guide

This Configuration Guide is applicable for the following serial numbers: M370-00251 and later with application firmware 2.1 and later and Dante firmware 1.1 (Ultimo 2.2.3.1) and later



SW1 – Mic Preamp Gain



40 dB



46 dB

SW2 – Channel 1 Talk Button Mode



Push to Talk



Push to Talk / Tap to Latch

SW3 – Channel 2 Talk Button Mode



Push to Talk



Push to Talk / Tap to Latch

SW4 – Channel 1 Listen Audio Routing



Left Channel



Left and Right Channels

SW5 – Channel 2 Listen Audio Routing



Right Channel



Left and Right Channels

Headset Connector Pinout

XLR5F

- | | | |
|---|---|-------------------------|
| 1 |  | MIC IN - / SHIELD |
| 2 |  | MIC IN + |
| 3 |  | PHONES COM |
| 4 |  | PHONES OUT LEFT / CH 1 |
| 5 |  | PHONES OUT RIGHT / CH 2 |