

BPS-8 & BPS-16 Connection View

Wednesday, May 16, 2007



BPS-16

Power Connector

Unused

BPS-16 control panel connects to one of the "BPS-Net" connectors on BPS-2020 via CAT 5 cable. The BPS-16 terminates one end and a U-NET terminator is installed at the opposite end of the BPS-NET. Up to 8 BPS-2020 chassis can be independently controlled by one BPS-16




BPS-8

Power Connector

Unused

BPS-8 control panel connected via a CAT5 cable to "Panel" connector on BPS-2020 chassis..

Note: in systems containing more than one BPS-2020 channel, a BPS-8 can be connected to each of the BPS-2020's "Panel" connector for local control of that channel. A BPS-16 may also be connected to the "BPS-NET" connector and looped through other channels; allowing centralized control of up to 8) BPS-2020 channels.



BPS-8 & 16 Front View

Wednesday, May 16, 2007

