grass valley

Kayak

DIGITAL PRODUCTION SWITCHER

Release Notes Addendum

SOFTWARE VERSION 6.9.0

071847505
FEBRUARY 2007

THOMSON
images & beyond

Contacting Grass Valley

International Support Centers	**France 24 x 7**	+800 8080 2020 or +33 1 48 25 20 20 +800 8080 2020 or +33 1 48 25 20 20	**United States/Canada 24 x 7**	+1 800 547 8949 or +1 530 478 4148
Local Support Centers (available during normal business hours)	**Asia**	**Hong Kong, Taiwan, Korea, Macau:** +852 2531 3058 **Indian Subcontinent:** +91 22 24933476 **Southeast Asia/Malaysia:** +603 7805 3884 **Southeast Asia/Singapore:** +65 6379 1313 **China:** +861 0660 159 450 **Japan:** +81 3 5484 6868		
	Australia and New Zealand: +61 1300 721 495			**Central/South America:** +55 11 5509 3443
	Middle East: +971 4 299 64 40 **Near East and Africa:** +800 8080 2020 or +33 1 48 25 20 20			
	Europe	**Belarus, Russia, Tadzikistan, Ukraine, Uzbekistan:** +7 095 2580924 225 **Switzerland:** +41 1 487 80 02 **S. Europe/Italy-Roma:** +39 06 87 20 35 28 **-Milan:** +39 02 48 41 46 58 **S. Europe/Spain:** +34 91 512 03 50 **Benelux/Belgium:** +32 (0) 2 334 90 30 **Benelux/Netherlands:** +31 (0) 35 62 38 42 1 **N. Europe:** +45 45 96 88 70 **Germany, Austria, Eastern Europe:** +49 6150 104 444 **UK, Ireland, Israel:** +44 118 923 0499		

Copyright © Grass Valley. All rights reserved.
This product may be covered by one or more U.S. and foreign patents.

Grass Valley Web Site

The www.thomsongrassvalley.com web site offers the following:

Online User Documentation — Current versions of product catalogs, brochures, data sheets, ordering guides, planning guides, manuals, and release notes in .pdf format can be downloaded.

FAQ Database — Solutions to problems and troubleshooting efforts can be found by searching our Frequently Asked Questions (FAQ) database.

Software Downloads — Software updates, drivers, and patches can be downloaded.

grass valley

END-OF-LIFE PRODUCT RECYCLING NOTICE

Grass Valley's innovation and excellence in product design also extends to the programs we've established to manage the recycling of our products. Grass Valley has developed a comprehensive end-of-life product take back program for recycle or disposal of end-of-life products. Our program meets the requirements of the European Union's WEEE Directive, the United States Environmental Protection Agency, and U.S. state and local agencies.

Grass Valley's end-of-life product take back program assures proper disposal by use of Best Available Technology. This program accepts any Grass Valley branded equipment. Upon request, a Certificate of Recycling or a Certificate of Destruction, depending on the ultimate disposition of the product, can be sent to the requester.

Grass Valley will be responsible for all costs associated with recycling and disposal, including freight. However, you are responsible for the removal of the equipment from your facility and packing the equipment to make it ready for pickup.

For further information on the Grass Valley product take back system please contact Grass Valley at + 800 80 80 20 20 or +33 1 48 25 20 20 from most other countries. In the U.S. and Canada please call 800-547-8949 or 530-478-4148, and ask to be connected to the EH&S Department. Additional information concerning the program can be found at: www.thomsongrassvalley.com/environment

THOMSON images & beyond

Version 6.9.0

FEBRUARY 2007

Release Notes Addendum

Kayak HD

Software Issues Corrected in Release Version 6.9.0

Area	Corrected Issue	ID
Auto-detect	Autodetection of Videostandard is not safe	66980
Boot	Autodetection of Videostandard is not safe	66981
Chroma Key	Auto-Chroma-Key with FGD is working only every second try	73781
Control Panel	Activating the control panel's Key BorderOn button has no effect. This does work for Preset Pattern border.	62047
DPM	Numeric entry doesn't work for all delegated channels in DPM menu.	66628
DPM	Edit Gang does not work for DPM lighting	70343
E-MEM	In Default mode if you have an E-MEM (Snapshot) that recalls an DPM effect and that effect is currently set prior to E-MEM recall with some minor Transform changes, it will not set the iDPMs back to the correct values set by the effect's first keyframe. Workaround: If 'Autorun' for DPM effects is turned on then this function works as expected.	62974
RamRec	Trim Clip function in Ram Recorder not working.	70816
RamRec	RamRec: From Webpage, Stills load into Clip list.	71733

Known Restrictions

Area	Known Issue	ID
Convergence Mode	Convergence Mode working incorrectly when Global is involved	67593
DPM	Performing a Factory Preset recalls DPM 0,but it should recall the system default values. Workaround: Store default values in DPM 0 on all M/E's available. Don't use DPM 0 for general effects.	62852
DPM	The DPM cannot be controlled as a VTR by using the BVW emulation protocol.	63066
DPM	DPM auto run doesn't run the effect. It will only auto run if you manually rewind the effect.	63368
DPM	DPM Depth Priority not working correctly	67576
DPM	DPM "Use Source" conflicts with EMEM source recall.	69709
DPM	Can't modify DPM path in Multi-channel effect.	75171
DPM	Current manufacturing, 671663100 boards are failing DPMs on Key 1 and Key 2	75897
Effects	Wipe-shapes using maximum H+V modulation are popping In/Out at the start/end of a transition.	65064
E-MEM	E-MEM does not recall clips from media player. Workaround: It is possible to recall the clips from an external device by importing a Macro into the timeline. First program a Macro that loads a clip from an external device and test it to make sure it works. Second, create your timeline and import the contents of the Macro into the timeline. Currently you must use the Sidepanel for this workaround. Store the timeline, and the clip will be recalled in the effect.	62380
E-MEM	Background Transition not working correctly with E-MEM	70676
Flash Disk	Description of erasing effects from Flash 3 disk is misleading	67607
Key Frame	Modify All KF's doesn't work with Define MEMo	72798
Keyer Matte	Keyer 3 & 4 Matte / Wash Control / Wash Source incorrect and Utility 1 and 2 video is swapped.	66763
Keyers	Combining Matte Fill and Glow on a key can cause Noise in image.	71270
M/E	M/E couple does not support utility buses.	61954
RAM	RAM video flashes when recording stills in SD. (Flash is not recorded.)	71646
RamRec	RamRec file transfers are not accessable from Kayak GUI	71337
RamRec	Can't reset the RamRec without losing Stills and Clips in memory.	71736
RamRec	In SD mode reseting the Main Frame causes the RamRec to sometimes have black or no output.	71916
RamRec	Timecode is changing when Mode is changed from VTR to Simple loop.	76088
Reference	Autodetection of Video standard is not reliable after software load or changing partition.	66981
Transition	Add Transition Type is not implemented.	61808
Transition	DSK keys can't be transitioned without also doing a background transition.	64979
USB Flash Drive	If a USB flash drive is detected on a USB port during startup the Kayak Panel remains black. Workaround: Remove the USB flash drive and reboot the system by turning the power off and then back on.	63621

Kayak DD

Software Issues Corrected in Release 6.9.0

Area	Corrected Issue	ID
DPM	VTR-emulation for DPM	61161
RamRec	Loading RamRec Stills from Memo-Stick or Sidepanel allows duplicate Stills-Names.	68524

Known Restrictions

Area	Known Issue	ID
Chroma Key	It's not possible to do auto adjustment of the chroma key for a second time when the chroma key adjustment is done in the FGD Fade Mode.	64840
E-MEM	Emem (TiM/E Memo) recalls of paired RamRec channels fails in Video-Video mode	68133
RamRec	Sometimes RamRec filetransfer doesn't transfer Clip/Stills data	68588