

# Kayak

DIGITAL PRODUCTION SWITCHER

## Release Notes Addendum



SOFTWARE VERSION 6.9.2

071847507  
SEPTEMBER 2007

—



# Contacting Grass Valley

<b>International Support Centers</b>	<b>France 24 x 7</b>	+800 8080 2020 or +33 1 48 25 20 20 +800 8080 2020 or +33 1 48 25 20 20	<b>United States/Canada 24 x 7</b>	+1 800 547 8949 or +1 530 478 4148
<b>Local Support Centers (available during normal business hours)</b>	<b>Asia</b>	<b>Hong Kong, Taiwan, Korea, Macau:</b> +852 2531 3058 <b>Indian Subcontinent:</b> +91 22 24933476 <b>Southeast Asia/Malaysia:</b> +603 7805 3884 <b>Southeast Asia/Singapore:</b> +65 6379 1313 <b>China:</b> +861 0660 159 450 <b>Japan:</b> +81 3 5484 6868		
		<b>Australia and New Zealand:</b> +61 1300 721 495		<b>Central/South America:</b> +55 11 5509 3443
		<b>Middle East:</b> +971 4 299 64 40 <b>Near East and Africa:</b> +800 8080 2020 or +33 1 48 25 20 20		
	<b>Europe</b>	<b>Belarus, Russia, Tadzikistan, Ukraine, Uzbekistan:</b> +7 095 2580924 225 <b>Switzerland:</b> +41 1 487 80 02 <b>S. Europe/Italy-Roma:</b> +39 06 87 20 35 28 <b>-Milan:</b> +39 02 48 41 46 58 <b>S. Europe/Spain:</b> +34 91 512 03 50 <b>Benelux/Belgium:</b> +32 (0) 2 334 90 30 <b>Benelux/Netherlands:</b> +31 (0) 35 62 38 42 1 <b>N. Europe:</b> +45 45 96 88 70 <b>Germany, Austria, Eastern Europe:</b> +49 6150 104 444 <b>UK, Ireland, Israel:</b> +44 118 923 0499		

Copyright © Grass Valley. All rights reserved.

This product may be covered by one or more U.S. and foreign patents.

## Grass Valley Web Site

The [www.thomsongrassvalley.com](http://www.thomsongrassvalley.com) web site offers the following:

**Online User Documentation** — Current versions of product catalogs, brochures, data sheets, ordering guides, planning guides, manuals, and release notes in .pdf format can be downloaded.

**FAQ Database** — Solutions to problems and troubleshooting efforts can be found by searching our Frequently Asked Questions (FAQ) database.

**Software Downloads** — Software updates, drivers, and patches can be downloaded.



## END-OF-LIFE PRODUCT RECYCLING NOTICE

Grass Valley's innovation and excellence in product design also extends to the programs we've established to manage the recycling of our products. Grass Valley has developed a comprehensive end-of-life product take back program for recycle or disposal of end-of-life products. Our program meets the requirements of the European Union's WEEE Directive, the United States Environmental Protection Agency, and U.S. state and local agencies.

Grass Valley's end-of-life product take back program assures proper disposal by use of Best Available Technology. This program accepts any Grass Valley branded equipment. Upon request, a Certificate of Recycling or a Certificate of Destruction, depending on the ultimate disposition of the product, can be sent to the requester.

Grass Valley will be responsible for all costs associated with recycling and disposal, including freight. However, you are responsible for the removal of the equipment from your facility and packing the equipment to make it ready for pickup.



For further information on the Grass Valley product take back system please contact Grass Valley at + 800 80 80 20 20 or +33 1 48 25 20 20 from most other countries. In the U.S. and Canada please call 800-547-8949 or 530-478-4148, and ask to be connected to the EH&S Department. Additional information concerning the program can be found at: [www.thomsongrassvalley.com/environment](http://www.thomsongrassvalley.com/environment)



# *Release Notes Addendum*

## **Kayak HD**

### **Software Issues Corrected in Release Version 6.9.2**

<b>Area</b>	<b>Description</b>	<b>ID</b>
DPM	When doing a Modify All Absolute all values are changed, not just the values that have been adjusted.	75173
DSK	DSK keys can't be transitioned without also doing a background transition.	64979
Glow	Combining Matte Fill and Glow on a key can cause Noise in image.	71270
Menu	Menu "Config - Editor" is set to default after renaming an Application from an older software.	79256
Output Rec	"On Time" control in inverted value 100% shuts off Strobe Effect.	78634
RamRec	RamRec file transfers are not accessable from Kayak GUI.	71337
RamRec	Environment file ignores Ram Recorder Keyer menu settings.	77490
RamRec	Adjusting record area can freeze ram recorder.	77496

## Known Restrictions

Area	Description	ID
Crops	Crops are enabled even when "Crop On" is greyed out.	77499
DPM	Performing a Factory Preset recalls DPM 0, but it should recall the system default values. Workaround: Store default values in DPM 0 on all M/E's available. Don't use DPM 0 for general effects.	62852
DPM	When doing a DPM-Transition in TransPVW mode the opacity level (s) of included Keyer(s) are affected.	65060
DPM	In S-Linear, path is still being calculated as curve	67528
DPM	Enabling Glow turns off the Drop Shadow Softness	67572
Effects	The edges of the wipe pattern are per default to soft	54714
Effects	Wipe-shapes using maximum H+V modulation are popping In/Out at the start/end of a transition.	65064
E-Mem	Wrong "Auto Aux PVW" source after E-Mem Recall when M/E('s) is set to "Permanent DSK PVW".	81158
E-MEM	E-MEM does not recall clips from media player. Workaround: It is possible to recall the clips from an external device by importing a Macro into the timeline. First program a Macro that loads a clip from an external device and test it to make sure it works. Second, create your timeline and import the contents of the Macro into the timeline. Currently you must use the Sidepanel for this workaround. Store the timeline, and the clip will be recalled in the effect.	62380
E-MEM	Transitions happen with EMEM even when transitions aren't programmed.	77054
E-MEM	Cannot modify an EMEM keyframe in sidepanel unless in 'View' mode.	83797
E-MEM	Recalling and running DPM effects with recursives using EMEM's is inconsistent. Workaround: When building an effect with trails the you want to run using EMEM's, make sure that the value for PERIOD in Strobe Timing is 30 or less.	83811
Error Message	Missing reference is not shown as an error message in the diagnosis menu if the reference is not present.	76162
Frame	Tally emulation protocol does not work on KHD frame.	63070
Keyframe	Montage mode is inaccurate when stamping on Keyframe	78609
M/E	M/E couple does not support utility buses.	61954
Macros	Macro editing of Ram still numbers cannot be edited.	84191
MatchDef	MatchDef scalars are causing two frames of delay instead of specified 1 frame, in at least 525i to 1080i conversion	77099
Mode	Timecode is changing when Mode is changed from VTR to Simple loop.	76088
MultiMix	For MultiMix and Offset Transition operation a sidepanel PC is necessary.	84307
Output Recursive	Montage with slab effects does not function properly.	83592
Output Recursive	In Montage, Chroma fades faster than the rest of the image.	83802
Pause	Inserting a Pause on a single Channel effect results in 2 individual Pauses being inserted.	65076
Ram Rec	If EE enabled on Ram Recorder in Video/Key mode, loading a clip or still will not take the key channel out of EE.	83794
RamRec	RAM video flashes when recording stills in SD. The flash is not recorded!	71646
RamRec	Newly Recorded Ram Clips should automatically set mark out as last frame	75243

Area	Description	ID
RamRec	"Move" a Clip/Still in RamRecorder Clips/Stills menu , causes a "Delete" of the target position when it's not an empty spot.	81402
Software Installing	When the software version V672.2 is reactivated or reinstalled after V683.x (or higher) has already been running it's possible that the Kayak CP won't come up. To make the Panel work with the older version do the following: - Perform a power cycle and boot the panel without loading the application (press 'home' and 'user 4' simultaneously while these buttons are blinking) - Press the 'ClearStateMem' button within the Reset menu (press 'Menu Lock' and 'Reset Device' simultaneously to get access to this button) - reboot the panel	83298
Turbo	Turbo won't take cue commands in BVW mode.	77050
USB Flash Drive	If a USB flash drive is detected on a USB port during startup the Kayak Panel remains black. Workaround: Remove the USB flash drive and reboot the system by turning the power off and then back on.	63621
Wipes	The edge of the Wipe Patterns are per default to soft.	54714

## Kayak DD

### Software Issues Corrected in Release 6.9.2

Area	Description	ID
DPM	When doing a Modify All Absolute all values are changed, not just the values that have been adjusted.	75173
Glow	Combining Matte Fill and Glow on a key can cause Noise in image.	71270
Menu	Menu "Config - Editor" is set to default after renaming an Application from an older software.	79256
Output Rec	"On Time" control in inverted value 100% shuts off Strobe Effect.	78634
RamRec	Sometimes RamRec filetransfer doesn't transfer Clip/Stills data.	68588
RamRec	RamRec file transfers are not accessible from Kayak GUI.	71337

### Known Restrictions

Area	Description	ID
Crops	Crops are enabled even when "Crop On" is greyed out.	77499
DPM	Performing a Factory Preset recalls DPM 0, but it should recall the system default values. Workaround: Store default values in DPM 0 on all M/E's available. Don't use DPM 0 for general effects.	62852
E-Mem	Wrong "Auto Aux PVW" source after E-Mem Recall when M/E(s) is set to "Permanent DSK PVW".	81158
E-MEM	E-MEM does not recall clips from media player. Workaround: It is possible to recall the clips from an external device by importing a Macro into the timeline. First program a Macro that loads a clip from an external device and test it to make sure it works. Second, create your timeline and import the contents of the Macro into the timeline. Currently you must use the Sidepanel for this workaround. Store the timeline, and the clip will be recalled in the effect.	62380
E-MEM	Transitions happen with EMEM even when transitions aren't programmed.	77054

Area	Description	ID
Error Message	Missing reference is not shown as an error message in the diagnosis menu if the reference is not present.	76162
M/E	For MultiMix and Offset Transition operation a sidepanel PC is necessary	84307
Macros	Some Macros attachments are disappearing after software update from 672 to 690. Workaround--reattach macros	79338
Macros	Macro editing of Ram still numbers cannot be edited.	84191
Mode	Timecode is changing when Mode is changed from VTR to Simple loop.	76088
Pause	Inserting a Pause on a single Channel effect results in 2 individual Pauses being inserted.	65076
RamRec	Newly Recorded Ram Clips should automatically set mark out as last frame	75243
Software Installing	When the software version V672.2 is reactivated or reinstalled after V683.x (or higher) has already been running it's possible that the Kayak CP won't come up. To make the Panel work with the older version do the following: - Perform a power cycle and boot the panel without loading the application (press 'home' and 'user 4' simultaneously while these buttons are blinking) - Press the 'ClearStateMem' button within the Reset menu (press 'Menu Lock' and 'Reset Device' simultaneously to get access to this button) - reboot the panel	83298
Turbo	Turbo won't take cue commands in BVW mode.	77050
USB Flash Drive	If a USB flash drive is detected on a USB port during startup the Kayak Panel remains black. Workaround: Remove the USB flash drive and reboot the system by turning the power off and then back on.	63621
Wipes	The edge of the Wipe Patterns are per default to soft.	54714