

LV5380 Software Upgrade Procedure

Caution: Please DO NOT turn off the power during software upgrade.

1. Unzip the file **LV5380.zip**
2. Copy the “**LV5380**” folder to the USB thumb drive from the PC.
(The LV5380 folder includes the SYS and LDR subfolders)
3. Plug in the USB thumb drive to the LV5380.
4. Power on the LV5380.
5. Press the **SYS** button on the front panel.
6. Press **[F5] NEXT MENU**.
7. Press **[F1] INIT**
8. Press **[F5] FIRMWARE UPDATE**.
9. Press **[F3] YES**
10. Update will take few minutes and it will reboot after update is completed.
11. END