

## STEPS TO UPGRADE

1. Plug USB with latest version package
2. Click 'System update' from left navigation bar on the Web GUI
3. Enter credentials (User name- [admin@test.com](mailto:admin@test.com) Password-Test123)
4. User should see upgrade package once they log into 'System Update' page Select the package in the list and click on 'Update System' button. Click 'Yes' once pop up message appears
5. Wait about 5 minutes for update process and reboot of system

