

4.3 Rear panel



- 2 x Mains input (IEC connector)
- 7 x BRANCH BNC connectors for the SDTI Network
- 1 x RS232 (COM) for upgrades
- 1 x RS422 (AUX) DB9 connectors (EVS internal use)

