

Leader

LV5490 Software Upgrade Procedures

Caution: Please DO NOT turn off the power during software upgrade.

1. Unzip the **xxxx.zip** file.
2. Copy the "**LV5490_UPDATE**" folder to a USB thumb drive from the PC. (The LV5490_UPDATE folder consists of one file only)
NOTE: The USB thumb drive maximum capacity should be 4GB and it should be formatted as FAT32.
3. Plug in the USB thumb drive to the LV5490.
4. Power on the LV5490.
5. Once the instrument has powered on, press the **[SYSTEM]** button on the front panel.
6. Press **[F7] INITIALIZE**.
7. Press **[F7] FIRMWARE UPDATE**
8. Press **[F3] UPDATE YES**
9. Update will take few minutes. Once completed, a message will ask to turn the instrument off and power it back on.
10. END