

**[ Confidential ]**

Sony Corporation

No. HDCM13-012

# Technical Memo

Class [3]

Issued : February 22, 2013

**Subject: Software Release (V1.0.1 => V1.1.0)**

[Applicable Model ]

Model / Destination	Serial Number	Number of Unit
HZC-CSM10 WW		

**[Description]**

Updated software of HZC-CSM10 (V1.0.1 => V1.1.0) is released. Upgrade it as necessary.

**[Change Point]**

## &lt;New Functions&gt;

1. Support new functions of HDC2000 series
  - (1) Transferring Gamma file
  - (2) Control of Custom Preset matrix file
  - (3) Control of Adaptive matrix, Natural skin detail
2. Add the copy function of the setting in the [Overview] tab.
3. Add the installer for Windows 8

**[Preparation]**

## &lt;Software Files&gt;

File name: HZC-CSM10\_1.1.0\_Windows7.zip, HZC-CSM10\_1.1.0\_Windows8.zip

- \* Obtain them from eCSite. There are two zip files for Windows7 and Windows8 separately.

**[Installation Procedure]**

## &lt;Condition&gt;

It can be installed either of new installation or overwrite installation to HZC-CSM10 V1.0.1.  
Even the older version is uninstalled, V1.1.0 can be installed newly.

- The version and the install key can be confirmed from “Help” on menu bar > “About Camera System Manegement Software”. The install key is deleted after the uninstallation.  
Confirm the key before the uninstallation.

## &lt;Procedure&gt;

- The install key is common for V1.0.1 and V1.1.0.  
Refer to the “ReadThisFirst” file regarding how to use the installer.

**[Confirmation]**

Confirm if the version is upgraded to V1.1.0.

- \* The version can be confirmed from “Help” on the menu bar > “About Camera System Manegement Software”.

**[Software History]**

V1.0.1	V1.1.0
2012.8.31	2012.12.25