Vista 6-7-8 Section – Contents

0 Contents

1 Vista 6-7-8 V4.2 Operating Instructions

2 Vista 6-7-8 Service Instructions

2.1 Vista 6-7-8 Basic Information
2.1.1 Vista 6/7 Basic Configurations
2.1.1.1 Block Diagrams
2.1.1.2 Layouts
2.1.1.3 Configurations
2.1.1.4 Installation
2.1.1.5 Applications
2.1.2 Vista 8 Basic Configurations
2.1.2.1 Block Diagrams
2.1.2.2 Layouts
2.1.2.3 Configurations
2.1.2.4 Installation
2.1.2.5 Applications
2.2 Diagrams
2.3 Service Instructions
Fader Bay
Control Bay
Remote Fader Bays
Desk & PC
Redundant PC
Core
Monitoring
Vista File Structure
Performa Core Troubleshooting and Maintenance
2.4 Service/Application Notes
Service Notes 2004
SN 2004-01 Vista_FaderTFT
SN 2004-02 Vista 6 Custom Keys
SN 2004-03 Vista PC Bios Settings v1
SN 2004-04 Vista Bay Configuration
Application Notes 2005
AN 2005-01 Signaling - Stereo to mono
AN 2005-03 Studio Talkback
Service Notes 2005
SN 2005-01 Vista Monitoring DA
SN 2005-02 Vista 7 Joystick
SN 2005-03b RedPC_152
SN 2005-07 Service News July 05
SN 2005-08 VGA Cards
SN 2005-09 Fader Touch Panel
SN 2005-10a EpoX EP-3PT
SN 2005-12 Service News Nov 05
Service Notes 2006
SN 2006-01 D21 MicLine Card
SN 2006-02b Vista8 Keyboard
SN 2006-03 DSP Core Configuration
SN 2006-04a Vista PC BIOS Settings ASUS
Service Notes 2007
SN 2007-01 Fader Touch
SN 2007-06 Custom Key Panel

Application Notes 2008
AN 2008-02 Pro-Bel Implementation Notes V1.5
Service Notes 2008
SN 2008-07 Service News July 08
Alps Fader Care
2.5 HW/SW Upgrade
2.5.1 PC Upgrade
PCUpgrade-67 2006-07
PCUpgrade-81 2006-07
PCUpgrade-82 2006-07
2.5.2 HW Upgrade
SN 2003-01 Vista CDW Upgrade
2.5.3 SW Upgrade
Vista_3404
Vista_3405
Vista_35
Vista_3502
Vista_3503
Vista_3505
Vista_3507
Vista_3509
Vista_3603
Vista_3604
Vista_3605
Vista_4003
Vista_4004
Vista_4005
Vista_41
Vista_42
Vista_4203
2.6 Appendix: 3rd-Party Components
2.6.1 PC_Components
EPoX EP-3PTA (1st-Generation Main Board)
ASUS P4P800 SE (2nd-Generation Main Board)
RadiSys (3rd-Generation Main Board)
BlueHeat Manual
CDRW Lite-On Manual
FastTrak_TX2000_manual
HD IBM T60gh40gn_ds
HD Seagate ST3200
PCRW1208_BR
PCRW5224
SilentDrive Enclosure
2.6.2 Peripherals
BiPort2x4_Manual
DMXI_KVM
IHSE_e
PowerSupply BPW-8310
2.7 Vista_PluginEngine
Block diagram Studer PlugIn Engine.pdf
Quick Start Guide Studer PlugIn Engine.pdf
3 D21 MultiFeed/MasterSync Operating and Service Instructions
4 SCore Live Operating Instructions
5 D21m I/O System Operating Instructions and Diagrams
6 Marketing (Brochures and Presentations
Additional Information

Revision History

Revision	Date	Comments
BD10.375022 (0109)	Jan 30, 2009	First issue
BD10.375022 (0509)	May 25, 2009	Chapter 2.7 'Vista PlugIn Engine' added
BD10.375022 (0609)	Jun 30, 2009	Drawings in chapters 2.1.1.2 and 2.1.2.2 added/updated (new main board)
BD10.375022 (0709)	Jul 1, 2009	Update to SW V4.1: - Chapter 'Differences and New Features' added at the end of chapter 1/Register 10 - SW upgrade to V4.1 added to chapter 2.5.3
BD10.375022 (0310)	Mar 18, 2010	Update to SW V4.2: - Chapter 'Differences and New Features' added at the end of chapter 1/Register 10 - SW upgrades to V4.2 and to V4.203 added to chapter 2.5.3
0310	Mar 23, 2010	- Added chapters: '6, Marketing: Brochures and Presentations' and 'Additional Information' - One single product DVD for Vista 5 and Vista 6-7-8
1110	Nov 2010	- D21m Diagrams updated - One single product DVD for Vista 5-9

Disclaimer

The information on this disc has been carefully checked and is believed to be accurate at the time of publication. However, no responsibility is taken by Studer for inaccuracies, errors, or omissions, nor is any liability assumed for any loss or damage resulting either directly or indirectly from use of the information contained within it.

Prepared and edited by
Studer Professional Audio GmbH
Technical Documentation
Riedthofstrasse 214
CH-8105 Regensdorf – Switzerland
http://www.studer.ch

Copyright by Studer Professional Audio GmbH

Published in Switzerland

Subject to change

Studer is a registered trade mark of Studer Professional Audio GmbH, Regensdorf