

360 Systems

Instant Replay² NETWORKED DIGITAL AUDIO



**NETWORKED DIGITAL AUDIO RECORDER-PLAYER
WITH EDITING**

Model DR-600

OWNER'S MANUAL

Warning Symbols

THE FOLLOWING WARNING SYMBOLS ARE USED ON THE PRODUCT IN THIS MANUAL:



ENGLISH	ATTENTION: REFER TO OWNER'S MANUAL FOR IMPORTANT INFORMATION.
FRANÇAIS	ATTENTION: VEUILLEZ VOUS RÉFÉRER AU MODE D'EMPLOI POUR UNE INFORMATION IMPORTANTE.
ITALIANO	ATTENZIONE: FATE RIFERIMENTO AL MANUALE PER INFORMAZIONI IMPORTANTI.
ESPAÑOL	ATENCIÓN: FAVOR DE REFERIR AL MANUAL DE OPERACION POR INFORMACION IMPORTANTE.



ENGLISH	WARNING: ELECTRICAL SHOCK HAZARD.
FRANÇAIS	AVERTISSEMENT: DANGER DE CHOC ÉLECTRIQUE.
ITALIANO	AVVERTIMENTO: PERICOLO DI SHOCK ELETTRICO.
ESPAÑOL	ADVERTENCIA: PELIGRO DE CHOQUE ELECTRICO.

Safety Compliance

Instant Replay II Plus complies with the following safety standards:

- UL 1950, Standard for Safety of Information Technology Equipment, Including Electrical Business Equipment.
- EN 60950, Standard for Safety of Information Technology Equipment, Including Electrical Business Equipment.

EU Declaration of Conformity

Type of Equipment:

Professional Use Audio Equipment.

Conforms to the Following Standards:

EN55103-1 (Emission) (1997) Electromagnetic compatibility – Product family standard for audio, video, audio-visual and entertainment lighting control apparatus for professional use.

EN55103-2 (Immunity) (1997) Electromagnetic compatibility – Product family standard for audio, video, audio-visual and entertainment lighting control apparatus for professional use.

IEC950 2nd Edition, Amendment 1 (1992), Amendment 2 (1993) and Amendment 3 (1995); Safety of Information Technology and Business Equipment.

FCC Compliance

This equipment complies with part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the owners manual, may cause interference to radio communications. Operation of this equipment in a residential area is likely to cause interference in which case the user will be required to correct the interference at his own expense.

This device will accept any interference received, including interference that may cause undesired operation. The user is cautioned that changes made to the equipment without the approval of the manufacturer could void the user's authority to operate this equipment. It is suggested that only shielded and grounded cables be used to ensure compliance with FCC rules.

Notice

This Class A digital apparatus meets all requirement of the Canadian Interference-Causing Equipment Regulations.

Français:

Cet appareil numérique de la classe A respecte toute les exigences du Reglement sur le matériel brouilleur du Canada.

Company Address & Shipping Information

Freight and mail may be sent to 360 Systems at the following address. **Please** call for a **Returned Material Authorization (RMA) number** before returning equipment or parts.

360 Systems
Customer Service
31355 Agoura Rd
Westlake Village, California 91361-4613 USA

Telephone (818) 991-0360, 8:00 AM to 5:00 PM, Pacific Time. Fax: (818) 991-1360

Email: support@360systems.com Visit our web site at www.360systems.com

CAUTION!

Instant Replay contains a hard disk drive. While today's hard disks are very reliable, they are vulnerable to shock. Handle with care. Please exercise care not to drop or bump Instant Replay – damage to the internal hard disk may result. Be sure power is off before moving the unit.

Product Improvements And Upgrades

360 Systems reserves the right to make changes and/or improvements to its products, without incurring any obligation to incorporate such changes or improvements in units previously sold or shipped.

360 Systems may issue Technical Support Bulletins from time to time, advising owners of record of product enhancements that become available. Technical Support Bulletins may also be requested through 360 Systems Customer Service department by telephone at (818) 991-0360 or Facsimile at (818) 991-1360. However, we cannot contact you if you do not return your Warranty Card. Please take a moment now to fill out your Warranty Card and either mail or fax it to 360 Systems. You may also register your warranty with us by telephone.

Trademarks And Patents

360 Systems, 360 Systems Instant Replay, and DigiCart are trademarks of 360 Systems

Software contained in this product is copyrighted by 360 Systems, Microware Systems Corp.

Designs incorporated in this product are the subject of current or pending U.S. and foreign patents.

Limited Warranty

Instant Replay is warranted against defects in material and workmanship for a period of one year from date of original purchase. This warranty includes parts and labor.

This warranty excludes units that have been modified, repaired by unauthorized personnel, or damaged by abuse, improper operation, dirt, or static electricity.

360 Systems assumes no liability whatsoever for real or consequential damages, loss of profits, inconvenience or any other losses due to non-operation of the Instant Replay.

360 Systems' sole liability under this limited warranty shall be the repair or replacement of defective product or components. Products being returned under warranty shall be sent to 360 Systems or one of its foreign service centers, freight prepaid in the original or equivalent packaging.

Printing history:

Software 2.1 February 2000

Software 2.3, October 2000

Software 3.47 April 2007

Copyright 1995-2007 360 Systems

Printed in the United States of America. All rights reserved.

TABLE OF CONTENTS

INTRODUCTION	7
CHAPTER 1 – OVERVIEW	8
FRONT PANEL CONTROLS	8
<i>Hot-Keys</i>	9
<i>Transport Control Buttons</i>	9
STOP	9
PLAY	9
RECORD	9
LOOP	9
PAUSE	9
<i>Metering and Level Controls</i>	10
<i>Function Buttons</i>	10
BANK SELECT	10
ASSIGN HOT-KEYS	10
PREVIEW	10
<i>Setup and Configuration Buttons</i>	10
MENU	10
CANCEL	11
<i>Scroll Up/Down Arrows</i>	11
FIND	11
ENTER	11
CHAPTER 2 – BASIC OPERATION	12
<i>Powering on Instant Replay</i>	12
<i>Connecting Instant Replay to External Audio Equipment</i>	13
<i>Recording a Cut</i>	14
<i>Limiting the Record Time of a Cut</i>	15
<i>Playing a Cut</i>	16
<i>Pausing a Cut</i>	16
<i>Erasing a Cut</i>	17
<i>Assigning a Cut to a Hot-Key</i>	17
<i>Using Hot-Key Banks</i>	18
<i>Replacing Cuts with Existing Hot-Key Assignments</i>	18
<i>Locating a Cut using FIND</i>	18
<i>Viewing the Sample Rate and Word Length of a Cut</i>	18
<i>Previewing a Cut</i>	18
<i>Looping a Cut</i>	19
Adjusting Output Gain on a Cut	19
<i>Using the Record Sample Rate Converter</i>	19
<i>Converting 24 bit material to 16 bits (Dither)</i>	20
<i>Using the Sample Rate Converter and Dither at the same time</i>	20
<i>Using the Playback Sample Rate Converter</i>	21
CHAPTER 3 – EDITING CUTS	22
<i>Using Head and Tail Trim</i>	22
<i>Setting the Head Trim</i>	22
<i>Setting the Tail Trim</i>	23
Setting the Pre-Roll before Setting the Tail Trim	23
Now Set the Tail Trim	23
Fade In	24
Fade Out	24
CHAPTER 4 – USING PLAYLISTS	26
<i>Creating a New Playlist</i>	26
<i>Editing a Playlist</i>	27
<i>Changing the Playlist Playback Order “On-the-Fly”</i>	27
<i>Playing a Playlist</i>	28

CHAPTER 5 – USING THE NETWORK.....	29
<i>Introduction</i>	29
<i>About WAV files</i>	29
<i>File Naming Conventions</i>	30
<i>Supported FTP Clients</i>	31
<i>Initial FTP Setup</i>	32
<i>Connecting to Instant Replay using FTP</i>	33
<i>Connecting to Instant Replay using a DOS Client</i>	34
<i>Downloading a file from Instant Replay to your host:</i>	34
<i>Uploading a file from your host computer to Instant Replay</i>	35
<i>Deleting a file from Instant Replay</i>	35
<i>Renaming a file on Instant Replay</i>	36
<i>Transferring Files with Flash FXP</i>	37
<i>Connect to Instant Replay</i>	37
<i>Upload/Download files</i>	38
<i>Renaming or Deleting a File using Flash FXP</i>	39
CHAPTER 6 – MACHINE SETUP MENU’S.....	40
<i>EDIT Menu</i>	40
<i>RECORD SETUP</i>	40
<i>NETWORKING Menu</i>	40
<i>OPERATIONS Menu</i>	40
<i>HOT-KEYS Menu</i>	41
CHAPTER 7 – THE REAR PANEL	42
ELECTRICAL POWER	42
<i>Power Switch</i>	42
<i>Fuses</i>	42
AUDIO CONNECTIONS	43
<i>Audio Inputs</i>	43
<i>Audio Outputs</i>	43
<i>Headphone Output</i>	43
DIGITAL AUDIO CONNECTIONS	43
<i>AES/EBU Input</i>	43
<i>IEC 958 Type II Input</i>	43
<i>Digital Audio Interfacing</i>	44
<i>Digital Audio Output</i>	44
<i>AES/EBU Output</i>	44
<i>IEC 958 Type II Output</i>	45
NETWORK CONNECTIONS	45
<i>Network Port</i>	45
CHAPTER 8 – MAINTENANCE AND DISK OPERATIONS	46
<i>FORMATTING THE INTERNAL HARD DISK</i>	46
<i>To Format the Internal Hard Disk</i>	46
INDEX	47

INTRODUCTION

Thank you for purchasing Instant Replay. The system provides a unique combination of mass storage, direct access to stored audio, network access and ease of operation, all in a professional quality package. Key features include:

- Storage of up to 1000 Audio Cuts
- At least 100 Hours of Storage
- Assignment of Cuts to 50 front panel Hot Keys
- Playlists that play a sequence of cuts manually or automatically
- 16 and 24 bit WAV support
- Head and Tail editing
- Variable fade in and fade out
- FIND function for locating cuts
- Familiar tape transport style controls to provide fast and sure operation
- Network Connectivity for uploading, downloading renaming and deleting Cuts.

CHAPTER 1 – OVERVIEW



FIGURE 1 - FRONT PANEL LAYOUT

FRONT PANEL CONTROLS

Instant Replay's front panel controls are shown in Figure 1. Most of the buttons include an indicator light to show when they are in use. They are functionally grouped as follows:

- Hot-Keys
- Transport Control
- Metering and Level Control
- Function Buttons
- Setup and Configuration Control

These controls are described briefly in this section.

Hot-Keys

There are three primary uses for Hot-Keys:

1. Triggering playback of assigned Cuts
2. As an alphanumeric keyboard
3. Bank selection, using the top row of keys

The main array of 50 buttons are Hot-Keys numbered 1 through 50. A Hot-Key's primary function is to trigger playback of a Cut assigned to it. Hot-Keys light up whenever their assigned Cut is playing.

In the Bank Select mode, the numbers 1 through 10 on the top row select the corresponding Banks numbered 1 through 10. The banks are like pages of Hot Keys. They extend the number of cuts that can be assigned to Hot Keys to 500 (50 Hot Keys times 10 Banks) and also provide a method for organizing cuts.

Transport Control Buttons

The Transport Controls include **STOP**, **PLAY**, **PAUSE** and **RECORD**. They perform in the traditional manner of tape recorders.

STOP

STOP Immediately ends recording or playback. **STOP** will halt some sequential operations, such as Network Transfers.

PLAY

PLAY Starts playback of the currently selected Cut. Note that pressing **PLAY** initiates playback from the beginning of the selected Cut, even if it is already playing. The exception is when **PLAY** is used to disengage **PAUSE**.

RECORD

RECORD Places Instant Replay in Record Ready mode. (Instant Replay will enter record when the **PLAY** button is pressed.)

LOOP

LOOP causes a Cut to repeat endlessly until either **STOP** or **LOOP** is pressed. **STOP** ends playback immediately. Pressing **LOOP** exits from the Loop mode, and allows the current Cut to continue playing to its end. Pressing **LOOP** while running a Playlist will cause the entire Playlist to loop.

PAUSE

PAUSE interrupts playback of a Cut. When pressed again, playback will resume.

Metering and Level Controls

Level Meters

The LEVEL METERS show the current record or playback level.

Input Level Controls

The Left and Right INPUT LEVEL Controls set the levels for recording. Set the levels so that the loudest part of your recording causes the first red segment of the meter to light. When turned all the way down, the input will be muted. The level controls do not apply to digital recording from the AES/EBU inputs.

Headphone Level Control

Sets the level of the HEADPHONE OUTPUT.

Function Buttons

BANK SELECT

The 50 Hot-Keys are further organized into 10 Banks. This allows 500 Cuts to be programmed into Hot-Keys. When you press the **BANK SELECT** button, it lights and the top row of Hot-Keys flash. The display changes to show the Number and Name of the current Bank; the number of Hot-Key Assignments it contains; and an indication of the presence of a Playlist in the Bank. Pressing Hot-Keys 1-10 will directly select the corresponding Bank.

ASSIGN HOT-KEYS

The **ASSIGN HOT-KEYS** button lights when pressed and the display prompts for selection of a HOT-KEY. Pressing a HOT-KEY immediately assigns the Cut shown in the top line of the display to that HOT-KEY, overwriting any previous assignment.

PREVIEW

When **PREVIEW** is pressed in Stop mode the main audio outputs are muted, so Cuts played subsequently can be auditioned from the headphone output only. Both the analog and digital audio outputs are muted.

Setup and Configuration Buttons

MENU

Pressing the **MENU** button will bring up all configurable items. As with most menus in equipment of this type, these are organized as nested menus. Once a menu option is selected, pressing **ENTER** will allow you to select a value for that option. Pressing **MENU** a second time will exit to normal operation. See Chapter 6, "Machine Setup Menus" for a listing of menu options.

Note: In this manual, MENU navigation is shown using arrows to indicate a new menu level. For example, **MENU->CONFIGURATION->PLAYBACK SAMPLE RATE** is telling the user to press **MENU**, scroll to the CONFIGURATION option, Press **ENTER**, then scroll to the PLAYBACK SAMPLE RATE menu item.

CANCEL

This button is used to end operations, exit menus, or to answer "no" to display prompts. In Playlist mode, **CANCEL** deletes the currently selected Step of the Playlist.

Scroll Up/Down Arrows

Used to select Cuts, Banks, Menus, Playlist Steps and adjust parameter values. Cuts can be selected during playback of other Cuts.

FIND

FIND searches for a Cut by Index Number or Name. When you press the **FIND** button, any previously found Cut name or ID number is displayed. To use that name for the current **FIND** simply press **ENTER**. To use a different Name or Index Number, simply type it and press **ENTER**.

ENTER

Used to enter Menus, initiate operations, confirm choices, and to answer "yes" to display prompts. In Playlist mode, pressing **ENTER** causes the selected Step to be set as the next Step to play. If the currently selected cut is displayed but not being played, pressing **ENTER** will momentarily display the sample rate and word length of the cut.

CHAPTER 2 – BASIC OPERATION

Instant Replay is an extensively featured, high quality professional audio workstation. However, it is also very simple and intuitive to use. The following sections cover Instant Replay's basic operation.

Powering on Instant Replay

CAUTION!
CONNECT THIS PRODUCT ONLY TO AN AC POWER SOURCE WITHIN THE VOLTAGE AND FREQUENCY RANGE INDICATED ON THE REAR PANEL. THE PRODUCT IS SUPPLIED WITH A DETACHABLE IEC TYPE AC LINE CORD APPROPRIATE TO THE COUNTRY TO WHICH THE UNIT WAS ORIGINALLY DELIVERED. CHECK TO SEE THAT IT MATCHES THE ELECTRICAL OUTLET YOU WILL BE USING.

- Connect the supplied power connector to the rear panel and plug it into an AC power outlet.
- Turn on the power switch located at the far right of the rear panel.
- Instant Replay will run through a power up sequence that includes lighting each front panel indicator in sequence.
- When it is ready to use, the **Display Module** will display the current selected Cut per Figure 2 below.
 - The Index number is a unique number associated with the file
 - The Cut Name is the user-supplied Cut Name.
 - The File Type indicates if the file is a WAV or DC2 file type.
 - The Duration indicates the length of the cut in minutes and seconds.
 - The Hot Key Bank/Number indicates the Hot Key Bank and number the cut is assigned to. 01-00 Indicates it has NOT been assigned to a hot key.




FIGURE 2 – THE DISPLAY MODULE

Instant Replay ships with a large number of sample cuts you can use to try it out. If there are no cuts available the Display Module will display:

NO CUTS AVAILABLE

Connecting Instant Replay to External Audio Equipment

The rear panel of the Instant Replay is shown in Figure 3.

Connecting Input Sources

Connect Balanced stereo analog sources to the BALANCED INPUT stereo pair.

Connect Un-balanced stereo analog sources to the UNBALANCED IN stereo pair.

Note: These inputs are mixed together internally and are both active whenever the AUDIO Input is set to ANALOG.

Connect a digital AES/EBU source to the AES/EBU DIGITAL IN connection.

Connect a digital IEC-958 RCA source to the IEC-958 II RCA jack.

The input source used for recording is selected via the AUDIO INPUT menu under the RECORD SETUP. See Page 14.

Connecting Monitoring Equipment

Connect Balanced stereo analog monitors to the BALANCED OUTPUT stereo pair.

Connect Un-balanced stereo analog monitors to the UNBALANCED OUT stereo pair.

Connect a digital AES/EBU monitor to the AES/EBU DIGITAL OUT connection.

Connect standard stereo headphones to the 1/4" headphones jack (far left).

Cuts will be played on all outputs at all times with one exception. When the PREVIEW key is lighted, Cuts will be played only to the headphone output.

Refer to Page 43 for technical details about audio connections.




FIGURE 3 - INSTANT REPLAY REAR PANEL

Recording a Cut

The Model DR-600 stores at least 130 hours of stereo audio. Total storage capacity varies according to the type of cuts you create. Individual Cuts can be from about 4 hours to about 7 hours long depending on the Recording Format you select.

Table 1 indicates the types of Cuts you can create and their associated durations in hours, minutes and seconds (HHH:MM:SS).

Sample Rate	Word Length	Format	Max Record Time Per Cut	Total Record Time
44.1K	16	WAV	06:45:41	216:44:53
44.1K	24	WAV	04:30:27	142:14:23
48K	16	WAV	06:12:44	195:12:05
48K	24	WAV	04:08:29	130:35:50
44.1K	16	DC2	06:45:41	216:44:53
48K	16	DC2	06:12:44	195:12:05

Table 1

Note: The quality of 16 bit WAV and DC2 are identical. The only reason to use DC2 format is for compatibility with the *DigiCart E* product.

WARNING

Note that while you can have Cuts recorded in any of the formats stored in the unit, it is best not to mix formats on a particular project. Switching from a 48K Linear to 44.1 will cause the output sample rate to change, causing possible disturbance of equipment monitoring the digital outputs. In most cases, the Playback sample rate converter may be used to maintain a constant output rate regardless of the sample rate of the original Cut. (See Page 21).

NOTE

The Balanced and Unbalanced analog inputs are mixed together. It is not recommended that both be connected at the same time, unless one or the other is muted.

To Record A Cut:

Disable the RECORD ERASE LOCKOUT if necessary

Press **MENU->RECORD SETUP->RECORD/ERASE LOCKOUT** then **ENTER**

The parameter should be set to OFF.

Select an Input Source

Press **MENU->RECORD SETUP->AUDIO INPUT** then **ENTER**

Select ANALOG to use the BALANCED inputs or UNBALANCED I/O inputs.

Select AES/EBU XLR-3 To use the digital AES/EBU inputs.

Select IEC-958 TYPE II to use the IEC-958 II Input

with Consumer format digital audio sources.

Select AES/SMPTE-75 OHM RCA to use the IEC-958 II Input

with Professional format digital audio sources.

Adjust Levels in Record Standby Mode

Press **RECORD** to enter Record Standby. You can monitor levels and set input level controls (Analog inputs only) before beginning to record.

Begin Recording

Press **PLAY** to begin recording.

Press **STOP** to stop recording.

A default cut name, such as NEW001 will be provided. Press **ENTER** to accept the name or type in a new name using the alphanumeric and scroll keys, then press **ENTER**.

Limiting the Record Time of a Cut

You can limit the maximum record time of a cut to 5 minutes, 30 minutes or 1 hour. This is useful if you want to make a longer recording and don't want to wait for it to finish before stopping the recording. Once the Record Time Limit is set, it will apply to all recordings until it is specifically disabled.

All of the record time limits allow a little extra than the time advertised. For example, a time limit of 5 minutes will actually allow you to record for nearly six minutes.

To set a Record Time Limit:

Press **MENU->RECORD SETUP->RECORD TIME LIMIT** then **ENTER**

Select NONE, 5,30 or 60 minutes. Press **ENTER**.

Playing a Cut

There are a number of ways to play a cut.

Play a Cut Using a Hot Key

If the cut has been assigned to a Hot Key, simply press the hot key to play the cut. Refer to *Assigning A Cut To a Hot Key* on Page 10 for instructions on assigning a cut to a Hot Key.

Play a Cut by selecting the cut in the Display Module window

A cut that is currently displayed on the Display Module can be played simply by Pressing **PLAY**. To display a cut in the Display Module, use the **SCROLL KEYS**.

To locate a cut by name or index number, use the **FIND** key. Refer to *Locating A Cut Using FIND* on Page 18.

Play a Cut Using the rear-panel GPI

Instant Replay includes a General Purpose Interface (GPI) that duplicates the PLAY button. It is on a 1/8" mini phone jack on the back panel. Connect a momentary switch (console button, footswitch, etc.) to the back panel jack marked GPI/PLAY. This must be enabled before it can be used.

To enable GPI, press **MENU->CONFIGURATION->GPI INPUT** then **ENTER**

Select **ENABLE** using the **SCROLL KEYS**. Press **ENTER**

When you activate the remote momentary switch, Instant Replay will behave as if you had pressed **PLAY**. You can also initiate recording remotely by putting Instant Replay in Record Ready and activating the remote switch.

Note that activating the remote switch will also **CANCEL PAUSE** if it is active. While Instant Replay is Paused, pressing a Hot-Key displays the Assigned Cut's title and statistics but does not play it. This lets you check the Hot-Key assignment silently, and is most useful in a live broadcast or performance application. For example, an engineer can find and cue up a Hot-Key Cut to be played, and on-air talent can start playback with the remote switch.

Pausing a Cut

Press **PAUSE** TO interrupt playback of a Cut. Press **PAUSE** again to resume playback.

TIP:

Note that while Instant Replay is paused, pressing a Hot-Key displays the Assigned Cut's title and statistics, but the Cut will not play until **PAUSE** or **PLAY** is pressed. Several Hot-Keys can be pressed in series to see what Cuts are assigned to them, allowing the Hot-Key Assignments to be reviewed silently. Only the last one pressed will play when Pause is released.

Erasing a Cut

Erasing a cut will permanently delete the cut from the disk. There are two ways to erase a cut.

1. From the Display Module Menu Front Panel
2. Using FTP with the network connection.

The Display Module method works fine for most cases. If you need to erase a lot of cuts, it may be easier to use the network connection. See the example of this on Page 35.

To ERASE a Cut using the Display Module Front Panel:

Disable the RECORD ERASE LOCKOUT if necessary

Press **MENU->RECORD SETUP->RECORD/ERASE LOCKOUT** then **ENTER**

The parameter should be set to OFF.

Select the cut

Select the cut in the Display Module window using the SCROLL KEYS.

Erase the Cut

Press **MENU->OPERATIONS->ERASE** then press **ENTER**.

Instant Replay will Prompt

ARE YOU SURE?

PRESS ENTER/CANCEL

Press **ENTER** to erase the cut. Press **CANCEL** to cancel the operation.

If you pressed **ENTER**, Instant Replay will scroll to the next cut. By pressing **ENTER** twice you can erase this cut as well, then the next cut and so on. This is a good way to get rid of lots of cuts at once.

Assigning a Cut to a Hot-Key

The **ASSIGN HOT-KEY** button lights when pressed and the display prompts for selection of a **HOT-KEY**. Pressing a **HOT-KEY** immediately assigns the Cut shown in the top line of the display to that **HOT-KEY**, overwriting any previous assignment.

You do not need to clear a Hot-Key before assigning a new Cut, assignments can be simply overwritten.

The same audio Cut may be assigned to keys in different banks. If a Cut is assigned to keys in several different banks, reassigning a new Cut to one key will not disturb assignments in other banks. For example, if a station ID is assigned to Hot-Key #1 in each of four different banks (1, 2, 3, and 4), and you reassign Hot-Key #1 in bank 4 to a different Cut, then the station ID remains assigned in banks 1, 2, and 3.

You can select other Cuts to be assigned using the SCROLL ARROW keys or **FIND**. With the new Cut selected, press the **HOT-KEY** you wish to assign it to.

To exit, press **ASSIGN HOT-KEY** again, or **CANCEL**.

Using Hot-Key Banks

There are ten Banks numbered 1 to 10. Each Bank is like a separate “page”; changing Banks is equivalent to flipping a page, and presents a different set of Hot-Key Assignments. Note that the ten Banks all have access to all the Cuts recorded in Instant Replay. Banks are a convenient way to organize Instant Replay’s audio collection. A total of 500 Cuts can be assigned to Hot-Keys if all 50 keys in each of the 10 banks are assigned to a different Cut.

Replacing Cuts with Existing Hot-Key Assignments

When audio that is assigned to Hot-Keys is replaced by any means (FTP Upload or Record Overwrite) the Hot-Key assignments will still exist, and will be assigned to the new audio. This allows material to be updated without the need for manually reassigning Hot-Keys. For instance, hourly promos can be named for their time slot and day of the week. Each week the new promos can be loaded in over the network and will appear at the same places in *all* Banks and Playlists.

Locating a Cut using FIND

FIND searches for a Cut by Index Number or Name. When you press the **FIND** button, any previously found Cut name or ID number is displayed. To use that name for the current **FIND** simply press **ENTER**. To use a different Name or Index Number, simply type it and press **ENTER**.

Cuts can be located by entering part of the name followed by the Asterisk key (“*”, Hot-Key number 40). In the event many Cuts exist with almost the same name, they will be found in alphabetical order with each subsequent use of the Find command. The Scroll Arrows may be used to examine all similar entries when the Sort By Name option is active in the configuration menu.

Viewing the Sample Rate and Word Length of a Cut

With the Cut selected on the display module but NOT playing, hit the **ENTER** key briefly. The Sample Rate (44.1KHz or 48KHz) and word length (16 bit or 24 bit) will be displayed for 2 seconds in place of the cut name.

Previewing a Cut

When **PREVIEW** is pressed in Stop mode the main audio outputs are muted, so Cuts played subsequently can be auditioned from the headphone output only. Both the analog and digital audio outputs are muted.

If **PREVIEW** is turned on during playback, the display changes from showing the current Cut and playing time, to showing the ID Number, Name, Length and Hot-Key Assignment of the playing Cut. The Cut will continue playing from both the main and headphone outputs. Other Cuts can be selected using the Scroll Arrows, Find, or the Hot-Keys to view their information.

TIP: Using Preview to Find Unassigned Hot-Keys

<p>PREVIEW is useful when assigning Hot-Keys to find an unassigned or unneeded key without losing track of the Cut you are about to assign. Before pressing ASSIGN HOT-KEY, press PREVIEW and then push HOT-KEYS until you find one that can be re-used or that is unassigned. Press STOP if a Cut is still playing, then press PREVIEW again. The Cut to be assigned reappears. Use the normal Assign Hot-Key procedure to assign the Hot-Key you found.</p>

Looping a Cut

LOOP causes a Cut to repeat endlessly until either **STOP** or **LOOP** is pressed. **STOP** ends playback immediately. Pressing **LOOP** exits from the Loop mode, and allows the current Cut to continue playing to its end.

While a Cut is looping, another Cut can be selected for playback. A different Hot-Key can also be played. The new Cut will immediately start from the beginning, and will also loop until Loop mode is exited.

Looping works in all modes. You can loop a single Cut, or an individual Cut in a Manual-Step Playlist. Turning Loop on during playback of a Follow-On Playlist causes the entire list to loop.

Adjusting Output Gain on a Cut

Cuts also contain an Output Gain value, which allows you to adjust and store the playback level after the recording has been made. You can adjust output gain in 1 dB increments from +6 dB (twice as loud) to -90 dB, which is close to the softest sound that can be recorded.

Go to **MENU->EDIT->ADJUST OUTPUT GAIN**. Then press **ENTER**

ADJUST OUTPUT GAIN
0 dB

The cursor will blink over the value to be changed. Use the **SCROLL** keys to make an adjustment to the numeric value. Press **ENTER** to accept the displayed value.

Press **MENU** or **CANCEL** to return to previous menu level.

Using the Record Sample Rate Converter

What the Record Sample Rate Converter does.

If you are recording material using the digital (AES/EBU or IEC958 II) inputs, you can ensure that it will be recorded at the sample rate you have selected, even if the incoming material is at a different sample rate. The sample rate converter can do the following.

1. Convert 44.1K digital content to 48K
2. Convert 48K digital content to 44.1K

For example, assume your **RECORDING FORMAT** is set to 44.1K 16 Bit WAV and your input source is the AES/EBU inputs. The digital source is clocking at a 48K sample rate. If the Sample Rate Converter is enabled, the incoming 48K signal will be converted to your selected 44.1K format. Likewise, if the **RECORDING FORMAT** is set to 48K, an incoming signal clocking at 44.1K will be converted to 48K if the Sample Rate Converter is enabled.

Note: The Sample Rate Converter has no effect if you are using the balanced or unbalanced analog inputs for recording.

To Enable the Sample Rate Converter:

Press **MENU->RECORD SETUP->DIG INPUT PROCESS ->SAMPLE RATE CONVERT**

Then Press **ENTER**.

Converting 24 bit material to 16 bits (Dither)

If you are recording material using the digital (AES/EBU or IEC958 II) inputs, you can convert 24 bit material to 16 bit material using the dither option. Dither is a professional audio technique for data reduction that results in an extremely high quality content at a reduced data rate.

To Enable dither:

Press **MENU->RECORD SETUP->DIG INPUT PROCESS->DITHER 24BIT -> 16BIT**

Then Press **ENTER**.

Note: The Dither setting has no effect if you are using the balanced or unbalanced analog inputs for recording.

Note: Enabling dither if you are using a 16 bit digital source is unnecessary and will slightly increase noise level.

Using the Sample Rate Converter and Dither at the same time

The Dither option and the Sample Rate Converter can be used at the same time. This would be appropriate under the following conditions.

1. You are using the digital (AES/EBU or IEC958 II) inputs.
2. You are recording from a 24 bit source and want to convert it to 16 bits.
3. You want to convert the sample rate of the input source.

To Enable dither and the sample rate converter at the same time:

Press **MENU->RECORD SETUP->DIG INPUT PROCESS->DITHER->16BIT + SRC**

Press **ENTER**.

Using the Playback Sample Rate Converter

There are three ways to set the sample rate of a Cut being played.

1. At the same sample rate it was recorded
2. At a specified sample rate (44.1K or 48K)
3. At a rate determined by the AES/EBU or IEC958 II input clock

To play a cut at a user-specified sample rate.

Press **MENU->CONFIGURATION->PLAYBACK SAMPLE RATE** Then Press **ENTER**

- Select OUTPUT AT 48K to play the cut at 48Kb/S
- Select OUTPUT AT 44.1K to play the cut at 44.1Kb/S
- Select SYNC TO DIGITAL IN to play the cut at the rate of the AES/EBU or IEC958 II input clock
- Select AS RECORDED to play the cut at the rate it was recorded (this is the default)

Press **ENTER** to complete the selection

CHAPTER 3 – EDITING CUTS

Instant Replay features the following cut editing operations.

1. Adjustable Head Trim
2. Adjustable Tail Trim
3. Variable length Fade In
4. Variable length fade out

Using Head and Tail Trim

You can perform precise Head and Tail Trims on an existing file or immediately after recording a new cut. Head trim is a means of chopping off some content at the start of the cut. Usually, this is used to remove unwanted sound at the start of the cut to provide a smooth sounding cut.

Tail Trim performs the identical function, but at the end of the cut.

Head and Tail trim can be performed in one of two ways.

1. By manually entering a trim time.
2. By playing the cut and marking the trim points as it plays.

Head and Tail trims can be as short as a tenth of a second. Head and Tail Trims can be as long as the cut, as long as the two trim points do not overlap.

Setting the Head Trim

Head trim can be performed in one of two ways.

1. If “Prompt for Head/Tail” is ENABLED in the RECORD SETUP, you will be automatically prompted to enter head trim after a new recording is created.
2. Select an existing cut in the display module then press :

MENU->EDIT->SET HEAD TRIM.

The only difference between the two methods is that after a new recording you will be prompted to enter both a head and tail trim.


The Head Trim editor display looks like this. The display is in Hours, Minutes, seconds and hundredths of a second.



Hit **ENTER** to leave head trim unchanged. The Head Trim is set 00:00:00.00, which is no trim.

Or... Type in the amount of time you want to trim off the head of the cut using the alphanumeric keypad. The value is in hours, minutes, seconds and hundredths of a second. Use the < and > keys to move forward and backwards if necessary. Hit **ENTER** once you have entered the Head trim delay you want.

Or... Hit the **PLAY** key to begin playing the cut. Hit **ENTER** or **STOP** to pause playback. Hit **ENTER** again to accept the trim at the paused location or manually type a value and hit **ENTER**. The display will look like this as the cut is playing in edit mode. The top set of counters will indicate your current position in the clip. The bottom set of counters will indicate the current Head Trim setting. If you have never set the Head Trim, this will be zero.



Setting the Tail Trim

Tail trim can be performed in one of two ways.

1. If “Prompt for Head/Tail” is ENABLED in the RECORD SETUP, you will be automatically prompted to enter tail trim after a new recording is created.
2. By selecting a cut in the display module, and Selecting TAIL TRIM from the EDIT menu.

The only difference between the two methods is that after a new recording you will be prompted to enter both a head and tail trim.

Setting the Pre-Roll before Setting the Tail Trim

Before Entering the Tail Trim time, you may want to set the Pre-Roll. This sets the length of time counting backward from the end of the file that the cut will begin playing if you want to set Tail Trim in real-time mode. Pre-Roll is useful on longer cuts, because you can start playback a few seconds before the end instead of listening to the entire cut to mark your tail trim point.

To set the Pre-Roll, Type **EDIT->SET TAIL PRE-ROLL**. The pre-roll defaults to 5 Seconds. If this is ok, you can skip this step. Otherwise, set it to any value that is less than the length of the cut.



If you prefer a different default pre-roll, you can edit the default pre-roll setting under:

CONFIGURE->TAIL PRE-ROLL



This will change the initial pre-roll setting on all unedited cuts to the new default.

Now Set the Tail Trim

To set the Tail-Trim, Type **MENU->EDIT->SET TAIL TRIM**. The Tail Trim editor display looks like this. The counter indicates the current length of the cut.

00:00:22.60 TAIL
ENTER/ADJUST OR PLAY

Hit **ENTER** to leave tail trim unchanged.

Or... Type in the amount of time you want to trim off the tail of the cut using the alphanumeric keypad. The value is in hours, minutes, seconds and hundredths of a second. Hit **ENTER** once you have entered the tail trim value you want.

Note: Tail Trim is entered as a new cut length. For example, if the cut is 00:22.60 long, and you want to cut 2 seconds off the tail, enter 00:20.60 in the edit menu.

Or... Hit the **PLAY** key to begin playing the cut. The cut will begin at the end of the cut, minus the current setting of pre-roll. For example, if the cut 00:22.60 long and Pre-Roll is set to 5 Seconds, the cut will begin playing at 00:17.60. You can listen to the cut and hit **ENTER** at the point you want to trim. Hit **ENTER** again to accept the change.

Fade In

To set the fade-in, press **MENU->EDIT->SET FADE IN** then press **ENTER**

Enter a new fade in time then press **ENTER**. Fade values are expressed in duration of the fade. Fades are limited to a maximum length of 40 seconds.

00:00.00 FADE IN
ENTER/ADJUST OR PLAY

Press **MENU** or **CANCEL** to return to previous menu level.

Or

Press the **PLAY** key to start playback, the displayed Head Point time value will increase from the current Head Point position. During this time, press the **ENTER** key to capture a new value for the end of the Fade In "On-the-Fly". You may then make fine adjustments using the **SCROLL** and **CURSOR** keys. Press **ENTER** again to save the setting, or press **CANCEL** to revert to the original Fade In point.

Press **MENU** or **CANCEL** to return to previous menu level.

Fade In is limited to a maximum length of 40 seconds.

Fade Out

To set the Fade Out Press **MENU->EDIT->SET FADE OUT** then press **ENTER**

00:00.00 FADE OUT
ENTER/ADJUST OR PLAY

Press the **ENTER** key to make an adjustment. Fade values are expressed in duration of the fade. Fades are limited to a maximum of 40 seconds.

Press the **ENTER** key, then use the **CURSOR** keys to move the cursor to the digit to be adjusted. Then use the **NUMERIC** keys (top row of Hot-Keys), or the **SCROLL** keys to make an adjustment to the numeric value.

Press **MENU** or **CANCEL** to return to previous menu level.

Or

Press **PLAY** to start playback, the displayed Fade Out time value will increase from the Pre-roll position to the End-of-File. During this time, press the **ENTER** key to capture a new value for the beginning of the Fade Out “On-the-Fly”. You may then make fine adjustments using the **SCROLL** and **CURSOR** keys. Press **ENTER** again to save the setting, or press **CANCEL** to revert to the original Fade Out point.

Press **MENU** or **CANCEL** to return to previous menu level.

CHAPTER 4 – USING PLAYLISTS

Playlists allow you to create and playback a sequence of Cuts that are assigned to Hot-Keys. You can set Playlists for Follow-On or Manual-Step playback. Refer to the section Creating a New Playlist, immediately below.

In Manual-Step mode, the playlist will pause after each cut until you press **PLAY**. In follow-on mode, the playlist will play all cuts to the end of the playlist.

You can create one Playlist for each Bank.

Creating a New Playlist

Set the Bank

Instant Replay has 10 Hot-Key banks. Each bank of Hot-Keys can have it's own Playlist. You can tell what bank you are currently on by pressing the **BANK SELECT** key. The keys 1 through 10 will blink with the exception of the key denoting the current bank, which will be solid. If you want to make a playlist for a different bank than the current bank, simply hit the numbered key for the bank you want to make a playlist for.

Clear the Playlist

If a Playlist is already assigned to the selected BANK, pressing **PLAYLIST** will indicate the first Cut in the Playlist and the Hot-Key the cut it is assigned to will blink. To create a new playlist in its place, you need to clear the playlist. . If **PLAYLIST PROTECTION** is ON, the Playlist cannot be cleared.

Press **MENU->PLAYLIST** then **ENTER**.

The Display Indicates:

Clear Playlist?

Press **ENTER**

The Display Indicates:

Are you Sure?

Press **ENTER**

The Display Indicates:

Playlist Cleared

Assign Cuts to the Playlist

Press **PLAYLIST**

The Display Indicates:

**LIST IS EMPTY
SELECT HOT KEY**

Press the HOT-KEYS you want to assign to the playlist in sequence.

Press **PLAYLIST** to complete the operation.

Set the Playlist to **MANUAL STEP** or **FOLLOW-ON**

The Playlist will be **MANUAL STEP** by default. This means it will pause after each Cut until you press **PLAY**. Changing the Playlist to **FOLLOW ON** mode will allow it to play all cuts on the list in sequence without operator intervention.

To change the Playlist to **FOLLOW-ON**, Press **PLAYLIST**. Scroll with the down arrow to the beginning of the playlist.

The Display Indicates:

**START OF PLAYLIST
MANUAL STEP**

Press **ENTER**.

Scroll to **FOLLOW ON**.

Press **ENTER**.

Editing a Playlist

Remove a Step from a Playlist

To remove a Step from the Playlist, use the **SCROLL ARROWS** to select the Step, then press **CANCEL** to remove it from the list. Press **ENTER** to confirm, or **CANCEL**.

Append a Step to a playlist

To append a Step to the end of the Playlist, **SCROLL** to the end of the list and press additional **HOT-KEYS** to add additional Steps.

Changing the Playlist Playback Order “On-the-Fly”

The **SCROLL ARROWS** and **ENTER** key can be used in real time to change the sequence in which the Cuts are played. At any time you can **SCROLL** through the list. If you then press **ENTER**, the step you selected will be played next, and the Playlist will continue from that point onward. You can **SCROLL UP** the list, effectively skipping steps in the Playlist, or you can **SCROLL DOWN** to repeat steps. This can be done while stopped or during playback. When a Cut is playing (and Playlist is not enabled), pressing the **PLAYLIST** key enables the Playlist mode and “cues up” the first Cut of the Playlist. The current Cut will play to completion and the button corresponding to the first Cut in the Playlist will flash. However, the Playlist will not execute until you press **PLAY**, even if it is a Follow-On Playlist.

Playing a Playlist

Select the BANK if necessary. Press **PLAYLIST**, then press **PLAY**. To Halt the Playlist, Press **PLAYLIST** again. The current cut will play to completion, then play will stop.

Looping a Playlist

Press **LOOP** at any time to cause a playlist to loop. The playlist will continue to loop until you press **LOOP** again to deactivate looping.

Protecting a Playlist

Turning playlist protection on will lock the current Playlists. They cannot be edited or deleted until protection is turned back off. To enable playlist protection:

Press **MENU->PLAYLIST->PLAYLIST PROTECTION**

Select ON. Press ENTER

CHAPTER 5 – USING THE NETWORK

Introduction

Instant Replay offers 10/100 ethernet connectivity using an RFC-1359 compliant FTP server. This allows you to connect to Instant Replay from a host computer using most commercially available FTP clients. Using FTP, you can do the following.

-  Rapidly Download Cuts, including WAV cuts, from Instant Replay to your computer.
-  List Cuts
-  Rename Cuts
-  Delete Cuts

Important: Instant Replay can only perform FTP transfers while in FTP Mode. Record and Playback cannot be performed while in FTP Mode. Pressing **STOP** at any time will abort FTP Mode, allowing Record and Playback operations to resume. If an FTP transfer is in progress when **STOP** is pressed it will be aborted. Pressing **STOP** while an FTP transfer is in progress will also DISABLE FTP Mode. Refer to Page 30 for instructions on entering FTP Mode.

Note: Instant Replay has a “flat” file system. All cuts must reside in the “root” directory. Instant Replay will not allow you to create sub-directories using FTP.

About WAV files

Exporting WAV Cuts

Instant Replay can record 16 and 24 bit WAV files at sample rates of 44.1 or 48Khz. Using FTP, these cuts can be exported and played on a Personal Computer or any device capable of playing WAV files. Refer to *Downloading a File From Instant Replay* on Page 31.

Note: Many Personal Computers do NOT support 24 Bit WAV files. If 24 bit WAV files created on Instant Replay will not play on your personal computer, check to see if your sound card supports 24 bit WAV files.

Importing WAV Cuts

Instant Replay can also import WAV files from a personal computer and play them. Refer to *Uploading a File From Your Host To Instant Replay* on Page 32.

Note: Many “stock” WAV files on Personal Computers are recorded at a sample rates other than 44.1K or 48KHz. These cannot be uploaded or played. The following message will be displayed if you upload a WAV file that is not 44.1 or 48KHz.

SAMPLE RATE UNAVAIL

File Naming Conventions

Instant Replay filenames must be 15 characters or less, not counting the file suffix (e.g. WAV,DC2). Alphanumeric characters, hyphens, spaces and underscores are allowed.

Each file on Instant Replay is referenced by a user-supplied file name and a unique index number. Files of the same name are not allowed for the same file type (WAV or DC2). The one exception is noted below.

Note: Files originated on other equipment that have filenames longer than 15 characters will be truncated to 15 characters when they are uploaded to Instant Replay. A ‘~’ character will indicate the file was originally longer than 15 characters.

For Example:

1234567890abcdefghijklmn.wav

Will be truncated to:

1234567890abcd~.wav

Note: Uploading groups of files with long but similar file names may result in many cuts having the same name. This is the only case in which identical file names are allowed.

For Example:

Upload the following three files.

123456789abcdef_01.wav
123456789abcdef_02.wav
123456789abcdef_03.wav

They will all be named 123456789abcde~.wav. However, they will all have a unique index number and, often, a unique duration, so they can be identified on the local Display Module. You may then rename them if you so desire, using the local Display Module or using the FTP client.

On the Local Display Module the '~' character looks like a little superscript square.

Supported FTP Clients

Instant Replay includes an RFC-1359 compliant FTP server. The user connects to the FTP server using a commercially available FTP client. Most FTP clients should work with Instant Replay, but it has been tested with the following products. Table 2 indicates approved FTP clients.

FTP Client	Version	Platform
Flash FXP	3.2.0	WINDOWS XP, WIN2K
DOS FTP	XP Version 5.1.2600	WINDOWS XP, WIN2K
WS FTP	5.08	WINDOWS XP, WIN2K

Table 2 – Approved FTP Clients

Initial FTP Setup

Connect the ethernet cable

Connect a Standard RJ45 Ethernet cable between to the rear panel connector marked NETWORK. Connect the other end to your network. If the cable is connected correctly, the green LINK LED directly above the cable port will turn ON. If the green LED is not ON, check the cable polarity, cable continuity or network connection.

Set the FTP User ID

Optionally enter a new login User ID. The default User ID is **360USER**.

Press **MENU**. Use the SCROLL and **ENTER** keys to navigate the menus as shown.

Networking->FTP USERNAME

Press **ENTER** then type in a user ID. Use up to 11 numbers and letters in any combination.

Press **ENTER**

Set the FTP password

Optionally enter a new login password. The default password is **PASSWORD**.

Press **MENU**. Use the SCROLL and **ENTER** keys to navigate the menus as shown.

Networking->FTP PASSWORD

Press **ENTER** then type in a password. Use up to 11 numbers and letters in any combination.

Press **ENTER**

Set the IP Address

Optionally enter a new FTP IP Address. The default IP Address is **192.168.1.100**.

Networking->FTP IP Address

Press **ENTER** then type in a new IP address. Any IP address is allowed.

Press **ENTER**.

OR...Automatically acquire an IP address using DHCP

Optionally, Instant Replay can acquire it's IP address from a DHCP server.

Networking->DHCP Enable

Select **ON**. Press **ENTER**

NOTE: If DHCP is enabled, Instant Replay will acquire it's IP address when FTP Mode is turned on. The address will be momentarily displayed when FTP Mode is enabled.

WARNING: If you are connecting over a network that has more than one network device attached to it, use caution when setting the IP address. If the IP address you select conflicts with another device having the same address, unstable operation of either device may result.

Set the Subnet Mask

Optionally enter a new FTP Subnet mask. The default subnet mask is **255.255.255.0**.

Networking->FTP Subnet Mask

Hit **<ENTER>** then type in a new subnet mask.

TIP: Don't set the subnet mask unless you need to.

Note: If you don't know what a subnet mask is, don't change it. Chances are, the default will work on your network.

Enable FTP MODE

The FTP Server is only turned on when it is in use.

Press **MENU**. Use the **SCROLL** and **ENTER** keys to navigate the menus as shown.

Networking->FTP Mode

Press **ENTER**. Use the scroll keys to set it to **ON**.

Press **ENTER**.

Press **MENU**.

The Display will indicate **FTP MODE ON!**

Hit **STOP** at any time to exit FTP Mode. Hitting **STOP** while a transfer is in progress will **CANCEL** the transfer.

Connecting to Instant Replay using FTP

Note: These instructions will vary according to the FTP client you select. The example uses a Windows XP/ Win 2K DOS FTP Client

Note: Make sure your Instant Replay is at the Top Level menu. Press **CANCEL** a few times if you are not sure.

Connecting to Instant Replay using a DOS Client.

1. From a Windows XP or Windows 2K environment, open a DOS Shell as follows.

START->All Programs->Accessories->Command Prompt


From the command prompt, type

ftp <IP ADDRESS>

...where the IP ADDRESS is the address you set your Instant Replay to in the Initial Setup step. For example 192.168.1.120 would be a valid entry. The display will do the “dots” for you.

2. Type in USER ID when Prompted.

3. Type in the PASSWORD when prompted.



```
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\>ftp 192.168.1.16
Connected to 192.168.1.16.
220 RT-IP FTP Server ready. Type HELP for help
User (192.168.1.16:(none)): FACTORY
331 User name okay, need password.
Password:
230 User logged in, proceed.
ftp> ls
200 Command okay.
150 File status okay; about to open data connection.
COWBELL
DMP
BOING
DING
226 Closing data connection. Transfer succeeded
ftp: 27 bytes received in 0.17Seconds 0.16Kbytes/sec.
ftp>
```

Downloading a file from Instant Replay to your host:

Log in per the example above. Type:

Get <FILENAME>

At the FTP prompt:

```
Command Prompt - ftp 192.168.1.16
C:\>ftp 192.168.1.16
Connected to 192.168.1.16.
220 RT-IP FTP Server ready. Type HELP for help
User (192.168.1.16:(none)): FACTORY
331 User name okay, need password.
Password:
230 User logged in, proceed.
ftp> ls
200 Command okay.
150 File status okay; about to open data connection.
COWBELL
DMP
BOING
DING
226 Closing data connection. Transfer succeeded
ftp: 27 bytes received in 0.16Seconds 0.17Kbytes/sec.
ftp> get DMP
200 Command okay.
150 File status okay; about to open data connection.
226 Closing data connection. Transfer succeeded
ftp: 2514944 bytes received in 5.11Seconds 492.26Kbytes/sec.
ftp> exit
Invalid command.
ftp>
```

Uploading a file from your host computer to Instant Replay

Log in per the example above. Type:

put <FILENAME>

At the FTP prompt:

```
Command Prompt - ftp 192.168.1.16
Y:\>c:
C:\>ftp 192.168.1.16
Connected to 192.168.1.16.
220 RT-IP FTP Server ready. Type HELP for help
User (192.168.1.16:(none)): FACTORY
331 User name okay, need password.
Password:
230 User logged in, proceed.
ftp> put SIREN
200 Command okay.
150 File status okay; about to open data connection.
226 Closing data connection. Transfer succeeded
ftp: 2287616 bytes sent in 2.97Seconds 770.50Kbytes/sec.
ftp> ls
200 Command okay.
150 File status okay; about to open data connection.
SIREN
DMP
BOING
DING
COWBELL
226 Closing data connection. Transfer succeeded
ftp: 34 bytes received in 0.14Seconds 0.24Kbytes/sec.
ftp>
```

Deleting a file from Instant Replay

Log in per the example above. Type:

Del <FILENAME>

At the FTP prompt:

```
c:\ Command Prompt - ftp 192.168.1.16
220 RT-IP FTP Server ready. Type HELP for help
User (192.168.1.16:(none)): FACTORY
331 User name okay, need password.
Password:
230 User logged in, proceed.
ftp> ls
200 Command okay.
150 File status okay; about to open data connection.
FIRE
BOING
DING
COWBELL
226 Closing data connection. Transfer succeeded
ftp: 28 bytes received in 0.22Seconds 0.13Kbytes/sec.
ftp> del DING
250 Requested file action okay, completed.
ftp> ls
200 Command okay.
150 File status okay; about to open data connection.
FIRE
BOING
COWBELL
226 Closing data connection. Transfer succeeded
ftp: 22 bytes received in 0.20Seconds 0.11Kbytes/sec.
ftp>
```

Renaming a file on Instant Replay

Log in per the example above. Type:

rename <CURRENT FILENAME> < NEW FILENAME >

At the FTP prompt:

```
c:\ Command Prompt - ftp 192.168.1.16
230 User logged in, proceed.
ftp> ls
200 Command okay.
150 File status okay; about to open data connection.
SIREN
DMP
BOING
DING
COWBELL
226 Closing data connection. Transfer succeeded
ftp: 34 bytes received in 0.20Seconds 0.17Kbytes/sec.
ftp> rename SIREN FIRE
350 Requested file action pending further information.
250 Requested file action okay, completed.
ftp> ls
200 Command okay.
150 File status okay; about to open data connection.
FIRE
DMP
BOING
DING
COWBELL
226 Closing data connection. Transfer succeeded
ftp: 33 bytes received in 0.22Seconds 0.15Kbytes/sec.
ftp>
```

Transferring Files with Flash FXP


Flash FXP™ is a popular FTP client that is available online for a very modest sum. Flash FXP™ can be obtained at www.inicom.net. Instant Replay has been tested with Flash FXP™ version 3.2.0.

Connect to Instant Replay


Start up Flash FXP. The listing on the right hand side shows local files on your computers drive.

Set Instant Replay to FTP Mode by pressing **MENU->NETWORKING->FTP MODE->ON** then pressing **ENTER**.

Click on the yellow Lightning Bolt then select Open Connection.




The login dialog box appears. Set the IP address, User ID and Password fields to the values you configured your Instant Replay to under the Networking menu.



Upload/Download files

You can move files from Instant Replay to your computer simply by dragging them across to the listing on the right side of the screen. Likewise you can move files from your computer to Instant Replay by dragging them from left to right.



Renaming or Deleting a File using Flash FXP

Right click on the file. Select RENAME or DELETE from the pull-down menu. Rename or delete the file.

CHAPTER 6 – MACHINE SETUP MENU’S

Default values are UNDERLINED. All settings are saved on disk and restored on power up.

EDIT Menu

Menu Item	Values
Adjust Head Point	<u>0.00</u>
Adjust Tail Point	<u>end of file</u>
Set Fade In Length	Range is <u>0.00</u> to 40.00
Set Fade Out Length	Range is <u>0.00</u> to 40.00
Set Tail Pre-roll	Variable from 1 to 9 seconds. Default is <u>5 sec.</u>
Adjust Output Gain	Range is +6 to – 90 dB. Default is <u>0dB</u>

Refer to the section, “Editing Cuts” on page 22 for more information about these settings.

RECORD SETUP

Menu Item	Values
Audio Input	<u>ANALOG</u> , AES/EBU XLR-3, AES/SMPTE-75 OHM RCA, IEC-958 TYPE II RCA
Threshold (in dB)	OFF, -6, -12, -18, -24, -30, -36, <u>-42</u> , -48, -54, -60
Record Overwrite	<u>OFF</u> , ON
Record Time Limit	NONE, <u>60 MIN</u> , 30 MIN, 5 MIN
Record/Erase Lockout	<u>OFF</u> , ON
Recording Format	44.1K WAV 16 Bit, 48K WAV 24 Bit, 44.1K WAV 16 Bit, 48K WAV 16 Bit, 44.1K DC2, 48K DC2
Dig Input Processing	OFF, Dither 24-> 16 Bit, Sample Rate Convert, Dither 24-> 16 Bit + SRC
Prompt for Head/Tail	<u>Enabled</u> , Disabled

Refer to the section, “Recording A Cut” on Page 13 for more information about these settings.

NETWORKING Menu

Menu Item	Values
FTP Enable	ENABLE, <u>DISABLE</u>
FTP User	<u>360USER</u>
FTP Password	<u>PASSWORD</u>
Subnet Mask	<u>255.255.255.0</u>
IP Address	<u>192.168.1.100</u>
DHCP Enable	ON, <u>OFF</u>

OPERATIONS Menu

Menu Item	Function
Change Cut Name	Changes name of currently selected Cut
Erase	Erases currently selected Cut
Move Cut	Move currently selected Cut to any unused Index number
Change Bank Name	Changes name of currently selected Bank

HOT-KEYS Menu

Menu Item	Values
Assign HOT-KEYS	-
HOT-KEY Protect	<u>OFF</u> , ON
Assign Bank	-
Clear HOT-KEY	-


PLAYLIST Menu

Menu Item	Values
Clear Playlist	-
Playlist Protection	<u>OFF</u> , ON

CONFIGURATION Menu

Menu Item	Values
Time Display	<u>TIME REMAINING</u> , ELAPSED TIME
Sort Directory By	<u>INDEX</u> , NAME
Select Language	<u>ENGLISH</u> , SPANISH
Digital Output	OFF, <u>PROFESSIONAL FORMAT</u> , CONSUMER FORMAT,
COPY PROT. CONSUMER	-
Playback sample Rate	<u>AS RECORDED</u> , SYNC TO DIGITAL IN, OUTPUT AT 48K, OUTPUT AT 44.1K
GPI PLAY ENABLE	ENABLED, <u>DISABLED</u>
Tail Trimmed Audio	KEEP ONLY 1ST 30 SEC, KEEP ALL

CHAPTER 7 – THE REAR PANEL



INSTANT REPLAY REAR PANEL

ELECTRICAL POWER

CAUTION!

CONNECT THIS PRODUCT ONLY TO AN AC POWER SOURCE WITHIN THE VOLTAGE AND FREQUENCY RANGE INDICATED ON THE REAR PANEL. THE PRODUCT IS SUPPLIED WITH A DETACHABLE IEC TYPE AC LINE CORD APPROPRIATE TO THE COUNTRY TO WHICH THE UNIT WAS ORIGINALLY DELIVERED. CHECK TO SEE THAT IT MATCHES THE ELECTRICAL OUTLET YOU WILL BE USING.

WARNING:

REPLACE POWER CORD ONLY WITH UNDERWRITERS LABORATORIES (UL) LISTED CORD OF EQUIVALENT TYPE AND RATING!

Power Switch

The POWER SWITCH is located next to the AC POWER INPUT on the rear of the product.

Fuses

The fuses in this product are not user replaceable. Failure of a fuse is an indication of other component failure, and will require service by a qualified repair technician. Contact 360 Systems, or your 360 Systems distributor.

AUDIO CONNECTIONS

Audio Inputs

The ANALOG INPUTS are a pair of female XLR-3 connectors marked LEFT and RIGHT. The inputs are electronically balanced, with an impedance of 40k ohms. With the INPUT LEVEL controls up full, a 6.75dBu tone will produce a full scale output, approximately 15dBu with the OUTPUT ATTENUATOR in the -10 position and 25 dBu in the 0 position. Refer to Table 3 for input and output connections.

Input cables should be wired as follows:

XLR Connector Pin	Balanced Connection	Unbalanced Connection
PIN 1	COMMON	GROUND
PIN 2	+ INPUT	SIGNAL
PIN 3	- INPUT	No Connect

TABLE 3 - INPUT AND OUTPUT CONNECTIONS

Audio Outputs

The main ANALOG OUTPUTS are a pair of male XLR-3 connectors. The output is electronically balanced, and is capable of driving loads of 600 ohms or greater. Output cables should be wired the same as shown above for the inputs.

Headphone Output

The HEADPHONE OUTPUT always carries the same signal as the Main outputs, but its level is controlled by the HEADPHONES LEVEL control on the front panel.

When the PREVIEW button is activated in Stop mode, the HEADPHONE OUTPUT is active and the Main Outputs are turned off during subsequent playback. It may be helpful to use the HEADPHONE OUTPUT for control room monitoring, while the Main Outputs provide the main feed to a mixer or transmitter.

DIGITAL AUDIO CONNECTIONS

AES/EBU Input

An XLR-3 female connector is provided for digital input in the AES/EBU format. There is a selectable Sample Rate Converter built in to Instant Replay. When SAMPLE RATE CONVERTER is ENABLED, the input will accept any sample rate from 24k samples/second to 50k samples/second. Use only special AES cable having an impedance of 110 ohms. Limit the cable run to 100 feet. Do not use microphone cables for runs of over 6 feet.

IEC 958 Type II Input

An RCA "phono" connector provides a digital input from consumer or semi-pro equipment. Most equipment with connectors marked "S/P DIF" can be connected to this input.

As described in the previous section, when SAMPLE RATE CONVERTER is ENABLED the input will accept any sample rate from 24k samples/second to 50k samples/second. Use only low-

capacitance 75Ω coaxial cable, such as those made for video connection between VCRs and television video inputs. Do not use audio cables with RCA connectors.

Digital Audio Interfacing

Should Instant Replay detect a mismatch at its digital audio ports when preparing to record, the PLAY button is disabled and an error message, INTERFACE MISMATCH, appears in the display. Possible mismatches can include professional/consumer data format conflicts, non-audio data and data flagged as invalid. Copyright Protected data (“SCMS”) will cause a similar error message. Correct the mismatch as necessary.

If the SAMPLE RATE CONVERTER is DISABLED, another mismatch condition can arise between the selected RECORDING FORMAT and the sample rate of the incoming digital audio. The 48K Linear format requires the digital audio to be input from a 48K source. The 44.1K Linear format requires digital audio to be input from a 44.1K source.

Some digital audio equipment does not correctly output audio data or flags. Also, the data might be flagged as invalid when not in play mode. This is most common in consumer CD players with digital outputs. The following techniques may help:

- Put the device in Play and Pause before pressing Play on Instant Replay to start recording.
- Put the device in play and “cue” or “scan” backwards until the previous audio selection is heard, or in the case of CDs the “preroll” seconds are displayed (usually shown as P :02 or -:02). Let go of the button on the device and press Play on Instant Replay to begin recording immediately.
- Start Instant Replay recording on the fly between two selections and use Head Trim to remove any unwanted audio from the start of the recording. This can be useful with DAT machines that are unstable until they have played for a few seconds.

In cases where Instant Replay records for only a few milliseconds or seconds and then stops, check for proper connections and cabling. Try another cable, or different device equipped with a digital output.

If all else fails, use the analog inputs. The conversion to digital is of high quality and will result in minimal loss of fidelity.

Digital Audio Output

When using Instant Replay as a digital audio source, RECEIVER ECHO should be DISABLED in the FILE TRANSFER MENU. Also, **it is not a good idea to use cuts with different sample rates on the same project**, as this may cause equipment connected to the digital outputs to click, pop, mute or stop recording when the sample rate changes. Use the Playback Sample Rate Converter (Page 21) to make all of your cuts conform to a single sample rate at the output. The analog outputs are not affected by sample rate changes.

AES/EBU Output

An XLR-3 male connector provides a digital audio output in the AES/EBU format. Use only special AES cable having an impedance of 110 ohms. Limit the cable run to 100 feet. Do not use microphone cable for runs over 6 feet.

Always set the DIGITAL AUDIO OUTPUT parameter in the CONFIGURATION Menu to PROFESSIONAL when using the AES/EBU output. Although the output is still active with the CONSUMER output formats selected, the signal is not AES/EBU compliant.

IEC 958 Type II Output

An RCA "phono" connector provides a digital audio output to consumer or semi-pro equipment. Most equipment with input connectors marked "S/P DIF" can also be connected to this output.

Always set the DIGITAL AUDIO OUTPUT parameter in the CONFIGURATION Menu to CONSUMER or COPY PROT. CONS. when using the IEC 958 Type II output with IEC 958 or S/P DIF equipment. Recordings made from Instant Replay in COPY PROT. CONS. mode can not be copied by other digital audio input devices equipped with the Serial Copy Management System (SCMS).

When DIGITAL AUDIO OUTPUT is set to PROFESSIONAL, this output produces a signal that is compatible with the AES/SMPTE digital audio standard. This signal is normally supplied on a BNC connector. It is designed to allow digital audio to be routed and cabled using the same methods as 75Ω video signals

NETWORK CONNECTIONS

Network Port

Instant Replay has a 10/100 ethernet port and features an FTP server. This allows you to connect Instant Replay using most commercially available FTP clients. Using the FTP client, you can do the following.

- Upload cuts from your computer to Instant Replay
- Download cuts from Instant Replay to your computer
- Display cuts
- Rename cuts
- Delete cuts

CHAPTER 8 – MAINTENANCE AND DISK OPERATIONS

FORMATTING THE INTERNAL HARD DISK

The Format Disk option for the internal drive is only available through a special "power-on" sequence. **This option will erase the entire contents of Instant Replay's internal hard disk** It is essential to back up the contents of your hard drive using the FTP Network Port. Refer to Chapter 4 to read how to do this. During FORMAT DISK, if you wait too long to select an option, Instant Replay will "time out", aborting the Format Disk operation.

CAUTION!

**FORMAT DISK WILL PERMANENTLY ERASE THE CONTENTS OF THE HARD DISK .
IF AT ANY TIME THE FORMATTING PROCESS IS ABORTED, YOU MUST RECYCLE POWER
(TURN THE MACHINE OFF, THEN BACK ON AGAIN) TO ENSURE PROPER OPERATION. REPEAT
THE FORMAT PROCESS AFTER CYCLING POWER.**

To Format the Internal Hard Disk

- Turn Instant Replay's power switch OFF.
- While holding down the STOP button, turn power ON. Continue to hold stop until the unit initializes. The display will prompt:

**FORMAT & ERASE DISK?
PRESS ENTER/CANCEL**

- Press ENTER to proceed, or **CANCEL** to abort. If you press ENTER, the display will prompt:

**PLAY
CANCEL**

- Press PLAY to continue. The display will prompt:

**FORMATTING
WAIT**

After the formatting operation is complete, the display will show the initializing message, then will indicate "NO CUTS AVAILABLE". At this point, you may:

- Press RECORD and begin recording new material.

INDEX

- 24->16 Bit Conversion, 20
- Audio Connections
 - analog, 43–45
 - digital, 43–45
- Banks, 10
- Cancel, 11
- Compliance
 - emissions and immunity, 2, 3
 - safety, 2
- Configuration Menu, 41
- Controls, 8
 - front panel, 8
- Declaration of Conformity, 2
- Digital Output format selection, 41
- Editing Operations, 22
 - fade in, 24
 - fade out, 24
- Editing Setup Menu, 40
- Electrical Power, 42
- Enter, 11
- Erase, 17
- Find, 11, 18
- Format
 - internal drive, 46
- Front Panel Controls, 8
- FTP
 - Connecting to, 33, 34, 39
 - Downloading, 34
 - Initial Setup, 32
 - Renaming, 36
 - Supported Clients, 31
 - Uploading, 35
- Headphone Level Control, 10
- Hot-Keys, 9
 - assigning, 10, 17, 18
 - overwriting, 10
 - reassigning audio, 18
- Hot-Keys, 17, 18
- Input Level Controls, 10
- Level Meters, 10
- Loop, 9, 19
- Menu
 - configuration, 41
 - editing, 40
 - File Transfer, 40
 - operations, 40, 41
 - record, 40
 - setup options, 40
- Menu Key, 10
- Operations Menu, 40, 41
- Output gain adjust, 19
- Pause, 9
- Play, 9
- Playing, 16
- Power-On, 12, 13
- Preview, 10, 18
- Rear Panel, 13, 42
- Record, 9
- Record Setup Menu, 40
- Recording, 14, 15
- Sample Rate Converter, 19, 21
- Scroll Keys, 11
- Sort Directory By, 41
- Stop, 9
- Symbols
 - warning and information, 2
- Transport Control Buttons, 9
- Transport Controls, 9
- Warranty Information, 4
 - RMA number, 3