


9083-ENCD

9083-ENCE



HD/SD Frame Sync

with Audio Embedding/De-Embedding and Dolby® Encoder

9083-ENCD – with Dolby® Digital™ Encoder

9083-ENCE – with Dolby® E™ Encoder

Product Manual



Cobalt Digital Inc.

2406 E. University Ave.
Urbana, IL 61802
Voice 217.344.1243 • Fax 217.344.1245
www.cobaltdigital.com

Copyright

©Copyright 2010, Cobalt Digital Inc. All Rights Reserved.

Duplication or distribution of this manual and any information contained within is strictly prohibited without the express written permission of Cobalt Digital Inc. This manual and any information contained within, may not be reproduced, distributed, or transmitted in any form, or by any means, for any purpose, without the express written permission of Cobalt Digital Inc. Reproduction or reverse engineering of software used in this device is prohibited.

Disclaimer

The information in this document has been carefully examined and is believed to be entirely reliable. However, no responsibility is assumed for inaccuracies. Furthermore, Cobalt Digital Inc. reserves the right to make changes to any products herein to improve readability, function, or design. Cobalt Digital Inc. does not assume any liability arising out of the application or use of any product or circuit described herein.

Trademark Information

Cobalt® is a registered trademark of Cobalt Digital Inc.

COMPASS™ is a trademark of Cobalt Digital Inc.

DashBoard™ and **openGear™** are trademarks of Ross Video Limited. **Dolby®** is a registered trademark of Dolby Laboratories, Inc. Other product names or trademarks appearing in this manual are the property of their respective owners.

2.0-to-5.1 audio upmixer licensed feature uses the **AutoMAX-II™** upmix algorithm provided under license from **Linear Acoustic Inc. Linear Acoustic**, the "LA" symbol, **UPMAX**, **AutoMAX**, and **AutoMAX-II** are trademarks of Linear Acoustic Inc. All Rights Reserved.

Congratulations on choosing the Cobalt® 9083-ENCD / 9083-ENCE HD/SD Frame Sync with Audio Embedding/De-Embedding and Dolby® Encoder option. The 9083 is part of a full line of modular processing and conversion gear for broadcast TV environments. The Cobalt Digital Inc. line includes video decoders and encoders, audio embedders and de-embedders, distribution amplifiers, format converters, remote control systems and much more. Should you have questions pertaining to the installation or operation of your 9083, please contact us at the contact information on the front cover.

Manual No.:	9083-ENC-OM
Document	
Version:	4.0
Release Date:	January 7, 2010
Applicable for	
Software	
Version:	4.0 / 2823

Table of Contents

Chapter 1	Introduction	1-1
	Overview	1-1
	9083 Card Software Versions and this Manual	1-2
	Manual Conventions	1-3
	Warnings, Cautions, and Notes	1-3
	Labeling Symbol Definitions	1-4
	Safety Summary	1-4
	Warnings	1-4
	Cautions	1-4
	9083 Functional Description	1-5
	9083 Input/Output Formats	1-5
	Video Functions Description	1-7
	Audio Processor Description	1-8
	AES Audio Input Advanced Features	1-12
	Audio LKFS Monitor Description	1-13
	Dolby® Digital (AC-3) Encoder Description (9083-ENCD only)	1-13
	Dolby® E Encoder Description (9083-ENCE only)	1-16
	User Control Interface	1-19
	9083 Rear I/O Modules	1-21
	Audio and Video Formats Supported by the 9083	1-23
	Technical Specifications	1-24
	Warranty and Service Information	1-28
	Cobalt Digital Inc. Limited Warranty	1-28
	Contact Cobalt Digital Inc.	1-29
 Chapter 2	 Installation and Setup	 2-1
	Overview	2-1
	Setting I/O Switches for AES I/O (1-4) Ports	2-1
	Installing the 9083 Into a Frame Slot	2-2
	Installing a Rear I/O Module	2-5
	9083 Rear I/O Modules	2-6
	Setting Up 9083 Network Remote Control	2-10

Chapter 3	Operating Instructions	3-1
	Overview	3-1
	Control and Display Descriptions	3-1
	Function Submenu/Parameter Submenu Overview	3-2
	9083 Card Edge Controls, Indicators, and Display	3-3
	DashBoard™ User Interface	3-8
	Cobalt® Remote Control Panel User Interfaces	3-11
	Accessing the 9083 Card via Remote Control	3-12
	Accessing the 9083 Card Using DashBoard™	3-12
	Accessing the 9083 Card Using a Cobalt® Remote Control Panel	3-13
	Checking 9083 Card Information.....	3-14
	Ancillary Data Line Number Locations and Ranges	3-15
	9083 Function Submenu List and Descriptions	3-16
	Audio Input Controls	3-17
	AFD	3-20
	Framesync	3-21
	Embedded Audio Group 1/2	3-27
	Embedded Audio Group 3/4	3-33
	Audio LKFS Monitor	3-35
	AES Audio Out Pairs 1-4	3-38
	Audio Mixing	3-43
	Tone Generator	3-48
	Licensable Features	3-48
	Presets	3-49
	Dolby® Digital (9083-ENCD Only) Functions Submenu List.....	3-51
	Dolby Digital Encoder	3-51
	Dolby Digital External Metadata	3-54
	Dolby Digital Internal Metadata	3-56
	Dolby Digital Channel Mapping	3-57
	Dolby® E (9083-ENCE Only) Functions Submenu List.....	3-59
	Dolby E Encoder	3-59
	Dolby E External Metadata	3-60
	Dolby E Internal Metadata	3-63
	Dolby E Channel Mapping	3-64
	Example Setups Using The 9083 and DashBoard™	3-66
	Audio Routing Example Using DashBoard™	3-66
	Dolby® Digital™ (AC-3) Setup and Routing	
	Example (9083-ENCD only).....	3-69
	Dolby® E Setup and Routing Example (9083-ENCE only)	3-71

Troubleshooting	3-73
Error and Failure Indicator Overview	3-73
Basic Troubleshooting Checks	3-77
9083 Processing Error Troubleshooting	3-78
Troubleshooting Network/Remote Control Errors	3-82
In Case of Problems	3-82

Appendix A	Loudness Measurement Guidelines and Techniques	A-1
	About Loudness Measurement Applied to Program Material	A-1
	About Target LKFS Value.....	A-2
	Measurement Techniques For Various Program Material Forms.....	A-3
	Importance of an Anchor Element.....	A-4
	Assumptions and Conditions For Meaningful LKFS Measurements	A-4
	Specific Measurement Techniques for Various Material Forms	A-6
	Modifying LKFS Assessments Using Parametric Settings	A-7

This page intentionally blank

Introduction

Overview

This manual provides installation and operating instructions for the 9083-ENC D and 9083-ENCE HD/SD Frame Sync with Audio Embedding/De-Embedding and Dolby Encoder cards (also referred to herein as the 9083-ENC D, 9083-ENCE, or collectively as the “9083”).

Note: This manual covers the 9083-ENC D (which is the 9083 card equipped with an optional Dolby® Digital™ encoder as an option) and the 9083-ENCE (which is the 9083 card equipped with an optional Dolby® E encoder). Where applicable, descriptions related exclusively to either the 9083-ENC D or the 9083-ENCE are respectively denoted by **(9083-ENC D only)** or **(9083-ENCE only)**. In all other aspects, both cards function identically as described in this manual.

This manual consists of the following chapters:

- **Chapter 1, “Introduction”** – Provides information about this manual and what is covered. Also provides general information regarding the 9083.
- **Chapter 2, “Installation and Setup”** – Provides instructions for installing the 9083 in a frame, and optionally installing 9083 Rear I/O Modules.
- **Chapter 3, “Operating Instructions”** – Provides overviews of operating controls and instructions for using the 9083.

This chapter contains the following information:

- **9083 Card Software Versions and this Manual (p. 1-2)**
- **Manual Conventions (p. 1-3)**
- **Safety Summary (p. 1-4)**
- **9083 Functional Description (p. 1-5)**
- **Technical Specifications (p. 1-24)**
- **Warranty and Service Information (p. 1-28)**
- **Contact Cobalt Digital Inc. (p. 1-29)**

9083 Card Software Versions and this Manual

When applicable, Cobalt Digital Inc. provides for continual COMPASS™ card product enhancements through software updates. As such, functions described in this manual may pertain specifically to cards loaded with a particular software build. **If you received your 9083 and this manual at the same time, this manual reflects all facets of your card.**

This manual (9083-ENC-OM (V4.0)) was specifically written for
Software Version: 4.0 / 2823 (or greater)

If your 9083 was purchased **earlier** than receiving this manual, you can check the Software Release Number/Software Build Number of your 9083 and see if it matches the Software Release Number/Software Build Number covered by this manual.

If necessary, the Software Release Number/Software Build Number of your 9083 can be checked by viewing this information as displayed on the **Info** submenu on the card-edge display, or by checking the **Card Info** menu in DashBoard™. See Checking 9083 Card Information (p. 3-14) in Chapter 3, “Operating Instructions” for more information.

Proceed as follows if your 9083 card’s software does not match this manual:

Card Software earlier than version in manual	<p>Card is not loaded with the latest software. Not all functions and specified performance described in this manual may be available.</p> <p>If desired, contact Cobalt Digital Inc. to receive the latest Update software for your card. Software is typically sent by e-mail.</p> <p>You can update your card by uploading the new Update software by going to the Support>Downloads link at www.cobaltdigital.com. Then, go to the listing for your card and download “COMPASS™ Firmware Update Guide”.</p>
Card Software newer than version in manual	<p>A new manual is expediently released whenever a card’s software is updated and specifications and/or functionality have changed as compared to an earlier version (a new manual is not necessarily released if specifications and/or functionality have not changed). A manual earlier than a card’s software version may not completely or accurately describe all functions available for your card.</p> <p>If your card shows features not described in this manual, you can check for the latest manual (if applicable) and download it by going to the Support>Downloads link at www.cobaltdigital.com.</p>

Manual Conventions

In this manual, display messages and connectors are shown using the exact name shown on the 9083 itself. Examples are provided below.

- Card-edge display messages are shown like this:

Ch01

- Connector names are shown like this: **AES IN 1**

In this manual, the terms below are applicable as follows:

- **9083-ENCD** refers to the 9083 HD/SD Frame Sync with Audio Embedding/De-Embedding and Dolby® Digital™ (AC-3) Encoder card.
- **9083-ENCE** refers to the 9083 HD/SD Frame Sync with Audio Embedding/De-Embedding and Dolby® E Encoder card.
- **Frame** refers to the 8310 (or similar) frame that houses the Cobalt® COMPASS™ cards.
- **Device** and/or **Card** refers to a COMPASS™ card.
- **System** and/or **Video System** refers to the mix of interconnected production and terminal equipment in which the 9083 and other COMPASS™ cards operate.

Warnings, Cautions, and Notes

Certain items in this manual are highlighted by special messages. The definitions are provided below.

Warnings

Warning messages indicate a possible hazard which, if not avoided, could result in personal injury or death.




Cautions

Caution messages indicate a problem or incorrect practice which, if not avoided, could result in improper operation or damage to the product.

Notes

Notes provide supplemental information to the accompanying text. Notes typically precede the text to which they apply.

Labeling Symbol Definitions

	Attention, consult accompanying documents.
	Electronic device or assembly is susceptible to damage from an ESD event. Handle only using appropriate ESD prevention practices. If ESD wrist strap is not available, handle card only by edges and avoid contact with any connectors or components.
	Symbol (WEEE 2002/96/EC) For product disposal, ensure the following: <ul style="list-style-type: none"> • Do not dispose of this product as unsorted municipal waste. • Collect this product separately. • Use collection and return systems available to you.

Safety Summary

Warnings

! WARNING !

To reduce risk of electric shock do not remove line voltage service barrier cover on frame equipment containing an AC power supply. **NO USER SERVICEABLE PARTS INSIDE.** REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

Cautions

CAUTION

This device is intended for environmentally controlled use only in appropriate video terminal equipment operating environments.

CAUTION

This product is intended to be a component product of an openGear™ frame. Refer to the openGear™ frame Owner's Manual for important safety instructions regarding the proper installation and safe operation of the frame as well as its component products.

CAUTION

Heat and power distribution requirements within a frame may dictate specific slot placement of cards. Cards with many heat-producing components should be arranged to avoid areas of excess heat build-up, particularly in frames using only convection cooling. The 9083 has a moderate power dissipation (15 W max.). As such, avoiding placing the card adjacent to other cards with similar dissipation values if possible.

CAUTION

If required, make certain Rear I/O Module(s) is installed before installing the 9083 into the frame slot. Damage to card and/or Rear I/O Module can occur if module installation is attempted with card already installed in slot.

CAUTION

If card resists fully engaging in rear I/O module mating connector, check for alignment and proper insertion in slot tracks. Damage to card and/or rear I/O module may occur if improper card insertion is attempted.

9083 Functional Description

Figure 1-1 shows a functional block diagram of the 9083. The 9083 frame synchronizer also includes a full 16-channel audio embedder/de-embedder, an 8-channel, and a 24-bit balanced analog-to-digital audio converter. The 9083 also handles AFD code detection/insertion. Additionally, the 9083-ENCD also performs Dolby® Digital™ (AC-3) encoding using any of the audio sources supported by the 9083, and using either external or internally generated metadata. Similarly, the 9083-ENCE also performs Dolby® E encoding using any of the audio sources supported by the 9083, and using either external or internally generated metadata.

Note: Some of the functions described below are available only when using the DashBoard™, or Cobalt® OGCP-9000 or OGCP-9000/CC Remote Control Panels user interfaces. Refer to User Control Interface (p. 1-19) for user interface descriptions.

9083 Input/Output Formats

The 9083 provides the following inputs and outputs:

- **Inputs:**
 - **HD/SD SDI IN** – dual-rate HD/SD-SDI input
 - **AES I/O (1-4)** – user-switchable as AES inputs or AES outputs
 - **AES IN (5-8)** – dedicated AES inputs
 - **AN-AUD IN (1-8)** – balanced analog audio inputs
 - **DOLBY META IN** – RS-485 external Dolby® metadata input
- **Outputs:**
 - **SDI OUT** – two dual-rate HD/SD-SDI buffered video outputs
 - **RCK OUT** – two reclocked HD/SD-SDI buffered input copies
 - **AES OUT (1-4)** – dedicated AES outputs
 - **AES I/O (1-4)** – user-switchable as AES inputs or AES outputs
 - **ENCD COPY (1-4)** – four Dolby® encoded pair copies (available on discrete AES output channels 9/10 thru 15/16 over the **AES OUT 5-8** BNC connectors)

Note: The input/output complement listed above represents the maximum capability of the 9083. The practical input/output complement is determined by the particular Rear I/O Module used with the 9083. Refer to 9083 Rear I/O Modules (p. 1-21) for more information.




Figure 1-1 9083 Functional Block Diagram

Video Functions Description

Frame Sync Function

This function provides for frame sync control using either one of two external **EXT REF IN (1,2)** reference signals distributed with the card frame, or the input video as a frame sync reference.

This function also allows horizontal and/or vertical offset to be added between the output video and the frame sync reference.

A video/audio delay offset function allows adding or reducing audio delay from the matching video delay. This function is useful for correcting lip sync problems when video and audio paths in the chain experience differing overall delays. A Reset Framesync function resets the frame sync following any horizontal or vertical offset changes, clearing any buffered audio and video and re-establishing the frame sync. The 9083 re-establishes video/audio sync following framesync changes by applying an offset in small, progressive amounts to provide a seamless, glitch-free retiming. A user-selectable hard resync function allows setting a threshold at which hard resync is applied if audio-video offset exceeds the threshold. Hard resync provides fastest sync-up suitable for off-air manipulation. Conversely, a threshold setting that avoids hard resync allows glitch-free on-air manipulation.

In the event of input video loss of signal, this function provides for disabling the video, going to a desired color raster, or freezing to the last intact frame (frame having valid SAV and EAV codes).

AFD Inserter

This function provides for assignment and insertion of AFD codes into the SDI output video. Using this function, AFD codes in accordance with the standard 4-bit AFD code designations can be applied to the output video.

This function checks for any existing AFD code within the received video input. If a code is present, the code is displayed. When used in conjunction with a separate downstream card capable of providing AFD-directed scaling, the image can in turn be scaled in accordance with the AFD coding embedded by this card.

The function also allows the selection/changing of the AFD code ancillary data line number for the outputted AFD code.

Audio Processor Description

The audio processor operates as an internal audio router. The router function chooses from the following inputs:

- 16 channels of embedded AES from the SDI video
- 16 channels (8 pairs) of discrete AES input
- 8 channels of balanced analog audio input
- Four independent internal tone generators (described below)
- Digital silence (mute) setting
- Internal Down Mix and Mono Mixer outputs (described below)
- **(9083-ENCD only)** Dolby® Digital (AC-3) encoded pair
- **(9083-ENCE only)** Dolby® E encoded pair

The router function provides the following audio outputs:

- 16 channels of embedded AES SDI output
- 8 channels of discrete AES output on four discrete AES pairs
- Dolby® encoded pair, which can be routed on embedded or discrete AES channels

The router acts as a full audio cross point. Each of the 24 output channels (16 embedded, 8 discrete AES) can receive signal from any one of the 40 (16 embedded, 16 discrete AES, 8 analog) input channels, four internal tone generators, or several mixer sources. Unused output channels can be mapped to a “Silence” source. Each output also provides gain adjustment and selectable polarity inversion.

Output audio rates are always 48 kHz, locked to output video, but discrete AES inputs can be set to use sample rate converters to align these inputs with the output timing. (AES must be nominally 48 kHz input; 32, 44.1, 96, and 192 kHz inputs are not compatible with the 9083.) The sample rate converters are disabled by default. Output AES is always precisely synchronized with the output video. The balanced analog audio input is sampled at 48 kHz with a +24 dBu clipping level (+24 dBu => 0 dBFS).

As set with the default settings, the routing between embedded audio channels **Embed Ch 1** thru **Embed Ch 16** and discrete AES audio channels **AES Ch1** thru **AES Ch 16** is as shown in Figure 1-2. In this mode, the routing is basic 1-to-1 embedding/de-embedding for the 16 embedded and AES discrete audio channels. Other sources and/or destinations (described below) for each channel are selected using the card edge controls or a remote control system.

Note: As shown in Figure 1-1, the 9083-ENCD and 9083-ENCE are equipped with eight discrete AES input pair ports and four discrete AES output pair ports. On Rear I/O Modules having limited AES I/O capabilities, switches S11 thru S14 allow available rear module BNC connectors to be allotted between AES inputs and outputs as desired. Buffered copies of **AES OUT (1-4)** are available as dedicated outputs and as respective outputs fed through S11 – S14 on the card.




Figure 1-2 Default Embed/De-Embed Audio Routing

Audio Down Mixer and Mono Mixer Function

(See Figure 1-3.) The audio down mixer function provides for the selection of any five embedded, AES discrete, or analog audio sources serving as Left (**L**), Right (**R**), Center (**C**), Left Surround (**Ls**), and Right Surround (**Rs**) individual signals to be multiplexed into a stereo pair (Down Mix Left (**DM-L**) and Down Mix Right (**DM-R**)). The resulting stereo pair **DM-L** and **DM-R** can in turn be routed and processed just like any of the other audio sources described earlier.




Figure 1-3 Audio Down Mix Functional Block Diagram with Example Sources

The mono mixer function (Figure 1-4) generates an additional mono-mixed channel from two selected embedded, AES discrete, or analog input channels serving as left and right inputs. The resulting mono mix channel **MONO** can in turn be routed and processed just like any of the other audio sources described earlier.




Figure 1-4 Audio Mono Mix Functional Block Diagram with Example Sources

2.0-to-5.1 Upmix Function

Note: Upmix function is an optional licensable feature. This function and its controls appear only when a license key is entered and activated. (This option (identified in Cobalt® price lists as “OPT-SW-UM”) can be purchased upon initial order, or field-activated using a key string which is sent to you when this option is purchased.)

The 2.0-to-5.1 upmixer function receives a normal PCM stereo pair from the Audio Routing/Gain Control function and upmixes the pair to provide 5.1 channels (Left (**L**), Right (**R**), Center (**C**), Low Frequency Effects (**LFE**), Left Surround (**Ls**), and Right Surround (**Rs**)). Whenever the upmixer is active, it overwrites the six selected channels with the new 5.1 upmix signals (including replacing the original source stereo **L** and **R** inputs with new **L** and **R** signals).

The 2.0-to-5.1 upmixer can be set to up mix in any of three modes: Always upmix, Bypass upmix, or Auto enable/bypass upmixing. The Auto upmixing mode looks at the signal levels on the selected channels and compares them to a selectable level threshold. It then determines whether or not to generate 5.1 upmixing from the stereo pair as follows:

- If the upmixer detects signal level **below** a selected threshold on **all four** of the selected channels designated as **C**, **LFE**, **Ls**, and **Rs**, this indicates to the upmixer that these channels are not carrying 5.1. In this case, the upmixer overwrites all six selected channels with the new 5.1 content.
- If the upmixer detects signal level **above** a selected threshold on **any** of the four selected channels designated as **C**, **LFE**, **Ls**, and **Rs**, this indicates to the upmixer that the channel(s) are already carrying viable 5.1 content. In this case, the upmixer is bypassed, allowing the original channels to pass unaffected.

The examples in Figure 1-5 show the automatic enable/disable up-mixing function applied to example selected channels **Emb Ch 1** thru **Emb Ch 6**. As shown and described, the processing is contingent upon the signal levels of the channels selected to carry the new 5.1 upmix relative to the selected threshold (in this example, -60 dBFS). Note also that this function is applied **after** the Audio Routing/Gain Control function. Because all audio inputs pass through the Audio Routing/Gain Control function before the up mixer, the up mixer can use embedded, AES discrete, and/or analog audio sources.




Figure 1-5 Up Mix Auto Enable/Bypass with Example Sources

Tone Generator Function

The 9083 contains four built-in tone generators (Tone Generator 1 thru Tone Generator 4). Each of the four tone generators can be set to a different frequency, and are available as audio sources for the embedded or AES audio outputs.

18 discrete sine wave frequencies are available, ranging from 50 Hz to 16 kHz (default frequency is 1.0 kHz).

AES Audio Input Advanced Features

AES Sample Rate Converter

The 9083 AES inputs have sample rate converters that can be independently enabled for each AES pair to allow the card to interface with asynchronous AES sources (sources in which AES timing does not match the video input timing). The sample rate converters are set to disabled (bypassed) by default; this is necessary when embedding undecoded, non-PCM audio such as Dolby® E or Dolby® Digital™ audio streams. When a valid Dolby® E or Dolby® Digital™ signal (in accordance with SMPTE 337M) is detected on an AES or embedded audio signal, SRC is automatically bypassed along with gain and polarity controls.

Zero-Delay Audio Embedding

In cases where additional delay must be avoided, it may be desirable to embed AES with minimum latency. Using zero-delay embedding, the video can then be delayed by one frame to account for any remaining audio delay. In this manner, any delay between video and audio can be cleanly contained and managed within one frame period.

When zero-delay audio embedding is enabled for a given AES pair, the pair is directly embedded into its corresponding group (for example, AES Pair 1 into embedded channels 1 and 2; AES Pair 2 into embedded channels 3 and 4, and so on) with the normal frame sync audio delay being bypassed.

This function overrides the audio routing system (for example, if AES Pair 1 is selected then the controls to route AES Pair 1 into other embedded channels will not apply). Gain and polarity control is not available when this option is selected. Zero-delay audio embedding is set to Off by default.

Low-Latency AES Passthrough

This function is similar to zero-delay audio embedding. If low-latency AES passthrough is selected for a given input pair, it causes the corresponding AES output pair to act as a bit-for-bit copy of the corresponding AES input pair.

This control overrides the normal audio routing and delay. Gain and polarity control is not available when this option is selected. Passthrough is set to Off by default.

Audio LKFS Monitor Description

Note: Refer to Appendix A, “Loudness Measurement Guidelines and Techniques” for more information about LKFS parameters and this function, as well as practical measurement techniques.

This function monitors selected output (“destination”) channels from the Audio Routing/Gain Control function and applies signal analysis based on ITU-R BS.1770-1 – ATSC A/85 criteria to produce an LKFS measurement and provide indications of under-threshold and over-threshold level conditions.

The function can monitor any combination of embedded, AES, or analog channels (or channels fed to the Dolby® encoder) selected as the L, R, C, Ls, and Rs ITU-R BS.1770-1 channels (note that the LFE and AUX channels are not included in any LKFS calculations). Because the LKFS monitor uses output (post-processed “destination”) channels, LKFS under/over conditions can be corrected using the Dashboard™ controls on this card for the monitored channels (Dolby® channel selections use the channels routed to the Dolby encoder inputs).

The functions provides a configurable moving average period for tailoring the measurement to suit various program material conditions, as well as configurable thresholds which provide an unambiguous alarm indication if the measured LKFS deviates from the thresholds. This function uses the encoder metadata dialnorm setting as the LKFS target reference.

Dolby® Digital (AC-3) Encoder Description (9083-ENCD only)

(See Figure 1-6.) The Dolby® Digital (AC-3) Encoder receives up to six different audio sources (**Input Audio IN 1** thru **IN 6**) from the card Audio Routing/Control and produces an encoded Dolby® pair using either received external metadata or internally generated metadata that can be user-defined using the encoder controls. The encoded pair can be sent from the card as embedded audio or over discrete AES-3id connections as a SMPTE 337M-formatted non-PCM signal.

Note: On cards equipped with a Rear I/O Module accommodating AES OUT pairs 5-8, the encoded pair is available as copies on AES channels 9 thru 16.

Input Audio Mapping

Any audio input supported by the card can serve as audio inputs for the Dolby® Digital (AC-3) Encoder. The six user-selected audio sources are mapped to **Encr Ch 1** thru **Encr Ch 6**, which are then fed to the Dolby® Audio Encode function.

Dolby® Metadata Selection/Control

When external metadata is being used for encoding, the Dolby® Digital (AC-3) Encoder allows user selection of the following external metadata sources:

- **Input Video** – De-muxed metadata extracted from SDI input video VBI portion in accordance with SMPTE 2020.
- **RS-485 Input Port** – Metadata received from external device/system using the card's **DOLBY META IN** RS-485 connector.

When an external source is selected, its status is displayed showing the following:

- Presence of data on selected source.
- Program configuration status (AC-3 modes for the various program configurations defined in the metadata).




Figure 1-6 Dolby® Digital (AC-3) Encoder Functional Block Diagram

Where multiple external source programs are available (up to eight separate programs), the descriptions and audio settings for each program 1 thru 8 are displayed. This function in turn allows selection of the desired AC-3 external source program. The external metadata selected here is fed to Failover Select.

Failover Select allows user selection of the action to take in the event of loss of external metadata, with the choices being:

- Switch to internal metadata
- Use last received metadata
- Stop encoding

The available metadata following this function is fed to the Dolby® Audio Encode function.

Internal Metadata Generator

The Internal Metadata Generator provides full audio setup, program coding, and bitstream definition controls, allowing user-generated metadata for providing Dolby® Digital (AC-3) encoding without any external metadata being required.

Full audio production controls are provided in general conformance with ATSC A/52B definitions, as well as extended bitstream controls. The Internal Metadata Generator can be used as a stable, known source of metadata/encoding, or can be used as a failover in the event of loss of external metadata.

Dolby® Audio Encode

In accordance with the selected metadata, the Dolby® Audio Encode function receives the audio inputs **Encr Ch 1- Ch 6** from Audio Input Mapping/Control and provides the Dolby® Digital (AC-3) encoded SMPTE 337M pair **Encd Pair 1/2**. The pair is available as a source as an embedded channel pair (allowing the encoded pair to be embedded in the SDI output) and as a source for an AES output pair (allowing the encoded pair to be available over a discrete AES-3id port).

Note: On the encoder-equipped 9083, AES Audio Out pairs 5-8 serve as four dedicated copies of the encoded pair in addition to any other encoded pair routing.

The encoded AC-3 data rate can be selected from multiple choices with associated audio quality trade-offs.

Dolby® E Encoder Description (9083-ENCE only)

(See Figure 1-6.) The Dolby® E Encoder receives up to eight different audio sources (**Input Audio IN 1** thru **IN 8**) from the card Audio Routing/Control and produces an encoded Dolby® pair using either received external metadata or internally generated metadata that can be user-defined using the encoder controls. The encoded pair can be sent from the card as embedded audio or over discrete AES-3id connections as a SMPTE 337M-formatted non-PCM signal.

Note: On cards equipped with a Rear I/O Module accommodating AES OUT pairs 5-8, the encoded pair is available as copies on AES channels 9 thru 16.

Input Audio Mapping

Any audio input supported by the card can serve as audio inputs for the Dolby® E Encoder. The eight user-selected audio sources are mapped to **Encr Ch 1** thru **Encr Ch 8**, which are then fed to the Dolby® Audio Encode function.

Dolby® Metadata Selection/Control

When external metadata is being used for encoding, the Dolby® E Encoder allows user selection of the following external metadata sources:

- **Input Video** – De-muxed metadata extracted from SDI input video VBI portion in accordance with SMPTE 2020.
- **RS-485 Input Port** – Metadata received from external device/system using the card's **DOLBY META IN** RS-485 connector.

When an external source is selected, its status is displayed showing the following:

- Presence of data on selected source.
- Program configuration status (program descriptions for the various program configurations defined in the metadata).




Figure 1-7 Dolby® E Encoder Functional Block Diagram

Where multiple external source programs are available (up to eight separate programs), the descriptions and audio settings for each program 1 thru 8 are displayed. The external metadata selected here is fed to Failover Select.

Failover Select allows user selection of the action to take in the event of loss of external metadata, with the choices being:

- Switch to internal metadata
- Use last received metadata
- Stop encoding

The available metadata following this function is fed to the Dolby® Audio Encode function.

Internal Metadata Generator

The Internal Metadata Generator provides full audio setup, program coding, and bitstream definition controls, allowing user-generated metadata for providing Dolby® E encoding without any external metadata being required.

Full audio production controls are provided in general conformance with ATSC A/52B definitions. The Internal Metadata Generator can be used as a stable, known source of metadata/encoding, or can be used as a failover in the event of loss of external metadata.

Dolby® Audio Encode

In accordance with the selected metadata, the Dolby® Audio Encode function receives the audio inputs **Encr Ch 1- Ch 8** from Audio Input Mapping/Control and provides the Dolby® E encoded SMPTE 337M pair **Encd Pair 1/2**. The pair is available as a source as an embedded channel pair (allowing the encoded pair to be embedded in the SDI output) and as a source for an AES output pair (allowing the encoded pair to be available over a discrete AES-3id port).

Note: On the encoder-equipped 9083, AES Audio Out pairs 5-8 serve as four dedicated copies of the encoded pair in addition to any other encoded pair routing.

User Control Interface

Figure 1-8 shows the user control interface options for the 9083. These options are individually described below.

Note: All user control interfaces described here are cross-compatible and can operate together as desired. Where applicable, any control setting change made using a particular user interface is reflected on any other connected interface.




Figure 1-8 9083 User Control Interface

- **Built-in Card Edge User Interface** – Using the built-in card edge controls and display, card control settings can be set using a front panel menu which is described in Chapter 3, “Operating Instructions”.

Note: Some of the 9083 functions described in this manual are available only when using the DashBoard™, or Cobalt® OGCP-9000 or OGCP-9000/CC Remote Control Panels user interfaces.

- **DashBoard™ User Interface** – Using DashBoard™, the 9083 and other cards installed in openGear™ frames such as the Cobalt® 8310-C Frame can be controlled from a computer and monitor.

DashBoard™ allows users to view all frames on a network with control and monitoring for all populated slots inside a frame. This simplifies the setup and use of numerous modules in a large installation and offers the ability to centralize monitoring. Cards define their controllable parameters to DashBoard™, so the control interface is always up to date.

Download the free DashBoard™ software by going to www.cobaltdigital.com and selecting “DashBoard Control and Monitoring” on the home page. The DashBoard™ user interface is described in Chapter 3, “Operating Instructions”.

Note: If network remote control is to be used for the frame and the frame has not yet been set up for remote control, Cobalt® reference guide **COMPASS™ Remote Control User Guide” (PN 9000RCS-RM)** provides thorough information and step-by-step instructions for setting up network remote control of COMPASS™ cards using DashBoard™.

Download a copy of this guide by clicking on the **Support>Downloads** link at www.cobaltdigital.com and then select DashBoard Remote Control Setup Guide as a download, or contact Cobalt® as listed in Contact Cobalt Digital Inc. (p. 1-29).

- **Cobalt® OGCP-9000 and OGCP-9000/CC Remote Control Panels** – The OGCP-9000 and OGCP-9000/CC Remote Control Panels conveniently and intuitively provide parameter monitor and control of the 9083 and other video and audio processing terminal equipment meeting the open-architecture Cobalt COMPASS™ cards for openGear™ standard.

In addition to circumventing the need for a computer to monitor and control signal processing cards, the Remote Control Panels allow quick and intuitive access to hundreds of cards in a facility, and can monitor and allow adjustment of multiple parameters at one time.

The Remote Control Panels are totally compatible with the openGear™ control software DashBoard™; any changes made with either system are reflected on the other. The Remote Control Panel user interface is described in Chapter 3, “Operating Instructions”.

9083 Rear I/O Modules

The 9083 physically interfaces to system video and audio connections using a Rear I/O Module. Figure 1-9 shows a typical 9083 Rear I/O Module.

All inputs and outputs shown in the 9083 Functional Block Diagram (Figure 1-1) enter and exit the card via the card edge backplane connector. The Rear I/O Module breaks out the 9083 card edge connections to industry standard connections that interface with other components and systems in the signal chain.

In this manner, the inputs and outputs required for a particular application can be accommodated using a Rear I/O Module that suits the requirements. The required input and outputs are broken out to the industry standard connectors on the Rear I/O Module; the unused inputs and outputs remain unterminated and not available for use.

The full assortment of 9083 Rear I/O Modules is shown and described in 9083 Rear I/O Modules (p. 2-6) in Chapter 2, “Installation and Setup”.




Figure 1-9 Typical 9083 Rear I/O Module

Figure 1-10 shows a 9083 card using an RM-9083-B Rear I/O Module. Using this Rear I/O Module, this module provides industry standard break-out connections for the following inputs and outputs required by this application:

- **Inputs:**
 - **HD/SD SDI IN** – dual-rate HD/SD-SDI input
 - **AN-AUD IN (1-6)** – balanced analog audio inputs (inputs 7-8 unused)
- **Outputs:**
 - **SDI OUT** – HD/SD-SDI buffered video outputs

The other 9083 inputs and outputs not accommodated by this Rear I/O Module (shown in gray in Figure 1-10) remain unterminated.




Figure 1-10 9083 with RM-9083-B Rear I/O Module

Audio and Video Formats Supported by the 9083

The 9083 supports all current SMPTE standard SD and HD video formats. Table 1-1 lists and provides details regarding the audio and video formats supported by the 9083.

Table 1-1 Supported Audio and Video Formats

Item	Description/Specification	
Input / Output Video	Raster Structure:	Frame Rate:
	1080PsF	23.98; 24
	1080p	23.98; 24
	1080i ⁽¹⁾	25; 29.97; 30
	720p	23.98; 24; 25; 29.97; 30; 50; 59.94; 60
	486i ⁽¹⁾	29.97
	575i ⁽¹⁾	25
Embedded Audio	The 9083 supports all four groups (16 channels) of embedded audio at full 24-bit resolution in both SD (with extended data packets) and HD.	
Analog Audio	The 9083 supports 8 channels of balanced (differential) analog audio. The analog audio is encoded such that a +24 dBu input is equivalent to digital 0 dBFS.	
Discrete AES Audio Input	The 9083 can accept 16 channels (8 pairs) of discrete AES audio on 75Ω BNC connections. Sample rate conversion can be employed to account for minor clock rate differences in the AES stream and the input video stream. Note: The AES signal must have a nominal rate of approximately 48 kHz. The 9083 does not support AES input at 32 kHz, 44.1 kHz, 96 kHz or 192 kHz rates.	
Discrete AES Audio Output	The 9083 can provide 8 channels (AES pairs 1 thru 4) of discrete AES audio on 75Ω BNC connections.	
(1) All rates displayed as frame rates; interlaced ("i") field rates are two times the rate value shown.		

Technical Specifications

Table 1-2 lists the technical specifications for the 9083 HD/SD Frame Sync with Audio Embedding/De-Embedding and Dolby® Decoding Option card.

Table 1-2 Technical Specifications

Item	Characteristic
Part number, nomenclature	<ul style="list-style-type: none"> • 9083-ENCD – HD/SD Frame Sync with Audio Embedding/De-Embedding and Dolby® Digital™ (AC-3) Encoder • 9083-ENCE – HD/SD Frame Sync with Audio Embedding/De-Embedding and Dolby® E Encoder
Installation/usage environment	Intended for installation and usage in frame meeting openGear™ modular system definition.
Power consumption	< 15 Watts maximum
Environmental: Operating temperature: Relative humidity (operating or storage):	32° – 104° F (0° – 40° C) < 95%, non-condensing
Frame communication	10/100 Mbps Ethernet with Auto-MDIX.
Indicators	Card edge display and indicators as follows: <ul style="list-style-type: none"> • 4-character alphanumeric display • Status/Error LED indicator • Input Format LED indicator
Controls	Card edge switches as follows: <ul style="list-style-type: none"> • Menu Enter pushbutton switch • Menu Exit pushbutton switch • Up/down selection toggle switch
Internal Tone Generators	Four built-in tone generators, each configurable for 18 discrete sine wave frequencies ranging from 50 Hz to 16 kHz. Generator source signal level is equivalent to -20 dBu.

Table 1-2 Technical Specifications — continued

Item	Characteristic
Serial Digital Video Input	<p>Data Rates Supported: SMPTE 292 HD-SDI: 1.485 Gbps or 1.485/1.001 Gbps SMPTE 259M-C SD-SDI: 270 Mbps</p> <p>Impedance: 75 Ω terminating</p> <p>Equalization (HD): 328 ft (100 m) Belden 1694A</p> <p>Equalization (SD): 1000 ft (305 m) Belden 1694A</p> <p>Return Loss: > 15 dB at 5 MHz – 1.485 GHz</p>
Serial Digital Video Outputs	<p>Number of Outputs: Two processed HD/SD-SDI BNC per IEC 60169-8 Amendment 2 Two buffered reclocked input copies</p> <p>Impedance: 75 Ω</p> <p>Return Loss: > 15 dB at 5 MHz – 270 MHz > 12 dB at 270 MHz – 1.485 GHz</p> <p>Signal Level: 800 mV \pm 10%</p> <p>DC Offset: 0 V \pm 50 mV</p> <p>Jitter (HD): < 0.15 UI (all outputs)</p> <p>Jitter (SD): < 0.10 UI (all outputs)</p> <p>Overshoot: < 0.2% of amplitude</p>
Pre-Processor (Reclocked) Serial Digital Video Outputs	<p>Number of Outputs: Two HD/SD-SDI BNC per IEC 60169-8 Amendment 2</p> <p>Impedance: 75 Ω</p>

Table 1-2 Technical Specifications — continued

Item	Characteristic
AES Audio Input	<p>Standard: SMPTE 276M</p> <p>Number of Inputs (maximum): 8 unbalanced</p> <p>Input Level: 0.1 to 2.5 Vp-p (5 Vp-p tolerant)</p> <p>Input Impedance: 75 Ω</p> <p>Return Loss: > 12 dB at 100 kHz to 6 MHz</p> <p>Resolution: 24-bit only</p> <p>Sample Rate: 48 kHz</p> <p>SRC: 32-channel; 142 dB S/N</p>
AES Audio Output	<p>Standard: SMPTE 276M</p> <p>Number of Outputs (maximum):</p> <ul style="list-style-type: none"> • 4 unbalanced AES • 4 unbalanced Dolby® Digital™ encoded pair output copies <p>Output Impedance: 75 Ω</p> <p>Return Loss: > 30 dB 100 kHz to 6 MHz</p> <p>Sample Rate: 48 kHz</p>
(9083-ENCD only) Dolby® Digital™ Audio Input Encode	Supports up to six audio inputs and provides Dolby® Digital™ (AC-3) encoded pair (available as embedded or discrete AES) per SMPTE 337M.
(9083-ENCE only) Dolby® E Audio Input Encode	Supports up to eight audio inputs and provides Dolby® E encoded pair (available as embedded or discrete AES) per SMPTE 337M.
Dolby® External Metadata Input	User-selectable from de-muxed metadata on input video (per SMPTE 2020-1-2008), or from RS-485 interface.

Table 1-2 Technical Specifications — continued

Item	Characteristic
Analog Audio Input	<p>Number of Inputs (maximum): Eight, 3-wire balanced analog audio using Phoenix connectors with removable screw terminal blocks (Phoenix PN 1803581; Cobalt PN 5000-0013-000R)</p> <p>Sampling Rate: 48 kHz (locked to video input)</p> <p>Signal Level: +24 dBu => 0 dBFS</p> <p>A/D Frequency Response: 20 – 20 kHz \pm 0.25 dB</p>
Reference Video Input	<p>Number of Inputs: Two non-terminating (looping) Frame Reference inputs</p> <p>Standards Supported (HD): 720p 24; 25; 29.97; 30; 50; 59.94 1080i 25; 29.97 1080p 23.98; 24; 25; 29.97; 30 1080p/sF 23.98; 24</p> <p>Standards Supported (SD): 486i 29.97 (NTSC) 575i 25 (PAL)</p> <p>Signal Level: 1 Vp-p nominal</p> <p>Signal Type: Analog video sync (black burst or tri-level)</p> <p>Impedance: 75 Ω</p> <p>Return Loss: > 30 dB to 30 MHz</p> <p>Allowable Maximum DC on Ref Input: \pm1.0 V</p>

Warranty and Service Information

Cobalt Digital Inc. Limited Warranty

This product is warranted to be free from defects in material and workmanship for a period of five (5) years from the date of shipment to the original purchaser, except that 4000, 5000, 6000, 8000 series power supplies, and Dolby® modules (where applicable) are warranted to be free from defects in material and workmanship for a period of one (1) year.

Cobalt Digital Inc.'s ("Cobalt") sole obligation under this warranty shall be limited to, at its option, (i) the repair or (ii) replacement of the product, and the determination of whether a defect is covered under this limited warranty shall be made at the sole discretion of Cobalt.

This limited warranty applies only to the original end-purchaser of the product, and is not assignable or transferrable therefrom. This warranty is limited to defects in material and workmanship, and shall not apply to acts of God, accidents, or negligence on behalf of the purchaser, and shall be voided upon the misuse, abuse, alteration, or modification of the product. Only Cobalt authorized factory representatives are authorized to make repairs to the product, and any unauthorized attempt to repair this product shall immediately void the warranty. Please contact Cobalt Technical Support for more information.

To facilitate the resolution of warranty related issues, Cobalt recommends registering the product by completing and returning a product registration form. In the event of a warrantable defect, the purchaser shall notify Cobalt with a description of the problem, and Cobalt shall provide the purchaser with a Return Material Authorization ("RMA"). For return, defective products should be double boxed, and sufficiently protected, in the original packaging, or equivalent, and shipped to the Cobalt Factory Service Center, postage prepaid and insured for the purchase price. The purchaser should include the RMA number, description of the problem encountered, date purchased, name of dealer purchased from, and serial number with the shipment.

Cobalt Digital Inc. Factory Service Center

2406 E. University Avenue
Urbana, IL 61802 USA
www.cobaltdigital.com

Office: (217) 344-1243
Fax: (217) 344-1245
Email: info@cobaltdigital.com

THIS LIMITED WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND OF ALL OTHER OBLIGATIONS OR LIABILITIES ON COBALT'S PART. ANY SOFTWARE PROVIDED WITH, OR FOR USE WITH, THE PRODUCT IS PROVIDED "AS IS." THE BUYER OF THE PRODUCT ACKNOWLEDGES THAT NO OTHER REPRESENTATIONS WERE MADE OR RELIED UPON WITH RESPECT TO THE QUALITY AND FUNCTION OF THE GOODS HEREIN SOLD. COBALT PRODUCTS ARE NOT AUTHORIZED FOR USE IN LIFE SUPPORT APPLICATIONS.

COBALT'S LIABILITY, WHETHER IN CONTRACT, TORT, WARRANTY, OR OTHERWISE, IS LIMITED TO THE REPAIR OR REPLACEMENT, AT ITS OPTION, OF ANY DEFECTIVE PRODUCT, AND SHALL IN NO EVENT INCLUDE SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS), EVEN IF IT HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Contact Cobalt Digital Inc.

Feel free to contact our thorough and professional support representatives for any of the following:

- Name and address of your local dealer
- Product information and pricing
- Technical support
- Upcoming trade show information

Phone:	(217) 344-1243
Fax:	(217) 344-1245
Web:	www.cobaltdigital.com
General Information:	info@cobaltdigital.com
Technical Support:	support@cobaltdigital.com

This page intentionally blank

Installation and Setup

Overview

This chapter contains the following information:

- Setting I/O Switches for AES I/O (1-4) Ports (p. 2-1)
- Installing the 9083 Into a Frame Slot (p. 2-2)
- Installing a Rear I/O Module (p. 2-5)
- Setting Up 9083 Network Remote Control (p. 2-10)

Setting I/O Switches for AES I/O (1-4) Ports

Note: This procedure is applicable only if any of the four AES I/O (1-4) ports on the 9083 are to be used as **outputs** (the switches are set to input mode by factory default). The 9083 is equipped with a four-section red DIP switch that sets AES pairs 1 thru 4 as either inputs or outputs. The factory default position is the **input** position for each pair.

- If all of the AES I/O (1-4) ports are to be used as inputs (or not used at all), omit this procedure.
- If any of the AES I/O (1-4) ports are to be used as outputs, set the switches as described in this procedure.

Note switch S11 thru S14 settings for **AES I/O 1** thru **AES I/O 4** mode shown in Figure 2-1. For port to be used as an **output**, set switch to down position as shown in Figure 2-1.

Note: Regardless of S11 thru S14 settings for **AES I/O 1** thru **AES I/O 4**, outputs **AES OUT (1-4)** are still available on cards equipped with a Rear I/O Module having dedicated **AES OUT** BNC connectors.




Figure 2-1 9083 AES I/O (1-4) Mode Switches

Installing the 9083 Into a Frame Slot

CAUTION

Heat and power distribution requirements within a frame may dictate specific slot placement of cards. Cards with many heat-producing components should be arranged to avoid areas of excess heat build-up, particularly in frames using only convection cooling. The 9083 has a moderate power dissipation (15 W max.). As such, avoiding placing the card adjacent to other cards with similar dissipation values if possible.

CAUTION



This device contains semiconductor devices which are susceptible to serious damage from Electrostatic Discharge (ESD). ESD damage may not be immediately apparent and can affect the long-term reliability of the device.

Avoid handling circuit boards in high static environments such as carpeted areas, and when wearing synthetic fiber clothing. Always use proper ESD handling precautions and equipment when working on circuit boards and related equipment.

- Note:**
- **If installing the 9083 in an 8310-C-BNC or 8310-BNC frame** (which is pre-equipped with a 100-BNC rear I/O module installed across the entire backplane) or a slot already equipped with a suitable I/O module, proceed to card installation steps below.
 - **If installing the 9083 in a slot with no rear I/O module, a Rear I/O Module is required** before cabling can be connected. Refer to Installing a Rear I/O Module (p. 2-5) for rear I/O module installation procedure.

CAUTION

If required, make certain Rear I/O Module(s) is installed before installing the 9083 into the frame slot. Damage to card and/or Rear I/O Module can occur if module installation is attempted with card already installed in slot.

- Note:** Check the packaging in which the 9083 was shipped for any extra items such as a Rear I/O Module connection label. In some cases, this label is shipped with the card and should be installed on the Rear I/O connector bank corresponding to the slot location of the card.

Install the 9083 into a frame slot as follows:

1. Determine the slot in which the 9083 is to be installed.
2. Open the frame front access panel.
3. While holding the card by the card edges, align the card such that the plastic ejector tab is on the bottom.
4. Align the card with the top and bottom guides of the slot in which the card is being installed.
5. Gradually slide the card into the slot. When resistance is noticed, gently continue pushing the card until its rear printed circuit edge terminals engage fully into the rear I/O module mating connector.

CAUTION

If card resists fully engaging in rear I/O module mating connector, check for alignment and proper insertion in slot tracks. Damage to card and/or rear I/O module may occur if improper card insertion is attempted.

6. Verify that the card is fully engaged in rear I/O module mating connector.
7. Close the frame front access panel.

8. Connect the input and output cables as follows:

- If the 9083 is being installed in a PN 8310-BNC or 8310-C-BNC frame, refer to the label on the connector bank corresponding to the card's slot location for connector designations.
- If the 9083 is being installed in a PN 8310-C frame using a 9083 Rear I/O Module (PN RM-9083-A thru RM-9083-H), connect cabling in accordance with the appropriate diagram shown in Table 2-1, "9083 Rear I/O Modules" (p. 2-6).

9. Repeat steps 1 through 8 for other 9083 cards.

Note: The 9083 BNC inputs are internally 75-ohm terminated. It is not necessary to terminate unused BNC inputs or outputs.

Note: To remove a card, press down on the ejector tab to unseat the card from the rear I/O module mating connector. Evenly draw the card from its slot.

10. If network remote control is to be used for the frame and the frame has not yet been set up for remote control, perform setup in accordance with Cobalt® reference guide "COMPASS™ Remote Control User Guide (PN 9000RCS-RM)".

Note: If installing a card in a frame already equipped for, and connected to DashBoard™, no network setup is required for the card. The card will be discovered by DashBoard™ and be ready for use.

Installing a Rear I/O Module

Note: This procedure is applicable **only if a Rear I/O Module is not currently installed** in the slot where the 9083 is to be installed.

If installing the 9083 in a 8310-C-BNC or 8310-BNC frame (which is pre-equipped with a 100-BNC rear I/O module installed across the entire backplane) or a slot already equipped with a suitable I/O module, omit this procedure.

The full assortment of 9083 Rear I/O Modules is shown and described in 9083 Rear I/O Modules (p. 2-6). Install a Rear I/O Module as follows:

1. On the 8310 frame, determine the slot in which the 9083 is to be installed.
2. In the mounting area corresponding to the slot location, install Rear I/O Module as shown in Figure 2-2.




Figure 2-2 Rear I/O Module Installation

9083 Rear I/O Modules

Table 2-1 shows and describes the full assortment of Rear I/O Modules specifically for use with the 9083.

Note: Rear I/O Modules equipped with 3-wire Phoenix connectors are supplied with removable screw terminal block adapters. For clarity, the adapters are omitted in the drawings below.

Table 2-1 9083 Rear I/O Modules



9083 Rear I/O Module	Description
<p>RM-9083-A</p> 	<p>Provides the following connections:</p> <ul style="list-style-type: none"> • HD/SD-SDI coaxial input (SDI IN) • Two HD/SD-SDI reclocked input copies (RCK OUT) • Four AES I/O coaxial input/outputs (AES I/O 1 thru AES I/O 4; I/O function of each connection is user-configurable) • Two buffered SDI coaxial outputs (SDI OUT)
<p>RM-9083-B</p> 	<p>Provides the following connections:</p> <ul style="list-style-type: none"> • HD/SD-SDI coaxial input (SDI IN) • Six analog balanced audio inputs (AN-AUD IN 1 thru AN-AUD IN 6) • Two buffered SDI coaxial outputs (SDI OUT)

Table 2-1 9083 Rear I/O Modules — continued



9083 Rear I/O Module	Description
<p>RM-9083-C</p> 	<p>Provides the following connections:</p> <ul style="list-style-type: none"> • HD/SD-SDI coaxial input (SDI IN) • Four AES I/O coaxial input/outputs (AES I/O 1 thru AES I/O 4; I/O function of each connection is user-configurable) • Two dedicated AES coaxial audio inputs (AES IN 5 and AES IN 6) • Eight analog balanced audio inputs (AN-AUD IN 1 thru AN-AUD IN 8) • Two dedicated AES coaxial audio outputs (AES OUT 1 and AES OUT 2) <p>Note: AES OUT 1 and AES OUT 2 on RM-9083-C Rear I/O Module always function as outputs regardless of whether AES I/O 1 or AES I/O 2 are used as inputs or outputs.</p> <ul style="list-style-type: none"> • Two buffered SDI coaxial outputs (SDI OUT)
<p>RM-9083-D</p> 	<p>Provides the following connections:</p> <ul style="list-style-type: none"> • HD/SD-SDI coaxial input (SDI IN) • Four AES I/O coaxial input/outputs (AES I/O 1 thru AES I/O 4; I/O function of each connection is user-configurable) • Eight analog balanced audio inputs (AN-AUD IN 1 thru AN-AUD IN 8) • Dolby® RS-485 metadata input (DOLBY META) • Two dedicated AES coaxial audio outputs (AES OUT 1 and AES OUT 2) <p>Note: AES OUT 1 and AES OUT 2 on RM-9083-D Rear I/O Module always function as outputs regardless of whether AES I/O 1 or AES I/O 2 are used as inputs or outputs.</p> <ul style="list-style-type: none"> • Two buffered SDI coaxial outputs (SDI OUT)

Table 2-1 9083 Rear I/O Modules — continued



9083 Rear I/O Module	Description
<p>RM-9083-E</p> 	<p>Provides the following connections:</p> <ul style="list-style-type: none"> • HD/SD-SDI coaxial input (SDI IN) • Four AES I/O coaxial input/outputs (AES I/O 1 thru AES I/O 4; I/O function of each connection is user-configurable) • Three dedicated AES coaxial audio inputs (AES IN 5, AES IN 6, AES IN 8) • Dolby® RS-485 metadata input (DOLBY META) • Four dedicated AES coaxial audio outputs (AES OUT 1 thru AES OUT 4) <p>Note: AES OUT 1 and AES OUT 4 on RM-9083-E Rear I/O Module always function as outputs regardless of whether AES I/O 1 thru AES I/O 4 are used as inputs or outputs.</p> <p>Note: AES OUT 5 thru AES OUT 8 on 9083 always function as Dolby® encoded pair copies.</p> <ul style="list-style-type: none"> • Two buffered SDI coaxial outputs (SDI OUT)
<p>RM-9083-F</p> 	<p>Provides the following connections:</p> <ul style="list-style-type: none"> • HD/SD-SDI coaxial input (SDI IN) • Five AES coaxial inputs (AES IN 1 thru AES IN 4; AES IN 8) <p>Note: For AES IN 1 thru AES IN 4 on RM-9083-F Rear I/O Module to function as inputs, AES I/O switches S11 – S14 must be set to Input (factory default). See Setting I/O Switches for AES I/O (1-4) Ports (p. 2-1) for more information.</p> <ul style="list-style-type: none"> • Two dedicated AES coaxial audio outputs (AES OUT 1 and AES OUT 2) • Two buffered SDI coaxial outputs (SDI OUT)

Table 2-1 9083 Rear I/O Modules — continued

9083 Rear I/O Module	Description
RM-9083-G	<p>Provides the following connections:</p> <ul style="list-style-type: none"> • HD/SD-SDI coaxial input (SDI IN) • Two HD/SD-SDI reclocked input copies (RCK OUT) • Eight dedicated AES coaxial audio inputs (AES IN 1 thru AES IN 8) <ul style="list-style-type: none"> Note: For AES IN 1 thru AES IN 4 on RM-9083-G Rear I/O Module to function as inputs, AES I/O switches S11 – S14 must be set to Input (factory default). See Setting I/O Switches for AES I/O (1-4) Ports (p. 2-1) for more information. • Eight analog balanced audio inputs (AN-AUD IN 1 thru AN-AUD IN 8) • Four dedicated AES coaxial audio outputs (AES OUT 1 thru AES OUT 4) <ul style="list-style-type: none"> Note: AES OUT 5 thru AES OUT 8 on 9083 always function as Dolby® encoded pair copies. • Two buffered SDI coaxial outputs (SDI OUT)
RM-9083-H	<p>Provides the following connections:</p> <ul style="list-style-type: none"> • HD/SD-SDI coaxial input (SDI IN) • Four dedicated AES coaxial audio inputs (AES IN 5 thru AES IN 8) • Four AES I/O coaxial input/outputs (AES I/O 1 thru AES I/O 4; I/O function of each connection is user-configurable) • Four dedicated AES coaxial audio outputs (AES OUT 1 thru AES OUT 4) <ul style="list-style-type: none"> Note: AES OUT 1 thru AES OUT 4 on RM-9083-H Rear I/O Module always function as outputs regardless of whether AES I/O 1 thru AES I/O 4 are used as inputs or outputs. • Two buffered SDI coaxial outputs (SDI OUT)

Setting Up 9083 Network Remote Control

Perform remote control setup in accordance with Cobalt® reference guide “COMPASS™ Remote Control User Guide (PN 9000RCS-RM)”.

- Note:**
- If network remote control is to be used for the frame and the frame has not yet been set up for remote control, Cobalt® reference guide **COMPASS™ Remote Control User Guide (PN 9000RCS-RM)** provides thorough information and step-by-step instructions for setting up network remote control of COMPASS™ cards using DashBoard™. (Cobalt® OGCP-9000 and OGCP-9000/CC Remote Control Panel product manuals have complete instructions for setting up remote control using a Remote Control Panel.)
Download a copy of this guide by clicking on the **Support>Downloads** link at www.cobaltdigital.com and then select DashBoard Remote Control Setup Guide as a download, or contact Cobalt® as listed in Contact Cobalt Digital Inc. (p. 1-29).
 - If installing a card in a frame already equipped for, and connected to DashBoard™, no network setup is required for the card. The card will be discovered by DashBoard™ and be ready for use.

Operating Instructions

Overview

This chapter contains the following information:

- Control and Display Descriptions (p. 3-1)
- Accessing the 9083 Card via Remote Control (p. 3-12)
- Checking 9083 Card Information (p. 3-14)
- Ancillary Data Line Number Locations and Ranges (p. 3-15)
- 9083 Function Submenu List and Descriptions (p. 3-16)
- Troubleshooting (p. 3-73)

Control and Display Descriptions

This section describes the user interface controls, indicators, and displays (both on-card and remote controls) for using the 9083 card. The 9083 functions can be accessed and controlled using any of the user interfaces described here.

The format in which the 9083 functional controls, indicators, and displays appear and are used varies depending on the user interface being used. Regardless of the user interface being used, access to the 9083 functions (and the controls, indicators, and displays related to a particular function) follows a general arrangement of Function Submenus under which related parameters can be accessed (as described in Function Submenu/Parameter Submenu Overview below).

After familiarizing yourself with the arrangement described in Function Submenu/Parameter Submenu Overview, proceed to the subsection for the particular user interface being used. Descriptions and general instructions for using each of the three user interfaces are individually described in the following subsections:

- 9083 Card Edge Controls, Indicators, and Display (p. 3-3)
- DashBoard™ User Interface (p. 3-8)
- Cobalt® Remote Control Panel User Interfaces (p. 3-11)

- Note:** Instructions provided here are applicable for all available user control methods. However, DashBoard™ and the Remote Control Panel provide greatly simplified user interfaces as compared to using the 9083 card edge controls. For this reason, **it is strongly recommended** that DashBoard™ or a Remote Control Panel be used for all 9083 applications other than the most basic cases.
- Note:** Not all functions available using DashBoard™ or the Control Panel are available using the card edge controls.
- Note:** When a setting is changed, settings displayed on DashBoard™ (or the Remote Control Panel) are the settings as effected by the 9083 card itself and reported back to the remote control; the value displayed at any time is the actual value as set on the card.

Function Submenu/Parameter Submenu Overview

The functions and related parameters available on the 9083 card are organized into function **submenus**, which consist of parameter groups as shown below.

Figure 3-1 shows how the 9083 card and its submenus are organized, and also provides an overview of how navigation is performed between cards, function submenus, and parameters.




Figure 3-1 Function Submenu/Parameter Submenu Overview

9083 Card Edge Controls, Indicators, and Display

Figure 3-2 shows and describes the 9083 card edge controls, indicators, and display.




Figure 3-2 9083 Controls, Indicators, and Display

9083 Card Edge Control Menu/Submenu Structure

(See below.) Using the menu system of group menus and submenus described earlier, the 9083 parameters/controls are organized into menus and submenus. As appropriate, a submenu similarly may have its own further additional subordinate submenus.

Menu Group Item	Menu Depth	Menu depth (as indicated by 9083 Menu Depth LEDs)
		none
Submenu 1 (Submenu 1 selection items)	1	● ○ ○ ○
Submenu 2 (Submenu 2 selection items)	2	● ● ○ ○
Submenu 3 (Submenu 3 selection items and/or parameter values)	3	● ● ● ○
Submenu 4 (Submenu 4 selection items and/or parameter values)	4	● ● ● ●

Figure 3-3 shows an example of using the card edge controls to access the Embedded Audio processing group menu (along with some of its submenus) to set the routing and signal processing parameters for an embedded audio channel. (A) through (S) in Figure 3-3 denote the discrete tasks required in performing the example setup using the 9083 card edge controls.

In this example, the following input processing is being performed:

- Embedded Channel 3 is selected as the source for Embedded Channel 1 within Embedded Audio Group 1.
- Gain is increased over unity default by 12.1.
- Phase is inverted.

In this example, the following output processing is being performed:

- The embedded Channel 1 path has been directed to AES Output Channel 1.
- Gain is increased over unity output default by 18.5.
- Phase is normal (non-inverted).

Due to the limited control available when using the built-in card edge control user interface, the navigation into and out of submenus shown in Figure 3-3 is required to perform the setup described above.

Embedded Audio				Select a top-level menu item (in this example, select Aud (embedded audio routing/control))	
Submenu Depth					
	1	2	3	4	
(A)	Embd AES Tone				Press Enter Menu and in this example, select Embd (Embedded Audio Groups). This selects embedded audio function of the Audio processor.
(B)		Grp1 Grp2 Grp3 Grp4			Press Enter Menu again and in this example, select Grp1 (Embedded Audio Group 1). This selects the embedded audio group to be accessed.
(C)			Enbl		Press Enter Menu again and in this example, select Enbl (Enable).
(D)				On Off	Press Enter Menu again and in this example, select On . This sets the selected embedded audio group to Enabled .
(E)			Ch01 Ch02 Ch03 Ch04		Press Exit Menu and in this example, select Ch01 (Destination: Embedded Channel 1). This selects the embedded channel to be accessed.
(F)				Src Gain Pol	Press Enter Menu and select in this example, Src (source for embedded channel 1). This selects the source for the embedded channel.
(G)				Em01 Em02 Em03 ...	Press Enter Menu again and in this example, select Em03 (embeddded channel 3 as source for embedded channel 1). This selects embedded channel 3 as the source for embedded channel 1.
(H)				Src Gain Pol	Press Exit Menu and in this example, select Gain (gain adjustment field for selected embedded audio channel).
(I)				(gain value)	Press Enter Menu again and in this example, select a gain value of 12.1 for this channel.
(J)				Src Gain Pol	Press Exit Menu and in this example, select Pol (phase for embedded channel 1).
(K)				Norm Inv	Press Enter Menu again and in this example, select Inv (invert polarity for embedded channel 1).
(continued on next page)					

(continued on next page)

Figure 3-3 Card Edge Controls Setup of Example Embedded Audio Function (sheet 1 of 2)

Submenu Depth					(continued from previous page)
	1	2	3	4	
(L)	Embd AES Tone				Go to submenu 1 and in this example, select AES (AES output channel selection). This selects an AES output channel as the output for this group.
(M)		Ch01 Ch02 Ch03 ...			Press Enter Menu and in this example, select Ch01 (AES Output Channel 1).
(N)			Src Gain Pol		Press Enter Menu again and select in this example, Src (source for AES Output Channel 1).
(O)				Em01 Em02 Em03 ...	Press Enter Menu again and in this example, select Em01 (Embeddded Channel 1 as source for AES Output Channel 1).
(P)			Src Gain Pol		Press Exit Menu and in this example, select Gain (gain adjustment field for selected AES output channel).
(Q)				(gain value)	Press Enter Menu and in this example, select a gain value of 18.5 for this channel.
(R)			Src Gain Pol		Press Exit Menu and in this example, select Pol (polarity for Embedded Channel 1).
(S)				Norm Inv	Press Enter Menu and in this example, select Norm (no invert for AES output channel 1).

Card Edge Setup Abbreviated Diagram

In Table 3-2, "9083 Function Submenu List" abbreviated diagrams (as shown above and in the example to the right) show the navigation required to access a particular submenu item or parameter when using the card edge controls.

In this example, group enable for Embedded Audio Group 1 is being enabled.

Card Edge Control Menu:

Aud

1	2	3	4
Embd	Grp1	Enbl	On Off

Set embedded audio group to On
Set embedded audio group to Off

Figure 3-3 Card Edge Controls Setup of Example Embedded Audio Function (sheet 2 of 2)

Card Edge Display Orientation, Brightness, and Timeout Adjust

The card edge 4-Character Alphanumeric Display can be changed between vertical or horizontal character orientation to suit the mounting position of the card as shown and described below.






Figure 3-4 Card Edge Display Orientation

1. Access the **Displ** (Display) menu.
2. Select between Horizontal or Vertical as shown below.



Adjust the display brightness as described below.

1. Access the **Displ** (Display) menu.
2. Select from the relative brightness levels as shown below.



The timeout period from when a menu is entered to when the display times out (reverts to the default card model display) can be adjusted from 5 to 9999 seconds (166.7 minutes) as described below.

1. Access the **Displ** (Display) menu.
2. Use the up/down switch to enter the desired timeout value as shown below.

Card Edge Control Menu:

Disp

1

2

TOUT (value)

Timeout value (in seconds)

DashBoard™ User Interface

(See Figure 3-5.) The 9083 function submenus are organized in DashBoard™ using tabs (for example, “Embedded Audio Group 1/2” in Figure 3-5). When a tab is selected, each parametric control or selection list item associated with the function is displayed. Scalar (numeric) parametric values can then be adjusted as desired using the GUI slider controls. Items in a list can then be selected using GUI drop-down lists. (In this manner, the setting effected using controls and selection lists displayed in DashBoard™ are comparable to the submenu items accessed and committed using the 9083 card edge controls.)

Figure 3-5 shows the same setup described in Figure 3-3 as performed using DashBoard™. Note how this setup is greatly simplified using DashBoard™ with most of the discrete tasks ((A) through (S) in Figure 3-3) performed with the card edge controls now rolled into simple actions using DashBoard™.




Figure 3-5 DashBoard™ Setup of Example Embedded Audio Function (sheet 1 of 2)




Figure 3-5 DashBoard™ Setup of Example Embedded Audio Function (sheet 2 of 2)

Cobalt® Remote Control Panel User Interfaces

(See Figure 3-6.) Similar to the function submenu tabs using DashBoard™, the OGCP-9000 (and OGCP-9000/CC) Remote Control Panels have a Select Submenu key that is used to display a list of function submenus. From this list, a control knob on the Control Panel is used to select a function from the list of displayed function submenu items.

When the desired function submenu is selected, each parametric control or selection list item associated with the function is displayed. Scalar (numeric) parametric values can then be adjusted as desired using the control knobs, which act as potentiometers. Items in a list can then be selected using the control knobs which correspondingly act as rotary switches. (In this manner, the setting effected using controls and selection lists displayed on the Control Panel are comparable to the submenu items accessed and committed using the 9083 card edge controls.)

Figure 3-6 shows accessing a function submenu and its parameters (in this example, “Embedded Audio Output Group 1/2”) using the Control Panel as compared to using the card edge controls.

Note: Refer to “OGCP-9000 Remote Control Panel User Manual” (PN OGCP-9000-OM) or “OGCP-9000/CC Remote Control Panel User Manual” (PN OGCP-9000/CC-OM) for complete instructions on using the Control Panels.





Figure 3-6 Control Panel Setup of Example Audio Control Function

Accessing the 9083 Card via Remote Control


Access the 9083 card using DashBoard™ or Cobalt® Remote Control Panel as described below.

Accessing the 9083 Card Using DashBoard™


1. On the computer connected to the frame LAN, open DashBoard™.
2. As shown below, in the left side Basic View Tree locate the Network Controller Card associated with the frame containing the 9083 card to be accessed (in this example, “MFC-8310-N SN: 00108053”).



3. As shown below, expand the tree to access the cards within the frame. Click on the card to be accessed (in this example, “Slot 7: CDI-9083-ENCE”).




As shown on the next page, when the card is accessed a DashBoard™ its function submenu screen showing tabs for each function is displayed. (The particular submenu screen displayed is the previously displayed screen from the last time the card was accessed by DashBoard™).



Accessing the 9083 Card Using a Cobalt® Remote Control Panel

Press the **Select Device** key and select a card as shown in the example below.



Checking 9083 Card Information

The operating status and software version the card can be checked using DashBoard™ or the card edge control user interface. Figure 3-7 shows and describes the 9083 card information screen using DashBoard™ and accessing card information using the card edge control user interface.

Note: Proper operating status in DashBoard™ is denoted by green icons for the status indicators shown in Figure 3-7. Yellow or red icons respectively indicate an alert or failure condition. Refer to Troubleshooting (p. 3-73) for corrective action.

The **Tree View** shows the cards seen by DashBoard™. In this example, Network Controller Card MFC-8310-N (serial number ...8053) is hosting a 9083-ENCE card in slot 7.

Software Version Number
Refer to this number to check that documentation (such as this manual) matches the card's Software Version Number. Use this number also when communicating to Cobalt® regarding this card.

Power Consumption and Temperature Displays
This display shows the power consumed by the 9083 for both the +12V and -7.5V rails, as well as key device temperatures.

Status Displays
These displays show the status the signal being received by the 9083. Green Settings icon shows that any changes made on DashBoard™ are successfully saved on the card's memory.

The screenshot shows the DashBoard™ interface. On the left, the 'Tree View' displays a hierarchy: 'MFC-8310-N SN: 00108053' with a green status icon, and under it, 'Slot 0: MFC-8310-N' and 'Slot 7: CDI-9083-ENCE'. The main panel shows 'CDI-9083-ENCE' with 'Card state: OK' and 'Connection: ONLINE'. Below this is the 'Card Info' section with the following fields: Product (CDI-9083-ENCE), Manufacturer (Cobalt Digital Inc.), Software Version (4.0.2823), FPGA Build Number (2780.5), DSP (Count: 2, Version: 2609), +12V Power Rail (12.7 W), -7.5V Power Rail (0.974 W), Temperature Sensor 1 (26 C), Temperature Sensor 2 (29.8 C), Video Input Standard (1080i_5994), Reference Standard (Reference 1: 525i_5994), SSN (0000137ACB77), Video (OK), Audio (OK), Frame Sync (OK), and Settings (Saved).

Checking Card Using Card Edge Controls		Info
1	2	
+POW	(value)	+12V Watts consumed
-POW	(value)	- 7.5V Watts consumed
SWR#	(value)	Software Release Number
SWB#	(value)	Software Build Number
FPG#	(value)	FPGA Build Number

Figure 3-7 9083 Card Info Utility

Ancillary Data Line Number Locations and Ranges

Table 3-1 lists typical default output video VANC line number locations for various ancillary data items that may be passed or handled by the card.

Table 3-1 Typical Ancillary Data Line Number Locations/Ranges

Item	Default Line No. / Range	
	SD	HD
AFD	12 (Note 2)	9 (Note 2)
ATC_VITC	12 (locked)	9/8 (Note 2)
ATC_LTC	—	10 (Note 2)
Dolby [®] Metadata	13 (Note 2)	13 (Note 2)
SDI VITC Waveform	14/16 (Note 2)	—
Closed Captioning	21 (locked)	10 (Note 2)

Notes:

- The card does not check for conflicts on a given line number. Make certain the selected line is available and carrying no other data.
- While range indicated by drop-down list on GUI may allow a particular range of choices, the actual range is automatically clamped (limited) to certain ranges to prevent inadvertent conflict with active picture area depending on video format. Limiting ranges for various output formats are as follows:

Format	Line No. Limiting	Format	Line No. Limiting	Format	Line No. Limiting
525i	12-19	720p	9-25	1080p	9-41
625i	9-22	1080i	9-20		

Because line number allocation is not standardized for all ancillary items, consideration should be given to all items when performing set-ups. Figure 3-8 shows an example of improper and corrected VANC allocation within an HD-SDI stream.





Figure 3-8 Example VANC Line Number Allocation Example

9083 Function Submenu List and Descriptions

Table 3-2 individually lists and describes each 9083 function submenu (“tab”) and its related list selections, controls, and parameters. Where helpful, examples showing usage of a function are also provided. Table 3-2 is primarily based upon using DashBoard™ to access each function and its corresponding submenus and parameters.

Note: All numeric (scalar) parameters displayed on DashBoard™ can be changed using the slider controls,  arrows, or by numeric keypad entry in the corresponding numeric field. (When using numeric keypad entry, add a return after the entry to commit the entry.)

Note: Table 3-2 also provides abbreviated menu structure charts showing the menu structure for accessing the function/parameter using the card edge controls. If using card edge controls, refer to 9083 Card Edge Control Menu/Submenu Structure (p. 3-4) and Figure 3-3 for an explanation and an example of card edge control menu structure navigation. Where a card edge menu is not shown for a particular control, this indicates the control is **not** available using card edge controls.

On DashBoard™ itself and in Table 3-2, the function submenu items are organized using tabs as shown below.



The table below provides a quick-reference to the page numbers where each function submenu item can be found.

Function Submenu Item	Page	Function Submenu Item	Page
Audio Input Controls	3-17	9083-ENCD Dolby® Functions (Table 3-3)	
AFD	3-20	Dolby Digital Encoder	3-51
Framesync	3-21	Dolby Digital External Metadata	3-54
Embedded Audio Group 1/2	3-27	Dolby Digital Internal Metadata	3-56
Embedded Audio Group 3/4	3-33	Dolby Digital Channel Mapping	3-57
Audio LKFS Monitor	3-35	9083-ENCE Dolby® Functions (Table 3-4)	
AES Audio Out Pairs 1-4	3-38	Dolby E Encoder	3-59
Audio Mixing	3-43	Dolby E External Metadata	3-60
Tone Generator	3-48	Dolby E Internal Metadata	3-63
Licensable Features	3-48	Dolby E Channel Mapping	3-64
Presets	3-49		

Table 3-2 9083 Function Submenu List

Audio Input Controls

Controls the AES Audio Input features for the eight AES input pairs, and displays signal status for the AES pairs and the 16 embedded audio channels. Also provides global unity routing/parameter control resets.

Note: Also refer to AES Audio Input Advanced Features (p. 1-12) in Chapter 1, "Introduction" for detailed information regarding these functions.

• AES SRC

AES SRC

Pair 1 Disabled

Pair 2 Enabled

...

Pair 8 Disabled

Card Edge Control Menu:

Aud	1	2	3	4
AES		SBYP	AES(n)	
				Apply to AES pair (1 thru 8)
				On Off
				SRC Bypass turned on SRC Enabled (Bypass turned off)

Individual SRC **Disable** control for each AES pair (1 thru 8) disables or enables Sample Rate Conversion (SRC) bypass as follows:

• **Disabled:** In this mode, AES SRC for the corresponding AES pair is **bypassed**. SRC is set to **Disabled** by default. This mode is preferred where the AES rate matches the input video rate. This mode is necessary when embedding non-PCM AES audio such as Dolby® E or Dolby Digital™ audio streams.

Note: In this mode AES rate must match the input video rate or audio dropouts will occur.

Note: AES audio must be nominally 48 kHz.

• **Enabled:** In this mode, AES SRC for the corresponding AES input pair is **enabled**. SRC enabled allows the 9083 to interface with asynchronous AES sources (sources in which the AES timing does not match the video reference timing). SRC can be used to compensate for minor clock rate differences in the AES stream and the input video stream.

• AES Passthrough

AES Passthrough

Pair 1 Off

Pair 2 On

...

Pair 8 Off

Card Edge Control Menu:

Aud	1	2	3	4
AES		PASS	AES(n)	
				Apply to AES pair (1 thru 8)
				Off On
				Passthrough Disabled Passthrough Enabled

Individual AES Passthrough **On/Off** control for each AES pair (1 thru 8) disables or enables Passthrough as follows:

• **Off:** Disables AES passthrough for the selected AES input pair. Passthrough is set to **Off** by default.

• **On:** Passthrough is turned on, with the corresponding AES output pair to act as a bit-for-bit copy with zero delay of the corresponding AES input pair.


Note: AES Passthrough set to **On** overrides normal audio routing. Gain and polarity control is not available when AES passthrough is enabled.

Table 3-2 9083 Function Submenu List — continued

Audio Input Controls

(continued)

AES Zero Delay Embedding



AES	Zero Delay Embedding
Pair 1	Off
Pair 2	On
...	
Pair 8	Off

Card Edge Control Menu:


Aud	1	2	3	4
AES		ODLY	AES(n)	
				Apply to AES pair (1 thru 8)
				Off Zero-Delay Embedding Disabled
				On Zero-Delay Embedding Enabled

Individual AES Zero-Delay Embedding **On/Off** control for each AES pair (1 thru 8) disables or enables Zero-Delay Embedding as follows:

- **Off:** Disables Zero-Delay Embedding for the selected AES input pair. Zero-delay embedding is set to **Off** by default.
- **On:** The selected pair directly embeds into its corresponding group (AES Pair 1 embeds into embedded channels 1 and 2; AES pair 2 embeds into embedded channels 3 and 4, and so on) with the normal frame sync audio delay being bypassed.

Note: Zero Delay Embedding overrides the standard audio routing system. For example, if AES Pair 1 is selected, then the controls to route into embedded channels 1 and 2 will not apply. Gain and polarity control is not available when zero-delay embedding is enabled.

Status Displays




AES	Status
Pair 1	Not Present
Pair 2	Present, Professional
...	
Pair 8	Not Present

Individual signal status displays for AES pairs 1-8, and embedded audio channels 1-16 as follows:

- **Not Present:** Indicates AES pair or embedded channel does not contain recognized audio PCM data.
- **Note:** Channel displaying Not Present may still carry usable audio data with **Not Present** being displayed due to invalid headers.
- **Present, Professional:** Indicates AES pair or embedded channel contains recognized AES audio PCM data.
- **Present, Consumer:** Indicates AES pair or embedded channel contains audio PCM data other than AES (for example, S/PDIF).
- **Present, Dolby E:** Indicates AES pair or embedded channel contains Dolby® E encoded data.
- **Present, Dolby Digital:** Indicates AES pair or embedded channel contains Dolby® Digital encoded data.

Note: Dolby status displays shown to the left only occur for valid Dolby® signals meeting SMPTE 337M standard.



Embedded Group	Channel	Status
Embedded Group 1	Channel 1	Present, Professional
...		
Embedded Group 4	Channel 16	Present, Dolby E

The 9083 card does not perform Dolby® decoding on the signal. Although the 9083 controls will appear to be usable for this signal tag, the signal is passed with 1-to-1 routing and all related gain and polarity controls set to unity.

Table 3-2 9083 Function Submenu List — continued







	(continued)
<p>• Embedded Unity Channel Selection</p> 	<p>Selects unity reset of Embedded Audio Group 1/2 and 3/4 controls and re-establishes default 1-to-1 routing as follows:</p> <ul style="list-style-type: none"> • Embedded: Routes Embedded Ch 1 thru Ch 16 as sources to destination channels Embedded Ch 1 thru Embedded Ch 16. • AES: Routes AES Ch 1 thru Ch 16 as sources to destination channels Embedded Ch 1 thru Embedded Ch 16. • Analog: Routes Analog Ch 1 thru Ch 8 as sources to destination channels Embedded Ch 1 thru Embedded Ch 8. Sets Embedded Ch 9 thru Ch 16 to Silence.
<p>• AES Unity Channel Selection</p> 	<p>Selects unity reset of AES Outputs Pairs 1-4 and 5-8 controls and re-establishes default 1-to-1 routing as follows:</p> <ul style="list-style-type: none"> • Embedded: Routes Embedded Ch 1 thru Ch 8 as sources to destination channels AES Ch 1 thru AES Ch 8. • AES: Routes AES Ch 1 thru Ch 8 as sources to destination channels AES Ch 1 thru AES Ch 8. • Analog: Routes Analog Ch 1 thru Ch 8 as sources to destination channels AES Ch 1 thru AES Ch 8.
<p>• Dolby Encoder Unity Channel Selection</p> 	<p>Maps selected audio source as the encoder audio inputs and applies default unity parametric settings in Dolby Channel Mapping function tab as described below.</p> <p>Note:</p> <ul style="list-style-type: none"> • (9083-ENCD only) Up to six channels can be sources for encoder inputs Encoder Ch1 thru Encoder Ch 6. • (9083-ENCE only) Up to eight channels can be sources for encoder inputs Encoder Ch1 thru Encoder Ch 8. • Embedded: Routes embedded channel sources as sources to encoder audio inputs. • AES: Routes AES channel sources to encoder audio inputs. • Analog: Routes analog channel sources to encoder audio inputs.
	<p>Applies embedded and AES unity channel selection (as set in the above drop-down lists). To apply the selections, click the Confirm button. When Confirm is clicked, a Confirm? pop-up appears, requesting confirmation.</p> <ul style="list-style-type: none"> • Click Yes to proceed with the unity reset. • Click No to reject unity reset. <p>For any selection following confirm, the destination channel controls are default reset as follows:</p> <ul style="list-style-type: none"> • Gain is to unity • Phase control is set to Normal • Channel is set to Unmuted
<p>• Tie AES and Embedded Controls</p> 	<p>When set to Enabled, gangs Gain, Phase, and Mute controls for same-numbered Embedded and AES channels 1 thru 8. Ganging is bilateral, with Embedded channel control settings affecting corresponding AES channel controls, and vice-versa.</p>

Table 3-2 9083 Function Submenu List — continued

<div>AFD</div>	Allows assignment of AFD (Active Format Description) codes to the SDI output video.																																																																
<p>Note:</p> <ul style="list-style-type: none">• This function only marks the SDI output with an AFD code. Actual AFD processing must be performed by a downstream card or system that recognizes an AFD code assigned here.• Framesync must be enabled for proper AFD insertion.																																																																	
<div><div>Incoming AFD</div><div>16:9 coded frame - 1010 - 16:9 (image protected) -</div></div>	<p>Displays incoming AFD setting as follows:</p> <ul style="list-style-type: none">• If AFD code is present, one of the 11, four-bit AFD codes is displayed (as shown in the example to the left). Also displayed is the VANC line number of the incoming AFD code.• If no AFD setting is present in the video signal, No AFD Present is displayed.																																																																
<div><div>Output Mode</div><div>Pass If Present, Else Insert</div><div>Pass If Present, Else Insert</div><div>Pass Incoming Code</div><div>Replace Incoming Code</div></div>	<p>Drop-down selection determines action to take in presence or absence of existing AFD code on input video.</p>																																																																
<div><div>Output Code</div><div>No AFD</div><div>No AFD</div><div>4:3 - 0000 - Undefined</div><div>4:3 - 0010 - Box 16:9 (top)</div><div>4:3 - 0011 - Box 14:9 (top)</div><div>•</div><div>•</div><div>•</div><div>16:9 - 1111 - 16:9 (w/alt 4:3 center)</div></div>	<p>Drop-down list assigns desired AFD to output SDI.</p> <table><tr><th colspan="4">4:3 Coded Frame</th></tr><tr><th>AFD Code⁽¹⁾</th><th>Description</th><th>AFD Code⁽¹⁾</th><th>Description</th></tr><tr><td>—</td><td>No code present</td><td>1001</td><td>Full frame</td></tr><tr><td>0000</td><td>Undefined</td><td>1010</td><td>16:9 (center)</td></tr><tr><td>0010</td><td>Box 16:9 (top)</td><td>1011</td><td>14:9 (center)</td></tr><tr><td>0011</td><td>Box 14:9 (top)</td><td>1101</td><td>4:3 (with alternate 14:9 center)</td></tr><tr><td>0100</td><td>Box > 16:9 (center)</td><td>1110</td><td>16:9 (with alternate 14:9 center)⁽²⁾</td></tr><tr><td>1000</td><td>Full frame</td><td>1111</td><td>16:9 (with alternate 4:3 center)⁽²⁾</td></tr></table> <table><tr><th colspan="4">16:9 Coded Frame</th></tr><tr><th>AFD Code⁽¹⁾</th><th>Description</th><th>AFD Code⁽¹⁾</th><th>Description</th></tr><tr><td>—</td><td>No code present</td><td>1001</td><td>4:3 (center)</td></tr><tr><td>0000</td><td>Undefined</td><td>1010</td><td>16:9 (image protected)⁽²⁾</td></tr><tr><td>0010</td><td>Full frame</td><td>1011</td><td>14:9 (center)</td></tr><tr><td>0011</td><td>4:3 (center)</td><td>1101</td><td>4:3 (with alternate 14:9 center)</td></tr><tr><td>0100</td><td>Box > 16:9 (center)</td><td>1110</td><td>16:9 (with alternate 14:9 center)⁽²⁾</td></tr><tr><td>1000</td><td>Full frame</td><td>1111</td><td>16:9 (with alternate 4:3 center)⁽²⁾</td></tr></table> <p>1: AFD codes numbering and definitions conform to SMPTE 2016-1-2007.</p> <p>2: Image Protected implies picture content that must not be cropped by conversion processes or display devices. Alternate center formats may have protected center areas, with areas outside of the protected area not containing mandatory content.</p>	4:3 Coded Frame				AFD Code ⁽¹⁾	Description	AFD Code ⁽¹⁾	Description	—	No code present	1001	Full frame	0000	Undefined	1010	16:9 (center)	0010	Box 16:9 (top)	1011	14:9 (center)	0011	Box 14:9 (top)	1101	4:3 (with alternate 14:9 center)	0100	Box > 16:9 (center)	1110	16:9 (with alternate 14:9 center) ⁽²⁾	1000	Full frame	1111	16:9 (with alternate 4:3 center) ⁽²⁾	16:9 Coded Frame				AFD Code ⁽¹⁾	Description	AFD Code ⁽¹⁾	Description	—	No code present	1001	4:3 (center)	0000	Undefined	1010	16:9 (image protected) ⁽²⁾	0010	Full frame	1011	14:9 (center)	0011	4:3 (center)	1101	4:3 (with alternate 14:9 center)	0100	Box > 16:9 (center)	1110	16:9 (with alternate 14:9 center) ⁽²⁾	1000	Full frame	1111	16:9 (with alternate 4:3 center) ⁽²⁾
4:3 Coded Frame																																																																	
AFD Code ⁽¹⁾	Description	AFD Code ⁽¹⁾	Description																																																														
—	No code present	1001	Full frame																																																														
0000	Undefined	1010	16:9 (center)																																																														
0010	Box 16:9 (top)	1011	14:9 (center)																																																														
0011	Box 14:9 (top)	1101	4:3 (with alternate 14:9 center)																																																														
0100	Box > 16:9 (center)	1110	16:9 (with alternate 14:9 center) ⁽²⁾																																																														
1000	Full frame	1111	16:9 (with alternate 4:3 center) ⁽²⁾																																																														
16:9 Coded Frame																																																																	
AFD Code ⁽¹⁾	Description	AFD Code ⁽¹⁾	Description																																																														
—	No code present	1001	4:3 (center)																																																														
0000	Undefined	1010	16:9 (image protected) ⁽²⁾																																																														
0010	Full frame	1011	14:9 (center)																																																														
0011	4:3 (center)	1101	4:3 (with alternate 14:9 center)																																																														
0100	Box > 16:9 (center)	1110	16:9 (with alternate 14:9 center) ⁽²⁾																																																														
1000	Full frame	1111	16:9 (with alternate 4:3 center) ⁽²⁾																																																														
<div><div>Output Line</div><div>9</div></div>	<p>Allows selecting the line location of the AFD data within the video signal Ancillary Data space. (Range is 9 thru 41.)</p> <p>Note:</p> <ul style="list-style-type: none">• Although the output line drop-down will allow any choice within the 9 thru 41 range, the actual range is automatically clamped (limited) to certain ranges to prevent inadvertent conflict with active picture area depending on video format. See Ancillary Data Line Number Locations and Ranges (p. 3-15) for more information.• The card does not check for conflicts on a given line number. Make certain the selected line is available and carrying no other data.																																																																

Table 3-2 9083 Function Submenu List — continued









	<p>Provides video Frame Sync offset and audio re-sync tools.</p>
<p>• Framesync Enable</p>  	<p>Disables the Frame Sync function, or selects from choices below.</p> <ul style="list-style-type: none"> • Off: Disables Frame Sync function; output video timing matches the input video timing. • Reference 1: Allows Frame Sync function to use external Reference 1 as the reference standard. • Reference 2: Allows Frame Sync function to use external Reference 2 as the reference standard. <p>Note: If Reference 1 or Reference 2 is selected and an appropriate external reference is not received, the  Reference Invalid indication appears in the Card Info status portion of DashBoard™, indicating invalid frame sync reference error. (Additionally, the card edge ERR indicator illuminates indicating the same.) External reference signals Reference 1 and Reference 2 are distributed to the 9083 and other cards via an 8310 frame bus.</p> <ul style="list-style-type: none"> • Input Video: Uses the input video signal as the reference standard. <p>Note: If Input Video is used for framesync, any timing instability on the input video will result in corresponding instability on the output video.</p>
<p>• Vertical Delay Control</p>  	<p>When Framesync is enabled, sets vertical delay (in number of lines of output video/format) between the output video and the frame sync reference.</p> <p>(Range is -1124 thru 1124 lines.)</p> <p>Note: Lines refer to lines in the output video format, and not to the reference format.</p>
<p>• Horizontal Delay Control</p>  	<p>When Framesync is enabled, sets (in usec of output video timing) horizontal delay between the output video and the frame sync reference.</p> <p>(Range is -64.000 thru 64.000 usec)</p> <p>Note: When an external framesync reference is used, the card will not produce a framesync reset until the variance between framesync reference and output video exceeds ± 2 clock periods. Therefore, a framesync reset will not result if offsets within this window are applied.</p> <p>To apply an offset/framesync reset within this window, first apply a relatively large offset, then apply the target smaller offset.</p> <p>Example: To apply a 1-period offset, first apply a 10-period positive offset and then apply a 9-period negative offset. This results in the target 1-period offset being applied to the output video.</p>

Table 3-2 9083 Function Submenu List — continued





Framesync	(continued)				
<p>• Minimum Latency Control</p>  <p>Minimum Latency (Frames) 0</p> <div data-bbox="240 554 594 726"> <p>Card Edge Control Menu:</p> <p>FS</p> <table border="1"> <tr> <td>1</td> <td>2</td> </tr> <tr> <td>LATF</td> <td>(value)</td> </tr> </table> <p>Min. Latency (in frames)</p> </div>	1	2	LATF	(value)	<p>When Framesync is enabled, specifies the smallest amount of latency allowed by the frame sync (latency measurement in output video frames). The frame sync will not output a frame unless the specified number of frames are captured in the buffer. The operational latency of the frame sync is always between the specified minimum latency and minimum latency plus one frame (not one field). (0 to 13 frame range; default = 1 frame)</p> <p>Note: Due to card memory limits, the maximum available Minimum Latency Frames is related to the output video format. For example, with a 1080i59.94 output, the maximum allowed setting is 5. For a 1080i film (23.98) output, the maximum allowed setting is 3. Conversely, greater maximum settings are allowed for SD formats such as 525i59.94, where the practical maximum limit is 13.</p> <p>When using this control, be sure to check the Framesync Status display as follows:</p> <div data-bbox="789 806 971 831"> <p>Framesync Status On</p> </div> <ul style="list-style-type: none"> • Latency frames selection within limits. <div data-bbox="789 905 1419 930"> <p>Framesync Status Minimum Latency Frames set to 3 the maximum amount for this standard.</p> </div> <ul style="list-style-type: none"> • Latency frames selection exceeds limits.
1	2				
LATF	(value)				
<p>• Audio Hard Resync Threshold Control</p>  <p>Audio Hard Resync Threshold (Frames) 1.5</p>	<p>Sets threshold at which hard resync is applied if audio-video offset exceeds threshold (see below). Hard resync provides fastest sync-up suitable for off-air manipulation. Conversely, a threshold setting that avoids hard resync allows glitch-free on-air manipulation. (Range is 1.5 to 13.0 frames in 0.1 frame increments)</p> <p>With offset less than selected hard resync threshold, resync is progressively applied in many small steps to provide a seamless, glitch-free retiming. After the successive steps, the audio is synchronized with the video (in this example, 40 msec). (Progressive correction is applied at 1 msec/sec appr. rate.)</p>  <p>Video: 40 msec Audio: 240 msec</p> <p>In this example, initial offset of 200 msec (appr. 6 frames) is below 9 frame threshold and results in soft resync being progressively applied.</p> <hr/> <p>With offset greater than selected hard resync threshold, resync is immediately applied.</p>  <p>Video: 40 msec Audio: 440 msec</p> <p>In this example, initial offset of 400 msec (appr. 12 frames) is above 9 frame threshold and results in immediate hard resync.</p>				

Table 3-2 9083 Function Submenu List — continued

<div>Framesync</div>	(continued)
<div><div>• Audio Offset Control</div><div><div>Audio Offset from Video (ms)</div><div>-575.0</div></div><div><div>Card Edge Control Menu:</div><div>FS</div><div><div>1</div><div>2</div><div>3</div></div><div><div>ADLY</div><div>ADJ</div><div>(value) Delay value</div></div></div></div>	<p>When Framesync is enabled, adds or reduces (offsets) audio delay from the matching video delay (audio delay offset setting adds or removes delay in addition to any delay included by other actions). This control is useful for correcting lip sync problems when video and audio paths in the chain experience differing overall delays.</p> <p>(-575.0 msec to 575.0 msec range; null = 0.0 msec)</p> <p>Note: Delay offset values of less than approximately 1 frame are progressively applied by the card to provide a seamless, glitch-free retiming. However, delay offset values exceeding 1-1/2 frames may result in a slight audio discontinuity at the moment when the offset is applied using this control if the Audio Hard Resync Threshold control is not at a setting greater than the delay offset.</p> <p>To prevent this condition during an on-air manipulation, it is recommended that the Audio Hard Resync Threshold control be set high enough such that expected delay offsets exceeding 1-1/2 frames are progressively applied.</p> <p>Note: If using Audio Offset control to perform off-air corrections, it is recommended to temporarily set the Audio Hard Resync Threshold control to its minimum setting, thereby allowing the offset to be assessed and corrected as fast as possible.</p>
<div><div>• Current Audio Delay Display</div><div><div>Current Audio Delay</div><div>2.02 ms / 0 Frames 31 lines</div></div><div><div>Card Edge Control Menu:</div><div>FS</div><div><div>1</div><div>2</div><div>3</div></div><div><div>ADLY</div><div>DVAL</div><div>(value) Delay value (in msec)</div></div><div><div>Note:</div><div>Value shown in column 3 is displayed value only. No control is available in this mode.</div></div></div></div>	<p>Displays the current input-to-output audio delay (in msec units) as well as in terms of Frames/fractional frame (in number of lines).</p>
<div><div>• Video Delay Display</div><div><div>Video Delay</div><div>0.06 ms / 0 Frames 1 lines</div></div><div><div>Card Edge Control Menu:</div><div>FS</div><div><div>1</div><div>2</div></div><div><div>VDLY</div><div>(value) Delay value (in msec)</div></div><div><div>Note:</div><div>Value shown in column 2 is displayed value only. No control is available in this mode.</div></div></div></div>	<p>Displays the current input-to-output video delay (in msec units) as well as in terms of Frames/fractional frame (in number of lines).</p>

Table 3-2 9083 Function Submenu List — continued

Framesync	(continued)
<div><div>• Framesync Status Display</div><div><div>Framesync Status</div><div>On</div></div></div>	<div>Displays the current framesync status as follows:</div> <div><div><div>Framesync Status</div><div>On</div></div><div>• Framesync status OK.</div></div> <div><div><div>Framesync Status</div><div>Off</div></div><div>• Framesync source off or not connected.</div></div> <div><div><div>Framesync Status</div><div>Off no valid reference detected</div></div><div>• Improper or missing framesync reference.</div></div> <div><div><div>Framesync Status</div><div>Minimum Latency Frames set to 3 the maximum amount for this standard</div></div><div>• Latency frames selection exceeds limits.</div></div> <div>Note: See Minimum Latency Frames Control above for more information about this message.</div>
<div><div>• Loss of Input Signal Selection</div><div><div>On Loss of Input Signal:</div><div><div>Disable Outputs</div><div>Disable Outputs</div><div>Freeze Last Frame</div><div>Freeze to Color</div></div></div><div><div>Card Edge Control Menu:</div><div><div>FS</div><div><div>1</div><div>2</div></div><div><div>LOS</div><div>DISO</div><div>FRFR</div><div>FRCL</div></div><div><div></div><div>Disable outputs</div><div>Freeze to last frame</div><div>Freeze to selected color</div></div></div></div></div>	<div>In the event of input video Loss of Signal (LOS), determines action to be taken as follows:</div> <div><div>• Disable Outputs: Disable all outputs.</div><div>• Freeze Last Frame: Freeze image to last good frame (last frame having valid SAV and EAV codes).</div><div>• Freeze to Color: Freeze image to a color raster (as selected using Framesync LOS Freeze Color control).</div></div>

Table 3-2 9083 Function Submenu List — continued



<div data-bbox="274 260 623 325">Framesync</div>	(continued)																												
<p>• Framesync LOS Freeze Color</p>  <div data-bbox="269 804 592 1171"> <p>Card Edge Control Menu:</p> <p>FS</p> <table border="1"> <thead> <tr> <th>1</th><th>2</th></tr> </thead> <tbody> <tr> <td>LOSC</td><td></td></tr> <tr> <td></td><td>WHT White</td></tr> <tr> <td></td><td>YELO Yellow</td></tr> <tr> <td></td><td>CYAN Cyan</td></tr> <tr> <td></td><td>GRN Green</td></tr> <tr> <td></td><td>MAGE Magenta</td></tr> <tr> <td></td><td>RED Red</td></tr> <tr> <td></td><td>BLUE Blue</td></tr> <tr> <td></td><td>GR10 Gray 10%</td></tr> <tr> <td></td><td>GR25 Gray 25%</td></tr> <tr> <td></td><td>GR50 Gray 50%</td></tr> <tr> <td></td><td>BLK Black</td></tr> <tr> <td></td><td>CSTM Custom</td></tr> </tbody> </table> </div>	1	2	LOSC			WHT White		YELO Yellow		CYAN Cyan		GRN Green		MAGE Magenta		RED Red		BLUE Blue		GR10 Gray 10%		GR25 Gray 25%		GR50 Gray 50%		BLK Black		CSTM Custom	<p>In the event of LOS with Freeze to Color enabled above, sets the image raster color from choices shown to the left.</p>
1	2																												
LOSC																													
	WHT White																												
	YELO Yellow																												
	CYAN Cyan																												
	GRN Green																												
	MAGE Magenta																												
	RED Red																												
	BLUE Blue																												
	GR10 Gray 10%																												
	GR25 Gray 25%																												
	GR50 Gray 50%																												
	BLK Black																												
	CSTM Custom																												
<p>• Custom Color Hue</p>  <div data-bbox="272 1367 680 1551"> <p>Card Edge Control Menu:</p> <p>FS</p> <table border="1"> <thead> <tr> <th>1</th><th>2</th></tr> </thead> <tbody> <tr> <td>CHUE</td><td></td></tr> <tr> <td></td><td>(hue value) Custom freeze color hue (in degrees)</td></tr> </tbody> </table> </div>	1	2	CHUE			(hue value) Custom freeze color hue (in degrees)	<p>Adjusts raster hue (phase angle) for custom LOS color.</p> <p>(-360° to 360° range in 0.1° steps; null = 0°)</p>																						
1	2																												
CHUE																													
	(hue value) Custom freeze color hue (in degrees)																												

Table 3-2 9083 Function Submenu List — continued





	(continued)				
<p>• Custom Color Saturation</p>  <p>Custom Color Saturation 0.0</p> <div data-bbox="243 552 644 728"> <p>Card Edge Control Menu:</p> <p>FS</p> <table border="1"> <tr> <td>1</td> <td>2</td> </tr> <tr> <td>CSAT</td> <td>(sat value)</td> </tr> </table> <p>Color saturation level (in percent)</p> </div>	1	2	CSAT	(sat value)	<p>Adjusts raster saturation level for custom LOS color.</p> <p>(0% to 100% range in 0.1% steps)</p>
1	2				
CSAT	(sat value)				
<p>• Custom Color Y Level</p>  <p>Custom Color Y Level 64</p> <div data-bbox="240 921 654 1098"> <p>Card Edge Control Menu:</p> <p>FS</p> <table border="1"> <tr> <td>1</td> <td>2</td> </tr> <tr> <td>CVAL</td> <td>(gain value)</td> </tr> </table> <p>Luma level</p> </div>	1	2	CVAL	(gain value)	<p>Adjusts raster luma level for custom LOS color.</p> <p>(64 to 940 range)</p>
1	2				
CVAL	(gain value)				
<p>• Reset Framesync</p>  <p>Reset Framesync Confirm</p> <div data-bbox="237 1291 656 1503"> <p>Card Edge Control Menu:</p> <p>FS</p> <table border="1"> <tr> <td>1</td> <td>2</td> </tr> <tr> <td>RSET</td> <td>Y?</td> </tr> </table> <p>Move toggle switch left (or up) to confirm reset. Reject reset by pressing Exit Menu pushbutton.</p> </div>	1	2	RSET	Y?	<p>Resets the frame sync, clearing any buffered audio and video.</p> <p>When Confirm is clicked, a Confirm? pop-up appears, requesting confirmation.</p> <ul style="list-style-type: none"> Click Yes to reset the frame sync. Click No to reject reset.
1	2				
RSET	Y?				

Table 3-2 9083 Function Submenu List — continued

<h2>Embedded Audio Group 1/2</h2>	<p>Selects the audio source for each embedded audio channel 1 thru 8 (Embedded Audio Groups 1 and 2). It also provides Gain, Mute, and Phase Invert controls for each channel.</p>
<p>The example above shows various Source selections and individual audio control settings for various audio sources fed to the Destination channels Embedded Ch 1 thru Embedded Ch 8 in Embedded Audio Groups 1 and 2, with the resulting setup (right).</p> <p>The source-to-destination correlation shown here is only an example; any of the sources on the left can connect to any of the destinations on the right, or to Embedded Audio Groups 3 and 4 (not shown here). Additional sources not shown here are also available. These are described on the following pages.</p> <p>The controls shown here are described in detail on the following pages. Refer to Audio Routing Example Using DashBoard™ (p. 3-66) for more examples of using these controls.</p>	
<p>Note: After familiarizing yourself with the controls described in the audio routing/control sections that follow, see “Audio Routing Example Using DashBoard™” (p. 3-66) in “Example Setups Using The 9083 and DashBoard™” for a full example using these controls.</p>	

Table 3-2 9083 Function Submenu List — continued

Embedded Audio Group 1/2		(continued)
<div><div>• SD Audio Depth</div><div><div>SD Audio Depth</div><div>20 bit</div></div><div><div>SD Audio Depth</div><div>24 bit</div></div></div>	<p>Allows option of using 24-bit audio data structure per SMPTE 272M, §3.10 (default is 20-bit per SMPTE 272M, §3.5).</p> <p>Note:</p> <ul style="list-style-type: none">• If 24-bit depth is desired, make certain upstream equipment is compatible with 24-bit SD audio data.• Depth control setting applied here affects both Embedded Audio Group 1/2 and 3/4.	
<div><div>• Group Enable</div><div><div>Group Enable</div><div>On</div></div><div><div>Card Edge Control Menu:</div><div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>Embd</div><div>Grp1</div><div>Enbl</div><div>On Off</div></div><div><div>Group 1 select (range is group 1 thru group 4)</div><div>On (enabled) Off (disabled)</div></div></div></div></div>	<p>When enabled (On), enables the embedding of the corresponding embedded audio group (Embedded Audio Group 1 or Embedded Audio Group 2).</p> <ul style="list-style-type: none">• Embedded Audio Group 1 consists of embedded channels 1 thru 4.• Embedded Audio Group 2 consists of embedded channels 5 thru 8. <p>Two Group Enable buttons correspondingly enable or disable Embedded Audio Group 1 and Embedded Audio Group 2.</p> <p>Disabling a group removes the entire group of embedded audio channels while preserving the settings of the channels belonging to the group.</p>	
<p>Note:</p> <ul style="list-style-type: none">• Embedded Ch 2 thru Embedded Ch 8 have controls identical to the Source, Gain, Mute, and Phase controls described here for Embedded Ch 1. Therefore, only the Embedded Ch 1 controls are shown here.• For each channel, its source and destination should be considered and appropriately set. Unused destination channels should be set to the Silence selection.		
<div><div>• Embedded Channel Source</div><div><div>Destination</div><div>Embedded Ch 1</div></div><div><div>Source</div><div>Embed Ch 1</div></div><div><div>Card Edge Control Menu:</div><div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>Embd</div><div>Grp</div><div>Ch(n)</div><div>Src</div></div><div><div>Destination channel number</div><div>Set up to select Source</div></div></div></div></div>	<p>Using the Source drop-down list, selects the audio input source to be embedded in the corresponding embedded channel from the choices described below.</p>	

Table 3-2 9083 Function Submenu List — continued

Embedded Audio Group 1/2	(continued)
<div>• Embedded Ch 1 thru Ch 16 as Source</div> <div><div><div>Destination</div><div>Embedded Ch 1</div></div><div><div>Source</div><div>Embed Ch 1</div><div>Embed Ch 1</div><div>⋮</div><div>Embed Ch 16</div></div></div> <div><div>Card Edge Control Menu:</div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>Embd</div><div>Grp</div><div>Ch(n)</div><div>Src</div></div><div><div>Em(n)</div><div>Source: Embedded Channel (1 thru 16)</div></div></div>	<div>Embed Ch 1 thru Embed Ch 16 range in Source drop-down list enables an embedded channel (Ch 1 thru Ch 16) to be the source for the selected destination Embedded Audio Group channel.</div> <div>(In this example, Embed Ch 1 (embedded Ch 1) is the source for destination Embedded Ch 1)</div>
<div>• AES Ch 1 thru AES Ch 16 as Source</div> <div><div><div>Destination</div><div>Embedded Ch 1</div></div><div><div>Source</div><div>AES Ch 1</div><div>AES Ch 1</div><div>⋮</div><div>AES Ch 16</div></div></div> <div><div>Card Edge Control Menu:</div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>Embd</div><div>Grp</div><div>Ch(n)</div><div>Src</div></div><div><div>Ae(n)</div><div>Source: AES Channel (1 thru 16)</div></div></div>	<div>AES Ch 1 thru AES Ch 16 range in Source drop-down list enables a discrete AES channel (Ch 1 thru Ch 16) to be the source for the selected destination Embedded Audio Group channel.</div> <div>(In this example, AES Ch 1 is the source for destination Embedded Ch 1)</div>
<div>• Analog Ch 1 thru Ch 8 as Source</div> <div><div><div>Destination</div><div>Embedded Ch 1</div></div><div><div>Source</div><div>Analog Ch 1</div><div>Analog Ch 1</div><div>⋮</div><div>Analog Ch 8</div></div></div> <div><div>Card Edge Control Menu:</div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>Embd</div><div>Grp</div><div>Ch(n)</div><div>Src</div></div><div><div>An(n)</div><div>Source: Analog Channel (1 thru 8)</div></div></div>	<div>Analog Ch 1 thru Analog Ch 8 range in Source drop-down list enables a balanced-input analog channel (Ch 1 thru Ch 8) to be the source for the selected destination Embedded Audio Group channel.</div> <div>(In this example, Analog Ch1 is the source for destination Embedded Ch 1)</div>

Table 3-2 9083 Function Submenu List — continued







<div>Embedded Audio Group 1/2</div>	(continued)
<p>• Down Mix Left or Right as Source</p>  <p>Card Edge Control Menu:</p> 	<p>Down Mix Left and Down Mix Right selections in Source drop-down list allow either downmixer left or right channel to be the source for the selected destination Embedded Audio Group channel.</p> <p>(In this example, the Down Mix Left channel is the source for destination Embedded Ch 1)</p> <p>Note: Down Mix Left and Down Mix Right channels are a stereo pair derived from the L, R, C, Ls, and Rs channel inputs selected using the Audio Mixing function. The stereo pair consists of basic L/R PCM signals with no additional encoded information.</p> <p>Refer to Audio Mixing function description on page 3-43 for more information.</p>
<p>• Mono Mix as Source</p>  <p>Card Edge Control Menu:</p> 	<p>Mono selection in Source drop-down list allows mono mix content to be the source for the selected destination Embedded Audio Group channel.</p> <p>(In this example, the mono content is the source for destination Embedded Ch 1)</p> <p>Note: Mono mix content is set up using Mono Mixer Selection in the Audio Mixing function). Refer to Audio Mixing function description on page 3-43 for more information.</p>
<p>• Dolby® Encoded Pair as Source</p>  <p>Card Edge Control Menu:</p> 	<p>Dolby Encoder selection in Source drop-down list allows Dolby® Encoder encoded pair to be the source for the selected destination Embedded Audio Group channel pair. When either channel of a companion pair is sourced from the encoder, the companion channel is automatically similarly selected.</p> <p>(In this example, the encoder output is the source for destination Embedded channel pair 1/2)</p> <p>Note: Encoded channel pairs selected can only be applied to companion intact pairs (e.g., signals can be applied to embedded pair 1/2, or embedded pair 3/4 and so on, but not split to route through fabricated unrelated pairs such as embedded ch 2/ch 3).</p> <p>Note: Although the Gain, Muting, and Phase controls will appear to be usable when an encoded pair is selected, the controls are disabled.</p>

Table 3-2 9083 Function Submenu List — continued

Embedded Audio Group 1/2	(continued)
<div><div>• Tone Generator 1 thru 4 as Source</div><div><div><div>Destination</div><div>Embedded Ch 1</div></div><div><div>Source</div><div><div>Tone 1</div><div>Tone 1</div><div>Tone 2</div><div>Tone 3</div><div>Tone 4</div></div></div></div><div><div>Card Edge Control Menu:</div><div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>Embd</div><div>Grp</div><div>Ch(n)</div><div>Src TG(n)</div></div><div>Source: TG 1 thru 4</div></div></div></div>	<div><div>Tone Generator 1 thru Tone Generator 4 range in Source drop-down list enables one of four tone generators (Tone 1 thru Tone 4) to be the source for the selected destination Embedded Audio Group channel.</div><div>(In this example, Tone 1 (tone generator 1) is the source for destination Embedded Ch 1)</div><div><div>Note: Tone generator frequencies can be independently set for the four tone generator sources.</div><div>Refer to Tone Generator function description on page 3-48 for more information.</div></div></div>
<div><div>• Silence (Mute) as Source</div><div><div><div>Destination</div><div>Embedded Ch 1</div></div><div><div>Source</div><div><div>Silence</div><div>Silence</div></div></div></div><div><div>Card Edge Control Menu:</div><div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>Embd</div><div>Grp</div><div>Ch(n)</div><div>Src Off</div></div><div>Channel Silence</div></div></div></div>	<div><div>Silence selection in Source drop-down list mutes the selected destination Embedded Audio Group channel. Use this setting for unused destination channels.</div><div>(In this example, silence (muting) is applied to Embedded Ch 1)</div></div>
<div><div>• Gain (dB) Control</div><div><div><div>Gain (dB)</div><div><div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div><div><div>21.0</div></div></div></div><div><div>Card Edge Control Menu:</div><div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>Embd</div><div>Grp</div><div>Ch(n)</div><div>Gain (value)</div></div><div>Gain value (in dB)</div></div></div></div></div>	<div><div>Adjusts relative gain (in dB) applied to the corresponding destination Embedded Audio Group channel.</div><div>(-80 to +40 dB range in 0.1 dB steps; unity = 0.0 dB)</div></div>

Table 3-2 9083 Function Submenu List — continued

<div><div>Embedded Audio Group 1/2</div></div>	(continued)
<div><div><div>• Mute Control</div><div><div>Channel is</div><div>Unmuted</div></div><div><div>Channel is</div><div>Muted</div></div></div><div><div>Card Edge Control Menu:</div><div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>Embd</div><div>Grp</div><div>Ch(n)</div><div>Mute Off On</div></div><div><div>Unmuted</div><div>Muted</div></div></div></div></div>	Allows pushbutton On/Off channel muting while saving all other settings.
<div><div><div>• Phase Control</div><div><div>Phase</div><div><div>Normal</div><div>Invert</div><div>Normal</div></div></div></div><div><div>Card Edge Control Menu:</div><div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>Embd</div><div>Grp</div><div>Ch(n)</div><div>Pol Norm Inv</div></div><div><div>non-invert</div><div>invert</div></div></div></div></div>	Selects between Normal and Invert phase (relative to source original phase) for the destination Embedded Audio Group channel.

Table 3-2 9083 Function Submenu List — continued

<h1>Embedded Audio Group 3/4</h1>	<p>Selects the audio source for each embedded audio channel 9 thru 16 (Embedded Audio Groups 3 and 4). It also provides Gain, Mute, and Phase Invert controls for each channel.</p>																																																			
<div><div>SD Audio Depth20 bit</div><div><div>Group EnableOn</div><table><tr><th>Destination</th><th>Embedded Ch 9</th><th>Embedded Ch 10</th><th>Embedded Ch 11</th><th>Embedded Ch 12</th></tr><tr><td>Source</td><td>Embed Ch 4</td><td>Embed Ch 8</td><td>AES Ch 1</td><td>AES Ch 2</td></tr><tr><td>Gain (dB)</td><td><div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div><div>6.0</div></td><td><div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div><div>6.0</div></td><td><div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div><div>10.0</div></td><td><div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div><div>10.0</div></td></tr><tr><td>Channel is</td><td>Unmuted</td><td>Unmuted</td><td>Unmuted</td><td>Unmuted</td></tr><tr><td>Phase</td><td>Normal</td><td>Normal</td><td>Normal</td><td>Normal</td></tr></table><div><div>Group EnableOn</div><table><tr><th>Destination</th><th>Embedded Ch 13</th><th>Embedded Ch 14</th><th>Embedded Ch 15</th><th>Embedded Ch 16</th></tr><tr><td>Source</td><td>AES Ch 14</td><td>Analog Ch 1</td><td>Down Mix Left</td><td>Down Mix Right</td></tr><tr><td>Gain (dB)</td><td><div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div><div>-20.0</div></td><td><div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div><div>-15.0</div></td><td><div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div><div>0.0</div></td><td><div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div><div>0.0</div></td></tr><tr><td>Channel is</td><td>Unmuted</td><td>Unmuted</td><td>Unmuted</td><td>Unmuted</td></tr><tr><td>Phase</td><td>Invert</td><td>Normal</td><td>Normal</td><td>Normal</td></tr></table></div></div></div>		Destination	Embedded Ch 9	Embedded Ch 10	Embedded Ch 11	Embedded Ch 12	Source	Embed Ch 4	Embed Ch 8	AES Ch 1	AES Ch 2	Gain (dB)	<div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div> <div>6.0</div>	<div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div> <div>6.0</div>	<div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div> <div>10.0</div>	<div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div> <div>10.0</div>	Channel is	Unmuted	Unmuted	Unmuted	Unmuted	Phase	Normal	Normal	Normal	Normal	Destination	Embedded Ch 13	Embedded Ch 14	Embedded Ch 15	Embedded Ch 16	Source	AES Ch 14	Analog Ch 1	Down Mix Left	Down Mix Right	Gain (dB)	<div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div> <div>-20.0</div>	<div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div> <div>-15.0</div>	<div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div> <div>0.0</div>	<div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div> <div>0.0</div>	Channel is	Unmuted	Unmuted	Unmuted	Unmuted	Phase	Invert	Normal	Normal	Normal	<div><p>The example above shows various Source selections and individual audio control settings for various audio sources fed to the Destination channels Embedded Ch 9 thru Embedded Ch 16 in Embedded Audio Groups 3 and 4, with the resulting setup (right).</p><p>The source-to-destination correlation shown here is only an example; any of the sources on the left can connect to any of the destinations on the right, or to Embedded Audio Groups 1 and 2 (not shown here). Additional sources not shown here are also available.</p></div> <div><div><div>Emb Ch 1 – 16</div><div>AES I/O (1-4)</div><div>AES IN (5-8)</div><div>AN-AUD IN (1-8)</div><div>Downmix DM-(L, R, Mono)</div><div>Encoded Pair D 1/2</div></div><div><div>Embed Ch 4</div><div>Embed Ch 8</div><div>AES Ch 1</div><div>AES Ch 2</div><div>AES Ch 14</div><div>Analog Ch 1</div><div>DM-L</div><div>DM-R</div></div><div><div>6 dB</div><div>6 dB</div><div>10 dB</div><div>10 dB</div><div>-20 dB</div><div>-15 dB</div><div>0 dB</div><div>0 dB</div></div><div><div>Embedded Audio Group 3</div><div>CH9</div><div>CH10</div><div>CH11</div><div>CH12</div><div>CH13</div><div>CH14</div><div>CH15</div><div>CH16</div><div>Embedded Audio Group 4</div></div></div>
Destination	Embedded Ch 9	Embedded Ch 10	Embedded Ch 11	Embedded Ch 12																																																
Source	Embed Ch 4	Embed Ch 8	AES Ch 1	AES Ch 2																																																
Gain (dB)	<div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div> <div>6.0</div>	<div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div> <div>6.0</div>	<div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div> <div>10.0</div>	<div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div> <div>10.0</div>																																																
Channel is	Unmuted	Unmuted	Unmuted	Unmuted																																																
Phase	Normal	Normal	Normal	Normal																																																
Destination	Embedded Ch 13	Embedded Ch 14	Embedded Ch 15	Embedded Ch 16																																																
Source	AES Ch 14	Analog Ch 1	Down Mix Left	Down Mix Right																																																
Gain (dB)	<div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div> <div>-20.0</div>	<div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div> <div>-15.0</div>	<div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div> <div>0.0</div>	<div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div> <div>0.0</div>																																																
Channel is	Unmuted	Unmuted	Unmuted	Unmuted																																																
Phase	Invert	Normal	Normal	Normal																																																

Table 3-2 9083 Function Submenu List — continued

<div>Embedded Audio Group 3/4</div>	(continued)
<div><div><div>• SD Audio Depth</div><div><div>SD Audio Depth</div><div>20 bit</div></div><div><div>SD Audio Depth</div><div>24 bit</div></div></div></div>	<div>Allows option of using 24-bit audio data structure per SMPTE 272M, §3.10 (default is 20-bit per SMPTE 272M, §3.5).</div> <div><div>Note:</div><div><div>• If 24-bit depth is desired, make certain upstream equipment is compatible with 24-bit SD audio data.</div><div>• Depth control setting applied here affects both Embedded Audio Group 1/2 and 3/4.</div></div></div>
<div><div><div>• Group Enable</div><div><div>Group Enable</div><div>On</div></div></div><div><div>Card Edge Control Menu:</div><div><div>Aud</div><div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>Embd</div><div>Grp1</div><div>Enbl</div><div>On Off</div></div><div><div>Group 1 select (range is group 1 thru group 4)</div><div>On (enabled) Off (disabled)</div></div></div></div></div></div>	<div>When enabled (On), enables the embedding of the corresponding embedded audio group (Embedded Audio Group 1 or Embedded Audio Group 2).</div> <div><div>• Embedded Audio Group 1 consists of embedded channels 1 thru 4.</div><div>• Embedded Audio Group 2 consists of embedded channels 5 thru 8.</div></div> <div>Two Group Enable buttons correspondingly enable or disable Embedded Audio Group 1 and Embedded Audio Group 2.</div> <div>Disabling a group removes the entire group of embedded audio channels while preserving the settings of the channels belonging to the group.</div>
<div><div>Note:</div><div><div>• Embedded Ch 9 thru Embedded Ch 16 have controls that are identical to the Source, Gain, Mute, and Phase controls described for Embedded Ch 1. Refer to Embedded Audio Group 1/2 on page 3-27 for descriptions of these controls.</div><div>• For each channel, its source and destination should be considered and appropriately set. Unused destination channels should be set to the Silence selection.</div></div></div>	

Table 3-2 9083 Function Submenu List — continued

<div style="background-color: #444; color: white; padding: 5px; text-align: center; font-weight: bold;">Audio LKFS Monitor</div>	<p>Provides an ITU-R BS.1770-1 / ATSC A/85 Audio Loudness (LKFS) measurement of selected channels comprising the L, R, C, Ls, and Rs channels of a 5.1-channel complement. Also provide a configurable alert if summation LKFS result exceeds configurable thresholds.</p>
<p>Note:</p> <ul style="list-style-type: none"> • This function provides only LKFS monitoring as described here; this function does not provide active LKFS correction. Selected channels are passed through the card unaffected by settings made for this function. • The Audio LKFS Monitor target LKFS uses the Dialnorm value setting per the received selected external metadata (or per the internal metadata settings where used). See Appendix A, “Loudness Measurement Guidelines and Techniques” for more information about LKFS parameters and measurement techniques. Read and understand the information in this appendix before changing LKFS parameters from default values. 	
<p>• Monitor Channel Selection</p> <div style="border: 1px solid #ccc; padding: 5px; margin-top: 10px;"> <p>Monitor Channel Selection</p> <p>Left: Embed Out Ch 1</p> <p>Right: Embed Out Ch 2</p> <p>Center: Embed Out Ch 3</p> <p>Left Surround: Embed Out Ch 5</p> <p>Right Surround: Embed Out Ch 6</p> </div>	<p>Separate drop-down lists for Left, Right, Center, Left Surround (Ls), and Right Surround (Rs) for applying any combination of card audio outputs to each of the five LKFS monitor inputs as shown below.</p> <p>Note: Set any unused LKFS monitor channel inputs to Silence.</p> <div style="border: 1px solid #ccc; padding: 5px; margin-top: 10px;"> <p>Monitor Channel Selection</p> <div style="border: 1px solid #ccc; padding: 2px;"> <div style="background-color: #eee; padding: 2px;">Embed Out Ch 1</div> <div style="background-color: #eee; padding: 2px;">Embed Out Ch 16</div> <div style="background-color: #eee; padding: 2px;">AES Out Ch 1</div> <div style="background-color: #eee; padding: 2px;">AES Out Ch 8</div> <div style="background-color: #eee; padding: 2px;">Dolby Encoder In Ch 1</div> <div style="background-color: #eee; padding: 2px;">Dolby Encoder In Ch 6</div> <div style="background-color: #eee; padding: 2px;">Silence</div> </div> </div> <p>The example below shows selection from various channel sources applied to the LKFS monitor inputs. Because the LKFS monitor uses output (post-processed “destination”) channels, LKFS under/over conditions can be corrected using the Dashboard™ controls for the monitored channels. (Dolby® channel selections use the channels routed to the Dolby encoder inputs.)</p> <div style="display: flex; align-items: center; margin-top: 10px;"> <div style="border: 1px solid #ccc; padding: 5px; margin-right: 10px;"> <p>Monitor Channel Selection</p> <p>Left: AES Out Ch 1</p> <p>Right: AES Out Ch 2</p> <p>Center: Embed Out Ch 3</p> <p>Left Surround: Embed Out Ch 5</p> <p>Right Surround: Embed Out Ch 6</p> </div> <div style="flex-grow: 1;"> <pre> graph LR subgraph Inputs A1[AES Ch 1 Out] A2[AES Ch 2 Out] E[Emb Ch 1 - Ch 16 Out] end subgraph Monitor [LKFS Monitor] L[AES Ch 1 L] R[AES Ch 2 R] C[Emb Ch 3 C] Ls[Emb Ch 5 Ls] Rs[Emb Ch 6 Rs] end A1 --> L A2 --> R E --> C E --> Ls E --> Rs Monitor --> Display[LKFS Value Display] </pre> </div> </div>
<p>• Measured Loudness Display</p> <div style="border: 1px solid #ccc; padding: 5px; margin-top: 10px;"> <p>Measured Loudness (ITU-R BS.1770-1): -24.247 LKFS</p> </div>	<p>Displays the current aggregate ITU-R BS.1770-1 LKFS loudness for the selected monitored channels.</p> <p>Note: -inf LKFS display indicates LKFS monitor is not receiving any input (for example, as in the case of intended channels not being “seen” by the LKFS monitor due to desired embedded channels being directed to AES output and not embedded output channels).</p>

Table 3-2 9083 Function Submenu List — continued

Audio LKFS Monitor	(continued)
<p>• LKFS/Dialnorm Deviation Alarm Control</p> <p>LKFS/Dialnorm Deviation Alarm <input type="button" value="On"/></p> <hr/> <p>Audio ● OK</p> <p>Audio ● LKFS Outside of Dialnorm Setting</p>	<p>When set to On, provides indication (in the Card Info pane) of LKFS compliance or violation vs. target LKFS/dialnorm as shown. LKFS target value, averaging, and thresholds are set as described below.</p>
<p>• Target LKFS Setting</p> <p>The Audio LKFS Monitor uses the currently selected Dolby® dialnorm setting as its target LKFS (see examples below).</p> <div data-bbox="284 835 727 1491"> </div> <p>If External Metadata is being used, reported dialnorm value of selected AC-3 program coding serves as target LKFS value (in this example, -27 LKFS)</p>	<div data-bbox="906 835 1333 1470"> </div> <p>If Internal Metadata is being used, dialnorm (as set using Dashboard-configurable internal metadata setting) serves as target LKFS value (in this example, -24 LKFS)</p>

Table 3-2 9083 Function Submenu List — continued





Audio LKFS Monitor	(continued)
<p>• Measurement Window Control</p>  <p>Measurement Window (seconds) 0.1</p>	<p>Sets the duration (in seconds) that sampling time accumulates before each averaging recalculation (see below) (0.1 to 30.0 seconds range in 0.1-second steps; default = 10.0 sec)</p>
<p>In this example, the last 3 measurement periods are averaged in each reported LKFS value. This cycle is continually repeated. The Measurement Window parameter sets the sampling time accumulated before each averaging recalculation.</p> <p>Session</p>  <p>The diagram shows a horizontal timeline labeled 'Session' and 't (sec)'. It features a series of vertical tick marks representing measurement periods. Below the timeline, three overlapping rectangular boxes represent the measurement windows for the 1st, 2nd, and 3rd reports. Arrows point from the labels '1st Report', '2nd Report', and '3rd Report' to the corresponding boxes. The 1st Report window covers the first three measurement periods, the 2nd Report covers the second, third, and fourth, and the 3rd Report covers the third, fourth, and fifth.</p>	
<p>• Allowed Deviation (dB) Control</p>  <p>Allowed Deviation (dB) 0.0</p>	<p>Sets the allowable deviation above or below dialnorm (LKFS) target level, at which where exceeded the measured LKFS is considered out of range. (0.0 to 40.0 dB (LKFS) range in 0.1 dB steps; default of ± 4.0 dB (LKFS))</p>
<p>• Deviation Alarm Time Control</p>  <p>Deviation Alarm Time (seconds) 0</p>	<p>Sets the allowable time an out of range measured LKFS (as set above) can loiter, after which results in an LKFS out of range alarm display. (0 to 30 sec range in 1-second steps; default = 1.0 sec)</p>

Table 3-2 9083 Function Submenu List — continued

AES Audio Out Pairs 1-4	Routes audio sources to discrete AES output channels 1 thru 8 (AES Audio Out Pairs 1-4). Also provides Gain, Mute, and Phase Invert controls for each channel.
<p>The example above shows various Source selections and individual audio control settings for various audio sources fed to the Destination channels AES Ch 1 thru AES Ch 8, with the resulting setup (right).</p> <p>The source-to-destination correlation shown here is only an example; any of the sources on the left can connect to any of the destinations on the right.</p> <p>The controls shown here are described in detail on the following pages. Refer to Audio Routing Example Using DashBoard™ (p. 3-66) for more examples of using these controls.</p>	

Table 3-2 9083 Function Submenu List — continued




AES Audio Out Pairs 1-4	(continued)
<p>Note:</p> <ul style="list-style-type: none"> • AES Ch 2 thru AES Ch 8 have controls that are identical to the Source, Gain, Mute, and Phase controls described here for AES Ch 1. Therefore, only the AES Ch 1 controls are shown here. • For each channel, its source and destination should be considered and appropriately set. Unused destination channels should be set to the Silence selection. • 9083-ENCD and 9083-ENCE do not have flexible routing/control for AES Audio Out pairs 5-8, therefore controls similar to these for AES Out 5-8 are not included. Instead, AES Audio Out Pairs 5-8 serve as four copies of the Dolby® encoded pair in addition to any other encoded pair routing. 	
<p>• AES Channel Source</p> 	<p>Using the Source drop-down list, selects the audio source to be routed to the corresponding AES output channel from the choices described below.</p>
<p>• Embedded Ch 1 thru Ch 16 as Source</p> 	<p>Embed Ch 1 thru Embed Ch 16 range in Source drop-down list enables an embedded channel (Ch 1 thru Ch 16) to be the source for the selected destination AES channel.</p> <p>(In this example, Embed Ch 1 (embedded Ch 1) is the source for destination AES Ch 1)</p>
<p>• AES Ch 1 thru AES Ch 16 as Source</p> 	<p>AES Ch 1 thru AES Ch 16 range in Source drop-down list enables a discrete AES channel (Ch 1 thru Ch 16) to be the source for the selected destination AES channel.</p> <p>(In this example, AES Ch 5 is the source for destination AES Ch 1)</p>

Table 3-2 9083 Function Submenu List — continued

AES Audio Out Pairs 1-4		(continued)
<div>• Analog Ch 1 thru Ch 8 as Source</div> <div><div><div>Destination</div><div>AES Ch 1</div></div><div><div>Source</div><div>▼</div><div>Analog Ch 1</div><div>⋮</div><div>Analog Ch 8</div></div></div> <div><div>Card Edge Control Menu:</div><div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>AES</div><div>Ch(n)</div><div>Src</div><div>An(n)</div></div><div>Source: Analog Channel (1 thru 8)</div></div></div>	<div>Analog Ch 1 thru Analog Ch 8 range in Source drop-down list enables a balanced-input analog channel (Ch 1 thru Ch 8) to be the source for the selected destination AES channel.</div> <div>(In this example, Analog Ch1 is the source for destination AES Ch 1)</div>	
<div>• Down Mix Left or Right as Source</div> <div><div><div>Destination</div><div>AES Ch 1</div></div><div><div>Source</div><div>▼</div><div>Down Mix Left</div><div>Down Mix Right</div></div></div> <div><div>Card Edge Control Menu:</div><div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>AES</div><div>Ch(n)</div><div>Src</div><div>DM L DM R</div></div><div>Downmix L channel Downmix R channel</div></div></div>	<div>Down Mix Left and Down Mix Right selections in Source drop-down list allow either downmix left or right channel to be the source for the selected destination AES channel.</div> <div>(In this example, the Down Mix Left channel is the source for destination AES Ch 1)</div> <div><div>Note:</div>Down Mix Left and Down Mix Right channels are a stereo pair derived from the L, R, C, Ls, and Rs channel inputs selected using the Audio Mixing function. The stereo pair consists of basic L/R PCM signals with no additional encoded information.</div> <div>Refer to Audio Mixing function description on page 3-43 for more information.</div>	
<div>• Mono Mix as Source</div> <div><div><div>Destination</div><div>AES Ch 1</div></div><div><div>Source</div><div>▼</div><div>Mono</div></div></div> <div><div>Card Edge Control Menu:</div><div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>AES</div><div>Ch(n)</div><div>Src</div><div>Mono</div></div><div>Mono mix selection as source</div></div></div>	<div>Mono selection in Source drop-down list allows mono mix content to be the source for the selected destination AES channel.</div> <div>(In this example, the mono content is the source for destination AES Ch 1)</div> <div><div>Note:</div>Mono mix content is set up using Mono Mixer Selection in the Audio Mixing function). Refer to Audio Mixing function description on page 3-43 for more information.</div>	

Table 3-2 9083 Function Submenu List — continued

AES Audio Out Pairs 1-4

(continued)

• Dolby® Encoded Pair as Source

The screenshot shows the 'Destination' dropdown set to 'AES Ch 1' and the 'Source' dropdown set to 'Dolby Encoder'. A second dropdown for 'AES Ch 2' is also set to 'Dolby Encoder'.

Card Edge Control Menu:

Aud

1	2	3	4
AES	Ch(n)	Src	DENC

Dolby encoder selection as source

Dolby Encoder selection in Source drop-down list allows Dolby® Encoder encoded pair to be the source for the selected destination AES output channel pair. When either channel of a companion pair is sourced from the encoder, the companion channel is automatically similarly selected.

(In this example, the encoder output is the source for destination AES channel pair 1/2)

Note: Encoded channel pairs selected can only be applied to companion intact pairs (e.g., signals can be applied to AES pair 1/2, or AES pair 3/4 and so on, but not split to route through fabricated unrelated pairs such as AES ch 2/ch 3).

Note: Although the Gain, Muting, and Phase controls will appear to be usable when an encoded pair is selected, the controls are disabled.

• Tone Generator 1 thru 4 as Source

The screenshot shows the 'Destination' dropdown set to 'AES Ch 1' and the 'Source' dropdown set to 'Tone 1'. A list of options (Tone 1, Tone 2, Tone 3, Tone 4) is visible below the dropdown.

Card Edge Control Menu:

Aud

1	2	3	4
AES	Ch(n)	Src	TG(n)

Source: Tone Generator (1 thru 4)

Tone Generator 1 thru **Tone Generator 4** range in Source drop-down list enables one of four tone generators (Tone 1 thru Tone 4) to be the source for the selected destination AES channel.

(In this example, Tone 1 (tone generator 1) is the source for destination AES Ch 1)

Note: Tone generator frequencies can be independently set for the four tone generator sources.

Refer to **Tone Generator** function description on page 3-48 for more information.

• Silence (Mute) as Source

The screenshot shows the 'Destination' dropdown set to 'AES Ch 1' and the 'Source' dropdown set to 'Silence'. A list of options (Silence) is visible below the dropdown.

Card Edge Control Menu:

Aud

1	2	3	4
AES	Ch(n)	Src	Off

Channel Silence

Silence selection in Source drop-down list mutes the selected destination AES channel. **Use this setting for unused destination channels.**

(In this example, silence (muting) is applied to AES Ch 1)

Table 3-2 9083 Function Submenu List — continued

AES Audio Out Pairs 1-4	(continued)
<div>• Gain (dB) Control</div> <div><div>Gain (dB)</div><div><div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div><div>21.0</div></div></div> <div>Card Edge Control Menu:</div> <div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>AES</div><div>Ch(n)</div><div>Gain</div><div>(value) Gain value (in dB)</div></div></div> <td><div>Adjusts relative gain (in dB) applied to the corresponding destination AES channel.</div><div>(-80 to +40 dB range in 0.1 dB steps; unity = 0.0 dB)</div></td>	<div>Adjusts relative gain (in dB) applied to the corresponding destination AES channel.</div> <div>(-80 to +40 dB range in 0.1 dB steps; unity = 0.0 dB)</div>
<div>• Mute Control</div> <div><div>Channel is</div><div>Unmuted</div></div> <div><div>Channel is</div><div>Muted</div></div> <div>Card Edge Control Menu:</div> <div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>AES</div><div>Ch(n)</div><div>Mute</div><div>Off On Unmuted Muted</div></div></div> <td><div>Allows pushbutton On/Off channel muting while saving all other settings.</div></td>	<div>Allows pushbutton On/Off channel muting while saving all other settings.</div>
<div>• Phase Control</div> <div><div>Phase</div><div><div>Normal</div><div>Invert</div><div>Normal</div></div></div> <div>Card Edge Control Menu:</div> <div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>AES</div><div>Ch(n)</div><div>Pol</div><div>Norm Inv non-invert invert</div></div></div> <td><div>Selects between Normal and Invert phase (relative to source original phase) for the destination AES channel.</div></td>	<div>Selects between Normal and Invert phase (relative to source original phase) for the destination AES channel.</div>

Table 3-2 9083 Function Submenu List — continued






	<p>Provides down-mix audio routing selections that multiplexes any five embedded, AES, or analog audio channel sources into a stereo pair (Down Mix Left and Down Mix Right), or selection of any two audio sources to be mono-mixed to serve as a monaural source.</p> <p>With an optional upmixer licensable feature activated, any normal PCM stereo pair can be fed to the upmixer to generate 5.1 surround sound audio which in turn can be applied to six user-selectable channels.</p>
<p>• Down Mixer Selection</p> 	<p>Separate drop-down lists for Left, Right, Center, Left Surround (Ls), and Right Surround (Rs) inputs allow embedded, AES, or analog channel audio source selection for each of the five inputs as shown below.</p>  <p>The example below shows selection from various sources and the resulting stereo pair DM-L and DM-R. The two signals comprising the pair can be routed and processed the same as any other audio input source.</p>  <p>Note: The stereo pair are basic L/R PCM signals with no additional encoded information.</p>
<p>• Center Mix Ratio Control</p> 	<p>Adjusts the attenuation ratio of center-channel content from 5-channel source that is re-applied as Lt and Rt content to the DM-L and DM-R stereo mix.</p> <ul style="list-style-type: none"> • Minimum attenuation setting (-0.0 dB) applies no ratiometric reduction. Center channel content is restored as in-phase center-channel content with no attenuation, making center-channel content more predominate in the overall mix. • Maximum attenuation setting (-10.0 dB) applies a -10 dB ratiometric reduction of center-channel content. Center-channel content is restored as in-phase center-channel content at a -10 dB ratio relative to overall level, making center-channel content less predominate in the overall mix. <p>(0.0 dB to -10.0 dB range in 0.1 dB steps; default = -3 dB)</p> <p>Note: Default setting of -3.0 dB is recommended to maintain center-channel predominance in downmix representative to that of the original source 5-channel mix.</p>

Table 3-2 9083 Function Submenu List — continued




<div style="background-color: #333; color: white; padding: 5px; text-align: center; font-weight: bold;">Audio Mixing</div>	(continued)
<p>• Surround Mix Ratio Control</p> 	<p>Adjusts the attenuation ratio of surround-channel content from 5-channel source that is re-applied as Lo and Ro content to the DM-L and DM-R stereo mix.</p> <ul style="list-style-type: none"> • Minimum attenuation setting (-0.0 dB) applies no ratiometric reduction. Surround-channel content is restored with no attenuation, making Lo and Ro content more predominate in the overall mix. • Maximum attenuation setting (-10.0 dB) applies a -10 dB ratiometric reduction of surround-channel content. Surround-channel content is restored at a -10 dB ratio relative to overall level, making surround-channel content less predominate in the overall mix. <p>(0.0 dB to -10.0 dB range in 0.1 dB steps; default = -3 dB)</p> <p>Note: Default setting of -3.0 dB is recommended to maintain surround-channel predominance in downmix representative to that of the original source 5-channel mix.</p>
<p>• Mono Mixer Selection</p> 	<p>Separate drop-down lists for Left and Right inputs allow selected embedded, AES, analog, or the DM-L / DM-R input channels to provide an additional mono-mixed channel.</p> <p>The resulting mono mix (Mono) is available as an audio source for any of the 32 destination embedded or AES output channels as shown below.</p> <div style="display: flex; align-items: flex-start;"> <div style="flex: 1;"> <p>Destination</p> <div style="border: 1px solid #ccc; padding: 5px; margin-bottom: 5px;"> <div style="background-color: #333; color: white; padding: 2px; font-weight: bold;">Embedded Ch 1</div> <div style="border: 1px solid #ccc; padding: 2px;">Mono</div> <div style="border: 1px solid #ccc; padding: 2px;">Analog Ch 8</div> <div style="border: 1px solid #ccc; padding: 2px;">Down Mix Left</div> <div style="border: 1px solid #ccc; padding: 2px;">Down Mix Right</div> <div style="border: 1px solid #ccc; padding: 2px;">Mono</div> <div style="border: 1px solid #ccc; padding: 2px;">Tone 1</div> </div> </div> <div style="flex: 2;">  </div> </div> <p>Note: Selection of any two channels for mono mixing in no way affects the source channels themselves.</p>

Table 3-2 9083 Function Submenu List — continued




Audio Mixing	(continued)
<p>Note:</p> <ul style="list-style-type: none"> • 2.0-to-5.1 upmixer function is an optional licensable feature. This function and its controls appear only when a license key is entered and activated. Refer to Licensable Features function description on page 3-48 for more information. • Channel sources used by the upmixer are post-processed signals received from the Audio Routing/Gain Control function. When active, the channel selections made using this function are directly embedded in the output SDI or AES discrete pairs. Refer to 2.0-to-5.1 Upmix Function (p. 1-10) in Chapter 1, "Introduction" for detailed functional description and signal flow. • For any six channels selected for this function, the Left and Right channel selections always serve as the stereo input pair. 	
<p>• 2.0-to-5.1 Up Mixer Selection</p> 	<p>Separate drop-down lists for Left, Right, Center, LFE, Left Surround, and Right Surround allow embedded, AES, or analog channel audio source selection, and embedded or AES discrete channel assignments for the six generated 5.1 channels.</p>  <p>The example below shows selection of embedded channels 1 and 2 as the received stereo source (Embed Ch1 and Ch 2 for Left and Right drop-down list selections in the Up Mixer Selection tool).</p> <p>Using the setup shown in the example, when upmix is active the embedded channel 1/2 stereo pair is overwritten with the new stereo pair L/R on channels 1/2. As selected in the example, the additional 5.1 channels C, LFE, Left Surround (Ls), and Right Surround (Rs) overwrite Emb Ch 3 – Ch 6, respectively.</p> 

Table 3-2 9083 Function Submenu List — continued




<div data-bbox="237 260 639 327">Audio Mixing</div>	(continued)
<p>• Up Mixer Mode Control</p> 	<p>Enables or bypasses upmixer as follows:</p> <ul style="list-style-type: none"> • Auto: Automatic enable/bypass of 5.1 upmix function as follows: <ul style="list-style-type: none"> • If detected signal level on all four of the selected channels designated as Center, LFE, Left Surround, and Right Surround are below the level threshold set using the 5.1 Detection Threshold control, upmixer overwrites all six selected channels with the new 5.1 content generated by the upmixer. • If detected signal level on any of the four of the selected channels designated as Center, LFE, Left Surround, and Right Surround is above the level threshold set using the 5.1 Detection Threshold control, upmixer is bypassed and the original channels pass unaffected. • Always Upmix: Manual enable turns on upmixer and overwrites content on all six selected channels with new 5.1 content generated by the upmixer regardless of original signal level or content. • Bypass: Manual disable bypasses the upmixer. When bypassed, the six embedded audio channels pass unaffected.
<p>• Up Mixer Status Display</p> 	<p>Shows activity status of upmixer processing as follows:</p> <ul style="list-style-type: none"> • Auto Mode - Currently Upmixing: With upmixer enable set to Auto, indicates selected channels designated as Center, LFE, Left Surround, and Right Surround are clear for use (as described above); upmixer is currently up-mixing received stereo pair and overwriting the six selected channels with new 5.1 upmix. • Auto Mode - Currently Bypassed: With upmixer enable set to Auto, indicates selected channels designated as Center, LFE, Left Surround, and Right Surround have content (such as existing original 5.1 or other content); upmixer is bypassed (disabled) and allows normal passage of six selected channels. • Upmixing: Indicates upmixer is manually enabled (set to Always Upmix) and is currently up-mixing received stereo pair and overwriting the six selected channels with new 5.1 upmix. • Bypassed: Indicates upmixer is manually disabled (set to Bypass) and is currently passing all selected channels unaffected.
<p>• Auto Crossfade Speed Controls</p> 	<p>Individual controls select the relative crossfade transition speed between Upmix to Bypass (going to inactive; from 5.1 to 2.0) and Bypass to Upmix (going to active; from 2.0 to 5.1) when upmixer enable is set to Auto and the active threshold (as set by the 5.1 Detection Threshold control) is crossed in either direction.</p> <p>To suit program material and production aesthetic preferences, several choices are available as shown to the left. Slower settings allow for a more gradual transition between modes, however with a longer interval before levels stabilize. Faster settings conversely allow for a smaller interval before levels stabilize, however with greater perceived abruptness.</p>

Table 3-2 9083 Function Submenu List — continued

<div data-bbox="269 260 672 325"> <h2>Audio Mixing</h2> </div>	<div data-bbox="810 275 959 308">(continued)</div>
<div data-bbox="263 388 605 413"> <p>• 5.1 Detection Threshold Control</p> </div> <div data-bbox="280 424 660 508"> <p>5.1 Detection Threshold (dBFS) -150.0</p> </div>	<p>Adjusts the threshold at which selected channels designated as C, LFE, Ls, and Rs are considered to have viable content, or at which signal levels can be considered insignificant when upmixer enable is set to Auto. Setting affects automatic enable/bypass of 5.1 upmix function as follows:</p> <ul style="list-style-type: none"> • If detected signal level on all four of the selected channels designated as Center, LFE, Left Surround, and Right Surround are below the level threshold set using the 5.1 Detection Threshold control, upmixer allows overwrite of all six selected channels with the new 5.1 signal complement. • If detected signal level on any of the four of the selected channels designated as Center, LFE, Left Surround, and Right Surround is above the level threshold set using the 5.1 Detection Threshold control, upmixer is bypassed, thereby releasing the selected six channels and allowing the original channels to pass unaffected. <p>(Range is -150 dB to 0 dB in 0.1dB steps; 0 dB equivalent to +24 dBu=> 0 dBFS)</p> <div data-bbox="771 831 1440 1218"> <p>Typically, the 5.1 Detection Threshold control should be set to provide a usable threshold that maintains a threshold at which valid levels large enough over the threshold disable the auto upmix (A, left), while nuisance levels considerably below the threshold (B, left) are rejected, allowing the upmixer to stay locked in the enabled mode and overwrite these signals with the new signals.</p> <p>Optimum setting is dependent on program material general overall levels. A -60 dB setting is recommended for material closely adhering to the SMPTE -20 dBFS Alignment level for normal material such as dialog.</p> </div>
<div data-bbox="263 1270 496 1295"> <p>• Center Width Control</p> </div> <div data-bbox="280 1304 561 1390"> <p>Center Width 0.0</p> </div>	<p>Adjusts center channel content (in terms of percentage) applied to L and R channels.</p> <ul style="list-style-type: none"> • Minimum setting keeps all L+R (mono) content confined to center (C) channel, with any center channel content removed from L and R channels. • Higher settings progressively blend respective L and R mono content back into L and R channels, with 100% setting resulting in center channel level going to zero and L/R channels becoming normal L/R channels containing some mono content. <p>(0% to 100% range in 0.1% steps; default = 0%)</p>
<div data-bbox="263 1560 526 1585"> <p>• Surround Depth Control</p> </div> <div data-bbox="280 1593 561 1682"> <p>Surround Depth 0.0</p> </div>	<p>Adjusts surround channel content (in terms of percentage) applied to Ls and Rs channels.</p> <ul style="list-style-type: none"> • Maximum setting results in greatest surround channel levels. • Lower settings progressively diminish surround channel levels, with 0% setting resulting in no Ls or Rs level, with Ls and Rs content progressively folded back into L and R, respectively. <p>(0% to 100% range in 0.1% steps; default = 100%)</p>

Table 3-2 9083 Function Submenu List — continued

<div>Tone Generator</div>	<p>Sets the test tone frequency for each of four tone generators (Tone Generator 1 thru 4).</p>
<div><div>• Frequency Selection Lists</div><div><div>Tone Generator 1 Frequency1 KHz▼</div><div>Tone Generator 2 Frequency1 KHz▼</div><div>Tone Generator 3 Frequency1 KHz▼</div><div>Tone Generator 4 Frequency1 KHz▼</div></div><div><div>Card Edge Control Menu:</div><div>Aud</div><div><div>123</div><div>ToneTG1...TG4</div><div>Select Tone Generator (1 thru 4)</div><div>50...16K</div><div>Select frequency for selected tone generator (in Hz)</div></div></div></div>	<p>Selects the frequency for each of the four tone generators. 18 discrete sine wave frequencies are available, ranging from 50 Hz to 16 kHz (default frequency is 1.0 kHz).</p> <p>Note: Unity-gain signal level is equivalent to -20 dBu.</p>
<div>Licensable Features</div>	<p>Allows activation of optional licensed features.</p>
<div><div><div><div><div>Note:</div><div>For card pre-ordered with licensed feature(s), the activation steps described below are not required; the feature will already be installed activated. To order features and obtain a license key, contact Cobalt® sales at sales@cobaltdigital.com or at the contact information in Contact Cobalt Digital Inc. in Chapter 1, "Introduction". Please provide the "SSN" number of your card (displayed in the Card Info pane) when contacting us for your key.</div></div></div></div></div>	
<div><div>• License Feature and Key Entry window</div><div><div>FeatureUnlicensed</div><div>Feature KeyEnter Key Here</div></div></div>	<p>Activate licensable feature as described below.</p> <ol style="list-style-type: none">1. Enter the feature key string in the Feature Key box. Press return or click outside of the box to acknowledge entry.<p>Note: Entry string is case sensitive. Do not enter any spaces.</p>2. In the DashBoard™ Card Info pane, wait for the feature identification to be shown for the card product number (for example, "-UM" appearing after the card part number) and Valid Key Entered to be displayed. This indicates the key was correctly entered and recognized by the card.<p>Note: If DashBoard™ card function submenu/control pane does not re-appear, close the card and re-open it.</p>3. Click and confirm Reboot. When the card function submenu/control pane appears again, the licensable feature will be available. <p>Notes:</p> <ul style="list-style-type: none">• Applying the licensable feature and its reboot has no effect on prior settings. All control settings and drop-down selections are retained.• A licensable feature can be de-activated using this entry box by entering the feature string[space]revoke[return].

Table 3-2 9083 Function Submenu List — continued










	<p>Allows up to 16 card user settings configuration presets to be saved in a Preset and then recalled (loaded) as desired. All current settings (including list selections and scalar (numeric) control settings such as Gain, etc.) are saved when a Preset Save is invoked.</p>
	<p>The Preset Name field and Preset Save button allow custom user setting configurations to be labeled and saved to a Preset for future use.</p> <p>The Preset Load button and the Selected Preset drop-down list allow saved presets to be selected and loaded as desired. When a preset is loaded, it immediately becomes active with all user settings now automatically set as directed by the preset.</p> <p>Saved presets can be uploaded to a computer for use with other same-model COMPASS™ cards.</p> <p>Each of the items to the left are described in detail on the following pages.</p>
<p>• Preset Save and Load</p> 	<ul style="list-style-type: none"> • Preset Save stores all current card control settings to the currently selected preset. (For example, if Preset 1 is selected in the Selected Preset drop-down list, clicking and confirming Preset Save will then save all current card control settings to Preset 1) • Preset Load loads (applies) all card control settings defined by whatever preset (Preset 1 thru Preset 16) is currently selected in the Selected Preset drop-down list. (For example, if Preset 3 is selected in the Selected Preset drop-down list, clicking and confirming Preset Load will then apply all card control settings defined in Preset 3) <p>The above buttons have a Confirm? pop-up that appears, requesting confirmation.</p> <p>Note: Applying a change to a preset using the buttons described above rewrites the previous preset contents with the invoked contents. Make certain change is desired before confirming preset change.</p>
<p>• Selected Preset</p> 	<p>Selected Preset 1 thru Selected Preset 16 range in drop-down list selects one of 16 stored presets as ready for Save (being written to) or for Load (being applied to the card).</p> <p>Note: The preset names shown to the left are the default (unnamed) preset names. All 16 presets in this case are loaded identically with the factory default settings.</p>
<p>• Card Name</p> 	<p>Text entry field provides for optional entry of card name, function, etc. (as shown in this example).</p> <p>Note: Card name can be 31 ASCII characters maximum.</p>

Table 3-2 9083 Function Submenu List — continued

Presets	(continued)														
<p>• Reset Current Preset</p> 	<p>• Reset Current Preset resets all parameters (including preset custom name entered) of the currently selected Preset (as displayed in the Selected Preset field) to factory default settings.</p> <p>The above button has a Confirm? pop-up that appears, requesting confirmation.</p> <p>The factory default settings are as follows:</p> <table border="1" data-bbox="748 546 1403 1201"> <thead> <tr> <th>Function</th><th>Parameter/Setting</th></tr> </thead> <tbody> <tr> <td>Audio Mapping (Embedded Audio Group 1/2 and Embedded Audio Group 3/4)</td><td>Audio mapping reset for simultaneous embedding and de-embedding: <ul style="list-style-type: none"> Discrete AES input channels 1-16 are mapped to embedded audio output channels 1-16. Embedded audio input channels 1-16 are mapped to discrete AES output channels 1-16. </td></tr> <tr> <td>Audio Input Controls</td><td>AES SRC, Passthrough, and Zero Delay Embedding are all disabled.</td></tr> <tr> <td>Audio controls (all audio functions)</td><td>All Gain and Phase (polarity) controls are set to unity and normal, respectively.</td></tr> <tr> <td>Framesync</td><td>Framesync is disabled; Reference 1 or 2 must be selected to enable the frame sync.</td></tr> <tr> <td>Audio Mixing Up Mixer Selection (Licensable Feature activated only)</td><td>Upmixer set to Always Enabled, with upmix function using embedded channels 1 thru 6. <ul style="list-style-type: none"> Center width set to 0%. Surround Depth set to 100%. 5.1 Detection Threshold set to -150 dB. </td></tr> <tr> <td>Audio LKFS Monitor</td><td>LKFS/Dialnorm Deviation Alarm set to disabled.</td></tr> </tbody> </table>	Function	Parameter/Setting	Audio Mapping (Embedded Audio Group 1/2 and Embedded Audio Group 3/4)	Audio mapping reset for simultaneous embedding and de-embedding: <ul style="list-style-type: none"> Discrete AES input channels 1-16 are mapped to embedded audio output channels 1-16. Embedded audio input channels 1-16 are mapped to discrete AES output channels 1-16. 	Audio Input Controls	AES SRC , Passthrough , and Zero Delay Embedding are all disabled.	Audio controls (all audio functions)	All Gain and Phase (polarity) controls are set to unity and normal, respectively.	Framesync	Framesync is disabled; Reference 1 or 2 must be selected to enable the frame sync.	Audio Mixing Up Mixer Selection (Licensable Feature activated only)	Upmixer set to Always Enabled, with upmix function using embedded channels 1 thru 6. <ul style="list-style-type: none"> Center width set to 0%. Surround Depth set to 100%. 5.1 Detection Threshold set to -150 dB. 	Audio LKFS Monitor	LKFS/Dialnorm Deviation Alarm set to disabled.
Function	Parameter/Setting														
Audio Mapping (Embedded Audio Group 1/2 and Embedded Audio Group 3/4)	Audio mapping reset for simultaneous embedding and de-embedding: <ul style="list-style-type: none"> Discrete AES input channels 1-16 are mapped to embedded audio output channels 1-16. Embedded audio input channels 1-16 are mapped to discrete AES output channels 1-16. 														
Audio Input Controls	AES SRC , Passthrough , and Zero Delay Embedding are all disabled.														
Audio controls (all audio functions)	All Gain and Phase (polarity) controls are set to unity and normal, respectively.														
Framesync	Framesync is disabled; Reference 1 or 2 must be selected to enable the frame sync.														
Audio Mixing Up Mixer Selection (Licensable Feature activated only)	Upmixer set to Always Enabled, with upmix function using embedded channels 1 thru 6. <ul style="list-style-type: none"> Center width set to 0%. Surround Depth set to 100%. 5.1 Detection Threshold set to -150 dB. 														
Audio LKFS Monitor	LKFS/Dialnorm Deviation Alarm set to disabled.														
<p>• Preset Name</p> 	<p>With one of 16 presets selected, provides for entry of custom name for the preset (as shown in example below).</p>  <p>Entering text in Preset Name field (in this example, "RCVR21") applies custom name to selected Preset (in this example, Preset 2)</p> <p>Note:</p> <ul style="list-style-type: none"> Preset name can be seven ASCII characters maximum. The Preset ID number does not need to be entered; it is added automatically. 														
<p>• Download Presets</p> 	<p>Download Presets allows all 16 presets to be stored to a specified location on a network computer for use with other same-model COMPASS™ cards.</p> <p>Refer to Cobalt® reference guide COMPASS™ Remote Control User Guide (PN 9000RCS-RM) for instructions on using the Download Presets function.</p>														

Dolby® Digital (9083-ENCD Only) Functions Submenu List

Table 3-3 *Dolby® Digital Encoder (9083-ENCD only) Function Submenu List*






	<p>Provides Dolby® metadata source selection/failover controls, AC-3 data handling controls, and metadata/encoding status displays.</p>
<p>Note: After familiarizing yourself with the controls described in the Dolby® functions sections that follow, see “Dolby® Digital™ (AC-3) Setup and Routing Example” (p. 3-69) in “Example Setups Using The 9083 and DashBoard™” (p. 3-66) for a full example using these controls.</p>	
<p>• Encoding Mode</p> 	<p>Selects audio input fed to the encoder as shown to the left.</p> <p>Encode Input Audio selection routes program material audio as selected using the Dolby Digital Channel Mapping tab (p. 3-57).</p>
<p>• Encoding Status Display</p> 	<p>Displays encoding status as follows:</p> <ul style="list-style-type: none"> • Encoding Active: Indicates encoder is receiving valid metadata (either from selected source or selected failover if desired source is not present), and encoded audio is being generated. • Encoding Stopped: Indicates encoder is not receiving valid metadata from selected source. <p>Note:</p> <ul style="list-style-type: none"> • If external metadata is selected as source, intended physical source (SMPTE 2020 de-mux from SDI or RS-485) must be appropriately selected. See Dolby External Metadata function for more information. • Encoding can be set to failover to internal metadata if desired (as described later).
<p>• Encoded AC-3 Stream Controls</p>	<p>Basic controls for assigning bitstream numbers, format and rates as described below.</p> <p>Note: These controls is not required to produce the encoded output. These controls offer expanded functions, as desired, in conformance with Dolby® Digital (AC-3) encoding capabilities.</p>
<p>• Encoded AC-3 Stream Number</p> 	<p>Sets stream ID number (0 thru 6) to identify the current stream to subsequent downstream processes or devices.</p>
<p>• Encoded AC-3 Bitstream Format</p> 	<p>Sets AC-3 bitstream as full 32-bit, or channel-divided 16-bit bitstream.</p>

Table 3-3 **Dolby® Digital Encoder (9083-ENCD only) Function Submenu List — continued**

<div data-bbox="258 260 617 325" style="background-color: #444; color: white; padding: 5px; text-align: center;">Dolby Encoder</div>	(continued)
<p>• Encoded AC-3 Data Rate</p> <div data-bbox="186 415 690 619"> <p>Encoded AC-3 Data Rate Automatic (384 kbps maximum) ▾</p> <div style="border: 1px solid #ccc; padding: 5px; margin-top: 5px;"> <p>Automatic (384 kbps maximum)</p> <p>Automatic (448 kbps maximum)</p> <p>56 kbps</p> <p>⋮</p> <p>640 kbps</p> </div> </div>	<p>Where desired, allows selection of alternate AC-3 data rates. Lower settings (where appropriate when used in conjunction with compressed audio formatting) allows for more packet free space. (Output and AES stream always runs at 3.072 Mbps.)</p>
<p>• AC-3 Metadata Source</p> <div data-bbox="186 709 690 913"> <p>AC-3 Metadata Source From External Source (Program 1) ▾</p> <div style="border: 1px solid #ccc; padding: 5px; margin-top: 5px;"> <p>From External Source (Program 1)</p> <p>From External Source (Program 2)</p> <p>⋮</p> <p>From External Source (Program 8)</p> <p>From Internal Metadata Controls</p> </div> </div>	<p>Selects metadata source as follows:</p> <ul style="list-style-type: none"> • From External Source: Allows encoding using selected metadata from external source and selects the desired AC-3 program (1 thru 8). <p>Note: If external metadata is selected as source, intended physical source (SMPTE 2020 de-mux from SDI or RS-485) must be appropriately selected. See Dolby External Metadata function for more information.</p> <p>Encoding can be set to failover to internal metadata if desired (as described later).</p> • From Internal Metadata Controls: Allows encoding using internal metadata generator.

Where external metadata is used, the details of each resulting AC-3 program can be checked by viewing the **External Metadata Program Status** displays in the **Dolby External Metadata** tab.

After observing the program status/description, the desired external source can be selected using the **AC-3 Metadata Source** drop-down list described above (**Program 1** as shown here and selected in the example above).

Dolby External Metadata

External Metadata Source RS485 In ut Port ▾

VBI (SMPTE 2020-1-2008) Metadata Removal On

External Metadata Status Valid, extended BSI is present

External Metadata Program Configuration Status 2 + 2 + 2 + 2

Update Metadata Update

External Metadata Program Status	1	2	3	4	5	6	7
Program Description							
Bitstream Mode	Complete Main	Complete Main	Complete Main	Complete Main			
Audio Coding Mode	2/0 (L,R)	2/0 (L,R)	2/0 (L,R)	2/0 (L,R)			
Center Mix Level	Attenuation is -3dB	Attenuation is -3dB	Attenuation is -3dB	Attenuation is -3dB			
Surround Mix Level	Attenuation is -3dB	Attenuation is -3dB	Attenuation is -3dB	Attenuation is -3dB			
Dolby Surround Mode	Not Indicated	Not Indicated	Not Indicated	Not Indicated			

Table 3-3 *Dolby® Digital Encoder (9083-ENCD only) Function Submenu List — continued*




	(continued)
<p>• On Loss of External Metadata</p> 	<p>Selects the action to take in the event of loss of external metadata as shown to the left.</p>
<p>• Metadata Status Display</p> 	<p>Displays the metadata source currently being used as follows:</p> <ul style="list-style-type: none"> • Internal Metadata is being used: Indicates internal metadata usage (either by manual selection or failover). • External Metadata is being used: Indicates external metadata usage; external metadata selected and available. • Last Received External Metadata is being used: When enabled (as described above), indicates last received external metadata is being used as a failover in lieu of valid current external metadata.

Table 3-3 **Dolby® Digital Encoder (9083-ENCD only) Function Submenu List — continued**








	<p>Provides selection of external metadata physical source and control, and provides status and audio programming detail displays for the external metadata.</p>
<p>• External Metadata Source</p> 	<p>Selects the physical source of external metadata to be used as shown to the left.</p> <p>Note:</p> <ul style="list-style-type: none"> • RS-485 metadata is available only on cards equipped with appropriate Rear I/O Module having a DOLBY META IN port. • No failover exists to switch between loss of RS-485 metadata and Input Video SMPTE 2020 VBI metadata. If selected metadata is lost, the function reverts to failovers described for the On Loss of External Metadata control described on the previous page.
<p>• VBI Metadata Removal</p> 	<p>VBI Metadata Removal (On/Off) controls SMPTE 2020-1 metadata removal from the SDI video output.</p> <ul style="list-style-type: none"> • When set to On, metadata is removed from the SDI output. • When set to Off, metadata is allowed to pass on the SDI output. <p>Note: When encoding is active, it is recommended to set Metadata Removal to On. Because the valid metadata for the newly encoded audio is now carried in the encoded audio stream, removal of previous SMPTE 2020 VBI metadata is recommended.</p>
<p>• External Metadata Status Display</p>  	<p>Displays the current external metadata source status as follows:</p> <ul style="list-style-type: none"> • Valid: Indicates valid external metadata being received. If extended bitstream is present, this is also displayed. • Not Present: Indicates external metadata is not available from selected physical source.
<p>• External Metadata Program Configuration Status Display</p> 	<p>Displays the program configuration of the currently received external metadata (5.1+2 in this example).</p>
<p>• Update Metadata</p> 	<p>Updates the external metadata status and program configuration display screen. The display always shows the last initiated metadata transaction; to refresh screen for any changes, click Update.</p> <p>Note: Metadata does not continuously report. Use this button to report new metadata. When clicked, the button stays in the “depressed” position while updating. When the button displays the “out” position, update is complete and all displays are current.</p>

Table 3-3 **Dolby® Digital Encoder (9083-ENCD only) Function Submenu List — continued**

Dolby External Metadata		(continued)					
• External Metadata Program Details		Displays the status and programming details for each AC-3 program dictated by the received external metadata. Note: • This display is read-only. No changes can be made to the settings. All displays are reports per the received metadata. • Information provided here is intended as an overview of the screen. Displayed parameters are per ATSC A/52B definitions. Refer to ATSC A/52B for detailed descriptions and background.					
Status and programming details are displayed for up to eight Dolby® AC-3 programs in each column corresponding to an AC-3 program. (AC-3 programs are selected for the encoder using the AC-3 Metadata Source drop-down list in the Audio Input Controls tab described on page 3-52.)							
Where AC-3 programs exist for the current metadata coding, the columns show the details for the individual AC-3 programs		Where AC-3 programs do not exist for the current metadata coding, the columns are collapsed					
External Metadata Program Status		1234567					
Program Description							
Bitstream Mode	Complete Main		Complete Main		Complete Main		
Audio Coding Mode	2/0 (L,R)		2/0 (L,R)		2/0 (L,R)		
Center Mix Level	Attenuation is -3dB		Attenuation is -3dB		Attenuation is -3dB		
Surround Mix Level	Attenuation is -3dB		Attenuation is -3dB		Attenuation is -3dB		
Dolby Surround Mode	Not Indicated		Not Indicated		Not Indicated		
LFE Enable	LFE is Off (not coded)		LFE is Off (not coded)		LFE is Off (not coded)		
Dialog Normalization	-27 dBFS		-27 dBFS		-27 dBFS		
DC Highpass Filter		Bypassed		Bypassed		Bypassed	
Bandwidth Lowpass Filter		Bypassed		Bypassed		Bypassed	
LFE Channel Lowpass Filter		Bypassed		Bypassed		Bypassed	
Surround Channel 90 Degrees Phase Shift Filter		Bypassed		Bypassed		Bypassed	
Surround Channel -3 dB Attenuation		Bypassed		Bypassed		Bypassed	
Compression Words		Not Present		Not Present		Not Present	
Compression Profile		Music: Standard		Music: Standard		Music: Standard	
Dynamic Range Compression Words		Not Present		Not Present		Not Present	
Dynamic Range Compression Profile		Music: Standard		Music: Standard		Music: Standard	
						</	

Table 3-3 **Dolby® Digital Encoder (9083-ENCD only) Function Submenu List — continued**

Dolby Internal Metadata	Provides the audio production/parametric controls and bitstream controls required for setting up and using internal metadata generation.
<ul style="list-style-type: none"> • Internal Metadata Programming Controls 	Provides audio production and bitstream controls for internal metadata. Note: <ul style="list-style-type: none"> • Information provided here is intended as an overview of the screen. Displayed parameters are per ATSC A/52B definitions. Refer to ATSC A/52B for detailed descriptions and background. • When internal metadata is used, settings performed here have a profound effect on program material technical and aesthetic aspects. Setup should only be performed by authorized personnel.

The screenshot displays the 'Internal Metadata Controls' menu. It is divided into two main sections. The top section, titled 'Internal Metadata Controls', includes settings for Bitstream Mode (Complete Main), Audio Coding Mode (3/2 (L,C,R,Ls,Rs)), Center Mix Level (-3 dB), Surround Mix Level (-3 dB), Dolby Surround Mode (Not Indicated), LFE Enable (LFE is On (coded)), and Dialog Normalization (-27). Below this is the 'Audio Production Information' section, which includes Does Not Exist, Mix Level (dB) (80), and Room Type (Not Indicated). A vertical ellipsis indicates additional settings. The bottom section includes DC Highpass Filter (Enabled), Bandwidth Lowpass Filter (Enabled), LFE Channel Lowpass Filter (Bypassed), Surround Channel 90 Degrees Phase Shift Filter (Enabled), Surround Channel -3 dB Attenuation (Bypassed), Compression Words (Do Not Exist), Compression Profile (Film: Standard), Dynamic Range Compression Words (Do Not Exist), and Dynamic Range Compression Profile (Film: Standard). A bracket on the right side of the screenshot groups the bottom section of settings.

For an internally generated metadata, individual audio production parametric settings and bitstream information controls allow setup. Drop-down lists provide on/off settings or selection from a range of appropriate choices in general conformance with Dolby® Digital (AC-3) encoding and ATSC A/52B practices.

Table 3-3 *Dolby® Digital Encoder (9083-ENCD only) Function Submenu List — continued*

Dolby Ch Map

Provides mapping selection and basic parametric control of the up to six audio channels that comprise the audio channels carried by the Dolby® Digital (AC-3) encoded pair.

Notes:

- Encoder input channels shown in DashBoard™ (destination channels Encoder Ch 1 thru Encoder Ch 6) correlate to typical channel designations as shown below. Note that channel designations are a function of encoding. Based on encoding, actual channel designations may vary from the examples shown here.
- LS/RS = Left Surround/Right Surround LFE = Low-Frequency Effects
- C = Center (or mono as applicable) S = Surround mono
- = Not available; do not use
- “L” modes (e.g., “3/0L”) are LFE-enabled modes (**Internal Metadata** controls or external metadata coding set to produce an LFE channel).







Encoder Input Channel	1/0	2/0	3/0	2/1	3/1	2/2	3/2
Ch 1	—	L	L	L	L	L	L
Ch 2	—	R	R	R	R	R	R
Ch 3	C	—	C	—	C	—	C
Ch 4	—	—	—	—	—	—	—
Ch 5	—	—	—	S	S	LS	LS
Ch 6	—	—	—	—	—	RS	RS

Encoder Input Channel	3/0L	2/1L	3/1L	2/2L	3/2L
Ch 1	L	L	L	L	L
Ch 2	R	R	R	R	R
Ch 3	C	—	C	—	C
Ch 4	LFE	LFE	LFE	LFE	LFE
Ch 5	—	S	S	LS	LS
Ch 6	—	—	—	RS	RS

• Audio Input Source Select

Selects the input channel mapping. Drop-down lists for encoder inputs Destination Encoder Ch 1 thru Encoder Ch 6 can be independently sourced from embedded, discrete AES, analog, downmix, mono, or tone generator audio source as shown to the left.

Table 3-3 **Dolby® Digital Encoder (9083-ENCD only) Function Submenu List — continued**

	(continued)
<p>• Gain (dB) Control</p> 	<p>Adjusts relative gain (in dB) applied to the corresponding encoder input. (-80 to +40 dB range in 0.1 dB steps; unity = 0.0 dB)</p>
<p>• Muting Control</p> 	<p>Allows pushbutton On/Off muting of the corresponding encoder input while saving all other settings.</p>
<p>• Phase Control</p> 	<p>Selects between Normal and Invert phase (relative to source original phase) for the corresponding encoder input.</p>
Encoded Pair Output Routing	<p>Routes encoded channel pair to SDI output and/or discrete AES outputs using the Embedded Audio Group and AES Audio Out Pair controls as described below.</p>
<p>• Encoded Pair Carried By Embedded Channel Pair</p> 	<p>Using the Source drop-down list in the Embedded Audio Group 1/2 or Embedded Audio Group 3/4 tab, selects the encoded pair using the drop-down list as shown to the left. When either channel of a companion pair is sourced from the Dolby® Encoder, the companion channel is automatically similarly selected.</p> <p>Note: Encoded channel pairs selected can only be applied to companion intact pairs (e.g., signals can be applied to embedded pair 1/2, or embedded pair 3/4 and so on, but not split to route through fabricated unrelated pairs such as embedded ch 2/ch 3).</p> <p>Note: Although the Gain, Muting, and Phase controls will appear to be usable when an encoded pair is selected, the controls are disabled.</p>
<p>• Encoded Pair Carried By AES Output Channel Pair</p> 	<p>Using the Source drop-down list in AES Audio Out Pairs 1-4 tab, selects the encoded pair using the drop-down list as shown to the left. When either channel of a companion pair is sourced from the Dolby® Encoder, the companion channel is automatically similarly selected.</p> <p>Note: Encoded channel pairs selected can only be applied to companion intact pairs (e.g., signals can be applied to AES pair 1/2, or AES pair 3/4 and so on, but not split to route through fabricated unrelated pairs such as AES Ch 2/Ch 3).</p> <p>Note: Although the Gain, Muting, and Phase controls will appear to be usable when an encoded pair is selected, the controls are disabled.</p> <p>Note: The AES Audio Out Pairs 5-8 tab is not available or displayed in DashBoard™ for the 9083. Instead, the encoded pair (when active) is available as copies on AES Out pairs 5 thru 8 regardless of other output routing selections.</p>

Dolby® E (9083-ENCE Only) Functions Submenu List

Table 3-4 *Dolby® E Encoder (9083-ENCE only) Function Submenu List*







	<p>Provides Dolby® metadata source selection/failover controls, AC-3 data handling controls, and metadata/encoding status displays.</p>
<p>Note: After familiarizing yourself with the controls described in the Dolby® functions sections that follow, see “Dolby® E Setup and Routing Example” (p. 3-71) in “Example Setups Using The 9083 and DashBoard™” (p. 3-66) for a full example using these controls.</p>	
<p>• Encoding Mode</p> 	<p>Selects audio input fed to the encoder as shown to the left.</p> <p>Encode Input Audio selection routes program material audio as selected using the Dolby E Channel Mapping tab (p. 3-64).</p>
<p>• Encoding Status Display</p> 	<p>Displays encoding status as follows:</p> <ul style="list-style-type: none"> • Encoding Active: Indicates encoder is receiving valid metadata (either from selected source or selected failover if desired source is not present), and encoded audio is being generated. • Encoding Stopped: Indicates encoder is not receiving valid metadata from selected source.
<p>• AC-3 Metadata Source</p> 	<p>Selects metadata source as follows:</p> <ul style="list-style-type: none"> • From External Source: Allows encoding using selected metadata from external source. <p>Note: If external metadata is selected as source, intended physical source (SMPTE 2020 de-mux from SDI or RS-485) must be appropriately selected. See Dolby External Metadata function for more information. Encoding can be set to failover to internal metadata if desired (as described later).</p> <ul style="list-style-type: none"> • From Internal Metadata Controls: Allows encoding using internal metadata generator.
<p>• On Loss of External Metadata</p> 	<p>Selects the action to take in the event of loss of external metadata as shown to the left.</p>
<p>• Metadata Status Display</p> 	<p>Displays the metadata source currently being used as follows:</p> <ul style="list-style-type: none"> • Internal Metadata is being used: Indicates internal metadata usage (either by manual selection or failover). • External Metadata is being used: Indicates external metadata usage; external metadata selected and available. • Last Received External Metadata is being used: When enabled (as described above), indicates last received external metadata is being used as a failover in lieu of valid current external metadata.

Table 3-4 **Dolby® E Encoder (9083-ENCE only) Function Submenu List — continued**


<div data-bbox="228 273 602 312" data-label="Section-Header"> <h2>Dolby External Metadata</h2> </div>	<p>Provides selection of external metadata physical source and control, and provides status and audio programming detail displays for the external metadata.</p>
<p>Where external metadata is used, the details of each resulting AC-3 program can be checked by viewing the External Metadata Program Status displays in the Dolby External Metadata tab.</p> <p>Where external metadata does not specify all eight available AC-3 programs, the columns for the unspecified programs are collapsed (as shown here when Dolby® E2+2 is specified by the external metadata).</p> 	
<p>• External Metadata Source</p> <div data-bbox="178 1188 703 1297" data-label="Form"> <p>External Metadata Source</p> <div> <div>RS485 Input Port</div> <div>RS485 Input Port</div> <div>Input Video VBI (per SMPTE 2020-1-2008)</div> </div> </div>	<p>Selects the physical source of external metadata to be used as shown to the left.</p> <p>Note:</p> <ul style="list-style-type: none"> • RS-485 metadata is available only on cards equipped with appropriate Rear I/O Module having a DOLBY META IN port. • No failover exists to switch between loss of RS-485 metadata and Input Video SMPTE 2020 VBI metadata. If selected metadata is lost, the function reverts to failovers described for the On Loss of External Metadata control described on the previous page.
<p>• VBI Metadata Removal</p> <div data-bbox="178 1434 703 1486" data-label="Form"> <p>VBI (SMPTE 2020-1-2008) Metadata Removal</p> <div>On</div> </div>	<p>VBI Metadata Removal (On/Off) controls SMPTE 2020-1 metadata removal from the SDI video output.</p> <ul style="list-style-type: none"> • When set to On, metadata is removed from the SDI output. • When set to Off, metadata is allowed to pass on the SDI output. <p>Note: When encoding is active, it is recommended to set Metadata Removal to On. Because the valid metadata for the newly encoded audio is now carried in the encoded audio stream, removal of previous SMPTE 2020 VBI metadata is recommended.</p>

Table 3-4 *Dolby® E Encoder (9083-ENCE only) Function Submenu List — continued*

Dolby External Metadata	(continued)
<p>• External Metadata Status Display</p> <div data-bbox="219 420 727 571"> <div>External Metadata Status Valid, extended BSI is present</div> <hr/> <div>External Metadata Status Not Present</div> </div>	<p>Displays the current external metadata source status as follows:</p> <ul style="list-style-type: none"> • Valid: Indicates valid external metadata being received. If extended bitstream is present, this is also displayed. • Not Present: Indicates external metadata is not available from selected physical source.
<p>• External Metadata Program Configuration Status Display</p> <div data-bbox="219 688 711 739"> <div>External Metadata Program Configuration Status 5.1 + 2</div> </div>	<p>Displays the program configuration of the currently received external metadata (5.1+2 in this example).</p>
<p>• Update Metadata</p> <div data-bbox="219 835 605 890"> <div>Update External Metadata Update</div> </div>	<p>Updates the external metadata status and program configuration display screen. The display always shows the last initiated metadata transaction; to refresh screen for any changes, click Update.</p> <p>Note: Metadata does not continuously report. Use this button to report new metadata. When clicked, the button stays in the “depressed” position while updating. When the button displays the “out” position, update is complete and all displays are current.</p>

Table 3-4 **Dolby® E Encoder (9083-ENCE only) Function Submenu List — continued**

Dolby External Metadata	(continued)							
<ul style="list-style-type: none">External Metadata Program Details	<p>Displays the status and programming details for each AC-3 program dictated by the received external metadata.</p> <p>Note:</p> <ul style="list-style-type: none">This display is read-only. No changes can be made to the settings. All displays are reports per the received metadata.Information provided here is intended as an overview of the screen. Displayed parameters are per ATSC A/52B definitions. Refer to ATSC A/52B for detailed descriptions and background.							

Status and programming details are displayed for up to eight Dolby® AC-3 programs in each column corresponding to an AC-3 program.

Where AC-3 programs exist for the current metadata coding, the columns show the details for the individual AC-3 programs

Where AC-3 programs do not exist for the current metadata coding, the columns are collapsed

Dolby External Metadata

External Metadata Program Status	1	2	3	4	5	6	7	8
Program Description								
Bitstream Mode	Complete Main	Complete Main						
Audio Coding Mode	2/0 (L,R)	2/0 (L,R)						
Center Mix Level	Attenuation is -3dB	Attenuation is -3dB						
Surround Mix Level	Attenuation is -3dB	Attenuation is -3dB						
Dolby Surround Mode	Not Indicated	Not Indicated						
LFE Enable	LFE is Off (not coded)	LFE is Off (not coded)						
Dialog Normalization	-27 dBFS	-27 dBFS						
⋮								
DC Highpass Filter	Bypassed	Bypassed						
Bandwidth Lowpass Filter	Bypassed	Bypassed						
LFE Channel Lowpass Filter	Bypassed	Bypassed						
Surround Channel 90 Degrees Phase Shift Filter	Bypassed	Bypassed						
Surround Channel -3 dB Attenuation	Bypassed	Bypassed						
Compression Words	Not Present	Not Present						
Compression Profile	Film: Standard	Film: Standard						

For each AC-3 program as applicable, individual audio production parametric settings and bitstream information is displayed in accordance with the programming inherent in the received metadata.

Table 3-4 **Dolby® E Encoder (9083-ENCE only) Function Submenu List — continued**


Dolby Internal Metadata	Provides the audio production/parametric controls and bitstream controls required for setting up and using internal metadata generation.
<ul style="list-style-type: none"> Internal Metadata Programming Controls 	Provides audio production and bitstream controls for internal metadata. <p>Note:</p> <ul style="list-style-type: none"> Information provided here is intended as an overview of the screen. Displayed parameters are per ATSC A/52B definitions. Refer to ATSC A/52B for detailed descriptions and background. When internal metadata is used, settings performed here have a profound effect on program material technical and aesthetic aspects. Setup should only be performed by authorized personnel.
<p>Program Configuration drop-down list allows selection of various standard Dolby® E program configurations. For each individual program comprising the program configuration, individual drop-down list allow a Program ID number to be assigned. (In this example, each Program ID drop-down list has a range of 8, corresponding to the number of programs defined by example E8x1 program configuration.)</p>  <p>For an internally generated metadata, individual audio production parametric settings and bitstream mode controls allow setup. Drop-down lists provide on/off settings or selection from a range of appropriate choices in general conformance with Dolby® encoding and ATSC A/52B practices.</p>	

Table 3-4 **Dolby® E Encoder (9083-ENCE only) Function Submenu List — continued**

Dolby Ch Map

Provides mapping selection and basic parametric control of the up to eight audio channels that comprise the audio channels carried by the Dolby® encoded pair.

Notes:

- Encoder input channels shown in DashBoard™ (destination channels Encoder Ch 1 thru Encoder Ch 8) correlate to typical channel designations as shown below. Note that channel designations are a function of encoding. Based on encoding, actual channel designations may vary from the examples shown here.
- Unnumbered channel designations imply channel 1 where multiple programs exist.
 - LF/RF = Left Front/Right Front
 - LFE = Low-Frequency Effects
 - S = Surround mono
 - LE/RE = Left Extra/Right Extra
 - LS/RS = Left Surround/Right Surround
 - C = Center (or mono as applicable)
 - BSL/BSR = Back-Surround Left/Back Surround Right
 - = Not available; do not use

Encoder Input Channel	5.1 + 2	5.1 + 2 x 1	4 + 4	4 + 2 x 2	4 + 2 + 2 x 1	4 + 4 x 1	4 x 2	3 x 2 + 2 x 1	2 x 2 + 4 x 1	2 + 6 + 1	8 x 1	5.1
Ch 1	LF	LF	LF	LF	LF	LF	LF	LF	LF	LF	C	LF
Ch 2	RF	RF	RF	RF	RF	RF	RF	RF	RF	RF	2C	RF
Ch 3	C	C	C	C	C	C	3L	3L	3C	4C	3C	C
Ch 4	LFE	LFE	S	S	S	S	3R	3R	4C	5C	4C	LFE
Ch 5	LS	LS	2C	3L	3C	4C	4L	4C	5C	6C	5C	LS
Ch 6	RS	RS	2S	3R	4C	5C	4R	5C	6C	7C	6C	RS
Ch 7	2L	2C	2L	2L	2L	2C	2L	2L	2L	2C	7C	—
Ch 8	2R	3C	2R	2R	2R	3C	2R	2R	2R	3C	8C	—
Encoder Input Channel	4 + 2	4 + 2 x 1	3 x 2	2 x 2 + 2 x 1	2 + 4 x 1	6 x 1	4	2 + 2	2 + 2 x 1	4 x 1	7.1	7.1 Screen
Ch 1	LF	LF	L	L	L	C	L	L	L	C	LF	LF
Ch 2	RF	RF	R	R	R	2C	R	R	R	2C	RF	RF
Ch 3	C	C	3L	3C	4C	3C	C	—	—	3C	C	C
Ch 4	S	S	3R	4C	5C	4C	S	—	—	4C	LFE	LFE
Ch 5	—	—	—	—	—	5C	—	—	—	—	LS	LS
Ch 6	—	—	—	—	—	6C	—	—	—	—	RS	RS
Ch 7	2L	2C	2L	2L	2C	—	—	2L	2C	—	BSL	LE
Ch 8	2R	3C	2R	2R	3C	—	—	2R	3C	—	BSR	RE

• Audio Input Source Select

Selects the input channel mapping. Drop-down lists for encoder inputs Destination Encoder Ch 1 thru Encoder Ch 6 can be independently sourced from embedded, discrete AES, analog, downmix, mono, or tone generator audio source as shown to the left.

Table 3-4 **Dolby® E Encoder (9083-ENCE only) Function Submenu List — continued**

<div>Dolby Ch Map</div>	(continued)
<div><div>• Gain (dB) Control</div><div><div>Gain (dB)</div><div><div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div><div>21.0</div></div></div></div>	<div>Adjusts relative gain (in dB) applied to the corresponding encoder input. (-80 to +40 dB range in 0.1 dB steps; unity = 0.0 dB)</div>
<div><div>• Muting Control</div><div><div>Channel is</div><div>Unmuted</div></div><div><div>Channel is</div><div>Muted</div></div></div>	<div>Allows pushbutton On/Off muting of the corresponding encoder input while saving all other settings.</div>
<div><div>• Phase Control</div><div><div>Phase</div><div><div>Normal</div><div>Invert</div><div>Normal</div></div></div></div>	<div>Selects between Normal and Invert phase (relative to source original phase) for the corresponding encoder input.</div>
<div>Encoded Pair Output Routing</div>	<div>Routes encoded channel pair to SDI output and/or discrete AES outputs using the Embedded Audio Group and AES Audio Out Pair controls as described below.</div>
<div><div>• Encoded Pair Carried By Embedded Channel Pair</div><div><div><div>Destination</div><div>Embedded Ch 1</div><div>Embedded Ch 2</div></div><div><div>Source</div><div>Dolby Encoder</div><div>Dolby Encoder</div></div><div><div>Gain (dB)</div><div><div><div></div><div>40.0</div><div>0.0</div></div><div><div></div><div>40.0</div><div>0.0</div></div></div></div></div></div>	<div>Using the Source drop-down list in the Embedded Audio Group 1/2 or Embedded Audio Group 3/4 tab, selects the encoded pair using the drop-down list as shown to the left. When either channel of a companion pair is sourced from the Dolby® Encoder, the companion channel is automatically similarly selected.</div> <div>Note: Encoded channel pairs selected can only be applied to companion intact pairs (e.g., signals can be applied to embedded pair 1/2, or embedded pair 3/4 and so on, but not split to route through fabricated unrelated pairs such as embedded ch 2/ch 3).</div> <div>Note: Although the Gain, Muting, and Phase controls will appear to be usable when an encoded pair is selected, the controls are disabled.</div>
<div><div>• Encoded Pair Carried By AES Output Channel Pair</div><div><div><div>Destination</div><div>AES Ch 1</div><div>AES Ch 2</div></div><div><div>Source</div><div>Dolby Encoder</div><div>Dolby Encoder</div></div><div><div>Gain (dB)</div><div><div><div></div><div>40.0</div><div>0.0</div></div><div><div></div><div>40.0</div><div>0.0</div></div></div></div></div></div>	<div>Using the Source drop-down list in AES Audio Out Pairs 1-4 tab, selects the encoded pair using the drop-down list as shown to the left. When either channel of a companion pair is sourced from the Dolby® Encoder, the companion channel is automatically similarly selected.</div> <div>Note: Encoded channel pairs selected can only be applied to companion intact pairs (e.g., signals can be applied to AES pair 1/2, or AES pair 3/4 and so on, but not split to route through fabricated unrelated pairs such as AES Ch 2/Ch 3).</div> <div>Note: Although the Gain, Muting, and Phase controls will appear to be usable when an encoded pair is selected, the controls are disabled.</div> <div>Note: The AES Audio Out Pairs 5-8 tab is not available or displayed in DashBoard™ for the 9083. Instead, the encoded pair (when active) is available as copies on AES Out pairs 5 thru 8 regardless of other output routing selections.</div>

Example Setups Using The 9083 and DashBoard™

Audio Routing Example Using DashBoard™

Figure 3-9 shows an example of using the 9083 Embedded Audio Group and AES Output Pairs functions to de-embed audio, route the audio to discrete outputs for post-production processing, and finally re-embed the audio into the SDI video output. Additionally, the example shows how external analog and internal tone generator sources can be embedded into the SDI output.




Figure 3-9 Audio Routing Example (Sheet 1 of 3)

In the example here, Embedded Channels 1 thru 5 are de-embedded from the input SDI data and routed to discrete AES channels 1 thru 5. Also, an internal tone generator (TG1) and two analog inputs are routed to AES channels 6 thru 8, respectively. Figure 3-9 (sheet 2) shows the 9083 control settings that result in this routing.







Figure 3-9 Audio Routing Example (Sheet 2 of 3)

The discrete AES audio on AES channels 9 thru 16 is now re-embedded using the 9083 control settings shown in Figure 3-9 (sheet 3).



Using the **Embedded Audio Group 1/2** and **3/4** functions, the **Source** selections shown above route the discrete AES audio signals received from the console on Rear I/O Module **AES IN 5** thru **AES IN 8** BNC connectors to **Embedded Audio Group 1/2** embedded channels 1 thru 8.

Unused **Embedded Audio Group 3/4** embedded channels 9 thru 16 are set to Silence (mute).

Figure 3-9 Audio Routing Example (Sheet 3 of 3)

Dolby® Digital™ (AC-3) Setup and Routing Example (9083-ENCD only)

Figure 3-10 shows an example setup of using the 9083 Dolby® controls and audio routing controls to perform the following:

- Encode AES channels 1 thru 6 into an AC-3 encoded pair.
- Use RS-485 external metadata received on **DOLBY META IN** port; remove the VBI metadata following encoding.
- Perform encoding using received AC-3 Program 1.
- Set the AC-3 data rate to 384 kbps max. automatic.
- Route the encoded pair to embedded channel pair 1/2.

Figure 3-10 (sheet 1) shows this setup consisting of steps **(A)** through **(G)**. Figure 3-10 (sheet 2) correspondingly shows the DashBoard™ function tabs and control settings that are used for this setup.




Figure 3-10 Dolby® Digital™ (AC-3) Setup Example (Sheet 1 of 2)

Dolby External Metadata

External Metadata Source RS485 Input Port

VBI (SMPTE 2020-1-2008) Metadata Removal On

A Using the External Metadata Source drop-down, select **RS-485** external metadata.

B Remove VBI SMPTE 2020 metadata from the output video by setting Metadata Removal to **On**.

Dolby Encoder

AC-3 Metadata Source From External Source (Program 1)

On Loss of External Metadata Use Last Received Metadata

Encoded AC-3 Data Rate Automatic (384 kbps maximum)

C Using the AC-3 Metadata Source drop-down, select **Program 1** for AC-3 Metadata Source.

D Using the On Loss of External Metadata drop-down, select **Use Last Received Metadata** as the failover source should the current metadata become unavailable.

E Using the Encoded AC-3 Data Rate drop-down, select **348 kbps** as AC-3 data rate for the encoded pair.

Dolby Ch Map

Destination	Encoder Ch 1	Encoder Ch 2	...	Encoder Ch 6
Source	AES Ch 1	AES Ch 2	...	AES Ch 6

F Using the Encoder Ch 1 thru Encoder Ch 6 drop-downs, map AES Ch 1 thru Ch 6 to Encoder audio input channels 1 thru 6.

Embedded Audio Group 1/2

Destination	Embedded Ch 1	Embedded Ch 2
Source	Dolby Encoder	Dolby Encoder

G Using the card general audio routing controls (in this example, Embedded Audio Group 1/2), set embedded channel pair 1/2 to use the Dolby Encoder as the source.

Figure 3-10 Dolby® Digital™ (AC-3) Setup Example (Sheet 2 of 2)

Dolby® E Setup and Routing Example (9083-ENCE only)

Figure 3-11 shows an example setup of using the 9083 Dolby® controls and audio routing controls to perform the following:

- Encode AES channels 1 thru 8 into a Dolby® E 5.1+2 encoded pair using input video VBI SMPTE 2020 external metadata; remove the VBI metadata following encoding.
- Perform encoding using received 5.1+2 Program Configuration per received metadata.
- Set failover to use internal metadata if loss of external metadata loss.
- Route the encoded pair to embedded channel pair 1/2.

Figure 3-11 (sheet 1) shows this setup consisting of steps (A) through (F). Figure 3-11 (sheet 2) correspondingly shows the DashBoard™ function tabs and control settings that are used for this setup.




Figure 3-11 Dolby® E Setup Example (Sheet 1 of 2)

Dolby External Metadata

External Metadata Source

Input Video VBI (per SMPTE 2020-1-2008)

RS485 Input Port

Input Video VBI (per SMPTE 2020-1-2008)

Using the External Metadata Source drop-down, select **Input Video VBI** external metadata.

VBI (SMPTE 2020-1-2008) Metadata Removal

On

Remove VBI SMPTE 2020 metadata from the output video by setting Metadata Removal to **On**.

Dolby Encoder

On Loss of External Metadata

Switch to Internal Metadata Controls

Use Last Received Metadata

Switch to Internal Metadata Controls

Stop Encoding

Using the On Loss of External Metadata drop-down, select **Switch to Internal Metadata Controls** as the failover source should the current metadata become unavailable.

Dolby Internal Metadata

Program Configuration

5.1 + 2

Internal Metadata Controls

1

2

Program ID

1

2

Bitstream Mode

Complete Main

Complete Main

Audio Coding Mode

3/2 (L,C,R,Ls,Rs)

2/0 (L,R)

Dynamic Range Compression Words

Do Not Exist

Do Not Exist

Dynamic Range Compression Profile

Film: Standard

Film: Standard

Using the Program Configuration drop-down, select **5.1 + 2** as the encoding mode. The default audio settings can be used, or the settings can be modified as desired.

Dolby Ch Map

Destination

Encoder Ch 1

Encoder Ch 2

...

Encoder Ch 8

Source

AES Ch 1

AES Ch 2

...

AES Ch 8

Using the Encoder Ch 1 thru Encoder Ch 8 drop-downs, map AES Ch 1 thru Ch 8 to Encoder audio input channels 1 thru 8.

Embedded Audio Group 1/2

Destination

Embedded Ch 1

Embedded Ch 2

Source

Dolby Encoder

Dolby Encoder

Using the card general audio routing controls (in this example, Embedded Audio Group 1/2), set embedded channel pair 1/2 to use the Dolby Encoder as the source.

Figure 3-11 Dolby® E Setup Example (Sheet 2 of 2)

Troubleshooting

This section provides general troubleshooting information and specific symptom/corrective action for the 9083 card. The 9083 card requires no periodic maintenance in its normal operation; if any error indication (as described in this section) occurs, use this section to correct the condition.

Error and Failure Indicator Overview

The 9083 card itself and its remote control systems all (to varying degrees) provide error and failure indications. Depending on how the 9083 card is being used (i.e, standalone or network controlled through DashBoard™ or a Remote Control Panel), check all available indications in the event of an error or failure condition.

The various 9083 card and remote control error and failure indicators are individually described below.

Note: The descriptions below provide general information for the various status and error indicators. For specific failures, also use the appropriate subsection listed below.

- Basic Troubleshooting Checks (p. 3-77)
- 9083 Processing Error Troubleshooting (p. 3-78)
- Troubleshooting Network/Remote Control Errors (p. 3-82)

9083 Card Edge Status/Error Indicators and Display

Figure 3-12 shows and describes the 9083 card edge status indicators and display. These indicators and the display show status and error conditions relating to the card itself and remote (network) communications (where applicable). Because these indicators are part of the card itself and require no external interface, the indicators are particularly useful in the event of communications problems with external devices such as network remote control devices.




Figure 3-12 9083 Card Edge Status Indicators and Display

DashBoard™ Status/Error Indicators and Displays

Figure 3-13 shows and describes the DashBoard™ status indicators and displays. These indicator icons and displays show status and error conditions relating to the 9083 card itself and remote (network) communications.









Indicator Icon or Display	Error Description
  	<p>Red indicator icon in Card Access/Navigation Tree pane shows card with Error condition (in this example, the Card Access/Navigation Tree pane shows a general error issued by the 9083 card in slot 7).</p> <p>Specific errors are displayed in the Card Info pane (in this example "No connection to device" indicating 9083 card is not connecting to frame/LAN).</p> <p>If the 9083 card is not connecting to the frame or LAN, all controls are grayed-out (as shown in the example here).</p>
	<p>Gray indicator icon in Card Access/Navigation Tree pane shows card(s) are not being seen by DashBoard™ due to lack of connection to frame LAN (in this example, both a 9083 card in slot 7 and the MFC-8310-N Network Controller Card for its frame in slot 0 are not being seen).</p>
 	<p>Yellow indicator icon in Card Access/Navigation Tree pane shows card with Alert condition (in this example, the Card Access/Navigation Tree pane shows a general alert issued by the MFC-8310-N Network Controller Card).</p> <p>Clicking the card slot position in the Card Access/Navigation Tree (in this example Network Controller Card "Slot 0: MFC-8310-N") opens the Card Info pane for the selected card. In this example, a "Fan Door Open" specific error is displayed.</p>
	<p>Yellow indicator icon in 9083 Card Info pane shows error alert, along with cause for alert (in this example, the 9083 is receiving no video input, or a video input that is invalid for the card and/or its current settings).</p>
	<p>Where available, error messages within a function submenu pane show highly specific information relating to detected errors (in this example, message shows an invalid or missing Framesync Enable reference selection).</p>

Figure 3-13 DashBoard™ Status Indicator Icons and Displays

Access Card Info panes for specific cards by clicking the card slot position in the Card Access/Navigation Tree pane (as shown in the example in Figure 3-14).




Figure 3-14 Selecting Specific Cards for Card Info Status Display

Basic Troubleshooting Checks

Failures of a general nature (affecting many cards and/or functions simultaneously), or gross inoperability errors are best addressed first by performing basic checks before proceeding further. Table 3-5 provides basic system checks that typically locate the source of most general problems. If required and applicable, perform further troubleshooting in accordance with the other troubleshooting tables in this section.

Table 3-5 Basic Troubleshooting Checks

Item	Checks
Verify power presence and characteristics	<ul style="list-style-type: none"> On both the frame Network Controller Card and the 9083, in all cases when power is being properly supplied there is always at least one indicator illuminated. Any card showing no illuminated indicators should be cause for concern. Check the Power Consumed indications for both the +12 V and -7.5 V supply rails for the 9083 card. This can be observed using the DashBoard™ Card Info pane, or using the card edge controls and indicators as shown in Figure 3-7 on page 3-14. <ul style="list-style-type: none"> If either of the rail supplies show no power being consumed, either the frame power supply, connections, or the 9083 card itself is defective. If either of the rail supplies show excessive power being consumed (see Technical Specifications (p. 1-24) in Chapter 1, “Introduction”), the 9083 card may be defective.
Check Cable connection secureness and connecting points	Make certain all cable connections are fully secure (including coaxial cable attachment to cable ferrules on BNC connectors). Also, make certain all connecting points are as intended. Make certain the selected connecting points correlate to the intended card inputs and/or outputs. Cabling mistakes are especially easy to make when working with large I/O modules.
Card seating within slots	Make certain all cards are properly seated within its frame slot. (It is best to assure proper seating by ejecting the card and reseating it again.)
Check status indicators and displays	On both DashBoard™ and the 9083 card edge indicators, red indications signify an error condition. If a status indicator signifies an error, proceed to the following tables in this section for further action.
Troubleshoot by substitution	All cards within the frame can be hot-swapped, replacing a suspect card or module with a known-good item.

9083 Processing Error Troubleshooting

Table 3-6 provides 9083 processing troubleshooting information. If the 9083 card exhibits any of the symptoms listed in Table 3-6, follow the troubleshooting instructions provided.

In the majority of cases, most errors are caused by simple errors where the 9083 is not appropriately set for the type of signal being received by the card.

Note: The error indications shown below are typical for the corresponding error conditions listed. Other error indications not specified here may also be displayed on DashBoard™ and/or the 9083 card edge status indicators.

Note: Where errors are displayed on both the 9083 card and network remote controls, the respective indicators and displays are individually described in this section.

Table 3-6 Troubleshooting Processing Errors by Symptom



Symptom	Error/Condition	Corrective Action
<ul style="list-style-type: none"> DashBoard™ shows Video yellow icon and Input Invalid message in 9083 Card Info pane.  <ul style="list-style-type: none"> Card edge Input Format LEDs show continuous cycling. 	No video input present	Make certain intended video source is connected to appropriate 9083 card video input. Make certain BNC cable connections between frame Rear I/O Module for the card and signal source are OK.
<ul style="list-style-type: none"> DashBoard™ shows Frame Sync red icon and Reference Invalid message in 9083 Card Info pane.  <ul style="list-style-type: none"> Card edge red ERR indicator illuminated. 	Frame sync reference not properly selected or not being received	<ul style="list-style-type: none"> If external frame sync reference is not intended to be used, make certain the Framesync Enable selection list is set to Off or Input Video as desired. If external frame sync reference is intended to be used, make certain selected external frame sync reference is active on frame sync 8310 frame bus. (External reference signals Reference 1 and Reference 2 are distributed to the 9083 and other cards via an 8310 frame bus.) <p>Refer to Framesync function submenu tab on page 3-21 for more information.</p>

Table 3-6 Troubleshooting Processing Errors by Symptom — continued



Symptom	Error/Condition	Corrective Action
<p>DashBoard™ shows Framesync Status error message in 9083 Framesync function submenu screen.</p> 	Specified Minimum Latency Frames setting exceeds 9083 card buffer space for the selected output video format	<p>Reduce the Minimum Latency Frames setting as specified in the error message to correct the error.</p> <p>Note: Due to card memory limits, the maximum available Minimum Latency Frames is related to the output video format selected.</p> <p>For example, with a 1080i 5994 output, the maximum setting is 5. For a 1080i film (2398) output, the maximum setting is 3 (due to the increased buffer space needed for the slower frame rate). Conversely, greater maximum settings are allowed for SD formats such as 525i 5994, where the practical maximum limit is 13.</p>
Video/audio synchronization or delay noted.	Source synchronization condition	<p>Use the Audio Offset from Video control to compensate for video/audio delay.</p> <p>Refer to Framesync function submenu tab on page 3-21 for more information.</p>
Ancillary data (closed captioning, timecode, Dolby® metadata, AFD) not transferred through 9083.	<ul style="list-style-type: none"> Control(s) not enabled 	<ul style="list-style-type: none"> Make certain respective control is set to On or Enabled (as appropriate).
	<ul style="list-style-type: none"> VANC line number conflict between two or more ancillary data items 	<ul style="list-style-type: none"> Make certain each ancillary data item to be passed is assigned a unique line number (see Ancillary Data Line Number Locations and Ranges on page 3-15).
<ul style="list-style-type: none"> DashBoard™ shows red Audio icon and Analog Input Clipping message in 9083 Card Info pane.  <ul style="list-style-type: none"> Card edge display shows code E101 . 	Analog peak audio input on selected input exceeds +24 dBu level	<p>Reduce analog audio level at the source.</p> <p>Note: 9083 audio gain controls cannot be used to correct analog input overload condition. The condition must be corrected at the source.</p>

Table 3-6 Troubleshooting Processing Errors by Symptom — continued

Symptom	Error/Condition	Corrective Action
Audio signal(s) do not route as expected. Parameter control not available as expected.	<ul style="list-style-type: none"> Embedded or AES audio contains Dolby® E or Dolby Digital encoded signal 	<ul style="list-style-type: none"> When a valid Dolby® E or Dolby Digital signal (in accordance with SMPTE 337M) is detected on an AES or embedded audio signal, SRC is automatically bypassed (disabled) along with gain and polarity controls being bypassed (even though controls may appear to be functional). Gain and polarity controls are not available for this signal type. <p>Refer to Status displays in Audio Input Controls function submenu tab on page 3-17 for more information.</p>
	<ul style="list-style-type: none"> Audio Input Controls AES Passthrough or Zero Delay Embedding mode may inadvertently be enabled 	<ul style="list-style-type: none"> When either of these modes is enabled, flexible routing and parametric controls are not available. When either of these modes is not intended for use, make sure they are disabled. <p>Refer to Audio Input Controls function submenu tab on page 3-17 for more information.</p> <p>Note: Routing and parametric controls may appear functional when either of these mode are enabled, although the controls will not be functional.</p>
Audio not processed or passed through card.	<ul style="list-style-type: none"> Input audio of type that cannot be locked by 9083 card 	<ul style="list-style-type: none"> AES discrete and embedded audio must be nominal 48 kHz input. <p>Note: Although the Status Displays in Audio Input Controls function submenu tab will show audio formats other than “Present, Professional” as being locked (such as “Present, Consumer”), in any case the audio must be at nominal 48 kHz rate for lock and processing to occur.</p>
	<ul style="list-style-type: none"> Enable control not turned on 	<ul style="list-style-type: none"> Group Enable button for Embedded Audio Group 1/2 or Embedded Audio Group 3/4 function submenu must be turned on for sources to be embedded into respective embedded channels.

Table 3-6 Troubleshooting Processing Errors by Symptom — continued

Symptom	Error/Condition	Corrective Action
Audio not processed or passed through card (cont.).	<ul style="list-style-type: none"> Upmixer inadvertently enabled (Upmixer Licensed Feature only) 	<ul style="list-style-type: none"> Make certain upmixer is set to Bypass if not intended for use. <p>Note: When manually enabled or set for automatic enable with appropriate signal levels, upmixer overwrites selected embedded channels with new data; same-channel embedded output will no longer represent same-channel embedded inputs for selected channels.</p>
	<ul style="list-style-type: none"> AES pairs 1 thru 4 switch not set for Input (factory default) mode 	<ul style="list-style-type: none"> If any of AES IN 1 thru AES IN 4 are to be used as inputs, the respective DIP switch must be set to the default INPUT mode position. <p>See Setting I/O Switches for AES I/O (1-4) Ports (p. 2-1) in Chapter 2, “Installation and Setup” for more information.</p>
Dolby® encoded audio cannot be decoded on upstream monitor or device.	<ul style="list-style-type: none"> Improper metadata source selection. 	<ul style="list-style-type: none"> If external metadata is to be used, make certain source as input video VBI or source as RS-485 is appropriately set. No failover exists to switch between loss of RS-485 metadata and Input Video SMPTE 2020 VBI metadata. (See Dolby Digital External Metadata (p. 3-54) or Dolby E External Metadata (p. 3-60) for more information.)
	<ul style="list-style-type: none"> Failover improperly set. 	<ul style="list-style-type: none"> The card offers choices to revert to internal or last received metadata as failover choices for loss of external metadata. A choice to stop encoding upon metadata loss is also available. Make certain this choice is selected only if intended. (See Dolby Digital Encoder (p. 3-51) or Dolby E Encoder (p. 3-59) for more information.)

Troubleshooting Network/Remote Control Errors

Refer to Cobalt® reference guide “COMPASS™ Remote Control User Guide (PN 9000RCS-RM)” for network/remote control troubleshooting information.

In Case of Problems

Should any problem arise with this product that was not solved by the information in this section, please contact the Cobalt Digital Inc. Technical Support Department.

If required, a Return Material Authorization number (RMA) will be issued to you, as well as specific shipping instructions. If required, a temporary replacement item will be made available at a nominal charge. Any shipping costs incurred are the customer's responsibility. All products shipped to you from Cobalt Digital Inc. will be shipped collect.

The Cobalt Digital Inc. Technical Support Department will continue to provide advice on any product manufactured by Cobalt Digital Inc., beyond the warranty period without charge, for the life of the product.

See Contact Cobalt Digital Inc. (p. 1-29) in Chapter 1, “Introduction“ for contact information.

Loudness Measurement Guidelines and Techniques

This appendix provides a condensed guide to practical techniques for properly measuring and assessing loudness in various types of program material.

The content here is in general accordance with ATSC A/85, “ATSC Recommended Practice: Techniques for Establishing and Maintaining Audio Loudness for Digital Television”. This document is available free of charge and can be downloaded by going to:

<http://www.atsc.org/standards/practices.php>

About Loudness Measurement Applied to Program Material

A very useful aspect of the loudness measurement model is that a target and a measured end-assessment are based upon simple, single-value LKFS measurements that can be unambiguously displayed and assessed.

(Additionally, the Audio LKFS Monitor function can provide a simple pass or fail result for the piece based on the target and thresholds configured for the target LKFS value.) When properly performed as described in this appendix, the LKFS measurement model accommodates reasonable short-term loudness variations in most types of professionally produced material without nuisance failure indications or ambiguous results.

The loudness measurement model specified in ATSC A/85 uses the LKFS loudness unit to provide the simple, single-unit value that can be used to assess program material loudness. Basically, before an assessment is performed, two important initial facets must be considered:

- **Target LKFS Value** – This is the desired reading that is to be observed for a given segment or piece of program material. The Audio LKFS Monitor function uses the dialnorm value set in the material’s metadata as the LKFS target value.
- **Measurement Technique** – Consideration should be given in using techniques that result in the most meaningful or representative LKFS measurements. These techniques are described below, along with techniques suggestions suitable for various types of program material.

About Target LKFS Value

(See Figure A-1.) Adherence to a target LKFS value across various program material (typically from any number of individual, diverse sources) relieves viewers from having to constantly adjust program volume at their homes in order to maintain an overall comfortable, desired loudness level. General guidelines for determining a target LKFS value are as follows:

- Unless specified by a metadata dialnorm value or some other specified guidance, target LKFS should be at or about -24 ± 2.0 LKFS (that of the typical dialnorm value) across any portion of program material containing any appreciable audio content (anything other than dramatically or aesthetically intentional silence).
- Because the LKFS unit of measure is directly derived from the decibel, a gain change of a given amount modifies measured LKFS by the same amount. For example, material exhibiting an LKFS of -12 LKFS can be made to match that of material exhibiting a -24 LKFS level by **reducing** the overall level at the source by 12 dB.
- Where local content is to be added to a network-supplied feed (e.g., local commercial or programming announcements), care should be taken that the LKFS level of local content matches that specified by the metadata dialnorm.
- Dynamic Range Control (DRC) control/management systems by themselves cannot unconditionally be relied upon to assure proper LKFS compliance. Many DRC systems use measurement/control schemes that do not reflect perceived loudness. A system specified to use energy measurement/assessment models reflecting perceived loudness, such as the Cobalt® OPT-SW-LP Loudness Processing option (licensed from Linear Acoustic™), can reliably provide DRC to achieve LKFS compliance.

Figure A-1 shows an example of measuring LKFS for an ingest piece and using the result to assess and remedy the loudness variation between the piece and a dialnorm-specified network feed.

The Audio LKFS Monitor function provides a means to set a threshold above and below a target LKFS value in which an LKFS error is displayed in the Card Info pane. The function also has a threshold which sets the allowable time a high or low LKFS measurement can persist, after which an error is indicated. These configurable parameters are described in detail in the tab description for “Audio LKFS Monitor” in Chapter 3, “Operating Instructions”.




Figure A-1 Balancing LKFS Across Different Material Sources

Measurement Techniques For Various Program Material Forms

Because of the sometimes intentional broad variance of overall levels and audio density in various types of program material, consideration must be given in applying techniques that concentrate only on meaningful segments within a piece where representative LKFS measurements can be obtained. Currently, a fully automated means of accurately assessing LKFS for all cases or forms of material has not been specified in ATSC A/85. Therefore, techniques appropriate for the material must be applied. This section provides guidance and examples of properly applied techniques for various cases and forms of typical program material.

Importance of an Anchor Element

ATSC A/85 defines an **anchor element** as the aural element in material that serves as the item within a group of sounds that assumes a dominant role and is the “center of attention”. For example, in a piece containing relatively constant dialog (such as a typical commercial), the mix and creative input would typically position this dialog as the predominate or “anchor” element in the mix (in terms of both relative level and channel placement). As such, all other elements would normally have levels that proportionally track and stay well below that of the anchor element. For example, in program material consisting of dialog and background sounds or music, the anchor element would be dialog with other sounds **substantially** lower in level.

Note that in a given piece, the anchor element can change assignment within the course of the material (for example, at the end of a commercial where score music or a jingle now may assume the role of creative dominance and correspondingly become the anchor element).

Assumptions and Conditions For Meaningful LKFS Measurements


Again depending on the material form, meaningful LKFS measurement and assessment can be very straightforward or, conversely, require some techniques to help ensure a meaningful assessment is obtained. Very straightforward assessments can be obtained when the following are present and/or observed:

- Typical production aesthetics with typical post-production refinement using moderate, controlled compression and aural content density.
- Consistent audio levels in center channel throughout the piece (e.g., dialog or music score).
- Dialog (or equivalent) serving as an anchor element.
- Material containing no excessive periods of unusual loudness or silence.
- LKFS is intended as a long-term measurement. The shorter the averaging period, the less representative an assessment is of a given piece of ingest material. Where feasible, an observation should run the entire length of the ingest material. If the material does not contain an anchor element, the predominate element (e.g., featured music or obvious effects) should serve as the anchor.

In these cases, the Audio LKFS Monitor function can be used with its default settings.

Figure A-2 shows an example (using a target LKFS of -24.0) where these assumptions can be followed, and an example where certain techniques should be applied in order to obtain a meaningful LKFS assessment.

60-second Commercial with Dialog and Background Music. In this example, predominate dialog in the center channel serves as an anchor element. Because of the relatively compressed and dense audio content, a simple observation over the course of the material can reliably be used to apply gain adjustment that correspondingly provides loudness correction.



5-minute Nature Show Act with Narrative/Background Music and Creative-Element Near Silence. In this example, predominate narrative dialog in the center channel serves as an anchor element, with subordinate elements being music score and ambient soundtrack. However, the piece also contains a significantly long segment containing only very low-level ambient soundtrack during a nature close-up sequence. This loudness change is creatively intentional and must be maintained. If this segment is included in the LKFS observation, it can result in an under-representation of overall perceived loudness. If the gain is increased to compensate for this under-represented LKFS, loudness during periods of narrative/music will be unacceptably high. As such, proper technique would be to ignore the quiet portion.




Figure A-2 LKFS Measurement/Assessment for Various Program Material Forms

Specific Measurement Techniques for Various Material Forms

Described below are specific techniques and suggestions for various settings and program material which can be assessed using the Audio LKFS Monitor function.

Live Production. The Audio LKFS Monitor function can be used in live production to guide the mixing operator to maintain audio level at an LKFS reasonably close to that specified by the dialnorm. Where aural activity is significant (i.e., some sort of anchor element clearly exists), the LKFS measurement provides a good baseline of target loudness compliance. Observing LKFS over a 10-second period (appr.) will typically suffice.

Note that in this setting, audio may not be always be compressed/limited; very wide swings in dynamic range are possible. Again, only segments that are realistically viable in terms of content density, anchor element, and level amplitude/consistency should be considered for measurement. If continual or sustained LKFS “high” violations are noted, it may be indicative of an overall “hot” level on the channel or overall mix.

Post-Production. The guidelines for this settings are similar to that used for live production, except that a LKFS measurement should be observed for representative segments by cueing and rolling tape, thereby circumventing quiet segments from influencing the measurement.

Long-Form Finished Material. LKFS observation should be run for as long a segment as possible, however restricting the observation to representative portion(s) within an act. A representative segment should of course contain an anchor element or the next reasonable equivalent. Only absent a representative anchor element should the unrestricted length of the piece be observed and considered.

Short-Form Finished Material (e.g., “Commercials”). Typically, this material will have a clearly discernible anchor element and relatively consistent loudness density. As long as the material does not have loudness pauses exceeding half the overall run time (which is typically unlikely), a simple observation over the course of the material will typically provide a very reliable LKFS measurement.

Modifying LKFS Assessments Using Parametric Settings

Measurement Window Setting. (See Figure A-3.) The **Measurement Window** parameter sets the sampling time accumulated in each averaging recalculation. As such, longer periods will include more short-term LKFS “look-back” values into the moving average. Because the Measurement Window setting affects averaging that is used in measuring and calculating the LKFS measurement, changes in this setting will affect LKFS measurement.




Figure A-3 Modifying the Measurement Window Parameter

Allowed Deviation Threshold. (See Figure A-4.) This parameter sets the LKFS high/low points at which the Audio LKFS Monitor function considers the measured LKFS an error. This threshold setting is wholly independent of the LKFS measurement function. As such, resulting LKFS measured values displayed are not in any way affected by this threshold setting. In most cases, the default settings will provide reasonable, representative indications of material compliance or rejection with the configured target LKFS.

Deviation Alarm Time Threshold. (See Figure A-4.) This parameter sets the amount of time a measured LKFS level exceeding the Allowed Deviation threshold can loiter at before an alarm display occurs.




Figure A-4 Modifying LKFS Threshold Error Alert Parameters

Long-Form Simplified Measurement. (See Figure A-5.) Post-production long-form material can in many instances be easily assessed by applying a rather long **Measurement Window** (in this example, 10 seconds). In this manner, the typically brief loudness variations in professionally produced material (or breaks between material) will not result in nuisance errors. However, if the material exhibits a consistent gross deviation from the selected target LKFS or dialnorm (for example, due to level imbalance between a network feed and local insertion), the averaging period is conversely likely to be sufficiently short as to show a level-triggered error somewhere over the course of the offending material.




Figure A-5 Long-Form Simplified Measurement



Cobalt Digital Inc.

2406 E. University Ave.
Urbana, IL 61802
Voice 217.344.1243 • Fax 217.344.1245
www.cobaltdigital.com