


# 9083



**9083 HD/SD Frame Sync  
with Audio Embedding/De-Embedding  
and Dolby® Decoding Option**

## ***Product Manual***

---



**Cobalt Digital Inc.**

2406 E. University Ave.  
Urbana, IL 61802  
Voice 217.344.1243 • Fax 217.344.1245  
[www.cobaltdigital.com](http://www.cobaltdigital.com)

---

## Copyright

©Copyright 2010, Cobalt Digital Inc. All Rights Reserved.

Duplication or distribution of this manual and any information contained within is strictly prohibited without the express written permission of Cobalt Digital Inc. This manual and any information contained within, may not be reproduced, distributed, or transmitted in any form, or by any means, for any purpose, without the express written permission of Cobalt Digital Inc. Reproduction or reverse engineering of software used in this device is prohibited.

## Disclaimer

The information in this document has been carefully examined and is believed to be entirely reliable. However, no responsibility is assumed for inaccuracies. Furthermore, Cobalt Digital Inc. reserves the right to make changes to any products herein to improve readability, function, or design. Cobalt Digital Inc. does not assume any liability arising out of the application or use of any product or circuit described herein.

## Trademark Information

**Cobalt®** is a registered trademark of Cobalt Digital Inc.

**COMPASS™** is a trademark of Cobalt Digital Inc.

**DashBoard™** and **openGear™** are trademarks of Ross Video Limited. **Dolby®** is a registered trademark of Dolby Laboratories, Inc. Other product names or trademarks appearing in this manual are the property of their respective owners.

2.0-to-5.1 audio upmixer licensed feature uses the **AutoMAX-II™** upmix algorithm provided under license from **Linear Acoustic Inc.** **Linear Acoustic**, the "LA" symbol, **UPMAX**, **AutoMAX**, and **AutoMAX-II** are trademarks of Linear Acoustic Inc. All Rights Reserved.

Congratulations on choosing the Cobalt® 9083 HD/SD Frame Sync with Audio Embedding/De-Embedding and Dolby® Decoding Option. The 9083 is part of a full line of modular processing and conversion gear for broadcast TV environments. The Cobalt Digital Inc. line includes video decoders and encoders, audio embedders and de-embedders, distribution amplifiers, format converters, remote control systems and much more. Should you have questions pertaining to the installation or operation of your 9083, please contact us at the contact information on the front cover.

<b>Manual No.:</b>	9083-OM
<b>Document</b>	
<b>Version:</b>	4.0
<b>Release Date:</b>	May 13, 2010
<b>Applicable for</b>	
<b>9083 Software</b>	
<b>Version</b>	
<b>(or greater):</b>	4.0 / 2968

# Table of Contents

---

<b>Chapter 1</b>	<b>Introduction . . . . .</b>	<b>1-1</b>
	Overview . . . . .	1-1
	9083 Card Software Versions and this Manual . . . . .	1-2
	Cobalt Reference Guides . . . . .	1-3
	Manual Conventions . . . . .	1-3
	Warnings, Cautions, and Notes . . . . .	1-3
	Labeling Symbol Definitions . . . . .	1-4
	Safety Summary . . . . .	1-4
	Warnings . . . . .	1-4
	Cautions . . . . .	1-4
	9083 Functional Description . . . . .	1-5
	9083 Input/Output Formats . . . . .	1-5
	Video Processor Description . . . . .	1-7
	Audio Processor Description . . . . .	1-9
	AES Audio Input Advanced Features . . . . .	1-15
	Dolby® Decoding (9083-DEC only) . . . . .	1-16
	User Control Interface . . . . .	1-17
	9083 Rear I/O Modules . . . . .	1-19
	Audio and Video Formats Supported by the 9083 . . . . .	1-20
	Technical Specifications . . . . .	1-21
	Warranty and Service Information . . . . .	1-25
	Cobalt Digital Inc. Limited Warranty . . . . .	1-25
	Contact Cobalt Digital Inc. . . . .	1-26
 <b>Chapter 2</b>	 <b>Installation and Setup . . . . .</b>	 <b>2-1</b>
	Overview . . . . .	2-1
	Setting I/O Switches for AES I/O (1-4) Ports . . . . .	2-1
	Installing the 9083 Into a Frame Slot . . . . .	2-2
	Installing a Rear I/O Module . . . . .	2-5
	9083 Rear I/O Modules . . . . .	2-6
	Setting Up 9083 Network Remote Control . . . . .	2-10

---

<b>Chapter 3</b>	<b>Operating Instructions .....</b>	<b>3-1</b>
	Overview .....	3-1
	Control and Display Descriptions .....	3-1
	Function Submenu/Parameter Submenu Overview .....	3-2
	9083 Card Edge Controls, Indicators, and Display .....	3-3
	DashBoard™ User Interface .....	3-8
	Cobalt® Remote Control Panel User Interfaces .....	3-11
	Accessing the 9083 Card via Remote Control .....	3-12
	Accessing the 9083 Card Using DashBoard™ .....	3-12
	Accessing the 9083 Card Using a Cobalt® Remote Control Panel .....	3-13
	Checking 9083 Card Information.....	3-14
	Ancillary Data Line Number Locations and Ranges .....	3-15
	9083 Function Submenu List and Descriptions .....	3-16
	Audio Input Controls .....	3-17
	Video Proc .....	3-20
	AFD .....	3-22
	Embedded Audio Group 1/2 .....	3-29
	Embedded Audio Group 3/4 .....	3-35
	AES Audio Out Pairs 1-4 .....	3-37
	AES Audio Out Pairs 5-8 .....	3-42
	Dolby Metadata .....	3-43
	Dolby Decoder .....	3-44
	Dolby E Metadata .....	3-47
	Dolby D Metadata .....	3-48
	Timecode .....	3-49
	Audio Mixing .....	3-53
	Tone Generator .....	3-58
	Licensable Features .....	3-58
	Presets .....	3-59
	Audio Routing Example Using DashBoard™ .....	3-61
	Dolby® E Processing and Routing Example (9083-DEC only) .....	3-64
	Troubleshooting .....	3-66
	Error and Failure Indicator Overview .....	3-66
	Basic Troubleshooting Checks.....	3-70
	9083 Processing Error Troubleshooting.....	3-71
	Troubleshooting Network/Remote Control Errors.....	3-74
	In Case of Problems .....	3-74

# Introduction

## Overview

This manual provides installation and operating instructions for the 9083 HD/SD Frame Sync with Audio Embedding/De-Embedding and Dolby® Decoding Option card (also referred to herein as the 9083).

**Note:** This manual also covers the 9083-DEC, which is the 9083 card equipped with Dolby® decoding as an option. Where applicable, descriptions related exclusively to either the 9083 or the 9083-DEC are respectively denoted by **(9083 only)** or **(9083-DEC only)**. In all other aspects, both the 9083 and 9083-DEC function identically as described in this manual.

**This manual** consists of the following chapters:

- **Chapter 1, “Introduction”** – Provides information about this manual and what is covered. Also provides general information regarding the 9083.
- **Chapter 2, “Installation and Setup”** – Provides instructions for installing the 9083 in a frame, and optionally installing 9083 Rear I/O Modules.
- **Chapter 3, “Operating Instructions”** – Provides overviews of operating controls and instructions for using the 9083.

**This chapter** contains the following information:

- **9083 Card Software Versions and this Manual (p. 1-2)**
- **Manual Conventions (p. 1-3)**
- **Safety Summary (p. 1-4)**
- **9083 Functional Description (p. 1-5)**
- **Technical Specifications (p. 1-21)**
- **Warranty and Service Information (p. 1-25)**
- **Contact Cobalt Digital Inc. (p. 1-26)**

## 9083 Card Software Versions and this Manual

When applicable, Cobalt Digital Inc. provides for continual COMPASS™ card product enhancements through software updates. As such, functions described in this manual may pertain specifically to cards loaded with a particular software build. **If you received your 9083 and this manual at the same time, this manual reflects all facets of your card.**

If your card was purchased **earlier** than receiving this manual, you can check the Software Version of your card and see if it matches the Software Version covered by this manual.

If necessary, the Software Release Number/Software Build Number of your 9083 can be checked by viewing this information as displayed on the **Info** submenu on the card-edge display, or by checking the **Card Info** menu in DashBoard™. See Checking 9083 Card Information (p. 3-14) in Chapter 3, “Operating Instructions” for more information.

Proceed as follows if your 9083 card’s software does not match this manual:

Card Software <b>earlier</b> than version in manual	<p>Card is not loaded with the latest software. Not all functions and/or specified performance described in this manual may be available.</p> <p>If desired, contact Cobalt Digital Inc. to receive the latest Update software for your card. Software is typically sent by e-mail.</p> <p>You can update your card by uploading the new Update software by going to the <b>Support&gt;Firmware</b> link at <a href="http://www.cobaltdigital.com">www.cobaltdigital.com</a>. Download “Firmware Update Guide”, which provides simple instructions for downloading the latest firmware for your card onto your computer, and then uploading it to your card.</p>
Card Software <b>newer</b> than version in manual	<p>A new manual is expediently released whenever a card's software is updated <b>and specifications and/or functionality have changed</b> as compared to an earlier version (a new manual is not necessarily released if specifications and/or functionality have not changed). A manual earlier than a card's software version may not completely or accurately describe all functions available for your card.</p> <p>If your card shows features not described in this manual, you can check for the latest manual (if applicable) and download it by going to the <b>Support&gt;Documents&gt;Product Information and Manuals</b> link at <a href="http://www.cobaltdigital.com">www.cobaltdigital.com</a>.</p>

---


## Cobalt Reference Guides

From the Cobalt® web home page, go to **Support>Documents>Reference Guides** for easy to use guides covering network remote control, card firmware updates, and other topics.

## Manual Conventions

In this manual, display messages and connectors are shown using the exact name shown on the 9083 itself. Examples are provided below.

- Card-edge display messages are shown like this:



- Connector names are shown like this: **SDI OUT**

In this manual, the terms below are applicable as follows:

- **9083** refers to the 9083 HD/SD HD/SD Frame Sync with Audio Embedding/De-Embedding and Dolby® Decoding Option card.
- **Frame** refers to the 8321 (or similar) frame that houses the Cobalt® COMPASS™ cards.
- **Device** and/or **Card** refers to a COMPASS™ card.
- **System** and/or **Video System** refers to the mix of interconnected production and terminal equipment in which the 9083 and other COMPASS™ cards operate.

## Warnings, Cautions, and Notes

Certain items in this manual are highlighted by special messages. The definitions are provided below.

### Warnings

Warning messages indicate a possible hazard which, if not avoided, could result in personal injury or death.




### Cautions

Caution messages indicate a problem or incorrect practice which, if not avoided, could result in improper operation or damage to the product.

### Notes

Notes provide supplemental information to the accompanying text. Notes typically precede the text to which they apply.

## Labeling Symbol Definitions

	Attention, consult accompanying documents.
	Electronic device or assembly is susceptible to damage from an ESD event. Handle only using appropriate ESD prevention practices.  If ESD wrist strap is not available, handle card only by edges and avoid contact with any connectors or components.
	Symbol (WEEE 2002/96/EC) For product disposal, ensure the following: <ul style="list-style-type: none"> <li>• Do not dispose of this product as unsorted municipal waste.</li> <li>• Collect this product separately.</li> <li>• Use collection and return systems available to you.</li> </ul>

## Safety Summary

### Warnings

#### ! WARNING !

To reduce risk of electric shock do not remove line voltage service barrier cover on frame equipment containing an AC power supply. **NO USER SERVICEABLE PARTS INSIDE.** REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

### Cautions

#### CAUTION

This device is intended for environmentally controlled use only in appropriate video terminal equipment operating environments.

#### CAUTION

This product is intended to be a component product of an openGear™ frame. Refer to the openGear™ frame Owner's Manual for important safety instructions regarding the proper installation and safe operation of the frame as well as its component products.

#### CAUTION

Heat and power distribution requirements within a frame may dictate specific slot placement of cards. Cards with many heat-producing components should be arranged to avoid areas of excess heat build-up, particularly in frames using only convection cooling. The 9083 has a moderate power dissipation (15 W max.). As such, avoiding placing the card adjacent to other cards with similar dissipation values if possible.

#### CAUTION

If required, make certain Rear I/O Module(s) is installed before installing the 9083 into the frame slot. Damage to card and/or Rear I/O Module can occur if module installation is attempted with card already installed in slot.

#### CAUTION

If card resists fully engaging in rear I/O module mating connector, check for alignment and proper insertion in slot tracks. Damage to card and/or rear I/O module may occur if improper card insertion is attempted.



---

## 9083 Functional Description

Figure 1-1 shows a functional block diagram of the 9083. The 9083 frame synchronizer also includes a full 16-channel audio embedder/de-embedder, an 8-channel, and a 24-bit balanced analog-to-digital audio converter. The 9083 also handles AFD code detection/insertion and transfer of Dolby® metadata.

**(9083-DEC only)** The 9083-DEC also performs Dolby® E and Dolby® Digital™ decoding and decoded channel routing.

**Note:** Some of the functions described below are available only when using the DashBoard™, or Cobalt® OGCP-9000 or OGCP-9000/CC Control Panels user interfaces. Refer to User Control Interface (p. 1-17) for user interface descriptions.

### 9083 Input/Output Formats

The 9083 provides the following inputs and outputs:

- **Inputs:**
  - **HD/SD SDI IN** – dual-rate HD/SD-SDI input
  - **AES I/O (1-4)** – user-switchable as AES inputs or AES outputs
  - **AES IN (5-8)** – dedicated AES inputs
  - **AN-AUD IN (1-8)** – balanced analog audio inputs
- **Outputs:**
  - **SDI OUT** – two dual-rate HD/SD-SDI buffered video outputs
  - **RCK OUT** – two reclocked HD/SD-SDI input copies
  - **AES OUT (1-8)** – dedicated AES outputs
  - **AES I/O (1-4)** – user-switchable as AES inputs or AES outputs
  - **DOLBY META** – RS-485 Dolby® metadata output (extracted from input video). **(9083-DEC only)** RS-485 Dolby® metadata output can consist of input video or Dolby® decoder metadata output.

**Note:** The input/output complement listed above represents the maximum capability of the 9083. The practical input/output complement is determined by the particular Rear I/O Module used with the 9083. Refer to 9083 Rear I/O Modules (p. 1-19) for more information.




Figure 1-1 9083 Functional Block Diagram

---

## Video Processor Description

### Video Processor

The 9083 provides full color processing control (luma gain and lift, chroma saturation, and color phase) of the output video.

### Frame Sync Function

This function provides for frame sync control using either one of two external **EXT REF IN (1,2)** reference signals distributed with the card frame, or the input video as a frame sync reference.

This function allows horizontal and/or vertical offset to be added between the output video and the frame sync reference.

A video/audio delay offset function allows adding or reducing audio delay from the matching video delay. This function is useful for correcting lip sync problems when video and audio paths in the chain experience differing overall delays. A Reset Framesync function resets the frame sync following any horizontal or vertical offset changes, clearing any buffered audio and video and re-establishing the frame sync. The 9083 re-establishes video/audio sync following framesync changes by applying an offset in small, progressive amounts to provide a seamless, glitch-free retiming. A user-selectable hard resync function allows setting a threshold at which hard resync is applied if audio-video offset exceeds the threshold. Hard resync provides fastest sync-up suitable for off-air manipulation. Conversely, a threshold setting that avoids hard resync allows glitch-free on-air manipulation.

In the event of input video loss of signal, this function provides for disabling the video, going to a desired color raster, or freezing to the last intact frame (last frame having valid SAV and EAV codes).

**(9083-DEC only)** When Dolby® data is received and actively routed into embedded or AES output channels, the frame sync function delays the video by one frame (as required by the Dolby® decode processing delay) to maintain video/audio sync.

### AFD Inserter

This function provides for assignment and insertion of AFD codes into the SDI output video. Using this function, AFD codes in accordance with the standard 4-bit AFD code designations can be applied to the output video.

This function checks for any existing AFD code within the received video input. If a code is present, the code is displayed. When used in conjunction with a separate downstream card capable of providing AFD-directed scaling, the image can in turn be scaled in accordance with the AFD coding embedded by this card.

The function also allows the selection/changing of the AFD code and ancillary data line number for the outputted AFD code.

## Dolby® Metadata Extractor/Re-inserter

- Notes:**
- **(9083 only)** This function allows metadata extraction from input video only.
  - **(9083-DEC only)** This function is replaced with Dolby metadata tools that are part of the Dolby® decoder function. Refer to Dolby® Decoding (p. 1-16) for description of Dolby® metadata processing for the 9083-DEC card.

This function extracts and preserves Dolby® metadata from the input SDI, and in turn allows the metadata to be re-inserted in the output SDI. (The 9083 does not offer Dolby® decoding or encoding, but will pass Dolby® E and/or Dolby® Digital™ encoded signals and metadata intact.) The extracted metadata is buffered and then output on a user-selectable line number on the SDI output, and on an RS-485 port on cards equipped with an appropriate Rear I/O Module.

## Timecode Processor

(See Figure 1-2.) This function provides for extraction of timecode data from the input video, and in turn re-insertion of timecode data into the output SDI. The function can monitor the SDI video input of the card for supported timecode formats, and then select and prioritize among SDI VITC, SDI ATC VITC, and SDI ATC LTC timecode sources. If the preferred format is detected, the preferred format is used by the card; if the preferred format is not detected, the card uses other formats (where available) as desired.

The function provides conversion between various timecode formats and provides independent insertion and line number controls for each SDI timecode output format.




Figure 1-2 Timecode Processor

---

## Audio Processor Description

The audio processor operates as an internal audio router. The router function chooses from the following inputs:

- 16 channels of embedded audio from the SDI video
- 16 channels (8 pairs) of discrete AES input
- 8 channels of balanced analog audio input
- Four independent internal tone generators (described below)
- Digital silence (mute) setting
- Internal Down Mix and Mono Mixer outputs (described below)
- **(9083-DEC only)** Decoded Dolby® channels

The router function provides the following audio outputs:


- 16 channels of embedded audio on the SDI output
- 16 channels of discrete AES output on eight AES pairs

The router acts as a full audio cross point. Each of the 32 output channels (16 embedded AES, 16 discrete AES) can receive signal from any one of the 40 (16 embedded AES, 16 discrete AES, 8 analog) input channels, four internal tone generators, or several mixer outputs. Unused output channels can be mapped to a “Silence” source. Each output also provides gain adjustment and selectable polarity inversion.

Output audio rates are always 48 kHz locked to output video, but discrete AES inputs can pass through the sample rate converters to align these inputs with the output timing. (AES must be nominally 48 kHz input; 32, 44.1, 96, and 192 kHz inputs are not compatible with the 9083.) The sample rate converters are disabled by default. Output AES is always precisely synchronized with the output video. The balanced analog audio input is sampled at 48 kHz with a +24 dBu clipping level (+24 dBu => 0 dBFS).

As set with the default settings, the routing between embedded audio channels **Embed Ch 1** thru **Embed Ch 16** and discrete AES audio channels **AES Ch1** thru **AES Ch 16** is as shown in Figure 1-3. In this mode, the routing is basic 1-to-1 embedding/de-embedding for the 16 embedded and AES discrete audio channels. Other sources and/or destinations (described below) for each channel are selected using the card edge controls or a remote control system.


**Note:** As shown in Figure 1-1, the 9083 is equipped with eight discrete AES input pair ports and eight discrete AES output pair ports. On Rear I/O Modules having limited AES I/O capabilities, switches S11 thru S14 allow available rear module BNC connectors to be allotted between AES inputs and outputs as desired. Buffered copies of **AES OUT (1-4)** are available as dedicated outputs and as respective outputs fed through S11 – S14 on the 9083 card.



**Figure 1-3 Default Embed/De-Embed Audio Routing**


### Audio Down Mixer and Mono Mixer Function

(See Figure 1-4.) The Audio Down Mixer function provides for the selection of any five embedded, AES discrete, or analog audio sources serving as Left (**L**), Right (**R**), Center (**C**), Left Surround (**Ls**), and Right Surround (**Rs**) individual signals to be multiplexed into a stereo pair (Down Mix Left (**DM-L**) and Down Mix Right (**DM-R**)). The resulting stereo pair **DM-L** and **DM-R** can in turn be routed and processed just like any of the other audio sources described earlier.



**Figure 1-4 Audio Mixing Functional Block Diagram with Example Sources**

The Mono Mixer function (Figure 1-5) generates an additional mono-mixed channel from two selected embedded, AES discrete, or analog input channels serving as left and right inputs. The resulting mono mix channel **MONO** can in turn be routed and processed just like any of the other audio sources described earlier.



*Figure 1-5 Audio Mono Mix Functional Block Diagram with Example Sources*

## 2.0-to-5.1 Upmix Function


**Note:** Upmix function is an optional licensable feature. This function and its controls appear only when a license key is entered and activated. (This option (identified in Cobalt® price lists as “OPT-SW-UM”) can be purchased upon initial order, or field-activated using a key string which is sent to you when this option is purchased.)

The 2.0-to-5.1 upmixer function receives a normal PCM stereo pair from the Audio Routing/Gain Control function and upmixes the pair to provide 5.1 channels (Left (**L**), Right (**R**), Center (**C**), Low Frequency Effects (**LFE**), Left Surround (**Ls**), and Right Surround (**Rs**)). Whenever the upmixer is active, it overwrites the six selected channels with the new 5.1 upmix signals (including replacing the original source stereo **L** and **R** inputs with new **L** and **R** signals).

The 2.0-to-5.1 upmixer can be set to up mix in any of three modes: Always upmix, Bypass upmix, or Auto enable/bypass upmixing. The Auto upmixing mode looks at the signal levels on the selected channels and compares them to a selectable level threshold. It then determines whether or not to generate 5.1 upmixing from the stereo pair as follows:

- If the upmixer detects signal level **below** a selected threshold on **all four** of the selected channels designated as **C**, **LFE**, **Ls**, and **Rs**, this indicates to the upmixer that these channels are not carrying 5.1. In this case, the upmixer overwrites all six selected channels with the new 5.1 content.
- If the upmixer detects signal level **above** a selected threshold on **any** of the four selected channels designated as **C**, **LFE**, **Ls**, and **Rs**, this indicates to the upmixer that the channel(s) are already carrying viable 5.1 content. In this case, the upmixer is bypassed, allowing the original channels to pass unaffected.

The examples in Figure 1-6 show the automatic enable/disable up-mixing function applied to example selected channels **Emb Ch 1** thru **Emb Ch 6**. As shown and described, the processing is contingent upon the signal levels of the channels selected to carry the new 5.1 upmix relative to the selected threshold (in this example, -60 dBFS). Note also that this function is applied **after** the Audio Routing/Gain Control function. Because all audio inputs pass through the Audio Routing/Gain Control function before the up mixer, the up mixer can use embedded, AES discrete, and/or analog audio sources.



**Figure 1-6 Up Mix Auto Enable/Bypass with Example Sources**



## Tone Generator Function

The 9083 contains four built-in tone generators (Tone Generator 1 thru Tone Generator 4). Each of the four tone generators can be set to a different frequency, and are available as audio sources for the embedded or AES audio outputs.

18 discrete sine wave frequencies are available, ranging from 50 Hz to 16 kHz (default frequency is 1.0 kHz).

## Audio Routing Example

Figure 1-7 shows an example of using the 9083 audio embedding/de-embedding and routing functions to de-embed audio, route the audio to discrete outputs for post-production processing (in this example, a console used for post-production EQ, levels, and monitor), and finally re-embed the audio into the SDI video output. Additionally, the example shows how external analog and internal tone generator sources can be embedded into the SDI output (in this example, a provision for local station ID voice-over analog and a tone).

Note that the source and destination correlations shown here are only examples; **any** source can route to **any** destination.




Figure 1-7 Audio Routing Example

---

## AES Audio Input Advanced Features

### AES Sample Rate Converter

The 9083 AES inputs have sample rate converters that can be independently enabled for each AES pair to allow the card to interface with asynchronous AES sources (sources in which AES timing does not match the video input timing). The sample rate converters are set to disabled (bypassed) by default; this is necessary when embedding non-PCM AES audio such as Dolby® E or Dolby® Digital audio streams. When a valid Dolby® E or Dolby® Digital signal (in accordance with SMPTE 337M) is detected on an AES or embedded audio signal, SRC is automatically bypassed along with gain and polarity controls.

### Zero-Delay Audio Embedding

In cases where additional delay must be avoided, it may be desirable to embed AES with minimum latency. For example if Dolby® E is to be embedded into video with no latency, additional delay may not be tolerable. Using zero-delay embedding, the video can then be delayed by one frame to account for the Dolby E encoding delay. In this manner, any delay between video and audio can be cleanly contained within one frame period.

When zero-delay audio embedding is enabled for a given AES pair, the pair is directly embedded into its corresponding group (for example, AES Pair 1 into embedded channels 1 and 2; AES Pair 2 into embedded channels 3 and 4, and so on) with the normal frame sync audio delay being bypassed.

This function overrides the audio routing system (for example if AES Pair 1 is selected, then the controls to route AES Pair 1 into other embedded channels will not apply). Gain and polarity control is not available when this option is selected. Zero-delay audio embedding is set to Off by default.

### Low-Latency AES Passthrough

This function is similar to zero-delay audio embedding. If low-latency AES passthrough is selected for a given input pair, it causes the corresponding AES output pair to act as a bit-for-bit copy of the corresponding AES input pair.

This control overrides the normal audio routing and delay. Gain and polarity control is not available when this option is selected. Passthrough is set to Off by default.

## Dolby® Decoding (9083-DEC only)

**Note:** Although the 9083-DEC Dolby® decoder can provide Dolby® Digital™ (AC-3) decoding, discussion and examples here describe only Dolby® E decoding.

When Dolby® E or Dolby® Digital™ is present on an embedded audio pair, the decoder produces up to 10 decoded channels (according to the Dolby® sub-format received from the metadata). All resulting channels are available as inputs to the audio router.

### Dolby® Identification and Metadata Output Processing

(See Figure 1-8.) All embedded channels are checked by the 9083-DEC for valid Dolby® status. When a valid Dolby® encoded embedded pair is detected, the channel pair carrying the Dolby® format is displayed as “Present, Dolby E” or “Present, Dolby Digital”, as applicable. (The decoder always uses the metadata associated with its respective pair.) A selected encoded channel pair can then be directed to the Dolby® decoder. The decoder then displays the Dolby® bitstream format and program configuration (for example, “Dolby E 20-bit 5.1+2” indicating 5-channel surround with LFE channel and stereo monitor pair) for the selected pair, as defined by its metadata.

The 9083-DEC can embed metadata on the SDI output, sourced from either SDI input video or from the decoder as desired. Similarly, the 9083-DEC **DOLBY META** output can provide RS-485 metadata for downstream devices or systems. Metadata on the **DOLBY META** RS-485 output can also be sourced from either SDI input video or from the decoder as desired.

### Audio Decoding

(See Figure 1-8.) Based on the channels carrying the Dolby® encoded pair and the format defined within, the Dolby® decoder provides up to 10 decoded audio channels (**Dolby Ch 1** thru **Dolby Ch 8**; **Dolby Mix 1**, **Dolby Mix 2**). Each channel can be routed just as any other audio channel described in this section.





Figure 1-8 Dolby® Decoding and Metadata Output Processing

## User Control Interface

Figure 1-9 shows the user control interface options for the 9083. These options are individually described below.

**Note:** All user control interfaces described here are cross-compatible and can operate together as desired. Where applicable, any control setting change made using a particular user interface is reflected on any other connected interface.



**Figure 1-9 9083 User Control Interface**

- **Built-in Card Edge User Interface** – Using the built-in card edge controls and display, card control settings can be set using a front panel menu which is described in Chapter 3, “Operating Instructions”.

**Note:** Some of the 9083 functions described in this manual are available only when using the DashBoard™, or Cobalt® OGCP-9000 or OGCP-9000/CC Remote Control Panel user interfaces.

- **DashBoard™ User Interface** – Using DashBoard™, the 9083 and other cards installed in openGear™ frames such as the Cobalt® 8321 Frame can be controlled from a computer and monitor.

DashBoard™ allows users to view all frames on a network with control and monitoring for all populated slots inside a frame. This simplifies the setup and use of numerous modules in a large installation and offers the ability to centralize monitoring. Cards define their controllable parameters to DashBoard™, so the control interface is always up to date.

The DashBoard™ software can be downloaded from the Cobalt Digital Inc. website: [www.cobaltdigital.com](http://www.cobaltdigital.com) (enter “DashBoard” in the search window). The DashBoard™ user interface is described in Chapter 3, “Operating Instructions”.

**Note:** If network remote control is to be used for the frame and the frame has not yet been set up for remote control, Cobalt® reference guide **Remote Control User Guide (PN 9000RCS-RM)** provides thorough information and step-by-step instructions for setting up network remote control of COMPASS™ cards using DashBoard™. (Cobalt® OGCP-9000 and OGCP-9000/CC Remote Control Panel product manuals have complete instructions for setting up remote control using a Remote Control Panel.)

Download a copy of this guide by clicking on the **Support>Documents>Reference Guides** link at [www.cobaltdigital.com](http://www.cobaltdigital.com) and then select DashBoard Remote Control Setup Guide as a download, or contact Cobalt® as listed in Contact Cobalt Digital Inc. (p. 1-26).

- **Cobalt® OGCP-9000 and OGCP-9000/CC Remote Control Panels** – The OGCP-9000 and OGCP-9000/CC Remote Control Panels conveniently and intuitively provide parameter monitor and control of the 9083 and other video and audio processing terminal equipment meeting the open-architecture Cobalt COMPASS™ cards for openGear™ standard.

In addition to circumventing the need for a computer to monitor and control signal processing cards, the Control Panels allow quick and intuitive access to hundreds of cards in a facility, and can monitor and allow adjustment of multiple parameters at one time.

The Remote Control Panels are totally compatible with the openGear™ control software DashBoard™; any changes made with either system are reflected on the other. The Remote Control Panel user interface is described in Chapter 3, “Operating Instructions”.


## 9083 Rear I/O Modules

The 9083 physically interfaces to system video and audio connections using a Rear I/O Module. Figure 1-10 shows a typical 9083 Rear I/O Module.

All inputs and outputs shown in the 9083 Functional Block Diagram (Figure 1-1) enter and exit the card via the card edge backplane connector. The Rear I/O Module breaks out the 9083 card edge connections to industry standard connections that interface with other components and systems in the signal chain.

In this manner, the particular inputs and outputs required for a particular application can be accommodated using a Rear I/O Module that suits the requirements. The required input and outputs are broken out to the industry standard connectors on the Rear I/O Module; the unused inputs and outputs remain unterminated and not available for use.

The full assortment of 9083 Rear I/O Modules is shown and described in 9083 Rear I/O Modules (p. 2-6) in Chapter 2, “Installation and Setup”.



**Figure 1-10 Typical 9083 Rear I/O Modules**

## Audio and Video Formats Supported by the 9083

The 9083 supports all current SMPTE standard SD and HD video formats. Table 1-1 lists and provides details regarding the audio and video formats supported by the 9083.

**Table 1-1 Supported Audio and Video Formats**

Item	Description/Specification	
Input / Output Video	Raster Structure:	Frame Rate:
	1080PsF	23.98; 24
	1080p	23.98; 24
	1080i <sup>(1)</sup>	25; 29.97; 30
	720p	23.98; 24; 25; 29.97; 30; 50; 59.94; 60
	486i <sup>(1)</sup>	29.97
	575i <sup>(1)</sup>	25
Embedded Audio	The 9083 supports all four groups (16 channels) of embedded audio at full 24-bit resolution in both SD (with extended data packets) and HD.	
Analog Audio	The 9083 supports 8 channels of balanced (differential) analog audio. The analog audio is encoded such that a +24 dBu input is equivalent to digital 0 dBFS.	
Discrete AES Audio Input	The 9083 can accept 16 channels (8 pairs) of discrete AES audio on 75Ω BNC connections. Sample rate conversion can be employed to account for minor clock rate differences in the AES stream and the input video stream.  <b>Note:</b> The AES signal must have a nominal rate of approximately 48 kHz. The 9083 does not support AES input at 32 kHz, 44.1 kHz, 96 kHz or 192 kHz rates.	
Discrete AES Audio Output	The 9083 can provide 16 channels (8 pairs) of discrete AES audio on 75Ω BNC connections.	
<b>(9083-DEC only)</b> Dolby® E/ Dolby® Digital™ Audio Input Decode	The 9083-DEC provides up to 10 decoded AES channels when valid Dolby® E or Dolby® Digital™ audio is received on either discrete AES or embedded inputs with corresponding metadata.	
(1) All rates displayed as frame rates; interlaced ("i") field rates are two times the rate value shown.		



## Technical Specifications

Table 1-2 lists the technical specifications for the 9083 HD/SD Frame Sync HD/SD Frame Sync with Audio Embedding/De-Embedding and Dolby® Decoding Option card.

**Table 1-2 Technical Specifications**

Item	Characteristic
Part number, nomenclature	<ul style="list-style-type: none"> <li>• 9083 – HD/SD Frame Sync HD/SD Frame Sync with Audio Embedding/De-Embedding</li> <li>• 9083-DEC – HD/SD Frame Sync HD/SD Frame Sync with Audio Embedding/De-Embedding and Dolby® Decoding Option</li> </ul>
Installation/usage environment	Intended for installation and usage in frame meeting openGear™ modular system definition.
Power consumption	< 15 Watts maximum
Environmental: Operating temperature: Relative humidity (operating or storage):	32° – 104° F (0° – 40° C) < 95%, non-condensing
Frame communication	10/100 Mbps Ethernet with Auto-MDIX.
Indicators	Card edge display and indicators as follows: <ul style="list-style-type: none"> <li>• 4-character alphanumeric display</li> <li>• Status/Error LED indicator</li> <li>• Input Format LED indicator</li> </ul>
Controls	Card edge switches as follows: <ul style="list-style-type: none"> <li>• Menu Enter pushbutton switch</li> <li>• Menu Exit pushbutton switch</li> <li>• Up/down selection toggle switch</li> </ul>
Internal Tone Generators	Four built-in tone generators, each configurable for 18 discrete sine wave frequencies ranging from 50 Hz to 16 kHz.  Generator source signal level is equivalent to -20 dBu.
Resolution	10-bit video data path

**Table 1-2 Technical Specifications — continued**

Item	Characteristic
Serial Digital Video Input	Data Rates Supported: SMPTE 292 HD-SDI: 1.485 Gbps or 1.485/1.001 Gbps SMPTE 259M-C SD-SDI: 270 Mbps Impedance: 75 $\Omega$ terminating Equalization (HD): 328 ft (100 m) Belden 1694A Equalization (SD): 1000 ft (305 m) Belden 1694A Return Loss: > 15 dB at 5 MHz – 1.485 GHz
Post-Processor Serial Digital Video Outputs	Number of Outputs: Two HD/SD-SDI BNC per IEC 60169-8 Amendment 2 Impedance: 75 $\Omega$ Return Loss: > 15 dB at 5 MHz – 270 MHz > 12 dB at 270 MHz – 1.485 GHz Signal Level: 800 mV $\pm$ 10% DC Offset: 0 V $\pm$ 50 mV Jitter (HD): < 0.15 UI (all outputs) Jitter (SD): < 0.10 UI (all outputs) Overshoot: < 0.2% of amplitude
Pre-Processor (Reclocked) Serial Digital Video Outputs	Number of Outputs: Two HD/SD-SDI BNC per IEC 60169-8 Amendment 2 Impedance: 75 $\Omega$

Table 1-2 Technical Specifications — continued

Item	Characteristic
AES Audio Input	Standard: SMPTE 276M Number of Inputs (maximum): 8 unbalanced Input Level: 0.1 to 2.5 Vp-p (5 Vp-p tolerant) Input Impedance: 75 $\Omega$ Return Loss: > 12 dB at 100 kHz to 6 MHz
	Resolution: 24-bit only Sample Rate: 48 kHz SRC: 32-channel; 142 dB S/N
Analog Audio Input	Number of Inputs (maximum): Eight, 3-wire balanced analog audio using Phoenix connectors with removable screw terminal blocks (Phoenix PN 1803581; Cobalt PN 5000-0013-000R) Sampling Rate: 48 kHz (locked to video input) Signal Level: +24 dBu => 0 dBFS A/D Frequency Response: 20 – 20 kHz $\pm$ 0.25 dB
AES Audio Output	Standard: SMPTE 276M Number of Outputs (maximum): 8 unbalanced Output Impedance: 75 $\Omega$ Return Loss: > 30 dB 100 kHz to 6 MHz Sample Rate: 48 kHz
<b>(9083-DEC only)</b> Dolby® Metadata Output	2-wire RS-485 and/or embedded into SDI video output (user selectable)

**Table 1-2 Technical Specifications — continued**

Item	Characteristic
Reference Video Input	<p>Number of Inputs: Two non-terminating (looping) Frame Reference inputs</p> <p>Standards Supported (HD): 720p 24; 25; 29.97; 30; 50; 59.94 1080i 25; 29.97 1080p 23.98; 24; 25; 29.97; 30 1080p/sF 23.98; 24</p> <p>Standards Supported (SD): 486i 29.97 (NTSC); 575i 25 (PAL)</p> <p>Signal Level: 1 Vp-p nominal</p> <p>Signal Type: Analog video sync (black burst or tri-level)</p> <p>Impedance: 75 <math>\Omega</math></p> <p>Return Loss: &gt; 30 dB to 30 MHz</p> <p>Allowable Maximum DC on Ref Input: <math>\pm 1.0</math> V</p>

---

## Warranty and Service Information

### Cobalt Digital Inc. Limited Warranty

This product is warranted to be free from defects in material and workmanship for a period of five (5) years from the date of shipment to the original purchaser, except that 4000, 5000, 6000, 8000 series power supplies, and Dolby® modules (where applicable) are warranted to be free from defects in material and workmanship for a period of one (1) year.

Cobalt Digital Inc.'s ("Cobalt") sole obligation under this warranty shall be limited to, at its option, (i) the repair or (ii) replacement of the product, and the determination of whether a defect is covered under this limited warranty shall be made at the sole discretion of Cobalt.

This limited warranty applies only to the original end-purchaser of the product, and is not assignable or transferrable therefrom. This warranty is limited to defects in material and workmanship, and shall not apply to acts of God, accidents, or negligence on behalf of the purchaser, and shall be voided upon the misuse, abuse, alteration, or modification of the product. Only Cobalt authorized factory representatives are authorized to make repairs to the product, and any unauthorized attempt to repair this product shall immediately void the warranty. Please contact Cobalt Technical Support for more information.

To facilitate the resolution of warranty related issues, Cobalt recommends registering the product by completing and returning a product registration form. In the event of a warrantable defect, the purchaser shall notify Cobalt with a description of the problem, and Cobalt shall provide the purchaser with a Return Material Authorization ("RMA"). For return, defective products should be double boxed, and sufficiently protected, in the original packaging, or equivalent, and shipped to the Cobalt Factory Service Center, postage prepaid and insured for the purchase price. The purchaser should include the RMA number, description of the problem encountered, date purchased, name of dealer purchased from, and serial number with the shipment.

**Cobalt Digital Inc. Factory Service Center**

2406 E. University Avenue  
Urbana, IL 61802 USA  
www.cobaltdigital.com

Office: (217) 344-1243  
Fax: (217) 344-1245  
Email: info@cobaltdigital.com

THIS LIMITED WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND OF ALL OTHER OBLIGATIONS OR LIABILITIES ON COBALT'S PART. ANY SOFTWARE PROVIDED WITH, OR FOR USE WITH, THE PRODUCT IS PROVIDED "AS IS." THE BUYER OF THE PRODUCT ACKNOWLEDGES THAT NO OTHER REPRESENTATIONS WERE MADE OR RELIED UPON WITH RESPECT TO THE QUALITY AND FUNCTION OF THE GOODS HEREIN SOLD. COBALT PRODUCTS ARE NOT AUTHORIZED FOR USE IN LIFE SUPPORT APPLICATIONS.

COBALT'S LIABILITY, WHETHER IN CONTRACT, TORT, WARRANTY, OR OTHERWISE, IS LIMITED TO THE REPAIR OR REPLACEMENT, AT ITS OPTION, OF ANY DEFECTIVE PRODUCT, AND SHALL IN NO EVENT INCLUDE SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS), EVEN IF IT HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

---

## Contact Cobalt Digital Inc.

Feel free to contact our thorough and professional support representatives for any of the following:

- Name and address of your local dealer
- Product information and pricing
- Technical support
- Upcoming trade show information

<b>Phone:</b>	(217) 344-1243
<b>Fax:</b>	(217) 344-1245
<b>Web:</b>	<a href="http://www.cobaltdigital.com">www.cobaltdigital.com</a>
<b>General Information:</b>	info@cobaltdigital.com
<b>Technical Support:</b>	support@cobaltdigital.com

---

# Installation and Setup

## Overview

This chapter contains the following information:

- Setting I/O Switches for AES I/O (1-4) Ports (p. 2-1)
- Installing the 9083 Into a Frame Slot (p. 2-2)
- Installing a Rear I/O Module (p. 2-5)
- Setting Up 9083 Network Remote Control (p. 2-10)

## Setting I/O Switches for AES I/O (1-4) Ports

**Note:** This procedure is applicable only if any of the four AES I/O (1-4) ports on the 9083 are to be used as **outputs** (the switches are set to input mode by factory default). The 9083 is equipped with a four-section red DIP switch that sets AES pairs 1 thru 4 as either inputs or outputs. The factory default position is the **input** position for each pair.

- If all of the AES I/O (1-4) ports are to be used as inputs (or not used at all), omit this procedure.
- If any of the AES I/O (1-4) ports are to be used as outputs, set the switches as described in this procedure.

Note switch S11 thru S14 settings for **AES I/O 1** thru **AES I/O 4** mode shown in Figure 2-1. For port to be used as an **output**, set switch to down position as shown in Figure 2-1.

**Note:** Regardless of S11 thru S14 settings for **AES I/O 1** thru **AES I/O 4**, outputs **AES OUT (1-8)** are still available on cards equipped with a Rear I/O Module having dedicated **AES OUT (1-8)** BNC connectors.




Figure 2-1 9083 AES I/O (1-4) Mode Switches

## Installing the 9083 Into a Frame Slot

### CAUTION

Heat and power distribution requirements within a frame may dictate specific slot placement of cards. Cards with many heat-producing components should be arranged to avoid areas of excess heat build-up, particularly in frames using only convection cooling. The 9083 has a moderate power dissipation (15 W max.). As such, avoiding placing the card adjacent to other cards with similar dissipation values if possible.

### CAUTION



This device contains semiconductor devices which are susceptible to serious damage from Electrostatic Discharge (ESD). ESD damage may not be immediately apparent and can affect the long-term reliability of the device.

Avoid handling circuit boards in high static environments such as carpeted areas, and when wearing synthetic fiber clothing. Always use proper ESD handling precautions and equipment when working on circuit boards and related equipment.



- Note:**
- **If installing the 9083 in an 8310-C-BNC or 8310-BNC frame** (which is pre-equipped with a 100-BNC rear I/O module installed across the entire backplane) or a slot already equipped with a suitable I/O module, proceed to card installation steps below.
  - **If installing the 9083 in an 8321 frame, or in a slot with no rear I/O module, a Rear I/O Module is required** before cabling can be connected. Refer to Installing a Rear I/O Module (p. 2-5) for rear I/O module installation procedure.

### CAUTION

**If required, make certain Rear I/O Module(s) is installed before installing the 9083 into the frame slot. Damage to card and/or Rear I/O Module can occur if module installation is attempted with card already installed in slot.**

- Note:** Check the packaging in which the 9083 was shipped for any extra items such as a Rear I/O Module connection label. In some cases, this label is shipped with the card and to be installed on the Rear I/O connector bank corresponding to the slot location of the card.

Install the 9083 into a frame slot as follows:

1. Determine the slot in which the 9083 is to be installed.
2. Open the frame front access panel.
3. While holding the card by the card edges, align the card such that the plastic ejector tab is on the bottom.
4. Align the card with the top and bottom guides of the slot in which the card is being installed.
5. Gradually slide the card into the slot. When resistance is noticed, gently continue pushing the card until its rear printed circuit edge terminals engage fully into the rear I/O module mating connector.

### CAUTION

**If card resists fully engaging in rear I/O module mating connector, check for alignment and proper insertion in slot tracks. Damage to card and/or rear I/O module may occur if improper card insertion is attempted.**

6. Verify that the card is fully engaged in rear I/O module mating connector.
7. Close the frame front access panel.

8. Connect the input and output cables as follows:
  - If the 9083 is being installed in a PN 8310-BNC or 8310-C-BNC frame, refer to the label on the connector bank corresponding to the card's slot location for connector designations.
  - If the 9083 is being installed in a frame using a specific 9083 Rear I/O Module, connect cabling in accordance with the appropriate diagram shown in Table 2-1, "9083 Rear I/O Modules" (p. 2-6).
9. Repeat steps 1 through 8 for other 9083 cards.

**Note:** The 9083 BNC inputs are internally 75-ohm terminated. It is not necessary to terminate unused BNC inputs or outputs.

**Note:** To remove a card, press down on the ejector tab to unseat the card from the rear I/O module mating connector. Evenly draw the card from its slot.

10. If network remote control is to be used for the frame and the frame has not yet been set up for remote control, perform setup in accordance with Cobalt® reference guide "COMPASS™ Remote Control User Guide" (PN 9000RCS-RM).

**Note:** If installing a card in a frame already equipped for, and connected to DashBoard™, no network setup is required for the card. The card will be discovered by DashBoard™ and be ready for use.


## Installing a Rear I/O Module

**Note:** This procedure is applicable **only if a Rear I/O Module is not currently installed** in the slot where the 9083 is to be installed.

If installing the 9083 in a 8310-C-BNC or 8310-BNC frame (which is pre-equipped with a 100-BNC rear I/O module installed across the entire backplane) or a slot already equipped with a suitable I/O module, omit this procedure.

The full assortment of 9083 Rear I/O Modules is shown and described in 9083 Rear I/O Modules (p. 2-6). Install a Rear I/O Module as follows:

1. On the frame, determine the slot in which the 9083 is to be installed.
2. In the mounting area corresponding to the slot location, install Rear I/O Module as shown in Figure 2-2.





**Figure 2-2 Rear I/O Module Installation**

## 9083 Rear I/O Modules

Table 2-1 shows and describes the full assortment of Rear I/O Modules specifically for use with the 9083.

- Notes:**
- Rear I/O Modules equipped with 3-wire Phoenix connectors are supplied with removable screw terminal block adapters. For clarity, the adapters are omitted in the drawings below.
  - RM20-x Rear I/O Modules compatible **only** with 8321 20-slot frames.

Table 2-1 9083 Rear I/O Modules

9083 Rear I/O Module	Description
<p><b>RM-9083-A</b></p> 	<p>Provides the following connections:</p> <ul style="list-style-type: none"> <li>• HD/SD-SDI coaxial input (<b>SDI IN</b>)</li> <li>• Two HD/SD-SDI reclocked input copies (<b>RCK OUT 1</b> and <b>RCK OUT 2</b>)</li> <li>• Four AES I/O coaxial input/outputs (<b>AES I/O 1</b> thru <b>AES I/O 4</b>; I/O function of each connection is user-configurable)</li> <li>• Two buffered SDI coaxial outputs (<b>SDI OUT 1</b> and <b>SDI OUT 2</b>)</li> </ul>
<p><b>RM20-9083-A/S</b></p> 	<p>Split Rear Module. Provides <b>each</b> of the following connections for two 9083 cards:</p> <ul style="list-style-type: none"> <li>• HD/SD-SDI coaxial input (<b>SDI IN</b>)</li> <li>• HD/SD-SDI reclocked input copy (<b>RCK OUT 1</b>)</li> <li>• Two AES I/O coaxial input/outputs (<b>AES I/O 1</b> and <b>AES I/O 2</b>; I/O function of each connection is user-configurable)</li> <li>• Buffered SDI coaxial output (<b>SDI OUT 1</b>)</li> </ul>

**Table 2-1 9083 Rear I/O Modules — continued**

9083 Rear I/O Module	Description
<p><b>RM-9083-B</b></p> <p>RM-9083-B.PNG</p>	<p>Provides the following connections:</p> <ul style="list-style-type: none"> <li>• HD/SD-SDI coaxial input (<b>SDI IN</b>)</li> <li>• Six analog balanced audio inputs (<b>AN-AUD IN 1</b> thru <b>AN-AUD IN 6</b>)</li> <li>• Two buffered SDI coaxial outputs (<b>SDI OUT 1</b> and <b>SDI OUT 2</b>)</li> </ul>
<p><b>RM-9083-C</b></p> <p>RM-9083-C.PNG</p>	<p>Provides the following connections:</p> <ul style="list-style-type: none"> <li>• HD/SD-SDI coaxial input (<b>SDI IN</b>)</li> <li>• Four AES I/O coaxial input/outputs (<b>AES I/O 1</b> thru <b>AES I/O 4</b>; I/O function of each connection is user-configurable)</li> <li>• Two dedicated AES coaxial audio inputs (<b>AES IN 5</b> and <b>AES IN 6</b>)</li> <li>• Two dedicated AES coaxial audio outputs (<b>AES OUT 1</b> and <b>AES OUT 2</b>)</li> <li>• Eight analog balanced audio inputs (<b>AN-AUD IN 1</b> thru <b>AN-AUD IN 8</b>)</li> <li>• Two buffered SDI coaxial outputs (<b>SDI OUT 1</b> and <b>SDI OUT 2</b>)</li> </ul> <p><b>Note:</b> <b>AES OUT 1</b> and <b>AES OUT 2</b> on RM-9083-C Rear I/O Module always function as outputs regardless of whether <b>AES I/O 1</b> or <b>AES I/O 2</b> are used as inputs or outputs.</p>

Table 2-1 9083 Rear I/O Modules — continued

9083 Rear I/O Module	Description
<p><b>RM-9083-D</b></p>	<p>Provides the following connections:</p> <ul style="list-style-type: none"> <li>• HD/SD-SDI coaxial input (<b>SDI IN</b>)</li> <li>• Four AES I/O coaxial input/outputs (<b>AES I/O 1</b> thru <b>AES I/O 4</b>; I/O function of each connection is user-configurable)</li> <li>• Two dedicated AES coaxial audio outputs (<b>AES OUT 1</b> and <b>AES OUT 2</b>)</li> <li>• Eight analog balanced audio inputs (<b>AN-AUD IN 1</b> thru <b>AN-AUD IN 8</b>)</li> <li>• Dolby® RS-485 metadata output (<b>DOLBY META</b>)</li> <li>• Two buffered SDI coaxial outputs (<b>SDI OUT 1</b> and <b>SDI OUT 2</b>)</li> </ul> <p><b>Note:</b> <b>AES OUT 1</b> and <b>AES OUT 2</b> on RM-9083-D Rear I/O Module always function as outputs regardless of whether <b>AES I/O 1</b> or <b>AES I/O 2</b> are used as inputs or outputs.</p>
<p><b>RM-9083-E</b></p>	<p>Provides the following connections:</p> <ul style="list-style-type: none"> <li>• HD/SD-SDI coaxial input (<b>SDI IN</b>)</li> <li>• Four AES I/O coaxial input/outputs (<b>AES I/O 1</b> thru <b>AES I/O 4</b>; I/O function of each connection is user-configurable)</li> <li>• Two dedicated AES coaxial audio inputs (<b>AES IN 5</b> and <b>AES IN 6</b>)</li> <li>• Eight dedicated AES coaxial audio outputs (<b>AES OUT 1</b> thru <b>AES OUT 8</b>)</li> <li>• Dolby® RS-485 metadata output (<b>DOLBY META</b>)</li> <li>• Two buffered SDI coaxial outputs (<b>SDI OUT 1</b> and <b>SDI OUT 2</b>)</li> </ul> <p><b>Note:</b> <b>AES OUT 1</b> thru <b>AES OUT 4</b> on RM-9083-E Rear I/O Module always function as outputs regardless of whether <b>AES I/O 1</b> thru <b>AES I/O 4</b> are used as inputs or outputs.</p>

**Table 2-1 9083 Rear I/O Modules — continued**




9083 Rear I/O Module	Description
<p><b>RM-9083-F</b></p> 	<p>Provides the following connections:</p> <ul style="list-style-type: none"> <li>• HD/SD-SDI coaxial input (<b>SDI IN</b>)</li> <li>• Five AES coaxial inputs (<b>AES IN 1</b> thru <b>AES IN 4</b>; <b>AES IN 8</b>)</li> <li>• Two dedicated AES coaxial audio outputs (<b>AES OUT 1</b> and <b>AES OUT 2</b>)</li> <li>• Two buffered SDI coaxial outputs (<b>SDI OUT 1</b> and <b>SDI OUT 2</b>)</li> </ul> <p><b>Note:</b> For <b>AES IN 1</b> thru <b>AES IN 4</b> on RM-9083-F Rear I/O Module to function as inputs, AES I/O switches S11 – S14 must be set to Input (factory default). See Setting I/O Switches for AES I/O (1-4) Ports (p. 2-1) for more information.</p>
<p><b>RM-9083-G</b></p> 	<p>Provides the following connections:</p> <ul style="list-style-type: none"> <li>• HD/SD-SDI coaxial input (<b>SDI IN</b>)</li> <li>• Two HD/SD-SDI reclocked input copies (<b>RCK OUT 1</b> and <b>RCK OUT 2</b>)</li> <li>• Four dedicated AES coaxial audio inputs (<b>AES IN 5</b> thru <b>AES IN 8</b>)</li> <li>• Four AES I/O coaxial input/outputs (<b>AES I/O 1</b> thru <b>AES I/O 4</b>; I/O function of each connection is user-configurable)</li> <li>• Eight dedicated AES coaxial audio outputs (<b>AES OUT 1</b> thru <b>AES OUT 8</b>)</li> <li>• Eight analog balanced audio inputs (<b>AN-AUD IN 1</b> thru <b>AN-AUD IN 8</b>)</li> <li>• Two buffered SDI coaxial outputs (<b>SDI OUT 1</b> and <b>SDI OUT 2</b>)</li> </ul> <p><b>Note:</b> <b>AES OUT 1</b> thru <b>AES OUT 4</b> on RM-9083-G Rear I/O Module always function as outputs regardless of whether <b>AES I/O 1</b> thru <b>AES I/O 4</b> are used as inputs or outputs.</p>

Table 2-1 9083 Rear I/O Modules — continued

9083 Rear I/O Module	Description
<b>RM-9083-H</b> 	<p>Provides the following connections:</p> <ul style="list-style-type: none"> <li>• HD/SD-SDI coaxial input (<b>SDI IN</b>)</li> <li>• Four dedicated AES coaxial audio inputs (<b>AES IN 5</b> thru <b>AES IN 8</b>)</li> <li>• Eight dedicated AES coaxial audio outputs (<b>AES OUT 1</b> thru <b>AES OUT 8</b>)</li> <li>• Four AES I/O coaxial input/outputs (<b>AES I/O 1</b> thru <b>AES I/O 4</b>; I/O function of each connection is user-configurable)</li> <li>• Two buffered SDI coaxial outputs (<b>SDI OUT 1</b> and <b>SDI OUT 2</b>)</li> </ul> <p><b>Note:</b> <b>AES OUT 1</b> thru <b>AES OUT 4</b> on RM-9083-H Rear I/O Module always function as outputs regardless of whether <b>AES I/O 1</b> thru <b>AES I/O 4</b> are used as inputs or outputs.</p>

## Setting Up 9083 Network Remote Control

Perform remote control setup in accordance with Cobalt® reference guide “Remote Control User Guide” (PN 9000RCS-RM).

- Note:**
- If network remote control is to be used for the frame and the frame has not yet been set up for remote control, Cobalt® reference guide **Remote Control User Guide (PN 9000RCS-RM)** provides thorough information and step-by-step instructions for setting up network remote control of COMPASS™ cards using DashBoard™. (Cobalt® OGCP-9000 and OGCP-9000/CC Remote Control Panel product manuals have complete instructions for setting up remote control using a Remote Control Panel.)

Download a copy of this guide by clicking on the **Support> Documents>Reference Guides** link at [www.cobaltdigital.com](http://www.cobaltdigital.com) and then select DashBoard Remote Control Setup Guide as a download, or contact Cobalt® as listed in Contact Cobalt Digital Inc. (p. 1-26).

- If installing a card in a frame already equipped for, and connected to DashBoard™, no network setup is required for the card. The card will be discovered by DashBoard™ and be ready for use.



---

# Operating Instructions

## Overview

This chapter contains the following information:

- Control and Display Descriptions (p. 3-1)
- Accessing the 9083 Card via Remote Control (p. 3-12)
- Checking 9083 Card Information (p. 3-14)
- Ancillary Data Line Number Locations and Ranges (p. 3-15)
- 9083 Function Submenu List and Descriptions (p. 3-16)
- Troubleshooting (p. 3-66)

## Control and Display Descriptions

This section describes the user interface controls, indicators, and displays (both on-card and remote controls) for using the 9083 card. The 9083 functions can be accessed and controlled using any of the user interfaces described here.

The format in which the 9083 functional controls, indicators, and displays appear and are used varies depending on the user interface being used. Regardless of the user interface being used, access to the 9083 functions (and the controls, indicators, and displays related to a particular function) follows a general arrangement of Function Submenus under which related parameters can be accessed (as described in Function Submenu/Parameter Submenu Overview below).

After familiarizing yourself with the arrangement described in Function Submenu/Parameter Submenu Overview, proceed to the subsection for the particular user interface being used. Descriptions and general instructions for using each of the three user interfaces are individually described in the following subsections:


- 9083 Card Edge Controls, Indicators, and Display (p. 3-3)
- DashBoard™ User Interface (p. 3-8)
- Cobalt® Remote Control Panel User Interfaces (p. 3-11)

- Note:** Instructions provided here are applicable for all available user control methods. However, DashBoard™ and the Remote Control Panel provide greatly simplified user interfaces as compared to using the card edge controls. For this reason, **it is strongly recommended** that DashBoard™ or a Remote Control Panel be used for all card applications other than the most basic cases.
- Note:** Not all functions available using DashBoard™ or the Control Panel are available using the card edge controls.
- Note:** When a setting is changed, settings displayed on DashBoard™ (or the Remote Control Panel) are the settings as effected by the 9083 card itself and reported back to the remote control; the value displayed at any time is the actual value as set on the card.

## Function Submenu/Parameter Submenu Overview

The functions and related parameters available on the 9083 card are organized into function **submenus**, which consist of parameter groups as shown below.


Figure 3-1 shows how the 9083 card and its submenus are organized, and also provides an overview of how navigation is performed between cards, function submenus, and parameters.



**Figure 3-1 Function Submenu/Parameter Submenu Overview**

## 9083 Card Edge Controls, Indicators, and Display

Figure 3-2 shows and describes the 9083 card edge controls, indicators, and display.



**Figure 3-2 9083 Controls, Indicators, and Display**

### 9083 Card Edge Control Menu/Submenu Structure

(See below.) Using the menu system of group menus and submenus described earlier, the 9083 parameters/controls are organized into menus and submenus. As appropriate, a submenu similarly may have its own further additional subordinate submenus.

Menu Group Item	Menu Depth	Menu depth (as indicated by 9083 Menu Depth LEDs)
		none
Submenu 1 (Submenu 1 selection items)	1	● ○ ○ ○
Submenu 2 (Submenu 2 selection items)	2	● ● ○ ○
Submenu 3 (Submenu 3 selection items and/or parameter values)	3	● ● ● ○
Submenu 4 (Submenu 4 selection items and/or parameter values)	4	● ● ● ●

Figure 3-3 shows an example of using the card edge controls to access the Embedded Audio processing group menu (along with some of its submenus) to set the routing and signal processing parameters for an embedded audio channel. (A) through (S) in Figure 3-3 denote the discrete tasks required in performing the example setup using the 9083 card edge controls.

In this example, the following input processing is being performed:

- Embedded Channel 3 is selected as the source for Embedded Channel 1 within Embedded Audio Group 1.
- Gain is increased over unity default by 12.1.
- Phase is inverted.

In this example, the following output processing is being performed:

- The embedded Channel 1 path has been directed to AES Output Channel 1.
- Gain is increased over unity output default by 18.5.
- Phase is normal (non-inverted).

Due to the limited control available when using the built-in card edge control user interface, the navigation into and out of submenus shown in Figure 3-3 is required to perform the setup described above.

Embedded Audio					Select a top-level menu item (in this example, select <b>Aud</b> (embedded audio routing/control))
Submenu Depth					
	1	2	3	4	
(A)	Embd AES Tone				Press <b>Enter Menu</b> and in this example, select <b>Embd</b> (Embedded Audio Groups). This selects embedded audio function of the Audio processor.
(B)		Grp1 Grp2 Grp3 Grp4			Press <b>Enter Menu</b> again and in this example, select <b>Grp1</b> (Embedded Audio Group 1). This selects the embedded audio group to be accessed.
(C)			Enbl		Press <b>Enter Menu</b> again and in this example, select <b>Enbl</b> (Enable).
(D)				On Off	Press <b>Enter Menu</b> again and in this example, select <b>On</b> . This sets the selected embedded audio group to <b>Enabled</b> .
(E)			Ch01 Ch02 Ch03 Ch04		Press <b>Exit Menu</b> and in this example, select <b>Ch01</b> (Destination: Embedded Channel 1). This selects the embedded channel to be accessed.
(F)				Src Gain Pol	Press <b>Enter Menu</b> and select in this example, <b>Src</b> (source for embedded channel 1). This selects the source for the embedded channel.
(G)				Em01 Em02 Em03 ...	Press <b>Enter Menu</b> again and in this example, select <b>Em03</b> (embeddded channel 3 as source for embedded channel 1). This selects embedded channel 3 as the source for embedded channel 1.
(H)				Src Gain Pol	Press <b>Exit Menu</b> and in this example, select <b>Gain</b> (gain adjustment field for selected embedded audio channel).
(I)				(gain value)	Press <b>Enter Menu</b> again and in this example, select a gain value of 12.1 for this channel.
(J)				Src Gain Pol	Press <b>Exit Menu</b> and in this example, select <b>Pol</b> (phase for embedded channel 1).
(K)				Norm Inv	Press <b>Enter Menu</b> again and in this example, select <b>Inv</b> (invert polarity for embedded channel 1).

(continued on next page)

**Figure 3-3 Card Edge Controls Setup of Example Embedded Audio Function (sheet 1 of 2)**

Submenu Depth					(continued from previous page)
	1	2	3	4	
(L)	Embd <b>AES</b> Tone				Go to submenu 1 and in this example, select <b>AES</b> (AES output channel selection). This selects an AES output channel as the output for this group.
(M)		<b>Ch01</b> Ch02 Ch03 ...			Press <b>Enter Menu</b> and in this example, select <b>Ch01</b> (AES Output Channel 1).
(N)			<b>Src</b> Gain Pol		Press <b>Enter Menu</b> again and select in this example, <b>Src</b> (source for AES Output Channel 1).
(O)				<b>Em01</b> Em02 Em03 ...	Press <b>Enter Menu</b> again and in this example, select <b>Em01</b> (Embeddded Channel 1 as source for AES Output Channel 1).
(P)			Src <b>Gain</b> Pol		Press <b>Exit Menu</b> and in this example, select <b>Gain</b> (gain adjustment field for selected AES output channel).
(Q)				(gain value)	Press <b>Enter Menu</b> and in this example, select a gain value of 18.5 for this channel.
(R)			Src Gain <b>Pol</b>		Press <b>Exit Menu</b> and in this example, select <b>Pol</b> (polarity for Embedded Channel 1).
(S)				<b>Norm</b> Inv	Press <b>Enter Menu</b> and in this example, select <b>Norm</b> (no invert for AES output channel 1).

#### Card Edge Setup Abbreviated Diagram

In Table 3-2, "9083 Function Submenu List" abbreviated diagrams (as shown above and in the example to the right) show the navigation required to access a particular submenu item or parameter when using the card edge controls.

In this example, group enable for Embedded Audio Group 1 is being enabled.

Card Edge Control Menu:

**Aud**


1	2	3	4
Embd	Grp1	Enbl	<b>On</b> Off

**Set embedded audio group to On**  
Set embedded audio group to Off

**Figure 3-3 Card Edge Controls Setup of Example Embedded Audio Function (sheet 2 of 2)**


## Card Edge Display Orientation, Brightness, and Timeout Adjust

The card edge 4-Character Alphanumeric Display can be changed between vertical or horizontal character orientation to suit the mounting position of the card as shown and described below.




**Figure 3-4 Card Edge Display Orientation**

1. Access the **Displ** (Display) menu.
2. Select between Horizontal or Vertical as shown below.



Adjust the display brightness as described below.

1. Access the **Displ** (Display) menu.
2. Select from the relative brightness levels as shown below.



The timeout period from when a menu is entered to when the display times out (reverts to the default card model display) can be adjusted from 5 to 9999 seconds (166.7 minutes) as described below.

1. Access the **Displ** (Display) menu.
2. Use the up/down switch to enter the desired timeout value as shown below.

Card Edge Control Menu:

**Disp**

1

2

TOUT      (value)


Timeout value (in seconds)

## DashBoard™ User Interface

(See Figure 3-5.) The 9083 function submenus are organized in DashBoard™ using tabs (for example, “Embedded Audio Group 1/2” in Figure 3-5). When a tab is selected, each parametric control or selection list item associated with the function is displayed. Scalar (numeric) parametric values can then be adjusted as desired using the GUI slider controls. Items in a list can then be selected using GUI drop-down lists. (In this manner, the setting effected using controls and selection lists displayed in DashBoard™ are comparable to the submenu items accessed and committed using the 9083 card edge controls.)

Figure 3-5 shows the same setup described in Figure 3-3 as performed using DashBoard™. Note how this setup is greatly simplified using DashBoard™ with most of the discrete tasks (Ⓐ through Ⓢ in Figure 3-3) performed with the card edge controls now rolled into simple actions using DashBoard™.





**Figure 3-5 DashBoard™ Setup of Example Embedded Audio Function (sheet 1 of 2)**




## Cobalt® Remote Control Panel User Interfaces

(See Figure 3-6.) Similar to the function submenu tabs using DashBoard™, the Remote Control Panels have a Select Submenu key that is used to display a list of function submenus. From this list, a control knob on the Control Panel is used to select a function from the list of displayed function submenu items.

When the desired function submenu is selected, each parametric control or selection list item associated with the function is displayed. Scalar (numeric) parametric values can then be adjusted as desired using the control knobs, which act as potentiometers. Items in a list can then be selected using the control knobs which correspondingly act as rotary switches. (In this manner, the setting effected using controls and selection lists displayed on the Control Panel are comparable to the submenu items accessed and committed using the 9083 card edge controls.)

Figure 3-6 shows accessing a function submenu and its parameters (in this example, “Video Proc”) using the Control Panel as compared to using the card edge controls.

**Note:** Refer to “OGCP-9000 Remote Control Panel User Manual” (PN OGCP-9000-OM) or “OGCP-9000/CC Remote Control Panel User Manual” (PN OGCP-9000/CC-OM) for complete instructions on using the Control Panels.




**Figure 3-6 Remote Control Panel Setup of Example Video Proc Function**

## Accessing the 9083 Card via Remote Control


Access the 9083 card using DashBoard™ or Cobalt® Remote Control Panel as described below.

### Accessing the 9083 Card Using DashBoard™


1. On the computer connected to the frame LAN, open DashBoard™.
2. As shown below, in the left side Basic View Tree locate the Network Controller Card associated with the frame containing the 9083 card to be accessed (in this example, “MFC-8310-N SN: 00108053”).



3. As shown below, expand the tree to access the cards within the frame. Click on the card to be accessed (in this example, “Slot 7: CDI-9083 RCVR21”).




As shown on the next page, when the card is accessed a DashBoard™ its function submenu screen showing tabs for each function is displayed. (The particular submenu screen displayed is the previously displayed screen from the last time the card was accessed by DashBoard™).



## Accessing the 9083 Card Using a Cobalt® Remote Control Panel

Press the **Select Device** key and select a card as shown in the example below.



## Checking 9083 Card Information

The operating status and software version the 9083 card can be checked using DashBoard™ or the card edge control user interface. Figure 3-7 shows and describes the 9083 card information screen using DashBoard™ and accessing card information using the card edge control user interface.

**Note:** Proper operating status in DashBoard™ is denoted by green icons for the status indicators shown in Figure 3-7. Yellow or red icons respectively indicate an alert or failure condition. Refer to Troubleshooting (p. 3-66) for corrective action.

The **Tree View** shows the cards seen by DashBoard™. In this example, Network Controller Card MFC-8310-N (serial number ...8053) is hosting a 9083 card in slot 7.

**Software Version Number**  
Refer to this number to check that documentation (such as this manual) matches the card's Software Version Number. Use this number also when communicating to Cobalt® regarding this card.

**Power Consumption and Temperature Displays**  
This display shows the power consumed by the 9083 for both the +12V and -7.5V rails, as well as key device temperatures.

**Status Displays**  
These displays show the status the signal being received by the 9083. Green Settings icon shows that any changes made on DashBoard™ are successfully saved on the card's memory.

	1	2	
<b>Checking Card Using Card Edge Controls</b>	+POW	(value)	+12 V Watts consumed
	-POW	(value)	- 7.5V Watts consumed
	SWR#	(value)	Software Release Number
	SWB#	(value)	Software Build Number
	FPG#	(value)	FPGA Build Number
		(value)	

**Figure 3-7 9083 Card Info Utility**

## Ancillary Data Line Number Locations and Ranges

Table 3-1 lists typical default output video VANC line number locations for various ancillary data items that may be passed or handled by the card.

**Table 3-1 Typical Ancillary Data Line Number Locations/Ranges**


Item	Default Line No. / Range	
	SD	HD
AFD	12 (Note 2)	9 (Note 2)
ATC_VITC	12 (locked)	9/8 (Note 2)
ATC_LTC	—	10 (Note 2)
Dolby® Metadata	13 (Note 2)	13 (Note 2)
SDI VITC Waveform	14/16 (Note 2)	—
Closed Captioning	21 (locked)	10 (Note 2)

Notes:

- The card does not check for conflicts on a given line number. Make certain the selected line is available and carrying no other data.
- While range indicated by drop-down list on GUI may allow a particular range of choices, the actual range is automatically clamped (limited) to certain ranges to prevent inadvertent conflict with active picture area depending on video format. Limiting ranges for various output formats are as follows:

Format	Line No. Limiting	Format	Line No. Limiting	Format	Line No. Limiting
525i	12-19	720p	9-25	1080p	9-41
625i	9-22	1080i	9-20		


Because line number allocation is not standardized for all ancillary items, consideration should be given to all items when performing set-ups. Figure 3-8 shows an example of improper and corrected VANC allocation within an HD-SDI stream.



**Figure 3-8 Example VANC Line Number Allocation Example**

## 9083 Function Submenu List and Descriptions


Table 3-2 individually lists and describes each 9083 function submenu ('tab') and its related list selections, controls, and parameters. Where helpful, examples showing usage of a function are also provided. Table 3-2 is primarily based upon using DashBoard™ to access each function and its corresponding submenus and parameters.

**Note:** All numeric (scalar) parameters displayed on DashBoard™ can be changed using the slider controls,  arrows, or by numeric keypad entry in the corresponding numeric field. (When using numeric keypad entry, add a return after the entry to commit the entry.)

**Note:** Table 3-2 also provides abbreviated menu structure charts showing the menu structure for accessing the function/parameter using the card edge controls. Where this is not shown for a particular control, this indicates the control is **not** available using card edge controls.

If using card edge controls, refer to 9083 Card Edge Control Menu/Submenu Structure (p. 3-4) and Figure 3-3 for an explanation and an example of card edge control menu structure navigation.

On DashBoard™ itself and in Table 3-2, the function submenu items are organized using tabs as shown below.



The table below provides a quick-reference to the page numbers where each function submenu item can be found.

Function Submenu Item	Page	Function Submenu Item	Page
Audio Input Controls	3-17	Dolby Decoder <b>(9083-DEC only)</b>	3-44
Video Proc	3-20	Dolby E Metadata <b>(9083-DEC only)</b>	3-47
AFD	3-22	Dolby D Metadata <b>(9083-DEC only)</b>	3-48
Framesync	3-23	Timecode	3-49
Embedded Audio Group 1/2	3-29	Audio Mixing	3-53
Embedded Audio Group 3/4	3-35	Tone Generator	3-58
AES Audio Out Pairs 1-4	3-37	Licensable Features	3-58
AES Audio Out Pairs 5-8	3-42	Presets	3-59
Dolby Metadata <b>(9083 only)</b>	3-43		



**Table 3-2 9083 Function Submenu List**

## Audio Input Controls

Controls the AES Audio Input features for the eight AES pairs, and displays signal status for the AES pairs and the 16 embedded audio channels. Also provides global unity routing/parameter control resets.

**Note:** Also refer to AES Audio Input Advanced Features (p. 1-15) in Chapter 1, "Introduction" for detailed information regarding these functions.

### • AES SRC

Individual SRC **Disable** control for each AES pair (1 thru 8) disables or enables Sample Rate Conversion (SRC) bypass as follows:

- **Disabled On:** In this mode, AES SRC for the corresponding AES pair is **bypassed** (button pressed in). SRC is set to **Disabled** (bypass turned on) by default. This mode is preferred where the AES rate matches the input video rate. This mode is necessary when embedding non-PCM AES audio such a Dolby® E or Dolby Digital™ audio streams.

**Note:** In this mode AES rate must match the input video rate or audio dropouts will occur.

**Note:** AES audio must be nominally 48 kHz.

- **Disable Off:** In this mode, AES SRC for the corresponding AES input pair is **enabled** (button in out position). SRC enabled allows the 9083 to interface with asynchronous AES sources (sources in which the AES timing does not match the video reference timing). SRC can be used to compensate for minor clock rate differences in the AES stream and the input video stream.





### • AES Passthrough

Individual AES Passthrough **On/Off** control for each AES pair (1 thru 8) disables or enables Passthrough as follows:

- **Off:** Disables AES passthrough for the selected AES input pair. Passthrough is set to **Off** by default.
- **On:** Passthrough is turned on, with the corresponding AES output pair to act as a bit-for-bit copy with zero delay of the corresponding AES input pair.

**Note:** AES Passthrough set to **On** overrides normal audio routing. Gain and polarity control is not available when AES passthrough is enabled.

Table 3-2 9083 Function Submenu List — continued

Audio Input Controls	(continued)
<p>• <b>AES Zero Delay Embedding</b></p>  <p>Card Edge Control Menu:</p> 	<p>Individual AES Zero-Delay Embedding <b>On/Off</b> control for each AES pair (1 thru 8) disables or enables Zero-Delay Embedding as follows:</p> <ul style="list-style-type: none"> <li>• <b>Off:</b> Disables Zero-Delay Embedding for the selected AES input pair. Zero-delay embedding is set to <b>Off</b> by default.</li> <li>• <b>On:</b> The selected pair directly embeds into its corresponding group (AES Pair 1 embeds into embedded channels 1 and 2; AES pair 2 embeds into embedded channels 3 and 4, and so on) with the normal frame sync audio delay being bypassed.</li> </ul> <p><b>Note:</b> Zero Delay Embedding overrides the standard audio routing system. For example, if AES Pair 1 is selected, then the controls to route into embedded channels 1 and 2 will not apply. Gain and polarity control is not available when zero-delay embedding is enabled.</p>
<p>• <b>Status Displays</b></p>  	<p>Individual signal status displays for AES pairs 1-8, and embedded audio channels 1-16 as follows:</p> <ul style="list-style-type: none"> <li>• <b>Not Present:</b> Indicates AES pair or embedded channel does not contain recognized audio PCM data.</li> </ul> <p><b>Note:</b> Channel displaying Not Present may still carry usable audio data with <b>Not Present</b> being displayed due to invalid headers.</p> <ul style="list-style-type: none"> <li>• <b>Present, Professional:</b> Indicates AES pair or embedded channel contains recognized AES audio PCM data.</li> <li>• <b>Present, Consumer:</b> Indicates AES pair or embedded channel contains audio PCM data other than AES (for example, S/PDIF).</li> <li>• <b>Present, Dolby E:</b> Indicates AES pair or embedded channel contains Dolby® E encoded data.</li> <li>• <b>Present, Dolby Digital:</b> Indicates AES pair or embedded channel contains Dolby® Digital encoded data.</li> </ul> <p><b>Note:</b> Dolby status displays shown to the left only occur for valid Dolby® signals meeting SMPTE 337M standard.</p> <p><b>(9083 only)</b> The 9083 card does not perform Dolby® processing on the signal. Although the 9083 controls will appear to be usable for this signal tag, the signal is passed through with SRC bypassed as well as all gain and polarity controls set to unity.</p> <p><b>(9083-DEC only)</b> When Dolby® E or Dolby® Digital™ is present on a discrete AES pair or an embedded audio pair, the decoder can provide up to 10 decoded channels (according to the Dolby® sub-format and received metadata). All channels are available as inputs to audio routing.</p>

**Table 3-2 9083 Function Submenu List — continued**








	(continued)
<p>• <b>Embedded Unity Channel Selection</b></p> 	<p>Selects unity reset of Embedded Audio Group 1/2 and 3/4 controls and re-establishes default 1-to-1 routing as follows:</p> <ul style="list-style-type: none"> <li>• <b>Embedded:</b> Routes Embedded Ch 1 thru Ch 16 as sources to destination channels Embedded Ch 1 thru Embedded Ch 16.</li> <li>• <b>AES:</b> Routes AES Ch 1 thru Ch 16 as sources to destination channels Embedded Ch 1 thru Embedded Ch 16.</li> <li>• <b>Analog:</b> Routes Analog Ch 1 thru Ch 8 as sources to destination channels Embedded Ch 1 thru Embedded Ch 8. Sets Embedded Ch 9 thru Ch 16 to Silence.</li> </ul>
<p>• <b>AES Unity Channel Selection</b></p> 	<p>Selects unity reset of AES Outputs Pairs 1-4 and 5-8 controls and re-establishes default 1-to-1 routing as follows:</p> <ul style="list-style-type: none"> <li>• <b>Embedded:</b> Routes Embedded Ch 1 thru Ch 16 as sources to destination channels AES Ch 1 thru AES Ch 16.</li> <li>• <b>AES:</b> Routes AES Ch 1 thru Ch 16 as sources to destination channels AES Ch 1 thru AES Ch 16.</li> <li>• <b>Analog:</b> Routes Analog Ch 1 thru Ch 8 as sources to destination channels AES Ch 1 thru AES Ch 8. Sets AES Ch 9 thru Ch 16 to Silence.</li> </ul>
<p>• <b>Apply Audio Channel Selection</b></p> 	<p>Applies embedded and AES unity channel selection (as set in the above drop-down lists). To apply the selections, click the <b>Confirm</b> button. When Confirm is clicked, a <b>Confirm?</b> pop-up appears, requesting confirmation.</p> <ul style="list-style-type: none"> <li>• Click <b>Yes</b> to proceed with the unity reset.</li> <li>• Click <b>No</b> to reject unity reset.</li> </ul> <p>For any selection following confirm, the destination channel controls are default reset as follows:</p> <ul style="list-style-type: none"> <li>• Gain is to unity</li> <li>• Phase control is set to Normal</li> <li>• Channel is set to Unmuted</li> </ul>
<p>• <b>Tie AES and Embedded Controls</b></p> 	<p>When set to Enabled, gangs <b>Gain</b>, <b>Phase</b>, and <b>Mute</b> controls for same-numbered Embedded and AES channels. Ganging is bilateral, with embedded channel control settings affecting corresponding AES channel controls, and vice-versa.</p>
<p>• <b>HANC Timecode Controls</b></p> 	<p>Where ATC_LTC or ATC_VITC timecode data is present on input video HANC space (which can be affected by audio processing), allows extracting and preserving HANC timecode data, with re-direction of the timecode data safely to the VANC space.</p>
<p>• <b>HANC Timecode Preservation Selection</b></p> 	<p>Using the drop-down list, selects the action to take in presence or absence of HANC ATC_VITC and/or ATC_LTC timecode data.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• For 525i2994 SD_ATC, field 1 and field 2 timecode data is redirected to VANC lines 12 and 275. For 625i50 SD_ATC, field 1 and field 2 timecode data is redirected to VANC lines 8 and 321.</li> <li>• The card does not check for conflicts on a given line number. Make certain the selected line is available and carrying no other data. See Ancillary Data Line Number Locations and Ranges (p. 3-15) for more information.</li> </ul>

Table 3-2 9083 Function Submenu List — continued

<div>Video Proc</div>	Provides the following Video Proc parametric controls.
<div><div><div>Video Proc</div><div>On</div></div><div><div>Card Edge Control Menu:</div><div>Vid</div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>Proc</div><div>Enbl</div><div>On Off</div></div><div>Video Proc On Video Proc Off</div></div></div></div>	<div>Video Proc (On/Off) provides master on/off control of all Video Proc functions.</div> <div><div>When set to <b>Off</b>, all processing is bypassed.</div><div>When set to <b>On</b>, currently displayed parameter settings take effect.</div></div>
<div><div><div>Reset to Unity</div><div>Confirm</div></div><div><div>Card Edge Control Menu:</div><div>Vid</div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>Proc</div><div>Unly</div><div>Y?</div></div><div>Move toggle switch in either direction to confirm unity reset. Reject reset by pressing Exit Menu pushbutton.</div></div></div></div>	<div>Reset to Unity provides unity reset control of all Video Proc functions.</div> <div>When Confirm is clicked, a <b>Confirm?</b> pop-up appears, requesting confirmation.</div> <div><div>Click <b>Yes</b> to proceed with the unity reset.</div><div>Click <b>No</b> to reject unity reset.</div></div>
<div><div><div>Luma Gain</div><div>0.0</div></div><div><div>Card Edge Control Menu:</div><div>Vid</div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>Proc</div><div>Gain</div><div>(gain value)</div></div><div>Luma gain in percent</div></div></div></div>	<div>Adjusts gain percentage applied to Luma (Y channel).</div> <div>(0% to 200% range in 0.1% steps; unity = 100%)</div>
<div><div><div>Luma Lift</div><div>-100.0</div></div><div><div>Card Edge Control Menu:</div><div>Vid</div><div><div><div>1</div><div>2</div><div>3</div></div><div><div>Proc</div><div>Lift</div><div>(lift value)</div></div><div>Luma lift in percent</div></div></div></div>	<div>Adjusts lift applied to Luma (Y-channel).</div> <div>(-100% to 100% range in 0.1% steps; null = 0.0%)</div>

**Table 3-2 9083 Function Submenu List — continued**

Video Proc	(continued)
<div><div>• Color Gain</div><div><div>Color Gain</div><div>0.0</div></div><div><div>Card Edge Control Menu:</div><div><div>Vid</div><div><div>1</div><div>2</div><div>3</div></div><div><div>Proc</div><div>Sat</div><div>(sat value)</div></div><div>Color gain in percent</div></div></div></div>	<div>Adjusts gain percentage (saturation) applied to Chroma (C-channel).</div> <div>(0% to 200% range in 0.1% steps; unity = 100%)</div>
<div><div>• Color Phase</div><div><div>Color Phase</div><div>-360.0</div></div><div><div>Card Edge Control Menu:</div><div><div>Vid</div><div><div>1</div><div>2</div><div>3</div></div><div><div>Proc</div><div>Phas</div><div>(phase value)</div></div><div>Color phase angle applied in degrees</div></div></div></div>	<div>Adjusts phase angle applied to Chroma.</div> <div>(-360° to 360° range in 0.1° steps; null = 0°)</div>
<div><div>• Gang Luma and Color Gain</div><div><div>Gang Luma and Color Gain</div><div>On</div></div><div><div>Card Edge Control Menu:</div><div><div>Vid</div><div><div>1</div><div>2</div><div>3</div></div><div><div>Proc</div><div>Gang</div><div>On Off</div></div><div>Ganging On Ganging Off</div></div></div></div>	<div>When set to <b>On</b>, changing either the <b>Luma Gain</b> or <b>Color Gain</b> controls increases or decreases both the Luma and Chroma levels by equal amounts.</div>

Table 3-2 9083 Function Submenu List — continued

<div>AFD</div>	Allows assignment of AFD (Active Format Description) codes to the SDI output video.																																																																
<b>Note:</b> This function only marks the SDI output with an AFD code. Actual AFD processing must be performed by a downstream card or system that recognizes an AFD code assigned here.																																																																	
<div><div><div>Incoming AFD</div><div>16:9 coded frame - 1010 - 16:9 (image protecte</div></div></div>	<div>Displays incoming AFD setting as follows:</div> <ul style="list-style-type: none"><li>• If AFD code is present, one of the 11, four-bit AFD codes is displayed (as shown in the example to the left). Also displayed is the VANC line number of the incoming AFD code.</li><li>• If no AFD setting is present in the video signal, <b>No AFD Present</b> is displayed.</li></ul>																																																																
<div><div><div>Output Mode</div><div>Pass If Present, Else Insert</div><div>Pass If Present, Else Insert</div><div>Pass Incoming Code</div><div>Replace Incoming Code</div></div></div>	<div>Drop-down selection determines action to take in presence or absence of existing AFD code on input video.</div>																																																																
<div><div><div>Output Code</div><div>No AFD</div><div>No AFD</div><div>4:3 - 0000 - Undefined</div><div>4:3 - 0010 - Box 16:9 (top)</div><div>4:3 - 0011 - Box 14:9 (top)</div><div>⋮</div><div>16:9 - 1111 - 16:9 (w/alt 4:3 center)</div></div></div>	<div>Drop-down list assigns desired AFD to output SDI.</div> <div><table><tr><th colspan="4">4:3 Coded Frame</th></tr><tr><th>AFD Code<sup>(1)</sup></th><th>Description</th><th>AFD Code<sup>(1)</sup></th><th>Description</th></tr><tr><td>—</td><td>No code present</td><td>1001</td><td>Full frame</td></tr><tr><td>0000</td><td>Undefined</td><td>1010</td><td>16:9 (center)</td></tr><tr><td>0010</td><td>Box 16:9 (top)</td><td>1011</td><td>14:9 (center)</td></tr><tr><td>0011</td><td>Box 14:9 (top)</td><td>1101</td><td>4:3 (with alternate 14:9 center)</td></tr><tr><td>0100</td><td>Box &gt; 16:9 (center)</td><td>1110</td><td>16:9 (with alternate 14:9 center)<sup>(2)</sup></td></tr><tr><td>1000</td><td>Full frame</td><td>1111</td><td>16:9 (with alternate 4:3 center)<sup>(2)</sup></td></tr></table><table><tr><th colspan="4">16:9 Coded Frame</th></tr><tr><th>AFD Code<sup>(1)</sup></th><th>Description</th><th>AFD Code<sup>(1)</sup></th><th>Description</th></tr><tr><td>—</td><td>No code present</td><td>1001</td><td>4:3 (center)</td></tr><tr><td>0000</td><td>Undefined</td><td>1010</td><td>16:9 (image protected)<sup>(2)</sup></td></tr><tr><td>0010</td><td>Full frame</td><td>1011</td><td>14:9 (center)</td></tr><tr><td>0011</td><td>4:3 (center)</td><td>1101</td><td>4:3 (with alternate 14:9 center)</td></tr><tr><td>0100</td><td>Box &gt; 16:9 (center)</td><td>1110</td><td>16:9 (with alternate 14:9 center)<sup>(2)</sup></td></tr><tr><td>1000</td><td>Full frame</td><td>1111</td><td>16:9 (with alternate 4:3 center)<sup>(2)</sup></td></tr></table></div> <div><div>1: AFD codes numbering and definitions conform to SMPTE 2016-1-2007.</div><div>2: Image Protected implies picture content that must not be cropped by conversion processes or display devices. Alternate center formats may have protected center areas, with areas outside of the protected area not containing mandatory content.</div></div>	4:3 Coded Frame				AFD Code <sup>(1)</sup>	Description	AFD Code <sup>(1)</sup>	Description	—	No code present	1001	Full frame	0000	Undefined	1010	16:9 (center)	0010	Box 16:9 (top)	1011	14:9 (center)	0011	Box 14:9 (top)	1101	4:3 (with alternate 14:9 center)	0100	Box > 16:9 (center)	1110	16:9 (with alternate 14:9 center) <sup>(2)</sup>	1000	Full frame	1111	16:9 (with alternate 4:3 center) <sup>(2)</sup>	16:9 Coded Frame				AFD Code <sup>(1)</sup>	Description	AFD Code <sup>(1)</sup>	Description	—	No code present	1001	4:3 (center)	0000	Undefined	1010	16:9 (image protected) <sup>(2)</sup>	0010	Full frame	1011	14:9 (center)	0011	4:3 (center)	1101	4:3 (with alternate 14:9 center)	0100	Box > 16:9 (center)	1110	16:9 (with alternate 14:9 center) <sup>(2)</sup>	1000	Full frame	1111	16:9 (with alternate 4:3 center) <sup>(2)</sup>
4:3 Coded Frame																																																																	
AFD Code <sup>(1)</sup>	Description	AFD Code <sup>(1)</sup>	Description																																																														
—	No code present	1001	Full frame																																																														
0000	Undefined	1010	16:9 (center)																																																														
0010	Box 16:9 (top)	1011	14:9 (center)																																																														
0011	Box 14:9 (top)	1101	4:3 (with alternate 14:9 center)																																																														
0100	Box > 16:9 (center)	1110	16:9 (with alternate 14:9 center) <sup>(2)</sup>																																																														
1000	Full frame	1111	16:9 (with alternate 4:3 center) <sup>(2)</sup>																																																														
16:9 Coded Frame																																																																	
AFD Code <sup>(1)</sup>	Description	AFD Code <sup>(1)</sup>	Description																																																														
—	No code present	1001	4:3 (center)																																																														
0000	Undefined	1010	16:9 (image protected) <sup>(2)</sup>																																																														
0010	Full frame	1011	14:9 (center)																																																														
0011	4:3 (center)	1101	4:3 (with alternate 14:9 center)																																																														
0100	Box > 16:9 (center)	1110	16:9 (with alternate 14:9 center) <sup>(2)</sup>																																																														
1000	Full frame	1111	16:9 (with alternate 4:3 center) <sup>(2)</sup>																																																														
<div><div><div>Output Line</div><div>9</div></div></div>	<div>Allows selecting the line location of the AFD data within the video signal Ancillary Data space. (Range is 9 thru 41.)</div> <div><b>Note:</b> • Although the output line drop-down will allow any choice within the 9 thru 41 range, the actual range is automatically clamped (limited) to certain ranges to prevent inadvertent conflict with active picture area depending on video format. See Ancillary Data Line Number Locations and Ranges (p. 3-15) for more information.</div> <ul style="list-style-type: none"><li>• The card does not check for conflicts on a given line number. Make certain the selected line is available and carrying no other data.</li></ul>																																																																

**Table 3-2 9083 Function Submenu List — continued**













	<p>Provides video Frame Sync offset and audio re-sync tools.</p>
<p>• <b>Framesync Enable</b></p>  	<p>Disables the Frame Sync function, or selects from choices below.</p> <ul style="list-style-type: none"> <li>• <b>Off:</b> Disables Frame Sync function; output video timing matches the input video timing.</li> <li>• <b>Reference 1:</b> Allows Frame Sync function to use external Reference 1 as the reference standard.</li> <li>• <b>Reference 2:</b> Allows Frame Sync function to use external Reference 2 as the reference standard.</li> </ul> <p><b>Note:</b> If Reference 1 or Reference 2 is selected and an appropriate external reference is not received, the  <b>Reference Invalid</b> indication appears in the Card Info status portion of DashBoard™, indicating invalid frame sync reference error. (Additionally, the card edge ERR indicator illuminates indicating the same.) External reference signals Reference 1 and Reference 2 are distributed to the 9083 and other cards via a frame bus.</p> <ul style="list-style-type: none"> <li>• <b>Input Video:</b> Uses the input video signal as the reference standard.</li> </ul> <p><b>Note:</b> If <b>Input Video</b> is used for framesync, any timing instability on the input video will result in corresponding instability on the output video.</p>
<p>• <b>Vertical Delay Control</b></p>  	<p>When Framesync is enabled, sets vertical delay (in number of lines of <b>output video/format</b>) between the output video and the frame sync reference.</p> <p>(Range is -1124 thru 1124 lines.)</p> <p><b>Note:</b> Lines refer to lines in the output video format, and not to the reference format.</p>
<p>• <b>Horizontal Delay Control</b></p>  	<p>When Framesync is enabled, sets (in usec of <b>output video timing</b>) horizontal delay between the output video and the frame sync reference.</p> <p>(Range is -64.000 thru 64.000 usec)</p> <p><b>Note:</b> When an external framesync reference is used, the card will not produce a framesync reset until the variance between framesync reference and output video exceeds <math>\pm 2</math> clock periods. Therefore, a framesync reset will not result if offsets within this window are applied.</p> <p>To apply an offset/framesync reset within this window, first apply a relatively large offset, then apply the target smaller offset.</p> <p><b>Example:</b> To apply a 1-period offset, first apply a 10-period positive offset and then apply a 9-period negative offset. This results in the target 1-period offset being applied to the output video.</p>

Table 3-2 9083 Function Submenu List — continued

Framesync	(continued)
<p>• <b>Minimum Latency Control</b></p>  <p>Minimum Latency (Frames) slider set to 0.</p> <p>Card Edge Control Menu:</p> <p>FS</p> <p>1 2</p> <p>LATF (value) Min. Latency (in frames)</p>	<p>When Framesync is enabled, specifies the smallest amount of latency allowed by the frame sync (latency measurement in output video frames). The frame sync will not output a frame unless the specified number of frames are captured in the buffer. <b>The operational latency of the frame sync is always between the specified minimum latency and minimum latency plus one frame (not one field).</b> (Maximum range is 0 to 13; default = 1.)</p> <p><b>Note:</b> Due to card memory limits, the maximum available Minimum Latency Frames is related to the output video format. For example, with a 1080i59.94 output, the maximum allowed setting is 5. For a 1080i film (23.98) output, the maximum allowed setting is 3. Conversely, greater maximum settings are allowed for SD formats such as 525i59.94, where the practical maximum limit is 13.</p> <p>When using this control, be sure to check the <b>Framesync Status</b> display as follows:</p> <p>Framesync Status On</p> <ul style="list-style-type: none"> <li>• Latency frames selection within limits.</li> </ul> <p>Framesync Status Minimum Latency Frames set to 3 the maximum amount for this standard</p> <ul style="list-style-type: none"> <li>• Latency frames selection exceeds limits.</li> </ul>
<p>• <b>Audio Hard Resync Threshold Control</b></p>  <p>Audio Hard Resync Threshold (Frames) slider set to 1.5.</p> <p>With offset <b>less than</b> selected hard resync threshold, resync is progressively applied in many small steps to provide a seamless, glitch-free retiming. After the successive steps, the audio is synchronized with the video (in this example, 40 msec). (Progressive correction is applied at 1 msec/sec appr. rate.)</p>  <p>Video: 40 msec</p> <p>Audio: 240 msec</p> <p>In this example, initial offset of 200 msec (appr. 6 frames) is <b>below</b> 9 frame threshold and results in soft resync being progressively applied.</p> <hr/> <p>With offset <b>greater than</b> selected hard resync threshold, resync is immediately applied.</p>  <p>Video: 40 msec</p> <p>Audio: 440 msec</p> <p>In this example, initial offset of 400 msec (appr. 12 frames) is <b>above</b> 9 frame threshold and results in immediate hard resync.</p>	



**Table 3-2 9083 Function Submenu List — continued**

<div>Framesync</div>	(continued)
<div><div>• Audio Offset Control</div><div><div>Audio Offset from Video (ms)</div><div>-575.0</div></div><div><div>Card Edge Control Menu:</div><div>FS</div><div><div>1</div><div>2</div><div>3</div></div><div><div>ADLY</div><div>ADJ</div><div>(value) Delay value</div></div></div></div>	<p>When Framesync is enabled, adds or reduces (offsets) audio delay from the matching video delay (audio delay offset setting adds or removes delay in addition to any delay included by other actions). This control is useful for correcting lip sync problems when video and audio paths in the chain experience differing overall delays.</p> <p>(-575.0 msec to 575.0 msec range; null = 0.0 msec)</p> <p><b>Note:</b> Delay offset values of less than approximately 1 frame are progressively applied by the card to provide a seamless, glitch-free retiming. However, delay offset values exceeding 1-1/2 frames may result in a slight audio discontinuity at the moment when the offset is applied using this control if the <b>Audio Hard Resync Threshold</b> control is not at a setting greater than the delay offset.</p> <p>To prevent this condition during an on-air manipulation, it is recommended that the <b>Audio Hard Resync Threshold</b> control be set high enough such that expected delay offsets exceeding 1-1/2 frames are progressively applied.</p> <p><b>Note:</b> If using Audio Offset control to perform off-air corrections, it is recommended to temporarily set the <b>Audio Hard Resync Threshold</b> control to its <b>minimum</b> setting, thereby allowing the offset to be assessed and corrected as fast as possible.</p>
<div><div>• Current Audio Delay Display</div><div><div>Current Audio Delay</div><div>2.02 ms / 0 Frames 31 lines</div></div><div><div>Card Edge Control Menu:</div><div>FS</div><div><div>1</div><div>2</div><div>3</div></div><div><div>ADLY</div><div>DVAL</div><div>(value) Delay value (in msec)</div></div><div><div>Note:</div><div>Value shown in column 3 is displayed value only. No control is available in this mode.</div></div></div></div>	<p>Displays the current input-to-output audio delay (in msec units) as well as in terms of Frames/fractional frame (in number of lines).</p>
<div><div>• Video Delay Display</div><div><div>Video Delay</div><div>0.06 ms / 0 Frames 1 lines</div></div><div><div>Card Edge Control Menu:</div><div>FS</div><div><div>1</div><div>2</div></div><div><div>VDLY</div><div>(value) Delay value (in msec)</div></div><div><div>Note:</div><div>Value shown in column 2 is displayed value only. No control is available in this mode.</div></div></div></div>	<p>Displays the current input-to-output video delay (in msec units) as well as in terms of Frames/fractional frame (in number of lines).</p>

Table 3-2 9083 Function Submenu List — continued

Framesync	(continued)
<div><div>• Framesync Status Display</div><div><div>Framesync Status</div><div>On</div></div></div>	<div>Displays the current framesync status as follows:</div> <div><div><div>Framesync Status</div><div>On</div></div><div>• Framesync status OK.</div></div> <div><div><div>Framesync Status</div><div>Off</div></div><div>• Framesync source off or not connected.</div></div> <div><div><div>Framesync Status</div><div>Off no valid reference detected</div></div><div>• Improper or missing framesync reference.</div></div> <div><div><div>Framesync Status</div><div>Minimum Latency Frames set to 3 the maximum amount for this standard</div></div><div>• Latency frames selection exceeds limits.</div></div> <div>Note: See <b>Minimum Latency Frames Control</b> above for more information about this message.</div>
<div><div>• Loss of Input Signal Selection</div><div><div>On Loss of Input Signal:</div><div><div>Disable Outputs</div><div>Disable Outputs</div><div>Freeze Last Frame</div><div>Freeze to Color</div></div></div><div><div>Card Edge Control Menu:</div><div><div>FS</div><div><div>1</div><div>2</div></div><div><div>LOS</div><div>DISO</div><div>FRFR</div><div>FRCL</div></div><div><div></div><div>Disable outputs</div><div>Freeze to last frame</div><div>Freeze to selected color</div></div></div></div></div>	<div>In the event of input video Loss of Signal (LOS), determines action to be taken as follows:</div> <div><div>• <b>Disable Outputs:</b> Disable all outputs.</div><div>• <b>Freeze Last Frame:</b> Freeze image to last good frame (last frame having valid SAV and EAV codes).</div><div>• <b>Freeze to Color:</b> Freeze image to a color raster (as selected using Framesync LOS Freeze Color control).</div></div>

**Table 3-2 9083 Function Submenu List — continued**








<div data-bbox="274 260 623 325">Framesync</div>	(continued)																												
<p>• <b>Framesync LOS Freeze Color</b></p>  <div data-bbox="269 804 592 1173"> <p>Card Edge Control Menu:</p> <p>FS</p> <table border="1"> <thead> <tr> <th>1</th><th>2</th></tr> </thead> <tbody> <tr> <td>LOSC</td><td></td></tr> <tr> <td></td><td>WHT White</td></tr> <tr> <td></td><td>YELO Yellow</td></tr> <tr> <td></td><td>CYAN Cyan</td></tr> <tr> <td></td><td>GRN Green</td></tr> <tr> <td></td><td>MAGE Magenta</td></tr> <tr> <td></td><td>RED Red</td></tr> <tr> <td></td><td>BLUE Blue</td></tr> <tr> <td></td><td>GR10 Gray 10%</td></tr> <tr> <td></td><td>GR25 Gray 25%</td></tr> <tr> <td></td><td>GR50 Gray 50%</td></tr> <tr> <td></td><td>BLK Black</td></tr> <tr> <td></td><td>CSTM Custom</td></tr> </tbody> </table> </div>	1	2	LOSC			WHT White		YELO Yellow		CYAN Cyan		GRN Green		MAGE Magenta		RED Red		BLUE Blue		GR10 Gray 10%		GR25 Gray 25%		GR50 Gray 50%		BLK Black		CSTM Custom	<p>In the event of LOS with <b>Freeze to Color</b> enabled above, sets the image raster color from choices shown to the left.</p>
1	2																												
LOSC																													
	WHT White																												
	YELO Yellow																												
	CYAN Cyan																												
	GRN Green																												
	MAGE Magenta																												
	RED Red																												
	BLUE Blue																												
	GR10 Gray 10%																												
	GR25 Gray 25%																												
	GR50 Gray 50%																												
	BLK Black																												
	CSTM Custom																												
<p>• <b>Custom Color Hue</b></p>  <div data-bbox="272 1367 680 1551"> <p>Card Edge Control Menu:</p> <p>FS</p> <table border="1"> <thead> <tr> <th>1</th><th>2</th></tr> </thead> <tbody> <tr> <td>CHUE</td><td></td></tr> <tr> <td></td><td>(hue value) Custom freeze color hue (in degrees)</td></tr> </tbody> </table> </div>	1	2	CHUE			(hue value) Custom freeze color hue (in degrees)	<p>Adjusts raster hue (phase angle) for custom LOS color.</p> <p>(-360° to 360° range in 0.1° steps; null = 0°)</p>																						
1	2																												
CHUE																													
	(hue value) Custom freeze color hue (in degrees)																												

Table 3-2 9083 Function Submenu List — continued

	(continued)				
<p>• <b>Custom Color Saturation</b></p>  <p>Custom Color Saturation 0.0</p> <div data-bbox="245 554 646 730"> <p>Card Edge Control Menu:</p> <p>FS</p> <table border="1"> <tr> <td>1</td><td>2</td></tr> <tr> <td>CSAT</td><td>(sat value)</td></tr> </table> <p>Color saturation level (in percent)</p> </div>	1	2	CSAT	(sat value)	<p>Adjusts raster saturation level for custom LOS color.</p> <p>(0% to 100% range in 0.1% steps)</p>
1	2				
CSAT	(sat value)				
<p>• <b>Custom Color Y Level</b></p>  <p>Custom Color Y Level 64</p> <div data-bbox="245 926 656 1102"> <p>Card Edge Control Menu:</p> <p>FS</p> <table border="1"> <tr> <td>1</td><td>2</td></tr> <tr> <td>CVAL</td><td>(gain value)</td></tr> </table> <p>Luma level</p> </div>	1	2	CVAL	(gain value)	<p>Adjusts raster luma level for custom LOS color.</p> <p>(64 to 940 range)</p>
1	2				
CVAL	(gain value)				
<p>• <b>Resync Video and Reference</b></p>  <p>Resync Video and Reference Confirm</p> <div data-bbox="237 1262 657 1451"> <p>Card Edge Control Menu:</p> <p>FS</p> <table border="1"> <tr> <td>1</td><td>2</td></tr> <tr> <td>RSYN</td><td>Y?</td></tr> </table> <p>Move toggle switch left (or up) to confirm reset. Reject resync by pressing Exit Menu pushbutton.</p> </div>	1	2	RSYN	Y?	<p>Resyncs video with external reference.</p> <p>When Confirm is clicked, a <b>Confirm?</b> pop-up appears, requesting confirmation.</p> <ul style="list-style-type: none"> <li>Click <b>Yes</b> to resync.</li> <li>Click <b>No</b> to reject resync.</li> </ul>
1	2				
RSYN	Y?				
<p>• <b>Reset Framesync</b></p>  <p>Reset Framesync Confirm</p> <div data-bbox="237 1633 657 1822"> <p>Card Edge Control Menu:</p> <p>FS</p> <table border="1"> <tr> <td>1</td><td>2</td></tr> <tr> <td>RSET</td><td>Y?</td></tr> </table> <p>Move toggle switch left (or up) to confirm reset. Reject reset by pressing Exit Menu pushbutton.</p> </div>	1	2	RSET	Y?	<p>Resets the frame sync, clearing any buffered audio and video.</p> <p>When Confirm is clicked, a <b>Confirm?</b> pop-up appears, requesting confirmation.</p> <ul style="list-style-type: none"> <li>Click <b>Yes</b> to reset the frame sync.</li> <li>Click <b>No</b> to reject reset.</li> </ul>
1	2				
RSET	Y?				

**Table 3-2 9083 Function Submenu List — continued**

Embedded Audio Group 1/2	Selects the audio source for each embedded audio channel 1 thru 8 (Embedded Audio Groups 1 and 2). Also provides Gain, Phase Invert, and Muting controls for each channel.
	<p>The example above shows various Source selections and individual audio control settings for various audio sources fed to the Destination channels <b>Embedded Ch 1</b> thru <b>Embedded Ch 8</b> in Embedded Audio Groups 1 and 2, with the resulting setup (right).</p> <p>The source-to-destination correlation shown here is only an example; <b>any</b> of the sources on the left can connect to <b>any</b> of the destinations on the right, or to Embedded Audio Groups 3 and 4 (not shown here). Additional sources not shown here are also available. These are described on the following pages.</p> <p>The controls shown here are described in detail on the following pages.</p>

Table 3-2 9083 Function Submenu List — continued

Embedded Audio Group 1/2		(continued)
<div><div>• SD Audio Depth</div><div><div>SD Audio Depth</div><div>20 bit</div></div><div><div>SD Audio Depth</div><div>24 bit</div></div></div>	<p>Allows option of using 24-bit audio data structure per SMPTE 272M, §3.10 (default is 20-bit per SMPTE 272M, §3.5).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"><li>• If 24-bit depth is desired, make certain downstream equipment is compatible with 24-bit SD audio data.</li><li>• Depth control setting applied here affects both Embedded Audio Group 1/2 and 3/4.</li></ul>	
<div><div>• Group Enable</div><div><div>Group Enable</div><div>On</div></div><div><div>Card Edge Control Menu:</div><div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>Embd</div><div>Grp1</div><div>Enbl</div><div>On Off</div></div><div><div>Group 1 select (range is group 1 thru group 4)</div><div>On (enabled) Off (disabled)</div></div></div></div></div>	<p>When enabled (<b>On</b>), enables the embedding of the corresponding embedded audio group (Embedded Audio Group 1 or Embedded Audio Group 2).</p> <ul style="list-style-type: none"><li>• Embedded Audio Group 1 consists of embedded channels 1 thru 4.</li><li>• Embedded Audio Group 2 consists of embedded channels 5 thru 8.</li></ul> <p>Two Group Enable buttons correspondingly enable or disable Embedded Audio Group 1 and Embedded Audio Group 2.</p> <p>Disabling a group removes the entire group of embedded audio channels while preserving the settings of the channels belonging to the group.</p>	
<p><b>Note:</b></p> <ul style="list-style-type: none"><li>• <b>Embedded Ch 2</b> thru <b>Embedded Ch 8</b> have controls identical to the <b>Source</b>, <b>Gain</b>, <b>Mute</b>, and <b>Phase</b> controls described here for <b>Embedded Ch 1</b>. Therefore, only the <b>Embedded Ch 1</b> controls are shown here.</li><li>• For each channel, its source and destination should be considered and appropriately set. Unused destination channels should be set to the <b>Silence</b> selection.</li></ul>		
<div><div>• Embedded Channel Source</div><div><div>Destination</div><div>Embedded Ch 1</div></div><div><div>Source</div><div>Embed Ch 1</div></div><div><div>Card Edge Control Menu:</div><div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>Embd</div><div>Grp</div><div>Ch(n)</div><div>Src</div></div><div><div>Destination channel number</div><div>Set up to select Source</div></div></div></div></div>	<p>Using the <b>Source</b> drop-down list, selects the audio input source to be embedded in the corresponding embedded channel from the choices described below.</p>	

Table 3-2 9083 Function Submenu List — continued







<div>Embedded Audio Group 1/2</div>	(continued)
<p>• <b>Embedded Ch 1 thru Ch 16 as Source</b></p>  <p>Card Edge Control Menu:</p> 	<p><b>Embed Ch 1</b> thru <b>Embed Ch 16</b> range in Source drop-down list enables an embedded channel (Ch 1 thru Ch 16) to be the source for the selected destination Embedded Audio Group channel.</p> <p>(In this example, Embed Ch 1 (embedded Ch 1) is the source for destination Embedded Ch 1)</p>
<p>• <b>AES Ch 1 thru AES Ch 16 as Source</b></p>  <p>Card Edge Control Menu:</p> 	<p><b>AES Ch 1</b> thru <b>AES Ch 16</b> range in Source drop-down list enables a discrete AES channel (Ch 1 thru Ch 16) to be the source for the selected destination Embedded Audio Group channel.</p> <p>(In this example, AES Ch 1 is the source for destination Embedded Ch 1)</p>
<p>• <b>Analog Ch 1 thru Ch 8 as Source</b></p>  <p>Card Edge Control Menu:</p> 	<p><b>Analog Ch 1</b> thru <b>Analog Ch 8</b> range in Source drop-down list enables a balanced-input analog channel (Ch 1 thru Ch 8) to be the source for the selected destination Embedded Audio Group channel.</p> <p>(In this example, Analog Ch1 is the source for destination Embedded Ch 1)</p>

Table 3-2 9083 Function Submenu List — continued







<div>Embedded Audio Group 1/2</div>	(continued)
<p>• <b>Down Mix Left or Right as Source</b></p>  <p>Card Edge Control Menu:</p> 	<p><b>Down Mix Left</b> and <b>Down Mix Right</b> selections in Source drop-down list allow either downmixer left or right channel to be the source for the selected destination Embedded Audio Group channel.</p> <p>(In this example, the Down Mix Left channel is the source for destination Embedded Ch 1)</p> <p><b>Note:</b> Down Mix Left and Down Mix Right channels are a stereo pair derived from the L, C, R, Ls, and Rs channel inputs selected using the Audio Mixing function. The stereo pair consists of basic L/R PCM signals with no additional encoded information.</p> <p>Refer to <b>Audio Mixing</b> function description on page 3-53 for more information.</p>
<p>• <b>Mono Mix as Source</b></p>  <p>Card Edge Control Menu:</p> 	<p><b>Mono</b> selection in Source drop-down list allows mono mix content to be the source for the selected destination Embedded Audio Group channel.</p> <p>(In this example, the mono content is the source for destination Embedded Ch 1)</p> <p><b>Note:</b> Mono mix content is set up using Mono Mixer Selection in the <b>Audio Mixing</b> function). Refer to <b>Audio Mixing</b> function description on page 3-53 for more information.</p>
<p>• <b>Dolby® Decoded Channel as Source</b></p>  <p>Card Edge Control Menu:</p> 	<p><b>(9083-DEC only) Dolby Ch 1</b> thru <b>Dolby Ch 8</b> range in Source drop-down list enables a Dolby® decoded channel to be the source for the selected destination Embedded Audio Group channel.</p> <p>(In this example, Dolby® decoded Ch 1 is the source for destination Embedded Ch 1)</p> <p><b>Note:</b> Drop-down choices of Ch 1 thru Ch 8 and Mix 1/Mix 2 represent maximum channels available. Actual active channel complement is per received Dolby® format and upstream encoding. Inactive channels should not be used.</p> <p>Refer to <b>Dolby Metadata</b> function description on page 3-43 for more information.</p> <p>Refer to Dolby® E Processing and Routing Example on page 3-64 for an example of using Dolby® decoding.</p>



Table 3-2 9083 Function Submenu List — continued




<div>Embedded Audio Group 1/2</div>	(continued)
<p>• <b>Tone Generator 1 thru 4 as Source</b></p> 	<p><b>Tone Generator 1 thru Tone Generator 4</b> range in Source drop-down list enables one of four tone generators (Tone 1 thru Tone 4) to be the source for the selected destination Embedded Audio Group channel.</p> <p>(In this example, Tone 1 (tone generator 1) is the source for destination Embedded Ch 1)</p> <p><b>Note:</b> Tone generator frequencies can be independently set for the four tone generator sources.</p> <p>Refer to <b>Tone Generator</b> function description on page 3-58 for more information.</p>
<p>• <b>Silence (Mute) as Source</b></p> 	<p><b>Silence</b> selection in Source drop-down list mutes the selected destination Embedded Audio Group channel. <b>Use this setting for unused destination channels.</b></p> <p>(In this example, silence (muting) is applied to Embedded Ch 1)</p>
<p>• <b>Gain (dB) Control</b></p> 	<p>Adjusts and displays relative gain (in dB) applied to the corresponding destination Embedded Audio Group channel.</p> <p>(-80 to +40 dB range in 0.1 dB steps; unity = 0.0 dB)</p>

Table 3-2 9083 Function Submenu List — continued

Embedded Audio Group 1/2	(continued)
<div><div><div><div>• Mute Control</div><div><div>Channel is</div><div>Unmuted</div></div><div><div>Channel is</div><div>Muted</div></div></div><div><div>Card Edge Control Menu:</div><div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>Embd</div><div>Grp</div><div>Ch(n)</div><div>Mute Off On</div><div>Unmuted Muted</div></div></div></div></div></div>	<div>Allows pushbutton On/Off channel muting while saving all other settings.</div>
<div><div><div><div>• Phase Control</div><div><div>Phase</div><div><div>Normal</div><div>Invert</div><div>Normal</div></div></div></div><div><div>Card Edge Control Menu:</div><div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>Embd</div><div>Grp</div><div>Ch(n)</div><div>Pol Norm Inv</div><div>non-invert invert</div></div></div></div></div></div>	<div>Selects between <b>Normal</b> and <b>Invert</b> phase (relative to source original phase) for the destination Embedded Audio Group channel.</div>

**Table 3-2 9083 Function Submenu List — continued**

<h2>Embedded Audio Group 3/4</h2>	<p>Selects the audio source for each embedded audio channel 9 thru 16 (Embedded Audio Groups 3 and 4). Also provides Gain, Phase Invert, and Muting controls for each channel.</p>

The example above shows various Source selections and individual audio control settings for various audio sources fed to the Destination channels **Embedded Ch 9** thru **Embedded Ch 16** in Embedded Audio Groups 3 and 4, with the resulting setup (right).

The source-to-destination correlation shown here is only an example; **any** of the sources on the left can connect to **any** of the destinations on the right, or to Embedded Audio Groups 1 and 2 (not shown here). Additional sources not shown here are also available.

Table 3-2 9083 Function Submenu List — continued

Embedded Audio Group 3/4		(continued)
<div><div>• SD Audio Depth</div><div><div>SD Audio Depth</div><div>20 bit</div></div><div><div>SD Audio Depth</div><div>24 bit</div></div></div>	<p>Allows option of using 24-bit audio data structure per SMPTE 272M, §3.10 (default is 20-bit per SMPTE 272M, §3.5).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"><li>• If 24-bit depth is desired, make certain downstream equipment is compatible with 24-bit SD audio data.</li><li>• Depth control setting applied here affects both Embedded Audio Group 1/2 and 3/4.</li></ul>	
<div><div>• Group Enable</div><div><div>Group Enable</div><div>On</div></div><div><div>Card Edge Control Menu:</div><div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>Embd</div><div>Grp3</div><div>Enbl</div><div>On Off</div></div><div><div>Group 1 select (range is group 1 thru group 4)</div><div>On (enabled) Off (disabled)</div></div></div></div></div>	<p>When enabled (<b>On</b>), enables the embedding of the corresponding embedded audio group (Embedded Audio Group 3 or Embedded Audio Group 4).</p> <ul style="list-style-type: none"><li>• Embedded Audio Group 3 consists of embedded channels 9 thru 12.</li><li>• Embedded Audio Group 4 consists of embedded channels 13 thru 16.</li></ul> <p>Two Group Enable buttons correspondingly enable or disable Embedded Audio Group 3 and Embedded Audio Group 4.</p> <p>Disabling a group removes the entire group of embedded audio channels while preserving the settings of the channels belonging to the group.</p>	
<p><b>Note:</b></p> <ul style="list-style-type: none"><li>• Embedded Ch 9 thru Embedded Ch 16 have controls that are identical to the <b>Source</b>, <b>Gain</b>, <b>Mute</b>, and <b>Phase</b> controls described for Embedded Ch 1. Refer to Embedded Audio Group 1/2 on page 3-29 for descriptions of these controls.</li><li>• For each channel, its source and destination should be considered and appropriately set. Unused destination channels should be set to the <b>Silence</b> selection.</li></ul>		

**Table 3-2 9083 Function Submenu List — continued**






AES Audio Out Pairs 1-4	Routes audio sources to discrete AES output channels 1 thru 8 (AES Audio Out Pairs 1-4). Also provides Gain, Phase Invert, and Muting controls for each channel.
	
<p>The example above shows various Source selections and individual audio control settings for various audio sources fed to the Destination channels <b>AES Ch 1</b> thru <b>AES Ch 8</b>, with the resulting setup (right).</p> <p>The source-to-destination correlation shown here is only an example; <b>any</b> of the sources on the left can connect to <b>any</b> of the destinations on the right.</p> <p>The controls shown here are described in detail on the following pages.</p>	
	




Table 3-2 9083 Function Submenu List — continued

AES Audio Out Pairs 1-4	(continued)
<p><b>Note:</b> • <b>AES Ch 2</b> thru <b>AES Ch 8</b> have controls that are identical to the <b>Source</b>, <b>Gain</b>, <b>Mute</b>, and <b>Phase</b> controls described here for <b>AES Ch 1</b>. Therefore, only the <b>AES Ch 1</b> controls are shown here.</p> <p>• For each channel, its source and destination should be considered and appropriately set. Unused destination channels should be set to the <b>Silence</b> selection.</p>	
<p>• <b>AES Channel Source</b></p> 	<p>Using the <b>Source</b> drop-down list, selects the audio source to be routed to the corresponding AES output channel from the choices described below.</p>
<p>• <b>Embedded Ch 1 thru Ch 16 as Source</b></p> 	<p><b>Embed Ch 1</b> thru <b>Embed Ch 16</b> range in Source drop-down list enables an embedded channel (Ch 1 thru Ch 16) to be the source for the selected destination AES channel.</p> <p>(In this example, Embed Ch 1 (embedded Ch 1) is the source for destination AES Ch 1)</p>
<p>• <b>AES Ch 1 thru AES Ch 16 as Source</b></p> 	<p><b>AES Ch 1</b> thru <b>AES Ch 16</b> range in Source drop-down list enables a discrete AES channel (Ch 1 thru Ch 16) to be the source for the selected destination AES channel.</p> <p>(In this example, AES Ch 5 is the source for destination AES Ch 1)</p>

**Table 3-2 9083 Function Submenu List — continued**

AES Audio Out Pairs 1-4	(continued)
<div><div>• Analog Ch 1 thru Ch 8 as Source</div><div><div><div>Destination</div><div>AES Ch 1</div></div><div><div>Source</div><div><div>Analog Ch 1</div><div>Analog Ch 1</div><div>⋮</div><div>Analog Ch 8</div></div></div></div><div><div>Card Edge Control Menu:</div><div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>AES</div><div>Ch(n)</div><div>Src</div><div>An(n)</div></div><div>Source: Analog Channel (1 thru 8)</div></div></div></div>	<div><div>Analog Ch 1 thru Analog Ch 8</div> range in Source drop-down list enables a balanced-input analog channel (Ch 1 thru Ch 8) to be the source for the selected destination AES channel.</div> <div>(In this example, Analog Ch1 is the source for destination AES Ch 1)</div>
<div><div>• Down Mix Left or Right as Source</div><div><div><div>Destination</div><div>AES Ch 1</div></div><div><div>Source</div><div><div>Down Mix Left</div><div>Down Mix Left</div><div>Down Mix Right</div></div></div></div><div><div>Card Edge Control Menu:</div><div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>AES</div><div>Ch(n)</div><div>Src</div><div>DM L DM R</div></div><div>Downmix L channel Downmix R channel</div></div></div></div>	<div><div>Down Mix Left</div> and <div>Down Mix Right</div> selections in Source drop-down list allow either downmix left or right channel to be the source for the selected destination AES channel.</div> <div>(In this example, the Down Mix Left channel is the source for destination AES Ch 1)</div> <div><div>Note:</div> Down Mix Left and Down Mix Right channels are a stereo pair derived from the L, C, R, Ls, and Rs channel inputs selected using the Audio Mixing function. The stereo pair consists of basic L/R PCM signals with no additional encoded information.</div> <div>Refer to <b>Audio Mixing</b> function description on page 3-53 for more information.</div>
<div><div>• Mono Mix as Source</div><div><div><div>Destination</div><div>AES Ch 1</div></div><div><div>Source</div><div><div>Mono</div></div></div></div><div><div>Card Edge Control Menu:</div><div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>AES</div><div>Ch(n)</div><div>Src</div><div>Mono</div></div><div>Mono mix selection as source</div></div></div></div>	<div><div>Mono</div> selection in Source drop-down list allows mono mix content to be the source for the selected destination AES channel.</div> <div>(In this example, the mono content is the source for destination AES Ch 1)</div> <div><div>Note:</div> Mono mix content is set up using Mono Mixer Selection in the <b>Audio Mixing</b> function). Refer to <b>Audio Mixing</b> function description on page 3-53 for more information.</div>

Table 3-2 9083 Function Submenu List — continued

AES Audio Out Pairs 1-4	(continued)
<p>• <b>Dolby® Decoded Channel as Source</b></p> 	<p><b>(9083-DEC only) Dolby Ch 1 thru Dolby Ch 8</b> range in Source drop-down list enables a Dolby® decoded channel to be the source for the selected destination AES channel.</p> <p>(In this example, Dolby® decoded Ch 1 is the source for destination AES Ch 1)</p> <p><b>Note:</b> Drop-down choices of Ch 1 thru Ch 8 and Mix 1/Mix 2 represent maximum channels available. Actual active channel complement is per received Dolby® format and upstream encoding. Inactive channels should not be used.</p> <p>Refer to <b>Dolby Metadata</b> function description on page 3-43 for more information.</p> <p>Refer to <b>Dolby® E Processing and Routing Example</b> on page 3-64 for an example of using Dolby® decoding.</p>
<p>• <b>Tone Generator 1 thru 4 as Source</b></p> 	<p><b>Tone Generator 1 thru Tone Generator 4</b> range in Source drop-down list enables one of four tone generators (Tone 1 thru Tone 4) to be the source for the selected destination AES channel.</p> <p>(In this example, Tone 1 (tone generator 1) is the source for destination AES Ch 1)</p> <p><b>Note:</b> Tone generator frequencies can be independently set for the four tone generator sources.</p> <p>Refer to <b>Tone Generator</b> function description on page 3-58 for more information.</p>
<p>• <b>Silence (Mute) as Source</b></p> 	<p><b>Silence</b> selection in Source drop-down list mutes the selected destination AES channel. <b>Use this setting for unused destination channels.</b></p> <p>(In this example, silence (muting) is applied to AES Ch 1)</p>



**Table 3-2 9083 Function Submenu List — continued**

AES Audio Out Pairs 1-4		(continued)
<div>• <b>Gain (dB) Control</b></div> <div><div>Gain (dB)</div><div><div><div></div><div>40.0</div><div>0.0</div><div>-40.0</div><div>-80.0</div></div><div>21.0</div></div></div> <div>Card Edge Control Menu:</div> <div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>AES</div><div>Ch(n)</div><div>Gain</div><div>(value) Gain value (in dB)</div></div></div> <td><div>Adjusts and displays relative gain (in dB) applied to the corresponding destination AES channel.</div><div>(-80 to +40 dB range in 0.1 dB steps; unity = 0.0 dB)</div></td>	<div>Adjusts and displays relative gain (in dB) applied to the corresponding destination AES channel.</div> <div>(-80 to +40 dB range in 0.1 dB steps; unity = 0.0 dB)</div>	
<div>• <b>Mute Control</b></div> <div><div>Channel is</div><div>Unmuted</div></div> <div><div>Channel is</div><div>Muted</div></div> <div>Card Edge Control Menu:</div> <div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>AES</div><div>Ch(n)</div><div>Mute</div><div>Off On Unmuted Muted</div></div></div> <td><div>Allows pushbutton On/Off channel muting while saving all other settings.</div></td>	<div>Allows pushbutton On/Off channel muting while saving all other settings.</div>	
<div>• <b>Phase Control</b></div> <div><div>Phase</div><div><div>Normal</div><div>Invert</div><div>Normal</div></div></div> <div>Card Edge Control Menu:</div> <div><div>Aud</div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>AES</div><div>Ch(n)</div><div>Pol</div><div>Norm Inv non-invert invert</div></div></div> <td><div>Selects between <b>Normal</b> and <b>Invert</b> phase (relative to source original phase) for the destination AES output channel.</div></td>	<div>Selects between <b>Normal</b> and <b>Invert</b> phase (relative to source original phase) for the destination AES output channel.</div>	

Table 3-2 9083 Function Submenu List — continued

AES Audio Out Pairs 5-8	Routes audio sources to AES output channels 9 thru 16 (AES Audio Out Pairs 5-8). Also provides Gain, Muting, and Phase Invert controls for each channel.
	<p>The example above shows various Source selections and individual audio control settings for various audio sources fed to the Destination channels <b>AES Ch 9</b> thru <b>AES Ch 16</b>, with the resulting setup (right).</p> <p>The source-to-destination correlation shown here is only an example; <b>any</b> of the sources on the left can connect to <b>any</b> of the destinations on the right, or receive sources. Available sources also include up to four tone generators (not shown here).</p>
<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• <b>AES Ch 9</b> thru <b>AES Ch 16</b> have controls that are identical to the <b>Source</b>, <b>Gain</b>, <b>Mute</b>, and <b>Phase</b> controls described for <b>AES Ch 1</b>. Refer to <b>AES Audio Out Pairs 1-4</b> on page 3-37 for descriptions of these controls.</li> <li>• For each channel, its source and destination should be considered and appropriately set. Unused destination channels should be set to the <b>Silence</b> selection.</li> </ul>	

**Table 3-2 9083 Function Submenu List — continued**






	<p><b>(9083 only)</b> Extracts and preserves Dolby® metadata from the input SDI, and in turn allows the metadata to be re-inserted in the output SDI.</p>
<p>• <b>Metadata Embedding</b></p>  <p>Card Edge Control Menu:</p> 	<p><b>Metadata Embedding (On/Off)</b> controls SMPTE 2020-1 metadata embedding in the SDI video output.</p> <ul style="list-style-type: none"> <li>• When set to <b>On</b>, metadata is extracted from the SDI input video, buffered, and re-directed to the output SDI video.</li> <li>• When set to <b>Off</b>, metadata is not embedded in the output SDI video.</li> </ul>
<p>• <b>Metadata Output Line</b></p>  <p>Card Edge Control Menu:</p> 	<p>Allows selection of SMPTE 2020-1 metadata line location within the VANC space for re-inserted Dolby® metadata. (Range is 9 thru 41; default is line #13.)</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• Although the output line drop-down will allow any choice within the 9 thru 41 range, the actual range is automatically clamped (limited to) certain ranges to prevent inadvertent conflict with active picture area depending on video format. See Ancillary Data Line Number Locations and Ranges (p. 3-15) for more information.</li> <li>• The card does not check for conflicts on a given line number. Make certain the selected line is available and carrying no other data unless existing metadata is to be intentionally overwritten.</li> </ul>
<p><b>Note: (9083 only)</b> The <b>Metadata Output Source</b> button in DashBoard™ is locked to Input Video for this card. With this function enabled, the extracted metadata is always available in the SDI video output and on cards equipped with an appropriate Rear I/O Module having a Dolby® metadata RS-485 connector.</p>	

Table 3-2 9083 Function Submenu List — continued

**(9083-DEC only)** Routes a Dolby® encoded pair to the Dolby® decoder, and provides Dolby® configuration display and metadata handling controls.

**Note:** • The Dolby tab controls described here appear only on card equipped with Dolby Decoder option (-DEC).

- If necessary, see Dolby® E Processing and Routing Example on page 3-64 for an example of using and routing Dolby® decoding.
- Decoded channels shown in DashBoard™ correlate to typical channel designations as shown below. Note that channel designations are a function of encoding. Based on encoding, actual channel designations may vary from the examples shown here.

Decoder Channels	E5.1+2	E7.1+2	E8x1
Ch 1	LF	LF	Ch 1
Ch 2	RF	RF	Ch 2
Ch 3	C	C	Ch 3
Ch 4	LFE	LFE	Ch 4
Ch 5	LS	LS	Ch 5
Ch 6	RS	RS	Ch 6
Ch 7	Aux 1	LB	Ch 7
Ch 8	Aux 2	RB	Ch 8
Mix 1	Lo	Lo	Mono Mix 1
Mix 2	Ro	Ro	Mono Mix 2

- See other important notes in this subsection regarding the proper use of metadata embedding tools available with the decoder function.

**• AES Pair as Input**

**AES Pair 1** thru **AES Pair 8** range in Input Select drop-down list selects an AES Pair (1 thru 8) to be the input for the Dolby® decoder.

(In this example, AES Pair 1 is the input for the Dolby® decoder)

**Table 3-2 9083 Function Submenu List — continued**







	(continued)
<p>• <b>Embedded Channel Pair as Input</b></p>  	<p><b>Embedded Ch 1+2</b> thru <b>Ch 15+16</b> range in Input Select drop-down list selects an embedded channel pair (1+2 thru 15+16) to be the input for the Dolby® decoder.</p> <p>(In this example, embedded channel pair 1+2 is the input for the Dolby® decoder)</p>
<p>• <b>Decoder Mode</b></p> 	<p>Using the drop-down list, selects the action to take in presence or absence of Dolby® E or Digital source from the choices shown on the left.</p>
<p>• <b>Dolby® Mode Display</b></p> 	<p>Shows specific bitstream information and Dolby® decoding type (Dolby® E or Dolby® Digital) for input applied to Dolby® decoder.</p> <p>(In this example, Dolby® E 20-bit with 5.1+2 decoded channel configuration is being decoded)</p> <p>If selected input has invalid or missing Dolby® data (such as if wrong channels are applied to decoder), <b>PCM / No Dolby Stream</b> is displayed.</p> <p>(In this case, PCM data passes undecoded and is present on <b>Dolby Ch 1</b> and <b>Dolby Ch 2</b> channels.)</p>
<p>• <b>Dolby® Digital Channel and Dynamic Range Controls</b></p> 	<p><b>Channel Select</b> drop-down list sets the channel carrying the Dolby® Digital encoded signal for D1/0 formats as shown from choices on the left.</p> <p><b>Dynamic Range Control</b> drop-down list selects from audio level compression scheme choices as shown to the left. (Line Mode is typical setting; RF Mode is used where signal may be fed through low-cost video/ audio RF modulator, in which case RF Mode helps prevent overmodulation. Refer to ATSC A/52B for more information.)</p>

Table 3-2 9083 Function Submenu List — continued





	(continued)
<p>• <b>Metadata Embedding</b></p> 	<p><b>Metadata Embedding (On/Off)</b> controls SMPTE 2020-1 metadata embedding in the SDI video output.</p> <ul style="list-style-type: none"> <li>• When set to <b>On</b>, metadata from selected source is embedded in the output SDI video.</li> <li>• When set to <b>Off</b>, metadata is not embedded in the output SDI video.</li> </ul> <p><b>Note:</b> Metadata Embedding should <b>only</b> be set to “On” if <b>new</b> metadata is to be embedded. <b>Existing</b> metadata on the SDI input is passed through the card unaffected, requiring no operator intervention.</p>
<p>• <b>Metadata Output Source</b></p> 	<p>Drop-down list allows embedding and RS485 metadata routing to the choices shown to the left and described below.</p> <ul style="list-style-type: none"> <li>• <b>Embedded: Dolby Decoder, RS485: Dolby Decoder</b> – Routes the metadata from the Dolby<sup>®</sup> decoder to both embedding on the output SDI and the RS485 port on card so equipped.</li> <li>• <b>Embedded: Input Video, RS485: Dolby Decoder</b> – Preserves input metadata and directly re-routes it to the output SDI. Routes the metadata from the Dolby<sup>®</sup> decoder to only the RS485 port on card so equipped.</li> <li>• <b>Embedded: Input Video, RS485: Input Video</b> – Routes the preserved input metadata to both embedding on the output SDI and the RS485 port on card so equipped.</li> </ul> <p><b>Note:</b> Typically, Metadata Output Source should be set to <b>Embedded: Dolby Decoder, RS485: Dolby Decoder</b>, since this is the new metadata produced by the card decoder and should also be made available in the SDI stream and to any other external systems. If embedding new metadata, make certain to set its line number such that any old metadata for the same purpose is overwritten (i.e., new metadata set to the same line number as the old metadata to be replaced).</p>
<p>• <b>Metadata Output Line</b></p> 	<p>Allows selection of SMPTE 2020-1 metadata line location within the VANC space for source embedding selected above.</p> <p>(Range is 9 thru 41; default is line #13.)</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• Although the output line drop-down will allow any choice within the 9 thru 41 range, the actual range is automatically clamped (limited to) certain ranges to prevent inadvertent conflict with active picture area depending on video format. See Ancillary Data Line Number Locations and Ranges (p. 3-15) for more information.</li> <li>• The card does not check for conflicts on a given line number. Make certain the selected line is available and carrying no other data unless existing metadata is to be intentionally overwritten.</li> </ul>

Table 3-2 9083 Function Submenu List — continued

## Dolby E Metadata

**(9083-DEC only)** Displays the status and programming details for each Dolby® E AC-3 program dictated by the received external metadata.

**Note:**

- This display is read-only. No changes can be made to the settings. All displays are reports per the received metadata.
- Information provided here is intended as an overview of the screen. Displayed parameters are per ATSC A/52B definitions. Refer to ATSC A/52B for detailed descriptions and background.

Updates the external metadata status and program configuration display screen. The display always shows the last initiated metadata transaction; to refresh screen for any changes, click **Update**.

**Note:** Metadata does not continuously report. Use this button to report new metadata. When clicked, the button stays in the “depressed” position while updating. When the button displays the “out” position, update is complete and all displays are current.

Where AC-3 programs exist for the current metadata coding, the columns show the details for the individual AC-3 programs

Where AC-3 programs do not exist for the current metadata coding, the columns are collapsed

Update Metadata	<b>Update</b>							
Dolby E AC-3 Metadata	1	2	3	4	5	6	7	8
Bitstream Mode	Complete Main	Complete Main						
Audio Coding Mode	3/2 (L,C,R,Ls,Rs)	2/0 (L,R)						
Center Mix Level	Attenuation is -3dB	Attenuation is -3dB						
Surround Mix Level	Attenuation is -3dB	Attenuation is -3dB						
Dolby Surround Mode	Not Indicated	Not Indicated						
LFE Enable	LFE is On (coded)	LFE is Off (not coded)						
Dialog Normalization	-27 dBFS	-27 dBFS						
Audio Production Information	Not Present	Not Present						
Mix Level	80 dB	80 dB						

•  
•  
•

DC Highpass Filter	Bypassed	Bypassed						
Bandwidth Lowpass Filter	Bypassed	Bypassed						
LFE Channel Lowpass Filter	Bypassed	Bypassed						
Surround Channel 90 Degrees Phase Shift Filter	Bypassed	Bypassed						
Surround Channel -3 dB Attenuation	Bypassed	Bypassed						
Compression Words	Not Present	Not Present						
Compression Profile	Film: Standard	Film: Standard						
Dynamic Range Compression Words	Not Present	Not Present						
Dynamic Range Compression Profile	Film: Standard	Film: Standard						

Table 3-2 9083 Function Submenu List — continued

<div>Dolby D Metadata</div>	<p><b>(9083-DEC only)</b> Displays the status and programming details for Dolby® Digital program dictated by the received external metadata.</p>
<p><b>Note:</b></p> <ul style="list-style-type: none"><li>• This display is read-only. No changes can be made to the settings. All displays are reports per the received metadata.</li><li>• Information provided here is intended as an overview of the screen. Displayed parameters are per ATSC A/52B definitions. Refer to ATSC A/52B for detailed descriptions and background.</li></ul>	
<p>Updates the external metadata status and program configuration display screen. The display always shows the last initiated metadata transaction; to refresh screen for any changes, click <b>Update</b>.</p> <p><b>Note:</b> Metadata does not continuously report. Use this button to report new metadata. When clicked, the button stays in the “depressed” position while updating. When the button displays the “out” position, update is complete and all displays are current.</p>	<div><div><div>Update Metadata</div><div>Update</div><div>Bitstream Mode</div><div>Complete Main</div><div>Audio Coding Mode</div><div>2/0 (L,R)</div><div>Center Mix Level</div><div>Attenuation is -3dB</div><div>Surround Mix Level</div><div>Attenuation is -3dB</div><div>Dolby Surround Mode</div><div>Not Indicated</div><div>LFE Enable</div><div>LFE is Off (not coded)</div><div>Dialog Normalization</div><div>-27 dBFS</div><div>Audio Production Information</div><div>Present</div><div>Mix Level</div><div>105 dB</div><div>Room Type</div><div>Small Room (Flat EQ)</div><div>Copyright Bit</div><div>Copyright Protected</div><div>Original Bitstream</div><div>Original</div></div><div><div>LoRo Center Mix Level</div><div>Level is Adjusted +3.0 dB</div><div>LoRo Surround Mix Level</div><div>Level is Adjusted +3.0 dB</div><div>Extended Bitstream Group 2</div><div>Not Included</div><div>Dolby Surround EX Mode</div><div>Not Indicated</div><div>Compression Words</div><div>Present</div><div>Compression Profile</div><div>Unknown</div><div>Dynamic Range Compression Words</div><div>Present</div><div>Dynamic Range Compression Profile</div><div>None</div><div>Dynamic Range Compression Words</div><div>Present</div><div>Dynamic Range Compression Profile</div><div>None</div></div></div>



**Table 3-2 9083 Function Submenu List — continued**














Timecode	Provides timecode data extraction from various sources, and provides formatting and re-insertion controls for inserting the timecode into the output video.
<p>Shown below is an example in which received SDI video with SDI VITC waveform timecode is to be converted to SDI ATC_VITC and SDI ATC_LTC timecode data. Each Timecode control is fully described on the pages that follow.</p>	
	
<p><b>A</b> Noting that the incoming video contains VITC waveform timecode data (as shown in the status display), set the Source Priority drop-down lists to include VITC Waveform timecode data (<b>SDI VITC</b>) as a choice. This extracts VITC Waveform timecode data from the incoming video.</p>	
<p><b>B</b> In this example, it is desired to provide both SDI ATC_VITC and ATC_LTC timecode data in the converted HD output video. As such, set both <b>HD ATC VITC Insertion</b> and <b>HD ATC LTC Insertion</b> to <b>Enabled</b>.</p>	
<p>In the example here, the line numbers are set to the default SMPTE 12M-2-2008 recommended values.</p>	
	

Table 3-2 9083 Function Submenu List — continued

<div>Timecode</div>	(continued)
<p>• <b>Timecode Source Status Displays</b></p> 	<p>Displays the current status and contents of the three supported timecode formats shown to the left.</p> <ul style="list-style-type: none"> <li>• If a format is receiving timecode data, the current content (timecode running count and line number) is displayed.</li> <li>• If a format is not receiving timecode data, Unlocked is displayed.</li> </ul>
<p>• <b>Incoming ATC Packet Removal Control</b></p> 	<p>Enables or disables removal of existing input video ATC timecode packets from the output. This allows removal of undesired existing timecodes from the output, resulting in a “clean slate” where only desired timecodes are then re-inserted into the output. (For example, if both SD VITC Waveform and SD ATC_VITC timecode data are present on the input video, and only ATC_VITC is desired, using the Removal control will remove both timecodes from the output. The ATC_VITC timecode by itself can then be re-inserted on the output using the other controls discussed here.)</p> <p><b>Note:</b> When the Scaler is enabled, ATC packets are automatically removed. The Timecode function must be used to re-insert the timecode data into the output video.</p>
<p>• <b>Source Priority</b></p> 	<p>As described here, selects the priority assigned to each of the four supported formats in the event the preferred source is unavailable. Each of the four Source Priority selection lists allows assignment of source priority from the following choices:</p>  <p><b>Source Priority 1</b> thru <b>Source Priority 4</b> select the preferred format to be used in descending order (i.e., Source Priority 2 selects the second-most preferred format, and so on).</p>
<p>• <b>Output Status Display</b></p> 	<p>Displays the current content and source being used for the timecode data as follows:</p>  <ul style="list-style-type: none"> <li>• Output status OK (in this example, running SDI VITC timecode received and outputted).</li> </ul>  <ul style="list-style-type: none"> <li>• Timecode not available due to lack of appropriate input timecode data on enabled formats.</li> </ul> <p><b>Note:</b> Timecode output requires that source and priority are appropriately selected (as described above in <b>Source Priority</b>). Also, video input must contain appropriate timecode data.</p>  <ul style="list-style-type: none"> <li>• <b>Timecode Insertion</b> button set to <b>Disabled</b>; output insertion disabled.</li> </ul>

**Table 3-2 9083 Function Submenu List — continued**

<div>Timecode</div>	(continued)
<p>• <b>VITC Waveform Output Line</b></p> <p>VITC Waveform Output 1 Line Number <input type="text" value="14"/></p> <p>VITC Waveform Output 2 Line Number <input type="text" value="16"/></p> <div> <div>Card Edge Control Menu:</div> <div> <div>TC</div> <div> <div>1</div> <div>2</div> </div> <div> <div>VITO</div> <div>(value)</div> </div> </div> <div>VITC output 1 line number only (6 thru 22)</div> </div>	<p>Selects the VITC1 and VITC2 line numbers (6 thru 22) where the VITC data is inserted when the output is SD. (The default is line #14/16.)</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>Although the output line drop-down will allow any choice within the 6 thru 22 range, the actual range is automatically clamped (limited) to certain ranges to prevent inadvertent conflict with active picture area depending on video format. See Ancillary Data Line Number Locations and Ranges (p. 3-15) for more information.</li> <li>The card does not check for conflicts on a given line number. Make certain the selected line is available and carrying no other data.</li> <li>If only one output line is to be used, set both controls for the same line number.</li> </ul>
<p>• <b>SD VITC Waveform Insertion Control</b></p> <p>SD VITC Waveform Insertion <input type="button" value="Disabled"/></p> <div> <div>Card Edge Control Menu:</div> <div> <div>TC</div> <div> <div>1</div> <div>2</div> </div> <div> <div>SDVC</div> <div>Off</div> </div> </div> <div>SD VITC timecode insertion disabled SD VITC timecode insertion enabled</div> </div>	<p>Enables or disables VITC waveform timecode insertion into the SD-SDI output stream.</p> <p><b>Note:</b> SD VITC Waveform Insertion control only affects VITC waveforms inserted (or copied to a new line number) by this function. An existing VITC waveform on the SDI input is not affected by this control and in all cases is passes on the SDI output.</p>
<p>• <b>SD ATC Insertion Control</b></p> <p>SD ATC Insertion <input type="button" value="Disabled"/></p> <div> <div>Card Edge Control Menu:</div> <div> <div>TC</div> <div> <div>1</div> <div>2</div> </div> <div> <div>SDAT</div> <div>Off</div> </div> </div> <div>SD ATC timecode insertion disabled SD ATC timecode insertion enabled</div> </div>	<p>For SD output, enables or disables SD ATC_VITC timecode insertion into the video stream.</p> <p><b>Note:</b> SD ATC_VITC is locked to line 12. The card does not check for conflicts on a given line number. Make certain this line is available if SD ATC_VITC is to be used. See Ancillary Data Line Number Locations and Ranges (p. 3-15) for more information.</p>
<p>• <b>HD ATC_VITC Insertion Control</b></p> <p>HD ATC VITC Insertion <input type="button" value="Disabled"/></p> <div> <div>Card Edge Control Menu:</div> <div> <div>TC</div> <div> <div>1</div> <div>2</div> </div> <div> <div>HFVC</div> <div>Off</div> </div> </div> <div>HD ATC_VITC timecode insertion disabled HD ATC_VITC timecode insertion enabled</div> </div>	<p>For HD output, enables or disables SD ATC_VITC timecode insertion into the video stream.</p>

Table 3-2 9083 Function Submenu List — continued


	(continued)						
<p>• <b>HD ATC_VITC Line Insertion Controls</b></p> <p>HD ATC_VITC Insertion Line Field 1 <input type="text" value="9 - SMPTE 12M-2-2008 Recommended"/></p> <p>HD ATC_VITC Insertion Line Field 2 <input type="text" value="8 (571) - SMPTE 12M-2-2008 Recommended"/></p>	<p>For HD ATC_VITC timecode output, selects the line number for ATC_VITC1 and ATC_VITC2.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>Although the output line drop-down will allow any choice within the 8 thru 20 range, the actual range is automatically clamped (limited) to certain ranges to prevent inadvertent conflict with active picture area depending on video format. See Ancillary Data Line Number Locations and Ranges (p. 3-15) for more information.</li> <li>The card does not check for conflicts on a given line number. Make certain the selected line is available and carrying no other data.</li> <li>If only one output line is to be used, set both controls for the same line number.</li> </ul>						
<p>• <b>HD ATC_LTC Insertion Control</b></p> <p>HD ATC LTC Insertion <input type="button" value="Disabled"/></p> <div data-bbox="237 858 678 1041"> <p>Card Edge Control Menu:</p> <p>TC</p> <table border="1"> <tr> <td>1</td> <td>2</td> </tr> <tr> <td>HDLT</td> <td>Off</td> </tr> <tr> <td></td> <td>On</td> </tr> </table> <p>HD ATC LTC timecode insertion disabled HD ATC LTC timecode insertion enabled</p> </div>	1	2	HDLT	Off		On	<p>For HD output, enables or disables ATC_LTC timecode insertion into the video stream.</p>
1	2						
HDLT	Off						
	On						
<p>• <b>HD ATC_LTC Line Insertion Control</b></p> <p>HD ATC_LTC Insertion Line <input type="text" value="10 - SMPTE 12M-2-2008 Recommended"/></p>	<p>For HD timecode output, selects the line number for ATC_LTC timecode data.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>Although the output line drop-down will allow any choice within the 9 thru 20 range, the actual range is automatically clamped (limited) to certain ranges to prevent inadvertent conflict with active picture area depending on video format. See Ancillary Data Line Number Locations and Ranges (p. 3-15) for more information.</li> <li>The card does not check for conflicts on a given line number. Make certain the selected line is available and carrying no other data.</li> </ul>						
<p>• <b>ATC_VITC Legacy Support Control</b></p> <p>ATC VITC Legacy Support <input type="button" value="Disabled"/></p> <div data-bbox="237 1520 647 1703"> <p>Card Edge Control Menu:</p> <p>TC</p> <table border="1"> <tr> <td>1</td> <td>2</td> </tr> <tr> <td>AVLS</td> <td>Off</td> </tr> <tr> <td></td> <td>On</td> </tr> </table> <p>ATC VITC legacy support disabled ATC VITC legacy support enabled</p> </div>	1	2	AVLS	Off		On	<p>When enabled, accommodates equipment requiring ATC_VITC packet in both fields as a "field 1" packet (non-toggling).</p> <p><b>Note:</b> Non-toggling VITC1 and VITC2 packets do not conform to SMPTE 12M-2-2008 preferences. As such, ATC_VITC Legacy Support should be enabled only if required by downstream equipment.</p>
1	2						
AVLS	Off						
	On						

Table 3-2 9083 Function Submenu List — continued






	<p>Provides down-mix audio routing selections that multiplexes any five embedded, AES, or analog audio channel sources into a stereo pair (Down Mix Left and Down Mix Right), or selection of any two audio sources to be mono-mixed to serve as a monaural source.</p> <p>With an optional upmixer licensable feature activated, any normal PCM stereo pair can be fed to the upmixer to generate 5.1 surround sound audio which in turn can be applied to six user-selectable channels.</p>
<p>• <b>Down Mixer Selection</b></p> 	<p>Separate drop-down lists for <b>Left</b>, <b>Right</b>, <b>Center</b>, <b>Left Surround (Ls)</b>, and <b>Right Surround (Rs)</b> inputs allow embedded, AES, or analog channel audio source selection for each of the five inputs as shown below.</p>  <p>The example below shows selection from various sources and the resulting stereo pair DM-L and DM-R. The two signals comprising the pair can be routed and processed the same as any other audio input source.</p>  <p><b>Note:</b> The stereo pair are basic L/R PCM signals with no additional encoded information.</p>
<p>• <b>Center Mix Ratio Control</b></p> 	<p>Adjusts the attenuation ratio of center-channel content from 5-channel source that is re-applied as Lt and Rt content to the DM-L and DM-R stereo mix.</p> <ul style="list-style-type: none"> <li>• Minimum attenuation setting (-0.0 dB) applies no ratiometric reduction. Center channel content is restored as in-phase center-channel content with no attenuation, making center-channel content more predominate in the overall mix.</li> <li>• Maximum attenuation setting (-10.0 dB) applies a -10 dB ratiometric reduction of center-channel content. Center-channel content is restored as in-phase center-channel content at a -10 dB ratio relative to overall level, making center-channel content less predominate in the overall mix.</li> </ul> <p>(0.0 dB to -10.0 dB range in 0.1 dB steps; default = -3 dB)</p> <p><b>Note:</b> Default setting of -3.0 dB is recommended to maintain center-channel predominance in downmix representative to that of the original source 5-channel mix.</p>

Table 3-2 9083 Function Submenu List — continued





<div style="background-color: #333; color: white; padding: 5px; text-align: center; font-weight: bold;">Audio Mixing</div>	(continued)
<p>• <b>Surround Mix Ratio Control</b></p> 	<p>Adjusts the attenuation ratio of surround-channel content from 5-channel source that is re-applied as Lo and Ro content to the DM-L and DM-R stereo mix.</p> <ul style="list-style-type: none"> <li>• Minimum attenuation setting (-0.0 dB) applies no ratiometric reduction. Surround-channel content is restored with no attenuation, making Lo and Ro content more predominate in the overall mix.</li> <li>• Maximum attenuation setting (-10.0 dB) applies a -10 dB ratiometric reduction of surround-channel content. Surround-channel content is restored at a -10 dB ratio relative to overall level, making surround-channel content less predominate in the overall mix.</li> </ul> <p>(0.0 dB to -10.0 dB range in 0.1 dB steps; default = -3 dB)</p> <p><b>Note:</b> Default setting of -3.0 dB is recommended to maintain surround-channel predominance in downmix representative to that of the original source 5-channel mix.</p>
<p>• <b>Mono Mixer Selection</b></p> 	<p>Separate drop-down lists for <b>Left</b> and <b>Right</b> inputs allow selected embedded, AES, analog, or the DM-L / DM-R input channels to provide an additional mono-mixed channel.</p> <p>The resulting mono mix (<b>Mono</b>) is available as an audio source for any of the 32 destination embedded or AES output channels as shown below.</p> <div style="display: flex; align-items: flex-start;"> <div style="flex: 1;">  </div> <div style="flex: 1;">  </div> </div> <p><b>Note:</b> Selection of any two channels for mono mixing in no way affects the source channels themselves.</p>

Table 3-2 9083 Function Submenu List — continued







Audio Mixing	(continued)
<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• 2.0-to-5.1 upmixer function is an optional licensable feature. This function and its controls appear only when a license key is entered and activated. Refer to <b>Licensable Features</b> function description on page 3-58 for more information.</li> <li>• Channel sources used by the upmixer are post-processed signals received from the Audio Routing/Gain Control function. When active, the channel selections made using this function are <b>directly embedded in the output SDI or AES discrete pairs</b>. Refer to 2.0-to-5.1 Upmix Function (p. 1-11) in Chapter 1, "Introduction" for detailed functional description and signal flow.</li> <li>• For any six channels selected for this function, the <b>Left</b> and <b>Right</b> channel selections always serve as the stereo input pair.</li> </ul>	
<p>• <b>2.0-to-5.1 Up Mixer Selection</b></p> 	<p>Separate drop-down lists for <b>Left</b>, <b>Right</b>, <b>Center</b>, <b>LFE</b>, <b>Left Surround</b>, and <b>Right Surround</b> allow embedded, AES, or analog channel audio source selection, and embedded or AES discrete channel assignments for the six generated 5.1 channels.</p>  <p>The example below shows selection of embedded channels 1 and 2 as the received stereo source (Embed Ch1 and Ch 2 for <b>Left</b> and <b>Right</b> drop-down list selections in the Up Mixer Selection tool).</p> <p>Using the setup shown in the example, when upmix is active the embedded channel 1/2 stereo pair is overwritten with the new stereo pair L/R on channels 1/2. As selected in the example, the additional 5.1 channels C, LFE, Left Surround (Ls), and Right Surround (Rs) overwrite Emb Ch 3 – Ch 6, respectively.</p> 

Table 3-2 9083 Function Submenu List — continued

<div data-bbox="237 260 639 327">Audio Mixing</div>	(continued)
<p>• <b>Up Mixer Mode Control</b></p> 	<p>Enables or bypasses upmixer as follows:</p> <ul style="list-style-type: none"> <li>• <b>Auto:</b> Automatic enable/bypass of 5.1 upmix function as follows: <ul style="list-style-type: none"> <li>• If detected signal level on <b>all four</b> of the selected channels designated as <b>Center, LFE, Left Surround, and Right Surround</b> are <b>below</b> the level threshold set using the <b>5.1 Detection Threshold</b> control, upmixer overwrites all six selected channels with the new 5.1 content generated by the upmixer.</li> <li>• If detected signal level on <b>any of the four</b> of the selected channels designated as <b>Center, LFE, Left Surround, and Right Surround</b> is <b>above</b> the level threshold set using the <b>5.1 Detection Threshold</b> control, upmixer is bypassed and the original channels pass unaffected.</li> </ul> </li> <li>• <b>Always Upmix:</b> Manual enable turns on upmixer and overwrites content on all six selected channels with new 5.1 content generated by the upmixer regardless of original signal level or content.</li> <li>• <b>Bypass:</b> Manual disable bypasses the upmixer. When bypassed, the six embedded audio channels pass unaffected.</li> </ul>
<p>• <b>Up Mixer Status Display</b></p> 	<p>Shows activity status of upmixer processing as follows:</p> <ul style="list-style-type: none"> <li>• <b>Auto Mode - Currently Upmixing:</b> With upmixer enable set to <b>Auto</b>, indicates selected channels designated as <b>Center, LFE, Left Surround, and Right Surround</b> are clear for use (as described above); upmixer is currently up-mixing received stereo pair and overwriting the six selected channels with new 5.1 upmix.</li> <li>• <b>Auto Mode - Currently Bypassed:</b> With upmixer enable set to <b>Auto</b>, indicates selected channels designated as <b>Center, LFE, Left Surround, and Right Surround</b> have content (such as existing original 5.1 or other content); upmixer is bypassed (disabled) and allows normal passage of six selected channels.</li> <li>• <b>Upmixing:</b> Indicates upmixer is manually enabled (set to Always Upmix) and is currently up-mixing received stereo pair and overwriting the six selected channels with new 5.1 upmix.</li> <li>• <b>Bypassed:</b> Indicates upmixer is manually disabled (set to Bypass) and is currently passing all selected channels unaffected.</li> </ul>
<p>• <b>Auto Crossfade Speed Controls</b></p> 	<p>Individual controls select the relative crossfade transition speed between Upmix to Bypass (going to inactive; from 5.1 to 2.0) and Bypass to Upmix (going to active; from 2.0 to 5.1) when upmixer enable is set to <b>Auto</b> and the active threshold (as set by the <b>5.1 Detection Threshold</b> control) is crossed in either direction.</p> <p>To suit program material and production aesthetic preferences, several choices are available as shown to the left. Slower settings allow for a more gradual transition between modes, however with a longer interval before levels stabilize. Faster settings conversely allow for a smaller interval before levels stabilize, however with greater perceived abruptness.</p>



**Table 3-2 9083 Function Submenu List — continued**

<div data-bbox="269 260 672 325"> <h2>Audio Mixing</h2> </div>	<div data-bbox="810 275 958 306">(continued)</div>
<div data-bbox="263 388 605 413"> <p>• <b>5.1 Detection Threshold Control</b></p> </div> <div data-bbox="280 424 660 508"> <p>5.1 Detection Threshold (dBFS) -150.0</p> </div>	<p>Adjusts the threshold at which selected channels designated as C, LFE, Ls, and Rs are considered to have viable content, or at which signal levels can be considered insignificant when upmixer enable is set to <b>Auto</b>. Setting affects automatic enable/bypass of 5.1 upmix function as follows:</p> <ul style="list-style-type: none"> <li>• If detected signal level on <b>all four</b> of the selected channels designated as Center, LFE, Left Surround, and Right Surround are <b>below</b> the level threshold set using the <b>5.1 Detection Threshold</b> control, upmixer allows <b>overwrite</b> of all six selected channels with the new 5.1 signal complement.</li> <li>• If detected signal level on <b>any of the four</b> of the selected channels designated as Center, LFE, Left Surround, and Right Surround is <b>above</b> the level threshold set using the <b>5.1 Detection Threshold</b> control, upmixer is <b>bypassed</b>, thereby releasing the selected six channels and allowing the original channels to pass unaffected.</li> </ul> <p>(Range is -150 dB to 0 dB in 0.1dB steps; 0 dB equivalent to +24 dBu=&gt; 0 dBFS)</p> <div data-bbox="771 831 1440 1218"> <p>Typically, the <b>5.1 Detection Threshold</b> control should be set to provide a usable threshold that maintains a threshold at which valid levels large enough over the threshold <b>disable</b> the auto upmix (A, left), while nuisance levels considerably below the threshold (B, left) are rejected, allowing the upmixer to stay locked in the enabled mode and <b>overwrite</b> these signals with the new signals.</p> <p>Optimum setting is dependent on program material general overall levels. A -60 dB setting is recommended for material closely adhering to the SMPTE -20 dBFS Alignment level for normal material such as dialog.</p> </div>
<div data-bbox="263 1270 496 1293"> <p>• <b>Center Width Control</b></p> </div> <div data-bbox="280 1304 561 1390"> <p>Center Width 0.0</p> </div>	<p>Adjusts center channel content (in terms of percentage) applied to L and R channels.</p> <ul style="list-style-type: none"> <li>• Minimum setting keeps all L+R (mono) content confined to center (C) channel, with any center channel content removed from L and R channels.</li> <li>• Higher settings progressively blend respective L and R mono content back into L and R channels, with 100% setting resulting in center channel level going to zero and L/R channels becoming normal L/R channels containing some mono content.</li> </ul> <p>(0% to 100% range in 0.1% steps; default = 0%)</p>
<div data-bbox="263 1560 526 1583"> <p>• <b>Surround Depth Control</b></p> </div> <div data-bbox="280 1593 561 1682"> <p>Surround Depth 0.0</p> </div>	<p>Adjusts surround channel content (in terms of percentage) applied to Ls and Rs channels.</p> <ul style="list-style-type: none"> <li>• Maximum setting results in greatest surround channel levels.</li> <li>• Lower settings progressively diminish surround channel levels, with 0% setting resulting in no Ls or Rs level, with Ls and Rs content progressively folded back into L and R, respectively.</li> </ul> <p>(0% to 100% range in 0.1% steps; default = 100%)</p>

Table 3-2 9083 Function Submenu List — continued





	<p>Sets the test tone frequency for each of four tone generators (Tone Generator 1 thru 4).</p>
<p>• <b>Frequency Selection Lists</b></p> 	<p>Selects the frequency for each of the four tone generators. 18 discrete sine wave frequencies are available, ranging from 50 Hz to 16 kHz (default frequency is 1.0 kHz).</p> <p><b>Note:</b> Unity-gain signal level is equivalent to -20 dBu.</p>
	<p>Allows activation of optional licensed features.</p>
<p><b>Note:</b> For card pre-ordered with licensed feature(s), the activation steps described below are not required; the feature will already be installed activated. To order features and obtain a license key, contact Cobalt<sup>®</sup> sales at sales@cobaltdigital.com or at the contact information in Contact Cobalt Digital Inc. in Chapter 1, “Introduction”. Please provide the “SSN” number of your card (displayed in the Card Info pane) when contacting us for your key.</p>	
<p>• <b>License Feature and Key Entry window</b></p> 	<p>Activate licensable feature as described below.</p> <ol style="list-style-type: none"> <li>1. Enter the feature key string in the <b>Feature Key</b> box. Press return or click outside of the box to acknowledge entry. <p><b>Note:</b> Entry string is case sensitive. Do not enter any spaces.</p> </li> <li>2. In the DashBoard™ Card Info pane, wait for the feature identification to be shown for the card product number (for example, “-UM” appearing after the card part number) and <b>Valid Key Entered</b> to be displayed. This indicates the key was correctly entered and recognized by the card. <p><b>Note:</b> If DashBoard™ card function submenu/control pane does not re-appear, close the card and re-open it.</p> </li> <li>3. Click and confirm <b>Reboot</b>. When the card function submenu/control pane appears again, the licensable feature will be available. <p><b>Note:</b> Applying the licensable feature and its reboot has no effect on prior settings. All control settings and drop-down selections are retained.</p> </li> </ol>

Table 3-2 9083 Function Submenu List — continued






	<p>Allows up to 16 card user settings configuration presets to be saved in a Preset and then recalled (loaded) as desired. All current settings (including list selections and scalar (numeric) control settings such as Gain, etc.) are saved when a Preset Save is invoked.</p>
	<p>The <b>Preset Name</b> field and <b>Preset Save</b> button allow custom user setting configurations to be labeled and saved to a Preset for future use.</p> <p>The <b>Preset Load</b> button and the <b>Selected Preset</b> drop-down list allow saved presets to be selected and loaded as desired. When a preset is loaded, it immediately becomes active with all user settings now automatically set as directed by the preset.</p> <p>Saved presets can be uploaded to a computer for use with other same-model COMPASS™ cards.</p> <p>Each of the items to the left are described in detail on the following pages.</p>
<p>• <b>Preset Save and Load</b></p> 	<ul style="list-style-type: none"> <li>• <b>Preset Save</b> stores all current card control settings to the currently selected preset. (For example, if Preset 1 is selected in the Selected Preset drop-down list, clicking and confirming Preset Save will then save all current card control settings to Preset 1)</li> <li>• <b>Preset Load</b> loads (applies) all card control settings defined by whatever preset (<b>Preset 1</b> thru <b>Preset 16</b>) is currently selected in the <b>Selected Preset</b> drop-down list. (For example, if Preset 3 is selected in the Selected Preset drop-down list, clicking and confirming Preset Load will then apply all card control settings defined in Preset 3)</li> </ul> <p>The above buttons have a <b>Confirm?</b> pop-up that appears, requesting confirmation.</p> <p><b>Note:</b> Applying a change to a preset using the buttons described above <b>rewrites</b> the previous preset contents with the invoked contents. Make certain change is desired before confirming preset change.</p>
<p>• <b>Selected Preset</b></p> 	<p><b>Selected Preset 1</b> thru <b>Selected Preset 16</b> range in drop-down list selects one of 16 stored presets as ready for <b>Save</b> (being written to) or for <b>Load</b> (being applied to the card).</p> <p><b>Note:</b> The preset names shown to the left are the default (unnamed) preset names. All 16 presets in this case are loaded identically with the factory default settings.</p>
<p>• <b>Card Name</b></p> 	<p>Text entry field provides for optional entry of card name, function, etc. (as shown in this example).</p> <p><b>Note:</b> Card name can be 31 ASCII characters maximum.</p>

Table 3-2 9083 Function Submenu List — continued

Presets	(continued)														
<p>• <b>Preset Name</b></p> <p>Preset Name <input type="text" value="FactPre"/></p>	<p>With one of 16 presets selected, provides for entry of custom name for the preset (as shown in example below).</p> <div data-bbox="771 451 1063 556"> <p>Selected Preset <input type="text" value="2.RCVR21"/></p> <p>Preset Name <input type="text" value="RCVR21"/></p> </div> <p>Entering text in Preset Name field (in this example, "RCVR21") applies custom name to selected Preset (in this example, Preset 2)</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• Preset name can be seven ASCII characters maximum.</li> <li>• The Preset ID number does not need to be entered; it is added automatically.</li> </ul>														
<p>• <b>Reset Current Preset</b></p> <p>Reset Current Preset <input type="button" value="Confirm"/></p>	<p>• <b>Reset Current Preset</b> resets all parameters (including preset custom name entered) of the currently selected Preset (as displayed in the <b>Selected Preset</b> field) to factory default settings.</p> <p>The above button has a <b>Confirm?</b> pop-up that appears, requesting confirmation.</p> <p>The factory default settings are as follows:</p> <table border="1"> <thead> <tr> <th>Function</th><th>Parameter/Setting</th></tr> </thead> <tbody> <tr> <td>Audio Mapping</td><td>Audio mapping reset for simultaneous embedding and de-embedding: <ul style="list-style-type: none"> <li>• Discrete AES input channels 1-16 are mapped to embedded audio output channels 1-16.</li> <li>• Embedded audio input channels 1-16 are mapped to discrete AES output channels 1-16.</li> </ul> </td></tr> <tr> <td>Audio Input Controls</td><td><b>AES SRC, Passthrough, and Zero Delay Embedding</b> are all disabled.</td></tr> <tr> <td>Audio controls (all audio functions)</td><td>All <b>Gain</b> and <b>Phase</b> (polarity) controls are set to unity and normal, respectively.</td></tr> <tr> <td>Video Proc</td><td>All parameters set to unity/null settings.</td></tr> <tr> <td>Framesync</td><td><b>Framesync</b> is disabled; Reference 1 or 2 must be selected to enable the frame sync.</td></tr> <tr> <td>Audio Mixing Up Mixer Selection (Licensable Feature activated only)</td><td>Upmixer set to Always Enabled, with upmix function using embedded channels 1 thru 6. <ul style="list-style-type: none"> <li>• Center width set to 0%.</li> <li>• Surround Depth set to 100%.</li> <li>• 5.1 Detection Threshold set to -150 dB.</li> </ul> </td></tr> </tbody> </table>	Function	Parameter/Setting	Audio Mapping	Audio mapping reset for simultaneous embedding and de-embedding: <ul style="list-style-type: none"> <li>• Discrete AES input channels 1-16 are mapped to embedded audio output channels 1-16.</li> <li>• Embedded audio input channels 1-16 are mapped to discrete AES output channels 1-16.</li> </ul>	Audio Input Controls	<b>AES SRC, Passthrough, and Zero Delay Embedding</b> are all disabled.	Audio controls (all audio functions)	All <b>Gain</b> and <b>Phase</b> (polarity) controls are set to unity and normal, respectively.	Video Proc	All parameters set to unity/null settings.	Framesync	<b>Framesync</b> is disabled; Reference 1 or 2 must be selected to enable the frame sync.	Audio Mixing Up Mixer Selection (Licensable Feature activated only)	Upmixer set to Always Enabled, with upmix function using embedded channels 1 thru 6. <ul style="list-style-type: none"> <li>• Center width set to 0%.</li> <li>• Surround Depth set to 100%.</li> <li>• 5.1 Detection Threshold set to -150 dB.</li> </ul>
Function	Parameter/Setting														
Audio Mapping	Audio mapping reset for simultaneous embedding and de-embedding: <ul style="list-style-type: none"> <li>• Discrete AES input channels 1-16 are mapped to embedded audio output channels 1-16.</li> <li>• Embedded audio input channels 1-16 are mapped to discrete AES output channels 1-16.</li> </ul>														
Audio Input Controls	<b>AES SRC, Passthrough, and Zero Delay Embedding</b> are all disabled.														
Audio controls (all audio functions)	All <b>Gain</b> and <b>Phase</b> (polarity) controls are set to unity and normal, respectively.														
Video Proc	All parameters set to unity/null settings.														
Framesync	<b>Framesync</b> is disabled; Reference 1 or 2 must be selected to enable the frame sync.														
Audio Mixing Up Mixer Selection (Licensable Feature activated only)	Upmixer set to Always Enabled, with upmix function using embedded channels 1 thru 6. <ul style="list-style-type: none"> <li>• Center width set to 0%.</li> <li>• Surround Depth set to 100%.</li> <li>• 5.1 Detection Threshold set to -150 dB.</li> </ul>														
<p>• <b>Download Presets</b></p> <p>Download Presets <input type="text" value="CDI- ---- Presets.bin"/> <input type="button" value="Save"/></p>	<p>Download Presets allows all 16 presets to be stored to a specified location on a network computer for use with other same-model COMPASS™ cards.</p> <p>Refer to Cobalt® reference guide "Remote Control User Guide" (PN 9000RCS-RM) for instructions on using the Download Presets function.</p>														

## Audio Routing Example Using DashBoard™

Figure 3-9 shows an example of using the 9083 Embedded Audio Group and AES Output Pairs functions to de-embed audio, route the audio to discrete outputs for post-production processing, and finally re-embed the audio into the SDI video output. Additionally, the example shows how external analog and internal tone generator sources can be embedded into the SDI output.

Note that the source and destination correlations shown here are only examples; **any** source can route to **any** destination.




Figure 3-9 Audio Routing Example (Sheet 1 of 3)

In the example here, Embedded Channels 1 thru 5 are de-embedded from the input SDI data and routed to discrete AES channels 1 thru 5. Also, an internal tone generator (TG1) and two analog inputs are routed to AES channels 6 thru 8, respectively. Figure 3-9 (sheet 2) shows the 9083 control settings (in this example, using the DashBoard™ user interface) that result in this routing.


**AES Audio Out Pairs 1-4**

Destination	AES Ch 1	AES Ch 2	AES Ch 3	AES Ch 4
Source	Embed Ch 1	Embed Ch 2	Embed Ch 3	Embed Ch 4
Gain (dB)	40.0 0.0 -40.0 -80.0 0.0	40.0 0.0 -40.0 -80.0 0.0	40.0 0.0 -40.0 -80.0 0.0	40.0 0.0 -40.0 -80.0 0.0
Channel is	Unmuted	Unmuted	Unmuted	Unmuted
Phase	Normal	Normal	Normal	Normal

Destination	AES Ch 5	AES Ch 6	AES Ch 7	AES Ch 8
Source	Embed Ch 5	Tone 1	Analog Ch 1	AES Ch 2
Gain (dB)	40.0 0.0 -40.0 -80.0 0.0	40.0 0.0 -40.0 -80.0 -6.0	40.0 0.0 -40.0 -80.0 10.0	40.0 0.0 -40.0 -80.0 10.0
Channel is	Unmuted	Unmuted	Unmuted	Unmuted
Phase	Normal	Normal	Normal	Normal

AUD\_ROUTE\_EX1\_V4.PNG



Using the **AES Audio Out Pairs 1-4** function, the **Source** selections shown above route the selected sources to discrete AES channels 1 through 8. These discrete outputs are then available on the 9083 card Rear I/O Module **AES OUT 1** thru **AES OUT 4** BNC connectors.

**Figure 3-9 Audio Routing Example (Sheet 2 of 3)**

The discrete AES audio on AES channels 9 thru 16 is now re-embedded using the 9083 control settings shown in Figure 3-9 (sheet 3).





Figure 3-9 Audio Routing Example (Sheet 3 of 3)

## Dolby® E Processing and Routing Example (9083-DEC only)

Figure 3-10 shows an example of using the 9083-DEC **Audio Input Controls**, **Dolby Decoder**, and **Embedded Audio Group 1/2** functions to decode a received Dolby® E encoded pair and route the decoded channels. The example also shows routing the metadata to the 9083-DEC **DOLBY META** output.

Note that the source and destination correlations shown here are only examples; **any** embedded channel pair carrying encoded Dolby® data can be decoded. Decoded Dolby® channels can in turn be routed route to **any** embedded channel destination.





**Figure 3-10 Dolby® E Processing Example (Sheet 1 of 2)**

In the example here, Dolby® E 5.1+2 data on embedded pair 7/8 is to be decoded and embedded (using spare embedded channels 9 thru 16) along with the existing embedded audio channels (embedded channels 1 thru 6). Figure 3-10, sheet 2 shows the 9083-DEC control settings (using DashBoard™) that result in this routing.




Using the Status display in the **Audio Input Controls** function, embedded channel pair 7+8 shows Dolby® E data.



Embedded pair 7+8 can then be selected as the **Dolby Decoder** Input Select source. The Bitstream Format and Dolby E Program Configuration displays also show this signal as Dolby® E; 5.1+2

**Metadata Embedding = On** allows decoder metadata embedding into the SDI stream (on line 13 as shown).

**Metadata Output Source** can be set to **Embedded: Dolby Decoder, RS485: Dolby Decoder** to select the decoder metadata as the source for embedded and RS485 metadata.



In this example, since the decoder displays a "5.1+2" configuration, the eight channels comprising this configuration can be embedded using eight spare embedded channels.

As such, the eight total decoded channels produced (Dolby Ch 1 thru Dolby Ch 6, and Dolby Mix 1 / Dolby Mix 2 corresponding to L, R, C, LFE, LS, RS, and Lo/Ro monitors) can be respectively routed to embedded channels 9 thru 16 as shown to the left using the **Embedded Audio Group 3/4** function.

(Note that decoder channels 7 and 8 are not used in this format.)

**Figure 3-10 Dolby® E Processing Example (Sheet 2 of 2)**

---

## Troubleshooting

This section provides general troubleshooting information and specific symptom/corrective action for the 9083 card and its remote control interface. The 9083 card requires no periodic maintenance in its normal operation; if any error indication (as described in this section) occurs, use this section to correct the condition.

### Error and Failure Indicator Overview

The 9083 card itself and its remote control systems all (to varying degrees) provide error and failure indications. Depending on how the 9083 card is being used (i.e, standalone or network controlled through DashBoard™ or a Remote Control Panel), check all available indications in the event of an error or failure condition.


The various 9083 card and remote control error and failure indicators are individually described below.

**Note:** The descriptions below provide general information for the various status and error indicators. For specific failures, also use the appropriate subsection listed below.

- Basic Troubleshooting Checks (p. 3-70)
- 9083 Processing Error Troubleshooting (p. 3-71)
- Troubleshooting Network/Remote Control Errors (p. 3-74)

### 9083 Card Edge Status/Error Indicators and Display






Figure 3-11 shows and describes the 9083 card edge status indicators and display. These indicators and the display show status and error conditions relating to the card itself and remote (network) communications (where applicable). Because these indicators are part of the card itself and require no external interface, the indicators are particularly useful in the event of communications problems with external devices such as network remote control devices.



**Figure 3-11 9083 Card Edge Status Indicators and Display**


## DashBoard™ Status/Error Indicators and Displays

Figure 3-12 shows and describes the DashBoard™ status indicators and displays. These indicator icons and displays show status and error conditions relating to the 9083 card itself and remote (network) communications.

Indicator Icon or Display	Error Description
	<p>Red indicator icon in Card Access/Navigation Tree pane shows card with Error condition (in this example, the Card Access/Navigation Tree pane shows a general error issued by the 9083 card in slot 7).</p> <p>Specific errors are displayed in the Card Info pane (in this example “No connection to device” indicating 9083 card is not connecting to frame/LAN).</p> <p>If the 9083 card is not connecting to the frame or LAN, all controls are grayed-out (as shown in the example here).</p>
	<p>Gray indicator icon in Card Access/Navigation Tree pane shows card(s) are not being seen by DashBoard™ due to lack of connection to frame LAN (in this example, both a 9083 card in slot 7 and the MFC-8310-N Network Controller Card for its frame in slot 0 are not being seen).</p>
	<p>Yellow indicator icon in Card Access/Navigation Tree pane shows card with Alert condition (in this example, the Card Access/Navigation Tree pane shows a general alert issued by the MFC-8310-N Network Controller Card).</p> <p>Clicking the card slot position in the Card Access/Navigation Tree (in this example Network Controller Card “Slot 0: MFC-8310-N”) opens the Card Info pane for the selected card. In this example, a “Fan Door Open” specific error is displayed.</p>
	<p>Yellow indicator icon in 9083 Card Info pane shows error alert, along with cause for alert (in this example, the 9083 is receiving no video input, or a video input that is invalid for the card and/or its current settings).</p>
	<p>Where available, error messages within a function submenu pane show highly specific information relating to detected errors (in this example, message shows an invalid or missing Framesync Enable reference selection).</p>

**Figure 3-12 DashBoard™ Status Indicator Icons and Displays**

Access Card Info panes for specific cards by clicking the card slot position in the Card Access/Navigation Tree pane (as shown in the example in Figure 3-13).



**Figure 3-13 Selecting Specific Cards for Card Info Status Display**

## Basic Troubleshooting Checks

Failures of a general nature (affecting many cards and/or functions simultaneously), or gross inoperability errors are best addressed first by performing basic checks before proceeding further. Table 3-3 provides basic system checks that typically locate the source of most general problems. If required and applicable, perform further troubleshooting in accordance with the other troubleshooting tables in this section.

**Table 3-3 Basic Troubleshooting Checks**

Item	Checks
<b>Verify power presence and characteristics</b>	<ul style="list-style-type: none"> <li>On both the frame Network Controller Card and the 9083, in all cases when power is being properly supplied there is always at least one indicator illuminated. Any card showing no illuminated indicators should be cause for concern.</li> <li>Check the Power Consumed indications for both the +12 V and -7.5 V supply rails for the 9083 card. This can be observed using the DashBoard™ Card Info pane, or using the card edge controls and indicators as shown in Figure 3-7 on page 3-14. <ul style="list-style-type: none"> <li>If either of the rail supplies show <b>no</b> power being consumed, either the frame power supply, connections, or the 9083 card itself is defective.</li> <li>If either of the rail supplies show <b>excessive</b> power being consumed (see Technical Specifications (p. 1-21) in Chapter 1, “Introduction”), the 9083 card may be defective.</li> </ul> </li> </ul>
<b>Check Cable connection secureness and connecting points</b>	Make certain all cable connections are fully secure (including coaxial cable attachment to cable ferrules on BNC connectors). Also, make certain all connecting points are as intended. Make certain the selected connecting points correlate to the intended card inputs and/or outputs. Cabling mistakes are especially easy to make when working with large I/O modules.
<b>Card seating within slots</b>	Make certain all cards are properly seated within its frame slot. (It is best to assure proper seating by ejecting the card and reseating it again.)
<b>Check status indicators and displays</b>	On both DashBoard™ and the 9083 card edge indicators, red indications signify an error condition. If a status indicator signifies an error, proceed to the following tables in this section for further action.
<b>Troubleshoot by substitution</b>	All cards within the frame can be hot-swapped, replacing a suspect card or module with a known-good item.

## 9083 Processing Error Troubleshooting

Table 3-4 provides 9083 processing troubleshooting information. If the 9083 card exhibits any of the symptoms listed in Table 3-4, follow the troubleshooting instructions provided.

In the majority of cases, most errors are caused by simple errors where the 9083 is not appropriately set for the type of signal being received by the card.

**Note:** The error indications shown below are typical for the corresponding error conditions listed. Other error indications not specified here may also be displayed on DashBoard™ and/or the 9083 card edge status indicators.

**Note:** Where errors are displayed on both the 9083 card and network remote controls, the respective indicators and displays are individually described in this section.

**Table 3-4 Troubleshooting Processing Errors by Symptom**





Symptom	Error/Condition	Corrective Action
<ul style="list-style-type: none"> <li><b>DashBoard™</b> shows <b>Video</b> yellow icon and Input Invalid message in 9083 Card Info pane.</li> </ul>  <ul style="list-style-type: none"> <li>Card edge <b>Input Format</b> LEDs show continuous cycling.</li> </ul>	No video input present	Make certain intended video source is connected to appropriate 9083 card video input. Make certain BNC cable connections between frame Rear I/O Module for the card and signal source are OK.
<ul style="list-style-type: none"> <li><b>DashBoard™</b> shows <b>Frame Sync</b> red icon and Reference Invalid message in 9083 Card Info pane.</li> </ul>  <ul style="list-style-type: none"> <li>Card edge red <b>ERR</b> indicator illuminated.</li> </ul>	Frame sync reference not properly selected or not being received	<ul style="list-style-type: none"> <li>If external frame sync reference is not intended to be used, make certain the Framesync Enable selection list is set to <b>Off</b> or <b>Input Video</b> as desired.</li> <li>If external frame sync reference is intended to be used, make certain selected external frame sync reference is active on frame sync frame bus. (External reference signals Reference 1 and Reference 2 are distributed to the 9083 and other cards via a frame bus.)</li> </ul> <p>Refer to <b>Framesync</b> function submenu tab on page 3-23 for more information.</p>

Table 3-4 Troubleshooting Processing Errors by Symptom — continued

Symptom	Error/Condition	Corrective Action
<p><b>DashBoard™</b> shows <b>Framesync Status</b> error message in 9083 Framesync function submenu screen.</p> 	Specified Minimum Latency Frames setting exceeds 9083 card buffer space for the selected output video format	<p>Reduce the Minimum Latency Frames setting as specified in the error message to correct the error.</p> <p><b>Note:</b> Due to card memory limits, the maximum available Minimum Latency Frames is related to the output video format selected. For example, with a 1080i 5994 output, the maximum setting is 5. For a 1080i film (2398) output, the maximum setting is 3 (due to the increased buffer space needed for the slower frame rate). Conversely, greater maximum settings are allowed for SD formats such as 525i 5994, where the practical maximum limit is 13.</p>
Video/audio synchronization or delay noted.	Source synchronization condition	<p>Use the <b>Audio Offset from Video</b> control to compensate for video/audio delay.</p> <p>Refer to <b>Framesync</b> function submenu tab on page 3-23 for more information.</p>
Ancillary data (closed captioning, timecode, Dolby® metadata, AFD) not transferred through 9083.	<ul style="list-style-type: none"> <li>Control(s) not enabled</li> </ul>	<ul style="list-style-type: none"> <li>Make certain respective control is set to <b>On</b> or <b>Enabled</b> (as appropriate).</li> </ul>
	<ul style="list-style-type: none"> <li>VANC line number conflict between two or more ancillary data items</li> </ul>	<ul style="list-style-type: none"> <li>Make certain each ancillary data item to be passed is assigned a unique line number (see Ancillary Data Line Number Locations and Ranges on page 3-15).</li> </ul>
<ul style="list-style-type: none"> <li><b>DashBoard™</b> shows red <b>Audio</b> icon and Analog Input Clipping message in 9083 Card Info pane.</li> </ul>  <ul style="list-style-type: none"> <li>Card edge display shows code E101.</li> </ul>	Analog peak audio input on selected input exceeds +24 dBu level	<p>Reduce analog audio level at the source.</p> <p><b>Note:</b> 9083 audio gain controls cannot be used to correct analog input overload condition. The condition must be corrected at the source.</p>
(9083-DEC only) Dolby® data indicated as <b>Present</b> on Audio Input Controls Status display does not process, or cannot be accessed as an audio source	<ul style="list-style-type: none"> <li><b>Input Select</b> in <b>Dolby Decoder</b> function selection not set for pair carrying locked Dolby® data</li> </ul>	<ul style="list-style-type: none"> <li>Make certain intended channels carrying locked Dolby® data are selected as the input for the Dolby® decoder.</li> </ul>
	<ul style="list-style-type: none"> <li>Upstream metadata not enabled</li> </ul>	<ul style="list-style-type: none"> <li>Check upstream device or system and enable as required.</li> </ul>



**Table 3-4 Troubleshooting Processing Errors by Symptom — continued**

Symptom	Error/Condition	Corrective Action
<p>Audio signal(s) do not route as expected.</p> <p>Parameter control not available as expected.</p>	<ul style="list-style-type: none"> <li>• <b>(9083 only)</b> Embedded or AES audio contains Dolby® E or Dolby Digital encoded signal</li> </ul>	<ul style="list-style-type: none"> <li>• When a valid Dolby® E or Dolby Digital signal (in accordance with SMPTE 337M) is detected on an AES or embedded audio signal, SRC is automatically bypassed (disabled) along with gain and polarity controls being bypassed (even though controls may appear to be functional). Gain and polarity controls are not available for this signal type.</li> </ul> <p>Refer to Status displays in <b>Audio Input Controls</b> function submenu tab on page 3-17 for more information.</p>
	<ul style="list-style-type: none"> <li>• <b>Audio Input Controls</b> AES Passthrough or Zero Delay Embedding mode may inadvertently be enabled</li> </ul>	<ul style="list-style-type: none"> <li>• When either of these modes is enabled, flexible routing and parametric controls are not available. When either of these modes is not intended for use, make sure they are disabled.</li> </ul> <p>Refer to <b>Audio Input Controls</b> function submenu tab on page 3-17 for more information.</p> <p><b>Note:</b> Routing and parametric controls may appear functional when either of these mode are enabled, although the controls will not be functional.</p>
<p>Audio not processed or passed through card.</p>	<ul style="list-style-type: none"> <li>• Input audio of type that cannot be locked by 9083 card</li> </ul>	<ul style="list-style-type: none"> <li>• AES discrete and embedded audio must be nominal 48 kHz input.</li> </ul> <p><b>Note:</b> Although the Status Displays in <b>Audio Input Controls</b> function submenu tab will show audio formats other than “Present, Professional” as being locked (such as “Present, Consumer”), in any case the audio must be at nominal 48 kHz rate for lock and processing to occur.</p>
	<ul style="list-style-type: none"> <li>• Enable control not turned on</li> </ul>	<ul style="list-style-type: none"> <li>• <b>Group Enable</b> button for <b>Embedded Audio Group 1/2</b> or <b>Embedded Audio Group 3/4</b> function submenu must be turned on for sources to be embedded into respective embedded channels.</li> </ul>

**Table 3-4 Troubleshooting Processing Errors by Symptom — continued**

Symptom	Error/Condition	Corrective Action
Audio not processed or passed through card (cont.).	<ul style="list-style-type: none"> <li>Upmixer inadvertently enabled (Upmixer Licensed Feature only)</li> </ul>	<ul style="list-style-type: none"> <li>Make certain upmixer is set to <b>Bypass</b> if not intended for use.</li> </ul> <p><b>Note:</b> When manually enabled or set for automatic enable with appropriate signal levels, upmixer overwrites selected embedded channels with new data; same-channel embedded output will no longer represent same-channel embedded inputs for selected channels.</p>
	<ul style="list-style-type: none"> <li>AES pairs 1 thru 4 switch not set for Input (factory default) mode</li> </ul>	<ul style="list-style-type: none"> <li>If any of <b>AES IN 1</b> thru <b>AES IN 4</b> are to be used as inputs, the respective DIP switch must be set to the default INPUT mode position.</li> </ul> <p>See Setting I/O Switches for AES I/O (1-4) Ports (p. 2-1) in Chapter 2, “Installation and Setup” for more information.</p>

## Troubleshooting Network/Remote Control Errors

Refer to Cobalt® reference guide “Remote Control User Guide” (PN 9000RCS-RM) for network/remote control troubleshooting information.

## In Case of Problems

Should any problem arise with this product that was not solved by the information in this section, please contact the Cobalt Digital Inc. Technical Support Department.

If required, a Return Material Authorization number (RMA) will be issued to you, as well as specific shipping instructions. If required, a temporary replacement item will be made available at a nominal charge. Any shipping costs incurred are the customer’s responsibility. All products shipped to you from Cobalt Digital Inc. will be shipped collect.

The Cobalt Digital Inc. Technical Support Department will continue to provide advice on any product manufactured by Cobalt Digital Inc., beyond the warranty period without charge, for the life of the product.

See Contact Cobalt Digital Inc. (p. 1-26) in Chapter 1, “Introduction” for contact information.





**Cobalt Digital Inc.**

2406 E. University Ave.  
Urbana, IL 61802  
Voice 217.344.1243 • Fax 217.344.1245  
[www.cobaltdigital.com](http://www.cobaltdigital.com)