

TABLE OF CONTENTS

1.	OVERVIEW.....	1
2.	INSTALLATION.....	2
2.1.	7707EO-DS3 CONNECTIONS	2
2.2.	7707EO-E3 CONNECTIONS.....	3
2.3.	CARE AND HANDLING OF OPTICAL FIBER.....	4
2.3.1.	Safety	4
2.3.2.	Assembly.....	4
2.3.3.	Labeling.....	4
2.3.4.	Handling and Connecting Fibers	5
3.	SPECIFICATIONS.....	5
3.1.	ELECTRICAL INPUTS	5
3.2.	ELECTRICAL OUTPUTS	5
3.3.	OPTICAL OUTPUT.....	6
3.4.	ELECTRICAL	6
3.5.	PHYSICAL.....	6
4.	STATUS LED'S	6
5.	JUMPERS AND USER ADJUSTMENTS	7
5.1.	SELECTING WHETHER LOCAL FAULTS WILL BE MONITORED BY THE GLOBAL FRAME STATUS.....	7
5.2.	SELECTING THE INPUT ISOLATION MODE	7
5.3.	SETTING THE TRANSMIT LEVEL	8
5.4.	CONFIGURING THE MODULE FOR FIRMWARE UPGRADES	9
6.	VISTALINK™ REMOTE MONITORING/CONTROL	9
6.1.	WHAT IS VISTALINK™?	9
6.2.	VISTALINK™ MONITORED PARAMETERS	10



6.3. *VistaLINK*[™] CONTROLLED PARAMETERS 10

Figures

Figure 1: 7707EO-DS3 or 7707EO-E3 Block Diagram 1
Figure 2: 7707EO-DS3 Rear Panels 2
Figure 3: 7707EO-E3 Rear Panels 3
Figure 4: Reproduction of Laser Certification and Identification Label 4
Figure 5: Jumper Locations 7
Figure 6: Input Isolation Jumper 8

Tables

Table 1: *VistaLINK*[™] Monitored Parameters 10

REVISION HISTORY

<u>REVISION</u>	<u>DESCRIPTION</u>	<u>DATE</u>
0.1	Preliminary Version	Feb 02
1.0	Added 8 new CWDM wavelengths	Dec 02
1.1	Removed preliminary watermark, minor typos fixed	Oct 03
1.2	Added 7707EO-E3	Jul 04
1.3	Corrected HI/LO Jumper Error	May 05
1.4	Updated safety section and added assembly and labeling sections	Aug 05

Information contained in this manual is believed to be accurate and reliable. However, Evertz assumes no responsibility for the use thereof nor for the rights of third parties, which may be effected in any way by the use thereof. Any representations in this document concerning performance of Evertz products are for informational use only and are not warranties of future performance, either express or implied. The only warranty offered by Evertz in relation to this product is the Evertz standard limited warranty, stated in the sales contract or order confirmation form.

Although every attempt has been made to accurately describe the features, installation and operation of this product in this manual, no warranty is granted nor liability assumed in relation to any errors or omissions unless specifically undertaken in the Evertz sales contract or order confirmation. Information contained in this manual is periodically updated and changes will be incorporated into subsequent editions. If you encounter an error, please notify Evertz Customer Service department. Evertz reserves the right, without notice or liability, to make changes in equipment design or specifications.



Never look directly into an optical fiber. Non-reversible damage to the eye can occur in a matter of milliseconds.



Do not hook up the 7707EO-DS3 or 7707EO-E3 DWDM cards directly with a short fiber optic cable. The 7707EO-DS3 and 7707EO-E3 DWDM cards produce +7dBm of power which will damage the receiver if connected directly.

1. OVERVIEW

The 7707EO-DS3 and 7707EO-E3 are *VistaLINK™* enabled, electrical to optical converter for DS3 (44.736 Mb/s) and E3 (34.368Mb/s) signals. Monitoring and control of card status and parameters is provided locally at the card edge, and remotely via *VistaLINK™* capability. The 7707EO-DS3 and 7707EO-E3 provides automatic coaxial cable equalization, reclocking and optical conversion to an assortment of optical wavelengths, accommodating standard, or CWDM transmission schemes. The 7707EO-DS3 & 7707EO-E3 accepts a B3ZS-encoded Alternate Mark Inversion (AMI) input signal and provides two reclocked G.703 compliant output signals, and one scrambled optical output signal.

Both the 7707EO-DS3 and 7707EO-E3 occupies one card slot and can be housed in either a 1RU frame that will hold up to three modules or a 3 RU frame that will hold up to 15 modules.

Features:

- Automatic cable equalization for up to 1000ft of high quality 75 Ohm cable
- Signal reclocking
- Output wave shaping for G.703 standards compliance
- Loss of signal (LOS) detection/indication (ANSI T1.231-1999 and ITU G.775)
- Electrical output drive level control for enhanced distance
- Transformer coupled inputs/outputs
- Optical output wavelengths of 1310nm, 1550nm, and up to sixteen CWDM wavelengths (ITU-T G.694.2) from 1270nm to 1610nm.
- DWDM wavelengths (ITU-T G.694.1 compliant) also available
- Supports multi-mode and single-mode fiber.
- Fully hot swappable from front of frame.
- *VistaLINK™* enabled for remote monitoring and control when installed in 7700FR-C frame with 7700FC Frame Controller




Figure 1: 7707EO-DS3 or 7707EO-E3 Block Diagram

2. INSTALLATION

The 7707EO-DS3 and 7707EO-E3 come with a companion rear plate that has 3 BNC connectors. For information on mounting the rear plate and inserting the module into the frame see the 7700FR chapter section 3.

2.1. 7707EO-DS3 CONNECTIONS




Figure 2: 7707EO-DS3 Rear Panels

INPUT Isolated input BNC for DS3 (44.736 Mb/s) signals. This input is also transformer coupled to meet G.703 requirements. A jumper is available on the main board, to allow the isolated BNC shield to be connected to DC ground or AC ground.

OUTPUT There are two BNC connectors with transformer coupled, reclocked outputs. The output drive levels for each output are independently jumper selectable for driving different cable lengths.

There is one SC/PC (shown), ST/PC or FC/PC female connector with the DS3 output converted to a scrambled optical signal as specified in section 3.3

2.2. 7707EO-E3 CONNECTIONS




Figure 3: 7707EO-E3 Rear Panels

INPUT Isolated input BNC for E3 (34.368Mb/s) signals. This input is also transformer coupled to meet G.703 requirements. A jumper is available on the main board, to allow the isolated BNC shield to be connected to DC ground or AC ground.

OUTPUT There are two BNC connectors with transformer coupled, reclocked outputs. The output drive levels for each output are independently jumper selectable for driving different cable lengths.

There is one SC/PC (shown), ST/PC or FC/PC female connector with the E3 output converted to a scrambled optical signal as specified in section 3.3

2.3. CARE AND HANDLING OF OPTICAL FIBER

2.3.1. Safety



Background colour: yellow
Triangular band: black
Symbol: black

CLASS 1 LASER PRODUCT

2.3.2. Assembly

Assembly or repair of the laser sub-module is done only at Evertz facility and performed only by qualified Evertz technical personnel.

2.3.3. Labeling

Certification and Identification labels are combined into one label. As there is no enough room on the product to place the label it is reproduced here in the manuals.

- There is no date of manufacture on this label as it can be traced by bar code label placed on the Printed circuit board of each Evertz plug-in module
- The Model number is one of: 7707EO13-DS3, 7707EO15-DS3, 7707EO13-E3
- 7707EOxx-DS3, 7707EOxx-E3 (xx = 27, 29, 31, 33, 35, 37, 43, 45, 47, 49, 51, 53, 55, 57, 59, 61)
7707EODyyy-DS3, 7707EODyyy-E3 (Dyyy represents ITU Grid Channel: D200, D210, D220, D230, D240, D250, D260, D270, D280, D290, D300, D310, D320, D330, D340, D350, D360, D370, D380, D390, D400, D410, D420, D430, D440, D450, D460, D470, D480, D490, D500, D510, D520, D530, D540, D550, D570, D580, D590, D600)




Figure 4: Reproduction of Laser Certification and Identification Label

2.3.4. Handling and Connecting Fibers



Never touch the end face of an optical fiber. Always keep dust caps on optical fiber connectors when not connected and always remember to properly clean the optical end face of a connector before making a connection.

The transmission characteristics of the fiber are dependent on the shape of the optical core and therefore care must be taken to prevent fiber damage due to heavy objects or abrupt fiber bending. Evertz recommends that you maintain a minimum bending radius of 5 cm to avoid fiber-bending loss that will decrease the maximum attainable distance of the fiber cable. The Evertz fiber optic modules come with cable lockout devices, to prevent the user from damaging the fiber by installing a module into a slot in the frame that does not have a suitable I/O module. For further information about care and handling of fiber optic cable see section 3 of the Fiber Optics System Design section of this manual binder.

3. SPECIFICATIONS

3.1. ELECTRICAL INPUTS

Standards:

7707EO-DS3 G.703 @ 44.736 Mb/s

7707EO-E3 G.703 @ 34.368 Mb/s

Connector: 1 BNC per IEC 60169-8 Amendment 2

Equalization: Automatic 300m with Belden 8281 or equivalent cable

Return Loss: > 20 dB up to 44 Mb/s

3.2. ELECTRICAL OUTPUTS

Standards:

7707EO-DS3 G.703 @ 44.736 Mb/s

7707EO-E3 G.703 @ 34.368 Mb/s

Number of Outputs: 2 Per Card-Reclocked.

Connector: BNC per IEC 60169-8 Amendment 2

Waveform: conforms to G.703 compliant masks

Return Loss: > 15 dB up to 44.736 Mb/s

Drive Level:

High: For driving cable lengths > 225 feet

Low: For driving cable lengths < 225 feet

3.3. OPTICAL OUTPUT

Standards:

7707EO-DS3 Scrambled DS3 @ 44.736Mb/s

7707EO-E3 Scrambled DS3 @ 34.368Mb/s

Number of Outputs: 1

Connector: Female SC/PC, ST/PC or FC/PC

Return Loss: > 14 dB

Fiber Size: 9 μ m core / 125 μ m overall

Wavelengths:

Standard 1310nm, 1550nm (nominal)

CWDM: 1270nm to 1610nm (See ordering information).

Output Power: -7dBm $\pm$ 1dB (1310nm FP laser types)
0dBm $\pm$ 1dB (1550 and CWDM DFB laser types)

3.4. ELECTRICAL

Voltage: + 12VDC

Power: 6 Watts.

EMI/RFI: Complies with FCC regulations for class A devices.
Complies with EU EMC directive.

3.5. PHYSICAL

7700 or 7701 frame mounting:

Number of slots: 1

4. STATUS LED'S

MODULE OK This Green LED will be On when the module is operating properly

LOCAL FAULT This Red LED will be On when the Signal Valid is Off, or Output Fault On or when there is a fault in the module power supply.

SIGNAL VALID This Green LED will be On when the input signal satisfies amplitude requirements.

OUTPUT FAULT This Red LED will be On when an electrical or optical output fault or coaxial output connection error exists.

5. JUMPERS AND USER ADJUSTMENTS




Figure 5: Jumper Locations

5.1. SELECTING WHETHER LOCAL FAULTS WILL BE MONITORED BY THE GLOBAL FRAME STATUS

The FRAME STATUS jumper J7, located at the top front of the module determines whether local faults (as shown by the Local Fault indicator) will be connected to the 7700FR frame's global status bus.

FRAME STATUS To monitor faults on this module with the frame status indicators (on the Power Supply FRAME STATUS LED's and on the Frame's Fault Tally output) install this jumper in the On position (default). When this jumper is installed in the Off position local faults on this module will not be monitored.

5.2. SELECTING THE INPUT ISOLATION MODE

The COUPLING jumper J30, located at the rear of the module beside the input BNC, is a two position jumper that sets whether the shield of the input BNC connector will be AC or DC coupled to ground. Figure 6 shows a schematic of the input configuration.

COUPLING When set to the **GND** position, the shield of the input BNC will be connected directly to the logic ground of the module.

When set to the **FLOAT** position, the shield of the input BNC will be AC coupled to the logic ground of the module.




Figure 6: Input Isolation Jumper

5.3. SETTING THE TRANSMIT LEVEL

The two LEVEL jumpers, J17 and 19, located at the rear of the module beside the four output BNCs, set the transmit level for the signal on the adjacent BNC output connector.

LEVEL When the cable length connected to the output is less than 225 feet (68.5 meters) set the jumper to the **LOW** position in order to meet the DSX-3 pulse specification.

When the cable length connected to the output is greater than 225 feet (68.5 meters) set the jumper to the **HIGH** position in order to meet the DSX-3 pulse specification.

5.4. CONFIGURING THE MODULE FOR FIRMWARE UPGRADES

UPGRADE The UPGRADE jumper is used when firmware upgrades are being done to the module. For normal operation it should be installed in the *RUN* position (see NOTE 1). See the *Upgrading Firmware* section of this manual for more information.

To upgrade the firmware in the module unit pull it out of the frame. Move the UPGRADE jumper into the *UPGRADE* position. Install the Upgrade cable provided (located in the vinyl pouch in the front of this manual) onto SERIAL header at the card edge. Re-install the module into the frame. Run the upgrade as described in the *Upgrading Firmware* section of this manual. Once the upgrade is completed, remove the module from the frame, move the UPGRADE jumper into the *RUN* position, remove the upgrade cable and re-install the module. The module is now ready for normal operation.

6. VISTALINK™ REMOTE MONITORING/CONTROL

6.1. WHAT IS VISTALINK™?

VistaLINK™ is Evertz's remote monitoring and control capability over an Ethernet network using Simple Network Management Protocol (SNMP). SNMP is a standard computer network protocol that enables different devices sharing the same network to communicate with each other. For monitoring there needs to be a detecting device that automatically reports all errors to a central alarm and error logging station. We also need to be able to interrogate individual detector devices from the central station to determine the status of individual channels. Finally, we need to be able to configure devices in the network from the central station and receive feedback that the configuration has been carried out.

There are 3 components of SNMP:

1. An SNMP manager also known as a Network Management System (NMS) is a computer running special software that communicates with the devices in the network. Evertz VL-Fiber demo Manager graphical user interface (GUI), third party or custom manager software may be used to monitor and control Evertz VistaLINK™ enabled fiber optic products.
2. Managed devices (such as 7707EO and 7707OE cards), each with a unique address (OID), communicate with the NMS through an SNMP Agent. Evertz VistaLINK™ enabled 7700 series modules reside in the 3RU 7700FR-C MultiFrame and communicate with the manager via the 7700FC VistaLINK™ frame controller module, which serves as the Agent.
3. A virtual database known as the Management information Base (MIB) lists all the variables being monitored and which both the Manager and Agent understand. Please contact Evertz for further information about obtaining a copy of the MIB for interfacing to a third party Manager/NMS.

For more information on connecting and configuring the VistaLINK™ network, see the 7700FC Frame Controller chapter.

6.2. VISTALINK™ MONITORED PARAMETERS

The following parameters can be remotely monitored through the VistaLINK™ interface.

Parameter	Description
Signal Valid	Indicates the presence of a valid input signal. (the state of the SIGNAL VALID LED)
Output Fault	Indicates the presence of an output fault condition. (the state of the OUTPUT FAULT LED)

Table 1: VistaLINK™ Monitored Parameters

6.3. VISTALINK™ CONTROLLED PARAMETERS

There are no VistaLINK™ controlled parameters.