

TABLE OF CONTENTS

1. OVERVIEW	1
2. INSTALLATION.....	3
2.1. VIDEO INPUTS AND OUTPUTS.....	4
2.2. TERMINAL STRIP INPUTS	4
2.2.1. RS232 Data Ports.....	5
2.2.2. RS422 Data Ports.....	5
2.2.3. General Purpose Inputs.....	5
3. SPECIFICATIONS.....	6
3.1. SERIAL VIDEO INPUT	6
3.2. SERIAL VIDEO OUTPUTS WITH EMBEDDED DATA.....	6
3.3. DATA INPUT.....	6
3.4. GENERAL PURPOSE INPUTS.....	6
3.5. TIME CODE (+GPI OPTION ONLY)	6
3.5.1. Ancillary Time Code Generator/Reader (ATC) - HD Video Standards Only	6
3.5.2. Vertical Interval Time Code Generator/Reader (VITC) - SD Video Standards Only	7
3.6. EMBEDDING DELAY	7
3.6.1. Video I/O Delay	7
3.6.2. Data Embedding Delay – Serial Ports.....	7
3.6.3. Delay For Data Embedding - GPI Signals.....	7
3.6.4. Delay For Time Code Embedding - GPI Signals (+GPI Option Only).....	7
3.7. ELECTRICAL.....	7
3.8. PHYSICAL	7
4. STATUS INDICATORS.....	8
4.1. MODULE STATUS LEDS	8
4.2. AUDIO/DATA GROUP STATUS LEDS.....	8
5. CARD EDGE MENU SYSTEM.....	9
5.1. NAVIGATING THE MENU SYSTEM	9
5.2. TOP LEVEL MENU STRUCTURE	9
5.3. ACTIVE FORMAT DESCRIPTOR (AFD) CONTROL	11
5.3.1. Configuring AFD Embedding Mode	12
5.3.2. Configuring the AFD Line Number.....	12
5.3.3. Configuring Dynamic GPI Control.....	12
5.3.4. Configuring the AFD Insertion Code	13
5.3.5. Configuring the Aspect Ratio of the AFD Code.....	15

5.3.6. Configuring the Bar Type For Bar Data	15
5.3.7. Configuring the Size of the First Bar	15
5.3.8. Configuring the Size of the Second Bar	15
5.3.9. Configuring the GPI Active Condition	15
5.4. EMBEDDED LTC GPI CONTROL	16
5.5. EMBEDDED VITC GPI CONTROL	16
5.6. FACTORY RESET CONTROL	16
5.7. CARD-EDGE DISPLAY CONTROL	16
5.8. LOSS OF VIDEO MODE CONTROL	16
5.9. AUDIO BIT ENCODING CONTROL	17
5.10. VITC LOSS FRAME DURATION	17
5.11. RP188 TIME CODE CONTROL	17
5.12. GPI USER BIT REMOTE CONTROL OPTION (+GPI OPTION)	17
5.12.1. Configuring the GPI Delay	19
5.12.2. Setting the VITC Generator Lines	19
5.12.2.1. Setting the First Line to Generate VITC	19
5.12.2.2. Setting the Second Line to Generate VITC	20
5.12.3. Setting the VITC Reader Lines	20
5.12.3.1. Setting the Start Line of the VITC Reader Range	20
5.12.3.2. Setting the End of the VITC range	20
5.13. SETTING THE INPUT VIDEO STANDARD	21
5.14. ENABLING THE DATA EMBEDDER	21
5.15. SETTING THE HANDLING OF INCOMING HANC DATA	21
5.16. CONFIGURING THE SERIAL PORTS	21
5.16.1. Configuring the Baud Rate of Port 1	22
5.16.2. Configuring the Stop Bits of Port 1	23
5.16.3. Configuring the Parity Setting of Port 1	23
5.16.4. Configuring the Data Length of Port 1	23
5.16.5. Configuring the Loopback Status of the UART for Port 1	23
5.16.6. Configuring the Status of the UART for the Transmit Port 1	23
5.16.7. Setting the Audio Group to Embed for Port 1	23
5.16.8. Setting the Audio Channel to Embed for Port 1	24
6. JUMPERS AND USER ADJUSTMENTS	25
6.1. SELECTING WHETHER LOCAL FAULTS WILL BE MONITORED BY THE GLOBAL FRAME STATUS	25
6.2. SETTING THE BYPASS RELAY JUMPER	26
6.3. SELECTING THE DATA COMMUNICATIONS STANDARD (RS-232 OR RS-422)	26
6.3.1. Configuring RS422 Device Communication between a Controller and Tributary	26
6.4. SELECTING THE DEFAULT BEHAVIOUR OF THE SERIAL PORT INPUTS WHEN THERE IS NO SIGNAL CONNECTED	27
6.5. SETTING THE GPI INPUT PULLUP VOLTAGE	27

6.6. CONFIGURING THE MODULE FOR FIRMWARE UPGRADES.....	27
7. VISTALINK [®] REMOTE MONITORING/CONTROL.....	29
7.1. WHAT IS VISTALINK [®] ?.....	29
7.2. MISC CONTROL TAB	30
7.2.1. HANC Control.....	30
7.2.2. Detected Video Standard.....	30
7.2.3. Video Standard.....	31
7.2.4. Embedder Enable.....	31
7.2.5. CardType.....	31
7.2.6. Bits Encoding.....	31
7.2.7. Factory Reset	32
7.2.8. Embedded VITC GPI Option (+GPI Only).....	32
7.2.9. Embedded LTC GPI Option (HD Formats Only)	32
7.2.10. RP188 (HD formats only).....	32
7.2.11. Serial Embedder Mode (+VANC only)	33
7.3. PORT CONTROL.....	33
7.3.1. Baud Rate.....	34
7.3.2. Stop Bits	34
7.3.3. Parity	34
7.3.4. Data Bits.....	34
7.3.5. Loop Back	35
7.3.6. Uart Enable.....	35
7.3.7. Audio Group	35
7.3.8. Audio Channel	35
7.4. VITC CONTROL (SD, +GPI OPTION ONLY).....	36
7.4.1. VITC Reader Start Line	36
7.4.2. VITC Reader End Line.....	36
7.4.3. VITC Generator Line 1.....	37
7.4.4. VITC Generator Line 2.....	37
7.4.5. Loss of VITC Duration	37
7.4.6. VITC Use Incoming Line.....	37
7.5. VITC CONTROL (HD, +GPI OPTION ONLY)	38
7.5.1. VITC GPI Delay	38
7.5.2. Loss of VITC Duration	38
7.6. USER VANC DATA (+VANC OPTION ONLY).....	39
7.6.1. DID	39
7.6.2. SDID.....	39
7.6.3. Line Select.....	40
7.6.4. Trigger Number	40
7.6.5. Cue, Fade In, Out	40
7.6.6. Baud Rate.....	40
7.6.7. Parity	41
7.6.8. Stop Bits	41
7.6.9. Data Bits.....	41
7.7. LATCHING GPI (+GPI OPTION ONLY).....	42
7.7.1. Latching.....	42
7.7.2. Set.....	42

7.7.3. Clear	42
7.8. SCTE 104 SETTINGS (+SCTE104 OPTION ONLY).....	43
7.8.1. GPI Mode	43
7.8.2. Upstream Pass Mode	43
7.8.3. Upstream Line Remap.....	43
7.8.4. GPI Triggering	44
7.8.5. DPI Filter	44
7.8.6. Line Select.....	44
7.8.7. Manual DPI Insert.....	44
7.8.8. Last Insertion Trigger.....	45
7.8.9. Custom DID/SDID Mode.....	45
7.8.9.1. DID.....	45
7.8.9.2. SDID	45
7.8.10. GPI SCTE 104 Selection	47
7.8.11. GPI Triggering	47
7.8.12. Multiple Operation Message	48
7.8.13. Insert DTMF Descriptor Request Data.....	50
7.8.14. Splice Request Data.....	51
7.8.15. Insert Segmentation Descriptor Request Data.....	53
7.8.16. Time Signal Request	55
7.8.17. Insert Tier Data Request	56
7.8.18. Splice Null Request	56
7.8.19. Follow Me	56
7.9. AFD CONTROL	57
7.9.1. AFD Embed Mode	58
7.9.2. AFD Embed Line	58
7.9.3. Aspect Ratio	58
7.9.4. AFD Code.....	59
7.9.5. AFD Bar Setting.....	61
7.9.6. AFD Bar Size 1	61
7.9.7. AFD Bar Size 2.....	61
7.9.8. GPI Mode	61
7.9.9. AFD Reserved Data Word.....	62
7.9.9.1. Enabling	62
7.9.9.2. Reserved Data Word.....	62
7.9.10. AFD Upstream Code Swap.....	62
7.9.10.1. Enabling	62
7.9.10.2. Reserved Data Word.....	62
7.10. FAULT TRAPS.....	63

Figures

Figure 1-1: 7721DE4-HD-HD Block Diagram	2
Figure 2-1: 7721DE4-HD Rear Panel.....	3
Figure 5-1: AFD Control Codes	14
Figure 6-1: Location of Jumpers (Rev 1 Submodule).....	25
Figure 6-2: Location of Jumpers (Rev A Submodule)	25
Figure 6-3: SMPTE 207M RS422 Controller/Tributary Wiring.....	26
Figure 6-4: Receiver Input Pull-up Configuration	27
Figure 7-1: VistaLINK [®] 7721DE4-HD Misc Control View	30
Figure 7-2: VistaLINK [®] 7721DE4-HD Port Control View	33

Figure 7-3: VistaLINK [®] 7721DE4-HD+GPI VITC Control (SD) View	36
Figure 7-4: VistaLINK [®] 7721DE4-HD+GPI VITC Control (HD) View	38
Figure 7-5: VistaLINK [®] 7721DE4-HD+VANC User VANC Data View	39
Figure 7-6: VistaLINK [®] 7721DE4-HD+GPI Latching GPI View	42
Figure 7-7: VistaLINK [®] 7721DE4-HD+SCTE104 Configuration View	43
Figure 7-8: VistaLINK [®] 7721DE4-HD+SCTE104 Configuration View Continued	46
Figure 7-9: VistaLINK [®] 7721DE4-HD AFD Control View	57
Figure 7-10: AFD Control Codes	60
Figure 7-11: VistaLINK [®] 7721DE4-HD Upstream AFD Code Swap Settings	62
Figure 7-12: VistaLINK [®] 7721DE4-HD Fault Trap View	63

Tables

Table 2-1: RX DATA Terminal Block Input	4
Table 4-1: Data Status LEDs	8
Table 5-1: Top End Menu Structure	10
Table 5-2: AFD Menu Control	11
Table 5-3: GPI I/O Mapping (+GPI option installed)	19
Table 5-4: Port Menu Structure	22
Table 7-1: SCTE 104 Multiple Operation Parameters	49
Table 7-2: Insert DTMF Descriptor Request Data Parameters	50
Table 7-3: Splice Data Request Parameters	52
Table 7-4: Insert Segmentation Descriptor Request Data Parameters	54
Table 7-5: Time Signal Request Parameters	55
Table 7-6: Insert Tier Data Request Parameters	56
Table 7-7: Splice Null Request Parameters	56

REVISION HISTORY

<u>REVISION</u>	<u>DESCRIPTION</u>	<u>DATE</u>
1.0	Preliminary Version	Jun 2004
1.1	First Release	Nov 2004
1.2	Manual Corrections	Feb 2005
1.3	Added VID option to menu section	March 2005
1.4	Changes to RS232 and RS422 configurations	April 2005
1.5	Added +GPI option feature to the manual	Jan 2006
1.6	Added SCTE 104 VistaLINK® controlled parameters	Oct 2008
1.7	Added AFD and other new menu features	Apr 2009
1.8	Added note regarding Dynamic GPI Control in section 5.3.3 Removed incorrect AFD Code selection in section 5.3.4	June 2009
2.0	Added +VANC functionality and expanded VLPro section Firmware version 4.4 build 674; VLPro Product Version 130	Sept 2010
2.1	Added new SCTE104 and VANC functionality Firmware version 4.9 build 7; VLPro Product Version 142	Oct 2011
2.2	Updated SCTE 104 information	Jun 2014

Information contained in this manual is believed to be accurate and reliable. However, Evertz assumes no responsibility for the use thereof nor for the rights of third parties, which may be affected in any way by the use thereof. Any representations in this document concerning performance of Evertz products are for informational use only and are not warranties of future performance, either expressed or implied. The only warranty offered by Evertz in relation to this product is the Evertz standard limited warranty, stated in the sales contract or order confirmation form.

Although every attempt has been made to accurately describe the features, installation and operation of this product in this manual, no warranty is granted nor liability assumed in relation to any errors or omissions unless specifically undertaken in the Evertz sales contract or order confirmation. Information contained in this manual is periodically updated and changes will be incorporated into subsequent editions. If you encounter an error, please notify Evertz Customer Service department. Evertz reserves the right, without notice or liability, to make changes in equipment design or specifications.

1. OVERVIEW

The 7721DE4-HD Quad Serial data embedder inserts 4 x RS-232 or RS-422 serial data streams and GPI contact closure information into a 270 Mb/s SD-SDI or 1.5Gb/s HD-SDI video signal. The RS-232/422 serial data and GPI information are first formatted into an AES audio signal, then embedded into the video stream according to SMPTE 272M-A for SD-SDI and SMPTE 292M for HD-SDI. A data error detection and correction scheme is also applied to maintain data integrity for the data de-embedder at the receiver end. At the embedded packet layer, data packets resemble and have the same group DIDs as embedded audio packets. The data is packetized and inserted into the AES sub-frame according to SMPTE 337M.

The 7721DE4-HD module also has the ability to insert Active Format Descriptor (AFD) packets into the VANC of the output video. This can be done in a static, pass-through check, or GPI controlled method or combination of these.

Adding the +GPI option to the encoder allows the user to encode remote control contact closure information in VITC (SD) or ATC (HD) user bits **instead of** encoding the GPI information into the AES embedded data stream. This feature allows the user to use the six parallel remote control inputs to set one of the six remote control user bit patterns. At the decoder end the model 7721DD4-HD+GPI Decoder module decodes the remote control user bits and outputs them on six open collector outputs.

The +SCTE104 option on the encoder allows the user to insert SCTE104 messages into the VANC. Each of the six GPI's is tied to a custom SCTE104 message, and when the GPI is activated (user selectable HIGH or LOW) a SCTE104 message is inserted.

The +VANC option on the encoder allows the user to insert serial data into a customer VANC packet **instead of** encoding it into the AES embedded data stream.

The 7721DE4-HD series modules occupy one card slot in the 3RU frame (7700FR-C), which will hold up to 15 modules or one slot in the 1RU frame (7701FR), which will hold up to three modules. The 7721DE4-HD series modules may also be used in a standalone unit (S7701FR).

Features:

- Automatic detection of SD-SDI or HD-SDI video input
- 4 x RS-232/422 serial inputs with selectable baud rate
- Parity selection: none, even or odd
- Support serial input with BREAK character according to SMPTE 207M
- Packetize data into sub-frame AES format according to SMPTE 337M
- Share the same group DIDs as for embedded audio, selectable from group 1 to 4
- Group selection for mapping data into one of four Audio Groups
- Redundant data transmission to allow data error detection and correction at the receiver end
- Automatically remove the existing embedded packets when the conflict of group DID occurs
- Six GPI inputs to embed simple control information into the video input
- Card edge LEDs indicate video signal and data presence, cable equalization and module faults
- Smart AFD Insertion (SMPTE 2016), via GPI or SNMP
- Inserts SCTE104 DPI messages as per SMPTE 2010 (+SCTE104 option)
- Inserts up to four serial RS-232/422 data streams into VANC (+VANC option)

Additional Features with +GPI Option Installed:

- Transmits remote control contact closure information in VITC or ATC user bits (instead of encoding the GPI information into AES data)

Additional Features with +SCTE104 Option Installed:

- Transmits up to six SCTE104 DPI messages as per SMPTE 2010, triggered by GPI's.

Additional Features with +VANC Option Installed:

- Transmits serial data in a user selectable VANC packet, instead of encoding in AES data.




Figure 1-1: 7721DE4-HD-HD Block Diagram

2. INSTALLATION

The 7721DE4-HD module comes with a companion rear plate that has 3 BNCs and a 16 pin removable Terminal Strip Connector. For information on mounting the rear plate and inserting the module into the frame see section 3 of the 7700FR chapter.




Figure 2-1: 7721DE4-HD Rear Panel



Some early versions of the 7721DE rear plate silkscreen were incorrect. Please compare your 7721DE4-HD rear plate to Figure 2-1. Ensure your Rx DATA Polarities on your rear plate (+ and -) are correct and match the above drawing. Negative (-) Polarity is the left set of pins and positive polarity (+) is the right set of pins. If polarities are reversed on your rear panel, silkscreen, please note and correct.

2.1. VIDEO INPUTS AND OUTPUTS

HD INPUT: Input BNC connector for 10-bit serial digital video signals compatible with the SMPTE 259M-C or SMPTE 292M standards.

HD OUTPUT: There are two BNC connectors with reclocked serial component video outputs, compatible with the SMPTE 259M and SMPTE 292M standard. These outputs contain the input video with the data from the RS-232/422 and GPI ports embedded in accordance with the SMPTE 337M. The top output is protected by a bypass relay, which will activate in the event of power loss to the module. The remaining output is not bypass protected.

When the +GPI option is installed, these outputs will also have ATC (HD) or VITC (SD) time code inserted with GPI information encoded into the user bits.

2.2. TERMINAL STRIP INPUTS

The 7721DE4-HD modules have a 16 pin terminal block containing 4 serial data port inputs and six GPI inputs. The input cables can be secured into the removable portion of the terminal strips using a small screwdriver. The removable part of the terminal strip is then inserted into the rear panel.

Table 2-1 shows the pin out of the Terminal Block labeled **RX DATA**. Note the location of pins shown in Figure 2-1.

Pin Number	Rear Panel Reference	RS-422 IN	Description	RS-232 IN	Description
1	RX Data - 1	DATA 1 IN 422	Receive Data -	DATA 1 IN 232	RXD for UART 1
2	RX Data + 1	DATA 1 IN 422	Receive Data +		
3	RX Data - 2	DATA 2 IN 422	Receive Data -	DATA 2 IN 232	RXD for UART 2
4	RX Data + 2	DATA 2 IN 422	Receive Data +		
5	RX Data - 3	DATA 3 IN 422	Receive Data -	DATA 3 IN 232	RXD for UART 3
6	RX Data + 3	DATA 3 IN 422	Receive Data +		
7	RX Data - 4	DATA 4 IN 422	Receive Data -	DATA 4 IN 232	RXD for UART 4
8	RX Data + 4	DATA 4 IN 422	Receive Data +		
9	\perp	Digital Ground			
10	\perp	Digital Ground			
11	GPI 1	General Purpose Input 1			
12	GPI 2	General Purpose Input 2			
13	GPI 3	General Purpose Input 3			
14	GPI 4	General Purpose Input 4			
15	GPI 5	General Purpose Input 5			
16	GPI 6	General Purpose Input 6			

Table 2-1: RX DATA Terminal Block Input

The RS-232 or RS-422 inputs are located on pins 1 through 8. Common digital grounds are shared for all the Data Inputs, located at Pins 9 and 10.



Some early versions of the 7721DE rear plate silkscreen were incorrect. Please compare your 7721DE4-HD rear plate to Figure 2-1. Ensure your Rx DATA Polarities on your rear plate (+ and -) are correct and match the above drawing. Negative (-) Polarity is the left set of pins and positive polarity (+) is the right set of pins. If polarities are reversed on your rear panel silkscreen, please note and correct.

2.2.1. RS232 Data Ports

To transfer RS-232 data, first set jumper J33 to RS-232 mode. Connect your RS-232 TX signal to the pin marked RX DATA - #. See Table 2-1 as reference. Connect the ground signal from your RS-232 source to GROUND pins 9 or 10. Configure the Port settings via the card edge menu. (See Section 5.12.)

2.2.2. RS422 Data Ports

To transfer RS-422 data, first set jumper J33 to RS-422 mode. Connect your RS-422 TXD + and TXD - source signals to RX DATA + and RX DATA - # pins. See Table 2-1 as reference. Connect the ground signal from your RS-422 source to GROUND Pins 9 or 10. Configure the Port settings via the card edge menu. (See Section 5.12.)

2.2.3. General Purpose Inputs

The user can activate GPIs simply by connecting the GPI input pins (PINS 11-16) to Ground. This can be done with a button, switch, relay or an open collector transistor. On the standard version, the GPI information is embedded into the data stream and will activate the corresponding GPO outputs on the 7721DD4-HD Data De-embedder. They can be used to pass simple contact closure information along with the video signal.

When the +GPI option is fitted the GPI information is encoded in VITC (for SD inputs) or RP188 ATC (for HD inputs) user bits instead of encoding the GPI information into the AES embedded data stream. See section 5.12.

When using the GPI's to control AFD insertion, they can be configured to be active low or active hi (+5 or 12 V). See section 5.3.

3. SPECIFICATIONS

3.1. SERIAL VIDEO INPUT

Standard: SMPTE 259M C, SMPTE 292M
Connector: BNC per IEC 169-8
Equalization: Automatic 300m @ 270 Mb/s, 100m @ 1.5Gb/s
with Belden 1694A or equivalent cable
Return Loss: > 15 dB up to 1.5Gb/s

3.2. SERIAL VIDEO OUTPUTS WITH EMBEDDED DATA

Number of Outputs: 2 output (bypass relay protected)
Standard: same as input
Connectors: BNC per IEC 169-8
Signal Level: 800mV nominal
DC Offset: 0V \pm 0.5V
Rise and Fall Time: 600ps nominal SD-SDI, 200ps nominal HD-SDI
Overshoot: <10% of amplitude
Return Loss: > 15 dB up to 1.5Gb/s (Relay Protected)
> 10 dB up to 1.5Gb/s
Wide Band Jitter: < 0.2 UI

3.3. DATA INPUT

Standard: 4 x RS-232 or RS-422
Connector: Terminal Block
Baud Rate: 110*, 300*, 600*, 1200*, 2400, 4800, 9600, 14400, 19200, 38400, 57600, 115200
* not available on +VANC option
Format: 5-8 bits, parity (none, even or odd), 1 or 2 stop bit

3.4. GENERAL PURPOSE INPUTS

Number of Inputs: 6
Type: Opto-isolated, active low (or active high configurable in AFD and SCTE104 modes)
Connector: Terminal Block
Signal Level: pull up to +5V or +12V nominal (jumper selectable)

3.5. TIME CODE (+GPI OPTION ONLY)

3.5.1. Ancillary Time Code Generator/Reader (ATC) - HD Video Standards Only

Standard: SMPTE RP188
Generator Lines: VITC packets – Line 9, 571; LTC packets – Line 10 as per RP188
Reader Line: Autodetect

3.5.2. Vertical Interval Time Code Generator/Reader (VITC) - SD Video Standards Only

Standard: SMPTE 12M, SMPTE 266M D-VITC
Line Range:
 525i/59.94: 10 to 21
 625i/50: 6 to 22
Generator Lines: Follows input VITC or user selectable when no input VITC
Reader Line: Autodetect or user selectable

3.6. EMBEDDING DELAY**3.6.1. Video I/O Delay**

The video I/O delay is approximately one line.

3.6.2. Data Embedding Delay – Serial Ports

Average Latency: 1200 μ s +/- 20% (All Baud rates)

3.6.3. Delay For Data Embedding - GPI Signals

Average Latency: 20 μ s +/- 10%

3.6.4. Delay For Time Code Embedding - GPI Signals (+GPI Option Only)

Encoding Latency: 1 frame plus GPI sampling delay
(GPI inputs sampled once per frame at beginning of field 1)

3.7. ELECTRICAL

Voltage: + 12VDC
Power: 12 Watts
EMI/RFI: Complies with FCC Part 15, class A and EU EMC directive

3.8. PHYSICAL**7700 or 7701 Frame Mounting:**

Number of Slots: 1

Stand Alone Enclosure:

Dimensions: 14 " L x 4.5 " W x 1.9 " H
(355 mm L x 114 mm W x 48 mm H)
Weight: approx. 1.5 lbs. (0.7 Kg)

4. STATUS INDICATORS

The location of the status LEDs is shown in Figure 6-1.

4.1. MODULE STATUS LEDS

MODULE OK: This Green LED will be On when the module is operating properly.

LOCAL FAULT: This Red LED makes it easy to identify one module in a frame that is missing an essential input or has another fault.

The LED will blink on and off if the microprocessor is not running.

The LED will be on solid when input video is missing or audio is missing from both AES inputs or there is a fault in the module power supply.

VIDEO PRESENT: This Green LED will be On when there is a valid video signal present at the module input.

AUDIO: This Green LED will be On when there is embedded audio/data present.

4.2. AUDIO/DATA GROUP STATUS LEDS

Four LEDs located on the lower end of the module (opposite the Card Edge Display) indicate the status of the audio/data groups. Group LED 1 is located closest to the center of the module.

Data LED	Colour	Group Status
1	Off	There is no group 1 data present on the input port
	On/Pulse	Group 1 data is being encoded/decoded
2	Off	There is no group 2 data present on the input port
	On/Pulse	Group 2 data is being encoded/decoded
3	Off	There is no group 3 data present on the input port
	On/Pulse	Group 3 data is being encoded/decoded
4	Off	There is no group 4 data present on the input port
	On/Pulse	Group 4 data is being encoded/decoded

Table 4-1: Data Status LEDs

5. CARD EDGE MENU SYSTEM

5.1. NAVIGATING THE MENU SYSTEM

You can use the toggle switch to move up and down the list of available parameters to adjust. To adjust any parameter, use the toggle switch to move up or down to the desired parameter and press the pushbutton. Using the toggle switch, adjust the parameter to its desired value. If the parameter is a numerical value, the number will increase if you push up on the toggle switch and decrease if you push down on the toggle switch. If the parameter contains a list of choices, you can cycle through the list by pressing the toggle switch in either direction. The parameter values are changed as you cycle through the list.

When you have stopped at the desired value, depress the pushbutton. This will return to the parameter select menu item you are setting (the display shows the parameter name you were setting). To change another parameter, use the toggle switch to select other parameters. If neither the toggle switch nor pushbutton is operated for several seconds the card edge control will exit the menu system and return to an idle state.

On all menus, there is an extra selectable item: *BACK*. Selecting *BACK* will take you to the previous menu (the one that was used to get into the current menu). On the main menu, *BACK* will both take the user to the normal operating mode (indicated by the moving line on the card edge display).



Not all functionality is accessible through the card edge controls. See VistaLINK[®] Section 7 for the full list of controls available through SNMP.

5.2. TOP LEVEL MENU STRUCTURE

Table 5-1 gives a brief description of the top level of the menu tree that appears when you enter the card edge menu system. Selecting one of these items will take you down into the next menu level to set the value of that parameter. The details of the each of the menu items are described in sections 5.12.1 to 5.16.

<i>AFD</i>	Configures Active Format Descriptor (AFD) parameters.
<i>GPIL</i>	Embedded LTC GPI Option.
<i>GPIV</i>	Embedded VITC GPI Option.
<i>PRST</i>	Performs a factory reset.
<i>DSPL</i>	Controls the display orientation.
<i>LOV</i>	Controls the loss of video mode.
<i>ABIT</i>	Sets the audio bit resolution encoding.
<i>VDUR</i>	Sets the duration of VITC loss for alarming.
<i>R188</i>	Controls which RP188 timecode is used.
<i>DLAY</i>	Configures the delay between incoming GPIs. (+GPI option)
<i>VGLN</i>	Sets the lines for generated VITC lines. (+GPI option)
<i>VRLN</i>	Sets the range for read VITC lines. (+GPI option)
<i>VID</i>	Sets the input video standard.
<i>EMB</i>	Enables or disables the data embedders.
<i>HANC</i>	Allows the user to Clean or Pass upstream HANC data.
<i>PRT1</i>	Allows the user to configure the settings for Port 1.
<i>PRT2</i>	Allows the user to configure the settings for Port 2.
<i>PRT3</i>	Allows the user to configure the settings for Port 3.
<i>PRT4</i>	Allows the user to configure the settings for Port 4.

Table 5-1: Top End Menu Structure

5.3. ACTIVE FORMAT DESCRIPTOR (AFD) CONTROL

Active Format Description (AFD) is intended to guide downstream equipment regarding the display of aspect ratio. It is implemented as an embedded packet within the video stream. This packet contains information such as the aspect ratio formatting of the original material, how the material is currently formatted and the primary and secondary ways that the video is best displayed. This information determines whether the video should be *letterboxed*, *pillarboxed*, 4:3 or 16:9.

MODE	Sets the AFD Embedding Mode.
LINE	Sets what line AFD codes will be embedded on.
GPI	Loads the GPI to be configured by the following six menu items.
CODE	Sets the AFD code to be embedded.
AR	Sets the aspect ratio of the source frame.
BARS	Sets the bar data bar type.
BAR1	Sets the first bar data value.
BAR2	Sets the second bar data value.
GPIM	Controls the GPI active condition.

Table 5-2: AFD Menu Control

5.3.1. Configuring AFD Embedding Mode

AFD	This parameter sets the AFD embedding mode.
MODE	
PASS	Selecting PASS will pass through existing AFD codes.
BLCK	Selecting BLCK will erase any incoming AFD codes.
FI	Selecting FI will allow static AFD insertion while block incoming AFD.
CI	Selecting CI will perform a check and insert. If AFD is present, it will be passed through. If it is not present, then a static AFD code will be inserted.
G_FI	Selecting G_FI or G_CI will perform GPI controlled functionality of the FI or CI commands respectively. When the GPI is active, the commands will be the same as the FI or CI commands. When it is inactive, incoming AFD will be passed-through.
G_CI	

5.3.2. Configuring the AFD Line Number

AFD	This parameter sets which line AFD packets will be embedded on.
LINE	
7-24 (12)	

5.3.3. Configuring Dynamic GPI Control

AFD	This parameter sets which GPI will be configured by the remaining menu settings. GPI 1-6 can be selected corresponding to the physical GPI inputs.
GPI	
NONE	A selection of NONE control static GPI insertion.
1-6	



Once the *Dynamic GPI Control* is configured (i.e. GPI 1), the remaining AFD parameters will apply to the selected GPI.

5.3.4. Configuring the AFD Insertion Code

<i>AFD</i>	
<i>CODE</i>	
<i>0</i>	
<i>2</i>	
<i>3</i>	
<i>4</i>	
<i>8</i>	
<i>9</i>	
<i>10</i>	
<i>11</i>	
<i>13</i>	
<i>14</i>	
<i>15</i>	

Sets the AFD code that is inserted. Refer to Figure 5-1 for a visualization of each code. These codes are used in conjunction with the AR parameter.

0000
0010
0011
0100
1000
1001
1010
1011
1101
1110
1111























Original 4:3 coded frame	Original 16:9 coded frame
<p>0000 Undefined -Code 0000 indicates that information is unavailable, therefore video equipment should interpret active format the same as coded frame unless 'bar data' is available. -May not be supported worldwide. -Should be used with caution</p>  <p>0010 16:9 image at top of frame -May not be supported worldwide. -Should be used with caution</p>  <p>0011 14:9 image at top of frame -May not be supported worldwide. -Should be used with caution</p>  <p>0100 Wider than 16:9 image centered in frame -Bar data should always be associated with AFD code 0100 to signal the exact size of letterbox bars. -May not be supported worldwide. -Should be used with caution</p>  <p>1000 Full frame image Same as coded frame</p>  <p>1001 4:3 image centered in frame -For a 4:3 frame, AFD code 1001 resulted in the same image as AFD code 1000, therefore code 1000 is preferred coding in such cases.</p>  <p>1010 16:9 image centered in frame -All image area is protected, therefore cropping is not allowed and only letterbox format can be used.</p>  <p>1011 14:9 image centered in frame</p>  <p>1101 4:3 image with alternative 14:9 center cut -14:9 image area is protected -Visual information outside protected area may be cropped with minimum impact for the viewer.</p>  <p>1110 16:9 image with alternative 14:9 center cut -14:9 image area is protected -Visual information outside protected area may be cropped with minimum impact for the viewer.</p>  <p>1111 16:9 image with alternative 4:3 center cut -4:3 image area is protected -Visual information outside protected area may be cropped with minimum impact for the viewer.</p> 	<p>0000 Undefined -Code 0000 indicates that information is unavailable, therefore video equipment should interpret active format the same as coded frame unless 'bar data' is available. -May not be supported worldwide. -Should be used with caution</p>  <p>0010 16:9 image Same as coded frame -For a 16:9 frame, AFD code 0010 resulted in the same image as AFD code 1000, therefore code 1000 is preferred coding in such cases.</p>  <p>0011 14:9 image Same as coded frame -For a 16:9 frame, AFD code 0011 resulted in the same image as AFD code 1011, therefore code 1000 is preferred coding in such cases.</p>  <p>0100 Wider than 16:9 image centered in frame -Bar data should always be associated with AFD code 0100 to signal the exact size of letterbox bars. -May not be supported worldwide. -Should be used with caution</p>  <p>1000 Full frame image Same as coded frame</p>  <p>1001 4:3 image centered in frame</p>  <p>1010 16:9 image full frame -All image area is protected, therefore cropping is not allowed.</p>  <p>1011 14:9 image centered in frame</p>  <p>1101 4:3 image with alternative 14:9 center cut -14:9 image area is protected -Visual information outside protected area may be cropped with minimum impact for the viewer.</p>  <p>1110 16:9 image with alternative 14:9 center cut -14:9 image area is protected -Visual information outside protected area may be cropped with minimum impact for the viewer.</p>  <p>1111 16:9 image with alternative 4:3 center cut -4:3 image area is protected -Visual information outside protected area may be cropped with minimum impact for the viewer.</p> 

Figure 5-1: AFD Control Codes

5.3.5. Configuring the Aspect Ratio of the AFD Code

AFD
AR
4x3
16x9

This parameter sets whether the original frame is 4:3 or 16:9 aspect ratio coded.

A selection of 4x3 will choose AFD codes from the 4:3 selections.

A selection of 16x9 will choose AFD codes from the 16:9 selections.

5.3.6. Configuring the Bar Type For Bar Data

AFD
BARS
PLLRLTTR

This parameter sets the type of bars that are on the picture when using bar data.

A selection of PLLR will be valid for video that has bars on the sides (pillarboxed).

A selection of LTTR will be valid for video that has bars on the top and bottom (letterboxed).

5.3.7. Configuring the Size of the First Bar

AFD
BAR1

This parameter sets the size of the first bar, as selected under Bar Type.

The values available in this field will depend on the input video format.

5.3.8. Configuring the Size of the Second Bar

AFD
BAR2

This parameter sets the size of the second bar, as selected under Bar Type.

The values available in this field will depend on the input video format.

5.3.9. Configuring the GPI Active Condition

AFD
GPIM
NONE
LOW
HIGH

This parameter sets the GPI active condition for the selected GPI.

A selection of NONE will disable the GPI for AFD insertion.

A selection of LOW will make the GPI active LO.

A selection if HIGH will make the GPI active HI (+5 or 12 V, jumper selectable).

5.4. EMBEDDED LTC GPI CONTROL

GPIL

NONE
UPSG
COMG
LCLG

This parameter sets how GPIs will be inserted into incoming LTC timecode. This menu option will only be available if LTC or BOTH are selected under RP188.

A selection of NONE will send out LTC timecode with no GPIs encoded.

A selection of UPSG will send out LTC time code with previously upstream GPIs.

A selection of COMG will combine local and upstream GPIs in the LTC.

A selection of LCLG will encode only local GPIs in LTC.

5.5. EMBEDDED VITC GPI CONTROL

GPIV

NONE
UPSG
COMG
LCLG

This parameter sets how GPIs will be inserted into incoming VITC timecode. This menu option will only be available if VITC or BOTH are selected under RP188.

A selection of NONE will send out VITC timecode with no GPI's encoded.

A selection of UPSG will send out VITC time code with previously upstream GPIs.

A selection of COMG will combine local and upstream GPI's in the VITC.

A selection of LCLG will encode only local GPIs in VITC.

5.6. FACTORY RESET CONTROL

PRST

0000
FACT

This parameter will perform a factory reset, when FACT is selected, all parameters will be restored to a preset default.

5.7. CARD-EDGE DISPLAY CONTROL

DSPL

VERT
HORZ

This parameter sets how the card-edge LED display is oriented.

Selecting VERT will cause it to be displayed vertically. (Suited for insertion in a standard 3RU frame).

Selecting HORZ will cause it to be displayed horizontally. (Suited for insertion in a 1RU or standalone frame).

5.8. LOSS OF VIDEO MODE CONTROL

LOV

BLUE
BLCK

This parameter sets the output display when no video is applied on the input. Note that the module will always have a video output, therefore GPIs, and data, etc. are always passed through.

5.9. AUDIO BIT ENCODING CONTROL

<i>ABIT</i>
<i>AUTO</i>
<i>16BT</i>
<i>20BT</i>
<i>24BT</i>

This parameter sets the resolution of audio bit encoding.

5.10. VITC LOSS FRAME DURATION

<i>VDUR</i>
<i>0001-0060</i>

This parameter sets how many frames will pass without VITC present before a VITC loss alarm is raised.

5.11. RP188 TIME CODE CONTROL

<i>R188</i>
<i>VITC</i>
<i>LTC</i>
<i>BOTH</i>

This parameter sets which RP188 time code will be used for GPI insertion.

A selection of BOTH will find valid time code in either VITC or LTC, and use that for GPI insertion.

5.12. GPI USER BIT REMOTE CONTROL OPTION (+GPI OPTION)

When the +GPI option is fitted, the 7721DE4-HD+GPI allows the user to encode remote control contact closure information in VITC (for SD inputs) or RP188 ATC (for HD inputs) user bits instead of encoding the GPI information into the AES embedded data stream. Incoming timecode (VITC or ATC) will be passed through with the user bits modified. If there is no incoming timecode, then the 7721DE4-HD+GPI will generate VITC or ATC depending on the video format. This feature allows the user to use the six parallel remote control inputs on the 7721DE4-HD+GPI to set one of the six remote control user bit patterns. At the decoder end the 7721DD4-HD+GPI ATC GPI Decoder module decodes the remote control user bits and outputs them on six open collector outputs.

The User bit remote control works on one of two modes. In immediate mode, the GPI1 to GPI6 inputs are used to set special codes in the timecode user bits as long as the GPI is closed to ground. When the 7721DD4-HD+GPI decodes these special user bit codes it closes the corresponding GPO output. In deferred GPI mode the GPI input to the encoder card occurs a fixed number of frames (user programmable on the encoder using the *DELAY* menu item) before the user actually wants the GPO Output to occur at the decoder. When the GPI input occurs at the encoder, a special code is sent in the user bits indicating the amount of delay and which GPI should activate. When the decoder receives this code, instead of outputting the GPO immediately, it will start a countdown timer and output the GPO at the delayed time. In addition, the encoder will output a second user bit code at the delayed time. The decoder will receive this code at the same time as its countdown reaches zero and output a GPO based on one or the other or both of these codes. This redundancy provides protection for lost contact closure data due to breakups in the video path between the encoder and decoder.

When the 7721DE4-HD+GPI is operated in immediate mode with standard definition video, its VITC GPI encoding may be decoded with the 7721DD4-HD+GPI as well as the 7721GPI-D VITC GPI decoder modules. When you are using deferred mode you must use the 7721DD4-HD+GPI as a decoder.

When the 7721DE4-HD+GPI is operated with high definition video, its ATC GPI encoding may be decoded with the 7721DD4-HD+GPI (in immediate or deferred mode) decoder modules. If the video is downconverted using a 7710DCDA or similar downconverter that passes the timecode through to the downconverted output, the encoded GPI signals can be decoded by the 7721GPI-D SDI decoder, in immediate mode only. When you are using deferred mode you must use the 7721DD4-HD+GPI as a decoder.

When the 7721DD4-HD+GPI is operated with high definition video, its ATC GPI decoder is compatible with the 7721DE4-HD+GPI (in immediate or deferred mode) as well as the HD9010TM.

The parallel port pin designations for the various encoders are shown in Table 5-3. Table 5-3 also shows the corresponding output pins of the various decoders and the user bits that control them.

GPI	HD9010TM PIN (IN)	7721DE4-HD+GPI PIN (IN)	7721DD4-HD+GPI PIN (OUT)	7721GPI-D PIN (OUT)	User Bit Data byte 1
1	1	11	11	4	81
2	8	12	12	8	82
3	4	13	13	3	84
4	9	14	14	1	88
5	5	15	15	13	90
6	2	16	16	14**	A0

Table 5-3: GPI I/O Mapping (+GPI option installed)

The menu items described in sections 5.12.1 to 5.12.3 are used to configure the GPI functions of the embedder when the +GPI option is fitted. These menu items are not available in the standard version.

5.12.1. Configuring the GPI Delay

DLAY
0000
0000 to 1023

The *DLAY* menu is used to configure the delay (in frames) between GPIs that are transmitted over VITC. The range of the parameter is 0 to 1023 frames.

The default value is 0 frames of delay between GPIs.

5.12.2. Setting the VITC Generator Lines

The *VGLN* menu sets the lines to generate VITC for standard definition video formats. The chart below shows the items available in the *VGLN* menu. Sections 5.12.2.1 to 5.12.2.2 give detailed information about each of the menu items.

LN 1	Sets the value for first line to generate VITC on.
LN 2	Sets the value for second line to generate VITC on.

5.12.2.1. Setting the First Line to Generate VITC

VGLN
LN 1
0010 to 0032 (525)
006 to 0032 (625)

This parameter allows the user to set the first line to generate VITC when there is no incoming VITC.

For 525i/59.94 video, the range is line 10 to line 32 and the default value is line 14.

For 625i/50 video, the range is line 6 to line 32 and the default value is line 19.

5.12.2.2. Setting the Second Line to Generate VITC

VGLN
LN 2
0010 to 0032 (525)
006 to 0032 (625)

This parameter allows the user to set the second line to generate VITC when there is no incoming VITC. To generate VITC on only one line set this parameter to the same value as the *LN 1* menu item.

For 525i/59.94 video, the range is line 10 to line 32 and the default value is line 16.

For 625i/50 video, the range is line 6 to line 32 and the default value is line 21.

5.12.3. Setting the VITC Reader Lines

The *VRLN* menu sets the range of VITC lines to look for incoming VITC for standard definition video formats. The chart below shows the items available in the *VRLN* menu. Sections 5.12.3.1 to 5.12.3.2 give detailed information about each of the menu items.

STRT	Sets the beginning of the VITC reader range.
END	Sets the end of the VITC reader range.

5.12.3.1. Setting the Start Line of the VITC Reader Range

VRLN
STRT
0010 to 0032 (525)
006 to 0032 (625)

This parameter allows the user to set the first line to look for VITC on the incoming video.

For 525i/59.94 video, the range is line 10 to line 32 and the default value is line 10.

For 625i/50 video the range is line 6 to line 32 and the default value is line 6.

5.12.3.2. Setting the End of the VITC range

VRLN
END
0010 to 0032 (525)
006 to 0032 (625)

This parameter allows the user to set the last line to look for VITC on the incoming video.

For 525i/59.94 video, the range is line 10 to line 32 and the default value is line 20.

For 625i/50 video, the range is line 6 to line 32 and the default value is line 21.



The 7721DE4-HD+GPI will NOT allow the user to select values where the START line is greater than the END line. If the user selects a START line greater than the END line, the module will automatically move the END line to another valid value.

5.13. SETTING THE INPUT VIDEO STANDARD

VID	
<u>AUTO</u>	Sets the input video standard.
3I60	Auto detect
3I59	1035i/60
1P30	1035i/59.94
1P29	1080p/30
1P25	1080p/29.97
1P24	1080p/25
1P23	1080p/24
7P60	1080p/23.98
7P59	720p/60
1I60	720p/59.94
1I59	1080i/60 (1080p/30sF)
1I50	1080i/59.94 (1080p/29.97sF)
1S24	1080i/50 (1080p/25sF)
1S23	1080p/24sF
5I59	1080p/23.98sF
6I50	525i/59.94 Note some firmware versions may show <i>NTSC</i>
	625i/50 Note some firmware versions may show <i>PALB</i>

5.14. ENABLING THE DATA EMBEDDER

EMB	
<u>On</u>	The <i>EMB</i> function allows the user to enable or disable the embedding of the data.
Off	Setting the <i>EMB</i> to <i>On</i> will enable the embedding of data into the audio group.
	Setting the <i>EMB</i> to <i>Off</i> will disable the embedding of data.

5.15. SETTING THE HANDLING OF INCOMING HANC DATA

HANC	
<u>PASS</u>	The <i>HANC</i> menu allows the user to pass or remove HANC audio data from the incoming video feed. The RS232/422 data sent from the 7721DE4-HD is preserved, but all audio in the HANC can be removed.
CLN	Selecting <i>PASS</i> will pass all upstream audio in the HANC.
	Select <i>CLN</i> to remove all upstream audio.

5.16. CONFIGURING THE SERIAL PORTS

The *PRT1*, *PRT2*, *PRT3*, and *PRT4* menus allow the user to configure port settings to transfer data from the 7721DE4-HD to the 7721DD4-HD. The user will also be allowed to configure which audio group and channel to embed for each port. Sections 5.16.1 to 5.16.8 will describe the various parameters ports.

BAUD	Configures the Baud rate of the port.
STOP	Configures the Port Stop bits.
PRTY	Configures the parity setting of the Port
DATA	Configures the data length of the Port
LOOP	Configures the Loopback status of the UART for the Port
UART	Configures the status of the UART for the Port
GRP	Sets the audio group to de-embed to the Port
CHNL	Sets the audio channel to de-embed to the Port

Table 5-4: Port Menu Structure

The parameters are the same for all four ports. For simplicity sake, only the parameters for *PRT1*, will be described.



The following Port settings can be configured by the 7721DE4-HD ONLY and are transmitted within Control packets to the downstream 7721DD4-HD. The 7721DD4-HD will automatically configure itself to the same parameters and allows the user to MONITOR the parameters.

5.16.1. Configuring the Baud Rate of Port 1

PRT1
BAUD
110
300
600
1200
2400
4800
9600
14400
19200
38400
<u>57600</u>
115200

The Baud setting allows the user to monitor the baud rate of the data sent from the 7721DE4-HD to the 7721DD4-HD.

5.16.2. Configuring the Stop Bits of Port 1

PRT1
STOP
1
<u>2</u>

Allows the user to set the number of stop bits.

5.16.3. Configuring the Parity Setting of Port 1

PRT1
PRTY
None
Even
Odd

Allows the user to set the parity of the port.

5.16.4. Configuring the Data Length of Port 1

PRT1
DATA
5
6
7
<u>8</u>
None

Allows the user to set the data length of the packets being sent.

5.16.5. Configuring the Loopback Status of the UART for Port 1

PRT1
LOOP
On
Off

This sets the Loopback status of the UART for Port 1.

When *On* is displayed, the loopback function of the UART for the port is enabled.

When *Off* is displayed, the loopback function is disabled.

5.16.6. Configuring the Status of the UART for the Transmit Port 1

PRT1
UART
On
Off

This sets the status of the UART for Port 1.

When *On* is displayed, the port is enabled and ready to transmit data.

When *Off* is displayed, the port is disabled.

5.16.7. Setting the Audio Group to Embed for Port 1

PRT1
GRP
GRP1
GRP2
GRP3
GRP4

This parameter allows the user to select which audio group the Port 1 data will be embedded into.

Note: The user **CANNOT** set the same Audio Group and Channel to more than ONE transmit port.



5.16.8. Setting the Audio Channel to Embed for Port 1

PRT1
CHNL
CH 1
CH 2
CH 3
CH 4

This parameter allows the user to select which audio channel within the group set by the *GRP* menu item the Port 1 data will be embedded into.

Note: The user **CANNOT** set the same Audio Group and Channel to more than **ONE** transmit port.

6. JUMPERS AND USER ADJUSTMENTS




Figure 6-1: Location of Jumpers (Rev 1 Submodule)




Figure 6-2: Location of Jumpers (Rev A Submodule)

6.1. SELECTING WHETHER LOCAL FAULTS WILL BE MONITORED BY THE GLOBAL FRAME STATUS

FRAME STATUS: The FRAME STATUS jumper located at the front of the module determines whether local faults (as shown by the Local Fault indicator) will be connected to the 7700FR frame's global status bus.

To monitor faults on this module with the frame status indicators (on the PS FRAME STATUS LED's and on the Frame's Fault Tally input) install this jumper in the On position. (Default)

When this jumper is installed in the Off position, local faults on this module will not be monitored.

6.2. SETTING THE BYPASS RELAY JUMPER

BYPASS: The BYPASS jumper J25 controls the Bypass relay functionality.

Set the jumper to the top 2 pins to allow the Bypass relay to only activate when the card loses power. The relay will allow video to pass through the card when it is powered up.

Set the jumper to the bottom 2 pins to activate Bypass relay all the time. The video will not pass through the card. The non-bypassed video output will not have video available.

6.3. SELECTING THE DATA COMMUNICATIONS STANDARD (RS-232 OR RS-422)

232/422: The 232/422 jumper J33 selects whether the serial ports will be configured for RS-232 data or RS-422 data. See section 2.2 for information on connecting the serial ports and section 5.16 for the menu settings to configure the ports.

Set the jumper to the 2 pins on the left to configure the serial ports for RS-422 voltage levels.

Set the Jumper on the 2 pins on the right to configure the serial ports for RS-232 voltage levels.

6.3.1. Configuring RS422 Device Communication between a Controller and Tributary

SMPTE Standard 207M defines the electrical and mechanical characteristics of the device interface used in transferring data and control signals between production and post-production equipment. Each interface system consists of a single bus-controller and one or more tributaries. The bus-controller controls the communication flow to all tributaries connected to it, while a tributary transmits data to an operational device.

Two 7721DE4-HD/7721DD4-HD pairs can be configured to interface between a bus controller and a tributary if configured as follows:




Figure 6-3: SMPTE 207M RS422 Controller/Tributary Wiring

6.4. SELECTING THE DEFAULT BEHAVIOUR OF THE SERIAL PORT INPUTS WHEN THERE IS NO SIGNAL CONNECTED

The BIAS jumpers J32, J35, J2 and J4 located on the A7721DX4-HD sub-module control the behaviour of the RS-422 inputs for ports 1, 2, 3, and 4 respectively when there is no signal connected. This is not critical for most applications, and the setting will not typically affect performance. Figure 6-4 shows a simple schematic of the receiver input.




Figure 6-4: Receiver Input Pull-up Configuration

The RS-422 receiver device has a pulldown to ground on the Rx+ input and a pullup to +5v on the Rx- input. If you want to override the default pull-ups set the appropriate jumper as shown in the chart below.

Label	Jumper on pins	Function
NONE	1 & 2	Default pull-ups (Rx+ low, Rx- high)
HI	2 & 3	Rx- pulled up to +3.3 volts, Rx+ default (low)
LOW	3 & 4	Rx+ pulled up to + 3.3 volts, Rx- default (high)

6.5. SETTING THE GPI INPUT PULLUP VOLTAGE

On Rev 1 of the A7721Dx4-HD submodule, jumpers J36 and J1 are used to select the GPI input pullup voltage as either +12V or +3.3V. Jumper J36 sets the pullup voltage for GPI 1 to 4 and J1 sets the pullup voltage for GPI 5 and 6. (See Figure 6-1)

On Rev A of the A7721Dx4-HD submodule, jumper J36 is used to select the GPI input pullup voltage for all six GPIs as either +12V or +5V nominal. Note that the circuit board silkscreen on Rev A boards may incorrectly show 3.3 volts but it is actually +5 volts as shown in Figure 6-2.

6.6. CONFIGURING THE MODULE FOR FIRMWARE UPGRADES

UPGRADE: The UPGRADE jumper J5 is used when firmware upgrades are being done to the module. For normal operation it should be installed in the *RUN* position. See the *Upgrading Firmware* section in the front of this manual binder for more information.

To upgrade the firmware in the module unit pull it out of the frame. Move the UPGRADE jumper into the *UPGD* position. Install the Upgrade cable provided (located in the vinyl pouch in the front of this manual) onto the J24 header at the card edge. Re-install the module into the frame. Run the upgrade as described in the *Upgrading Firmware* section in the front of this manual binder. Once the upgrade is complete, remove the module from the frame, move the UPGRADE jumper into the *RUN* position, remove the upgrade cable and re-install the module. The module is now ready for normal operation.

7. VistaLINK® REMOTE MONITORING/CONTROL

7.1. What is VistaLINK®?

VistaLINK® is Evertz's remote monitoring and configuration platform which operates over an Ethernet network using Simple Network Management Protocol (SNMP). SNMP is a standard computer network protocol that enables different devices sharing the same network to communicate with each other. VistaLINK® provides centralized alarm management, which monitors, reports, and logs all incoming alarm events and dispatches alerts to all the VLPro Clients connected to the server. Card configuration through VistaLINK® PRO can be performed on an individual or multi-card basis using simple copy and paste routines, which reduces the time to configure each module separately. Finally, VistaLINK® enables the user to configure devices in the network from a central station and receive feedback that the configuration has been carried out.

There are 3 components of SNMP:

1. An SNMP manager, also known as a Network Management System (NMS), is a computer running special software that communicates with the devices in the network. Evertz VistaLINK® Pro Manager graphical user interface (GUI), third party or custom manager software may be used to monitor and control Evertz VistaLINK® enabled products.
2. Managed devices (such as the frame synchronizers), each with a unique address (OID), communicate with the NMS through an SNMP Agent. Evertz VistaLINK® enabled 7700 series modules reside in the 3RU 7700FR-C MultiFrame and communicate with the manager via the 7700FC VistaLINK® frame controller module, which serves as the Agent.
3. A virtual database known as the Management Information Base (MIB) lists all the variables being monitored, which both the Manager and Agent understand. Please contact Evertz for further information about obtaining a copy of the MIB for interfacing to a third party Manager/NMS.

For more information on connecting and configuring the VistaLINK® network, see the 7700FC Frame Controller chapter.

7.2. Misc Control Tab

This tab will allow the user to set miscellaneous parameters for controlling the module.




Figure 7-1: VistaLINK® 7721DE4-HD Misc Control View

7.2.1. HANC Control

Misc Control
HANC Control
Pass
Clean

The *HANC Control* menu allows the user to pass or remove HANC audio data from the incoming video feed. The RS232/422 data sent from the 7721DE4-HD is preserved, but all audio in the HANC can be removed.

Selecting *Pass* will pass all upstream audio in the HANC.

Select *Clean* to remove all upstream audio.

7.2.2. Detected Video Standard

Misc Control
Detected Video Standard
Video Standard

Displays the currently detected video standard, or *Video Unknown* if no video is detected.

7.2.3. Video Standard

Misc Control
Video Standard
Auto detect
1035i/60
1035i/59.94
1080p/30
1080p/29.97
1080p/25
1080p/24
1080p/23.98
720p/60
720p/59.94
1080i/60 (1080p/30sF)
1080i/59.94
(1080p/29.97sF)
1080i/50 (1080p/25sF)
1080p/24sF
1080p/23.98sF
525i/59.94
625i/50

Sets the input video standard.

7.2.4. Embedder Enable

Misc Control
Embedder Enable
On
Off

The *Embedder Enable* function allows the user to enable or disable the embedding of the data.

Setting the *Embedder Enable* to *On* will enable the embedding of data into the audio group.

Setting the *Embedder Enable* to *Off* will disable the embedding of data.

7.2.5. CardType

Misc Control
Card Type
7721DE4-HD+...

Displays the full module name, including installed options.

7.2.6. Bits Encoding

Misc Control
Bits Encoding
Auto
Encoding 20 bits
Encoding 24 bits
Encoding 16 bits

This parameter sets the resolution of audio bit encoding.

7.2.7. Factory Reset

Misc Control
Factory Reset
<u>False</u>
True

This parameter will perform a factory reset, when *True* is selected and applied, all parameters will be restored to a preset default.

7.2.8. Embedded VITC GPI Option (+GPI Only)

Misc Control
Embedded VITC GPI Option
<u>Local GPI Only In VITC</u>
Local Upstream GPI Combine In VITC
Upstream GPI Only In VITC
No GPI Embedded In VITC

This parameter sets how GPIs will be inserted into incoming VITC timecode.

A selection of *No GPI Embedded In VITC* will send out VITC timecode with no GPIs encoded.

A selection of *Upstream GPI Only In VITC* will send out VITC time code with previously upstream GPIs.

A selection of *Local Upstream GPI Combine In VITC* will combine local and upstream GPIs in the VITC.

A selection of *Local GPI Only In VITC* will encode only local GPIs in VITC.

7.2.9. Embedded LTC GPI Option (HD Formats Only)

Misc Control
Embedded LTC GPI Option
<u>Local GPI Only In LTC</u>
Local Upstream GPI Combine In LTC
Upstream GPI Only In LTC
No GPI Embedded In LTC

This parameter sets how GPIs will be inserted into incoming LTC timecode. This menu option will only be available if the standard is HD.

A selection of *No GPI Embedded In LTC* will send out LTC timecode with no GPIs encoded.

A selection of *Upstream GPI Only In LTC* will send out LTC time code with previously upstream GPIs.

A selection of *Local Upstream GPI Combine In LTC* will combine local and upstream GPIs in the LTC.

A selection of *Local GPI Only In LTC* will encode only local GPIs in LTC.

7.2.10. RP188 (HD formats only)

Misc Control
R188
<u>VITC</u>
LTC
BOTH

This parameter sets which RP188 time code will be used for GPI insertion.

A selection of *BOTH* will find valid time code in either VITC or LTC, and use that for GPI insertion.

7.2.11. Serial Embedder Mode (+VANC only)

Misc Control
Serial Embedder Mode
Audio
VANC

This parameter sets where GPI's and serial data will be embedded.

7.3. Port Control

The *Port Control* tab allows the user to configure the serial data which will be embedded in audio.

Port Control	Misc Control	AFD Control	Fault Traps
Baud Rate			
Port 1	Baud 110		
Port 2	Baud 300		
Port 3	Baud 19200		
Port 4	Baud 4800		
Stop Bits			
Port 1	2		
Port 2	2		
Port 3	2		
Port 4	2		
Parity			
Port 1	None		
Port 2	None		
Port 3	None		
Port 4	None		
Data Bits			
Port 1	8		
Port 2	8		
Port 3	8		
Port 4	8		
Loop Back			
Port 1	<input checked="" type="radio"/> Off <input type="radio"/> On		
Port 2	<input checked="" type="radio"/> Off <input type="radio"/> On		
Port 3	<input checked="" type="radio"/> Off <input type="radio"/> On		
Port 4	<input checked="" type="radio"/> Off <input type="radio"/> On		
Uart Enable			
Port 1	<input type="radio"/> Off <input checked="" type="radio"/> On		
Port 2	<input type="radio"/> Off <input checked="" type="radio"/> On		
Port 3	<input type="radio"/> Off <input checked="" type="radio"/> On		
Port 4	<input type="radio"/> Off <input checked="" type="radio"/> On		
Audio Group*			
Port 1	Group 4		
Port 2	Group 4		
Port 3	Group 4		
Port 4	Group 4		
Audio Channel*			
Port 1	Channel 1		
Port 2	Channel 2		
Port 3	Channel 3		
Port 4	Channel 4		

* NOTE: No two ports may have the same Group AND Channel selections at the same time.

Figure 7-2: VistaLINK® 7721DE4-HD Port Control View

7.3.1. Baud Rate

Port Control
Baud Rate
Port 1 – 4
110
300
600
1200
2400
4800
9600
14400
19200
38400
<u>57600</u>
115200

The Baud setting allows the user to set the baud rate of the data sent from the 7721DE4-HD to the 7721DD4-HD.

7.3.2. Stop Bits

Port Control
Stop Bits
Port 1 – 4
1
<u>2</u>

Allows the user to set the number of stop bits.

7.3.3. Parity

Port Control
Parity
Port 1 – 4
<u>None</u>
Even
Odd

Allows the user to set the parity of the port.

7.3.4. Data Bits

Port Control
Data Bits
Port 1 – 4
5
6
7
<u>8</u>

Allows the user to set the data length of the packets being sent.

7.3.5. Loop Back

Port Control
Loop Back
Port 1 – 4
On
Off

This sets the Loopback status of the UART for the selected port.

When *On* is displayed, the loopback function of the UART for the port is enabled.

When *Off* is displayed, the loopback function is disabled.

7.3.6. Uart Enable

Port Control
Uart Enable
Port 1 – 4
On
Off

This sets the status of the UART for Port 1.

When *On* is displayed, the port is enabled and ready to transmit data.

When *Off* is displayed, the port is disabled.

7.3.7. Audio Group

Port Control
Audio Group
Port 1 – 4
Group 1 (default Port 1)
Group 2 (default Port 2)
Group 3 (default Port 3)
Group 4 (default Port 4)

This parameter allows the user to select which audio group the selected port data will be embedded into. This setting works in conjunction with the *Audio Channel* setting in Section 7.3.8 to select which specific channel the data goes into.

Note: The user CANNOT set the same Audio Group and Channel to more than ONE transmit port.

7.3.8. Audio Channel

Port Control
Audio Channel
Port 1 – 4
Channel 1 (default Port 1)
Channel 2 (default Port 2)
Channel 3 (default Port 3)
Channel 4 (default Port 4)

This parameter allows the user to select which audio channel within the group set by the *GRP* menu item the Port 1 data will be embedded into.

Note: The user CANNOT set the same Audio Group and Channel to more than ONE transmit port.



Setting all ports to the same group, but different channels (i.e. channels 1-4), will allow an entire group to be reserved for data transmission.

7.4. VITC Control (SD, +GPI option only)

When operating with a SD video standard, the *VITC Control* tab allows the user to define the handling of VITC timecode.




Figure 7-3: VistaLINK® 7721DE4-HD+GPI VITC Control (SD) View

7.4.1. VITC Reader Start Line

VITC Control
VITC Control
VITC Reader Start Line
10 - 32 (525)
6 - 32 (625)

This parameter allows the user to set the first line to look for VITC on the incoming video.

For 525i/59.94 video, the range is line 10 to line 32 and the default value is line 10.

For 625i/50 video the range is line 6 to line 32 and the default value is line 6.

7.4.2. VITC Reader End Line

VITC Control
VITC Control
VITC Reader End Line
10 - 32 (525)
6 - 32 (625)

This parameter allows the user to set the last line to look for VITC on the incoming video.

For 525i/59.94 video, the range is line 10 to line 32 and the default value is line 20.

For 625i/50 video, the range is line 6 to line 32 and the default value is line 21.



The 7721DE4-HD+GPI will NOT allow the user to select values where the START line is greater than the END line. If the user selects a START line greater than the END line, the module will automatically move the END line to another valid value.

7.4.3. VITC Generator Line 1

VITC Control
VITC Control
VITC Generator Line 1
10 - 32 (525)
6 - 32 (625)

This parameter allows the user to set the first line to generate VITC when there is no incoming VITC.

For 525i/59.94 video, the range is line 10 to line 32 and the default value is line 14.

For 625i/50 video, the range is line 6 to line 32 and the default value is line 19.

7.4.4. VITC Generator Line 2

VITC Control
VITC Control
VITC Generator Line 2
10 - 32 (525)
6 - 32 (625)

This parameter allows the user to set the second line to generate VITC when there is no incoming VITC. To generate VITC on only one line set this parameter to the same value as the *LN 1* menu item.

For 525i/59.94 video, the range is line 10 to line 32 and the default value is line 16.

For 625i/50 video, the range is line 6 to line 32 and the default value is line 21.

7.4.5. Loss of VITC Duration

VITC Control
VITC Control
Loss of VITC Duration
1 - 60

This parameter determines the number of frames for VITC to not be present before a Loss of VITC alarm condition is raised.

7.4.6. VITC Use Incoming Line

VITC Control
VITC Control
VITC Use Incoming Line
<u>Enable</u>
<u>Disable</u>

This parameter allows the user to utilize existing time code lines or generate new lines.

When set to *Enable*, VITC will be placed on the same lines that the input video signal has VITC on.

When set to *Disable*, VITC will be generated on the two lines select by the VITC Generator.

7.5. VITC Control (HD, +GPI option only)

When operating with a HD video standard, the *VITC Control* tab allows the user to define the handling of VITC timecode when the module is operating with a SD video format.




Figure 7-4: VistaLINK® 7721DE4-HD+GPI VITC Control (HD) View

7.5.1. VITC GPI Delay

VITC Control
VITC Control
VITC GPI Delay
0 - 1023

The *DLAY* menu is used to configure the delay (in frames) between GPIs that are transmitted over VITC. The range of the parameter is 0 to 1023 frames.

The default value is 0 frames of delay between GPIs.

7.5.2. Loss of VITC Duration

VITC Control
VITC Control
Loss of VITC Duration
1 - 60

This parameter determines the number of frames for VITC to not be present before a Loss of VITC alarm condition is raised.

7.6. User VANC Data (+VANC option only)

The *User VANC Data* tab allows the user to configure the VANC packets which will encapsulate serial data. Note that this tab will only be present in modules with the +VANC option installed.

Figure 7-5: VistaLINK® 7721DE4-HD+VANC User VANC Data View

7.6.1. DID

<i>User VANC Data</i>
<i>DSK Trigger Insertion, Serial Embedding Port 1 - 4</i>
<i>DID</i>
<i>0x00 – 0xFF</i>

This parameter selects the DID value for the VANC packet which will encapsulate the data.

7.6.2. SDID

<i>User VANC Data</i>
<i>DSK Trigger Insertion, Serial Embedding Port 1 - 4</i>
<i>SDID</i>
<i>0x00 – 0xFF</i>

This parameter selects the SDID value for the VANC packet which will encapsulate the data.



Take care not to select a reserved DID and SDID value combination. Some common reserved DID values are: 61,01 (captioning); 60,60 (timecode); 41,05 (AFD).

See SMPTE standard 291M for a more detailed listing.

7.6.3. Line Select

User VANC Data
DSK Trigger Insertion, Serial Embedding Port 1 – 4
Line Select
6 – 29

This parameter selects the embed line for the VANC packet which will encapsulate the data.

7.6.4. Trigger Number

User VANC Data
DSK Trigger Insertion
Trigger Number
1 - 255

This parameter selects the trigger number that will be affected by the down stream keyer device.

7.6.5. Cue, Fade In, Out

User VANC Data
DSK Trigger Insertion
Cue, Fade In, Out
Mutually Exclusive Button Select

These parameters select which operation will be affected by the downstream keyer. They are mutually exclusive. Once pressed, the setting becomes active.

7.6.6. Baud Rate

User VANC Data
Serial Embedding Port 1 - 4
Baud Rate
2400
4800
9600
14400
19200
38400
<u>57600</u>
115200

The Baud Rate setting allows the user to set the baud rate of the data sent from the 7721DE4-HD to the 7721DD4-HD.

7.6.7. Parity

<i>User VANC Data</i>
<i>Serial Embedding Port 1 - 4</i>
<i>Baud Rate</i>
<u><i>None</i></u> <i>Even</i> <i>Odd</i>

This parameter sets the parity of the port.

7.6.8. Stop Bits

<i>User VANC Data</i>
<i>Serial Embedding Port 1 - 4</i>
<i>Stop Bits</i>
<u><i>1</i></u> <i>2</i>

This parameter sets the number of stop bits.

7.6.9. Data Bits

<i>User VANC Data</i>
<i>Serial Embedding Port 1 - 4</i>
<i>Data Bits</i>
<i>5</i> <i>6</i> <i>7</i> <u><i>8</i></u>

This parameter sets the data length of the packets being sent.

7.7. Latching GPI (+GPI option only)

The *Latching GPI* tab allows up to two GPI's to be configured as latching GPI's. The GPI selected as latching will be enabled when the set GPI is activated, and disabled when the clear GPI is activated. By setting a GPI as latched, the physical GPI will be ignored.




Figure 7-6: VistaLINK® 7721DE4-HD+GPI Latching GPI View

7.7.1. Latching

Latching GPI
Latching GPI
Latching
Disable
GPI 1 - 6

Allows the user to set a GPI that will be latched. To select no GPI's, set to Disable.

7.7.2. Set

Latching GPI
Latching GPI
Set
GPI 1 - 6

This parameter sets what GPI will enable the latched GPI.

7.7.3. Clear

Latching GPI
Latching GPI
Clear
GPI 1 - 6

This parameter sets what GPI will disable the latched GPI.

7.8. SCTE 104 Settings (+SCTE104 option only)

The *SCTE104 Settings* tab configures the SCTE104 insertion properties of the module. The six GPI's can be enabled to trigger custom SCTE104 message insertions.




Figure 7-7: VistaLINK® 7721DE4-HD+SCTE104 Configuration View

7.8.1. GPI Mode

<i>SCTE 104 Settings</i>
<i>General Settings</i>
<i>GPI Mode</i>
<i>Active Low</i>
<i>Active High</i>

This parameter sets the GPI active condition for the selected GPI.

A selection of *Active Low* will make the GPI's active LO.

A selection of *Active High* will make the GPI's active HI (+5 or 12 V, jumper selectable).

7.8.2. Upstream Pass Mode

<i>SCTE 104 Settings</i>
<i>General Settings</i>
<i>Upstream Pass Mode</i>
<i>Pass Through</i>
<i>Pass Remap</i>

This parameter defines the behavior of the 7721DE4-HD +SCTE104 if SCTE 104 packets are detected on the input.

When set to *Pass Through* and a SCTE 104 packet is detected on the input, they are directly passed to the output on the same detected line.

When set to *Pass Remap*, and a SCTE 104 packet is detected on the input, the original detected packets are marked for deletion as per SMPTE 291M and re-inserted onto a new line defined by the Upstream Line Remap Control.

7.8.3. Upstream Line Remap

<i>SCTE 104 Settings</i>
<i>General Settings</i>
<i>Upstream Line Remap</i>
<i>6 – 29 (11)</i>

This parameter defines which line to re-insert detected SCTE 104 packets. This parameter is only used when the Upstream Pass Mode parameter is set to a value of *Pass Remap*.

7.8.4. GPI Triggering

SCTE 104 Settings
General Settings
GPI Triggering
Enable
<u>Disable</u>

This parameter enables and disables the GPI processor.

When set to *Disable*, any GPI triggering activity will be ignored.

When set to *Enable*, each GPI will trigger a custom configured SCTE 104 packet.

Upon each successful GPI triggered SCTE 104 insertion the 7721DE4-HD+SCTE104 will send an SNMP trap alarm and also illuminate the card edge LED's for a period of approximately 5 seconds.

7.8.5. DPI Filter

SCTE 104 Settings
General Settings
DPI Filter
Enable
<u>Disable</u>

This parameter is used to disable or enable upstream DPI filtering.

When set to *Enable*, any detected upstream SCTE 104 messages will be filtered out.

When set to *Disable*, upstream SCTE 104 messages will pass through. The Upstream Pass Mode setting will be used to define the pass through behavior.

7.8.6. Line Select

SCTE 104 Settings
General Settings
Line Select
6 – 29 (<u>10</u>)

This parameter is used to define the insertion line for SCTE 104 triggers.

7.8.7. Manual DPI Insert

SCTE 104 Settings
General Settings
Manual DPI Insert
Enable
<u>Disable</u>

This parameter is used primarily as a test and debug control.

When set to a value of *Enable*, the 7721DE4-HD+SCTE104 will insert a SCTE 104 message once every 10 seconds. Upon each successful insertion the 7721DE4-HD+SCTE104 will illuminate the card edge LED's for a period of approximately 5 seconds.

When set to a value of *Disable*, no automatic SCTE104 messages will be inserted.

7.8.8. Last Insertion Trigger

SCTE 104 Settings
General Settings
Upstream Line Remap
No Insertions
GPI 1 - 6

This field will display the trigger of the last successfully SCTE 104 insertion.

7.8.9. Custom DID/SDID Mode

SCTE 104 Settings
General Settings
Custom DID/SDID
Enable
Disable

This parameter is used to specify the DID and SDID that will be used for SCTE 104 packets that are inserted into VANC. This feature is often used when equipment that is situated between the encoder and decoder are unable to pass VANC data with the default DID and SDID.

When this parameter is set to *Disable* the standard and default DID of 0x41 and SDID of 0x07 will be used. When set to *Enable* the DID and SDID set by the *DID* and *SDID* controls will be used.

7.8.9.1. DID

SCTE 104 Settings
General Settings
Custom DID/SDID
DID

This parameter is used to set the DID for the SCTE 104 packets that are inserted into VANC. This parameter has a range of 0x01 to 0xFF.

7.8.9.2. SDID

SCTE 104 Settings
General Settings
Custom DID/SDID
SDID

This parameter is used to set the SDID for the SCTE 104 packets that are inserted into VANC. This parameter has a range of 0x01 to 0xFF.

GPI SCTE104 Selection: ☒ GPI 1 ☐ GPI 2 ☐ GPI 3 ☐ GPI 4 ☐ GPI 5 ☐ GPI 6

SCTE 104 - GPI1

GPI Triggering:

Multiple Operation

Reserved:

messageSize:

protocol_version:

AS_Index:

message_number:

DPI_PID_Index:

SCTE35_protocol_version:

num_ops:

Time Type

time_type:

Insert DTMF Descriptor Request Data

☒ Included

opID: data_length:

pre-roll time (tenth):

DTMF_chars:

Insert Segmentation Descriptor Request Data

☒ Included opID: data_length:

segmentation_event_id:

segmentation_event_cancel_indicator:

duration (sec):

segmentation_upid_type:

segmentation_upid_length:

segmentation_upid:

segmentation_type_id:

segment_num:

segments_expected:

duration_extension_frames:

delivery_not_restricted_flag:

web_delivery_allowed_flag:

no_regional_blackout_flag:

archive_allowed_flag:

device_restrictions:

Splice Request Data

☒ Included opID: data_length:

splice_insert_type:

splice_event_source:

splice_event_number:

unique_program_id:

pre_roll_time(ms):

break_duration(tenths):

avail_num:

avails_expected:

auto_return_flag:

Follow Me

☐ Included

Splice Null Request Data

opID: data_length:

Insert Descriptor Request Data

opID: data_length:

descriptor_count:

descriptor_tag:

descriptor_length:

Identifier:

Mode:

Time Signal Request

☒ Included

opID:

data_length:

pre-roll_time(ms):

Figure 7-8: VistaLINK® 7721DE4-HD+SCTE104 Configuration View Continued

7.8.10. GPI SCTE 104 Selection

The *GPI SCTE104* selection allows the user to configure specific SCTE 104 messages that can be inserted using GPI triggers 1 to 6. The SCTE 104 data that is inserted into VANC is constructed of various messages. The messages that are available on the 7721DE4-HD+SCTE104 are just a subset of the ones that are available, but are the ones that are most used within the industry. All messages inserted by the 7721DE4-HD+SCTE104 are multiple operation messages that can contain one or more operations. The operations that are supported are as follows: *Insert DTMF Descriptor Request Data*, *Splice Request Data*, *Insert Segmentation Descriptor Request Data*, *Time Signal Request*, *Insert Tier Data Request* and *Splice Null Request Data*.

The first step in creating a SCTE 104 message for insertion is to enable the *GPI Triggering* control for each respective GPI. Once this is enabled, a multiple operation message is constructed by checking the *Included* checkbox of each operation that is to be included in the message. The tables in sections 7.8.12 to 7.8.18 describe the various parameters within each operation in detail.

7.8.11. GPI Triggering

SCTE 104 Settings
SCTE 104 GPI 1-6
GPI Triggering
<u>Disable</u>
<u>Enable</u>

This parameter is used to enable or disable GPI triggering of the respective SCTE 104 message. When disabled, the respective SCTE 104 message will not be triggered when the GPI is activated.

7.8.12. Multiple Operation Message

Reserved	This parameter is a fixed value and cannot be modified. The reserved parameter is two-byte field and is fixed to a value of 0xFFFF. It will be inserted as the first word in the SCTE 104 packet.
messageSize	The <i>messageSize</i> parameter defines the size of the entire <i>multiple_operation_message()</i> structure in bytes. This parameter is a read-only parameter and the 7721DE4-HD+SCTE104 generates its value dynamically.
protocol_version	The <i>protocol_version</i> is an 8-bit unsigned integer field whose function is to allow, in the future, this message type to carry parameters that may be structured differently than those defined in the current SCTE 104 protocol. It shall be zero (0x00). Non-zero values of <i>protocol_version</i> may be used by future versions of the SCTE 104 standard to indicate structurally different messages. This parameter is a read only parameter.
AS_Index	The <i>AS_index</i> uniquely identifies the source of the message (since it is possible to have several automation systems active at once). The number ranges from 0 to 255 and shall be zero if this index is not required. If non-zero, <i>AS_index</i> shall be unique within a single digital compression system.
message_number	The <i>message_number</i> can be any number in the range 0 to 255 and must be unique for the life of a message. The <i>message_number</i> is used to identify an individual request. This parameter is a read-only parameter and the 7721DE4-HD+SCTE104 generates its value dynamically. Each time a new message is injected, the message number will increment.
DPI_PID_index	The <i>DPI_PID_index</i> specifies the index to the DPI PID, which will carry the splice_info_sections. The number ranges from 0 to 65535. <i>DPI_PID_index</i> shall be zero if not required by the system architecture. This parameter has a range of 0x0000 to 0xFFFF.
SCTE35_protocol_version	An 8-bit unsigned integer field whose function is to allow, in the future, this message type to carry parameters that may be structured differently than those defined in the current protocol. It shall be zero (0x00). Non-zero values of <i>protocol_version</i> may be used by a future version of the SCTE 104 standard to indicate structurally different messages. This parameter is a read only parameter.

timestamp (time_type)	<p>If the value is set to <i>None</i>, then there is no time required and the remainder of the structure is empty. A value of <i>UTC</i> indicates that the time field has been setup for UTC time for triggering a DPI splice_info_section. A value of <i>VITC</i> indicates that the time field has been setup for SMPTE VITC timecode [see Informative Reference 4 of SCTE 104 for more information] for triggering a DPI Splice_info_section. A value of <i>GPI</i> indicates that a GPI input is being used to trigger a DPI splice_info_section.</p> <p>Note: Non-zero values of time_type that are not currently defined are reserved for future standardization. Any message received with a time_type it does not understand should be ignored and an error code of “time type unsupported” returned to the requestor. This error should not occur under normal circumstances, since the protocol_version will need to be increased to support new definitions of time.</p> <p>UTC</p> <ul style="list-style-type: none"> seconds – Elapsed seconds since 12:00 AM UTC January 6, 1980 UTC with the count of intervening leap seconds included. u-seconds – Offset in microseconds of the UTC_seconds field. <p>VITC</p> <ul style="list-style-type: none"> hours – This field encodes the hour of the day in 24-hour time. Values range from 0 to 23. minutes – This field encodes the minute of the hour. Values range from 0 to 59. seconds – This field encodes the seconds of the minute. Values range from 0 to 59. frames – This field encodes the frame within the current second. The range of values changes based upon whether the system is 30 Hz or 25 Hz based video and whether or not the frame rate is actually divided by 1.001. Typical values are 0 to 29 for 30 or 30/1.001 Hz systems, and 0 to 24 for 25 Hz systems. <p>GPI</p> <ul style="list-style-type: none"> the GPI that is used to encode the particular message will automatically be inserted into this field
num_ops	<p>This field defines an integer value that indicates the number of requests contained within the data packet. This parameter has a fixed value that is generated by the 7721DE4-HD+SCTE104.</p>

Table 7-1: SCTE 104 Multiple Operation Parameters

7.8.13. Insert DTMF Descriptor Request Data

opID	The opID is an integer value that indicates what request is being sent. This parameter is fixed to a value of 0x0109, indicating that the <i>insert_DTMF_descriptor_request_data()</i> table is transmitted. This value is fixed and cannot be modified.
data_length	The <i>data_length</i> is the size of the data() field being sent in bytes. This parameter is a read-only parameter and the 7721DE4-HD+SCTE104 generates its value dynamically.
pre-roll_time (tenth)	The pre-roll time encodes the number of tenths of seconds before the splice_point signaled in the resulting SCTE 35 section that a DTMF tone sequence should finish being emitted. To allow for processing time, the pre-roll signaled in the SCTE 35 message should be greater than this value.
DTMF_char(s)	<p>This field carries the characters of a DTMF sequence to be output by an IRD. This field should contain a sequence of the ASCII characters '0' through '9', '*', '#', and 'A' through 'D'. (no lowercase letters) Refer to SCTE 35 for detailed usage of this field.</p> <p>Up to 32 characters can be entered without any spaces in between. The number of characters entered will determine the dtmf_length parameter in the message, which is generated by the 7721DE4-HD+SCTE104 dynamically.</p>

Table 7-2: Insert DTMF Descriptor Request Data Parameters

7.8.14. Splice Request Data

opID	The opID is an integer value that indicates what request is being sent. This parameter is fixed to a value of 0x0101, indicating that the <i>splice_request_data()</i> table is transmitted. This value is fixed and cannot be modified.
data_length	The <i>data_length</i> is the size of the data() field being sent in bytes. This parameter is a read-only parameter and the 7721DE4-HD+SCTE104 generates its value dynamically.
splice_insert_type	<p>The <i>splice_insert_type</i> parameter is an 8-bit unsigned integer defining the type of insertion operation desired. This parameter has 6 possible states: <i>reserved</i>, <i>spliceStart_normal</i>, <i>spliceStart_immediate</i>, <i>spliceEnd_normal</i>, <i>spliceEnd_immediate</i>, and <i>splice_cancel</i>. (The <i>reserved</i> type is undefined by SCTE 104 by is left as a placeholder for future use. It has a value of 0.)</p> <p>Please refer to SCTE 104 for clarification of the inferred values.</p> <p><i>spliceStart_normal</i> section(s) occur at least once before a splice point. This interval should match the requirements of SCTE 35 and serve to set up the actual insertion. It is recommended that if sufficient pre-roll time is given by the AS, the Injector sends several succeeding SCTE 35 <i>splice_info_section()</i> sections (per SCTE 35 and SCTE 67) in response to a single <i>splice_request</i> message with a <i>spliceStart_normal</i></p> <p><i>splice_insert_type</i> value. <i>spliceStart_immediate</i> sections may come once at the splice point's exact location. The Injector shall set the <i>splice_immediate_flag</i> to 1 and the <i>out_of_network_indicator</i> to 1 in the resulting SCTE 35 <i>splice_info_section()</i> section. Usage of "immediate mode" signaling is not recommended by SCTE 35 and may result in inaccurate splices.</p> <p><i>spliceEnd_normal</i> sections come to terminate a splice done without a duration specified.</p> <p>They may also be sent to ensure a splice has terminated on schedule. The Injector sets the <i>out_of_network_indicator</i> to 0. If they are to terminate a <i>spliceStart_normal</i> with no duration specified, they should be sent prior to the minimum interval before the return point and carry a value for <i>pre_roll_time</i>, especially if terminating a long form insertion. <i>spliceEnd_immediate</i> sections come to terminate a current splice before the splice point, or a splice in process earlier than expected. The Injector sets the <i>out_of_network_indicator</i> to 0 and the <i>splice_immediate_flag</i> to 1. The value of <i>pre_roll_time</i> is ignored. <i>splice_cancel</i> sections come to cancel a recently sent <i>spliceStart_normal</i> section. The AS must supply the correct value of <i>splice_event_id</i> for the section to be cancelled. The Injector shall set the <i>splice_event_cancel_indicator</i> to 1.</p>

splice_event_source	The <i>splice_event_source</i> is a user assigned number for the source of a cue message. There are four possible values: 0, 4, 6 and 12. A value of 0 indicates that the source of the cue message is a cue embedded in the original source material. A value of 4 indicates a cue created by automation system switching. A value of 6 defines a cue created by a live event trigger system, and a value of 12 indicates a cue created by a local content replacement system. The <i>splice_event_source</i> and the <i>splice_event_number</i> together define the <i>splice_event_id</i> parameter that is inserted into the SCTE 104 message.
splice_event_number	The <i>splice_event_number</i> is the number chosen by the event source to identify an instance of the cue message. Its value makes up the lower 28 bits of the <i>splice_event_id</i> .
unique_program_id	This parameter is defined as a two-byte parameter and has a possible range of 0 to 65535. According to SCTE 104, the use of this field by servers and splicers is unknown at this time.
pre_roll_time (ms)	The <i>pre_roll_time</i> parameter is a 16-bit field giving the time to the insertion point in milliseconds. This parameter has a possible range of 0 to 65535. This field is ignored for <i>splice_insert_type</i> values other than <i>spliceStart_normal</i> and <i>spliceEnd_normal</i> .
break_duration (tenths)	The <i>break_duration</i> parameter is a 16-bit field giving the duration of the insertion in tenths of seconds. This parameter has a possible range of 0 to 65535. This field is ignored for <i>splice_insert_type</i> values other than <i>spliceStart_normal</i> and <i>spliceStart_immediate</i> .
avail_num	This parameter is an 8-bit field giving identification for a specific avail within the current <i>unique_program_id</i> . The value follows the semantics specified in SCTE 35 for this field. It may be zero to indicate its non-usage. This parameter has a possible range of 0 to 255.
avails_expected	This parameter is an 8-bit field giving a count of the expected number of individual avails within the current viewing event. If zero, it indicates that <i>avail_num</i> has no meaning. This parameter has a possible range of 0 to 255.
auto_return_flag	If this field is non-zero and a non-zero value of <i>break_duration</i> is present, then the <i>auto_return</i> field in the resulting SCTE 35 section will be set to one. This field is ignored for <i>splice_insert_type</i> values other than <i>spliceStart_normal</i> and <i>spliceStart_immediate</i> . Within this implementation this field is fixed to 0x00 and cannot be modified.

Table 7-3: Splice Data Request Parameters

7.8.15. Insert Segmentation Descriptor Request Data

opID	The opID is an integer value that indicates what request is being sent. This parameter is fixed to a value of 0x010B, indicating that the <i>insert_segmentation_descriptor_request_data()</i> table is transmitted. This value is fixed and cannot be modified.
data_length	The <i>data_length</i> is the size of the data() field being sent in bytes. This parameter is a read-only parameter and the 7721DE4-HD+SCTE104 generates its value dynamically.
segmentation_event_id	A 4 byte (32-bit) unique segmentation event identifier. This parameter has a possible range of 0 to 4294967296.
segmentation_event_cancel_indicator	A 1 byte flag that when set to '1' indicates that a previously sent segmentation event, identified by segmentation_event_id, has been cancelled.
duration (sec)	A 2 byte (16-bit) field giving the duration of the program segment in whole seconds. A zero value is legal and results in the segmentation_duration_flag in the resulting SCTE 35 section being set to '0'. See duration_extension_frames. This parameter has a possible range of 0 to 65535.
segmentation_upid_type	A 1 byte field that specifies the type of "UPID" utilized in this program. There are multiple types allowed to insure that programmers will be able to use an id that their systems support. The ones supported by the 7721DE4-HD+SCTE104 are: <i>User Defined, ISCI, Ad-ID, UMID, ISAN, V-ISAN, TID, Turner Identifier (TI) and ADI</i> . Refer to SCTE 35 for full details.
segmentation_upid_length	A 1 byte field that specifies the length in bytes of the segmentation_upid. This parameter is a read-only parameter and the 7721DE4-HD+SCTE104 generates its value dynamically depending on the value entered for the segmentation_upid parameter.
segmentation_upid	A variable-length field that specifies the "UPID" value for this segment. Refer to SCTE 35 for details. This parameter has a possible range of 0 to 32 characters.
segmentation_type_id	A 1 byte field which designates type of segmentation. The values for this field are: <i>Not Indicated, Content Identification, Program Start, Program End, Program Early Termination, Program Breakaway, Program Resumption, Program Runover Planned, Program Runover Unplanned, Program Overlap Start, Chapter Start, Chapter End, Provider Advertisement Start, Provider Advertisement End, Distributor Advertisement Start, Distributor Advertisement End, Placement Opportunity Start, Placement Opportunity End, Unscheduled_event_start and Unscheduled_event_end</i> .
chapter_num	Also known as segment_num. A 1 byte field that provides identification for a specific chapter within a segmentation_upid. Refer to SCTE 35 for full details. This parameter has a possible range of 0 to 255.
chapters_expected	Also known as segments_expected. A 1 byte field that provides a count of the expected number of individual chapters within the current segmentation event. This parameter has a possible range of 0 to 255.

duration_extension_frames	A one byte field that shall carry a value in the range from 0 to the value of the greatest integer less than frame rate, which shall be the number of frames in the fractional second not included in duration. The total duration of the program segment is duration seconds plus duration_extension_frames frame times. If duration is 0 this field carries no meaning. This parameter has a possible range of 0 to 255.
delivery_not_restricted_flag	A one byte flag that when set to 1 indicates there is no need for external checks prior to delivery. A value of 0 indicates the content requires external checks. Refer to SCTE 35 for full details. The values for this field are: <i>Delivery Restricted</i> and <i>Delivery Not Restricted</i> .
web_delivery_allowed_flag	A one byte flag that when set to 1 indicates web delivery is allowed. Refer to SCTE 35 for full details. The values for this field are: <i>Web Delivery Not Allowed</i> and <i>Web Delivery Allowed</i> .
no_regional_blackout_flag	A one byte flag that when set to 1 indicates there is not a regional blackout. Refer to SCTE 35 for full details. The values for this field are: <i>Regional Blackout Active</i> and <i>No Regional Blackout</i> .
archive_allowed_flag	A one byte flag that when set to 1 indicates the content is archiveable. Refer to SCTE 35 for full details. The values for this field are: <i>Content Not Archiveable</i> and <i>Content Archiveable</i> .
device_restrictions	A 1 byte field which designates type of segmentation and takes values specified in SCTE 35. The values for this field are: <i>Restrict Group 0</i> , <i>Restrict Group 1</i> , <i>Restrict Group 2</i> and <i>No Restrictions</i> . These values represent the hex values 0x00, 0x01, 0x10 and 0x11.

Table 7-4: Insert Segmentation Descriptor Request Data Parameters

7.8.16. Time Signal Request

opID	The opID is an integer value that indicates what request is being sent. This parameter is fixed to a value of 0x0104, indicating that the <i>time_signal_request_data()</i> table is transmitted. This value is fixed and cannot be modified.
data_length	The <i>data_length</i> is the size of the data() field being sent in bytes. This parameter is a read-only parameter and the 7721DE4-HD+SCTE104 generates its value dynamically.
pre-roll_time	<p>The splice splice_info_section may be sent by the automation system well in advance of when it is required. In order to support repeated sending of the same splice_info_section and to support multiple sections being outstanding simultaneously, this request supports the preloading of its parameters. The timestamp() indicates the time to process the splice_info_section. The pre-roll field indicates the amount of time, in milliseconds, after being processed that the action will occur. For the time_signal_request() this is the pre-roll for the associated descriptors. If this request arrives after the indicated time, the splice_info_section is sent as soon as possible.</p> <p>The timestamp field can indicate immediate processing (and therefore uses relative timing) or delayed processing (which uses exact timing). In all cases, the signaling point is calculated relative to the time the Request is processed. The pre-roll field determines the exact delay period for the splice point relative to the Request being processed.</p> <p>If this Request is processed immediately on arrival, then the physical insertion of the time signal request is as soon as it is received.</p> <p>In the case of an exact timestamp using a UTC timecode, VITC timecode or GPI triggering, the Request is processed at the indicated time.</p> <p>In the case when a component mode request is used to modify this basic request, the overall pre-roll time is not used. That is, this field is only used when the DPI splice_info_section produced is for a program mode splice. For component mode splicing, each component will have its own time stamp.</p>

Table 7-5: Time Signal Request Parameters

7.8.17. Insert Tier Data Request

opID	The opID is an integer value that indicates what request is being sent. This parameter is fixed to a value of 0x010F, indicating that the <i>insert_tier_data()</i> table is transmitted. This value is fixed and cannot be modified.
data_length	The <i>data_length</i> is the size of the data() field being sent in bytes. This parameter is a read-only parameter and the 7721DE4-HD+SCTE104 generates its value dynamically.
tier_data	A field with the most significant nibble set to 0x0 and containing, in the lower 12-bits, a value with semantics as specified in SCTE 35 [1] for “tier”. This parameter has a range of 0 to 4095.

Table 7-6: Insert Tier Data Request Parameters

7.8.18. Splice Null Request

opID	The opID is an integer value that indicates what request is being sent. This parameter is fixed to a value of 0x0102, indicating that the <i>splice_null_request_data()</i> table is transmitted. This value is fixed and cannot be modified.
data_length	The <i>data_length</i> is the size of the data() field being sent in bytes. This parameter is a read-only parameter and the 7721DE4-HD+SCTE104 generates its value dynamically.

Table 7-7: Splice Null Request Parameters

7.8.19. Follow Me

The *Follow Me* section of the *SCTE 104 Settings* tab is not part of the SCTE 104 standard and should not be used in a standard application. For further questions regarding its use, please contact the factory.

7.9. AFD Control

The *AFD Control* tab allows for the module to insert custom AFD packets in the output video. This can be done statically, via GPI, or conditionally based on the presence of incoming AFD packets.

The screenshot displays the configuration interface for the 7721DE4-HD module. The 'AFD Control' tab is selected, showing the following settings:

- AFD Setup Entry:**
 - AFD Embed Mode:**
 - ☒ **Pass Through** - Always pass through upstream AFD flags.
 - ☐ **Block** - Block upstream AFD flags only.
 - ☐ **Static AFD Insertion** - Block upstream AFD flags and always insert static AFD flags. (Ignore GPI activity.)
 - ☐ **Check and Insert** - If upstream AFD flag detected then pass through. Otherwise insert static AFD flags. (Ignore GPI activity.)
 - ☐ **GPI Controlled AFD Insertion** - If GPI active then insert corresponding AFD flags. Otherwise pass through any upstream AFD flags.
 - ☐ **GPI Controlled Check and Insert** - If GPI active and upstream AFD flag detected then pass through. If GPI active and upstream AFD flag not detected then insert corresponding AFD flags. If GPI not active and upstream AFD flag detected then pass through. If GPI not active and upstream AFD flag not detected then insert static AFD flags.
 - AFD Embed Line:** 12
- Static AFD Insertion:**
 - Aspect Ratio:** ☒ 4 x 3 ☐ 16 x 9
 - AFD Code:** 0000
 - AFD Bar Setting:** ☒ Pillar Box ☐ Letter Box
 - AFD Bar Size 1:** 0
 - AFD Bar Size 2:** 1279
- AFD Reserved Data Word:**
 - Enabling:** ☒ Disable ☐ Enable
 - Bits:** 7,6,5,4 and 3,2,1,0
 - Reserved Data Word 2:** 0000
 - Reserved Data Word 3:** 0000
- Dynamic GPI Control:**
 - GPI 1:**
 - GPI Mode:** ☒ Disable ☐ Active Low ☐ Active High
 - Aspect Ratio:** ☒ 4 x 3 ☐ 16 x 9
 - AFD Code:** 0000
 - AFD Bar Setting:** ☒ Pillar Box ☐ Letter Box
 - AFD Bar Size 1:** 0
 - AFD Bar Size 2:** 1919
 - GPI 2:**
 - GPI Mode:** ☒ Disable ☐ Active Low ☐ Active High
 - Aspect Ratio:** ☒ 4 x 3 ☐ 16 x 9
 - AFD Code:** 0000
 - AFD Bar Setting:** ☒ Pillar Box ☐ Letter Box
 - AFD Bar Size 1:** 0
 - AFD Bar Size 2:** 1919

Figure 7-9: VistaLINK® 7721DE4-HD AFD Control View

7.9.1. AFD Embed Mode

AFD Control
AFD Setup Entry
AFD Embed Mode
Pass Through
Block
Static AFD Insertion
Check and Insert
GPI Controlled AFD Insertion
GPI Controlled Check and Insert

This parameter sets the AFD embedding mode.

Selecting *Pass Through* will pass through existing AFD codes.

Selecting *Block* will erase any incoming AFD codes.

Selecting *Static AFD Insertion* will allow static AFD insertion while block incoming AFD.

Selecting *Check and Insert* will perform a check and insert. If AFD is present, it will be passed through. If it is not present, then a static AFD code will be inserted.

Selecting *GPI Controlled AFD Insertion* or *GPI Controlled Check and Insert* will perform GPI controlled functionality of the *Static AFD Insertion* or *Check and Insert* commands respectively. When the GPI is active, the commands will be the same as the *Static AFD Insertion* or *Check and Insert* commands. When it is inactive, incoming AFD will be passed-through.

7.9.2. AFD Embed Line

AFD Control
AFD Setup Entry
AFD Embed Line
7 – 24 (12)

This parameter sets which line AFD packets will be embedded on. Line 12 is the default.

7.9.3. Aspect Ratio

AFD Control
Static AFD Insertion, Dynamic AFD Insertion: GPI 1 - 6
Aspect Ratio
4 x 3 16 x 9

This parameter sets whether the original frame is 4:3 or 16:9 aspect ratio coded.

A selection of 4 x 3 will choose AFD codes from the 4:3 selections.

A selection of 16 x 9 will choose AFD codes from the 16:9 selections.

7.9.4. AFD Code

AFD Control	
Static AFD Insertion, Dynamic AFD Insertion: GPI 1 - 6	
AFD Code	
<u>0000</u>	
0010	
0011	
0100	
1000	
1001	
1010	
1011	
1101	
1110	
1111	

Sets the AFD code that is inserted. Refer to Figure 7-9 for a visualization of each code. These codes are used in conjunction with the *Aspect Ratio* parameter, detailed in Section 7.9.3.

Original 4:3 coded frame	Original 16:9 coded frame
<p>0000 Undefined -Code 0000 indicates that information is unavailable, therefore video equipment should interpret active format the same as coded frame unless 'bar data' is available. -May not be supported worldwide. -Should be used with caution</p>	<p>0000 Undefined -Code 0000 indicates that information is unavailable, therefore video equipment should interpret active format the same as coded frame unless 'bar data' is available. -May not be supported worldwide. -Should be used with caution</p>
<p>0010 16:9 image at top of frame -May not be supported worldwide. -Should be used with caution</p>	<p>0010 16:9 image Same as coded frame -For a 16:9 frame, AFD code 0010 resulted in the same image as AFD code 1000, therefore code 1000 is preferred coding in such cases.</p>
<p>0011 14:9 image at top of frame -May not be supported worldwide. -Should be used with caution</p>	<p>0011 14:9 image Same as coded frame -For a 16:9 frame, AFD code 0011 resulted in the same image as AFD code 1011, therefore code 1000 is preferred coding in such cases.</p>
<p>0100 Wider than 16:9 image centered in frame -Bar data should always be associated with AFD code 0100 to signal the exact size of letterbox bars. -May not be supported worldwide. -Should be used with caution</p>	<p>0100 Wider than 16:9 image centered in frame -Bar data should always be associated with AFD code 0100 to signal the exact size of letterbox bars. -May not be supported worldwide. -Should be used with caution</p>
<p>1000 Full frame image Same as coded frame</p>	<p>1000 Full frame image Same as coded frame</p>
<p>1001 4:3 image centered in frame -For a 4:3 frame, AFD code 1001 resulted in the same image as AFD code 1000, therefore code 1000 is preferred coding in such cases.</p>	<p>1001 4:3 image centered in frame</p>
<p>1010 16:9 image centered in frame -All image area is protected, therefore cropping is not allowed and only letterbox format can be used.</p>	<p>1010 16:9 image full frame -All image area is protected, therefore cropping is not allowed.</p>
<p>1011 14:9 image centered in frame</p>	<p>1011 14:9 image centered in frame</p>
<p>1101 4:3 image with alternative 14:9 center cut -14:9 image area is protected -Visual information outside protected area may be cropped with minimum impact for the viewer.</p>	<p>1101 4:3 image with alternative 14:9 center cut -14:9 image area is protected -Visual information outside protected area may be cropped with minimum impact for the viewer.</p>
<p>1110 16:9 image with alternative 14:9 center cut -14:9 image area is protected -Visual information outside protected area may be cropped with minimum impact for the viewer.</p>	<p>1110 16:9 image with alternative 14:9 center cut -14:9 image area is protected -Visual information outside protected area may be cropped with minimum impact for the viewer.</p>
<p>1111 16:9 image with alternative 4:3 center cut -4:3 image area is protected -Visual information outside protected area may be cropped with minimum impact for the viewer.</p>	<p>1111 16:9 image with alternative 4:3 center cut -4:3 image area is protected -Visual information outside protected area may be cropped with minimum impact for the viewer.</p>

Figure 7-10: AFD Control Codes

7.9.5. AFD Bar Setting

AFD Control
Static AFD Insertion, Dynamic AFD Insertion: GPI 1 - 6
AFD Bar Setting
<u>Pillar Box</u> Letter Box

This parameter sets the type of bars that are on the picture when using bar data.

A selection of *Pillar Box* will be valid for video that has bars on the sides.

A selection of *Letter Box* will be valid for video that has bars on the top and bottom.

7.9.6. AFD Bar Size 1

AFD Control
Static AFD Insertion, Dynamic AFD Insertion: GPI 1 - 6
AFD Bar Size 1
Line select, dependent on standard

This parameter sets the size of the first bar, as selected under Bar Type.

The values available in this field will depend on the input video format.

7.9.7. AFD Bar Size 2

AFD Control
Static AFD Insertion, Dynamic AFD Insertion: GPI 1 - 6
AFD Bar Size 2
Line select, dependent on standard

This parameter sets the size of the first bar, as selected under Bar Type.

The values available in this field will depend on the input video format.

7.9.8. GPI Mode

AFD Control
Dynamic AFD Insertion: GPI 1 - 6
GPI Mode
<u>None</u> Low High

This parameter sets the GPI active condition for the selected GPI.

A selection of *None* will disable the GPI for AFD insertion.

A selection of *Low* will make the GPI active LO.

A selection if *High* will make the GPI active HI (+5 or 12 V, jumper selectable).

7.9.9. AFD Reserved Data Word

7.9.9.1. Enabling

AFD Control
AFD Reserved Data Word
Enabling
<u>Disable</u>
Enable

This parameter sets the state of the AFD Reserved Data Words. When enabled, the reserved words will be set by the following commands.

7.9.9.2. Reserved Data Word

AFD Control
AFD Reserved Data Word
Reserved Data Word 2-3
0000 - 1111

These parameters set the value of the AFD Reserved Data Words.

Upstream AFD Code Swap			
AFD Code Swap <input checked="" type="radio"/> Disable <input type="radio"/> Enable			
0000 -->	0000	0001 -->	0000
0100 -->	0100	0101 -->	0000
1000 -->	1000	1001 -->	1001
1100 -->	0000	1101 -->	1101
0010 -->	0010	0110 -->	0000
0011 -->	0011	1010 -->	1010
0111 -->	0000	1011 -->	1011
1110 -->	1110	1111 -->	1111

Figure 7-11: VistaLINK[®] 7721DE4-HD Upstream AFD Code Swap Settings

7.9.10. AFD Upstream Code Swap

The AFD Upstream Code Swap is used to remap incoming AFD codes. This is primarily used to correct known, systematic mistakes in upstream code stamping.

7.9.10.1. Enabling

AFD Control
Upstream AFD Code Swap
Enabling
<u>Disable</u>
Enable

This parameter sets the state of the AFD remapping. When enabled, AFD codes will be remapped as per the table below.

7.9.10.2. Reserved Data Word

AFD Control
Upstream AFD Code Swap
0000-1111
0000 - 1111

These parameters set the AFD value to remap to.

7.10. Fault Traps

The *Fault Traps* tab contains the state of all the alarms on the module. Note that not all the below alarms are present for all permutations of the module (i.e. VITC present will not be on modules without +GPI option, or with +GPI option but HD video present).



Some traps may change state quicker than Auto Refresh can detect, such as a quick GPI or SCTE104 insertion. For accurate monitoring, look for the actual trap being sent from the module.

Misc Control	VITC Control	SCTE 104 Settings	AFD Control	User VANC Data	Latching GPI	Fault Traps
<div> <div> Trap Enable <input checked="" type="checkbox"/> Input Video Presence <input checked="" type="checkbox"/> VITC Presence <input checked="" type="checkbox"/> SCTE 104 Message Inserted <input type="checkbox"/> DSK Trigger Insertion </div> <div> Trap Status <div> <input checked="" type="checkbox"/> Input Video Presence <input checked="" type="checkbox"/> VITC Presence <input checked="" type="checkbox"/> RP 188 Presence <input checked="" type="checkbox"/> SCTE 104 Message Inserted <input checked="" type="checkbox"/> DSK Trigger Insertion </div> </div> </div>						
<div> <div> GPI Trap Enable <input checked="" type="checkbox"/> GPI 1 <input checked="" type="checkbox"/> GPI 2 <input checked="" type="checkbox"/> GPI 3 <input checked="" type="checkbox"/> GPI 4 <input checked="" type="checkbox"/> GPI 5 <input checked="" type="checkbox"/> GPI 6 </div> <div> GPI Trap Status <div> <input checked="" type="checkbox"/> GPI 1 <input checked="" type="checkbox"/> GPI 2 <input checked="" type="checkbox"/> GPI 3 <input checked="" type="checkbox"/> GPI 4 <input checked="" type="checkbox"/> GPI 5 <input checked="" type="checkbox"/> GPI 6 </div> </div> </div>						
<div> <div> Audio Group Traps Enable <input checked="" type="checkbox"/> Audio Group 1 Presence <input checked="" type="checkbox"/> Audio Group 2 Presence <input checked="" type="checkbox"/> Audio Group 3 Presence <input checked="" type="checkbox"/> Audio Group 4 Presence </div> <div> Audio Group Traps Status <div> <input checked="" type="checkbox"/> Audio Group 1 Presence <input checked="" type="checkbox"/> Audio Group 2 Presence <input checked="" type="checkbox"/> Audio Group 3 Presence <input checked="" type="checkbox"/> Audio Group 4 Presence </div> </div> </div>						
<div> <div> Serial Data Trap Enable <input checked="" type="checkbox"/> Serial Data 1 Presence <input checked="" type="checkbox"/> Serial Data 2 Presence <input checked="" type="checkbox"/> Serial Data 3 Presence <input checked="" type="checkbox"/> Serial Data 4 Presence </div> <div> Serial Data Trap Status <div> <input checked="" type="checkbox"/> Serial Data 1 Presence <input checked="" type="checkbox"/> Serial Data 2 Presence <input checked="" type="checkbox"/> Serial Data 3 Presence <input checked="" type="checkbox"/> Serial Data 4 Presence </div> </div> </div>						

Figure 7-12: VistaLINK® 7721DE4-HD Fault Trap View

This page left intentionally blank