9000NCP/9000NCP2 VistaLINK_® Network Control Panel

Instruction Manual

© Copyright 2003-2008

EVERTZ MICROSYSTEMS LTD.

 5288 John Lucas Drive, Burlington, Ontario, Canada, L7L 5Z9

 Phone:
 905-335-3700

 Fax:
 905-335-3573

 Internet:
 Sales:
 sales@evertz.com

 Tech Support:
 service@evertz.com

 Web Page:
 http://www.evertz.com

Version 1.7.3, November 2008

The material contained in this manual consists of information that is the property of Evertz Microsystems and is intended solely for the use of purchasers of the 9000NCP Series. Evertz Microsystems expressly prohibits the use of this manual for any purpose other than the operation of the 9000NCP Series.

All rights reserved. No part of this publication may be reproduced without the express written permission of Evertz Microsystems Ltd. Copies of this guide can be ordered from your Evertz products dealer or from Evertz Microsystems.

IMPORTANT SAFETY INSTRUCTIONS

The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of un-insulated "Dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.
The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (Servicing) instructions in the literature accompanying the product.

- Read these instructions
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water
- Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

WARNING

TO REDUCE THE RISK OF FIRE OR ELECTRIC – SHOCK, DO NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE

WARNING

DO NOT EXPOSE THIS EQUIPMENT TO DRIPPING OR SPLASHING AND ENSURE THAT NO OBJECTS FILLED WITH LIQUIDS ARE PLACED ON THE EQUIPMENT

WARNING

TO COMPLETELY DISCONNECT THIS EQUIPMENT FROM THE AC MAINS, DISCONNECT THE POWER SUPPLY CORD PLUG FROM THE AC RECEPTACLE

WARNING

THE MAINS PLUG OF THE POWER SUPPLY CORD SHALL REMAIN READILY OPERABLE

INFORMATION TO USERS IN EUROPE

<u>NOTE</u>

This equipment with the CE marking complies with both the EMC Directive (2004/108/EC) and the Low Voltage Directive (2006/95/EC) issued by the Commission of the European Community.

Compliance with these directives implies conformity to the following European standards:

- EN60950 Product Safety
- EN55103-1 Electromagnetic Interference Class A (Emission)
- EN55103-2 Electromagnetic Susceptibility (Immunity)

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to the European Union EMC directive. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.



EN60950 Safety EN55103-1: 1996 Emission EN55103-2: 1996 Immunity



EN504192 2005 Waste electrical products should not be disposed of with household waste. Contact your Local Authority for recycling advice

INFORMATION TO USERS IN THE U.S.A.

<u>NOTE</u>

FCC CLASS A DIGITAL DEVICE OR PERIPHERAL

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

WARNING

Changes or Modifications not expressly approved by Evertz Microsystems Ltd. could void the user's authority to operate the equipment.

Use of unshielded plugs or cables may cause radiation interference. Properly shielded interface cables with the shield connected to the chassis ground of the device must be used.

Evertz Microsystems Ltd		This device complies with part 15 of the FCC Rules.
	Tested to comply with	Operation is subject to the following two conditions:
For Home or Office Use	FCC Standards	This device may cause harmful interference, and This device must accept any interference received, including interference that may cause undesired operation.



REVISION HISTORY

REVISION	DESCRIPTION	DATE
0.1	Preliminary version	Mar 03
1.0	First release version	Mar 03
1.1	Added support for 7710UC-HD	Sep 03
1.2	Added support for 7735CEM-X	Oct 03
1.3	Added support for the 7720AM-AES4	Jan 04
1.4	Updated NCP/NCP2, VistaLINK $_{\!\!\rm I\!R}$ PRO and 7742DLY-HD	Feb 04
1.5	Added new NCP2 picture; updated7745FS-HD+P Parameter	Feb 04
1.5a	Minor corrections	Feb 04
1.6	Additional product support: DCDA-HD and other 7700 series	Aug 04
1.7	Updated NCP features and new VistaLINK $_{\ensuremath{\mathbb{R}}}$ Configuration Control	Oct 04
1.7.1	Fixed typos and formatting	Jun 07
1.7.2	Updated safety information	Jul 08
1.7.3	Added VistaLINK description	Nov 08

Information contained in this manual is believed to be accurate and reliable. However, Evertz assumes no responsibility for the use thereof or for the rights of third parties, which may be effected in any way by the use thereof. Any representations in this document concerning performance of Evertz products are for informational use only and are not warranties of future performance, either express or implied. The only warranty offered by Evertz in relation to this product is the Evertz standard limited warranty, stated in the sales contract or order confirmation form.

Although every attempt has been made to accurately describe the features, installation and operation of this product in this manual, no warranty is granted nor liability assumed in relation to any errors or omissions unless specifically undertaken in the Evertz sales contract or order confirmation. Information contained in this manual is periodically updated and changes will be incorporated into subsequent editions. If you encounter an error, please notify Evertz Customer Service department. Evertz reserves the right, without notice or liability, to make changes in equipment design or specifications.



This page left intentionally blank



TABLE OF CONTENTS

1.	OVERVIEW	1
2.	INSTALLATION	3
2	1. CONNECTING THE NETWORK CONTROL PANEL	3
2	.2. POWER SUPPLY	3
2	.3. MOUNTING	3
2	.4. UPGRADING NCP NETWORK CONTROL PANEL FIRMWARE	3
2	.5. SERVICING INSTRUCTIONS	4
	2.5.1. Changing the Fuses	4
3.	SPECIFICATIONS	5
3	.1. SERIAL I/O (COM1)	5
3	.2. ETHERNET INPUT/OUTPUT	5
3	3. ELECTRICAL	5
3	.4. PHYSICAL	5
4.	9000NCP NETWORK CONTROL PANEL	7
4. 4	9000NCP NETWORK CONTROL PANEL	7 7
4. 4	9000NCP NETWORK CONTROL PANEL 1. 9000NCP FRONT PANEL OVERVIEW 4.1.1. Overview of FRAME SELECT Pushbutton	7 7
4. 4	9000NCP NETWORK CONTROL PANEL	7 7 7
4. 4	9000NCP NETWORK CONTROL PANEL 1. 9000NCP FRONT PANEL OVERVIEW 4.1.1. Overview of FRAME SELECT Pushbutton 4.1.2. Overview of the Display Line Selection Pushbutton Tools 4.1.3. Overview of Rotary Control and Pushbutton Tool.	7 7 7 7
4. 4	9000NCP NETWORK CONTROL PANEL 1. 9000NCP FRONT PANEL OVERVIEW 4.1.1. Overview of FRAME SELECT Pushbutton	7 7 7 7 8
4. 4	9000NCP NETWORK CONTROL PANEL 1. 9000NCP FRONT PANEL OVERVIEW 4.1.1. Overview of FRAME SELECT Pushbutton 4.1.2. Overview of the Display Line Selection Pushbutton Tools 4.1.3. Overview of Rotary Control and Pushbutton Tool. 4.1.4. Overview of SETUP Pushbutton 4.1.5. Overview of SELECT Pushbutton 4.1.6. Overview of the PRESET CONFIGURATION Pushbuttons	7 7 7 8 8
4.	9000NCP NETWORK CONTROL PANEL 1. 9000NCP FRONT PANEL OVERVIEW 4.1.1. Overview of FRAME SELECT Pushbutton 4.1.2. Overview of the Display Line Selection Pushbutton Tools. 4.1.3. Overview of Rotary Control and Pushbutton Tool. 4.1.4. Overview of SETUP Pushbutton. 4.1.5. Overview of SELECT Pushbutton. 4.1.6. Overview of the PRESET CONFIGURATION Pushbuttons. 4.1.7. Overview of SHIFT Pushbutton.	7 7 7 7 8 8 8 8
4.	9000NCP NETWORK CONTROL PANEL 1. 9000NCP FRONT PANEL OVERVIEW 4.1.1 Overview of FRAME SELECT Pushbutton	7 7 7 8 8 8 8
4. 4 5.	9000NCP NETWORK CONTROL PANEL 1. 9000NCP FRONT PANEL OVERVIEW 4.1.1. Overview of FRAME SELECT Pushbutton 4.1.2. Overview of the Display Line Selection Pushbutton Tools. 4.1.3. Overview of Rotary Control and Pushbutton Tool. 4.1.4. Overview of SETUP Pushbutton. 4.1.5. Overview of SELECT Pushbutton. 4.1.6. Overview of SELECT Pushbutton. 4.1.7. Overview of SHIFT Pushbutton. 4.1.8. Overview of the PANEL LOCK Pushbutton. 9000NCP2 NETWORK CONTROL PANEL.	7 7 7 8 8 8 8 8
4. 4 5.	9000NCP NETWORK CONTROL PANEL 1. 9000NCP FRONT PANEL OVERVIEW 4.1.1 Overview of FRAME SELECT Pushbutton	7 7 7 8 8 8 8 8
4. 4 5.	9000NCP NETWORK CONTROL PANEL. 1. 9000NCP FRONT PANEL OVERVIEW. 4.1.1. Overview of FRAME SELECT Pushbutton	7 7 7 7 8 8 8 8
4. 4 5.	9000NCP NETWORK CONTROL PANEL. 1. 9000NCP FRONT PANEL OVERVIEW 4.1.1. Overview of FRAME SELECT Pushbutton 4.1.2. Overview of the Display Line Selection Pushbutton Tools. 4.1.3. Overview of Rotary Control and Pushbutton Tool. 4.1.4. Overview of SETUP Pushbutton. 4.1.5. Overview of SELECT Pushbutton. 4.1.6. Overview of SELECT Pushbutton. 4.1.6. Overview of the PRESET CONFIGURATION Pushbuttons. 4.1.7. Overview of SHIFT Pushbutton. 4.1.8. Overview of the PANEL LOCK Pushbutton. 9000NCP2 NETWORK CONTROL PANEL. 1. 9000NCP2 FRONT PANEL OVERVIEW. 5.1.1. Overview of the PRESET CONFIGURATION Pushbuttons. 5.1.2. Overview of Rotary Control and Parameter Selection	7 7 7 7 8 8 8 8
4. 4 5.	9000NCP NETWORK CONTROL PANEL 1. 9000NCP FRONT PANEL OVERVIEW 4.1.1. Overview of FRAME SELECT Pushbutton 4.1.2. Overview of the Display Line Selection Pushbutton Tools 4.1.3. Overview of Rotary Control and Pushbutton Tool. 4.1.4. Overview of SETUP Pushbutton 4.1.5. Overview of SELECT Pushbutton 4.1.6. Overview of SELECT Pushbutton 4.1.7. Overview of SHIFT Pushbutton 4.1.8. Overview of the PANEL LOCK Pushbutton 9000NCP2 NETWORK CONTROL PANEL 1. 9000NCP2 FRONT PANEL OVERVIEW 5.1.1. Overview of the PRESET CONFIGURATION Pushbuttons 5.1.2. Overview of Rotary Control and Parameter Selection 5.1.3. Overview of SETUP Pushbutton	7 7 7 7 8 8 8 8
4. 4 5.	9000NCP NETWORK CONTROL PANEL 1. 9000NCP FRONT PANEL OVERVIEW 4.1.1. Overview of FRAME SELECT Pushbutton 4.1.2. Overview of the Display Line Selection Pushbutton Tools 4.1.3. Overview of Rotary Control and Pushbutton Tool 4.1.4. Overview of SETUP Pushbutton 4.1.5. Overview of SELECT Pushbutton 4.1.6. Overview of SELECT Pushbutton 4.1.7. Overview of SHIFT Pushbutton 4.1.8. Overview of the PANEL LOCK Pushbutton 9000NCP2 NETWORK CONTROL PANEL 1. 9000NCP2 FRONT PANEL OVERVIEW 5.1.1. Overview of the PRESET CONFIGURATION Pushbuttons 5.1.2. Overview of SETUP Pushbutton 5.1.3. Overview of SETUP Pushbutton 5.1.4. Overview of SETUP Pushbutton	7 7 7 8 8 8 8 8
4. 4 5. 5	9000NCP NETWORK CONTROL PANEL 1. 9000NCP FRONT PANEL OVERVIEW 4.1.1. Overview of FRAME SELECT Pushbutton 4.1.2. Overview of the Display Line Selection Pushbutton Tools 4.1.3. Overview of Rotary Control and Pushbutton Tool. 4.1.4. Overview of SETUP Pushbutton 4.1.5. Overview of SELECT Pushbutton 4.1.6. Overview of SELECT Pushbutton 4.1.7. Overview of SHIFT Pushbutton. 4.1.8. Overview of the PRESET CONFIGURATION Pushbuttons 4.1.8. Overview of the PANEL LOCK Pushbutton 9000NCP2 NETWORK CONTROL PANEL 1. 9000NCP2 FRONT PANEL OVERVIEW 5.1.1. Overview of the PRESET CONFIGURATION Pushbuttons. 5.1.2. Overview of Rotary Control and Parameter Selection 5.1.3. Overview of SETUP Pushbutton 5.1.4. Overview of SELECT Pushbutton 5.1.4. Overview of SELECT Pushbutton	7 7 7 7 8 8 8 8



7.1.	WHAT IS VISTALINK® PRO?	13
7.2.	CONFIGURATION USING VISTALINK® PRO	13

Figures:

Figure 1-1: 9000NCP Network Control Panel	1
Figure 1-2: 9000NCP2 Network Control Panel	1
Figure 1-3: 9000NCP2 Network Control Panel	2
Figure 4-1: 9000NCP Front and Rear Views	7
Figure 5-1: 9000NCP2 Front and Rear Views	9
Figure 7-1: Quick Button Access Tab for 9000NCP	14
Figure 7-2: Masking Tab (Common to 9000NCP and 9000NCP2)	15
Figure 7-3: Hardware Configurations Tab (Common to 9000NCP and 9000NCP2)	16
Figure 7-4: Services Tab (Common to 9000NCP and 9000NCP2)	16
Figure 7-5: Manually Added IP Tab (Common to 9000NCP and 9000NCP2)	17
Figure 7-6: Server IP Tab (Common to 9000NCP and 9000NCP2)	17
Figure 7-7: Quick Button Access Tab for 9000NCP2	18
Figure 7-8: Quick Button Access Tab for 9000NCP2 in Split Mode	19

Tables:

Table 6-1: Fuse Ratings	4
-------------------------	---



1. OVERVIEW

The 1RU 9000NCP and 2RU 9000NCP2 VistaLINK® Network Control Panels (NCPs) are low-powered, rack mounted control panel interfaces to VistaLINK® -enabled frames and modules, allowing for real-time selection and configuration control of enabled parameters.

Both NCP units connect to the network via Ethernet, communicating via Simple Network Management Protocol (SNMP). In its simplest network configuration, NCP can be directly connected to a single frame via the frame controller using a cross-over network cable. In advanced systems, multiple NCPs can be connected within the same network, each capable of configuring all addressable parameters in every networked frame, or limited to a certain, user-defined set of frames, cards or parameters. With Evertz's VistaLINK_® PRO server running on the same network, NCP units are further enabled with custom labels, preset quick-access configuration buttons and masking/privilege control.



Figure 1-1: 9000NCP Network Control Panel



Figure 1-2: 9000NCP2 Network Control Panel



9000NCP Features:

- Low power, rack-mountable and compact 1RU control panel
- Single, 4-line, 24 alphanumeric digit per line vacuum fluorescent display (VFD) featuring very high brightness and the widest viewing angles
- 16 (8+Shift Key) illuminated, tactile and full-size quick-access pushbuttons with position and selector rotary control (shaft encoder)
- Built-in Simple Network Management Protocol (SNMP) communication interface over Ethernet connection
- Operational configuration control of key VistaLINK_® enabled product parameters
- Quick-access preset button, frame and card labels, and configuration privilege controls available via VistaLINK_ $\!\!\!\!\!\!_{\otimes}$



Figure 1-3: 9000NCP2 Network Control Panel

9000NCP2 Features:

- Low power, rack-mountable, 2RU control panel
- Two, 4-line, 24 alphanumeric digit per line vacuum fluorescent display (VFD) featuring very high brightness and the widest viewing angles
- 44 illuminated, tactile and full-size quick access pushbuttons with four position and selector rotary controls (shaft encoders)
- Provides convenient and fast configuration access for up to 4 simultaneous proc controls via splitscreen display feature
- Built-in Simple Network Management Protocol (SNMP) communication interface over Ethernet connection
- Operational configuration control of key VistaLINK_® enabled product parameters
- Quick-access preset button, frame and card labels, and configuration privilege controls available via VistaLINK_ $\!\!\!\!\!_{\scriptscriptstyle \mathbb{R}}$

2. INSTALLATION

2.1. CONNECTING THE NETWORK CONTROL PANEL

There are two network connection options available for all NCP panels:

- 1. Using a straight-thru, Cat5 cable, connect one end to the RJ45 port on the rear of the NCP, and the other to a network switch or hub. This connection method is recommended if more than 2 network nodes (beyond the NCP and single frame) are anticipated on the same network.
- 2. Using a cross-over, Cat5 cable, connect one end to the RJ45 port on the rear of the NCP, and the other end directly to the RJ-45 of the connector on the rear panel of the 7700FC Frame Controller. This method is suggested only if one network connection will be used.

In either case, communication between the network panel and frame(s) is through Simple Network Management Protocol (SNMP).

The SERIAL I/O 9 pin D connector (COM1) at the rear of the NCP is for upgrades. COM2 port is currently not available.

2.2. POWER SUPPLY

LINE: Both 9000NCP and 9000NCP2 Network Control Panels have one universal power supply that operates on either 115 Volt / 60 Hz or 230 Volt / 50 Hz AC.

2.3. MOUNTING

VistaLINK_® Network Control Panels are equipped with rack mounting brackets and fit into a standard 19 inch by 1 3/4 inch (483 mm x 45 mm) rack space. The mounting brackets may be removed if rack mounting is not required.

2.4. UPGRADING NCP NETWORK CONTROL PANEL FIRMWARE

The 9000NCP and 9000NCP2 Network Control Panels share the same firmware. The latest version is available on the Evertz website (in the "Downloads" section). Firmware is upgraded through the COM1 serial comm port of either unit using the following instructions:

- Connect PC containing 9000NCP and/or 9000NCP2 binary file to COM1 and enable terminal emulation program (i.e. HyperTerminal)
- Set the terminal emulation parameter to:

Baud	57600
Parity	no
Data bits	8
Stop bits	2
Flow Control	None

- With the comm. port connected and running terminal emulation, apply power to the NCP unit and upon boot-up, hit "CTRL-X" several times simultaneously to interrupt the boot-up process.
- Type "upgrade" at the prompt and <Enter>
- Select "Y" for yes to the upgrade question followed by <Enter>
- Send the binary file using the "X-modem" protocol option
- Upon completion, re-boot the NCP unit



2.5. SERVICING INSTRUCTIONS



CAUTION – These servicing instructions are for use by qualified service personnel only. To reduce risk of electric shock do not perform any servicing instructions in this section of the manual unless you are qualified to do so.

2.5.1. Changing the Fuses



Check that the line fuse is rated for the correct value marked on the rear panel. Never replace with a fuse of greater value.

The fuse holder is located inside the power entry module. To change the fuses, disconnect the line cord from the power entry module and pull out the fuse holder from the power entry module using a small screwdriver. The fuse holder contains two fuses, one for the line and one for the neutral side of the mains connection. Pull out the blown fuse and place a fuse of the correct value in its place. Use slo blo (time delay) 5×20 mm fuses rated for 250 Volts with a current rating of what is shown in Table 2-1. Carefully reinsert the fuse holder into the power entry module.

Model	Fuse Rating
9000NCP	1 amp
9000NCP-2	1 amp

Table 2-1: Fuse Ratings



3. SPECIFICATIONS

3.1. SERIAL I/O (COM1)

Standard:	RS-232
Connector:	Female DB-9
Baud Rate:	57600
Format:	8 bits, no parity, 2 stop bits, no hardware flow control
	(COM2 not available)

3.2. ETHERNET INPUT/OUTPUT

Standard:	IEEE 802.3 (10BaseT), IEEE 8002.3u (100BaseTx)
Connector:	1 RJ45
Cable Requirements	5:
10 Base T:	UTP category 3, 4 or 5 cable up to 328ft/100m (2 pairs)
100 Base Tx:	UTP category 5 cable up to 328ft/100m (2 pairs)

3.3. ELECTRICAL

Voltage:	+ 12VDC
Power:	9 Watts (9000NCP), 11 Watts (9000NCP2)
EMI/RFI:	Complies with FCC Part 15, class A and EU EMC directive.

3.4. PHYSICAL

Size:	9000NCP – 17 1/8" W x 4 3/8" D x 1 ¾" H (435mm x 111mm x 45mm) 9000NCP2 – 17 1/8" W x 4 3/8" D x 3 ½" H (435mm x 111mm x 89mm)
Weight:	9000NCP – 3 lbs. (1.36 kg) 9000NCP2 – 4 lbs. (1.81 kg)

Temperature: 0 to 50 deg. C. (Operating)



This page left intentionally blank

4. 9000NCP NETWORK CONTROL PANEL

The display area consists of a 24 digit alphanumeric display, 8 preset configuration pushbuttons (which, along with the "Shift" key enable up to 16 presets), 4 line select pushbuttons, tactile rotary with pushbutton selection and panel lock. The keypad can be used to select a specific frame, card or parameter being addressed by the NCP and is configurable by the user.



Figure 4-1: 9000NCP Front and Rear Views

4.1. 9000NCP FRONT PANEL OVERVIEW

4.1.1. Overview of FRAME SELECT Pushbutton

The FRAME SELECT button is used to display the top-most or root menu for the NCP. In some newer NCP models, the FRAME SELECT button has been re-labeled to "TOP MENU".

4.1.2. Overview of the Display Line Selection Pushbutton Tools

Line-select pushbuttons allow the user to quickly select the frame, card, channel or parameter corresponding to that pushbutton. Any of the four lines displayed in the VFD is accessed by pressing the corresponding pushbutton to the right of the display. If the desired selection is not within the boundaries of the VFD, the rotary selector knob can be used to scroll up or down to the desired line and then the corresponding pushbutton is used to select and proceed to the next lower menu.

4.1.3. Overview of Rotary Control and Pushbutton Tool

The rotary selector knob can be used to scroll through the top level menus. To make a selection, simply position the cursor over the particular line and press the knob gently towards the unit. This action will allow you to proceed to the next lower menu or parameter setting stage.

Once in the parameter setting stages, rotation of the selector knob selects the value of that parameter. Pressing the knob (shaft encoder) sets the parameter value and returns the screen to the previous menu.



4.1.4. Overview of SETUP Pushbutton

The **SETUP** pushbutton is used in conjunction with the menu and display pushbuttons. This allows the user to exit the current menu item and return to the previous level without saving any changes. The **SETUP** pushbutton is located to the lower-right of the rotary selector knob, below the **SELECT** pushbutton.

4.1.5. Overview of SELECT Pushbutton

The main function of the **SELECT** pushbutton is used to save and send a particular parameter value displayed on screen. The **SELECT** pushbutton is located to the right of the rotary selector knob, above the **SETUP** pushbutton.

4.1.6. Overview of the PRESET CONFIGURATION Pushbuttons

Preset configuration pushbuttons provide quick access to VistaLINK®-enabled frame/card parameters.

To set a Quick-Access Button from the panel:

- 1. Select a frame, card, parameter, service or configuration via the on-screen display menu and shaftencoder.
- 2. Press and hold the specific Quick-Access Preset Button for 3 seconds.
- 3. Upon acceptance of setting, Quick-Access Preset Button's LED will flash for 5 seconds, then remain "on".
- 4. When selected during regular operation, the Preset Button will flash for 5 seconds and the VFD will show the quick-access parameter ready to be configured.



If the selected button continues to flash once a preset configuration has been attempted, this indicates that the corresponding hardware/frame could not be found by the NCP. Subsequently no configuration through this selection is available. Attempt to run a single discovery cycle (see section 6) from the NCP to locate the hardware/frame. If flashing persists, contact Evertz service for further assistance.

4.1.7. Overview of SHIFT Pushbutton

Using the **SHIFT** function in combination with the PRESET CONFIGURATION pushbuttons allows the user to access other pre-configured access settings for an additional 8 inputs. If not selected, the SHIFT LED will remain off and the user can preset configuration buttons 1 to 8. When selected, the SHIFT LED will be on and allow the user to preset buttons 9 to 16.

4.1.8. Overview of the PANEL LOCK Pushbutton

The **PANEL LOCK** pushbutton locks the current front panel setup of the 9000NCP. The panel lock function must be disabled in order to change any settings on the unit. An illuminated LED on the pushbutton indicates panel lock status. The panel lock pushbutton is the right-most pushbutton on the front panel.

5. 9000NCP2 NETWORK CONTROL PANEL

The display area consists of a 24 digit alphanumeric display, 8 preset configuration pushbuttons, 4 line select pushbuttons, tactile rotary with pushbutton selection and panel lock. The keypad can be used to select a specific frame, card or parameter being addressed by the NCP and is configurable by the user.



Figure 5-1: 9000NCP2 Front and Rear Views

5.1. 9000NCP2 FRONT PANEL OVERVIEW

5.1.1. Overview of the PRESET CONFIGURATION Pushbuttons

To set a Quick-Access Button from the panel:

- 1. Select a frame/card parameter via the on-screen display menu and shaft-encoder.
- 2. Press and hold the specific Quick-Access Preset Button for 2 seconds.
- 3. Upon acceptance of setting, Quick-Access Preset Button's LED will flash for 5 seconds, then remain "on".
- 4. When selected during regular operation, the Preset Button will flash for 5 seconds and the VFD will show the quick-access parameter ready to be configured.





If the selected button continues to flash once a preset configuration has been attempted, the corresponding hardware/frame could not be found by the NCP and subsequently no configuration through this selection is available. Attempt to run a single discovery cycle (see section 6) from the NCP to locate the frame/module. If flashing persists, contact Evertz service for further assistance.

5.1.2. Overview of Rotary Control and Parameter Selection

The rotary selector knob is used to scroll through the menus. To make a selection, simply position the highlighted line over the frame, card or parameter and press the knob gently towards the unit. Similarly, the "Select" button for that particular VFD (Left or Right, see diagram) can also be used to make the selection. This action will allow you to proceed to the next lower menu or parameter setting stage.

Once in the parameter setting stages, rotation of the selector knob selects the value of that parameter. Pressing the knob (shaft encoder) sets the parameter value and returns the screen to the previous menu.

Split screen and dual rotary knob control is possible on the 9000NCP2. In this configuration, a particular parameter is selected by the right rotary knob, then transferred (by pressing and holding the right rotary knob for 5 seconds, then releasing) to the left for further configuration. The VFD automatically configures itself for split screen display, and the right rotary knob is now free to access a different parameter from those available. Left rotary knob parameter setting can only be performed by pressing the rotary knob into the unit (there are no "SETUP" and "SELECT" buttons). This is particularly useful when attempting to control multiple proc video and/or audio parameters for a single input channel.

5.1.3. Overview of SETUP Pushbutton

The **SETUP** pushbutton is used in conjunction with the menu and display pushbuttons. This allows the user to exit the current menu item and return to the previous level without saving any changes. The **SETUP** pushbutton is located to the lower-right of the rotary selector knob, below the **SELECT** pushbutton.

5.1.4. Overview of SELECT Pushbutton

The main function of the **SELECT** pushbutton is used to save and send a particular parameter value displayed on screen. The **SELECT** pushbutton is located to the right of the rotary selector knob, above the **SETUP** pushbutton.

6. 9000NCP AND 9000NCP2 CONFIGURATION MENU

When power is applied to the unit, the 9000NCP provides a set-up menu with the following parameters. Once IP addresses have been correctly added, verified and saved, it is suggested that the user perform a "single" discovery cycle (see "Discovery" below) of the existing network to identify VistaLINK_®-enabled frames and cards.

- **<back>:** Conveniently located at the start and end of a menu stack, this menu item allows the user to return to the previous menu for further configuration, if required.
- Network setup: Set the IP address of the NCP unit, its subnet mask, gateway IP and Server IP (IP address of VistaLINK_® PRO Server) and DHCP¹. Once the Server IP address is set, a connection is made between the NCP and VistaLINK_® PRO Server, with the Server providing a full configuration update, including labels, masks and presets to that NCP unit. Once entered, <u>30 seconds are required for the changes to be stored in memory.</u> Please do not power cycle the unit until after the <u>30 second window is expired</u>.
- **Configuration:** If connected to a VistaLINK_® PRO server, this menu option lists all available configurations that can be selected and applied through the NCP. If there is no server connected, this menu option will not display any selectable options.
- **Service:** If connected to a VistaLINK® PRO server, this menu option lists all available services accessed through the NCP or NCP2 unit. This is a convenient tool allowing the user to make the menu selection through commonly used (user configured) service names instead of frames and module identification. If there is no server connected, this menu option will not display any selectable options.
- **Reboot:** A menu option that allows the user a quick way to reboot the NCP/NCP2 unit without unplugging the AC power source from the unit. Options are "yes" and "cancel".
- **Discovery:** This parameter controls the auto-discovery cycle for the NCP unit. Set-up durations include: Off/Single/1 Minute/2 Minutes/5 Minutes/10/15/<u>30</u>/60 Minutes. Factory default discovery cycle is set to 30 minutes. More frequent discovery cycles add to network traffic, therefore, it is suggested that this NCP parameter is set to lower intervals for small networks and longer intervals (or even "Off") for larger networks. Once entered, <u>30 seconds are required</u> for the IP/DHCP changes to be stored in memory. Please do not power cycle the unit until after the <u>30 second window is expired</u>.
- Manually added IP: Menu option to enable link to other frames that exist on other subnets and were not detected through the Discovery process.
- **Remove IP:** Menu option to remove frames from the available list.
- **Request update:** A menu option that allows the user to refresh the NCP menu options based on a forced discovery cycle.

¹ If running the NCP on a DHCP enabled network, set this parameter to "enable" for automatic IP address assignment. If not, select "disable". (Factory default set to "enable".)



This page left intentionally blank



7. CONFIGURING NCP UNITS THROUGH VISTALINK® PRO

7.1. WHAT IS VISTALINK® PRO?

VistaLINK_® is Evertz's remote monitoring and configuration platform which operates over an Ethernet network using Simple Network Management Protocol (SNMP). SNMP is a standard computer network protocol that enables different devices sharing the same network to communicate with each other. VistaLINK_® provides centralized alarm management, which monitors, reports, and logs all incoming alarm events and dispatches alerts to all the VLPro Clients connected to the server. Card configuration through VistaLINK_® PRO can be performed on an individual or multi-card basis using simple copy and paste routines, which reduces the time to configure each module separately. Finally, VistaLINK_® enables the user to configure devices in the network from a central station and receive feedback that the configuration has been carried out.

There are 3 components of SNMP:

- 1. An SNMP manager, also known as a Network Management System (NMS), is a computer running special software that communicates with the devices in the network. Evertz *Vista*LINK_®-C Configuration Utility graphical user interface (GUI), third party or custom manager software may be used to monitor and control Evertz *Vista*LINK_® enabled products.
- 2. Managed devices, (such as 9000NCP control panel), each with a unique address (OID), communicate with the NMS through an SNMP Agent. The 9000NCP communicates directly with the manager using its internal Agent.
- 3. A virtual database known as the Management Information Base (MIB) lists all the variables being controlled, which both the Manager and Agent understand. Please contact Evertz for further information about obtaining a copy of the MIB for interfacing to a third party Manager/NMS.

7.2. CONFIGURATION USING VISTALINK® PRO

The 9000NCP and 9000NCP2 control panels can also be configured through VistaLINK_® PRO as shown below.

Configuration options are separated into tabs, with the following descriptions:

- Quick Access Buttons: Provide the user a simple GUI showing all configurable panel buttons with additional windows containing parameters, configurations and service which can then be assigned to these buttons.
- **Masking:** This menu option limits which frames and/or products are accessible to a particular NCP unit from the available (discovered) list. This option is convenient for applications which only require specific NCP configuration access control to specific areas or services.
- **Hardware Configurations:** From the available, preset "configurations" as shown on the "Configurations" branch of the network tree view, this menu option enables the NCP to select from an available list, which is then displayed on the "Quick Access Buttons" page in the configuration window.

Revision 1.7.3



- **Services:** Menu option to add service quick access from a previously generated service definition. The service is seen in the Service branch of the Navigation tree. If it is visible on this branch but is not available on this tab, this means that the service itself contains elements that are not configurable by this or any NCP unit.
- Manually Added IP: This menu option allows the user to add frame IP addresses from other equipment on a different subnet mask that may have not been detected through the NCP's discovery cycle.
- **Server IP:** This tab allows the user to link an NCP to a VistaLINK_® PRO server to share configuration information. If this item has been set through the NCP itself, the set IP address will be displayed in the specific field.

For further reference, screen shots with captions are provided on the subsequent pages.



Figure 7-1: Quick Button Access Tab for 9000NCP

Quick button access screen for 9000NCP showing configured (green) and available (gray) preset buttons, SET and CLEAR button selection used to save or erase a preset, Shift key to access the next bank of 8 buttons, and 3 windows to select a hardware parameter, configuration or service. Configuration and Service settings are made through the "Hardware Configurations" and "Services" tabs respectively.



To SET a button, first select an unused button from the available list, identify the parameter, configuration or service, then click on "Set Button". To CLEAR a button's preset, select the button then click on the "Clear Button".

The "Set to Value" checkbox is used to set a particular parameter, then have a preset button assign that value whenever it is pressed. To set the value, expand the hardware tree view in the Hardware window, select the module and expand to the parameter level. Double-click on the parameter to show a list of available settings, select one. The "Set to Value" box will be checked and the set value will be shown in the adjacent field.

OTTAWA - VistaLink Pro		
Eile Tree Alarm Configuration Auto	Config Augit Tools Window Help	
'남 🛢 11 🗁 🖏 🗮 🦓 🖉	1 🗉 🕄 🖉 🔍 🥾 🔤 🐘 🐘 🙋 🖉 🐪 ۹	6 % g
Navigation Tree	= 192.168.9.210: NCP Configuration	e ^r d ^r
E Configurations	Quick Access Buttons Masking Hardware Configurations \ 8	Services \ User Added IPs \ Server IP \
KevinTest		Update Masking
NewCTSConfig	NCP Enabled Hardware	Masked Hardware
- 📴 ets	Hardware	Products Masked
est est	192.168.9.232	Hardware
Hardware		
₱- ■ 192.168.9.4		
International		
B 192.188.9.29		
192 168 9 201		
International		
- X Launchables		
Web Control		
E Services		
E CTS-CDM		
CTS1 Service		
B-S NBC (OV1-5)		,
-K OTTAWA		Frames Masked
D-T SUDBURY		- Hardware
B Serv2		
B-T- SignalPath1 B-T- TSN (OV1-4)		
⊕-tstr		
⊜ yeager2		
CDM-A4 - Slot 4		
E- Quattro - Slot 6		
Video B		
Video C		
Quadrant 2		
Quadrant 3	<u>1</u>	

Figure 7-2: Masking Tab (Common to 9000NCP and 9000NCP2)

Select the frames and or module from the left window and then mask using the ">" button. The selected frame or module will appear in the appropriate window to the right. To re-enable this, select the frame or module, then "<". To update the NCP, select the "Update..." button, underneath the tabs. If this selection is not made, configuration changes on the NCP will not take effect.



CTTAWA - VistaLink Pro			
Elle Tree Alarm Configuration AgloConfig Augit Tgols Window Help			
钮 🛯 11 🗁 🖏 🗮 🥱 🖉 🖉	ñ 🗉 🖏 🖉 🔍 🎉 🕸 🐘 😹 🤣 🧶 🐘 %	s c	
Sta Navigation Tree	= 192.168.9.210: NCP Configuration		ក់ព័ 🗵
Configurations	Quick Access Buttons \ Masking ' Hardware Configurations \ Services	User Added IPs Server IP	
- B KevinTest	Update Cr	Infiguration Listing On NCP	,
- NewCTSConfig	Displayable Configurations		NCP Displayed Configurations
- 🛃 ets	Configs	Configs	
- E3 tost	CTSCDM		
Hardware	KevinTest		
192.168.9.4	NewCTSConfig		
III 192.168.9.10	test		
⊕	yeager		
192,168,9,201			
Image: Book and the second			
☐ 3 Launchables			
- Web Control			
E-X Services			
B-T CTS-CDM			
B-T, CTS1 Service			
0-1 NBC (0V1-2)		> <	
-K OTTAWA			
D-X SUDBURY			
B Serv2 B SignalBath1			
E-1 TSN (0V1-4)			
⊕-K mw9			
⊛— testr			
B-1 yeager2			
CDM-A4 - Stot 4			
🖨 🚽 Quattro - Stot 6			
Video B			
Video D			
Quadrant 2			
E Ouadrant 3	p		

Figure 7-3: Hardware Configurations Tab (Common to 9000NCP and 9000NCP2)

Select the configurations from the available list and enable them for NCP configuration by clicking ">". Remove them from the available list by selecting "<". To update the NCP, select the "Update..." button, underneath the tabs. If this selection is not made, configuration changes on the NCP will not take effect.

🛑 OTTAWA - VistaLink Pro			
Elle Tree Alarm Configuration Au	loConfig Au <u>d</u> it T <u>o</u> ols <u>W</u> indow <u>H</u> elp		
🔁 🛢 話 🗂 影林 🕸 🖉	ñ 🗉 🕄 🖉 🔍 🎉 🕸 🐘 😹 🙋 🖗	h 😘 🧐 🕼	
🔠 Navigation Tree	192.168.9.210: NCP Configuration		ታዊ 🗵
Configurations	Quick Access Buttons \ Masking \ Hardware Configuration	s 'Services \User Added IPs \Server IP \	
- KevinTest		Update Service Listing On NCP	
-B NewCTSConfig	Displayable services	NCP Displayed Serv	ices
- 22 cts	Services	Services	
veager	- CTS-CDM	-Serv2	
Hardware	CTS1 Service		
B	SignalPath1		
Image: 192.168.9.10			
B	testr		
- m 192.168.9.201			
192.168.9.210			
⊕ ================================			
- 3 Application			
Vieb Control			
Services			
CTS-CDM			
B-X-MTV (OV1-6)			
B NBC (0V1-2)		> <	
OTTAWA			
B-T. SUDBURY			
B-K TSN (0V1-4)			
⊕ S mw9			
B-Totestr			
B			
CDM-A4 - Slot 4			
🖨 – 🚽 Quattro - Stot 6			
Video R			
Quadrant 1			
Quadrant 2			

Figure 7-4: Services Tab (Common to 9000NCP and 9000NCP2)

Select services from the available list and enable them for NCP configuration by clicking ">". Remove them from the available list by selecting "<". To update the NCP, select the "Update..." button, underneath the tabs. If this selection is not made, configuration changes on the NCP will not take effect.



😴 OTTAWA - VistaLink Pro			
File Tree Alarm Configuration Auto	Config Audit Tools Window Help		
12 🖬 😒 🗁 🖏 🗮 🦓 🖉	1 m 🗈 // N. 🖳 k k 🐰 🖉 🖣	h 4h 4h 🗊	
🐮 Navigation Tree 📃	192.168.9.210: NCP Configuration		ក្រ 🗵
E Configurations	Quick Access Buttons (Masking) Hardware Configuration	Senices User Added IPs Sener IP	
CTSCDM	and second density (manning () manning of the	Dedate Lices Re	
B NewCT9Config		opdate oseries	-
- Z ets	Known Frames	Selecte	d Frames
-B test	192.168.9.44		
🔜 yeager	192.168.9.29		
🖻 📱 Hardware	192.168.9.10		
III 192.168.9.4	192.168.9.232		
⊕-■ 192.168.9.10	192.168.9.201 192.168.9.4		
192.108.8.29			
m 192,168,9,201			
Image: Market Ma Market Market M Market Market Mar Market Market Mark			
🖻 🦹 Launchables			
- X Application			
- R Web Control			
D-C-CTS-CDM			
B-T- CTS1 Service			
Image: MTV (OV1-6)			
B NBC (0V1-2)			
- N OTTAWA			
B-T, SUDBURY			
E SignalPath1			
E-1. TSN (0V1-4)			
⊕—K mw9			
i⊕ – Stestr			
⊖-N yeager2			
■-■ 192,168.9.29			
CUM-A4 - SI0L4			
Video A			
-J Video C			
	>		<
Quadrant 1		Manually add frame I	In selection
Quadrant 3		manualiy add trame t	A00

Figure 7-5: Manually Added IP Tab (Common to 9000NCP and 9000NCP2)

Select, add or remove IP addresses from this tab for NCP interfacing. To update the NCP, select the "Update..." button, underneath the tabs. If this selection is not made, configuration changes on the NCP will not take effect.

🛑 OTTAWA - VistaLink Pro		
File Tree Alarm Configuration Aut	oConfig Au <u>d</u> it Tools <u>W</u> indow <u>H</u> elp	
12: 13 13 Pm 12: 株 14: 27 4	1 m 2) // D. 😹 H: H: J: 22 // 🐪 % % %	
🐏 Navigation Tree	192168 9 210: NCP Configuration	
E B Configurations	Ouick Arease Buttone Machina Hachware Configurations Senices Licer Added IDs Senier IP	
- Z CTSCDM	ance secess potents (washing (Lanaware comparations (Denices (Oser Auted 1: 5) anies in)	
- S KevinTest	VistaLinkPro Server IP Address Update	
- S NewCTSConfig		
B toot		
veager		
Hardware		
D 192.168.9.4		
International		
₽		
B 192.168.9.44		
International		
E		
The Control		
E Carvinas		
B-S- CTS-CDM		
B-C CTS1 Service		
Image: MTV (0V1-6)		
B-S NBC (0V1-2)		
OTTAWA		
SUDBURY		
B Serv2		
0-1- TSN (0V1-4)		
B test		
R-N-veader?		
D = 192.168.9.29		
CDM-A4 - Slot 4		
Quattro - Slot 6		
Video A		
Video B		
Video C		
Video D		
Quadrant 1		
Quadrant 2		

Figure 7-6: Server IP Tab (Common to 9000NCP and 9000NCP2)

Identify the Server that this particular NCP is to link with for configuration updates. To update the NCP, select the "Update..." button. If this selection is not made, configuration changes on the NCP will not take effect. If the Server IP was configured through the NCP unit itself, the IP address will appear in the field.



😑 192.168.9.201 - ¥istaLink Pro			
Elle Tree Alarm Configuration AutoConfig Audit Tools Window Help			
"ස 🗏 🔝 🗁 🗒 🏁 🕱 🧞 🖉	1 • 3. 4 R 1/2 1/2 1/2 1/2 1/2 1/2 1/2 1/2 1/2 1/2		
📇 Navigation Tree	🖬 192 168 9 201 NCP2RU Configuration	8	
🖨 👺 Configurations	Quick Access Buttons \ Macking \ Hardware Configurations \ Services \ User Added IPs \ Server IP \		
	Buttons		
NewCTSConfig			
- 🔁 cts			
test			
yeager	Clear Button 23-4L		
Hardware 192.168.9.4	Leff Display Right Display		
⊕□ □ 192.168.9.10	Set value Set value		
⊕ 192.168.9.29			
192.168.9.210			
		511	
🖻 📲 Launchables	Crear Crear Crear		
Application	Decembers		
CTS-CDM	Hardware B Contigs Services Add to right display CTS-CDM Add to right display		
E CTS1 Service	KevinTest CT81 Service		
	- B NewCTSConfig - Serv2		
	SignalPath1		
	Test Test		
B Serv2			
TSN (OV1-4)			
ti mw9			
⊕ Ttestr			
E yeager2	Add to left display		
CDM-A4 - Slot 4			
🕀 🚽 Quattro - Slot 6			
Video A			
Jideo B			
Video D			
Quadrant 1			
Quadrant 2			

Figure 7-7: Quick Button Access Tab for 9000NCP2

This quick button access screen for 9000NCP2 shows configured (green) and available (gray) preset buttons, SET and CLEAR button selection used to save or erase a preset, Shift key to access the next bank of 22 buttons, and 3 windows to select a hardware parameter, configuration or service. Configuration and Service settings are made through the "Hardware Configurations" and "Services" tabs respectively.

To SET a button, first select an unused button from the available list, identify the parameter, configuration or service, then click on the "Set Button". To CLEAR a button's preset, select the button then click on the "Clear Button".

The "Set to Value" checkbox is used to set a particular parameter, onced selected use a preset button to assign that value whenever it is pressed. To set the value, expand the hardware tree view in the Hardware window, select the module and expand to the parameter level. Double-click on the parameter to show a list of available settings, and then select one. The "Set to Value" box will be checked and the set value will be shown in the adjacent field.

The NCP2 has the additional feature of split screen mode. When selected for "split mode" via the checkbox, up to 4 parameter configurations can be set to the same preset button, as shown in the next figure.



🤔 192.168.9.201 - VistaLink Pro			
<u>File Tree Alarm Configuration Auto</u>	Config Au <u>d</u> it T <u>o</u> ols <u>W</u> indow <u>H</u> elp		
≝ ▣ 11 🗁 ▷ ≈ 13 1⁄2 ⓓ □ 弓 / Q, ■, ▶ ₩ ₩ 22 2 🖷 ≝ ≝ 🦉			
🔁 Navigation Tree 📃	= 192.168.9.201: NCP2RU Configuration		
🖻 🗒 Configurations	Quick Access Buttons \ Masking \ Hardware Configurations \ Services \ Us	er Added IPs \ Server IP \	
	Buttons		
NewCTSConfig	Set Button		
tts			
	14 15 16 17	18 19 20 21 22	
🔜 🕎 yeager	Clear Button	23-40	
🖻 🔛 Hardware	Left Display	Right Display	
ter mm 192.168.9.4	Set value Set value	Set value Set value	
E			
⊕			
·	Clear	Clear	
Annication	Split Mode	Split Mode	
Web Control	Parameters		
🗄 🔨 Services		A Panipag	
🕀 💦 CTS-CDM		CTS-CDM	
E CTS1 Service	📕 🛃 KevinTest	CTS1 Service	
□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□	NewCTSCor	nfig Serv2	
	tts	SignalPath1	
⊕ K SUDBURY	🛁 🔤 test	To mw9 Add to right B display	
⊕ Serv2			
⊕ 💦 SignalPath1			
TSN (0V1-4)			
territy mwg			
B veager2			
₫~~~ 🗰 192.168.9.29		Add to left A' display	
CDM-A4 - Slot 4			
🖻 🚙 Quattro - Slot 6			
Video A		Add to left 'B' display	
Video C			
······ 🚽 Video D			
Quadrant 1			
Quadrant 2			
Video A 			

Figure 7-8: Quick Button Access Tab for 9000NCP2 in Split Mode



This page left intentionally blank



In order to simplify the operation of the VistaLINK_®-enabled modules, the operation from the 9000NCP network control panel has been limited to a subset of the enabled module menu system. Upon start-up, the 9000NCP or 9000NCP2 auto-discovers VistaLINK_®-enabled frames and lists frames and associated cards on the alphanumeric display. The user can then use the rotary control to scroll through the available list of frames and then push the "select" button once the frame has been identified, or use one of four "line-select" pushbuttons adjacent to the right of the display. Similarly, NCP/NCP2 accessible menu items are selected by either rotary or pushbutton control. For specific menu control items and descriptions see the module product manual for complete details.

On all menus, there is one extra selectable item: *Back*. Selecting *Back* through either the rotary knob (shaft encoder) or the pushbutton returns the user to the previous menu.

To adjust any parameter, use the rotary knob to set the specific parameter value, then press in the rotary knob to complete the setting change. For simplicity, NCP/NCP2-controlled parameters and their ranges per VistaLINK_{\otimes}-enabled products are listed in tables below.

This NCP manual corresponds t downloads.	o the following release	es: (consult <u>www.evertz.com</u> for the latest
NCP/NCP2 firmware	7700FC	VistaLINK _® PRO (including VLPRO-C)
2.04	1.14 build 1	10.0.7

For the latest VistaLINK_® controlled modules and parameters accessible through the NCP/NCP Network Control Panels, consult: http://www.evertz.com/products/block/9000NCP-Parameters.pdf.



This page left intentionally blank